

APOLLO SUPPORT DEPARTMENT

RCE-S/C OPERATOR COURSE STUDY GUIDES

CONTRACT NASw-410

31 JULY 1966

ACCEPTANCE CHECKOUT EQUIPMENT - SPACECRAFT

ACE-S/C OPERATOR COURSE STUDY GUIDES

CONTRACT NASw-410

1 August 1966

Apollo Support Department Missile and Space Division General Electric Company Daytona Beach, Florida

TABLE OF STUDY GUIDES

Number

Title

410-0(101)	Introduction to ACE-S/C
410-0 (102)	Positional Notational Numbering Systems
410-0(103)	ACE-S/C Functional Description
410-0(104)	ACE-S/C Physical Description
410-0(105)	Data Entry Equipment
410-0(106)	Data Processing
410-0(107)	Data Transmission and Verification Converter
410-0(108)	Digital Test Command System
410-0(109)	Command Monitor Unit (To Be Supplied)
410-0(110) 🗸	Digital Test Measurement System
410-0(111) V	Data Acquisition
410-0(112)	Display Computer
410-0(113)	Data Transmission, Digital Communications and Control Unit
410-0(114)	Alphanumeric Display System
410-0(114A)	Special Display and Recording Equipment
410-0(115)	Analog and Event Distribution
410-0(116)	Support Equipment

Glossary of Terms

Supplements

FOR TRAINING PURPOSES ONLY

INTRODUCTION TO ACE-S/C

OBJECTIVES

To familiarize the student with ACE-S/C concepts and requirements.

INTRODUCTION

The development of new manned spacecraft systems has increased the complexity of tasks relating to integrated acceptance testing and preflight checkout of complex spacecraft systems and subsystems. The magnitude of the Apollo spacecraft checkout requirements precludes the use of conventional testing methods. The initiation of test stimuli and the analysis of the resulting test data by conventional test equipment and methods would be time consuming, costly, and would reduce the reliability of the test effort because of possible human error.

To minimize these problems, an advanced, integrated checkout and display system, which provides for centralized programed control of spacecraft checkout operations, was developed. This advanced checkout system is called Acceptance Checkout Equipment - Spacecraft (ACE-S/C). The ACE-S/C ground station can accommodate independent subsystem and/or integrated system testing in either manual, semiautomatic, or automatic operational modes. Large quantities of test data can be processed and displayed in real time as well as recorded for post-test analysis.

ACE-S/C PROGRAM OBJECTIVES

The objectives of the ACE-S/C program are to:

- a. Provide advanced checkout and display equipment for MSC. c_0
- b. Provide universal checkout equipment.
- c. Provide optimum man-machine interface.
- d. Provide continuity into future programs.
- e. Insure spacecraft and checkout equipment compatibility.

LOCATIONS OF ACE-S/C EQUIPMENT

ACE-S/C ground stations are installed at the following locations for the purposes indicated:

a. <u>Merritt Island Launch Area (MILA)</u>, <u>Merritt Island</u>, <u>Florida</u> - ACE-S/C will KSC be utilized to conduct the complete range of subsystem and integrated system

testing from receipt of the spacecraft modules through spacecraft/launch vehicle mating and final prelaunch checkout.

- b. <u>Manned Spacecraft Center (MSC), Houston, Texas</u> ACE-S/C will be utilized in the testing of spacecraft and astronauts in simulated space and lunar environments. Reliability assessment data will be derived from extended spacecraft operations at MSC.
- <u>Grumman Aircraft Engineering Corporation (GAEC) Facility, Bethpage</u>, <u>New York</u> - ACE-S/C will be utilized for subsystem and integrated system testing of the Lunar Excursion Module (LEM) during the various stages of factory assembly and checkout.
- d. <u>North American Aviation Corporation (NAA) Facility</u>, <u>Downey</u>, <u>California</u> ACE-S/C will be utilized for subsystem and integrated system testing of the Command Module (CM) and Service Module (SM) during the various stages of factory assembly and checkout.

. . .

ACE-S/C SYSTEMS REQUIREMENT

The ACE-S/C ground station operates in conjunction with the spacecraft during checkout via the Digital Test Command System (DTCS) and the Digital Test Measurement System (DTMS). The DTCS receives, decodes, and converts digital test commands from the ACE-S/C ground station and the DTMS codes and multiplexes the response of the spacecraft subsystems to digital commands for transmission to the ACE-S/C ground station for processing.

The ACE-S/C ground station is divided into three primary areas: the computer room, the control room, and the terminal facility room. The computer room contains the data acquisition subsystem, the computer subsystem, and data transmission equipment. The control room (Figure 1) contains consoles, data display system, and part of the command generation equipment. The terminal facility room contains patching facilities, parts of the command and data display subsystems, and timing equipment.

Specifically the ACE-S/C ground station can perform the following functions:

- a. Provide the control, display, data processing, and recording required to control spacecraft stimuli equipment.
- b. Receive, process, display, and record spacecraft parameter data derived from spacecraft ground and flight telemetry systems.
- c. Provide self-check and calibration capacity for itself and related equipment.



Figure 1. ACE-S/C Control Room

FEATURES OF ACE-S/C

The ACE-S/C system was developed to check out a broad range of complex spacecraft. In its present application ACE-S/C is being utilized to perform the complete range of spacecraft testing from factory checkout to launch. In accomplishing its assigned task in the Apollo program, the ACE-S/C system:

- a. Completely tests integrated systems and independent subsystems.
- b. Provides any desired degree of test automation.
- c. Processes large quantities of data for real-time display.
- d. Adapts to any system or test mode by means of software changes.

The following additional advantages are accrued through the utilization of ACE-S/C:

- a. Provides for astronaut participation and launch control.
- b. Tests across system interfaces.
- c. Uses flight telemetry equipment.
- d. Minimizes cabling by serial transmission of commands and data.
- e. Has built-in self-check capability.

PROGRAM AND INTERFACE REQUIREMENTS

To generate the required command and display computer programs and the appropriate decommutator programs, computer programers must be provided with detailed information concerning the specific command functions assigned to various control consoles, measurement limits, and display devices to be used for the various measurements. This information is provided to the programers in the Test Operation Programing Requirements document. This document takes the form of punched cards and defines the configuration of the ACE-S/C equipment and the content of the computer and decommutator programs.

Upon receipt of the programing requirements, the programers generate an assembly program. This assembly program is used to assemble the test operation program by calling up existing routines and subprograms from the master file or program library tape.

A central program library of official ACE-S/C computer programs, subprograms, and subroutines is maintained. The program library contains a master card file for each program. This file is reproduced into master program magnetic tape, and from these tapes, a working library tape is prepared. The library tape contains all programs, subprograms, and subroutines in common use at a specific ACE-S/C facility. Provisions are made to replace, insert, or delete routines from the library tapes during all phases of operation including test preparation, checkout, and spacecraft test operations.

PERSONNEL REQUIREMENTS

Operator personnel will be supplied by the using agency to man the various operational consoles. These operator personnel will initiate the various tests to be performed by the spacecraft and in turn will evaluate the test results by monitoring the display de-vices located in the control room.

FOR TRAINING PURPOSES ONLY

410-0(102)

POSITIONAL NOTATIONAL NUMBERING SYSTEMS

OBJECTIVES

- 1. To review decimal, binary, and octal numbering systems.
- 2. To teach method of converting from one system to another.

INTRODUCTION

As man emerged from a totally primitive state, his progress was paced by the development of alphabets and number systems. Of the many number systems developed, probably the most commonly used base, or radix, was ten – which you recognize as the basis of the familiar decimal system. Possibly this radix was selected because man has ten fingers and ten toes and it was a natural and familiar concept on which to base a number system.

For the purposes of this course, we will be concerned with three numbering systems: (1) decimal, (2) binary, and (3) octal, having base numbers of 10, 2, and 8, respectively. Emphasis will be placed on the binary system, since its base of two admits only two digits, and this fact adapts it ideally to electronic computational devices.

The history of computing devices goes back several centuries, but it is only in recent years that electronic component development made possible the tremendous speeds and capacity of modern computers. The greatest contributions to this effect were the development of the transistor and the refinement of pulse and digital techniques.

The development of complex computing machines was greatly enhanced by Boolean algebra principles. This practice enabled engineers to mathematically analyze new circuitry prior to fabrication.

Since the decimal numbering system is used by all of us daily, it is very familiar. It consists of ten symbols (0 through 9) and, therefore, has a radix of 10. In a positional, notational system such as the decimal system, each digit of the number is recognized by the position that it occupies. The positional value of the first order in the decimal system is 1; the second is 10; the third is 100, etc. The first-order digit, which has the lowest value, is considered the least significant digit (LSD). The digit that has the

FOR TRAINING PURPOSES ONLY

410-0(102)

FOR TRAINING PURPOSES ONLY

Study Guide

highest value is the most significant digit (MSD). In the decimal number 23, the LSD is represented by the symbol 3 and the MSD by the symbol 2. When counting in a number system, two rules apply. First, each time a count of 1 takes place, the symbol in the first order changes to the next symbol in a repetitive sequence. By adding a 1 to 4 in the decimal system, the symbol changes to 5. Second, each time an order of a number changes from the highest symbol in the system to 0, a count of 1 is sent to the next highest order. For example, adding a 1 to a 9 in the decimal system changes the first order to 0 and adds 1 to the second order, giving numerical 10. Thus, when the positional value that is attached to each decimal order is known, the exact value of each digit in a decimal number can be determined. The procedure, for the decimal number 40,811 is as follows:

1	x	10	=	1	x	1	=	1
1	x	10 ¹	=	1	x	10	=	10
8	x	10 ²	=	8	x	100	=	800
0	x	10 ³	=	0	x	1000	=	0000
4	x	10 ⁴	=	4	x	10000	=	40000
								40811

In summary, the decimal numbering system represents numbers which are a sum of the powers of 10 with each position weighted by a digit between 0 and 9. There are many other numbering systems besides the decimal system. Two of these, the octal and binary, are of special importance because of their application in computational devices.

EXPLANATION

In digital computers the binary system is most commonly used. Binary digits are referred to as "bits." Since only two symbols are used, the radix of the binary system is two. Thus, the binary system represents quantities as a sum of the powers of 2, where each order of 2 is weighted by either the digit 0 or 1. A binary number is interpreted from the least significant digit (LSD) to the most significant digit (MSD) in increasing powers of 2. In binary counting the rotating sequence is 0, 1, 0, 1, 0, ... etc. Thus, a binary word (number) will appear as a series of 1's and 0's where the highest

FOR TRAINING PURPOSES ONLY

order will be larger than other 1's added together. An example of a simple binary count with decimal equivalents is as follows:

Decimal	Binary
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001
10	1010

The decimal number 7 is 0111 in binary. If the LSD (the extreme right-hand bit) is equal to 2 to the 0 power, the second bit is equal to 2 to the 1st power, the third equal to 2 to the 2nd power, and the fourth is equal to 2 to the 3rd power (e.g., 0111_2 can be evaluated as follows:

Su	ım	=	7	
0	x	2 ³	=	<u>0</u>
1	x	2 ²	=	4
1	x	2 ¹	=	2
1	x	20	=	1

therefore, 0111_2 is equal to 7_{10} .

It may be seen now how the highest order 1 is larger than the other 1's added together. If it is desired to know the decimal value of a large binary word, it is necessary only to add the values of the bits where a 1 is present. For example:

Position Value	2 ¹⁰	2 ⁹	2 ⁸	27	2 ⁶	25	2^4	2 ³	2 ²	2 ¹	2°
Binary	0	1	1	0	1	1	1	0	1	0	1
Decimal	0	512	256	128	64	32	16	0	4	02	1

Thus, the binary word 01101110101 represents the decimal equivalent 885.

FOR TRAINING PURPOSES ONLY

410-0(102)

FOR TRAINING PURPOSES ONLY

Study Guide

Whereas the binary system is used in the computer itself, the octal system is generally used for writing data for insertion into the computer. The great advantage of the octal system is the ease with which conversion may be made from and to binary numbers. The octal system is directly related to the binary system, as it represents the sum of the powers of 8, and 8 is the decimal number 2 to the third power (2^3) . In the octal system there are eight symbols: 0, 1, 2, 3, 4, 5, 6, and 7. In octal counting, the rotating sequence is 0, 1, 2, 3, 4, 5, 6, 7, 10, 11, 12, ... etc. Each time the order changes from 7 to 0, the next higher order receives a count of 1. For example, 7 + 1 = 10 in the octal system. The symbols 8 and 9 have no significance in the octal system, as seen in the following chart.

Decimal	Octal	Decimal	Octal
1	1	11	13
2	2	12	14
3	3	13	15
4	4	14	16
5	5	15	17
6	6	16	20
7	7	17	21
8	10	18	22
9	. 11	19	23
10	12	20	24

The use of coded binary in data processing is simpler from a design and cost standpoint and is generally used. Note that the binary number 101010101010 has little significance until it is converted to either a decimal or an octal number. In octal coded binary the 12 bits are broken down into groups of three (101-010-101-010) and then read directly as an octal number (5-2-5-2). This is the octal representation of the binary number and is used to denote addresses, instructions, and operands.

This guide will be concerned with the following three categories of numerical conversions:

- a. Conversion of octal and binary numbers to their decimal equivalents.
- b. Conversion of decimal numbers to either their octal or binary equivalents.
- c. Conversion of octal numbers to binary and binary numbers to octal.

FOR TRAINING PURPOSES ONLY

FOR TRAINING PURPOSES ONLY

For the first two categories, first the general rules are described; then the rules are applied to the octal and binary systems. (Refer to the rules while following the examples.) The third category is a special condition and the two conversions of this category are described, followed by application and explanation.

Conversion of Octal and Binary Numbers to Their Decimal Equivalents

To convert any nondecimal number to its equivalent, carry out the following steps:

- a. Arrange the digits of the number vertically, with the least significant digit at the top of the column and the most significant digit at the bottom.
- b. Note the radix of the nondecimal number and write the radix next to each of the digits of the number.
- c. To each of the radix numbers of step b, apply the decimal exponents 0, 1, 2, 3, etc.
- d. Expand the powers of step c.
- e. In each order multiply the digit of the number together with the expanded powers of step d to obtain the positional value for that digit.
- f. Add all the positional values to obtain the equivalent decimal number.

Following the above rules, the octal number 51043 is converted to its decimal equivalent as follows:

<u>Step a</u>	Steps b and c		<u>Step d</u>	<u>Step e</u> (Step a x Step d)
LSD 3	8 ⁰	=	1	3
4	81	=	8	32
0	8 ²	=	64	0
1	8 ³	=	512	512
MSD 5	8 ⁴	=	4096	20480
1043				Decimal' 21027 (Step f)

410-0(102)

FOR TRAINING PURPOSES ONLY

Study Guide

<u>Step a</u> <u>Ste</u>		Steps b and c	<u>Step d</u>	<u>Step e</u>	
				(Step a) x (Step d)	
LSD	1	2 [°]	1	1	
	1	2 ¹	2	2	
	0	2 ²	4	0	
	1	2 ³	8	8	
	0	2 ⁴	16	0	
	1	2 ⁵	32	32	
MSD	1	2 ⁶	64	64	
				Decimal 107 (Step f)	

Again following the rules, the binary number 1101011 is converted to its decimal equivalent as follows:

Conversion of Decimal Numbers to Either Their Binary or Octal Equivalent

To convert a decimal number to its octal or binary equivalent, carry out the following steps:

- a. Write the decimal number to be converted.
- b. Write the decimal radix of the system to which the decimal number is to be converted.
- c. Divide the decimal number by the radix. This division will result in a quotient and a remainder. Write the quotient below the decimal number and write the remainder to the right of the quotient. The first remainder is the least significant digit of the new number.
- d. Divide the quotient of step c by the radix to obtain a second quotient and a remainder. Place the new quotient beneath the quotient obtained in step c and place the new remainder below the remainder obtained in step c. This remainder is the second order digit of the new number.
- e. Repeat step d over and over again until the quotient of a division is 0. The remainder obtained for this division is the most significant digit of the new number. This completes the conversion.

Following the above rules, the decimal number 21027 is converted to its octal equivalent as follows:

<u>Step b</u>	<u>Step a</u>	<u>Step e</u>
8	21027 2628	3 LSB step c (step a divided by step d)
	328	4
	41	0
	5	1
	0	5 MSD; the octal equivalent is 51043

Following the above rules, the decimal number 107 is converted to its binary equivalent as follows:

<u>Step b</u>	<u>Step a</u>	<u>Step e</u>
2	107	
	53	1 LSD step c (step a divided by step d)
	26	1
	13	0
	06	1
	03	0
	01	1
	0	1 MSD; the binary equivalent is 1101011

Conversion of Binary to Octal/Octal to Binary

If the first eight binary numbers have been memorized, the binary-to-octal and octalto-binary conversions are very easily carried out. To convert a binary number to its octal equivalent, carry out the following steps:

- a. Arrange the binary number in groups of three digits, starting from the rightmost digit. These groups are referred to as triads.
- b. For each triad, write the octal equivalent (which is also the decimal equivalent), treating each triad as if it were an octal order. This gives

FOR TRAINING PURPOSES ONLY

Study Guide

the octal equivalent. Using these steps, the binary number 110011101 converted to its octal equivalent as follows:

Step a:	110	011	101	Binary
Step b:	6	3	5	Octal Equivalent

To convert an octal number to its binary equivalent, the above steps are carried out in reverse as follows:

Step a:	5	3	6	Octal
Step b:	101	011	110	Binary

To show all possible cases, the binary 111, 110, 101, 100, 011, 010, 001, 000 is converted to its octal equivalent as follows:

Step a:	111	110	101	100	011	010	001	000
Step b:	7	6	5	4	3	2	1	0

The four basic arithmetic operations are addition, subtraction, multiplication, and division. In general, all arithmetic operations involve three numbers. One number is the one that is being operated upon. This is generally referred to as the operand. The second number is the one that operates on the operand. This is generally referred to as the operator. The third number is the one produced by the operation. This is called the resultant. For each of the four arithmetic operations there are specific expressions for the general terms operand, operator, and resultant. These, together with the conventional way of writing, are as follows:

General Term

Specific Term

	Addition	Subtraction	Multiplication	Division
Operand:	Augend	Minuend	Multiplican	Dividend
Operator:	Addend	Subtrahend	Multiplier	Divisor
Resultant:	Sum	Difference	Product	Quotient

In practice, the term "operand" is generally used to refer to all of the above. Arithmetic operations are carried out in computers with binary numbers. Each of the four arithmetic operations is discussed in turn.

Binary Addition

Binary addition table:

	0	1	10
0	0	1	10
1	1	10	11
10	10	11	100

To add binary 1101 to 1001, the table is used in the following manner:

a. Arrange the numbers for addition -

b. Take the first order. From the table it can be seen that its sum is 10X. The first order of the sum is 0 and the carry is 1.



c. Take the second order. The sum of the second order is 1 with no carry to the third order.



- d. Take the third order. The sum is 1 with no carry.
 - ↓ 1001 +<u>1101</u> 110
- e. Take the fourth order. The sum is 10. The fourth order sum is 0 with a 1 carry to the 5th order.

↓ 1001 augend +<u>1101</u> addend 10110 sum

When an addition table is not available, the following rules will be helpful.

- 1. 0 + 0 = 02. 1 + 0 = 1
- 3. 1 + 1 = 0 and a 1 to carry to the next highest order.

FOR TRAINING PURPOSES ONLY

410-0(102)

FOR TRAINING PURPOSES ONLY

Binary Subtraction

The subtraction of one binary number from another, 10110 from 11000101, for example, is carried out in the following manner:

a. Arrange the numbers for subtraction -

11000101 minuend - 10110 subtrahend

b. Take the first order. Because the first order minuend is a 1 and the first order subtrahend is a 0, their difference is 1.

				۳
1	100	001	0	1
-	1	01	1	0
				1

- c. Take the second order. Note that because the minuend is a 0 while the subtrahend is a 1, borrowing is required. In the binary system a special rule for borrowing is as follows:
 - 1. Add 10 to the minuend in the order in which borrowing is required (in this case the second order) and then subtract. The result is:



2. Then consider the next higher order minuend. The rule is to change the number (if it is a 1, change it to a 0, and if it is a 0, change it to a 1). Note that, in the latter case, borrowing is done from a 0 to the next higher order, which is impossible; therefore the borrowing process must continue to successive higher orders of the minuend until a 1 is reached. This case is considered in the fourth step. Because the minuend of the next higher order (the third order) is a 1, change it to a 0. The result is then as follows. (Note that no further subtraction can be performed until this is done):

d. Take the third order. As in the second order, borrowing is required.

FOR TRAINING PURPOSES ONLY

Therefore, add 10 to the third order and subtract; the result is as follows:

$$1010
 11000 101
 10110
 111
 111$$

Consider the next higher order, the fourth order. But note that, in this case, because the number is a zero, it is impossible to borrow from the fourth order. Therefore, change the 0 to a 1 and go on to the next higher, or fifth order. As in the fourth order, the number is a 0; therefore, it is necessary to change the 0 to 1 of this order and of the succeeding orders until a 1 is reached. In this example, a 1 exists in the seventh order. Now change that 1 to a 0; the borrowing process is thus complete and the result is then as follows:

 $\begin{array}{c}
0 & 1 & 1 & 1 & 1 & 0 \\
1 & 1 & 0 & 0 & 0 & 1 & 0 & 1 \\
 & 1 & 0 & 1 & 1 & 1 & 0 \\
\end{array}$ minuend

The result can readily be checked by adding the subtrahend to the difference. This addition should equal the minuend.

Complements

The analog of the 10's complement in the binary system is called the 2's complement. This is generated by subtracting the number to be complemented from a power of binary 10. The analog of the 9's complement in the binary system is called the 1's complement. This can be generated by subtracting the number to be complemented from a series of 1's. In practice, the process of generating the 1's complement is very simple. Each bit (binary digit) of the binary number is inverted; each 1 becomes a 0, and each 0 becomes a 1. This is a very easy operation to carry out in computers, and is one of the great advantages of the 1's complement. In computers, the 2's complement is formed by adding a 1 to the 1's complement.

To carry out binary subtraction using complements (example: 11010 subtracted from 101101), perform the following steps:

a. Arrange the numbers for subtraction:

101101 minuend 11010 subtrahend 410-0(102)

FOR TRAINING PURPOSES ONLY

- b. Obtain the 1's complement of the subtrahend by changing each 0 to a 1 and each 1 to a 0. Then add 1 to the 1's complement to obtain the 2's complement.
 - 011010 subtrahend 100101 1's complement of subtrahend $+\frac{1}{100110}$ 2's complement of subtrahend
- c. In the subtraction arrangement, replace the subtrahend with its 2's complement and carry out binary addition.

101101 minuend +<u>100110</u> 2's complement of subtrahend 1010011

d. Drop the extreme left-hand digit 1, the end carry, to obtain the true difference.

1010011 10011 difference

e. Check that this is the correct difference by adding this difference to the original subtrahend. The sum obtained in this manner is equal to the original minuend.

10011difference11010subtrahend101101minuend

Binary Multiplication

The binary multiplication table is presented here:

 $\begin{array}{c|c}
0 & 1 \\
0 & 0 & 0 \\
1 & 0 & 1
\end{array}$

The multiplication of binary 1101 by binary 1011 is carried out in the following manner:

a. Arrange the numbers for multiplication:

1101 multiplicand x1011 multiplier

 b. Carry out the multiplication of the multiplicand by the first-order multiplier. Since the multiplier is 1, there are no carries and the multiplicand need only be transferred to provide the first-order product.

FOR TRAINING PURPOSES ONLY

↓ 1101 multiplicand <u>1011</u> multiplier 1101 first-order product

- c. Carry out the multiplication of the multiplicand by the second-order multiplier. Since the second multiplier order contains a 1, all that is required is that the multiplicand be transferred and shifted one place to the left to provide a second-order product.
 - 1101 multiplicand
 - 1011 multiplier
 - 1101 second-order product
- d. Carry out the multiplication of the multiplicand by the third-order multiplier. Since this order contains a 0, and the multiplicand is not transferred, the resulting order product is 0. Note that, for step e, however, the shift must be accounted for.

1101	multiplicand
x1011	multiplier
1101	first-order product
1101	second-order product
0000	third-order product

e. Carry out the multiplication of the multiplicand by the fourth-order multiplier. Since this order contains a 1, the multiplicand is transferred and shifted to provide the fourth-order product. Note that the third-order shift is also included. (Note that, in a digital machine, only two numbers are added together at any one time; the third number is added to the resulting sum of the first two.)

1101	multiplicand
1011	multiplier
1101	first-order product
1101	second-order product
0000	third-order product
1101	fourth-order product

f. Add the order products to get the final product.

1101	first-order product
1101	second-order product
0000	third-order product
1101	fourth-order product
10001111	final product

In binary multiplication, carries do not arise. The order of multiplication is either by a 0 or by a 1. If it is by a 0, the order product is also 0. If it is by a 1, the order product is the same as the multiplicand. Besides this, all that is necessary in binary multiplication is that each order product be shifted one place to the left. After the order products are suitably shifted, their sum provides the desired final product. The operation of binary multiplication is an add and shift operation.

Study Guide

Binary Division

In binary division note that, in general, there are only two possible cases. Either the divisor will go into the dividend or it will not. If the first case is true, enter a 1 in the quotient. If the second case is true, enter a 0. The next step is to subtract the divisor from the MSB side of the dividend. The resulting difference is then divided again by the divisor, and the appropriate entry is made in the quotient. The above steps are repeated until the desired accuracy is obtained.

The following problem illustrates the paper and pencil method of doing binary division. Divide 11110 by 101 using the following method:

a. Arrange the numbers for division

101 quotient 101 11110 divisor dividend

b. Divide the dividend by the divisor and make the appropriate entry in the quotient.

c. Subtract the divisor from MSB side of dividend:

d. Bring down the next bit from the dividend:

$$\begin{array}{r} 1 \\
101 \\ \hline
11110 \\
\underline{101x} \\
101
\end{array}$$

e. Repeat steps 2, 3, and 4 until the remainder is zero or until the desired accuracy is achieved.

$$\begin{array}{c|c}
 110 \\
 101 & 11110 \\
 \underline{101xx} \\
 101 \\
 \underline{101} \\
 0
\end{array}$$

f. The answer may be checked by multiplying the quotient and divisor to obtain the dividend.

 $\begin{array}{ccc}
101 & \text{divisor} \\
\underline{110} & \text{quotient} \\
1010 \\
\underline{101} \\
11110 & \text{dividend}
\end{array}$

Ordinarily in a digital computer, division is accomplished by sequentially subtracting and shifting. The quotient is then formed by evaluating the difference that is obtained for each subtraction. The machine method will be further developed during the Data Processing Course.



Study Guide

410-0(102)

TABLE OF POWERS OF 2

OCTAL-DECIMAL INTEGER CONVERSION TABLE

			0	1	2	3	4	5	6	7	100		0	1	2	3	4	5	6	7
0000	0000	0000	0000	0001	0002	0003	0004	0005	0006	0007	[0400	0256	0257	0258	0259	0260	0261	0262	0263
to	10	0010	0008	0009	0010	0011	0012	0013	0014	0015		0410	0264	0265	0266	0267	0268	0269	0270	0271
0717	0511	0030	0024	0025	0026	0027	0020	0029	0030	0023		0430	0280	0281	0282	0283	0284	0285	0286	0287
(Uctai)	(Decimal)	0040	0032	0033	0034	0035	0036	0037	0038	0039	122	0440	0288	0289	0290	0291	0292	0293	0294	0295
		0050	0040	0041	0042	0043	0044	0045	0046	0047		0450	0296	0297	0298	0299	0300	0301	0302	0303
Octal	Decimal	0070	0056	0045	0050	0059	0052	0053	0054	0055	10	0470	0312	0313	0314	0315	0316	0305	0318	0319
10000	4096	1000		Acies																
20000	8192	0100	0064	0065	0066	0067	0068	0069	0070	0071		0500	0320	0321	0322	0323	0324	0325	0326	0327
30000	12288	0120	0080	0073	0082	0075	0084	0085	0076	0075	2.1	0520	0326	0325	0338	0339	0340	0333	0342	0343
40000	16384	0130	0088	0089	0090	0091	0092	0093	0094	0095		0530	0344	0345	0346	0347	0348	0349	0350	0351
60000	24576	0140	0096	0097	0098	0099	0100	0101	0102	0103	1	0540	0352	0353	0354	0355	0356	0357	0358	0359
70000	28672	0160	0112	0113	0114	0115	0116	0117	0118	0119	1 and	0560	0368	0369	0302	0303	0372	0373	0374	0375
		0170	0120	0121	0122	0123	0124	0125	0126	0127		0570	0376	0377	0378	0379	0380	0381	0382	0383
		0200	0128	0129	0130	0131	0132	0133	0134	0135		0600	0384	0385	0386	0387	0388	0389	0390	0391
		0210	0136	0137	0138	0139	0140	0141	0142	0143		0610	0392	0393	0394	0395	0396	0397	0398	0399
		0220	0144	0145	0146	0147	0148	0149	0150	0151	1	0620	0400	0401	0402	0403	0404	0405	0406	0407
		0230	0152	0153	0154	0155	0156	0157	0156	0159	233	0630	0408	0409	0410	0419	0412	0413	0414	0415
		0250	0168	0169	0170	0171	0172	0173	0174	0175	1	0650	0424	0425	0426	0427	0428	0429	0430	0431
		0260	0176	0177	0178	0179	0180	0181	0182	0183	400	0660	0432	0433	0434	0435	0436	0437	0438	0439
		0270	0184	0185	0186	0187	0188	0183	0190	0191	1.46	06/0	0440	0441	0442	0443	0444	0445	0440	0441
		0300	0192	0193	0194	0195	0196	0197	0198	0199	1963	0700	0448	0449	0450	0451	0452	0453	0454	0455
		0310	0200	0201	0202	0203	0204	0205	0206	0207	63.8	0710	0456	0457	0458	0459	0460	0461	0462	0463
		0330	0216	0203	0218	0219	0220	0213	0222	0213		0730	0404	0405	0400	0407	0400	0403	0478	0479
		0340	0224	0225	0226	0227	0228	0229	0230	0231	1	0740	0480	0481	0482	0483	0484	0485	0486	0487
		0350	0232	0233	0234	0235	0236	0237	0238	0239	5.37	0750	0488	0489	0490	0491	0492	0493	0494	0495
		0370	0240	0241	0250	0243	0252	0245	0240	0255		0770	0490	0497	0498	0499	0508	0509	0510	0511
			0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7
1000	0512	1000	0	1	2	3 0515	4	5 0517	6 0518	7 0519		1400	0 0768	1 0769	2 0770	3 0771	4 0772	5 0773	6 0774	7 0775
1000 10 1777	0512 to 1023	1000 1010 1020	0 0512 0520 0528	1 0513 0521 0529	2 0514 0522 0530	3 0515 0523 0531	4 0516 0524 0532	5 0517 0525 0533	6 0518 0526 0534	7 0519 0527 0535		1400 1410 1420	0 0768 0776 0784	1 0769 0777 0785	2 0770 0778 0786	3 0771 0779 0787	4 0772 0780 0788	5 0773 0781 0789	6 0774 0782 0790	7 0775 0783 0791
1000 10 1777 (Octal)	0512 to 1023 (Decimal)	1000 1010 1020 1030	0 0512 0520 0528 0536	1 0513 0521 0529 0537	2 0514 0522 0530 0538	3 0515 0523 0531 0539	4 0516 0524 0532 0540	5 0517 0525 0533 0541	6 0518 0526 0534 0542	7 0519 0527 0535 0543		1400 1410 1420 1430	0 0768 0776 0784 0792	1 0769 0777 0785 0793	2 0770 0778 0786 0794	3 0771 0779 0787 0795	4 0772 0780 0788 0796	5 0773 0781 0789 0797	6 0774 0782 0790 0798	7 0775 0783 0791 0799
1000 to 1777 (Octal)	0512 to 1023 (Decimal)	1000 1010 1020 1030 1040	0 0512 0520 0528 0536 0544 0552	1 0513 0521 0529 0537 0545 0553	2 0514 0522 0530 0538 0546 0554	3 0515 0523 0531 0539 0547 0555	4 0516 0524 0532 0540 0548 0548	5 0517 0525 0533 0541 0549 0553	6 0518 0526 0534 0542 0550	7 0519 0527 0535 0543 0551		1400 1410 1420 1430 1440	0 0768 0776 0784 0792 0800	1 0769 0777 0785 0793 0801	2 0770 0778 0786 0794 0802 0810	3 0771 0779 0787 0795 0803 0911	4 0772 0780 0788 0796 0804	5 0773 0781 0789 0797 0805 0912	6 0774 0782 0790 0798 0806 0814	7 0775 0783 0791 0799 0807 0815
1000 to 1777 (Octal)	0512 to 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060	0 0512 0520 0528 0536 0544 0552 0560	1 0513 0521 0529 0537 0545 0553 0561	2 0514 0522 0530 0538 0546 0554 0562	3 0515 0523 0531 0539 0547 0555 0563	4 0516 0524 0532 0540 0548 0556 0564	5 0517 0525 0533 0541 0549 0557 0565	6 0518 0526 0534 0542 0550 0558 0566	7 0519 0527 0535 0543 0551 0559 0567		1400 1410 1420 1430 1440 1450 1460	O 0768 0776 0784 0792 0800 0808 0816	1 0769 0777 0785 0793 0801 0809 0817	2 0770 0778 0786 0794 0802 0810 0818	3 0771 0779 0787 0795 0803 0811 0819	4 0772 0780 0788 0796 0804 0812 0820	5 0773 0781 0789 0797 0805 0813 0821	6 0774 0782 0790 0798 0806 0814 0822	7 0775 0783 0791 0799 0807 0815 0823
1000 10 1777 (Octal)	0512 to 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070	0 0512 0520 0528 0536 0544 0552 0560 0568	1 0513 0521 0529 0537 0545 0553 0561 0569	2 0514 0522 0530 0538 0546 0554 0562 0570	3 0515 0523 0531 0539 0547 0555 0563 0571	4 0516 0524 0532 0540 0548 0556 0564 0572	5 0517 0525 0533 0541 0549 0557 0565 0573	6 0518 0526 0534 0542 0550 0558 0566 0574	7 0519 0527 0535 0543 0551 0559 0567 0575		1400 1410 1420 1430 1440 1450 1460 1470	0 0768 0776 0784 0792 0800 0808 0816 0824	1 0769 0777 0785 0793 0801 0809 0817 0825	2 0770 0778 0786 0794 0802 0810 0818 0826	3 0771 0779 0787 0795 0803 0811 0819 0827	4 0772 0780 0788 0796 0804 0812 0820 0828	5 0773 0781 0789 0797 0805 0813 0821 0829	6 0774 0782 0790 0798 0806 0814 0822 0830	7 0775 0783 0791 0799 0807 0815 0823 0831
1000 to 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070	0 0512 0520 0528 0536 0544 0552 0560 0568 0576	1 0513 0521 0529 0537 0545 0553 0561 0569 0577	2 0514 0522 0530 0538 0546 0554 0562 0570 0578	3 0515 0523 0531 0539 0547 0555 0563 0571 0579	4 0516 0524 0532 0540 0548 0556 0564 0572 0580	5 0517 0525 0533 0541 0549 0557 0565 0573 0565	6 0518 0526 0534 0542 0550 0558 0566 0574 0582	7 0519 0527 0535 0543 0551 0559 0567 0575 0583		1400 1410 1420 1430 1440 1450 1460 1470 1500	0 0768 0776 0784 0792 0800 0808 0816 0824 0832	1 0769 0777 0785 0793 0801 0809 0817 0825 0833	2 0770 0778 0786 0794 0802 0810 0818 0826 0834	3 0771 0779 0787 0795 0803 0811 0819 0827 0835	4 0772 0780 0788 0796 0804 0812 0820 0828 0828	5 0773 0781 0789 0797 0805 0813 0821 0829 0837	6 0774 0782 0790 0798 0806 0814 0822 0830 0838	7 0775 0783 0791 0799 0807 0815 0823 0831 0839
1000 10 1777 (Octal)	0512 to 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070 1100 1110	0 0512 0520 0528 0536 0544 0552 0560 0568 0576 0584	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585	2 0514 0522 0530 0538 0546 0554 0562 0570 0578 0578	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0581 0589	6 0518 0526 0534 0542 0550 0558 0566 0574 0582 0590	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591		1400 1410 1420 1430 1440 1450 1460 1470 1500 1510	0 0768 0776 0784 0792 0800 0808 0816 0824 0832 0840	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0842	3 0771 0779 0787 0795 0803 0811 0819 0827 0835 0843	4 0772 0780 0788 0796 0804 0812 0820 0828 0836 0844	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846	7 0775 0783 0791 0799 0807 0815 0823 0831 0839 0847
1000 to 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070 1100 1110 1120 1130	O 0512 0520 0528 0536 0544 0552 0560 0568 0576 0576 0576 0592 0600	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601	2 0514 0522 0530 0546 0554 0554 0562 0570 0578 0578 0586 0596	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587 0587 0595 0603	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588 0596 0504	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0581 0589 0597 0605	6 0518 0526 0534 0542 0550 0558 0566 0574 0582 0590 0598 0598	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591 0599 0607		1400 1410 1420 1430 1440 1450 1460 1470 1500 1510 1520	0 0768 0776 0784 0792 0800 0808 0816 0824 0832 0832 0832 0840 0848 0856	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0845 0857	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0842 0842 0858	3 0771 0779 0787 0795 0803 0811 0819 0827 0835 0843 0859	4 0772 0780 0788 0796 0804 0812 0820 0828 0836 0836 0836 0844 0850	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0845 0853	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846 0854 0862	7 0775 0783 0791 0799 0807 0815 0823 0831 0839 0847 0853
1000 to 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070 1100 1110 1120 1130 1140	O 0512 0520 0528 0536 0544 0552 0560 0568 0576 0584 0592 0600 0608	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601 0609	2 0514 0522 0530 0538 0546 0554 0562 0570 0578 0578 0586 0594 0602 0610	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587 0595 0603 0611	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588 0598 0598 0604 0612	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0589 0597 0505 0605 0613	6 0518 0526 0534 0542 0550 0558 0566 0574 0582 0590 0598 0506 0606 0614	7 0519 0527 0543 0543 0551 0559 0567 0575 0583 0591 0599 0607 0615		1400 1410 1420 1430 1440 1460 1460 1470 1500 1510 1520 1530 1540	0 0768 0776 0792 0800 0808 0816 0824 0832 0840 0848 0856 0864	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0849 0857 0865	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0826 0834 0834 0836 0836 0850 0856	3 0771 0779 0787 0795 0803 0811 0819 0827 0835 0843 0859 0867	4 0772 0780 0788 0796 0804 0812 0820 0828 0836 0836 0836 0836 0844 0852 0860 0868	5 0773 0781 0797 0805 0813 0821 0829 0837 0845 0853 0861 0869	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846 0854 0854 0854 0852 0870	7 0775 0783 0791 0799 0807 0815 0823 0831 0839 0847 0855 0863 0871
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1050 1060 1070 1100 1110 1120 1130 1140 1150	0 0512 0520 0528 0546 0554 0566 0568 0576 0584 0592 0600 0608 0616	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601 0609 0617 0625	2 0514 0522 0530 0538 0546 0554 0562 0570 0578 0586 0594 0602 0610 0618 0592	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587 0595 0603 0611 0619 0623	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588 0596 0604 0612 0620	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0589 0597 0605 0613 0621 0621	6 0518 0526 0534 0542 0550 0558 0566 0574 0582 0590 0598 0606 0614 0622	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591 0599 0607 0615 0623		1400 1410 1420 1440 1450 1460 1470 1500 1510 1520 1530 1540 1550	O 0768 0776 0784 0792 0800 0808 0816 0824 0832 0840 0848 0856 0864 0872 0872	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0849 0857 0865 0873	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0826 0834 0842 0850 0858 0866 0858	3 0771 0795 0803 0811 0819 0827 0835 0843 0851 0859 0867 0875	4 0772 0780 0786 0804 0812 0820 0828 0828 0836 0844 0852 0860 0868 0869 0868	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0853 0861 0869 0877	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846 0854 0854 0854 0862 0870 0878	7 0775 0783 0791 0799 0805 0823 0831 0839 0847 0855 0863 0871 0879
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1070 1100 1170 1120 1130 1140 1150 1160 1170	0 0512 0520 0528 0546 0544 0552 0560 0568 0576 0584 0592 0600 0608 0616 0624 0632	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601 0609 0617 0625 0633	2 0514 0522 0530 0538 0546 0554 0562 0570 0578 0586 0594 0602 0610 0618 0626 0634	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587 0595 0603 0611 0619 0627 0635	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588 0596 0604 0612 0620 0628 0636	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0589 0597 0605 0613 0621 0629 0637	6 0518 0526 0534 0542 0550 0558 0566 0574 0582 0598 0606 0614 0622 0638	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591 0599 0607 0615 0623 0639		1400 1410 1420 1430 1440 1450 1460 1470 1500 1510 1520 1530 1550 1550 1570	O 0768 0776 0784 0792 0800 0808 0816 0824 0832 0840 0832 0840 0848 0856 0864 0864 0872 0880	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0849 0857 0865 0873 0881 0889	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0842 0850 0858 0866 0874 0882 0890	3 0771 0779 0787 0795 0803 0811 0819 0827 0835 0843 0851 0859 0867 0875 0883	4 0772 0780 0788 0796 0820 0828 0836 0844 0852 0860 0868 0868 0868 0868 0868 0868 086	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0853 0861 0869 0877 0885 0893	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846 0854 0854 0854 0862 0870 0878 0886 0894	7 0775 0783 0791 0799 0815 0823 0831 0839 0847 0855 0863 0871 0879 0887
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1050 1070 1100 1110 1120 1130 1140 1150 1170	0 0512 0520 0528 0536 0544 0552 0560 0568 0576 0584 0592 0600 0608 0616 0624 0632	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601 0609 0617 0625 0633	2 0514 0522 0530 0538 0546 0554 0562 0570 0578 0586 0594 0602 0610 0618 0626 0634	3 0515 0523 0531 0547 0555 0563 0571 0579 0587 0595 0603 0611 0619 0627 0635	4 0516 0524 0532 0540 0548 0556 0564 0572 0580 0588 0596 0604 0612 0620 0628 0636	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0589 0597 0605 0613 0621 0629 0637	6 0518 0526 0534 0542 0558 0566 0574 0582 0590 0598 0606 0614 0620 0638	7 0519 0527 0535 0543 0551 0555 0567 0575 0583 0591 0599 0607 0615 0623 0631 0639		1400 1410 1420 1430 1440 1450 1440 1510 1510 1550 1550 155	O 0768 0776 0792 0800 0808 0816 0824 0832 0840 0832 0840 0848 0856 0864 0856 0864 0872 0880	1 0769 0777 0785 0793 0809 0817 0825 0833 0841 0849 0857 0865 0873 0881 0889	2 0770 0778 0786 0794 0802 0818 0826 0834 0842 0850 0858 0858 0858 0856 0874 0858 0856	3 0771 0795 0803 0811 0819 0827 0835 0843 0851 0859 0867 0875 0883 0891	4 0772 0780 0788 0796 0804 0820 0828 0836 0844 0852 0860 0868 0868 0868 0868 0884 0892	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0853 0861 0869 0877 0885 0893	6 0774 0782 0790 0798 0806 0814 0822 0830 0838 0846 0854 0854 0854 0862 0870 0878 0886 0894	7 0775 0783 0799 0807 0815 0823 0831 0839 0847 0855 0863 0871 0879 0885
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1050 1050 1050 1070 1100 1110 1120 1130 1140 1150 1170 1200 1210	0 0512 0520 0528 0536 0544 0552 0560 0568 0576 0584 0592 0600 0608 0616 0624 0632 0640 0648	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0585 0593 0601 0609 0617 0625 0633 0641 0649	2 0514 0522 0530 0538 0546 0554 0554 0570 0578 0594 0602 0610 0618 0626 0634 06242 0650	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0587 0595 0603 0611 0619 0627 0635 0643 0651	4 0516 0524 0540 0548 0556 0556 0556 0558 0596 0604 0612 0620 0620 0628 0636	5 0517 0525 0533 0541 0549 0557 0557 0557 0557 0558 0557 0605 0613 0621 0621 0621 0623 0621	6 0518 0526 0534 0542 0550 0558 0574 0582 0574 0582 0590 0598 0606 0614 0622 0630 0638 0666 0638	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591 0599 0607 0615 0623 0631 0639 0647 0655		1400 1410 1420 1440 1440 1450 1510 1550 1550 1550 155	O 0768 0776 0792 0800 0808 0816 0824 0832 0840 0848 0856 0864 0856 0864 0872 0888 0888	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0849 0857 0865 0873 0889 0897 0905	2 0770 0778 0786 0794 0802 0810 0818 0826 0834 0826 0834 0858 0858 0858 0858 0858 0858 0858 085	3 0771 0779 0787 0795 0803 0811 0819 0827 0835 0843 0851 0859 0867 0875 0883 0891	4 0772 0780 0786 0804 0820 0828 0836 0836 0836 084 0852 0860 0868 0868 0868 0876 0868 0876 0892	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0853 0861 0869 0877 0885 0893 0891 0901	6 0774 0782 0790 0806 0814 0822 0830 0838 0846 0854 0854 0862 0870 0878 0886 0894	7 0775 0783 0799 0807 0815 0823 0831 0839 0847 0855 0863 0871 0879 0887 0895 0903 0911
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1050 1050 1050 1070 1100 1110 1120 1130 1140 1150 1170 1210 1220	0 0512 0528 0536 0544 0552 0568 0558 0558 0592 0600 0692 0600 0692 0624 0624 0648 0648	1 0513 0521 0529 0537 0545 0569 0569 0657 0693 0601 0609 0617 0625 0633 0641 0649 0657	2 0514 0522 0538 0554 0554 0552 0570 0570 0570 0570 0570 0594 0610 0618 0626 0626 0626 0626 0626 0658	3 0515 0523 0531 0539 0547 0555 0563 0571 0587 0587 0603 0611 0619 0627 0627 0623 0623	4 0516 0524 0542 0540 0544 0556 0596 0596 0696 0698 0698 0698 0698 0698 0698 06	5 0517 0525 0533 0541 0549 0557 0573 0581 0597 0605 0613 0629 0629 0629 0629 0629 0629 0629 0629	6 0518 0526 0542 0550 0558 0566 0574 0582 0598 0698 0698 0698 0698 0638 0638	7 0519 0527 0543 0551 0559 0567 0575 0583 0599 0607 0615 0633 0631 0639 0647 0655 0663		1400 1410 1420 1430 1440 1450 1440 1510 1550 1550 1550 155	0 0768 0776 0792 0800 0808 0816 0824 0832 0840 0848 0856 0864 0872 0880 0888 0866 0864 0872 0880 0888 0896 0904	1 0769 0777 0785 0801 0809 0817 0825 0843 0841 0849 0857 0865 087 0881 0889 0881	2 0770 0778 0786 0892 0810 0826 0826 0826 0826 0850 0850 0850 0850 0850 0850 0850 085	3 0771 0787 0785 0803 0811 0819 0827 0835 0843 0851 0859 0867 0875 0883 0891 0883	4 0772 0780 0786 0894 0812 0820 0828 0828 0828 0828 0844 0852 0860 0852 0860 0852 0868 0876 0884 0852	5 0773 0781 0789 0895 0813 0829 0829 0829 0845 0845 0845 0845 0845 0845 0845 0845	6 0774 0782 0798 0806 0814 0822 0830 0830 0844 0845 0845 0854 0854 0854 0854 085	7 0775 0783 0791 0799 0807 0823 0831 0839 0847 0853 0863 0871 0879 0879 0895 0903 0911 0919
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070 1110 1110 1110 1110 1110 1150 1160 1170 1200 1210 1220 1220	0 0512 0520 0528 0546 0552 0560 0552 0560 0552 0560 0552 0568 0576 0584 0592 0600 0608 0616 0622 0640 0656	1 0513 0529 0537 0545 0553 0553 0553 0553 0553 0553 0553	2 0514 0522 0530 0538 0546 0554 0554 05570 0558 0594 0602 0610 0618 0626 0634 0626 0634	3 0515 0523 0531 0539 0547 0555 0563 0571 0595 0603 0611 0619 0627 0635 0661 0659 0659 0659	4 0516 0524 0542 0540 0540 0548 0556 0556 0557 05580 0596 0659 0629 0628 0628 0626 0628	5 0517 0525 0533 0541 0549 0557 0553 0573 0581 0597 0605 0613 0629 0637 0645 0653 0661 0663	6 0518 0526 0534 0554 0558 0566 0574 0582 0590 0598 0616 0614 0614 0614 0622 0630 0638	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0591 0599 0607 0615 0623 0631 0639 0647 0655		1400 1410 1420 1430 1440 1450 1460 1510 1520 1550 1550 1550 1560 1560 1560 1610 1620 1620	0 0768 07768 07764 0784 0784 0784 0800 0816 0816 0816 0816 0816 0816 0816 0840 0848 0856 0864 0864 0868 0868 0864 0864 0869 0909 000000	1 0769 0777 0785 0793 0801 0809 0807 0841 0849 0855 0873 0865 0865 0865 0865 0865 0865 0865 0865	2 0770 0786 0786 0784 0802 0818 0826 0818 0826 0834 0858 0858 0866 0874 0866 0868 0866 0868 0866 0868 0866 0868 0866 0869 0868 0966 0964 09914 0922	3 0771 0779 0787 0795 0803 0819 0827 0843 0859 0867 0867 0867 0867 0869 0883 0891 0899 0897	4 0772 0780 0786 0796 0804 0812 0820 0820 0820 0828 0836 0844 0852 0868 0868 0868 0868 0868 0868 0868 086	5 0773 0781 0789 0797 0805 0813 0821 0829 0853 0861 0869 0869 0869 0869 0869 0869 0869 0869	6 0774 0782 0790 0798 0806 0814 0822 0830 0854 0854 0856 0856 0859 0870 0878 0886 0894 0902 0910 0918 0926	7 0775 0783 0799 0807 0815 0823 0831 0853 0863 0863 0863 0863 0863 0867 08679 08679 08879 08879 08879 0895
1000 to 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1040 1050 1060 1100 1100 1110 1120 1130 1140 1150 1140 1150 1140 1150 1210 1210 1220 1220	0 0512 0520 0528 0544 0552 0560 0556 0556 0556 0556 0556 0556	1 0513 0529 0537 0545 0553 0553 0553 0553 0553 0553 0553	2 0514 0522 0530 0538 0546 0554 0554 0557 0557 0558 0594 0602 0610 0618 0626 0634 0662 0658 0666 0658	3 0515 0523 0531 0539 0547 0555 0563 0571 0595 0603 0571 0595 0603 0611 0619 0627 0635 0659 0663 0659 06659 06659	4 0516 0524 0532 0540 0552 0550 0554 0556 0564 0556 0564 0588 0596 0604 0612 0620 0628 0636 0636 0660 0668 0660 0668	5 0517 0525 0533 0541 0549 0557 0557 0557 0557 0557 0557 0557 055	6 0518 0526 0534 0554 0556 0566 0574 0582 0590 0598 0606 0614 0622 0630 0638 0664 0652 0662 0662 0662 0662 0662 0662 0662	7 0519 0527 0535 0543 0551 0557 0567 0567 0567 0567 0657 0615 0615 0623 0631 0639 0647 0653 0663 0663		1400 1410 1420 1430 1440 1450 1460 1510 1520 1550 1550 1550 1560 1560 1560 1610 1620 1630	0 0768 0776 0784 0792 0800 0808 0816 0824 0840 0840 0840 0840 0840 0840 0840	1 0769 0777 0785 0785 0785 0785 0785 0785 0785	2 0770 0786 0786 0786 0818 0818 0818 0826 0834 0858 0858 0866 0874 0866 0874 08690 0866 0868 0866 0874 0882 0890	3 0771 0779 0787 0787 0785 0803 0811 0827 0827 0843 0843 0843 0843 0859 0867 0875 0885 0889 0891 0895 0907 0915 0923 0931	4 0772 0780 0786 0786 0804 0812 0820 0820 0820 0828 0836 0844 0852 0868 0868 0868 0868 0868 0868 0868 086	5 0773 0781 0789 0797 0805 0813 0821 0829 0853 0861 0869 0869 0869 0869 0869 0869 0869 0869	6 0774 0782 0790 0790 0804 0814 0822 0830 0854 0854 0854 0856 0870 0870 0870 0870 0870 0870 0870 09894 09912 0918 0918 0918	7 0775 0783 0791 0799 0807 0815 0823 0831 0839 0847 0855 0863 0871 0889 0887 0895 0887 0895 0903 0911 0919 0927 0935
1000 10 177 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1060 1100 1110 1120 1130 1140 1150 1160 1170 1200 1210 1220 1230 1240	0 0512 0520 0528 0536 0544 0552 0560 0558 0556 0558 0552 0584 0552 0680 0616 0624 0632 0640 0646 0656 0656 0656 0656 0658	1 0513 0521 0529 0537 0545 0553 0561 0569 0577 0593 0601 0609 0617 0625 0633 0641 0649 0657 0655 0653	2 0514 0522 0530 0546 0554 0554 0554 0554 0554 0554 0659 0610 0618 0618 0618 0618 0618 0618 0658 0658 0654 0659	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0595 0603 0611 0619 0627 0635 0663 0659 06659 06659 06659 06653	4 0516 0524 0532 0540 0552 0556 0556 0556 0556 0556 0556 055	5 0517 0525 0533 0541 0549 0557 0557 0557 0557 0557 0557 0557 055	6 0518 0526 0534 0542 0558 0558 0558 0558 0558 0598 0606 0614 0622 0630 0622 0630 0622 0630 0622 0670 0628	7 0519 0527 0535 0543 0559 0567 0575 0583 0599 0607 0615 0623 0623 0623 0647 0655 0663		1400 1410 1420 1430 1440 1450 1510 1550 1550 1550 1550 155	0 0768 0776 0784 0792 0800 0808 0816 0824 0840 0840 0848 0866 0864 08656 0864 0862 0889 0889 0889 0912 0920 0928 0934	1 0769 0777 0785 0793 0809 0817 0825 0833 0841 0849 0857 0865 0863 0889 0897 0905 0913 0921 0921	2 0770 0786 0794 0802 0810 0818 0826 0834 0826 0858 0858 0866 0858 0866 0874 0882 0890 0874 0914 0914	3 0771 0787 0787 0787 0785 0803 0811 0827 0827 0843 0843 0843 0843 0843 0843 0859 0867 0875 0885 0889 0897 0915 0923 0938	4 0772 0780 0786 0804 0804 0820 0828 0836 0844 0852 0868 0852 0868 0876 0884 0892 0900 0908 0916 0934 0934	5 0773 0781 0789 0797 0805 0813 0821 0829 0845 0845 0845 0845 0845 0845 0845 0893 0861 0869 0893 0901 0909 0901 0909 0917 0925 0933	6 0774 0782 0790 0798 0806 0814 0822 0830 0830 0846 0846 0846 0846 0846 0846 0846 084	7 0775 0783 0791 0799 0815 0823 0831 0831 0839 0847 0855 0863 0871 0889 0887 0895 0903 0911 0919 0927 0935
1000 to 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1060 1060 1070 1100 1110 1120 1130 1140 1150 1160 1170 1210 1220 1230 1240 1250 1250 1250	0 0512 0520 0528 0536 0544 0550 0560 0568 0576 0584 0590 0600 0608 0616 0624 0624 0624 0648 0656 0664 0664 0668 0666 0688 06896	1 0513 0521 0529 0545 0545 0553 0561 0585 0585 0691 0609 0617 0625 0633 0641 0649 0641 0649 0657	2 0514 0522 0530 0546 0554 0554 0554 0554 0554 0659 0610 0618 0618 0634 0642 0650 0658 06666 0658 06626 0658	3 0515 0523 0531 0539 0547 0555 0563 0571 0579 0595 0603 0611 0619 0627 0635 0643 0659 0663 0659 0663 0683 0683 0689	4 0516 0524 0532 0548 0556 0564 0572 0580 0604 0612 0620 0628 0636 0628 0636 0664 0652 0684 0684 0682 0684	5 0517 0525 0533 0541 0557 0557 0557 0557 0559 0613 0621 0629 0637 0645 0663 0661 0669 0677	6 0518 0526 0534 0542 0550 0558 0558 0558 0558 0558 0558 0598 0606 0614 0622 0630 0622 0630 0622 0630 0622 0670 0678 0662 0664 0664 0694 0702	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0599 0615 0623 0631 0639 0647 0655 0663 0671 0679 0657 0671 0679		1400 1410 1420 1430 1440 1450 1510 1550 1550 1550 1550 155	0 0768 0776 0776 0784 0792 0800 0800 0800 0824 0842 0844 0842 0844 0872 0864 0864 0864 0864 0868 0866 0904 0920 0928 0936 0934 0934	1 0769 0777 0785 0793 0801 0809 0817 0825 0849 0849 0849 0849 0849 0889 0889 0889	2 0770 0786 0794 0802 0810 0818 0826 0850 0854 0850 0854 0850 0874 0882 0890 0874 0914 0922 0938 0936 0938	3 0771 0779 0787 0785 0803 0811 0819 0827 0843 0851 0875 0863 0863 0883 0891 0899 0907 0915 0939 0930	4 0772 0780 0786 0804 0820 0828 0826 0828 0828 0852 0868 0884 0852 0868 0884 0852 0900 0908 0916 0932 0930 09348 0935	5 0773 0781 0789 0797 0805 0805 0882 0883 0845 0845 0845 0845 0845 0893 0861 0869 0893 0901 0907 0917 0925 0931 0941 0949 0957	6 0774 0782 0790 0806 0806 0806 0806 0806 0880 0846 0846	7 0775 0783 0799 0807 0815 0823 0863 0839 0847 0855 0863 0863 0863 0863 0863 0863 0863 0863
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1050 1050 1050 1050 1050 1050 105	0 0512 0520 0528 0536 0544 0550 0560 0568 0576 0584 0590 0600 0608 0616 0624 0642 0648 0652 0640 0648 0652 0640 0624 0624 0624 0624 0624 0624 0624 0624 0624 0624 0626 0560 0562 0560 0564 0562 0560 0564 0562 0564 0562 0564 0562 0564 0562 0564 0562 0564 0562 0564 0564 0562 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0564 0566 0564 0566 0564 0564 0566 0564 0566 0564 0566 0568 0566 0564 0566 0568 0566 0568 0566 0568 0566 0568 0566 0568 0566 0568 0566 0568 0566 0568 0566 0568 0568 0566 0568 0568 0566 0566 056	1 0513 0521 0529 0537 0545 0553 0545 0553 0541 0569 0601 0601 0609 0617 0625 0633 0641 0649 06575 0653 0681 0689 0689 0689 0689 0689 0689 0689	2 0514 0522 0530 0546 0554 0554 0550 0552 0550 0552 0550 0552 0550 0552 0602 060	3 0515 0523 0539 0547 0555 0563 0563 0563 0563 0663 0663 0663	4 0516 0524 0532 0548 0556 0564 0572 0588 0604 0612 0620 0628 0636 0628 0636 0628 0636 0664 0652 0684 0682 0684 0684	5 0517 0525 0533 0541 0557 0557 0557 0557 0557 0557 0559 0633 0621 0629 0637 0621 0629 0637 0661 0669 0667 0685 0663 0701	6 0518 0526 0534 0550 0558 0550 0558 0574 0582 0598 0654 0654 0630 0630 0630 0638 0646 0654 0670 0670 0670 0670	7 0519 0527 0535 0543 0551 0559 0567 0575 0583 0599 0615 0623 0663 0663 0663 0663 0671 0655 0663 0671 0679 0695 0703		1400 1410 1420 1430 1440 1450 1510 1520 1550 1550 1550 1550 1550 1600 1620 1620 1620 1650 1650 1650	0 0768 0776 0776 0784 0792 0800 0800 0800 0824 0842 0844 0842 0844 0844	1 0769 0777 0785 0793 0801 0809 0817 0825 0833 0841 0845 0877 0865 0873 0881 0889 0891 0889 0913 0921 0923 0945 0953	2 0770 0778 0786 0794 0802 0810 0826 0826 0826 0826 0826 0882 0890 0882 0890 0882 0890 0882 0890 0882 0890 0988 0996 09942 0938 09946 0954	3 0771 0779 0787 0785 0803 0811 0819 0827 0843 0851 0855 0863 0867 0875 0883 0891 0899 0907 0915 0923 0939 0947 0955	4 0772 0780 0780 0786 0804 0812 0820 0828 0826 0826 0826 0826 0826 082	5 0773 0781 0781 0787 0805 0813 0829 0829 0829 0837 0845 0853 0893 0901 0909 0917 0949 0949 0949 0949 0949 0949	6 0774 0782 0790 0806 0814 0806 0814 0854 0854 0854 0852 0870 0886 0894 0902 0910 0918 09886 0894 0912 0910 0918 0958 0955	7 0775 07783 0799 0807 0807 0823 0823 0823 0823 0823 0863 0863 0863 0863 0863 0863 0863 086
1000 10 1777 (Octai)	0512 10 1023 (Decimal)	1000 1010 1020 1030 1040 1050 1060 1070 1100 1110 1120 1140 1150 1140 1150 1210 1220 1220 1230 1240 1250 1260 1270	0 0512 0528 0536 0544 0552 0560 0560 0552 0600 0592 0600 0616 0624 0632 0640 0648 0656 0664 0658 0664 0658 0664 0658 0664 0652 0640 0648 0656 0704 0720 0688 0704 0720 0720 0720 0720 0720 0720 0720 0720 0720 0720 0720 0720 0720 0720 0752 07555 07555 07555 07555 07555 07555 07555 07555 07555 07555	1 0513 0521 0537 0545 0553 0561 0569 0559 0659 0669 0667 06625 0673 0689 0689 0689 0689 0689 0689 0689 0689	2 0514 0522 0530 0546 0554 0554 0559 0559 0559 0650 0650 0650 0626 0650 0626 0650 0626 0650 0650	3 0515 0523 0531 0539 0547 0555 0563 0657 0697 0697 0627 0685 0663 0667 0667 0667 0687 0689 0707 0715	4 0516 0524 0532 0540 0548 0556 0564 0552 0560 0604 0628 0660 0628 0660 0628 0660 0628 0660 0682 0660 0682 0700 0708	5 0517 0525 0533 0541 0549 0557 0563 0653 0661 0629 0637 0645 0653 0661 0629 0677 0685 0661 0629 0677 0685 0653 0701 0709 0717	6 0518 0526 0534 0550 0550 0558 0566 0574 0590 0598 0614 0622 0614 0622 0614 0628 0614 0628 0616 0654 0654 0670 0678 0680 0670 0702	7 0519 0527 0535 0543 0551 0557 0555 0583 0599 0607 0615 0623 0623 0663 0663 0663 0663 0679 0665 0663 0679 0665 0669 0677 0695 0703		1400 1410 1420 1430 1440 1450 1510 1520 1530 1550 1550 1550 1550 1610 1620 1620 1630 1640 1650 1660 1650 1660 17710	0 0768 0776 0782 0792 0800 0808 0816 0824 0840 0840 0840 0840 0840 0842 0840 0872 0880 0872 0880 0979 0972 0979 0972 0979 0972 0972 0979 0972 0979 0972 0979 0972 0979 0972 0979 0972 0975 0075 007	1 0769 0777 0785 0793 0801 0801 0801 0825 0833 0841 0849 0857 0865 0873 0865 0873 0865 0873 0869 0889 0889 0931 0929 0935 0931 0929 0935	2 0770 0778 0786 0794 0802 0810 0826 0826 0834 0850 0856 0866 0874 0866 0866 08674 08690 0866 08906 0916 0922 0930 0926 0954	3 0771 0779 0785 0795 0785 0803 0819 0827 0843 0843 0843 0845 08659 08675 0883 0891 0875 0883 0891 0907 0915 0903 0995 0947 0955	4 0772 0780 0786 0786 0864 0812 0820 0828 0836 0844 0852 0868 0868 0868 0876 0900 0908 0916 0924 0930 0948 0956	5 0773 0781 0781 0787 0805 0813 0829 0837 0845 0853 0845 0853 0869 0877 0845 0893 0901 0909 0917 0909 0917 0909 0917 0909 0917 0949 0957	6 0774 0782 0790 0806 0814 0826 0830 0830 0838 0846 0854 0854 0854 0850 0870 0878 0870 0910 0910 0910 0910 0910 0910 0910 09	7 0775 0783 0799 0807 0815 0823 0831 0847 0845 0863 0871 0895 0867 0895 0903 0911 0911 0911 0911 0927 0943 0951 0959
1000 10 1777 (Octal)	0512 1023 (Decimal)	1000 1010 1020 1030 1050 1050 1060 1070 1100 1110 1120 1130 1140 1150 1130 1220 1220 1220 1240 1250 1260 1270 1300 1310	0 0512 0520 0536 054 0552 0560 0566 0576 0592 0600 0616 0648 0648 0646 0647 0688 0696 0704 0728	1 0513 0521 0537 0545 0553 0561 0569 0593 0601 0693 06617 0665 0633 0649 0657 0665 0653 0649 0657 0649 0657 0689 0697	2 0514 0522 0538 0546 0554 0556 0557 0557 0557 0557 0557 0557 0557	3 0515 0523 0539 0547 0555 0603 0595 0603 0619 0627 0635 0663 0651 0659 0665 06651 06659 0667 06651 06691 06699 0707 0715 0723	4 0516 0524 0540 0540 0564 0564 0564 0564 0564 0654 065	5 0517 0525 0533 0541 0549 0557 0565 0597 0605 0613 0621 06637 06637 06653 06619 06637 06653 06619 06637 06693 0701	6 0518 0526 0532 0542 0550 0558 0566 0574 0598 0606 0614 0622 0630 0638 0646 0654 0654 0654 0678 0686 0694 0702 0710 0718 0726	7 0519 0527 0535 0543 0551 0557 0567 0567 0567 0607 0615 0623 0663 0663 0663 0655 0663 0655 0663 0657 0655 0663 0703 0703		1400 1410 1420 1430 1440 1500 1510 1550 1550 1550 1560 1550 1600 1610 1620 1640 1650 1660 1670	0 0768 0776 0792 0800 0808 0816 0824 0848 0864 0864 0864 0864 0864 0864 086	1 0769 0777 0785 0793 0801 0809 0817 0849 0857 0865 0863 0849 0857 0868 0889 0893 0905 0913 0921 0945 0953 0953 0953	2 0770 0778 0786 0794 0802 0818 0826 0834 08450 0858 0866 0858 0866 09674 0906 0904 0904 0904 0904 09054 0954	3 0771 0779 0785 0785 0803 0819 0827 0843 0843 0859 0867 0875 0885 0891 0875 0887 09915 0997 09915 0993 09947 09955 09951 09951	4 0772 0780 0796 0804 0812 0820 0820 0820 0820 0852 0860 0852 0860 0852 0860 0868 0868 0892 0908 09916 0992 09948 09956 09964 09952	5 0773 0781 0789 0797 0805 0813 0821 0845 0853 0861 0863 0863 0893 0893 0909 0917 0925 0909 0917 0925 0957 0957	6 0774 0782 0798 0806 0814 0822 0830 0844 0862 0854 0854 0854 0854 0854 0894 0902 0910 0918 0926 0934 0958 0958	7 0775 0783 0799 0807 0815 0823 0831 0847 0855 0863 0879 0887 0895 0903 0911 0919 0927 0935 0943 0959 0959
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1050 1050 1060 1070 1100 1110 1120 1130 1140 1160 1170 1200 1220 1200 1220 1200 1200 1210 1200 1210 1200 1210 1200 1210 1200 1210 1200 1200 1200 1310 1200 1330 133	0 0512 0528 0536 0548 0552 0560 0552 0550 0552 0584 0584 0698 0616 0624 0652 0664 0652 0664 0656 0664 0658 0656 0664 0704 0712 0728 0736 0728 0736 0728 0736 0728 0736 0728 0736 0728 0736 0728 0736 0728 0736 0728 0736 074 0728 0736 0728 0736 0728 0736 0758 0759	1 0513 0521 0529 0537 0545 0553 0561 0569 0593 0601 0693 0649 0649 0649 0649 0649 0649 0649 0649 0649 0649 0649 0649 0657 0649 0657 0705 0617 0649 0673 0649 0677 0705 0673 0649 0677 0705 0673 0649 0677 0705 0673 0673 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0649 0677 0673 0677 0673 0677 0649 0677 0673 0677 0673 0677 0673 0677 0677 0679 0677 0697 0697 0697 0697 0697 0697 0697 0705 0773 0697 0773 0775 0773 0779 077	2 0514 0520 0538 0546 0554 0554 0554 0554 0558 0554 0658 0658 0658 0666 0634 0626 0658 0658 0658 0658 0658 0658 0658 065	3 0515 0523 0531 0559 0555 0563 0571 0555 0603 0587 0587 0587 0687 0687 0627 0659 0667 0659 0663 0683 06891 0699 0707 07715 0723 0731 0731	4 0516 0524 0530 0540 0548 0556 0564 0554 0580 0596 0604 0620 0620 0620 0623 0660 0652 0660 06652 0660 06652 0660 06652 0700 0702 0700 0700 0712 0700	5 0517 0525 0533 0541 0549 0557 0565 0573 0581 0597 0605 0697 0621 0629 0637 0645 0653 0653 0653 0653 0653 0653 0701 0709 0717 0725 0733 0741	6 0518 0526 0534 0542 0550 0556 0556 0556 0556 0556 0556 055	7 0519 0527 0533 0543 0559 0567 0575 0583 0593 0615 0623 0631 0639 0647 0655 0663 0639 0647 0659 0663 0639 0647 0659 0703 0711 0719 0735 0743 0743		1400 1410 1420 1430 1440 1450 1500 1510 1550 1540 1550 1560 1560 1610 1620 1640 1650 1640 1650 1640 1650 1640 1770 1770	0 7768 7766 7786 7780 7792 8800 8808 8816 0808 8848 8856 0864 0852 0864 0852 0864 0852 0864 0864 0852 0864 0864 0864 0864 0852 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0868 0866 0952 0952 0952 0952 0952 0952 0956 0952 0956 0952 0956 0056 005	1 0769 0777 0785 0801 0809 0817 0825 0837 0841 0849 0857 0873 0881 0889 0897 0905 0921 0923 0921 0929 0951 0953	2 0770 0778 0786 0794 0802 0810 0818 0826 0850 0850 0850 0850 0850 0850 0850 085	3 0771 0789 0785 0803 0851 0827 0835 0851 0855 0867 0875 0867 0875 0867 0875 0867 0875 0867 0899 0907 0915 0923 0931 0955	4 0772 0780 0786 0796 0804 0828 0826 0828 0826 0864 0852 0864 0868 0876 0868 0876 0900 0908 0916 0924 0934 0934 0934 0934 0934 0934 0934 093	5 0773 0781 0789 0797 0805 0813 0841 0829 0845 0853 0861 0863 0863 0863 0869 0897 0909 0909 0909 0909 0909 0909 090	6 0774 0782 0798 0806 0814 0822 0830 0814 0862 0830 0846 0854 0866 0870 0878 0870 0972 0910 0918 0926 0934 0950 0955 0956 0954	7 0775 0783 0799 0807 0815 0831 0831 0839 0847 0855 0863 0863 0863 08647 0885 0863 0911 0919 0927 0935 0943 0951 0955 0985
1000 10 1777 (Octal)	0512 10 1023 (Decimal)	1000 1010 1020 1050 1050 1050 1050 1050	0 0512 0528 0536 0552 0550 0552 0550 0552 0550 0552 0584 0592 0600 0688 0616 0624 0652 0664 0652 0664 0652 0664 0652 0664 0752 0668 0668 0664 0712 0712 0728 0736 0738 0738 0758 0758 0758 0548 0559 055	1 0513 0521 0537 0545 0553 0553 0553 0553 0585 0585 0585 058	2 0514 0522 0538 0546 0554 0554 0554 0554 0554 0658 0594 0610 0618 0626 0634 0658 0664 0658 0666 0658 0668 0698 0706 0698 0704 0714 0722 0730 0738 0746	3 0515 0523 0531 0539 0547 0555 0563 0555 0563 0557 0587 0587 0587 0587 0587 0683 0651 0659 0667 0665 0667 0667 0667 0667 0669 0667 07075	4 0516 0524 0540 0540 0556 0556 0556 0556 0596 0604 0612 0628 0636 0636 0636 0668 0676 0668 0700 0700 0700 0716 0724 0740 0740 0746	5 0517 0525 0533 0541 0549 0557 0565 0573 0565 0597 0605 0605 0621 0629 0637 0641 0669 0667 0685 0693 0701 0709 0717 0725 0733 0741 0749 0757 0741 0749 0757 0741 0749 0757 0741 0749 0757 0741 0749 0757 0645 0657 0709 0717 0725 0737 0741 0741 0747 0747 0747 0747 0747 0755 0757 075	6 0518 0526 0534 0552 0558 0566 0574 0582 0590 0590 0590 0590 0614 0622 0630 0614 0623 0638 0664 0654 0670 0678 0670 0678 0670 0772 0710 0718 0726	7 0519 0527 0533 0543 0559 0567 0559 0657 0599 0607 0599 0607 0639 0639 0639 0639 0639 0647 0655 0703 0679 0695 0703 0711 0779 0695 0703 0717 0735 0727 0743 0751 0743 0754 0759 0743 0759 0743 0759 0743 0759 0743 0759 0743 0759 075		1400 1410 1420 1430 1440 1450 1500 1510 1520 1530 1550 1550 1550 1550 1550 1660 1610 1620 1630 1650 1650 1650 1620 1650 1650 1700 1770 1770 1770	0 7768 0776 0782 0800 0816 0824 0832 0840 0854 0856 0864 0856 0866 0968 0866 0968 0866 0968 0866 0968 0952 0968 0976 0968 0976 0976 0978 0979 0079 00798 00798 00798 00798 00798 00798 00798 00798 00798 00798 00798 00798 00798 00798 007998 00798 00798 00798 007998 007998 00798 00798 00798 007998 00798 00798 00798 007998 007998 00798 007998 007998 00798 00798 00798 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007988 007888 007888 007888 0078888 007888 00788888 007888 00788888 007888 007888888 0078888888 0078888888 0078888888 0078888888 0078888888 0078888888888	1 0769 0777 0785 0809 0809 0817 0825 0833 0841 0849 0857 0845 0843 0841 0849 0857 0945 0913 0921 0921 0923 0923 0933 0921 0923 0923 0933 0953 0969 0969 0969 0969 0969 0969 0969 096	2 0770 0778 0786 0784 0802 0810 0818 0826 0850 0852 0850 0854 0852 0890 0890 0890 0890 0890 0890 0890 089	3 0771 0785 0785 0803 0819 0827 0835 0843 0859 0843 0859 0883 0881 0859 0883 0891 0895 0907 0915 0923 0931 0923 0931 0955 0947 0979 0987 0979	4 0772 0780 0796 0796 0804 0812 0820 0822 0826 0844 0852 0860 0884 0852 0884 0852 0884 0852 0884 0956 0990 0992 0992 0994 0956 0954 0956	5 0773 0781 0789 0797 0805 0813 0821 0829 0837 0845 0853 0861 0853 0861 0853 0861 0853 0861 0893 08937 09957 0925 0931 0957 0941 0957 0949 0957	6 0774 0782 0798 0806 0814 0822 0830 0814 0864 0864 0854 0854 0854 0856 0886 0886 0886 0894 0902 0918 0926 0958 0958 0958 0958	7 0775 0783 0799 0807 0815 0815 0831 0831 0839 0847 0855 0863 0855 0863 0855 0863 0891 0897 0959 0959 0959 0959 0959

410-0(102) FOR TRAINING PURPOSES ONLY

OCTAL-DECIMAL INTEGER CONVERSION TABLE

	N. CONTRACTOR		The loss of	-	Sector Sector							100					- United States			
	0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7		
2000	1024	1025	1026	1027	1028	1029	1030	1031	1200	2400	1280	1281	1282	1283	1284	1285	1286	1287	2000	1024
2010	1032	1033	1034	1035	1036	1037	1038	1039	121	2410	1288	1289	1290	1291	1292	1293	1294	1295	to	to
2020	1040	1041	1042	1043	1044	1045	1046	1047	1	2420	1296	1297	1298	1299	1300	1301	1302	1303	2111	1535
2030	1048	1049	1050	1051	1052	1053	1054	1055	122	2430	1304	1305	1306	1307	1308	1309	1310	1311	(Octal)	(Decima
2040	1056	1057	1058	1059	1060	1061	1062	1063	1.14	2440	1312	1313	1314	1315	1316	1317	1318	1319		
2050	1064	1065	1066	1067	1068	1069	1070	1071		2450	1320	1321	1322	1323	1324	1325	1326	1327		
2060	1072	1073	1074	1075	1076	1077	1078	1079		2460	1328	1329	1330	1331	1332	1333	1334	1335	Ortal	Decimal
2070	1080	1081	1082	1083	1084	1085	1080	1087		24/0	1330	1337	1338	1339	1340	1341	1342	1343	10000	4096
2100	1088	1089	1090	1091	1092	1093	1094	1095		2500	1344	1345	1346	1347	1348	1349	1350	1351	20000	8197
2100	1096	1003	1098	1099	1100	1101	1102	1103	1	2510	1352	1353	1354	1355	1356	1357	1358	1359	20000	12200
2120	1104	1105	1106	1107	1108	1109	1110	1111	aust	2520	1360	1361	1362	1363	1364	1365	1366	1367	30000	12200
2130	1112	1113	1114	1115	1116	1117	1118	1119	22/2	2530	1368	1369	1370	1371	1372	1373	1374	1375	40000	10304
2140	1120	1121	1122	1123	1124	1125	1126	1127	1 - 2	2540	1376	1377	1378	1379	1380	1381	1382	1383	50000	20480
2150	1128	1129	1130	1131	1132	1133	1134	1135	10 10 10	2550	1384	1385	1386	1387	1388	1389	1390	1391	60000	245/6
2160	1136	1137	1138	1139	1140	1141	1142	1143	74	2560	1392	1393	1394	1395	1396	1397	1398	1399	70000	28672
2170	1144	1145	1146	1147	1148	1149	1150	1151	1	2570	1400	1401	1402	1403	1404	1405	1406	1407		
				1	1															
2200	1152	1153	1154	1155	1156	1157	1158	1159	1	2600	1408	1409	1410	1411	1412	1413	1414	1415	in the state of the	
2210	1160	1161	1162	1163	1164	1105	1100	110/		2610	1410	141/	1418	1419	1420	1421	1422	1423		
2220	1176	1109	1170	1170	11/2	11/3	1102	11/5	25/2	2020	1424	1423	1420	1421	1420	1423	1430	1431	Section Section	
2230	1184	1195	1186	1187	1188	1190	1102	1103		2640	1432	1433	1434	1433	1430	1445	1430	1433	at a fait is	
2250	1192	1193	1194	1195	1196	1197	1198	1199	SAR. U	2650	1448	1449	1450	1451	1452	1453	1454	1455		
2260	1200	1201	1202	1203	1204	1205	1206	1207	1	2660	1456	1457	1458	1459	1460	1461	1462	1463		
2270	1208	1209	1210	1211	1212	1213	1214	1215		2670	1464	1465	1466	1467	1468	1469	1470	1471		
																	884.0	and the	The second	
2300	1216	1217	1218	1219	1220	1221	1222	1223	1	2700	1472	1473	1474	1475	1476	1477	1478	1479	and the second	
2310	1224	1225	1226	1227	1228	1229	1230	1231	1.578	2710	1480	1481	1482	1483	1484	1485	1486	1487	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	
2320	1232	1233	1234	1235	1236	1237	1238	1239	32.3	2720	1488	1489	1490	1491	1492	1493	1494	1495		
2330	1240	1241	1242	1243	1244	1245	1246	1247	304	2730	1496	1497	1498	1499	1500	1501	1502	1503		
2340	1248	1249	1250	1251	1252	1253	1254	1255		2740	1504	1505	1506	1507	1508	1519	1510	1511	and the second	
2350	1256	1257	1258	1259	1260	1261	1262	1263		2750	1512	1513	1514	1515	1516	1517	1518	1519		
2360	1264	1265	1266	1267	1268	1269	1270	1271	1	2760	1520	1521	1522	1523	1524	1525	1526	1527	Con division	
2370	12/2	12/3	12/4	12/5	1276	12/1	12/8	12/9		2110	1528	1529	1530	1531	1532	1533	1534	1535		
	0	1	2	3	4	5	6	7	1		0	1	2	3	4	5	6	7		
	0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7		
3000	0 1536	1 1537	2 1538	3 1539	4 1540	5 1541	6 1542	7 1543		3400	0 1792	1 1793	2 1794	3 1795	4 1796	5 1797	6 1798	7 1799	3000	1536
3000 3010	0 1536 1544	1 1537 1545	2 1538 1546	3 1539 1547	4 1540 1548	5 1541 1549	6 1542 1550	7 1543 1551		3400 3410	0 1792 1800	1 1793 1801	2 1794 1802	3 1795 1803	4 1796 1804	5 1797 1805	6 1798 1806	7 1799 1807	3000 to	1536 to
3000 3010 3020	0 1536 1544 1552	1 1537 1545 1553	2 1538 1546 1554	3 1539 1547 1555	4 1540 1548 1556	5 1541 1549 1557	6 1542 1550 1558	7 1543 1551 1559		3400 3410 3420	0 1792 1800 1808	1 1793 1801 1809	2 1794 1802 1810	3 1795 1803 1811	4 1796 1804 1812	5 1797 1805 1813	6 1798 1806 1814	7 1799 1807 1815	3000 to 3777	1536 to 2047
3000 3010 3020 3030	0 1536 1544 1552 1560	1 1537 1545 1553 1561	2 1538 1546 1554 1562	3 1539 1547 1555 1563	4 1540 1548 1556 1564	5 1541 1549 1557 1565	6 1542 1550 1558 1566	7 1543 1551 1559 1567		3400 3410 3420 3430	0 1792 1800 1808 1816	1 1793 1801 1809 1817	2 1794 1802 1810 1818	3 1795 1803 1811 1819	4 1796 1804 1812 1820	5 1797 1805 1813 1821	6 1798 1806 1814 1822	7 1799 1807 1815 1823	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 2050	0 1536 1544 1552 1560 1568	1 1537 1545 1553 1561 1569 1577	2 1538 1546 1554 1562 1570	3 1539 1547 1555 1563 1571	4 1540 1548 1556 1564 1572	5 1541 1549 1557 1565 1573 1573	6 1542 1550 1558 1566 1574	7 1543 1551 1559 1567 1575		3400 3410 3420 3430 3440 2450	O 1792 1800 1808 1816 1824 1822	1 1793 1801 1809 1817 1825 1822	2 1794 1802 1810 1818 1826 1824	3 1795 1803 1811 1819 1827 1827	4 1796 1804 1812 1820 1828 1828	5 1797 1805 1813 1821 1829 1827	6 1798 1806 1814 1822 1830 1838	7 1799 1807 1815 1823 1831 1839	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3050	0 1536 1544 1552 1560 1568 1576	1 1537 1545 1553 1561 1569 1577 1585	2 1538 1546 1554 1562 1570 1578 1586	3 1539 1547 1555 1563 1571 1579 1587	4 1540 1548 1556 1564 1572 1580 1588	5 1541 1549 1557 1565 1573 1581 1589	6 1542 1550 1558 1566 1574 1582 1590	7 1543 1551 1559 1567 1575 1583 1591		3400 3410 3420 3430 3440 3450 3460	O 1792 1800 1808 1816 1824 1832 1840	1 1793 1801 1809 1817 1825 1833 1841	2 1794 1802 1810 1818 1826 1834 1842	3 1795 1803 1811 1819 1827 1835 1843	4 1796 1804 1812 1820 1828 1836 1844	5 1797 1805 1813 1821 1829 1837 1845	6 1798 1806 1814 1822 1830 1838 1846	7 1799 1807 1815 1823 1831 1839 1847	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070	0 1536 1544 1552 1560 1568 1576 1584 1592	1 1537 1545 1553 1561 1569 1577 1585 1593	2 1538 1546 1554 1562 1570 1578 1586 1594	3 1539 1547 1555 1563 1571 1579 1587 1595	4 1540 1548 1556 1564 1572 1580 1588 1596	5 1541 1549 1557 1565 1573 1581 1589 1597	6 1542 1550 1558 1566 1574 1582 1590 1598	7 1543 1551 1559 1567 1575 1583 1591 1599		3400 3410 3420 3430 3440 3450 3460 3470	O 1792 1800 1808 1816 1824 1832 1840 1848	1 1793 1801 1809 1817 1825 1833 1841 1849	2 1794 1802 1810 1818 1826 1834 1842 1850	3 1795 1803 1811 1819 1827 1835 1843 1851	4 1796 1804 1812 1820 1828 1836 1844 1852	5 1797 1805 1813 1821 1829 1837 1845 1853	6 1798 1806 1814 1822 1830 1838 1846 1854	7 1799 1807 1815 1823 1831 1839 1847 1855	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070	0 1536 1544 1552 1560 1568 1576 1584 1592	1 1537 1545 1553 1561 1569 1577 1585 1593	2 1538 1546 1554 1562 1570 1578 1586 1594	3 1539 1547 1555 1563 1571 1579 1587 1595	4 1540 1548 1556 1564 1572 1580 1588 1596	5 1541 1549 1557 1565 1573 1581 1589 1597	6 1542 1550 1558 1566 1574 1582 1590 1598	7 1543 1551 1559 1567 1575 1583 1591 1599		3400 3410 3420 3430 3440 3450 3460 3470	0 1792 1800 1808 1816 1824 1832 1840 1848	1 1793 1801 1809 1817 1825 1833 1841 1849	2 1794 1802 1810 1818 1826 1834 1842 1850	3 1795 1803 1811 1819 1827 1835 1843 1851	4 1796 1804 1812 1820 1828 1836 1844 1852	5 1797 1805 1813 1821 1829 1837 1845 1853	6 1798 1806 1814 1822 1830 1838 1846 1854	7 1799 1807 1815 1823 1831 1839 1847 1855	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3100	0 1536 1544 1552 1560 1568 1576 1584 1592 1600	1 1537 1545 1553 1561 1569 1577 1585 1593 1601	2 1538 1546 1554 1562 1570 1578 1586 1594	3 1539 1547 1555 1563 1571 1579 1587 1595	4 1540 1548 1556 1564 1572 1580 1588 1596	5 1541 1549 1557 1565 1573 1581 1589 1597 1605	6 1542 1550 1558 1566 1574 1582 1590 1598	7 1543 1551 1559 1567 1575 1583 1591 1599 1607		3400 3410 3420 3430 3440 3450 3460 3470 3500	0 1792 1800 1808 1816 1824 1832 1840 1848	1 1793 1801 1809 1817 1825 1833 1841 1849 1857	2 1794 1802 1810 1818 1826 1834 1842 1850 1858	3 1795 1803 1811 1819 1827 1835 1843 1851 1859	4 1796 1804 1812 1820 1828 1836 1844 1852 1860	5 1797 1805 1813 1821 1829 1837 1845 1853 1861	6 1798 1806 1814 1822 1830 1838 1846 1854 1862	7 1799 1807 1815 1823 1831 1839 1847 1855 1863	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3100 3110	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611	4 1540 1548 1556 1564 1564 1580 1588 1596 1604 1612	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510	O 1792 1800 1808 1816 1824 1824 1840 1848 1856 1864	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3110 3110 3120	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619	4 1540 1548 1556 1564 1564 1580 1588 1596 1604 1612 1620	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621	6 1542 1550 1558 1566 1574 1590 1598 1606 1614 1622	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510 3520	O 1792 1800 1808 1816 1824 1824 1840 1848 1856 1864 1872	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3110 3120 3130	O 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629	6 1542 1550 1558 1566 1574 1590 1598 1606 1614 1622 1630	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510 3520 3530	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881	2 1794 1802 1810 1818 1826 1826 1850 1858 1866 1874 1882	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3110 3110 3120 3130 3140	O 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633	2 1538 1546 1554 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510 3520 3530 3540	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884 1892	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895	3000 to 3777 (Octal)	1536 to 2047 (Decimi
3000 3010 3020 3030 3040 3050 3060 3070 3100 3110 3120 3130 3140 3150	O 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641	2 1538 1546 1554 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1642	3 1539 1547 1555 1563 1571 1575 1587 1595 1603 1611 1619 1627 1635 1643	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636 1644	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510 3520 3530 3540 3550	O 1792 1800 1808 1816 1824 1824 1840 1848 1856 1864 1872 1880 1888 1896	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1897	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1858 1866 1874 1890 1898	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899	4 1796 1804 1812 1820 1828 1828 1844 1852 1860 1868 1876 1884 1892 1900	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1875 1885 1893 1901	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902	7 1799 1807 1823 1831 1839 1847 1855 1863 1871 1879 1879 1879 1895 1903	3000 10 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3070 3100 3110 3120 3140 3140 3150 3160	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1622 1610 1618 1624 1642 1650	3 1539 1547 1555 1563 1571 1575 1587 1595 1603 1611 1619 1625 1643 1651	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636 1644 1652	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1638 1646 1654	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1639 1647 1655		3400 3410 3420 3430 3440 3450 3460 3470 3500 3510 3520 3530 3540 3550 3550 3560	O 1792 1800 1808 1816 1824 1824 1848 1856 1864 1872 1860 1888 1896 1904	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1865 1873 1889 1897 1905	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1858 1866 1874 1890 1898 1906	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1863 1891 1899 1907	4 1796 1804 1812 1820 1828 1828 1844 1852 1860 1868 1876 1868 1876 1868 1876 1892 1900 1908	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1865 1893 1901 1909	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902 1910	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1867 1895 1903 1911	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3060 3070 3100 3110 3120 3130 3140 3150 3160 3170	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1624 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1631 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1659	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636 1644 1652 1660	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1661	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1664	7 1543 1551 1559 1567 15/5 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663		3400 3410 3420 3430 3440 3450 3470 3500 3510 3520 3550 3550 3550 3550 3550 3550	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1861 1889 1897 1905 1913	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906 1914	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1863 1891 1899 1907 1915	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884 1892 1900 1908 1916	5 1797 1805 1813 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1878 1862 1878 1878 1878 1894 1902 1910 1918	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895 1903 1911 1919	3000 to 3777 (Octal)	1536 to 2047 (Decimi
3000 3010 3020 3030 3050 3050 3060 3070 3110 3120 3130 3140 3150 3160 3170	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 16451 1659	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636 1644 1652 1660	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1661	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1662	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663		3400 3410 3420 3440 3450 3460 3470 3500 3510 3520 3530 3550 3550 3550 3570	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1897 1905 1913	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906 1914	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899 1907 1915	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884 1892 1900 1908 1916	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1866 1894 1900 1910 1918	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895 1903 1911 1919 1023	3000 10 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3060 3070 3110 3120 3130 3140 3150 3160 3170 3200	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1659 1667	4 1540 1548 1556 1564 1572 1580 1596 1596 1604 1612 1620 1628 1636 1644 1652 1660 1668	5 1541 1549 1555 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1661 1669	6 1542 1550 1558 1566 1574 1582 1598 1606 1614 1622 1630 1638 1646 1654 1662 1670	7 1543 1551 1559 1567 1575 1583 1599 1607 1615 1623 1631 1639 1647 1655 1663 1671		3400 3410 3420 3430 3440 3450 3510 3510 3510 3520 3550 3550 3550 3550 3570 3600	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912 1920	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1897 1905 1913 1921	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906 1914 1922	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899 1907 1915	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884 1892 1900 1908 1916 1924	5 1797 1805 1813 1829 1837 1845 1853 1861 1869 1875 1875 1893 1901 1909 1917 1925	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1866 1894 1902 1910 1918 1926	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1865 1903 1911 1919 1927	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3040 3050 3060 3070 3100 3110 3120 3130 3140 3150 3160 3170 3220	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1664	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657 1665 1673 1691	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1650 1658 1666 1674	3 1539 1547 1555 1563 1571 1575 1587 1595 1603 1611 1619 1627 1635 1643 1651 1659 1667 1675	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1629 1604 1612 1628 1644 1652 1660 1668 1676	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1633 1645 1653 1661 1669 1677	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1662	7 1543 1551 1559 1567 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663 1671 1679		3400 3410 3420 3430 3430 3440 3510 3510 3550 3550 3550 3550 3550 355	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912 1920 1928	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1889 1905 1913 1921 1922	2 1794 1802 1810 1818 1826 1834 1850 1858 1866 1874 1882 1890 1898 1906 1914 1922 1930	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1883 1889 1907 1915 1923 1931	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1868 1876 1884 1892 1900 1908 1916 1924 1932	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917 1925 1933 1941	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1854 1878 1878 1878 1878 1878 1878 1910 1918 1926 1934	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895 1903 1911 1919 1927 1927 1943	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3050 3070 3100 3110 3120 3130 3140 3150 3160 3170 3210 3220 3220	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1640 1648 1656	1 1537 1545 1553 1561 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1857 1685	2 1538 1546 1554 1557 1570 1578 1586 1594 1602 1610 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1603 1611 1619 1627 1643 1651 1659 1667 1675	4 1540 1548 1556 1564 1572 1580 1596 1604 1612 1620 1628 1636 1644 1652 1660 1688 1676	5 1541 1549 1557 1565 1573 1589 1589 1605 1613 1629 1637 1645 1653 1661 1689 1677	6 1542 1550 1558 1558 1566 1574 1582 1598 1606 1614 1622 1630 1638 1686 1654 1654 1656 1658	7 1543 1551 1559 1567 1575 1583 1591 1607 1615 1623 1631 1639 1647 1655 1663 1647 1679 1687		3400 3410 3420 3430 3440 3510 3510 3550 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1840 1840 1848 1856 1864 1864 1864 1864 1864 1864 1864 1904 1912 1928 1936	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1897 1905 1913 1921 1929 1937	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1914 1922 1930 1938	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1867 1867 1867 1867 1867 1867 1867	4 1796 1804 1812 1820 1828 1836 1836 1844 1852 1860 1884 1852 1866 1884 1852 1869 1980 1990 1990 1990 1991 1948	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917 1925 1933 1941	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902 1910 1918 1926 1934	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1875 1863 1871 1875 1895 1903 1911 1919 1927 1935 1943 1951	3000 to 3777 (Octal)	1536 to 2047 (Decimi
3000 3010 3020 3030 3050 3060 3060 3070 3100 3110 3120 3140 3140 3150 3140 3150 3220 3220 3220 3220	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1624 1632 1640 1688 1656 1664 1657 1680 1688	1 1537 1545 1553 1561 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657 1665 1673 1681 1689	2 1538 1546 1554 1552 1570 1578 1594 1602 1610 1618 1626 1634 1642 1650 1658 1666 1674 1682 1690	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1635 1643 1659 1667 1675 1683	4 1540 1548 1556 1564 1556 1580 1580 1580 1588 1596 1604 1628 1636 1644 1652 1660 1668 1666 1668	5 1541 1549 1557 1565 1573 1581 1581 1581 1587 1605 1613 1629 1637 1645 1663 1661 1661 1661 1661 1661 1661 1701	6 1542 1550 1558 1558 1566 1574 1590 1598 1606 1614 1622 1630 1638 1646 1652 1662 1670 1678 1686	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663 1671 1679 1887 1679		3400 3410 3420 3430 3440 3540 3540 3510 3520 3540 3550 3560 3560 3560 3560 3560 3610 3620 3630	O 1792 1800 1808 1816 1824 1848 1856 1864 1872 1880 1888 1896 1904 1912 1912 1920 1948 1946	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1873 1881 1873 1897 1905 1913 1921 1929 1937	2 1794 1802 1810 1818 1826 1834 1834 1834 1834 1834 1834 1832 1890 1898 1906 1938 1914 1922 1930 1938	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899 1907 1915 1923 1931 1939 1947	4 1796 1804 1812 1820 1828 1836 1836 1836 1836 1836 1868 1836 1884 1884 1884 1884 1884 1900 1908 1900 1908 1916 1912 1940	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917 1917 1917	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1854 1854 1854 1870 1918 1902 1910 1918 1919 1918	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1885 1903 1911 1919 1927 1935 1943 1951	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3060 3060 3100 3130 3130 3140 3150 3140 3150 3140 3170 3210 3220 3220 3220	0 1536 1544 1552 1560 1568 1576 1588 1616 1624 1648 1656 1664 1656 1664 1680 1688	1 1537 1545 1553 1561 1568 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657 1653 1657 1651 1681 1681 1689 1697	2 1538 1546 1554 1552 1570 1578 1586 1594 1602 1610 1618 1626 1634 1650 1658 1666 1674 1682 1682 1682	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1659 1667 1675 1683 1681 1683	4 1540 1556 1556 1556 1580 1580 1580 1580 1580 1580 1580 1684 1612 1628 1636 1636 1644 1652 1660 1684 1684 1684 1684 1700	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1629 1637 1645 1653 1661 1685 1693 1701	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1662 1670 1678 1686 1684 1700 2710	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663 1671 1679 1687 1687		3400 3410 3420 3430 3450 3510 3550 3550 3550 3550 3550 3550 35	O 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912 1920 1936	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1889 1897 1905 1913 1921 1922 1937 1945 1953	2 1794 1802 1810 1818 1842 1850 1854 1854 1854 1856 1874 1890 1898 1906 1914 1922 1938 1946 1954	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899 1907 1915 1931 1939 1947 1955	4 1796 1804 1812 1820 1886 1836 1844 1852 1860 1868 1876 1884 1892 1900 1908 1916 1924 1940 1948 1956	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917 1925 1933 1941 1949 1957	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1854 1854 1854 1870 1878 1878 1894 1910 1918 1926 1931 1942 1950 1955	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1887 1903 1911 1919 1927 1935 1951 1959	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3060 3050 3100 3120 3130 3140 3150 3140 3150 3140 3150 3120 3210 3220 3220 3220 3220	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1684 1624 1640 1648 1656 1664 1672 1680 1688 1896 1704	1 1537 1545 1553 1561 1568 1577 1585 1593 1609 1617 1625 1633 1641 1649 1657 1665 1673 1681 1689 1689 1689 1713	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1642 1650 1658 1666 1874 1682 1690 1698 1706	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1643 1651 1659 1667 1675 1683 1691 1699 1707	4 1540 1548 1556 1564 1560 1588 1596 1620 1620 1628 1620 1628 1644 1652 1660 1668 1676 1684 1652 1700 1708	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1861 1669 1677 1685 1693 1701 1709	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1654 1654 1654 1654 1654 1702	7 1543 1551 1559 1567 1575 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1655 1663 1647 1679 1687 1695 1703		3400 3410 3420 3430 3440 3500 3510 3550 3550 3550 3550 3550 355	O 1792 1800 1808 1816 1824 1824 1824 1824 1824 1824 1822 1820 1888 1866 1868 1867 1872 1880 1888 1896 1994 1992 1994 1952 1968	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1813 1873 1881 1873 1881 1897 1915 1913 1921 1929 1937 1945 1945	2 1794 1802 1810 1818 1826 1834 1850 1858 1866 1858 1866 1874 1888 1896 1914 1922 1930 1938 1946 1954 1954	3 1795 1803 1811 1819 1827 1835 1843 1851 1855 1867 1875 1883 1891 1907 1915 1933 1931 1939 1947 1947	4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884 1852 1940 1908 1916 1924 1948 1948 1956 1948	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1893 1891 1909 1917 1925 1933 1941 1949 1957 1949	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1862 1870 1910 1918 1926 1934 1945 1950 1958 1956	7 1799 1807 1815 1823 1823 1831 1839 1847 1855 1863 1871 1879 1903 1911 1911 1919 1927 1935 1943 1951 1959 1957	3000 to 3777 (Octal)	1536 to 2047 (Decimi
3000 3010 3020 3050 3050 3050 3050 3050 3050 305	0 1536 1544 1552 1560 1568 1576 1584 1559 1600 1608 1616 1624 1632 1640 1648 1656 1656 1656 1657 1680 1680 1680 1680 1722	1 1537 1545 1553 1561 1568 1577 1583 1601 1609 1617 1625 1633 1641 1649 1657 1657 1657 1665 1673 1681 1689 1713	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1626 1634 1650 1658 1650 1658 1866 1674 1682 1690 1698 1704	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1655 1667 1675 1683 1691 1699 1707 1715	4 1540 1548 1556 1564 1564 1572 1580 1596 1596 1620 1628 1636 1644 1652 1668 1668 1668 1676 1668 1700 1708	5 1541 1549 1557 1565 1573 1581 1597 1605 1613 1621 1637 1645 1653 1667 1669 1697 1687 1689 1701 1701 1701	6 1542 1550 1558 1566 1574 1582 1590 1606 1614 1622 1630 1638 1646 1654 1662 1670 1678 1688 1688 1670 1710 1710	7 1543 1551 1559 1567 1575 1583 1599 1607 1615 1623 1631 1639 1647 1655 1663 1655 1663 1671 1679 1687 1703 1711 1719		3400 3410 3420 3430 3440 3500 3510 3520 3550 3550 3550 3550 3550 3560 3550 3660 3630 3640 3630 3640 3630 3640 3650 3650	0 1792 1800 1808 1816 1824 1832 1848 1856 1864 1864 1864 1864 1868 1864 1868 1868	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1897 1905 1913 1921 1929 1937 1945 1953 1961	2 1794 1802 1810 1818 1826 1834 1850 1850 1850 1858 1856 1874 1850 1890 1898 1906 1930 1938 1944 1954 1954 1954	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1997 1907 1931 1931 1933 1931 1955 1963 1971	4 1796 1804 1812 1828 1828 1828 1828 1828 1844 1852 1860 1868 1854 1892 1900 1908 1916 1932 1932 1932 1932 1932 1934	5 1797 1805 1813 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909 1917 1925 1933 1941 1949 1957 1957 1957	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1878 1878 1878 1878 1878 1878 1894 1910 1911 1911 1918 1950 1954 1956 1954	7 1799 1807 1815 1823 1831 1847 1855 1863 1871 1879 1887 1895 1903 1911 1919 1927 1935 1943 1951 1959 1967 1975	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3050 3050 3050 3050 3100 3120 3120 3120 3150 3150 3150 3150 3150 3150 3150 315	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1656 1669 1688 1680 1704	1 1537 1545 1553 1561 1569 1593 1601 1609 1617 1625 1633 1641 1649 1657 1665 1673 1667 1673 1681 1689 1697 1705	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1622 1650 1658 1665 1658 1665 1658 1666 1674 1706 1714 1722	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1643 1651 1659 1667 1675 1683 1691 1699 1707 1715 1723	4 1540 1548 1556 1564 1567 1572 1580 1596 1620 1628 1620 1628 1644 1652 1660 1644 1652 1660 1684 1708 1708 1716 1724	5 1541 1549 1557 1565 1573 1581 1593 1593 1693 1693 1645 1653 1661 1665 16653 1661 1665 1667 1685 1697 1709 1709 1717	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1654 1662 1670 1678 1686 1694 1702 1710 1718 1726	7 1543 1551 1559 1567 1575 1583 1591 1575 1583 1591 1575 1615 1623 1637 1637 1637 1637 1647 1655 1663 1671 1677 1697 1703 1711 1719 1727		3400 3410 3420 3430 3440 3510 3550 3550 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1824 1824 1824 1840 1844 1856 1864 1864 1864 1912 1920 1928 1936 1944 1952 1960 1966 1976	1 1793 1801 1809 1817 1825 1833 1841 1825 1865 1865 1865 1865 1873 1887 1905 1913 1921 1922 1953 1951 1961 1969 1977	2 1794 1802 1810 1818 1826 1834 1850 1858 1866 1874 1889 1906 1914 1922 1930 1938 1946 1954 1962 1970 1978	3 1795 1803 1811 1819 1827 1835 1843 1851 1867 1867 1867 1867 1891 1997 1915 1931 1939 1947 1955 1963 1963 1971 1979	4 1796 1804 1812 1820 1828 1836 1848 1852 1860 1868 1852 1868 1852 1900 1908 1916 1924 1932 1932 1934 1954 1954 1954 1954 1954	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1893 1901 1909 1917 1925 1933 1941 1945 1965 1973 1981	6 1798 1806 1814 1822 1830 1838 1846 1854 1854 1870 1878 1894 1902 1910 1918 1926 1934 1942 1956 1958	7 1799 1807 1815 1823 1831 1847 1855 1863 1871 1875 1903 1991 1919 1927 1943 1951 1955 1967 1967 1967	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3050 3050 3050 3050 305	0 1536 1544 1552 1560 1568 1576 1584 1584 1584 1688 1686 1624 1632 1640 1648 1656 1664 1672 1688 1696 1704 1712 1720	1 1537 1545 1553 1561 1585 1585 1585 1585 1585 1585 1689 1687 1685 1689 1689 1689 1689 1713 1705	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634 1626 1650 1658 1650 1658 1690 1698 1714 1722	3 1539 1547 1555 1563 1571 1579 1687 1687 1687 1687 1687 1687 1687 1687	4 1540 1548 1556 1564 1572 1580 1588 1596 1628 1628 1628 1652 1660 1648 1652 1660 1668 1676 1692 1700 1708 1716 1724	5 1541 1549 1557 1565 1613 1589 1605 1613 1621 1663 1653 1661 1663 1663 1663 1663 166	6 1542 1550 1558 1566 1574 1582 1590 1694 1614 1622 1638 1644 1654 1654 1654 1654 1654 1702 1710 1718 1726	7 1543 1551 1559 1607 1615 1593 1607 1615 1623 1631 1639 1647 1655 1663 1671 1679 1687 1695 1703 1711 1719 1727		3400 3410 3420 3430 3440 3500 3510 3520 3550 3550 3550 3550 3600 3610 3620 3620 3650 3650 3650 3650 3650 3650 3650 365	0 1792 1800 1808 1816 1816 1824 1832 1840 1848 1856 1864 1872 1888 1896 1904 1912 1920 1928 1936 1952 1968 1976	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1849 1897 1905 1913 1921 1929 1937 1965 1969 1977	2 1794 1802 1810 1818 1842 1850 1858 1866 1874 1882 1890 1918 1990 1938 1990 1914 1922 1930 1938 1952 1970 1978	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1875 1963 1997 1907 1915 1963 1931 1937 1947 1979 1987	4 1796 1804 1812 1828 1836 1828 1836 1868 1876 1868 1876 1969 1908 1916 1924 1948 1956 1956 1957 1980	5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1845 1893 1901 1909 1917 1925 1933 1941 1909 1957 1957 1957 1957 1957 1973 1981	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902 1910 1918 1926 1934 1942 1958 1958 1958 1954 1974 1982	7 1799 1807 1815 1823 1831 1831 1855 1867 1867 1887 1887 1887 1903 1911 1959 1945 1959 1955 1963 1955 1963	3000 to 3777 (Octal)	1536 to 2047 (Decimi
3000 3010 3020 3030 3060 3100 3110 3120 3130 3140 3150 3140 3150 3140 3150 3140 3150 3210 3220 3220 3220 3220 3220 3240 3250 3240 3270 3200 3270 3300	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1640 1648 1656 1664 1667 1660 1667 1660 1702 1720 1720	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1687 1687 1681 1649 1657 1663 1681 1673 1681 1673 1681 1713	2 1538 1546 1552 1570 1578 1586 1594 1602 1610 1618 1634 1642 1650 1634 1658 1666 1714 1712 1730	3 1539 1547 1555 1563 1571 1577 1595 1603 1611 1659 1643 1651 1659 1667 1675 1683 1691 1699 1707 1715 1723	4 1540 1548 1564 1564 1564 1564 1564 1564 1588 1596 1604 1628 1660 1668 1664 1652 1660 1708 1716 1724	5 1541 1549 1567 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1661 1669 1677 1685 1685 1687 1709 1717 1725	6 1542 1550 1558 1568 1568 1568 1598 1606 1614 1622 1630 1638 1646 1654 1652 1638 1646 1654 1662 1702 1710 1712 1726	7 1543 1551 1559 1567 1583 1599 1607 1615 1623 1631 1639 1647 1655 1663 1671 1669 1887 1703 1711 1719 1703		3400 3410 3420 3430 3440 3500 3510 3520 3530 3540 3550 3540 3550 3640 3650 3640 3650 3640 3650 3640 3650 3640 3650 3640 3650 3640 3710	0 1792 1800 1808 1816 1824 1840 1840 1840 1840 1848 1856 1864 1904 1912 1920 1928 1936 1944 1952 1960 1958 1976	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1841 1849 1857 1865 1873 1841 1849 1857 1951 1953 1961 1953	2 1794 1802 1810 1818 1826 1834 1850 1858 1856 1874 1850 1890 1898 1996 1930 1938 1944 1952 1950 1958 1958	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1907 1907 1915 1923 1931 1939 1947 1955 1963	4 1796 1804 1812 1820 1828 1836 1860 1868 1844 1852 1860 1868 1916 1908 1916 1932 1932 1934 1935 1934 1935 1945 1945 1956	5 1797 1805 1813 1821 1829 1845 1853 1861 1865 1893 1897 1909 1917 1909 1917 1909 1917 1905 1933 1957 1957 1957 1957 1981	6 1798 1806 1814 1822 1830 1838 1834 1854 1854 1854 1854 1854 1950 1910 1918 1926 1934 1942 1958 1958 1958	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1863 1863 1863 1863 1863 1863 1903 1911 1919 1927 1943 1951 1943 1951 1945 1995	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3050 3050 3100 3120 3130 3130 3130 3140 3130 3140 3150 3140 3150 3140 3120 3220 3220 3220 3220 3220 3220 3250 3220 3250 325	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1672 1720 1728 1736	1 1537 1545 1553 1561 1585 1593 1601 1605 1617 1625 1633 1641 1649 1657 1665 1673 1681 1689 1697 1705 1713 1721	2 1538 1546 1552 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658 1666 1674 1682 1680 1706 1714 1722 1730	3 1539 1547 1555 1563 1571 1577 1595 1603 1611 1619 1627 1633 1651 1659 1667 1675 1683 1691 1691 1707 1715 1723	4 1540 1548 1564 1564 1564 1588 1588 1588 1588 1588 1628 1628 1628 1628 1628 1632 1660 1668 1676 1684 1652 1660 1688 1770 1724 1724	5 1541 1549 1557 1565 1573 1589 1589 1597 1605 1613 1629 1637 1645 1653 1861 1669 1675 1663 1701 1709 1717 1725	6 1542 1550 1558 1566 1574 1580 1690 1598 1606 1614 1622 1630 1638 1654 1654 1654 1770 1718 1726	7 1543 1551 1557 1567 1575 1587 1591 1695 1607 1615 1663 1631 1639 1647 1655 1663 1671 1679 1687 1703 1711 1719 1727 1743		3400 3410 3420 3430 3440 3500 3510 3520 3550 3550 3550 3550 3550 3550 355	O 1792 1800 1808 1816 1824 1840 1848 1856 1864 1868 1868 1868 1896 1904 1912 1920 1936 1944 1952 1960 1968 1976	1 1793 1801 1809 1807 1807 1817 1825 1833 1841 1849 1857 1865 1873 1881 1889 1995 1913 1921 1937 1945 1951 1961 1969 1977	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1914 1922 1930 1938 1946 1954 1962 1970 1978	3 1795 1803 1811 1819 1827 1855 1843 1851 1859 1867 1875 1875 1907 1915 1923 1931 1939 1947 1955 1963 1971 1979 1967	4 1796 1804 1812 1820 1820 1828 1836 1844 1852 1860 1868 1874 1884 1892 1900 1908 1916 1924 1930 1948 1956 1950 1954 1950 1958	5 1797 1805 1813 1821 1829 1845 1853 1861 1865 1893 1877 1885 1893 1901 1909 1917 1925 1933 1941 1949 1957 1965 1973 1981	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1896 1992 1910 1918 1926 1934 1942 1950 1958 1956 1974 1982 2006	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 18671 1879 1887 1903 1911 1919 1919 1951 1955 1967 1967 1995 1967 1995 1997	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3060 3100 3120 3130 3140 3150 3150 3150 3150 3150 3150 3150 315	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1656 1656 1656 1704 1712 1720 1728 1736	1 1537 1545 1553 1561 1567 1585 1593 1607 1685 1693 1687 1685 1685 1685 1687 1685 1689 1687 1713 1721 1729 1737 1745	2 1538 1546 1552 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658 1642 1650 1658 1666 1674 1682 1698 1704 1714 1722	3 1539 1547 1555 1563 1571 1587 1595 1603 1611 1627 1643 1651 1643 1655 1663 1667 1715 1723 1731 1739 1747	4 1540 1548 1556 1564 1572 1580 1620 1628 1620 1628 1640 1628 1640 1652 1660 1644 1652 1700 1708 1716 1724 1732 1740 1748	5 1541 1549 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1665 1661 1669 1677 1685 1661 1701 7709 1717 1725	6 1542 1550 1558 1566 1574 1590 1598 1690 1614 1622 1630 1638 1646 1654 1664 1664 1666 1678 1686 1678 1686 1702 1710 1718 1726	7 1543 1551 1557 1567 1575 1583 1591 1599 1607 1615 1623 1631 1623 1631 1647 1655 1663 1671 1679 1887 1703 1703 1711 1719 1727		3400 3410 3420 3430 3540 3550 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1840 1848 1856 1864 1872 1880 1888 1856 1904 1912 1920 1928 1936 1944 1952 1968 1976 1988	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1813 1881 1873 1881 1897 1905 1913 1921 1929 1937 1965 1953 1969 1977 1965	2 1794 1802 1810 1818 1826 1834 1852 1858 1858 1858 1858 1898 1906 1914 1922 1930 1938 1946 1954 1954 1954 1958 1958	3 1795 1803 1811 1819 1827 1843 1851 1859 1867 1883 1899 1907 1915 1923 1931 1931 1939 1947 1955 1967 1957 1967 1979	4 1796 1804 1812 1820 1828 1844 1852 1868 1876 1884 1876 1884 1876 1990 1908 1916 1932 1940 1932 1948 1956 1954 1952 1950 1958	5 17,97 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1991 1909 1917 1925 1933 1941 1957 1951 1949 1957 1973 1981	6 1798 1806 1814 1822 1830 1854 1854 1866 1854 1866 1894 1902 1910 1918 1926 1934 1942 1934 1934 1958 1958 1958 1954 1958 1954 1958 1954 1958 1954 1954 1954 1954 1954 1955 1954 1955 1954 1955 1955	7 1799 1807 1815 1823 1839 1847 1855 1863 1871 1879 1847 1903 1903 1911 1919 1943 1959 1963 1959 1967 1983	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3060 3100 3100 3110 3120 3130 3140 3150 3130 3140 3150 3160 3170 3210 3220 3220 3220 3220 3220 3220 3240 3220 3240 3220 3330 333	0 1536 1544 1552 1560 1588 1576 1584 1592 1600 1608 1616 1624 1632 1640 1684 1656 1664 1656 1680 1688 1680 1704 1720 1720 1728 1736 1744	1 1537 1545 1553 1561 1553 1561 1577 1585 1593 1601 1609 1617 1685 1633 1641 1649 1657 1665 1673 1681 1689 1705 1705 1717 1745 1753 1751 1753 1751	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1658 1682 1682 1650 1658 1664 1658 1664 1658 1764 1754 1722 1730 1738	3 1539 1547 1555 1563 1571 1579 1587 1579 1587 1579 1687 1683 1681 1659 1667 1675 1683 1683 1691 1691 1707 1715 1723	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636 1644 1652 1660 1668 1676 1684 1652 1700 1708 1716 1722 1740 1748 1756	5 1541 1549 1557 1557 1555 1573 1581 1589 1597 1605 1653 1661 1669 1677 1705 1709 1717 1725 1733 1741 1749	6 1542 1550 1558 1566 1574 1590 1598 1606 1614 1622 1630 1638 1646 1654 1662 1702 1710 1718 1726 1734 1742 1758	7 1543 1551 1557 1567 1575 1583 1631 1623 1631 1647 1655 1663 1671 1679 1687 1683 1703 1711 1719 1727 1735		3400 3410 3420 3430 3510 3540 3550 3550 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1840 1844 1852 1864 1864 1864 1864 1864 1864 1964 1992 1920 1926 1968 1976 1968 1976 1984 1972 2000 2008 2006	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1913 1897 1905 1913 1929 1937 1945 1953 1961 1969 1957 1945 1965 1993 2001 2009 2017	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1914 1922 1930 1938 1944 1954 1954 1954 1954 1954 1954 1954	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1907 1915 1923 1931 1931 1931 1931 1931 1951 1979 1987 1995 2003 2011 2011 2011	4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1884 1852 1900 1948 1916 1924 1930 1948 1956 1950 1956 1956 2004 2012 2012 2012	5 1797 1805 1813 1813 1821 1829 1853 1861 1869 1869 1867 1885 1863 1861 1869 1917 1925 1933 1941 1949 1957 1949 1957 1953 1989 1997 2005 2013 2021	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1910 1918 1992 1934 1942 1934 1934 1934 1934 1934 1934 1934 1934	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1865 1863 1865 1903 1903 1911 1919 1927 1943 1951 1943 1951 1943 1955 1985 1995 1995 1995 1999	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3040 3060 3060 3060 3060 3060 306	0 1536 1544 1552 1560 1568 1576 1584 1576 1584 1576 1584 1576 1688 1696 1608 1648 1656 1664 1672 1720 1720 1720 1720	1 1537 1545 1553 1561 1577 1585 1593 1601 1609 1617 1625 1633 1649 1657 1665 1673 1681 1689 1687 1687 1713 1721 1729 1737 1745 1745 1745 1745	2 1538 1546 1554 1562 1570 1610 1618 1618 1618 1618 1634 1658 1658 1658 1658 1658 1658 1659 1658 1659 1714 1722 1730 1738 1746 1754 1746 1754	3 1539 1547 1563 1571 1579 1587 1579 1687 1611 1619 1627 1643 1651 1659 1667 1675 1683 1651 1659 1667 1715 1713 1731 1731 1747 1747	4 1540 1548 1564 1567 1564 1572 1588 1596 1600 1628 1620 1628 1620 1626 1644 1652 1660 1668 1666 1664 1652 1700 1708 1716 1712 1740 1748 1754	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645 1653 1661 1669 1677 1685 1653 1701 1717 1725 1733 1741 1749	6 1542 1550 1568 1574 1566 1574 1582 1590 1598 1606 1614 1622 1638 1646 1654 1652 1638 1662 1654 1700 1718 1726 1734 1745 1750	7 1543 1551 1567 1575 1583 1591 1599 1607 1615 1623 1631 1663 1663 1663 1663 1663 1663		3400 3410 3420 3430 3430 3450 3510 3510 3520 3550 3550 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1840 1848 1852 1864 1864 1864 1864 1864 1975 1904 1912 1920 1928 1944 1952 1944 1952 1948 1952 1948 1952 1948 1952 1948 1952 1958 195	1 1793 1801 1809 1817 1825 1833 1841 1833 1841 1849 1857 1955 1953 1951 1959 1957 1955 1953 1961 1969 1977 1985 1969 1977	2 1794 1802 1810 1818 1826 1858 1834 1854 1854 1854 1856 1858 1906 1938 1906 1938 1946 1954 1957 1978 1949 1958 1949 1958 1940 1958 1940 1958 1940 1958 1958 1958 1958 1958 1958 1958 1958	3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1885 1867 1885 1867 1885 1867 1885 1997 1907 1915 1931 1939 1947 1955 1963 1971 1979 1987 1979 1987 1979 1987 1979 1987 1979 1987 1979 1987 1979 1987 1979 1987 1979 1987 1979 1979	4 1796 1804 1812 1820 1828 1844 1852 1868 1868 1884 1852 1900 1908 1908 1908 1908 1916 1924 1948 1956 1954 1956 1954 2004 2012 2004 2012	5 17,97 1805 1813 1821 1829 1837 1845 1853 1861 1869 1869 1869 1869 1869 1869 1869	6 1798 1806 1814 1822 1830 1854 1854 1862 1854 1854 1862 1910 1918 1920 1950 1958 1950 1958 1956 1954 1956 1954 1956 1956 2014 2006 2014 2006 2014	7 1799 1807 1815 1823 1831 1831 1839 1847 1855 1863 1867 1885 1903 1911 1919 1951 1951 1955 1943 1951 1959 1967 1975 1983 1991 1999 1997 1995	3000 to 3777 (Octal)	1536 to 2047 (Decima
3000 3010 3020 3030 3060 3100 3120 3130 3140 3150 3150 3150 3150 3150 3150 3150 315	0 1536 1544 1552 1560 1568 1576 1588 1576 1588 1592 1600 1608 1624 1632 1648 1656 1648 1656 1704 1712 1720 1728 1736 1744 1752	1 1537 1545 1553 1561 1577 1585 1593 1601 1609 1617 1625 1633 1649 1657 1649 1657 1768 1673 1681 1689 1777 1705 1721 1729 1737 1753 1751	2 1538 1546 1554 1552 1570 1578 1586 1594 1602 1610 1618 1686 1634 1642 1650 1658 1666 1674 1682 1698 1706 1712 1722 1730 1738	3 1539 1547 1555 1563 1571 1575 1587 1595 1603 1611 1619 1663 1651 1655 1663 1651 1655 1667 1675 1683 1691 1707 1715 1723 1723 1723	4 1540 1546 1556 1564 1576 1580 1580 1580 1580 1580 1580 1580 1604 1612 1622 1660 1648 1652 1660 1684 1652 1660 1700 1708 1710 1724 1720 1740	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1629 1633 1661 1629 1653 1861 1653 1861 1709 1717 1725 1733 1741 1749	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1638 1654 1654 1654 1654 1654 1702 1710 1718 1726 1734 1742 1758 1758	7 1543 1551 1559 1567 1575 1583 1591 1593 1593 1593 1607 1615 1623 1631 1639 1647 1655 1863 1647 1655 1863 1703 1711 1719 1727 1735 1743 1759 1775 1775 1775 1775 1775		3400 3410 3420 3430 3540 3540 3550 3550 3550 3550 355	0 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1864 1864 1872 1960 1928 1936 1936 1952 1956 1952 1960 1952 1956 1957 1952 1956 2008 2016 2008 2016 2008 2016 2024 2022 2008	1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1875 1875 1875 1913 1921 1925 1953 1953 1961 1967 1977 1985 1993 2007 1977	2 1794 1802 1810 1818 1810 1818 1842 1850 1834 1842 1856 1874 1856 1874 1965 1936 1936 1954 1954 1956 1954 1954 1954 1954 2010 2018	3 1795 1803 1811 1811 1819 1827 1835 1843 1859 1867 1875 1863 1891 1907 1915 1939 1937 1931 1937 1955 1963 1971 1979 1987 1979 1987 2003	4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1868 1876 1969 1908 1916 1924 1932 1940 1948 1956 1956 1950 1980 1980 1980 2004 2012 2020 2028 2036	5 17,97 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1991 1901 1907 1933 1941 1949 1997 1945 1949 1997 1947 1949 1997 2005 2005 2003 2021	6 1798 1806 1807 1814 1822 1830 1838 1846 1854 1854 1854 1862 1870 1918 1876 1937 1910 1918 1926 1934 1942 1958 1958 1958 1958 1958 1958 1958 1958	7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1847 1855 1903 1847 1919 1927 1943 1959 1967 1943 1959 1967 1957 1983 1991 1989 1980 198	3000 to 3777 (Octal)	1536 to 2047 (Decima

OCTAL-DECIMAL INTEGER CONVERSION TABLE

		0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7	
4000 2048	4000	2048	2049	2050	2051	2052	2053	2054	2055	3.12	4400	2304	2305	2306	2307	2308	2309	2310	2311	l
to to	4010	2056	2057	2058	2059	2060	2061	2062	2063	Sec.	4410	2312	2313	2314	2315	2316	2317	2318	2319	I
4/11 2559	4020	2064	2065	2066	2067	2068	2069	2070	2071	1337	4420	2320	2321	2322	2323	2324	2325	2326	2327	l
Octali (Decimal)	4030	2012	2013	2074	2075	2076	2011	20/8	2079	100	4430	2328	2329	2330	2331	2332	2333	2334	2335	I
	4040	2080	2081	2082	2083	2084	2085	2086	2087		4440	2336	2337	2338	2339	2340	2341	2342	2343	I
	4050	2088	2089	2090	2091	2092	2093	2094	2095	1.	4450	2344	2345	2346	234/	2348	2349	2350	2351	I
Octal Decimal	4000	2096	2097	2106	2099	2100	2101	2102	2103	6.761	4400	2352	2353	2354	2300	2350	2357	2356	2359	I
10000 4096	4070	2104	2105	2100	2107	2100	2105	2110			44/0	2300	2301	2302	2303	2304	2305	2300	2307	l
20000 8192	4100	2112	2113	2114	2115	2116	2117	2118	2119		4500	2368	2369	2370	23/1	2312	2373	2374	2375	ł
30000 12288	4110	2120	2121	2122	2123	2124	2125	2126	2127		4510	2376	2311	2378	2379	2380	2381	2382	2383	l
40000 16384	4120	2128	2129	2130	2131	2132	2133	2134	2135		4520	2384	2385	2386	2387	2388	2389	2390	2391	I
50000 20480	4130	2136	2137	2138	2139	2140	2141	2142	2143	1.6	4530	2392	2393	2394	2395	2396	2397	2398	2399	ŀ
60000 24576	4140	2144	2145	2140	214/	2148	2149	2150	2151	1111	4540	2400	2401	2402	2403	2404	2405	2406	2407	l
70000 28672	4160	2160	2161	2162	2163	2164	2165	2166	2167		4560	2416	2417	2418	2419	2420	2421	2422	2423	ł
	4170	2168	2169	2170	2171	2172	2173	2174	2175		4570	2424	2425	2426	2427	2428	2429	2430	2431	
	4200	2176	2177	21/8	2179	2180	2181	2182	2183		4600	2432	2433	2434	2435	2436	2437	2438	2439	l
	4210	2184	2185	2186	2187	2188	2189	2190	2191	1.54	4610	2440	2441	2442	2443	2444	2445	2446	2447	l
	4220	2192	2193	2194	2195	2196	2197	2198	2199		4620	2448	2449	2450	2451	2452	2453	2454	2455	ŀ
	4230	2200	2201	2202	2203	2204	2205	2206	2207		4630	2456	2457	2458	2459	2460	2461	2462	2463	l
	4240	2208	2209	2210	2211	2212	2213	2214	2215		4640	2464	2465	2466	2467	2468	2469	2470	2471	l
	4/50	2210	2211	2218	2219	2220	2221	22220	2223	200	4650	24/2	24/3	24/4	24/5	24/0	24//	24/8	24/9	
	42/0	2232	2233	2234	2235	2236	2237	2238	2239		4670	2488	2489	2490	2491	2492	2493	2494	2495	I
	4300	2240	2241	2742	2243	2244	2245	2246	2241		4700	2496	2497	2498	2499	2500	2501	2502	2503	
	4310	2248	2249	2250	2251	2252	2253	2254	2255	MAGE I	4710	2504	2505	2506	2507	2508	2509	2510	2511	I
	4320	2256	2257	2258	2259	2260	2261	2262	2263		4720	2512	2513	2514	2515	2516	2517	2518	2519	I
	4330	2264	2265	2266	2267	2268	2269	2270	2271	3.0	4730	2520	2521	2522	2523	2524	2525	2526	2527	ŀ
	4340	2212	2213	2214	2275	2276	2211	2278	2279		4740	2528	2529	2530	2531	2532	2533	2534	2535	l
	4350	2280	2281	2282	2283	2284	2285	2280	2287	1.14	4/50	2530	2537	2538	2539	2540	2541	2542	2543	l
	4370	2296	2291	2298	2299	2300	2301	2302	2303	100	4770	2552	2553	2554	2555	2556	2545	2558	2559	I
	1	1.									1.1	-								1
		-						-	-	1		-		-	-	-	-	-		1
	[0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7	1
5000 2560	5000	0 2560	1 2561	2 2562	3 2563	4	5 2565	6 2566	7 2567		5400	0 2816	1 2817	2 2818	3 2819	4 2820	5 2821	6 2822	7 2823	
5000 2560 to to	5000 5010	0 2560 2568 2575	1 2561 2569	2 2562 2570	3 2563 2571 2579	4 2564 2572 2590	5 2565 2573 2581	6 2566 2574 2582	7 2567 2575 2582		5400 5410	0 2816 2824	1 2817 2825	2 2818 2826 2824	3 2819 2827 2826	4 2820 2828	5 2821 2829	6 2822 2830	7 2823 2831 2829	
5000 2560 to to 5777 3071	5000 5010 5020 5030	0 2560 2568 2576 2584	1 2561 2569 2577 2585	2 2562 2570 2578 2586	3 2563 2571 2579 2587	4 2564 2572 2580 2588	5 2565 2573 2581 2589	6 2566 2574 2582 2590	7 2567 2575 2583 2591		5400 5410 5420 5430	0 2816 2824 2832 2840	1 2817 2825 2833 2841	2 2818 2826 2834 2842	3 2819 2827 2835 2843	4 2820 2828 2836 2844	5 2821 2829 2837 2845	6 2822 2830 2838 2846	7 2823 2831 2839 2847	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5040	0 2560 2568 2576 2584 2592	1 2561 2569 2577 2585 2593	2 2562 2570 2578 2586 2594	3 2563 2571 2579 2587 2587	4 2564 2572 2580 2588 2596	5 2565 2573 2581 2589 2597	6 2566 2574 2582 2590 2598	7 2567 2575 2583 2591 2599		5400 5410 5420 5430 5440	0 2816 2824 2832 2840 2848	1 2817 2825 2833 2841 2849	2 2818 2826 2834 2842 2850	3 2819 2827 2835 2843 2851	4 2820 2828 2836 2844 2852	5 2821 2829 2837 2845 2853	6 2822 2830 2838 2846 2854	7 2823 2831 2839 2847 2855	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5040 5050	0 2560 2568 2576 2584 2592 2600	1 2561 2569 2577 2585 2593 2601	2 2562 2570 2578 2586 2594 2602	3 2563 2571 2579 2587 2595 2603	4 2564 2572 2580 2588 2596 2604	5 2565 2573 2581 2589 2597 2605	6 2566 2574 2582 2590 2598 2606	7 2567 2575 2583 2591 2599 2607		5400 5410 5420 5430 5440 5440 5450	0 2816 2824 2832 2840 2848 2848 2856	1 2817 2825 2833 2841 2849 2857	2 2818 2826 2834 2842 2850 2858	3 2819 2827 2835 2843 2851 2859	4 2820 2828 2836 2844 2852 2860	5 2821 2829 2837 2845 2853 2853 2861	6 2822 2830 2838 2846 2854 2854 2862	7 2823 2831 2839 2847 2855 2863	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5040 5050 5060	0 2560 2568 2576 2584 2592 2600 2608	1 2561 2569 2577 2585 2593 2601 2609	2 2562 2570 2578 2586 2594 2602 2610	3 2563 2571 2579 2587 2595 2603 2611	4 2564 2572 2580 2588 2596 2604 2612	5 2565 2573 2581 2589 2597 2605 2613	6 2566 2574 2582 2590 2598 2606 2614	7 2567 2575 2583 2591 2599 2607 2615		5400 5410 5420 5430 5440 5450 5460	O 2816 2824 2832 2840 2848 2848 2856 2864	1 2817 2825 2833 2841 2849 2857 2865	2 2818 2826 2834 2842 2850 2858 2856	3 2819 2827 2835 2843 2851 2859 2867	4 2820 2828 2836 2844 2852 2860 2868	5 2821 2829 2837 2845 2853 2861 2869	6 2822 2830 2838 2846 2854 2854 2862 2870	7 2823 2831 2839 2847 2855 2863 2871	
5000 2560 tu to 5777 3071 (Octai) (Decimal)	5000 5010 5020 5030 5040 5050 5060 5070	0 2560 2568 2576 2584 2592 2600 2608 2616	1 2561 2569 2577 2585 2593 2601 2609 2617	2 2562 2570 2578 2586 2594 2602 2610 2618	3 2563 2571 2579 2587 2595 2603 2611 2619	4 2564 2572 2580 2588 2596 2604 2612 2620	5 2565 2573 2581 2589 2597 2605 2613 2621	6 2566 2574 2582 2590 2598 2606 2614 2622	7 2567 2575 2583 2591 2599 2607 2615 2623		5400 5410 5420 5430 5440 5450 5460 5460 5470	O 2816 2824 2832 2840 2848 2856 2864 2872	1 2817 2825 2833 2841 2849 2857 2865 2873	2 2818 2826 2834 2842 2850 2858 2856 2858 2866 2874	3 2819 2827 2835 2843 2851 2859 2867 2875	4 2820 2828 2836 2844 2852 2860 2868 2876	5 2821 2829 2837 2845 2853 2861 2869 2877	6 2822 2830 2838 2846 2854 2854 2862 2870 2878	7 2823 2831 2839 2847 2855 2863 2871 2879	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5040 5050 5060 5070 5100	0 2560 2568 2576 2584 2592 2600 2608 2616 2624	1 2561 2569 2577 2585 2593 2601 2609 2617 2625	2 2562 2570 2578 2586 2594 2602 2610 2618 2626	3 2563 2571 2579 2587 2595 2603 2611 2619 2627	4 2564 2572 2580 2588 2596 2604 2612 2620 2628	5 2565 2573 2581 2589 2597 2605 2613 2621 2629	6 2566 2574 2582 2590 2598 2606 2614 2622 2630	7 2567 2575 2583 2591 2599 2607 2615 2623 2631		5400 5410 5420 5430 5440 5450 5460 5470 5500	0 2816 2824 2832 2840 2848 2856 2864 2872 2880	1 2817 2825 2833 2841 2849 2857 2865 2873 2881	2 2818 2826 2834 2842 2850 2858 2866 2874 2882	3 2819 2827 2835 2843 2851 2859 2867 2875 2883	4 2820 2828 2836 2844 2852 2860 2868 2876 2884	5 2821 2829 2837 2845 2853 2861 2869 2877 2885	6 2822 2830 2838 2846 2854 2854 2862 2870 2878 2886	7 2823 2831 2839 2847 2855 2863 2871 2879 2887	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5040 5050 5050 5050 5050 5070 5100 5110	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2624 2624 2632 2640	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2625 2623 2641	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2626 2626	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2623 2642	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2628 2628	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2629 2637 2645	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2631 2639 2641		5400 5410 5420 5430 5450 5450 5460 5470 5500 5500	0 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2888 2888	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2881 2881 2889 2893	2 2818 2826 2834 2842 2850 2858 2866 2874 2882 2882 2882 2899	3 2819 2827 2835 2843 2851 2859 2867 2875 2863 2891 2883 2891	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2884	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2877 2885 2893	6 2822 2830 2838 2846 2854 2854 2854 2870 2878 2878 2886 2894 2889	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2887 2887	
5000 2560 to to 5777 3071 (Uctal) (Decimal)	5000 5010 5020 5030 5040 5050 5070 5100 5110 5120 5130	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2624 2624 2632 2648	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2649	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2650 2650	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2645 2651	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2628 2624 2652	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2653	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2638 2654	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655		5400 5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5530	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2897 2905	2 2818 2826 2834 2842 2850 2858 2866 2874 2882 2890 2898 2906	3 2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2891 2899 2907	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2990 2908	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909	6 2822 2830 2838 2846 2854 2854 2854 2870 2878 2886 2894 2992 2910	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2903 2911	
5000 2560 to to 5777 3071 (Uctal) (Decimal)	5000 5010 5020 5030 5040 5050 5070 5100 5110 5120 5130 5140	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2624 2624 2640 2648 2656	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2626 2634 2650 2658	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2643 2651 2659	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2628 2628 2624 2652 2660	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2654 2654 2654	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663		5400 5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5530 5540	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2887 2905 2913	2 2818 2826 2834 2842 2850 2858 2866 2874 2882 2882 2882 2890 2898 2906 2914	3 2819 2827 2835 2843 2851 2859 2867 2875 2867 2875 2883 2891 2899 2907 2915	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2877 2885 2893 2901 2909 2917	6 2822 2830 2838 2846 2854 2854 2862 2870 2878 2886 2894 2902 2910 2918	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2887 2887 2887 2903 2911 2919	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5060 5070 5100 5110 5120 5130 5140 5150	0 2560 2568 2576 2592 2600 2608 2616 2624 2624 2632 2640 2648 2656 2664	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2657 2655 2655	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2652 2658 2658 2658 2656	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2659 2667	4 25564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2656 2644 2660 2668	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669	6 25566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646 2654 2656 2656 2670	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2671		5400 5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5520 5530 5550	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920	1 2817 2825 2833 2841 2849 2855 2873 2865 2873 2881 2889 2897 2905 2913 2921	2 2818 2826 2834 2842 2850 2858 2866 2874 2882 2890 2898 2906 2914 2922	3 2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907 2915 2923	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916 2924	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925	6 2822 2830 2838 2846 2854 2862 2870 2878 2886 2894 2902 2910 2918 2926	7 2823 2831 2839 2847 2863 2863 2871 2879 2887 2895 2903 2911 2919 2927	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5050 5050 5060 5070 5100 5110 5120 5130 5140 5150 5160	0 2560 2568 2576 2594 2592 2600 2608 2616 2624 2632 2640 2648 2656 2664 2656 2664	1 2561 2569 2577 2585 2593 2601 2609 2617 2609 2617 2625 2633 2641 2649 2657 2665 2673	2 2562 2570 2578 2586 2596 2602 2610 2618 2626 2634 2652 2658 2658 2658 2658 2658	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2659 2667 2659 2667 2675	4 25564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2645 2660 2668 2660 2668 2676	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 26453 2665 2665 2665 2665 2667 2669 2677	6 25566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646 2654 2665 2665 26670 2678	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2663 2671 2679		5400 5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5550 5550 5550 5550	O 2816 2824 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920 2928	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2921 2929	2 2818 2826 2834 2850 2858 2866 2874 2882 2890 2898 2906 2914 2922 2930	3 2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907 2915 2923 2931	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916 2924 2932	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2909 2917 2909 2917 2925 2933	6 2822 2830 2838 2846 2854 2862 2870 2878 2886 2894 2900 2918 2926 2934	7 2823 2831 2839 2847 2853 2863 2871 2879 2887 2887 2887 2895 2903 2911 2919 2927 2935	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5050 5070 5100 5110 5120 5130 5140 5150 5160 5170	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648 2656 2664 2656 2664 2672 2680	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2652 2650 2658 2666 2674 2682	3 2563 2571 2595 2603 2611 2619 2627 2635 2663 2651 2659 2667 2675 2683	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2652 2660 2668 2660 2668 2676 2684	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677 2685	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2654 2654 2654 2654 2656 2670 2678 2686	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2671 2679 2687		5400 5410 5420 5430 5440 5450 5460 5470 5510 5510 5520 5530 5550 5550 5550 5550 5560 5570	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2888 2904 2912 2920 2928 2936	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2929 2937	2 2818 2826 2834 2850 2858 2866 2874 2882 2890 2898 2906 2914 2922 2930 2938	3 2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907 2915 2923 2931 2939	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916 2924 2932 2940	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941	6 2822 2830 2838 2846 2854 2854 2854 2870 2878 2886 2894 2902 2910 2918 2926 2934 2942	7 2823 2831 2839 2847 2855 2863 2871 2855 2867 2895 2903 2911 2919 2927 2935 2943	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5050 5050 5070 5110 5120 5110 5120 5130 5140 5150 5160 5170	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2662 2640 2648 2656 2664 2672 2680 2688	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681 2689	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2626 2654 2650 2658 2666 2674 2682 2690	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2651 2659 2667 2675 2683 2691	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2644 2652 2660 2668 2646 2652 2660 2668 2676 2684 2692	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677 2685 2653	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646 2654 2662 2670 2678 2686 2694	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2671 2679 2687 2695		5400 5410 5420 5430 5430 5440 5440 5440 5510 5510 5550 5550 555	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920 2928 2936 2944	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2929 2937 2945	2 2818 2834 2834 2850 2858 2856 2874 2882 2890 2898 2906 2914 2922 2930 2938 2946	3 2819 2827 28355 2843 2851 2859 2867 2875 2883 2891 2891 2891 2891 2907 2915 2923 2931 2939 2947	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2908 2916 2928 2916 2924 2932 2940 2948	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941 2949	6 2822 2830 2838 2846 2854 2854 2870 2878 2886 2894 2902 2910 2918 2926 2934 2942 2950	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2911 2919 2927 2935 2943 2951	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5060 5070 5100 5110 5120 5130 5140 5150 5170 5200 5210	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648 2656 2664 2672 2680 2688 2696	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681 2689 2697	2 2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642 2650 2658 2666 2674 2682 2690 2698	3 2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2651 2659 2667 2675 2683 2691 2699 2699	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2652 2660 2668 2668 2668 2668 2668 2668 266	5 2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677 2685 2693 2701	6 2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646 2638 2646 2654 2662 2670 2678 2686 2694 2702	7 2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2671 2679 2687 2695 2703		5400 5410 5420 5420 5440 5450 5470 5510 5520 5550 5550 5550 5550 5550 555	O 2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920 2928 2936 2936	1 2817 2825 2833 2841 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2929 2937 2945 2953	2 2818 2826 2834 2850 2858 2858 2858 2858 2858 2858 2858	3 2819 2827 2835 2843 2859 2867 2875 2883 2891 2899 2907 2915 2915 2923 2931 2939 2939 2947	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916 2924 2932 2940 2948 2956	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941 2949 2957	6 2822 2830 2838 2846 2854 2870 2878 2886 2894 2902 2910 2918 2926 2934 2942 2950 2958	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2911 2919 2927 2935 2943 2951 2959 2959	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5060 5070 5100 5110 5120 5130 5140 5150 5140 5120 5220 5220 5220	0 2560 2568 2576 2584 2592 2600 2608 2616 2624 2656 2656 2656 2656 2656 2656 265	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2657 2657 2681 2689 2697 2705	2 2562 2570 2578 2586 2602 2602 2602 2610 2618 2626 2634 2650 2658 2656 2658 2656 2658 2658 2658 2666 2674 2682 2690 2716	3 2563 2571 2579 2587 2595 2603 2611 2619 2657 2658 2659 2659 2659 2659 2699 2707 2015	4 2564 2572 2580 2588 2596 2604 2652 2660 2628 2650 2668 2660 2668 2660 2668 2660 2668 2660 2668 2660 2668 2660 2668 2676 2664 2672 2702 2702 2702 2702 2702 2702 2702	5 2565 2573 2581 2587 2605 2605 2613 2621 2629 2653 2651 2669 2667 2685 2669 2677 2685 2693 2701 2709	6 2566 2574 2582 2590 2606 2614 2652 2652 2652 2652 2652 2652 2652 265	7 2567 2575 2583 2591 2599 2667 2663 2663 2663 2663 2663 2663 2663		5400 5410 5420 5420 5430 5440 5470 5540 5550 5550 5550 5550 555	0 2816 2824 2822 2840 2848 2856 2864 2856 2864 2872 2888 2896 2904 2912 2920 2928 2936 2936 2936 2944 2952 2969	1 2817 2825 2833 2841 2869 2857 2865 2873 2881 2889 2905 2913 2913 2921 2929 2937 2945 2953 2961	2 2818 2826 2834 2850 2858 2858 2858 2858 2858 2858 2858	3 2819 2827 2835 2843 2859 2867 2875 2883 2891 2899 2907 2915 2923 2931 2939 2939 2947 2955 2963	4 2820 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2909 2908 2916 2924 2932 2940 2956 2956	5 2821 2829 2837 2845 2861 2869 2877 2885 2893 2901 2909 2917 2917 2917 2925 2933 2941 2949 2957 2965	6 2822 2830 2848 2854 2852 2870 2878 2886 2894 2910 2910 2918 2918 2918 2918 2918 2918 2919 2919	7 2823 2831 2839 2847 2855 2863 2879 2887 2895 2903 2911 2919 2927 2935 2943 2951 2959 2965 2925	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5060 5070 5100 5120 5130 5140 5150 5160 5170 5200 5210 5220 5220 5220 5230	0 2560 2568 2576 2582 2692 2600 2608 2616 2624 2632 2640 2648 2656 2664 2656 2664 2658 2668 2669 2672 2672 2680 2672 2672 2680 2772 2720	1 2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2649 2657 2649 2657 2663 2689 2697 2705 2711	2 2562 2570 2586 2594 2602 2610 2618 2626 2634 2652 2650 2658 2656 2658 2666 2658 2662 2659 2669 2669 2698 2706 2710	3 2563 2571 2587 2587 2585 2663 2651 2653 2651 2659 2667 2675 2683 2651 2675 2683 2667 2675 2683 2677 2783	4 2564 2572 2580 2588 2596 2664 2612 2628 2636 2644 2652 2660 2668 2666 2668 2676 2684 2672 2676 2684 2672 2708 2716 2724	5 2565 2573 2581 2587 2605 2613 2621 2629 2637 2653 2661 2669 2653 2667 2685 2693 2701 2709 2717 2725	6 2566 2574 2582 2598 2698 2614 2627 2630 2638 2646 2654 2654 2654 2654 2662 2654 2662 2678 2668 2678 2678 2678 2678 2702 2710 2710 2710 2710 2710 2710 2710	7 2567 2575 2583 2591 2607 2615 2623 2631 2637 2647 2655 2663 2679 2687 2679 2687 2679 2687 2679 2679 2679 2679 2679 2679 2679 267		5400 5410 5420 5430 5450 5450 5550 5550 5550 5550 555	0 2816 2824 2832 2840 2856 2864 2872 2880 2888 2896 2994 2912 2920 2924 2928 2936 2924 2928 2936 2944 2952 2960 2964	1 2817 2825 2833 2841 2857 2865 2873 2887 2887 2897 2905 2913 2929 2905 2937 2929 2937 2929 2937 2945 2953 2961 2965	2 2818 2826 2834 2842 2850 2858 2858 2858 2856 2874 2898 29906 2914 2930 2938 2938 2938 2938 29354 2954 2954	3 2819 2827 2835 2843 2859 2867 2875 2883 2891 2899 2907 2915 2923 2939 2937 2939 2939 2947 2955 2963 2939	4 2820 2828 2836 2844 2852 2860 2868 2876 2900 2908 2916 2924 2932 2940 2948 2956 2954 2954 2954 2956	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2917 2925 2909 2917 2925 2937 2941 2949 2941 2949 2957 2945 2943	6 2822 2830 2838 2845 2854 2854 2854 2854 2857 2878 2894 2902 2910 2918 2934 2934 2934 2942 2942 2950 2958 2946	7 2823 2831 2845 2863 2867 2855 2863 2879 2887 2895 2903 2911 2919 2927 2911 2919 2927 2943 2943 2943 2951 2959 2967 2975	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5050 5070 5110 5120 5130 5130 5140 5150 5170 5210 5220 5220 5220 5220 5220 5220 522	0 2560 2568 2576 2582 2692 2600 2608 2616 2632 2640 2648 2644 2632 2648 2648 2648 2648 2648 2648 2648 264	1 2561 2569 2577 2585 2593 2601 2609 2617 2665 2633 2641 2649 2657 2649 2657 2649 2657 2663 2681 2689 2689 2705 2713 2721	2 2562 2570 2578 2586 2594 2610 2618 2626 2634 2652 2650 2658 2656 2658 2662 2650 2658 2662 2674 2682 2690 2698 2716 2722 2730	3 2563 2571 2587 2587 2585 2663 2651 2653 2651 2655 2663 2655 2663 2665 2663 2675 2683 2683 2683 2683 2691 2707 2715 2723 2731	4 2564 2572 2580 2588 2596 2664 2612 2628 2636 2648 2652 2660 2668 2676 2684 2676 2684 2670 2708 2716 2718	5 2565 2573 2581 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677 2685 2685 2685 2693 2701 2709 27117 7225 2733	6 2566 2574 2582 2590 2614 2652 2630 2634 2654 2654 2654 2654 2654 2654 2654 265	7 2567 2575 2583 2591 2607 2615 2623 2631 2637 2655 2663 2671 2655 2667 2667 2667 2667 2667 2679 2687 2687 2687 2703 2711 2711 2712 2727 2713		5400 5410 5420 5430 5440 5450 5540 5550 5550 5550 555	0 2816 2824 2832 2848 2856 2864 2864 2862 2862 2888 2896 2900 2928 2936 2936 2936 2952 2952 2956 2956 2956 2956	1 2817 2825 2833 2841 2857 2857 2865 2873 2887 2897 2905 2913 2921 29295 2937 2937 2945 2953 2961 2965 2954	2 2818 2826 2834 2842 2858 2858 2858 2890 2914 2930 2930 2938 2938 2938 2938 2936 2954 29570 2970 2978	3 2819 2827 2835 2843 2859 2867 2897 2897 2897 2997 2915 2923 2937 2939 2947 2955 2963 2939 2947 2955 2963 2931	4 2820 2828 2836 2844 2852 2860 2868 2876 2884 2990 2908 2916 2924 2938 2916 2924 2930 2948 2940 2948 2956 2964 2956 2964	5 2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2939 2917 2925 2939 2941 2949 2957 2941 2957 2951 2957 2951 2951 2957 2951 2957 2951 2959 2957 2951 2959 2957 2951 2959 2957 2959 2959 2959 2959 2959 2959	6 2822 2830 2838 2846 2854 2854 2854 2894 2902 2910 2918 2934 2934 2934 2934 2934 2942 2950 2954 2954 2954 2954 2950	7 2823 2831 2847 2855 2863 2863 2871 2879 2887 2903 2911 2911 2919 2927 2943 2943 2951 2959 2967 2975 2987 29951	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5060 5070 5110 5120 5140 5140 5150 5140 5150 5160 5210 5220 5220 5220 5220 5220 5220 5250	0 2560 2568 2576 2584 2592 2600 2608 2612 2640 2642 2642 2642 2644 2656 2664 2656 2664 2656 2664 2656 2664 2656 2664 2704 2704 2712 2704	1 2561 2569 2577 2593 2601 2607 2607 2607 2607 2657 2665 2657 2665 2667 2665 2667 2668 2667 2668 2667 2705 2771 2721 2729	2 2562 2570 2578 2594 2602 2610 2618 2661 2618 2664 2658 2664 2658 2666 2658 2666 2658 2666 2658 2666 2658 2666 2764 2658 2666 2714 2730 2730	3 2563 2571 2579 2585 2603 2611 2619 2627 2635 2643 2659 2667 2659 2667 2669 2667 2669 2669 2669 2669 266	4 2564 2572 2588 2596 2604 2612 2620 2628 2636 2664 2652 2668 2660 2668 2660 2668 2660 2668 2660 2668 2700 2708 2716 2718 2716 2718	5 2565 2573 2587 2587 2605 2613 2621 2629 2637 2645 2653 2669 2669 2669 2709 2709 2717 2729 2709 2719 2733 2741	6 2566 2574 2582 2590 2614 2622 2638 2654 2654 2654 2654 2652 2670 2678 2686 2654 2702 2710 2718 2718 2726	7 2567 2583 2599 2607 2615 2623 2639 2647 2655 2663 2663 2663 2667 2687 2687 2687 2687 2687 2687 2703 2711 2711 2711 2712 2713		5400 5410 5420 5430 5440 5450 5540 5550 5550 5550 555	0 2816 2824 2832 2848 2856 2864 2872 2888 2896 2904 2912 2920 2928 2936 2936 2936 2950 2958 2956 2958 2956	1 2817 2825 2833 2849 2857 2865 2873 2887 2905 2913 2921 2921 2921 2923 2937 2945 2969 2969 2969 2967 2969	2 2818 2826 2834 2850 2858 2866 2874 2890 2898 2906 2914 2922 2930 2938 2946 2952 2970 2978 2962 2970 2978	3 2819 2827 2835 2843 2859 2867 2875 2895 2897 2915 2923 2931 2939 2927 2939 2923 2939 2947 2955 2963 2971 2979 2967	4 2820 2828 2836 2842 2852 2852 2852 2856 2876 2982 2990 2908 2996 2924 2932 2940 2924 2954 2954 2954 2954 2956 2956	5 2821 2829 2837 2845 2863 2861 2867 2897 2985 2991 2997 2995 2933 2941 2949 2955 2973 2981 2989 2981 2989	6 2822 2830 2838 2846 2854 2870 2878 2894 2902 2910 2918 2992 2910 2918 2924 2934 2942 2950 2958 2956 2974 2986 2974	7 2823 2831 2839 2847 2855 2863 2871 2879 2887 2993 2911 2917 2927 2935 2943 2951 2951 2957 2967 2967 2975 2983	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5060 5070 5120 5120 5120 5120 5210 5210 5220 522	0 2568 2576 2584 2592 2608 2616 2632 2648 2656 2664 2652 2648 2656 2664 2652 2688 2696 2704 2712 2720 2728 2736 2734	1 2561 2567 2587 2585 2593 2609 2617 2609 2617 2605 2641 2649 2657 2665 2665 2665 2665 2665 2665 2665	2 2562 2550 2588 2594 2610 2618 2626 2634 2650 2658 2650 2658 2666 2668 2668 2668 2668 2668 2668	3 2563 2571 2579 2587 2595 2603 2611 2619 2651 2653 2651 2657 2667 2667 2667 2667 2667 2667 2667	4 2564 2572 2588 2596 2604 2612 2620 2620 2628 2636 2668 2668 2668 2668 2668 2668	5 2565 2573 2587 2657 2657 2657 2657 2657 2655 2669 2669 2669 2669 2669 2669 2669	6 2566 2574 2582 2598 2606 2614 2622 2638 2654 2654 2654 2652 2662 2658 2662 2658 2662 2658 2662 2702 2702 2702 2710 2718 2726 2734 2734 2734	7 2567 2583 2599 2607 2615 2623 2639 2647 2655 2663 2663 2663 2663 2667 2669 2687 2687 2685 2719 2719 2719 2719 2719 2719 2719 2719		5400 5420 5430 5430 5440 5440 5540 5550 5550 555	0 2816 2824 2832 2840 2848 2856 2864 2856 2896 2990 2990 2990 2990 2992 2992 2992 29	1 2817 2825 2833 2841 2865 2873 2885 2905 2915 2995 2992 2993 2992 2993 2992 2993 2993	2 2818 2826 2834 2850 2858 2866 2874 2890 2898 2906 2914 2922 2930 2938 2946 2952 2952 2954 2962 2970 2978 2966 2994 3002	3 2819 2827 2835 2843 2859 2867 2875 2883 2891 2899 2907 2915 2923 2931 2939 2947 2953 2963 2963 2963 2971 2979 2987 2995 3003	4 2820 2828 2836 2862 2864 2852 2868 2876 2884 2990 2908 2916 2924 2932 2930 2932 2940 2932 2940 2934 2956 2956 2972 2988 2956 2972 2988 2956 2976 2978 2976 2978 2976 2978 2976 2978 2976 2978 2976 2978 2976 2978 2976 2978 2976 2976 2976 2977 2976 2976 2976 2976	5 2821 2829 2837 2845 2869 2869 2869 2887 2909 2917 2925 2933 2941 2949 2957 2933 2941 2949 2957 2933 2941 2949 2957 2957 2957 2985	6 2822 2830 2838 2846 2854 2870 2878 2892 2910 2918 2926 2934 2942 2934 2942 2950 2958 2956 2974 2956 2974 2986 2974 2986 2974 2989 2998 3006	7 2823 2831 2839 2847 2855 2863 2871 2895 2903 2911 2919 2927 2935 2943 2951 2957 2967 2967 2967 2967 2967 2967 2999 3007	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5060 5070 5100 5120 5120 5120 5210 5210 5220 522	0 2560 2564 2576 2584 2592 2608 2616 2632 2640 2648 2656 2664 2652 2688 2656 2664 2704 2712 2720 2704 2712 2726	1 2561 2569 2577 2585 2593 2609 2617 2609 2617 2609 2641 2649 2655 2665 2665 2665 2665 2665 2705 2713 2721 2729 2717 27245	2 2562 2570 2578 2586 2594 2610 2618 2626 2634 2650 2658 2650 2658 2654 2650 2658 2654 2652 2650 2658 2654 2652 2659 2706 2714 2738 2714 2735 27354 27355 27355 27355 27555 2757575 2757575 2757575 27575 2757575 27575 27575 2757575 2757575 2757575 275757575	3 2563 2571 2579 2587 2595 2603 2611 2619 2657 2653 2651 2657 2657 2657 2657 2657 2657 2657 2657	4 2564 2572 2588 2596 2604 2632 2632 2632 2636 2644 2652 2668 2668 2668 2668 2668 2700 2708 2708 2716 2724 2748 2748	5 2565 2573 2589 2589 2659 2631 2621 2639 2645 2645 2669 2669 2669 2669 2669 2701 2709 2717 2733 2741 2743 2741 2749	6 2566 2574 2580 2590 2598 2606 2698 2606 2638 2646 2654 2654 2654 2654 2669 22678 2686 2694 2702 2718 2718 2726 2713 2714 2750	7 2567 2575 2697 2697 2615 2623 2631 2639 2647 2655 2667 2679 2687 2695 2671 2679 2687 2695 2713 2711 2719 2715 2715 2743 2751 2755 2753 2755 2755 2755 2755 2697 2717 2715 2715 2715 2715 2759 275		5400 5420 5420 5430 5440 5440 5540 5510 5550 5550 5550 555	0 2816 2824 2832 2840 2848 2856 2864 2856 2896 2994 2992 2992 2992 2928 2936 2944 2952 2968 2976 2968 2976 2968 2976 2968 2976 2984 2992 3000	1 2817 2825 2833 2841 2865 2873 2865 2915 2915 2921 2929 2937 2929 2937 2945 2961 2969 2977 2969 2977 2969 2977 2965 2961 2969 2977 2965 2961 2961 2961 2965 2973 2965 2973 2955 2955 2957 2955 2957 2057 205	2 2818 2826 2834 2850 2858 2866 2874 2882 2996 2996 2930 2938 2946 2952 2942 2952 2943 2952 2954 2954 2954 2954 2954 2954 2954	3 2819 2827 2843 2851 2857 2883 2891 2907 2915 2923 2931 2931 2939 2947 2955 2963 2931 2939 2947 2955 2963 2931 2939 2947 2955 3003 3011	4 2820 2828 2836 2862 2864 2852 2868 2876 2884 2990 2998 2916 2924 2932 2930 2932 2940 2932 2940 2934 2954 2956 2954 2956 2956 2956 2956 2956 2956 2956 2956	5 2821 2829 2837 2845 2869 2869 2869 2809 2909 2917 2925 2933 2941 2949 2957 2933 2941 2949 2957 2953 2941 2949 2957 3055 3013	6 2822 2830 2838 2846 2854 2862 2870 2878 2886 2934 2930 2934 2934 2934 2934 2934 2934 2934 2934	7 2823 2831 2839 2867 2865 2863 2867 2867 2895 2903 2911 2919 2927 2935 2943 2951 2955 2967 2975 2967 2975 2989 2999 3007 3015	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5050 5050 5050 5100 5110 5130 5140 5150 5160 5170 5210 5220 5220 5220 5220 5220 5220 5250 5240 5250 5240 5250 525	0 2560 2568 2584 2592 2600 2608 2616 2632 2656 2656 2656 2656 2656 2656 265	1 2561 2562 2593 2691 2697 2697 2697 2697 2697 2697 2705 2689 2697 2705 2713 2721 2729 2737 2745	2 2562 2570 2586 2594 2602 2610 2618 2664 2654 2654 2654 2665 2664 2664 2664	3 2563 2571 2587 2587 2595 2663 2661 2659 2655 2663 2659 2667 2665 2669 2707 2715 2723 2731 2739 2747 2735 2747	4 2564 2572 2588 2596 2604 2632 2644 2652 2660 2668 2676 2684 2692 2700 2708 2706 2708 2716 2714 2714 2714	5 2565 2573 2589 2589 2597 2605 2653 2661 2669 2663 2663 2701 2709 2707 2703 2701 2717 2717 2717 27149 2741 2749	6 2566 2574 2580 2590 2598 2606 2638 2664 2662 2654 2654 2654 2654 2656 2657 2658 2658 2658 2669 2710 2718 2726 2735 2745 2745 2745 2745 2745 2745 2745 274	7 2567 2575 2591 2599 2697 2655 2663 2655 2663 2679 2655 2663 2679 2655 2663 2679 2655 2669 2703 2711 2719 2727 2735 2743 2751 2759 2757 2759 2767 2767 2767 2657 2703 2711 2713 2715 2713 2715 2713 2715 2713 2715 2713 2715 2755 2755 2755 2715 2715 2715 275		5400 5410 5420 5430 5440 5450 5540 5540 5550 5550 555	0 2816 2822 2832 2840 2842 2856 2856 2856 2896 2992 2920 2922 2920 2922 2926 2936 2952 2952 2956 2952 2956 2954 2952 2956 2952 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2956 2957 2957 2957 2956 2957 2956 2957 2957 2957 2957 2957 2956 2957 2957 2956 2957 2957 2956 2957 2057 205	1 2817 2825 2833 2841 2857 2857 2857 2857 2857 2857 2913 2921 2929 2937 2933 2945 2953 2953 2961 2953 2957 295	2 2818 2826 2834 2850 2858 2866 2858 2866 2914 2926 2930 2930 2938 2946 2954 2954 2954 2957 2970 2978 2970 2978 2970 2978 2994 3002	3 2819 2827 2843 2851 2857 2883 2891 2907 2915 2923 2939 2947 2955 2947 2955 3003 3011 3019	4 2820 2828 2836 2844 2852 2860 2868 2876 2989 2990 2908 2932 2930 2938 2932 2934 2935 2956 2956 2956 2956 2956 2956 2956 295	5 2821 2829 2837 2845 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941 2949 2957 2955 2957 2957 2957 2957 2957 295	6 2822 2830 2838 2846 2854 2867 2878 2886 2994 2910 2918 2936 2934 2934 2934 2934 2934 2934 2934 2934	7 2823 2831 2839 2847 2855 2863 2879 2887 2995 2911 2919 2935 2943 2951 2959 2955 2959 2957 2975 2983 2957 2975 2983 2077 307 3007 3015 3023 3021	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5030 5050 5070 5100 5120 5130 5130 5140 5150 5160 5170 5210 5220 5240 5250 5240 5250 5250 5250 525	0 2560 2568 2576 2584 2592 2600 2608 2616 2648 2656 2648 2656 2064 2680 2680 2680 2704 2712 2680 2704 2712 2720 2728 2736 2724 2744 2752 2744 2752 2746 2754 2754 2754 2754 2754 2754 2757 2754 2757 2757	1 2561 2565 2593 2601 2609 2617 2625 2633 2641 2649 2647 2665 2673 2681 2689 2687 2705 2705 2713 2721 2729 2737 2745 2745 2745	2 2562 2570 2586 2594 2602 2662 2664 2658 2658 2658 2658 2666 2674 2682 2666 2674 2682 2698 2706 2718 2730 2738 2746 27270 2746 2746 2746 2746 2746 2746 2746 2746	3 2563 2571 2587 2587 2587 2587 2683 2661 2651 2653 2663 2664 2665 2663 2667 2667 2667 2663 2669 2707 2715 2723 2731 2733 2731 2739 2747 2755 2763 2747	4 2564 2572 2588 2598 2598 2604 2617 2628 2664 2652 2668 2668 2668 2668 2668 2668 2668	5 2565 2573 2589 2597 2605 2613 2621 2629 2637 2645 2669 2669 2669 2669 2709 2709 2709 2709 2717 2709 2717 2709 2717 2749 2749 2749 2749 2745 2745 2745 2745 2745 2745 2745 2745	6 2566 2574 2582 2590 2696 2692 2696 2694 2692 2696 2654 2664 2664 2664 2664 2664 2668 2694 2702 2710 2710 2712 2710 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27166 27158 27160 27158 27160 27158 27160 27158 27160 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2717 2710 2710	7 2567 2573 2583 2591 2697 2615 2623 2639 2639 2639 2639 2639 2639 2667 2667 2667 2679 2687 2703 2711 2715 2759 2767 2759 2757 2777 2775 2775 2775 2775 2775 2775 2775 2775 2775 2775 2757 2757 2757 2757 2757 2757 2757 2757 2757 2757 2775 2775 2775 2775 2775 2775 2775 2775 2775 2775 2775 2757 275		5400 5410 5420 5430 5440 5450 5460 5540 5550 5550 5550 555	0 2816 2824 2840 2840 2840 2840 2846 2856 2864 2872 2892 2904 2912 2920 2922 2924 2936 2952 2952 2956 2952 2956 2956 2956 2957 2956 2956 2957 2956 2957 2957 2958 2956 2957 2957 2958 2956 2957 2976 2976 2976 2977 2976 2977 2970 3008 3037 207	1 2817 2825 2833 2841 2849 2857 2865 2873 2885 2893 2985 2913 2921 2929 2937 2925 2953 2961 2953 2961 2953 2961 2995 2995 3001 3009 3009	2 2818 2826 2834 2852 2858 2866 2874 2852 2896 2934 2946 2934 2942 2930 2938 2946 2954 2952 2930 2948 2954 2954 2954 2954 3002 3010 3028 302	3 2819 2827 2843 2851 2867 2875 2883 2897 2907 2915 2923 2937 2937 2939 2947 2955 2963 2955 2963 2971 2955 2963 3003 3011 3019 3027	4 2820 2828 2836 2844 2852 2868 2876 2888 2916 2900 2908 2916 2924 2932 2940 2924 2932 2940 2924 2956 2956 2956 2956 2956 2956 2956 2956	5 2821 2829 2837 2845 2853 2869 2869 2867 2909 2917 2909 2917 2925 2933 2941 2949 2957 2957 2957 2957 2957 2957 2957 3005 30013 3021	6 2822 2830 2846 2854 2852 2870 2878 2862 2980 2910 2918 2926 2934 2942 2958 2958 2958 2958 2958 2958 2958 295	7 2823 2831 2847 2853 2847 2853 2903 2911 2919 2927 2935 2943 2959 2967 2959 2967 2959 2967 2959 2959 2959 2959 2959 2959 2959 295	
5000 2560 to to 5777 3071 (Octal) (Decimal)	5000 5010 5020 5040 5050 5070 5100 5120 5130 5130 5140 5150 5170 5220 5220 5220 5220 5220 5220 5220 52	0 2560 2568 2576 2584 2592 2680 2608 2668 2664 2664 2664 2664 2664 2664 266	1 2561 2567 2585 2697 2601 2609 2617 2609 2617 2663 2663 2663 2663 2663 2663 2667 2663 2667 2705 2713 2712 2715 2713 2714 2715 2715 2715 2715 2715 2715 2715 2715	2 2562 2570 2586 2598 2598 2602 2610 2618 2626 2634 2658 2664 2658 2664 2658 2664 2658 2664 2658 2664 2658 2664 2658 2700 2718 2738 2746 2738 2746 2770 2738 2746 2770 2778 2757 2757 2757 2757 2757 2757 2757	3 2563 2571 2587 2587 2587 2587 2663 2663 2663 2663 2663 2665 2663 2665 2665	4 2564 2572 2580 2588 2596 2604 2612 2620 2628 2660 2662 2660 2668 2660 2668 2660 2668 2700 2708 2708 2716 2728 2740 2748	5 2565 2573 2581 2587 2697 2605 2613 2621 2627 2657 2653 2661 2663 2709 2709 2709 2709 2717 2709 2717 2714 2749 2757 2745 2773 2741 2749	6 2566 2574 2582 2598 2606 2614 2622 2638 2662 2678 2662 2678 2662 2678 2662 2678 2662 2710 2718 2712 2734 2742 2750 2734 2742 2750	7 2567 2575 2583 2591 2607 2615 2623 2631 2639 2647 2653 2647 2653 2671 2653 2671 2755 2743 2751 2755 2743 2751 2755 2743 2751 2755 2743 2757 2757 2757 2743 2757 275		5400 5410 5420 5430 5440 5450 5540 5540 5550 5550 555	0 2816 2824 2832 2840 2848 2856 2864 2872 2888 2896 2912 2920 2912 2920 2921 2922 2923 2936 2936 2936 2936 2952 2928 2936 2936 2952 2928 2936 2936 2936 2936 2936 2936 2936 2936	1 2817 2825 2833 2841 2849 2857 2857 2857 2857 2857 2953 2951 2929 2937 2929 2937 2945 2959 2957 2959 2957 2959 3001 3001 3005 3034	2 2818 2826 2834 2852 2858 2858 2858 2857 2890 2898 2906 2930 2938 2936 2938 2936 2938 2946 2952 2939 2938 2946 2954 2952 2939 3002 3010 3018 3026 3034	3 2819 2827 2835 2843 2859 2867 2875 2893 2937 2937 2937 2937 2939 2947 2953 3003 3011 3019 3027 3025	4 2820 2828 2836 2844 2852 2860 2868 2876 2892 2900 2908 29292 2916 2924 2932 2940 2934 2932 2940 2934 2932 2940 2948 2952 2950 2954 2952 2950 2954 2952 2950 2954 2952 2950 2954 2952 2950 2954 2952 2950 2954 2952 2950 2954 2952 2956 2954 2952 2956 2954 2952 2956 2954 2952 2956 2954 2952 2956 2954 2952 2956 2954 2956 29	5 2821 2829 2837 2845 2863 2861 2869 2877 2893 2901 2909 2937 2933 2941 2949 2957 2949 2957 2949 2957 3005 3013 3021 3029 3037	6 2822 2838 2846 2854 2854 2852 2870 2878 2896 2910 2934 2934 2934 2934 2934 2934 2934 2934	7 2823 2831 2847 2855 2863 2863 2879 2887 2919 2927 2935 2943 2951 2955 2943 2957 2957 2957 2959 3007 3015 3023 3031 3039	
5000 2560 to to 5777 3071 (Octai) (Decimal)	5000 5010 5020 5040 5050 5060 5070 5120 5120 5120 5120 5210 5210 5210 521	0 2560 2576 2577 2582 2592 2600 2602 2642 2642 2642 2644 2652 2644 2654 2664 266	1 2561 2562 2593 2601 2609 2617 2665 2663 2661 2665 2663 2681 2689 2697 2705 2681 2781 2781 2781 2781 2721 2721 2737 2745 2753 2753 2753	2 2562 2578 2586 2598 2598 2602 2610 2618 2626 2634 2658 2658 2658 2658 2668 2706 2658 2668 2706 2658 2706 2698 2708 2714 2712 2713 2714 27157 27157 27175 277577 277577 277577777777	3 2563 2571 2587 2587 2587 2583 2661 26619 2663 2663 2663 2665 2663 2665 2663 2669 2707 2715 2723 2731 2739 2747 2735 2747 2735 2747	4 2564 2572 2588 2596 2604 2612 2620 2628 2636 2644 2652 2660 2668 2660 2668 2700 2708 2716 2714 2714 2714 2714 2714 2714 27150 2716 2715 2715 2717 27180 2718 2717 27180 2718 2719 2719 2719 2719 2719 2719 2719 2719	5 2565 2573 2581 2587 2605 2613 2621 2663 2663 2663 2663 2661 2669 2677 2685 2685 2701 2709 2703 2701 2705 2713 27141 2749 27157 2717 271	6 2566 2574 2582 2582 2598 2606 2614 2652 2638 2662 2663 2663 2663 2662 2662 266	7 2567 2575 2583 2591 2599 2607 2615 2623 2639 2647 2653 2663 2663 2663 2663 2667 2663 2667 2677 2783 2743 2743 2759 2743 2759 2743 2759 2743 2759 2743 2759 275		5400 5410 5420 5420 5420 5440 5450 5540 5550 5540 5550 5540 5550 5540 5550 5560 5650 565	0 2816 2824 2832 2840 2848 2856 2864 2872 2888 2896 2904 2932 2932 2932 2936 2944 2952 2936 2948 2936 2948 2936 2948 2936 2948 2936 3000 3008 3012 3024 3024 3048	1 2817 2825 2833 2841 2849 2857 2857 2857 2857 2905 2937 2915 2929 2937 2945 2937 2945 2933 3001 3009 3017 3025 3033 3041 8049	2 2818 2826 2834 2852 2858 2858 2858 2890 2898 2906 2930 2938 2934 29354 2954 2954 2954 2954 2954 2954 2970 2978 29954 3002 3010 3018 3026 3034 3026 3034	3 2819 2827 2835 2843 2859 2867 2875 2893 2891 2899 2907 2915 2923 2931 2939 2947 2955 2953 2939 2947 2955 3003 3011 3019 3027 3035 3043	4 2820 2828 2836 2844 2852 2860 2882 2990 2992 2990 2992 2990 2992 2990 2992 2990 2994 2956 2954 2952 2956 3004 3012 3028 3036 3042	5 2821 2829 2837 2845 2857 2861 2869 2877 2885 2901 2909 2917 2925 2933 2941 2949 2957 2945 2957 2941 2949 2957 3005 3013 3021 3029 3037 3045	6 2822 2838 2846 2854 2852 2870 2878 2886 2887 2902 2918 2926 2932 2932 2932 2932 2942 2950 2958 2954 2954 2955 2954 2955 3006 3014 3024	7 2823 2831 2847 2859 2863 2863 2879 2895 2903 2911 2927 2935 2943 2951 2959 2959 2959 2955 2959 2955 2959 3007 3015 3023 3031 3039 3047	
5000 2560 to to 5777 3071 (Octai) (Decimal)	5000 5010 5020 5040 5050 5050 5050 5100 5110 5120 5130 5150 5170 5210 5210 5220 5240 5250 5250 5250 5250 5250 525	0 2560 2568 2576 2582 2592 2600 2608 2642 2648 2656 2664 2664 2762 2680 2768 2766 2704 2712 2720 2728 2736 2724 2720 2724 2726 2744 2752 2740 2748 2756 2744 2752 2740 2758 2746 2746 2746 2754 2754 2754 2754 2754 2754 2754 2754	1 2561 2569 2577 2583 2601 2617 2617 2617 2649 2657 2649 2657 2649 2657 2649 2657 2705 2713 2781 2729 2737 2721 2729 2735 2745 2715 2745 2715 2745 2745 2745 2745 2745 2745 2745 274	2 2562 2570 2584 2584 2584 2662 2650 2658 2666 2658 2666 2658 2666 2668 2668	3 2563 2571 2587 2587 2587 2585 2603 2611 2659 2667 2683 2667 2683 2667 2683 2689 2667 2675 2683 2691 2703 2713 2713 2713 2713 2713 2714 2715 2763 2714 2715 2714 2715 2719 2714 2715 2719 2714 2715 2719 2717 2715 2719 2717 2717 2715 2719 2717 2717 2717 2715 2719 2717 2715 2719 2717 2715 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2717 2719 2719	4 2564 2572 2580 2588 2596 2692 2642 2652 2662 2662 2662 2664 2692 2708 2708 2708 2708 2708 2708 2708 270	5 2565 2573 2581 2587 2697 2697 2697 2697 2697 2697 2697 269	6 2566 2574 2587 2598 2698 2614 2652 2654 2654 2654 2654 2654 2654 265	7 2567 2575 2599 2607 2615 2639 2647 2655 2663 2671 2655 2663 2671 2655 2663 2671 2655 2671 2679 2687 2695 2743 2711 2725 2745 2745 2745 2755 2767 2755 2755 2755 2767 2755 2755		5400 5410 5420 5420 5420 5450 5450 5550 5550 555	0 2816 2822 2832 2848 2856 2864 2856 2864 2856 2864 2912 2920 2928 2936 2936 2932 2936 2944 2932 2958 2945 2956 2960 2968 2976 2984 2976 2984 2975 2976 2984 2975 2976 2984 2976 2976 2976 2984 2976 2976 2976 2976 2976 2976 2976 2976	1 2817 2825 2833 2841 2889 2857 2865 2913 2921 2929 2937 2945 2929 2937 2945 2929 2937 2945 2993 2937 2945 2993 3001 3009 30017 3025	2 2818 2826 2834 2842 2850 2858 2866 2914 2926 2930 2938 2946 2954 2937 2938 2946 2954 2947 2938 2946 2954 2946 3002 3010 3018 3026 3034 3034 3034 3034 3034 3034 3034 303	3 2819 2827 2835 2843 2859 2867 2875 2875 2891 2997 2915 2923 2937 2931 2939 2947 2931 2939 2947 2955 2963 2971 2959 2987 2987 2987 2987 3003 3003 3001 3019 3027 3035 3043 3051 3055 30453 3055 30453 3055 3055 3055 30	4 2820 2828 2836 2845 2852 2860 2852 2876 2852 2908 2916 2924 2932 2932 2940 2948 2956 2952 2940 2958 2952 2954 2952 2952 2950 2952 2952 2952 2955 2956 2955 295	5 2821 2829 2837 2845 2869 2877 2885 2893 2909 2917 2925 2933 2941 2949 2933 2941 2949 2945 2949 2945 2945 2949 2945 2949 3005 3005 3037 3045	6 2822 2838 2846 2854 2862 2870 2918 29262 2910 2918 29262 2934 2934 2934 2934 2934 2934 2934 293	7 2823 2839 2847 2853 2863 2863 2867 2863 2863 2867 2895 2903 2919 2927 2935 2943 2951 2955 2943 2951 2957 2957 2957 2957 2957 2957 2957 2957	

410-0(102) FOR TRAINING PURPOSES ONLY Study Guide

OCTAL-DECIMAL INTEGER CONVERSION TABLE

			CARL MARK	1000		100-2012	and a start		and the second				10-10 A	-	10.00	1	1.00		0		
		0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7		
	6000	3072	3073	3074	3075	3076	3077	3078	3079	1000	6400	3328	3329	3330	3331	3332	3333	3334	3335	6000	3073
	6010	3080	3081	3082	3083	3084	3085	3086	3087		6410	3336	3337	3338	3339	3340	3341	3342	3343	10	10
	6020	3088	3089	3090	3091	3092	3093	3094	3095		6420	3344	3345	3346	3347	3348	3349	3350	3351	6777	3593
	6030	3096	3097	3098	3099	3100	3101	3102	3103	101.5	6430	3352	3353	3354	3355	3356	3357	3358	3359	(Octal)	(Decum
	6040	3104	3105	3106	3107	3108	3109	3110	3111	12.55	6440	3360	3361	3362	3363	3364	3365	3366	3367	(Octal)	IDecim
	6050	3112	3113	3114	3115	3116	3117	3118	3119		6450	3368	3369	3370	3371	3372	3373	3374	3375		
	6060	3120	3121	3122	3123	3124	3125	3126	3127		6460	3376	3377	3378	3379	3380	3381	3382	3383	Ornal	Desert
	6070	3128	3129	3130	3131	3132	3133	3134	3135		6470	3384	3385	3386	3387	3388	3389	3390	3391	Uctal	Uecimal
	6100	2176	2127	2120	2120	2140	2141	2142	2142	1	6500	2202	2202	2204	2205	2206	2207	2209	2200	10000	4096
	6110	3144	3145	3146	3147	3140	3149	3150	3151	10.00	6510	3400	3353	3354	3355	3404	3405	3350	3407	20000	8192
	6120	3152	3153	3154	3155	3156	3157	3158	3159		6520	3408	3409	3410	3411	3412	3413	3414	3415	30000	12288
	6130	3160	3161	3162	3163	3164	3165	3166	3167	1.0	6530	3416	3417	3418	3419	3420	3421	3472	3423	40000	16384
	6140	3168	3169	3170	3171	3172	3173	3174	3175	101-1	6540	3424	3425	3426	3427	3428	3429	3430	3431	50000	20480
	6150	3176	3177	3178	3179	3180	3181	3182	3183		6550	3432	3433	3434	3435	3436	3437	3438	3439	60000	24576
L	6160	3184	3185	3186	3187	3188	3189	3190	3191		6560	3440	3441	3442	3443	3444	3445	3446	3447	70000	28672
	6170	3192	3193	3194	3195	3196	3197	3198	3199		6570	3448	3449	3450	3451	3452	3453	3454	3455		
							-					1									
	6200	3200	3201	3202	3203	3204	3205	3206	3207	140	6600	3456	3457	3458	3459	3460	3461	3462	3463		
	6210	3208	3209	3210	3211	3212	3213	3214	3215		6610	3464	3465	3466	3467	3468	3469	3470	3471		
	6220	3210	3217	3218	3219	3220	3221	3222	3223	MARE	6620	34/2	34/3	34/4	34/5	34/6	34/1	3478	3479		
	6240	3224	3223	3220	3225	3220	3223	3230	3231		6640	3400	3481	3482	3483	3484	3485	3486	348/		
	6250	3240	3241	3242	3243	3244	3245	3246	3233		6650	3400	3403	3450	3491	3492	3493	3494	3495		
	6260	3248	3249	3250	3251	3252	3253	3254	3255	the second	6660	3504	3457	3450	3433	3500	3500	3502	3503		
E	6270	3256	3257	3258	3259	3260	3261	3262	3263		6670	3512	3513	3514	3515	3516	3517	3518	3519		
		-											3313	3314	3313	3310	3317	3310	3313		
	6300	3264	3265	3266	3267	3268	3269	3270	3271	364	6700	3520	3521	3522	3523	3524	3525	3526	3527		
	6310	3272	3273	3274	3275	3276	3277	3278	3279	11-2	6710	3528	3529	3530	3531	3532	3533	3534	3535		
	6320	3280	3281	3282	3283	3284	3285	3286	3287	-	6720	3536	3537	3538	3539	3540	3541	3542	3543		
	6330	3288	3289	3290	3291	3292	3293	3294	3295		6730	3544	3545	3546	3547	3548	3549	3550	3551		
	6340	3296	3297	3298	3299	3300	3301	3302	3303		6740	3552	3553	3554	3555	3556	3557	3558	3559		
	6350	3304	3305	3306	3307	3308	3309	3310	3311		6750	3560	3561	3562	3563	3564	3565	3566	3567		
	6300	3312	3313	3314	3313	3310	3317	3318	3319	Note 1	6730	3508	3569	3570	35/1	3572	35/3	3574	3575		
	0370	5520	3321	3322	3323	3324	3325	3320	3321		0//0	3570	3211	35/8	35/9	3280	3281	3582	3583		
		0	1	2	3	4	5	6	7			0	1	2	3	4	5	6	7		
	7000	0 3584	1 3585	2 3586	3 3587	4	5	6 3590	7 3591		7400	0 3840	1 3841	2 3842	3 3843	4 3844	5 3845	6 3846	7 3847	7000	3584
	7000 7010	0 3584 3592	1 3585 3593	2 3586 3594	3 3587 3595	4 3588 3496	5 3589 3497	6 3590 3598	7 3591 3599		7400 7410	O 3840 3848	1 3841 3849	2 3842 3850	3 3843 3851	4 3844 3852	5 3845 3853	6 3846 3854	7 3847 3855	7000 io	3584 to
	7000 7010 7020	O 3584 3592 3600	1 3585 3593 3601	2 3586 3594 3602	3 3587 3595 3603	4 3588 3496 3604	5 3589 3497 3605	6 3590 3598 3606	7 3591 3599 3607		7400 7410 7420	O 3840 3848 3856	1 3841 3849 3857	2 3842 3850 3858	3 3843 3851 3859	4 3844 3852 3860	5 3845 3853 3861	6 3846 3854 3862	7 3847 3855 3863	7000 io 7777	3584 to 4095
	7000 7010 7020 7030	0 3584 3592 3600 3608	1 3585 3593 3601 3609	2 3586 3594 3602 3610	3 3587 3595 3603 3611	4 3588 3496 3604 3612	5 3589 3497 3605 3613	6 3590 3598 3606 3614	7 3591 3599 3607 3615		7400 7410 7420 7430	O 3840 3848 3856 3864	1 3841 3849 3857 3865	2 3842 3850 3858 3866	3 3843 3851 3859 3867	4 3844 3852 3860 3868	5 3845 3853 3861 3869	6 3846 3854 3862 3870	7 3847 3855 3863 3871	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040	O 3584 3592 3600 3608 3616	1 3585 3593 3601 3609 3617	2 3586 3594 3602 3610 3618	3 3587 3595 3603 3611 3619	4 3588 3496 3604 3612 3620	5 3589 3497 3605 3613 3621	6 3590 3598 3606 3614 3622	7 3591 3599 3607 3615 3622		7400 7410 7420 7430 7440	0 3840 3848 3856 3864 3872	1 3841 3849 3857 3865 3873	2 3842 3850 3858 3866 3874	3 3843 3851 3859 3867 3875	4 3844 3852 3860 3868 3876	5 3845 3853 3861 3869 3877	6 3846 3854 3862 3870 3878	7 3847 3855 3863 3871 3879	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050	0 3584 3592 3600 3608 3616 3624 2523	1 3585 3593 3601 3609 3617 3625 2623	2 3586 3594 3602 3610 3618 3626	3 3587 3595 3603 3611 3619 3627	4 3588 3496 3604 3612 3620 3628	5 3589 3497 3605 3613 3621 3629 2627	6 3590 3598 3606 3614 3622 3630 2638	7 3591 3599 3607 3615 3622 3631 3632		7400 7410 7420 7430 7440 7450	0 3840 3848 3856 3864 3872 3880 2880	1 3841 3849 3857 3865 3873 3881	2 3842 3850 3858 3866 3874 3882 3892	3 3843 3851 3859 3867 3875 3883	4 3844 3852 3860 3868 3876 3884 3884	5 3845 3853 3861 3869 3877 3885	6 3846 3854 3862 3870 3878 3886	7 3847 3855 3863 3871 3879 3887 3887	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7060	0 3584 3592 3600 3608 3616 3624 3632 3640	1 3585 3593 3601 3609 3617 3625 3633 3641	2 3586 3594 3602 3610 3618 3626 3634 3642	3 3587 3595 3603 3611 3619 3627 3635 3643	4 3588 3496 3604 3612 3620 3628 3636 3644	5 3589 3497 3605 3613 3621 3629 3637 3645	6 3590 3598 3606 3614 3622 3630 3638 3646	7 3591 3599 3607 3615 3622 3631 3639 3647		7400 7410 7420 7430 7440 7450 7460 7460	0 3840 3848 3856 3864 3872 3880 3888 3888	1 3841 3849 3857 3865 3873 3881 3889 2897	2 3842 3850 3858 3866 3874 3882 3890 2899	3 3843 3851 3859 3867 3875 3883 3891 2899	4 3844 3852 3860 3868 3876 3884 3892 2900	5 3845 3853 3861 3869 3877 3885 3893 3893	6 3846 3854 3862 3870 3878 3886 3894 3890	7 3847 3855 3863 3871 3879 3887 3895 3895	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070	0 3584 3592 3600 3608 3616 3624 3632 3640	1 3585 3593 3601 3609 3617 3625 3633 3641	2 3586 3594 3602 3610 3618 3626 3634 3642	3 3587 3595 3603 3611 3619 3627 3635 3643	4 3588 3496 3604 3612 3620 3628 3636 3644	5 3589 3497 3605 3613 3621 3629 3637 3645	6 3590 3598 3606 3614 3622 3630 3638 3646	7 3599 3607 3615 3622 3631 3639 3647		7400 7410 7420 7430 7440 7450 7460 7470	0 3840 3848 3856 3864 3872 3880 3888 3896	1 3841 3849 3857 3865 3873 3881 3889 3897	2 3842 3850 3858 3866 3874 3882 3890 3898	3 3843 3851 3859 3867 3875 3883 3891 3899	4 3844 3852 3860 3868 3876 3884 3892 3900	5 3845 3853 3861 3869 3877 3885 3893 3901	6 3846 3854 3862 3870 3878 3886 3894 3902	7 3847 3855 3863 3871 3879 3887 3895 3903	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100	0 3584 3592 3600 3608 3616 3624 3632 3640 3648	1 3585 3593 3601 3609 3617 3625 3633 3641 3649	2 3586 3594 3602 3610 3618 3626 3634 3642 3650	3 3587 3595 3603 3611 3619 3627 3635 3643 3651	4 3588 3496 3604 3612 3620 3628 3636 3644 3652	5 3589 3497 3605 3613 3621 3629 3637 3645 3653	6 3590 3598 3606 3614 3622 3630 3638 3646 3654	7 3591 3599 3607 3615 3622 3631 3639 3647 3655		7400 7410 7420 7430 7440 7450 7460 7470 7500	0 3840 3848 3856 3864 3872 3880 3888 3896 3904	1 3841 3849 3857 3865 3873 3881 3889 3897 3897	2 3842 3850 3858 3866 3874 3882 3890 3898 3898	3 3843 3851 3859 3867 3875 3883 3891 3899 3907	4 3844 3852 3860 3868 3876 3884 3876 3884 3892 3900 3908	5 3845 3853 3861 3869 3877 3885 3893 3901 3909	6 3846 3854 3862 3870 3878 3886 3894 3902 3910	7 3847 3855 3863 3871 3879 3887 3895 3903 3911	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657	2 3586 3594 3602 3610 3618 3626 3634 3642 3650 3658	3 3587 3595 3603 3611 3619 3627 3643 3643 3651 3659	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3660	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3661	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3654 3662	7 3599 3607 3615 3622 3631 3639 3647 3655 3663		7400 7410 7420 7430 7440 7450 7460 7460 7470 7500 7510	O 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913	2 3842 3850 3858 3866 3874 3882 3890 3898 3906 3914	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915	4 3844 3852 3860 3868 3876 3884 3892 3900 3908 3916	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665	2 3586 3594 3602 3610 3618 3626 3634 3642 3650 3658 3666	3 3587 3595 3603 3611 3619 3627 3655 3643 3651 3659 3667	4 3588 3496 3604 3612 3620 3628 3638 3644 3652 3660 3668	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3661 3669	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3662 3670	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671		7400 7410 7420 7430 7440 7450 7460 7460 7470 7500 7510 7520	O 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921	2 3842 3850 3858 3866 3874 3882 3890 3898 3906 3914 3922	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915 3923	4 3844 3852 3860 3868 3876 3884 3892 3900 3908 3916 3924	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3656 3664 3672	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673	2 3586 3594 3602 3610 3618 3626 3634 3642 3650 3658 3666 3674	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3660 3668 3676	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3654 3662 3670 3678	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679		7400 7410 7420 7430 7440 7450 7460 7470 7500 7510 7520 7530	0 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920 3928	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929	2 3842 3850 3858 3866 3874 3882 3890 3898 3906 3914 3922 3930	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915 3923 3931	4 3844 3852 3860 3868 3876 3884 3892 3900 3908 3916 3924 3932	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130 7140	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3656 3664 3672 3680	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681	2 3586 3594 3602 3610 3618 3626 3634 3642 3650 3658 3666 3674 3682	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675 3683	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3660 3668 3676 3684	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3654 3662 3670 3678 3686	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687		7400 7410 7420 7430 7440 7450 7460 7470 7500 7510 7510 7520 7530 7540	O 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920 3928 3936	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929 3937	2 3842 3850 3858 3866 3874 3882 3890 3898 3906 3914 3922 3930 3938	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915 3923 3931 3939	4 3844 3852 3860 3868 3876 3884 3876 3884 3892 3900 3908 3916 3924 3932 3940	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130 7140 7150	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3672 3680 3688	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689	2 3586 3594 3602 3610 3618 3626 3634 3642 3650 3654 3650 3656 3674 3682 3690	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3655 36651 36659 36675 3683 3691	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3660 3668 3676 3684 3676 3684 3692	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3665 36653 3661 36677 3685 3693	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3654 3654 3654 3678 3678 3686 3694	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687 3695		7400 7410 7420 7430 7440 7450 7470 7500 7510 7500 7530 7530 7530 7550	O 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920 3928 3928 3936 3944	1 3841 3849 3857 3865 3873 3887 3889 3897 3905 3913 3921 3929 3937 3945	2 3842 3850 3858 3866 3874 3882 3898 3898 3996 3914 3922 3930 3938 3946	3 3843 3851 3859 3867 3875 3883 3899 3997 3915 3923 3931 3939 39347	4 3844 3852 3860 3868 3876 3884 3900 3908 3916 3924 3932 3940 3948	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942 3950	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3943 3951	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7050 7060 7070 7100 7110 7120 7130 7140 7150 7150	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3672 3680 3688 3688 3698	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689 3697 2705	2 3586 3594 3602 3618 3626 3634 3642 3650 3658 3665 3658 3666 3674 3682 3690 3698	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 36651 3659 3663 3691 3699 3699	4 3588 3496 3604 3612 3620 3628 3638 3644 3652 3644 3652 3660 3668 3676 3684 3692 3700	5 3589 3497 3605 3613 3621 3629 3637 3645 3663 3661 3669 3677 3685 3693 3701 2709	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3654 3662 3670 3678 3686 3686 3684 3684 3702	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687 3695 3703		7400 7410 7420 7430 7440 7450 7470 7500 7510 7510 7510 7530 7550 7550 7550 7550 7550	0 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920 3928 3936 3944 3952 2955	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3921 3921 3921 3937 3945 3953	2 3842 3850 3858 3866 3874 3882 3898 3906 3914 3920 3938 3946 3934 3954	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915 3923 3931 3939 3947 3955	4 3844 3852 3860 3868 3876 3884 3892 3900 3908 3916 3924 3932 3940 3948 3956	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942 3950 3958	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3951 3959	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7060 7060 7060 7070 7100 7110 7120 7120 7130 7140 7150 7150 7150 7150 7170	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3648 3656 3688 3688 3696 3704	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689 3697 3705	2 3586 3594 3602 3618 3626 3634 3642 3650 3658 3666 3658 3666 3678 3690 3698 3706	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675 3683 3691 3699 3707	4 3588 3496 3604 3620 3628 3636 3644 3652 3660 3668 3668 3668 3668 3684 3692 3700 3708	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685 3693 3701 3709	6 3590 3598 3606 3634 3630 3638 3646 3654 3654 3662 3670 3678 3688 3686 3694 3702 3710	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687 3695 3703 3711		7400 7410 7420 7440 7450 7460 7470 7500 7510 7520 7550 7550 7550 7550 7550 7570	0 3840 3848 3856 3864 3872 3880 3896 3912 3920 3928 3928 3936 3944 3952 3960	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929 3937 3945 3953 3961	2 3842 3850 3858 3864 3874 3882 3890 3898 3906 3914 3922 3930 3938 3946 3954 3962	3 3843 3851 3859 3867 3875 3883 3891 3899 3907 3915 3923 3931 3939 3947 3955 3963	4 3844 3852 3860 3868 3876 3884 3892 3900 3908 3916 3924 3932 3940 3948 3956 3964	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942 3950 3958 3966	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3945 3951 3959 3967	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7050 7050 7060 7070 7100 7110 7120 7140 7140 7140 7140 7140	0 3584 3592 3600 3608 3616 3624 3648 3656 3664 3656 3664 3668 3668 3668 3668 3668 3668 3704	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3681 3689 3697 3705	2 3586 3594 3602 3610 3618 3624 3634 3642 3650 3658 3666 3674 3662 3698 3698 3706	3 3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3693 3699 3707 3715	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3666 3668 3676 3684 3692 3700 3708 3716	5 3589 3497 3605 3613 3621 3629 3629 3629 3645 3645 36653 36653 36653 36677 36695 3677 36895 3677 3709 3717	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3662 3670 3678 3664 3694 3702 3710	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687 3695 3703 3711 3719		7400 7410 7420 7430 7440 7450 7440 7470 7500 7510 7530 7530 7530 7550 7550 7550 7550 755	0 3840 3848 3856 3864 3872 3880 3888 3896 3904 3912 3920 3928 3936 3934 3952 3944 3952 3960	1 3841 3849 3857 3865 3873 3889 3897 3905 3913 3921 3929 3937 3925 3953 3953 3961 3969	2 3842 3850 3858 3866 3874 3882 3890 3914 3930 3938 3946 3954 3954 3950	3 3843 3851 3859 3867 3883 3883 3899 3907 3915 3923 3931 3939 3947 3955 3963	4 3844 3852 3860 3868 3876 3884 3900 3908 3916 3924 3932 3940 3948 3956 3954 3954	5 3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3926 3934 3958 3958 3956 3958	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3951 3959 3967 3975	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7050 7060 7070 7100 7110 7120 7130 7140 7150 7150 7150 7150 7150 7120	0 3584 3592 3600 3608 3616 3623 3640 3648 3656 3656 3656 3664 3656 3664 3656 3664 3656 3704 3712 3720	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3667 3667 3689 3705 3713 3721	2 3586 3594 3602 3610 3618 3626 3634 3642 3658 3658 3658 3658 3658 3658 3658 3714 3714	3 3587 3595 3603 3611 3619 3627 3643 3643 3643 3667 3663 3667 3663 3667 3663 3699 3707 3715 3723	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3668 3668 3668 3668 3668 3668 3770 3708 3716 3724	5 3589 3497 3605 3613 3621 3629 3637 3645 3645 3669 3669 3669 3669 3669 3669 3669 3701 3709	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3664 3664 3664 36678 3678 3686 3693 3702 3710	7 3591 3607 3615 3622 3631 3647 3663 36647 3667 3667 3687 3687 3679 3687 3703 3701 3711 3719		7400 7410 7420 7430 7440 7450 7470 7500 7510 7520 7550 7550 7550 7560 7610	0 3840 3848 3856 3864 3872 3880 3888 3896 3934 3912 3920 3928 3936 3944 3952 3950 3952 3950	1 3841 3845 3857 3865 3873 3885 3887 3985 3993 3993 3921 3929 3937 3945 3953 3951 3953 3951 3953	2 3842 3850 3858 3866 3874 3890 3988 3994 3922 3930 3938 3944 3922 3930 3938 3945 3954 3954 3954	3 3843 3851 3859 3867 3875 3883 3899 3907 3915 3923 3931 3923 3947 3955 3953 3955 3953	4 3844 3852 3860 3868 3876 3884 3990 3900 3908 3916 3924 3940 3948 3956 3954 3954	5 3845 3863 3861 3869 3893 3901 3901 3901 3901 3925 3933 3941 3949 3957 3955 3965	6 3846 3854 3862 3870 3878 3894 3902 3918 3926 3934 3958 3958 3958 3958 3958	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3951 3951 3951 3951 3951 3967 3975 3983	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130 7140 7140 7150 7140 7150 7140 7150 7160 7170	0 3584 3592 3600 3608 3616 3624 3648 3656 3664 36648 3656 3662 36680 36888 3692 3672 3680 3672 3702 3728	1 3585 3693 3601 3625 3633 3641 3649 3657 3665 3673 3681 3689 3697 3705 3705	2 3586 3594 3602 3610 3618 3626 3634 3662 3650 3658 3664 3662 3690 3698 3704 3730	3 3587 3595 3603 3611 3619 3627 3643 3665 3663 3665 3663 3665 3663 3669 3667 3663 3683 3691 3699 3707 3715	4 3588 3496 3604 3612 3628 3636 3644 3652 3664 3664 3664 3664 3664 3664 3700 3708 3712	5 3589 3497 3605 3613 3621 3629 3637 3645 3653 3665 36653 3685 3685 3685 3685 36	6 3590 3606 3614 3630 3638 3664 3664 3670 3678 3686 3694 3710 3718 3726 3734	7 3591 3599 3607 3615 3623 3631 3639 3647 36655 3663 36647 36655 36647 36655 3703 3711 3719 3727 3735		7400 7410 7420 7430 7440 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3864 3888 3886 3888 3896 3994 3912 3920 3928 3928 3936 3944 3950 3968 3976 3984	1 3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929 3937 3945 3953 3961 3965	2 3842 3850 3858 3866 3874 3882 3890 3898 3906 3914 3922 3930 3938 3946 3954 3954 3954 3954 3978 3978	3 3843 3851 3859 3867 3883 3891 3997 3915 3923 3931 3939 3947 3955 3967 3979 3987	4 3844 3852 3860 3868 3876 3884 3982 3900 3916 3924 3932 3940 3948 3956 3956 3956 3956	5 3845 3853 3869 3867 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965 3973 3981	6 3846 3854 3862 3870 3886 3886 3884 3982 3910 3918 3926 3934 3942 3942 3950 3942 3953 3942 3954 3942 3954 3942 3954	7 3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3945 3959 3967 3975 3991	7000 io 7777 (Octal)	3584 to 4095 (Decima
	7000 7010 7020 7030 7050 7050 7050 7100 7100 7110 7120 7130 7140 7150 7150 7150 7170 7170 7120 7220 7220 7220	0 3584 3592 3600 3608 3616 3624 3624 3624 3624 3648 3656 3664 3656 3664 3656 3668 3696 3704 3712 3720 3728 3736	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3663 3681 3689 3705 3705 3713 3721 3729	2 3586 3594 3602 3610 3618 3626 3634 3642 3658 3666 3658 3666 3658 36698 3706 3714 3722 3730	3 3587 3595 3603 3611 3619 3627 3643 3651 3653 3663 3663 3663 3663 3663 366	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3664 3668 3676 3684 3673 3700 3708 3716 3724 3740	5 3589 3497 3605 3613 3629 3637 3645 3663 3669 3669 3669 3709 3709 3717 3725 3733 3741	6 3590 3614 3622 3630 3638 3646 3654 36678 3670 3678 3670 3678 3702 3710 3718 3726 3734	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3663 3667 3687 3695 3703 3711 3719 3727 3735 3743		7400 7410 7420 7430 7440 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3856 3864 3856 3888 3896 3904 3912 3920 3928 3936 3934 3952 3944 3952 3960 3968 3976	1 3841 3849 3857 3865 3873 3881 3889 3913 3921 3929 3937 3945 3953 3961 3953 3953 3953 3953 3953	2 3842 3850 3858 3866 3874 3882 3890 3994 3914 3922 3930 3938 3946 3954 3946 3954 3954 3962	3 3843 3851 3859 3867 38875 3883 3891 3993 3907 3915 3923 3931 3939 3947 3955 3963 3947 3955 3963	4 3844 3852 3860 3868 3876 3876 3990 3908 3916 3924 3924 3932 3940 3948 3956 3956 3956 3956	5 3845 3863 3869 3877 3885 3993 3990 3937 3933 3949 3949 3949 3949 3949 3949	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942 3958 3958 3958 3958 3958	7 3847 3855 3863 3871 3887 3887 3887 3983 3903 3911 3919 3927 3935 3943 3959 3959 3959 3959 3959 3959	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7050 7060 7070 7100 7110 7120 7140 7140 7140 7150 7140 7140 7140 7120 7210 7220 7230 7230 7230	0 3584 3592 3600 3608 3616 3624 3632 3640 3664 3656 3664 3664 3664 3664 3664 3664	1 3585 3593 3601 3609 3617 3625 3633 3641 3665 3665 3665 3665 3665 3667 3705 3713 3721 3729 3737 3737	2 3586 3594 3602 3610 3618 3626 3658 3656 3656 3656 3656 3656 3698 3706 3714 3730 3738 3738	3 3587 3695 3603 3611 3619 3627 3635 3643 3651 3667 3663 3699 3707 3715 3723 3739 3739 3739 3739	4 3588 3496 3612 3620 3628 3636 3644 3652 3666 3668 3668 3668 3668 3700 3708 3716 3724 3732 3740	5 3589 3497 3605 3613 3629 3637 3645 3663 3669 3669 3669 3669 3669 3701 3709 3717 3725 3733 3741	6 3590 3698 3614 3622 3630 3638 3646 3654 3670 3670 3678 3678 3678 3678 3678 3678 3702 3710 3718 3726 3734 3742 3750	7 3591 3607 3615 3622 3631 3639 3647 3665 3663 3671 3679 3687 3679 3687 3703 3711 3719 3727 3735 3743 3743		7400 7410 7420 7430 7450 7450 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3872 3880 3988 3896 3904 3912 3920 3928 3936 3944 3952 3944 3952 3944 3954 3944 3954 3946 3946 3946	1 3841 3849 3867 3863 3887 3905 3913 3929 3929 3937 3945 3953 3953 3953 3953 3953 3954	2 3842 3850 3858 3866 3874 3882 3890 3938 3930 3938 3946 3954 3954 3954 3954 3954 3954 3958	3 3843 3851 3859 3867 3987 3983 3997 3913 3931 3939 3947 3955 3963 3955 3963 3957 3995	4 3844 3852 3860 3868 3876 3987 3900 3916 3924 3932 3932 3932 3932 3934 39356 3956 3956 3956 4004	5 3845 3853 3861 3869 3877 3909 3917 3925 3933 3941 3949 3957 3965 3957 3965 3981 3987 3981	6 3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3958 3958 3958 3958 3958 3958 3958 3958	7 3847 3855 3863 3879 3887 3893 3903 3911 3919 3927 3943 3951 3953 3967 3975 3993 39975 3993	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7040 7060 7060 7070 7100 7110 7120 7130 7150 7150 7150 7150 7200 7210 7220 7230 7230 7240	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3664 3664 3664 3664 3664 3664	1 3585 3593 3601 3629 3633 3641 3649 3657 3665 3673 3681 3689 3705 3713 3705 3713 3721 3729 3737 3745 3745	2 3586 3594 3602 3610 3634 3634 3642 3658 3642 3658 3642 3658 3662 3658 3662 3674 3682 3690 3706 3714 3722 3730 3746 3746	3 3587 3595 3603 3611 3659 3663 3663 3663 3663 3663 3663 3669 3667 3675 3683 3683 3683 3707 3715 3723 3731 3747 3745	4 3588 3496 3604 3620 3628 3636 3664 3663 3664 3666 3666 3666 366	5 3589 3497 3605 3613 3621 3645 3645 3645 3663 3661 3669 3685 3685 3685 3685 3685 3701 3707 3717 3725 3733 3749 3749	6 3590 3608 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686 3694 3710 3718 3710 3718 3726 3734 3750 3750	7 3591 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3687 3703 3711 3719 3727 3743 3741 3751 3751		7400 7410 7420 7430 7440 7450 7450 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3872 3880 3880 3988 3994 3912 3920 3928 3934 3943 3952 3944 3952 3960 3968 3996 39968 39976 39984 4000	1 3841 3845 3865 3867 3863 3873 3887 3987 3995 3995 3995 3995 3995 3995 3995 3995 3997 3995 3997 3995 3997 3995	2 3842 3850 3858 3864 3859 3867 3874 3892 3930 3914 3922 3930 3938 3946 3954 3954 3954 3954 3958 3978 3978 3996	3 3843 3851 3859 3867 3875 3883 3883 3983 3937 3939 3947 3955 3963 3955 3963 3971 3979 3987 3979 3987 3979	4 3844 3852 3860 3868 3876 3884 3990 3900 3908 3916 3924 3932 3940 3948 3956 3964 3956 3964 4012	5 3845 3863 3863 3867 3893 3901 3909 3917 3925 3931 3949 3957 3949 3957 3965 3973 3989 3989 3989 3989 4005	6 3846 3854 3854 3862 3870 3878 3878 3984 3992 3934 3942 3950 3942 3958 3942 3956 3958 3942 3956 3958 3942 3990 3982 3990 4014	7 3847 3855 3863 3871 3879 3887 3903 3911 3919 3927 3935 3943 3955 3943 3959 395	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7050 7060 7070 7110 7110 7120 7130 7140 7150 7150 7210 7220 7230	0 3584 3592 3600 3616 3624 3632 3640 3656 3664 3656 3664 3656 3664 3656 3665 3664 3656 3666 3704 3712 3720 3728 3728 3728 3726 3752 3752 3752 3752 3752 3752 3752 3752	1 3585 3593 3601 3609 3633 3631 3641 3649 3657 3665 3673 3661 3681 3681 3681 3681 3705 3705 3713 3721 3729 3737 3745 3753 3761	2 3586 3594 3602 3618 3626 3634 3658 3658 3658 3658 3706 3714 3722 3730 3738 3746	3 3587 3595 3603 3611 3619 3659 36643 3659 36643 3659 3663 36693 3707 3715 3723 3731 3739 3747 3745 3755 3763	4 3588 3496 3604 3612 3620 3628 3636 3664 3666 3676 3684 3692 3700 3708 3716 3724 3732 3740 3748	5 3589 3497 3605 3613 3621 3623 3637 3645 3663 3669 3677 3683 3701 3709 3717 3725 3733 3741 3749	6 3590 3698 3606 3614 3622 3630 3638 3646 3654 3662 3670 3678 3684 3702 3710 3718 3728 3734 3734 3734 3734 3758 3768	7 3591 3699 3607 3615 3622 3631 3639 3647 3663 3663 3663 3703 3711 3719 3727 3743 3743 3743 3759 37659		7400 7410 7420 7430 7450 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3856 3864 3872 3880 3872 3880 3972 3920 3926 3936 3934 3952 3960 3954 3954 3954 3954 3954 3956 3954 3956 3957 3956 3957 395	1 3841 3849 3857 3865 3887 3889 3913 3921 3929 3937 3945 3945 3945 3945 3945 3945 3946 3953 3946 3985 3985 3985 3985 3985 3985 3985 3985 3985 3985 3985 3985 3949 3949 3949 3949 39577 3957 3957 3957 3957 39577 3957 3957 3957 3957 3957 3	2 3842 3850 3858 3866 3898 3898 3908 3914 3922 3930 3946 3954 3954 3954 3956 3998 3996 3998 4002	3 3843 3851 3859 3867 3883 3891 3937 3915 3923 3931 3947 3955 3963 3947 3957 3963 3971 3979 3987 3987 3987	4 3844 3852 3860 3876 3892 3990 3916 3932 3940 3932 3940 3932 3940 3948 3932 3940 3948 3944 3948 3954 4004 4012	5 3845 3853 3861 3869 3885 3893 3901 3917 3925 3933 3941 3949 3949 3949 3949 3949 3949	6 3846 3854 3862 3870 3878 3894 3992 3910 3918 3934 3934 3934 3934 3958 3958 3958 3956 3974 3982 3990 3998 4006 4014 4022	7 3847 3855 3863 3871 3879 3887 3903 3911 3919 3927 3943 3959 3959 3959 3959 3959 3959 3959 3959 4007 4023	7000 io 7777 (Octai)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130 7140 7140 7140 7140 7140 7140 7150 7140 7200 7210 7220 7220 7250 7250	0 3584 3592 3600 3618 3616 3624 3632 3640 3648 3656 3764 3728 3744 3712 3720 3778 3774 3776 3768	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3663 3681 3687 3763 3775 3713 3721 3729 3773 3737 3745 3753 3761 3769	2 3586 3594 3602 3610 3618 3626 3634 3664 3658 3664 3658 3664 3658 3764 3754 3730 3714 3738 3746 3774 3752 3770	3 3587 3595 3603 3611 3619 3627 3663 3663 36651 36653 36653 36675 36683 36675 36683 36675 36693 3707 3715 3723 3739 3747 3755 3773 3747 3755 3773	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3666 3668 3666 3668 3676 3684 3700 3708 3716 3724 3740 3748 3754 3754 3754 3754 3754 3754 3754 3754	5 3589 3497 3605 3613 3621 3637 3645 3663 3667 3663 3667 3663 3701 3709 3717 3725 3733 3741 3749 3745 3749 3773	6 3590 3598 3606 3614 3622 3630 3646 3678 3646 3678 3678 3678 3678 3702 3710 3718 3726 3734 3742 3750 3748	7 3591 3599 3607 3615 3639 3647 3655 3663 3671 3679 3687 3679 3687 3703 3711 3719 3727 3735 3743 3743 3743 3751	A	7400 7410 7420 7430 7440 7450 7510 7510 7510 7510 7510 7550 7550 75	0 3840 3848 3856 3864 3872 3880 3880 3912 3920 3928 3952 3954 3954 3954 3954 3954 3954 3954 4024	1 3841 3849 3857 3865 3873 3889 3897 3905 3913 3929 3937 3945 3953 3953 3953 3953 3953 3954 4001 4002	2 3842 3850 3858 3866 3874 3882 3990 3938 3930 3938 3930 3938 3944 3954 3954 3954 3954 3954 4002 4010	3 3843 3851 3859 3867 3883 3899 3907 3915 3923 3931 3939 3947 3955 3963 3971 3979 3987 3995 4003 4019 4027	4 3844 3852 3860 3868 3972 3900 3908 3916 3924 3932 3940 3948 3954 3954 3954 3954 3954 3954 3954 3954	5 3845 3863 3861 3869 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965 3965 3965 3965 3967 3981 3989 4013 4021 4021	6 3846 3854 3862 3870 3878 3894 3902 3910 3918 3924 3934 3934 3934 3934 3934 3934 3934	7 3847 3855 3863 3871 3879 3879 3993 3991 3959 395	7000 io 7777 (Octal)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7040 7050 7060 7100 7100 7110 7110 7110 7110 7150 715	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3664 3662 3662 3768 3778 3720 3728 3736 3774 3776 3768 3768	1 3585 3593 3601 3625 3633 3641 3649 3665 3673 3665 3673 3689 3697 3705 3713 3721 3729 3737 3745 3745 3745 3745 3745 3745 3745	2 3586 3594 3802 3610 3618 3626 3634 3642 3658 3666 3674 3682 3706 3698 3706 3714 3722 3730 3738 3746 3743 3745 3746 3774	3 3587 3595 3603 3611 3659 3643 3643 36651 36659 3667 3675 3683 3691 3691 3707 3715 3723 3737 3737 3747 3747 3747	4 3588 3496 3604 3612 3620 3628 3636 3644 3652 3664 3664 3664 36676 3684 3692 3700 3708 3708 3708 3708 3716 3748 3754 3748	5 3589 3497 3605 3613 3621 3637 3645 3663 3669 3669 3701 3709 3717 3725 3733 3749 3749 3749 3749	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 36678 3670 3678 3670 3677 3710 3718 3726 3734 3726 3758 3758 3758	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3687 3687 3687 3703 3711 3719 3727 3743 3751 3753 3767 3775 3775	4	7400 7410 7420 7430 7430 7430 7540 7550 7550 7550 7550 7550 7550 755	0 3840 3848 3856 3864 3872 3880 3904 3912 3928 3936 3936 3950 3960 3960 3960 3960 3960 3960 3960 4000 3950 400	1 3841 3849 3857 3865 3873 3889 3995 3921 3929 3937 3945 3945 3945 3945 3945 3945 3945 3946 4029 4007 4007 4025 4023	2 3842 3850 3858 3864 3869 3890 3914 3922 3930 3938 3946 3954 3954 3954 3954 3956 3970 3986 39978 3996 4010 4018 4026 4024	3 3843 3851 3859 3867 3883 3893 3907 3915 3923 3931 3939 3947 3955 3963 3963 3963 3971 3963 3964 4011 4012 4021	4 3844 3852 3860 3868 3876 3884 3932 3940 3948 3956 3954 3956 3956 3956 4004 4012 4020 4024 4024	5 3845 3863 3869 3877 3885 3933 3901 3909 3917 3925 3933 3949 394	6 3846 3854 3862 3870 3870 3878 3894 3902 3910 3918 3926 3934 3942 3950 3958 3956 3956 3956 3956 3956 3954 4014 4022 4030 40	7 3847 3863 3863 3863 3871 3895 3903 3911 3919 3923 3943 3959 395	7000 io 7777 (Octal)	3584 10 4095 (Decimi
	7000 7010 7020 7030 7040 7050 7060 7070 7100 7110 7120 7130 7140 7150 7140 7150 7140 7150 7210 7220 7230 7240 7250 7240 7250 7270	0 3584 3592 3600 3608 3616 3624 3640 3648 3656 3664 3664 3664 3664 3664 3664 3664	1 3585 3593 3601 3609 3617 3625 3633 3641 3665 3665 3665 3665 3665 3665 3669 3705 3705 3713 3729 3737 3745 3753 3761 3769 3777	2 3586 3594 3610 3610 3618 3626 3654 3654 3654 3654 3654 3656 3654 3658 3658 3658 3706 3714 3722 3730 3738 3754 3770 3754 3770	3 3587 3595 3603 3611 3619 3627 3643 3651 3663 36643 36651 3669 3707 3715 3723 3731 3731 3739 3747 37715 3763 3771 3775	4 3588 3496 3604 3602 3628 3636 3644 3652 3668 3668 3668 3668 3668 3668 3668 3700 3708 3716 3723 3740 3748 3776 3776 3776	5 3589 3497 3605 3613 3621 3663 3663 3663 3663 3669 3701 3709 3717 3725 3733 3741 3745 3773 3757 3775 3775	6 3590 3598 3606 3614 3622 3630 3654 3663 3678 3678 3678 3678 3678 3678 3767 3710 3718 3726 3774 3774 37758 37766 3774	7 3591 3599 3607 3615 3632 3639 3647 3655 3663 3671 3679 3687 3703 3711 3719 3727 3745 37451 3759 3767 37753 3759 3		7400 7410 7420 7430 7430 7430 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3872 3860 3914 3912 3920 3928 3928 3928 3934 3952 3954 3952 3960 3968 3954 4024 4002 4008 4016	1 3841 3849 3857 3865 3873 3889 3889 3995 3913 3929 3937 3945 3945 3953 3945 3953 3946 3953 3946 4009 4007 40025 4003	2 3842 3850 3858 3866 3874 3882 3906 3914 3922 3930 3930 3938 3946 3954 3954 3954 3954 4012 4018 4026 4042	3 3843 3851 3857 3867 3875 3883 3899 3907 3915 3933 3931 3939 3947 3955 3963 3955 3963 3971 3979 3987 3997 4003 4001 4019 4027	4 3844 3852 3860 3876 3876 3876 3878 3980 3916 3916 3924 3930 3948 3954 3954 3954 3954 3954 3954 4020 4028 4028 4028	5 3845 3863 3869 3893 3901 3917 3925 3933 3941 3941 3943 3941 3945 3965 3973 3985 3983 3989 3997 3989 3997 4005 4013 4021 4029	6 3846 3854 3862 3870 3878 3886 3894 3902 3918 3926 39342 3958 3942 3958 3958 3958 3958 3958 3958 3958 4006 4014 4012 4030	7 3847 3863 3863 3887 3895 3903 3913 3919 3927 3935 3943 3951 3953 3967 3957 3983 3997 3997 3997 3997 4017 4013 4014 4014	7000 io 7777 (Octai)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7040 7050 7060 7070 71100 71100 71100 71100 71100 71100 71100 71100 71100 71100 71100 7110 7210 72	0 3584 3592 3600 3608 3616 3624 3632 3640 3656 3664 3672 3764 3704 37720 3728 3744 37720 3778 3744 3752 3768 3776	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3664 3705 3705 3705 3713 3721 3729 3737 3745 3753 3761 3769 3777 3785	2 3586 3594 3602 3610 3618 3626 3634 3642 3658 3668 3668 3668 3668 3668 3668 3668	3 3587 3595 3603 3611 3617 3627 3643 3643 3659 3663 3663 3663 3663 3663 3663 366	4 3588 3496 3604 3612 3628 3636 3644 3652 3668 3668 3668 3700 3708 3716 3724 3730 3748 3756 3772 3780 3780	5 3589 3497 3605 3613 3629 3637 3645 3663 3661 3663 3663 3701 3709 3717 3725 3733 3741 3749 3757 3773 3761 37781	6 3590 3598 3606 3614 3623 3644 3662 3670 3678 3670 3678 3686 3694 3702 3710 3718 3726 3734 3750 3774 3765 3774	7 3591 3599 3607 3615 3639 3647 3655 3663 3671 3679 3687 3703 3711 3719 3723 3743 3743 3743 3759 3743 3759 3767 3775		7400 7410 7420 7430 7430 7400 7540 7540 7550 7550 7550 7550 755	0 3840 3848 3856 3864 3852 3864 3852 3888 3896 3912 3928 3928 3928 3928 3952 3952 3954 3952 3956 3954 4002 4008 4016 4024 4048	1 3841 3845 3857 3865 3873 3865 3873 3965 3913 3921 3923 3937 3945 3937 3945 3953 3961 3969 3997 3985 3993 3965 4001 4002 4017 4025	2 3842 3850 3858 3866 3874 3898 3906 3914 3914 3922 3938 3946 3954 3954 3954 3954 3954 4012 4012 4012 4012 4018 4026	3 3843 3851 3859 3907 3915 3923 3931 3939 3947 3955 3963 3955 3963 3971 3979 3987 3995 4003 3995 4001 4014 4027 4035 4045	4 3844 3852 3860 3876 3878 3872 3900 3908 3916 3924 3934 3956 3954 3956 3954 3956 3958 3956 3958 4024 4012 4028 4036	5 3845 3853 3869 3877 3885 3991 3901 3909 3917 3925 3933 3949 3949 3949 3949 3957 3941 3949 3957 3967 3941 3969 4013 4021 4021 4021 4021	6 3846 3854 3862 3870 3870 3878 3870 3918 3926 3934 3950 3958 3956 3958 3956 3958 3956 3958 3956 4044 4024 4024 4030	7 3847 3855 3863 3871 3879 3895 3903 3911 3919 3927 3943 3951 3953 3957 3953 3957 3953 3959 3959 4007 4015 4023 4031	7000 io 7777 (Octai)	3584 to to (Decimi
	7000 7010 7020 7030 7040 7050 7060 7070 7110 7120 7130 7140 7130 7140 7150 7110 7130 7210 7220 7230 7240 7230 7250 7270	0 3584 3592 3600 3608 3616 3624 3632 3640 3648 3656 3656 3664 3676 3680 3688 3704 3712 3720 3728 3736 3744 3760 3768 3776 3784 3776	1 3585 3593 3601 3607 3617 3665 3633 3641 3649 3657 3663 3673 3681 3689 3763 3725 3725 3745 3753 3745 3753 3769 3777 3785 3793 3785	2 3586 3594 3602 3610 3618 3626 3634 3642 3658 3666 3668 3706 3714 3722 3730 3738 3746 3742 3742 3730 3776 3776	3 3587 3595 3603 3611 3617 3635 3643 3651 3667 3675 3683 3691 3699 3707 3715 3723 3731 3723 3747 3747 3763 3747 3767 3779 3787 3795	4 3588 3496 3604 3612 3628 3636 3644 3652 3668 3678 3668 3678 3700 3708 3716 3724 3732 3740 3778 3748 3756 3764 3778	5 3589 3497 3605 3613 3629 3637 3645 3663 3661 3669 3693 3701 3709 3717 3725 3733 3741 3749 3749 3749 3749 3749 3749 3749	6 3590 3598 3606 3614 3622 3630 3638 3644 3654 3662 3670 3710 3718 3702 3710 3718 3726 3734 3742 3734 3758 3764 3758 3764 37790 3798	7 3591 3599 3607 3615 3622 3631 3639 3647 3655 3663 3671 3679 3695 3703 3711 3719 3727 3735 3743 3751 3755 3767 3775 375		7400 7410 7420 7430 7430 7430 7440 7450 7510 7520 7550 7550 7550 7550 7550 7550 755	0 3840 3848 3856 3864 3872 3880 3988 3888 3896 3920 3928 3936 3924 3952 3944 3952 3960 3954 3954 4000 4008 4016 4024 4040 4042	1 3841 3845 3857 3865 3873 3865 3873 3881 3889 3913 3929 3937 3945 3953 3953 3953 3953 3953 3954 4003 4003 4005 4025 4033 4057 3965 3957 4057 405	2 3842 3850 3858 3866 3874 3882 3906 3914 3922 3930 3938 3946 3954 3954 3954 3954 3954 3978 3986 4002 4010 4018 4026	3 3843 3851 3857 3867 3875 3883 3891 3993 3907 3915 3933 39347 3955 3963 3979 3987 3955 3963 3979 3987 3979 3987 4003 4001 4019 4027 4035 4043 4059	4 3844 3852 3860 3876 3878 3878 3980 3988 3990 3928 3940 3942 3940 3945 3956 3956 3956 3956 3956 4004 4012 4020 4028 4036 4044 4052	5 3845 3863 3869 3887 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965 3973 3985 3997 3989 3997 4005 4013 4021 4021 4022	6 3846 3854 3862 3870 3878 3986 3988 3988 3910 3918 3926 3934 3958 3942 3958 3942 3958 3958 3958 3958 3958 3958 3958 4014 4024 4034 4038 4046 4052	7 3847 3863 3863 3863 3871 3895 3919 3919 3927 3935 3943 3959 3959 3959 3959 3959 3959 3959 3959 3959 4007 4015 4023 4031 4039 4047 4054 4055 4054 40554 4055 4055 4055 4055 4055 4055 4055 4055 4055 4055 40	7000 io 7777 (Octai)	3584 to 4095 (Decimi
	7000 7010 7020 7020 7030 7040 7050 7050 7050 7050 7050 7050 705	0 3584 3592 3600 3608 3616 3624 3632 3640 3656 3664 3656 3664 3656 3664 3656 3662 3768 3774 3720 3728 3736 3776 3776 3776	1 3585 3593 3601 3609 3617 3625 3633 3641 3657 3665 3657 3665 3657 3667 3767 3705 3775 3775 3775 3775 3775 3775 377	2 3586 3594 3602 3610 3618 3626 3634 3642 3658 3668 3668 3668 3668 3668 3706 3714 3720 3778 3770 3778 3770 3778 3776 3770	3 3587 3595 3603 3611 3619 3627 3635 3643 3659 3663 3663 3663 3663 3663 3663 366	4 3588 3496 3604 3612 3628 3636 3660 3668 3666 3668 3668 3668 366	5 3589 3497 3605 3613 3629 3637 3645 3661 3661 3669 3677 3685 3693 3701 3709 3717 3725 3733 3731 3773 3757 3775 3773 3775 3778 37797 3805	6 3590 3598 3606 3638 3644 3652 3662 3662 3662 3662 3662 3662 3664 3710 3718 3726 3734 3742 3758 3766 3774 3758 3790 3798 3806	7 3591 3593 3607 3615 3622 3631 3663 36647 3663 36647 36657 3703 3703 3703 3703 3711 3719 3727 3743 3743 3743 3743 3759 3767 3775 3783 3791 3799 3807		7400 7410 7420 7430 7430 7430 7450 7510 7550 7550 7550 7550 7550 7550 75	0 3840 3848 3856 3864 3872 3860 3880 3880 3880 3993 3912 3920 3936 3936 3936 3944 3952 3946 3956 3956 3956 3958 4000 4001 4024 4024 4040 4048 4048 4054 4054	1 3841 3849 3857 3865 3873 3881 3889 3913 3921 3921 3923 3937 3943 3953 3953 3953 3953 3953 3961 3969 3977 3985 4001 40025 40025 4041 4049 4045	2 3842 3850 3858 3866 3874 3858 3866 3874 3932 3930 3914 3922 3930 3938 3944 4012 4018 4026 4034 4042 4050 4066	3 3843 3851 3859 3867 3875 3883 3891 3915 3923 3931 3939 3947 3955 3963 3947 3955 3963 3971 3979 3985 3967 3979 3967 3967 3967 3967 3979 3967 3967 3979 3967 3967 3979 3967 3967 3967 3979 3967 3967 3967 3979 3967 3967 3967 3979 3967 3967 3967 3979 3967 3967 3979 3967 3967 3979 3967 3979 3967 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3967 3979 3979 3975 3975 3967 3975 397	4 3844 3852 3860 3876 3876 3876 3876 3980 3990 3900 3908 3916 3924 39340 3948 3956 4004 4012 4020 4028 4028 4024 4052 4068	5 3845 3863 3869 3877 3901 3909 3917 3917 3917 3941 3949 3957 3981 3965 3973 3985 3987 3986 3997 4005 4013 4021 4029 4037 4045 4045	6 3846 3854 3862 3870 3878 3886 3894 3902 3918 3926 39342 3958 3942 3958 3958 3958 3958 3958 3958 3958 4014 4022 4030 4014 40454 40454	7 3847 3863 3863 3871 3873 3895 3903 3913 3913 3927 3935 3943 3951 3953 3951 3953 3957 3953 3957 3953 3957 3953 3959 4007 4015 4023 4031 4035 4047 4055 4071 3075 3095 3095 3095 3095 3095 3097 30975 307575 307575 307575 3075	7000 io 7777 (Octai)	3584 to 4095 (Decimi
	7000 7010 7020 7020 7050 7050 7050 7050 7050 7100 7110 711	0 3584 3592 3600 3608 3616 3624 3648 3656 3664 3656 3664 3656 3664 3656 3668 3668 3672 3688 3696 3704 3712 3728 3720 3728 3776 3768 3776 3776 3776 3776	1 3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3633 3641 3669 3705 3705 3705 3713 3729 3737 3745 3745 3745 3745 3745 3745 3745	2 3586 3594 3602 3610 3626 3634 3642 3650 3658 3664 3658 3664 3658 3706 3714 3752 3770 3778 3746 3776 3778 3778 3794 3794 3818	3 3587 3595 3603 3611 3617 3627 3635 3643 3659 3663 3663 3663 3663 3663 3663 366	4 3588 3496 3604 3612 3628 3636 3644 3652 3700 3708 3708 3708 3716 3724 3732 3740 3748 3756 3764 3772 3780 3778 3780 3796 3804 3820	5 3589 3497 3605 3613 3629 3637 3645 3663 3663 3663 3663 3701 3717 3725 3733 3741 3749 3745 3773 3745 3773 3765 3773 3781 3789 3797 3805 3813	6 3590 3598 3606 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686 3694 3702 3718 3726 3710 3718 3742 3750 3774 3756 3774 3782 3798 3806 3798 3806	7 3591 3599 3607 3615 3622 3631 3639 3647 3653 3663 3663 3663 3703 3703 3711 3719 3743 3743 3743 3743 3743 3743 3745 3743 3745 3743 3745 3745	100 million (100 m	7400 7410 7420 7430 7430 7400 7540 7540 7550 7550 7550 7550 755	0 3840 3848 3856 3864 3872 3888 3896 3912 3920 3936 3936 3936 3936 3936 3956 3944 4056 4024 4048 4048 4056 4072	1 3841 3845 3857 3865 3873 3865 3873 3965 3913 3921 3923 3937 3945 3937 3945 3937 3945 3953 3961 3969 3997 3993 3964 4017 4025 4033 4041 4049 4057 4063	2 3842 3850 3858 3866 3874 3890 3993 3914 3914 3914 3914 3938 3938 3938 3938 3938 3938 3938 3938 3938 4012 4012 4012 4014 4058 4058 4074	3 3843 3851 3859 3867 3875 3873 3899 3907 3939 3947 3939 3947 3939 3947 3939 3947 3955 3963 3979 3987 3987 4003 4001 4027 4035 4051 4051 4051 4055	4 3844 3852 3860 3876 3876 3882 3900 3908 3916 3924 3934 3956 3954 3954 3956 3958 3958 3958 4024 4012 4028 4036 4052 4060 4076 4076 4076	5 3845 3853 3869 3877 3885 3991 3917 3925 3933 3949 3949 3949 3949 3957 3961 3949 3949 3957 3961 3981 3989 4013 4021 4022 4003 4001 4029	6 3846 3854 3862 3870 3870 3878 3870 3918 3926 3934 3950 3958 3956 3958 3958 3958 3958 3958 3958 4044 4022 4030 4038 4046 4054 4054 4078	7 3847 3855 3863 3871 3879 3895 3903 3911 3919 3927 3943 3951 3953 3957 3953 3957 3953 3959 3959 4007 4015 4023 4031 4039 4047 4055 4063	7000 io 7777 (Octai)	3584 to 4095 (Decimi
	7000 7010 7020 7030 7060 7060 7060 7100 7100 7130 7140 7130 7140 7150 7140 7150 7140 7150 7200 7210 7220 7220 7230 7240 7250 7330 7340	0 3584 3592 3600 3608 3624 3632 3640 3648 3656 3664 3656 3664 3664 36656 3768 3768 3704 3712 3720 3728 3744 3752 3760 3778 3744 3752 3760 3808 3816 3808 3816 3808	1 3585 3593 3601 3607 3617 3665 3633 3641 3669 3673 3689 3697 3705 3713 3729 3737 3745 3753 3769 3775 3775 3769 3775 3769 3775 3775 3769 3775 3769 3775 3769 3775 3775 3775 3775 3775 3775 3775 377	2 3586 3594 3602 3610 3618 3626 3634 3658 3666 3668 3706 3714 3722 3730 3738 3746 3742 3730 3738 3746 3742 3745 3746 3746 3748 3746 3748 3746 3748 3746 3748 3748 3748 3748 3748 3748 3748 3748	3 3587 3595 3603 3611 3619 3627 3635 3643 3659 3665 36659 36659 36675 3683 36691 37675 3723 3767 3715 3733 3731 3737 3747 3745 3747 3747 3747 3747 3747	4 3588 3496 3604 3612 3620 3628 3636 3646 3646 3646 3646 3646 3708 3716 3708 3716 3732 3740 3748 3748 3746 3748 3748 3748 3748 3748 3748 3748 3748	5 3589 3497 3605 3613 3629 3637 3645 3661 3663 3661 3663 3667 3663 3701 3709 3717 3725 3733 3741 3733 3749 3749 3749 3749 3749 3749 3749	6 3590 3598 3606 3614 3622 3630 3638 3644 3654 3662 3670 3710 3718 3702 3710 3718 3726 3734 3734 3734 3742 3758 3764 3742 3758 3764 3742 3758 3774 3774 3778 3774 3778 3774 3778 3774 3778 3774 3774	7 3591 3593 3607 3615 3622 3631 3633 3663 3671 3663 3671 3745 3743 3745 374		7400 7410 7420 7430 7440 7450 7550 7550 7550 7550 7550 7560 7550 7660 7560 7610 7620 7630 7640 7650 7650 7650 7670 7710 7710 7730 7730 7730 7730	0 3840 3848 3856 3867 3880 3880 3880 3994 3912 3928 3936 3944 3936 3944 3952 3960 3952 3960 3952 3968 3954 4008 4008 4024 4040 4042 4056 4064 4064 4080	1 3841 3842 3857 3865 3873 3867 3887 3905 3913 3929 3937 3945 3953 3953 3953 3953 3953 3953 3953 3954 4009 4007 4003 4004 4057 4057 4067 3067 4081 3095 305	2 3842 3850 3868 3868 3868 3868 3867 3882 3890 3914 3920 3938 3934 3954 3954 3954 4002 4014 4014 4014 4042 4042 4058 4064 4058 4067 4082	3 3843 3859 3867 3879 3869 3883 3891 3923 3931 3939 3947 3923 3939 3939 3947 3955 3963 3955 3963 3971 3975 4003 3987 3987 4014 4015 4027 4043 4059 4067 4067 4067 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4083 4085 4085 4059 405	4 3844 3852 3860 3876 3878 3878 3980 3990 3916 3924 3932 3940 3932 3940 3945 3956 3964 3956 3964 3988 3996 4002 4020 4024 4020 4026 4044 4056 4068 4068 4084 4084 4084	5 3845 3863 3869 3877 3885 3893 3901 3901 3903 3931 3935 3931 3941 3941 3949 3957 3965 3973 3985 3997 3987 4005 4013 4021 4021 4021 4045 4045 4061 4069 4085	6 3846 3854 3862 3870 3878 3986 3988 3988 3910 3918 3926 3934 3958 3942 3958 3942 3958 3958 3956 3974 4006 4003 40038 4046 40454 40454 4070 4078	7 3847 3863 3863 3863 3871 3895 3903 3911 3919 3925 3943 3959 3943 3959 3959 3959 3959 3959 3959 3959 4007 4015 4023 4031 4039 4047 4059 4063 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 4079 4071 3959 4007 4015 4023 4031 4031 4059 4067 4071 4071 4073 4071 4073 4071 4073 4071 4073 4071 4073 4071 4073 4074 4073 4071 4074 4073 4071 4073 4074 4073 4071 4073 4074 407	7000 io 7777 (Octai)	3584 to 4095 (Decim:

FOR TRAINING PURPOSES ONLY

OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
000	000000	100	125000	200	250000	300	375000
001	001953	101	126953	200	251953	301	376953
002	003906	102	128906	207	253906	302	378906
003	005859	102	130859	202	255859	302	378900
004	007812	104	132812	203	253853	303	300055
005	009765	104	132012	204	257012	304	302012
006	011718	105	136718	205	259705	305	304/00
007	013671	107	138671	200	262671	300	300/10
007	010071	107	130071	207	203071	307	3000/1
010	015625	110	140625	210	265625	310	390625
011	017578	111	142578	211	267578	311	392578
012	019531	112	144531	212	269531	312	394531
013	021484	113	146484	213	271484	313	396484
014	023437	114	148437	214	273437	314	398437
015	025390	115	150390	215	275390	315	400390
016	027343	116	152343	216	277343	316	402343
017	029296	117	154296	217	279296	317	404296
Line - Marian			101200	211	215250	517	404230
020	031250	120	156250	220	281250	320	406250
021	033203	121	158203	221	283203	321	408203
022	035156	122	160156	222	285156	322	410156
023	037109	123	162109	223	287109	323	412109
024	039062	124	164062	224	289062	324	414062
025	041015	125	166015	225	291015	325	416015
026	042968	126	167968	226	292968	326	417968
027	044921	127	169921	227	294921	327	419921
000	040075			AL TELEVISION			
030	046875	130	171875	230	296875	330	421875
031	048828	131	173828	231	298828	331	423828
032	050781	132	175781	232	300781	332	425781
033	052734	133	177734	233	302734	333	427734
034	054687	134	179687	234	304687	334	429687
035	056640	135	181640	235	306640	335	431640
036	058593	136	183593	236	308593	336	433593
037	060546	137	185546	237	310546	337	435546
040	062500	140	197500	240	212500		107500
041	064452	140	10/500	240	312500	340	437500
041	066406	141	189453	241	314453	341	439453
042	069350	142	191406	242	316406	342	441406
043	070313	143	193359	243	318359	343	443359
045	070312	144	195312	244	320312	344	445312
045	072205	145	197205	245	322265	345	44/265
040	074210	140	199218	246	324218	346	449218
047	0/01/1	14/	2011/1	241	.326171	347	4511/1
050	078125	150	203125	250	328125	350	453125
051	080078	151	205078	251	330078	351	455078
052	082031	152	207031	252	332031	352	457031
053	083984	153	208984	253	333984	353	458984
054	085937	154	210937	254	335937	354	460937
055	087890	155	212890	255	337890	355	462890
056	089843	156	214843	256	339843	356	464843
057	091796	157	216796	257	341796	357	466796
A SALAN AND A SALAN							100700
060	093750	160	218750	.260	.343750	360	468750
061	095703	161	220703	.261	345703	361	470703
062	097656	162	222656	.262	347656	362	.472656
.063	099609	.163	224609	.263	.349609	363	474609
.064	101562	164	226562	.264	.351562	.364	476562
065	103515	.165	228515	.265	353515	.365	.478515
.066	105468	166	230468	.266	355468	.366	480468
067	107421	167	.232421	.267	.357421	.367	.482421
070	100275	170	224275	1 States and			
070	111220	170	234375	.270	.359375	.370	484375
071	112201	171	236328	.271	361328	.371	486328
072	115201	172	238281	.272	363281	.372	488281
073	117197	173	240234	.273	365234	373	490234
074	110140	174	24218/	.274	.36/187	.374	.492187
075	121002	.175	244140	.275	.369140	.375	494140
.076	121093	.176	246093	.276	.371093	.376	496093
	.123046	.177	.248046	.277	373046	.377	.498046

OCTAL-DECIMAL FRACTION CONVERSION TABLE



OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
000000	000000	000100	000244	000200	000488	000300	000732
000000	000000	000101	000247	000201	000492	000301	000736
000001	000003	000101	000251	000202	000495	000302	000740
000002	000007	000102	000255	000202	000499	000303	000743
000003	000011	000103	000255	000203	000499	000303	000743
000004	000015	000104	000259	000204	000503	000304	000751
000005	000019	000105	000263	000205	000507	000305	000751
000006	000022	000106	000267	000206	000511	000300	000755
000007	000026	000107	000270	000207	000514	000307	000759
000010	000030	000110	000274	000210	000518	000310	000762
000011	000034	000111	000278	000211	000522	000311	000766
000012	000038	000112	000282	000212	000526	000312	000770
000012	000041	000112	000286	000212	000530	000313	000774
000014	000045	000114	000289	000214	000534	000314	000778
000015	000049	000115	000293	000215	000537	000315	000782
000016	000053	000116	000297	000216	000541	000316	000785
000017	000057	000117	000201	000217	000545	000317	000789
000017	000037	000117	000001	000217	000040	000011	000700
000020	000061	000120	000305	000220	000549	000320	000793
000021	000064	000121	000308	000221	000553	000321	000797
.000022	000068	.000122	000312	000222	000556	000322	000801
000023	000072	000123	000316	000223	000560	000323	000805
000024	000076	000124	000320	000224	000564	000324	000808
000025	000080	000125	000324	000225	000568	000325	000812
000026	000083	000126	000328	000226	000572	000326	000816
000027	000087	000127	000331	000227	000576	000327	000820
.000030	000091	.000130	000335	000230	000579	000330	000823
.000031	.000095	.000131	000339	000231	000583	000331	000827
.000032	.000099	000132	000343	000232	000587	000332	000831
000033	.000102	000133	000347	000233	000591	000333	000835
.000034	.000106	000134	000350	000234	000595	000334	000839
.000035	.000110	000135	000354	000235	000598	000335	000843
000036	.000114	000136	000358	000236	000602	000336	000846
000037	.000118	000137	000362	000237	000606	000337	000850
000040	000122	000140	000266	000240	000610	000240	000854
000040	000122	000140	000300	000240	000614	000340	000854
.000041	000125	000141	000370	000241	000617	000341	000858
.000042	000129	000142	000373	000242	000617	000342	000862
000043	000133	000143	000377	000243	000625	000343	000865
000044	000137	000144	000381	000244	000625	000344	000809
.000045	000141	000145	000385	000245	000629	000345	000873
000048	000144	000140	000389	000240	000633	000340	000891
.000047	.000148	.000147	000392	000247	000037	000347	000881
.000050	000152	000150	000396	000250	000640	000350	000885
.000051	.000156	000151	000400	000251	000644	000351	000888
.000052	.000160	.000152	000404	000252	000648	000352	000892
.000053	.000164	.000153	.000408	000253	.000652	000353	000896
.000054	.000167	.000154	.000411	000254	000656	000354	.000900
.000055	.000171	.000155	000415	.000255	000659	.000355	000904
.000056	.000175	000156	.000419	.000256	.000663	000356	.000907
.000057	.000179	.000157	.000423	000257	000667	.000357	.000911
000060	000192	000160	000427	000000	000671	000000	000015
.000060	.000183	000160	.000427	000260	000675	000360	000915
.000061	.000186	.000161	.000431	000261	.000675	000361	.000919
.000062	.000190	.000162	.000434	000262	.000679	000362	.000923
.000063	.000194	.000163	.000438	000263	.000682	.000363	.000920
.000064	.000198	.000164	.000442	000264	000686	.000364	000930
000065	000202	000165	000440	000265	000690	000365	000934
.000066	.000205	000166	000450	000266	.000694	000366	000938
.000067	.000209	.000167	.000453	.000267	.000698	000367	000942
.000070	.000213	.000170	.000457	.000270	.000701	.000370	.000946
.000071	.000217	.000171	.000461	000271	.000705	.000371	.000949
.000072	.000221	.000172	.000465	.000272	.000709	.000372	.000953
.000073	.000225	.000173	.000469	.000273	.000713	.000373	.000957
.000074	.000228	.000174	.000473	.000274	.000717	000374	.000961
.000075	.000232	.000175	.000476	.000275	.000720	.000375	.000965
.000076	.000236	.000176	.000480	.000276	.000724	.000376	.000968
.000077	.000240	.000177	.000484	.000277	.000728	.000377	.000972
		-	Contraction of the second		the second s		

OCTAL-DECIMAL FRACTION CONVERSION TABLE

OCTAL-DECIMAL			FRACTI	ON CONVERSIC		N TABLE	
OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
000400	000976	000500	001220	000600	001464	000300	001300
000401	000980	000501	001220	000601	001468	000700	001708
000402	000984	000502	001228	000602	001472	000707	001712
000403	000988	000503	001232	000603	001472	000702	001770
000404	000991	000504	001235	000604	001480	000703	001720
000405	000995	000505	001239	000605	001483	000705	001728
000406	.000999	000506	001243	000606	001487	000706	001731
000407	001003	000507	001247	000607	001491	000707	001735
000410	001007	000540					
000410	001007	000510	001251	000610	001495	000710	001739
000412	001010	000511	001255	000611	001499	000711	001743
000413	001018	000512	001258	000612	001502	000712	001747
000414	001022	000514	001266	000614	001510	000714	001754
000415	001026	000515	001270	000615	001514	000715	001758
000416	001029	000516	001274	000616	001518	000716	001762
000417	001033	000517	001277	000617	001522	000717	001766
000420	001027	000520	001201	000000	001505	000700	
000420	001037	000520	001281	000620	001525	000720	001770
000422	001045	000522	001285	000621	001529	000721	001773
000423	001049	000522	001293	000622	001533	000722	001777
000424	001052	000523	001295	000623	001537	000723	001781
000425	001056	000525	001300	000625	001544	000724	001789
000426	001060	000526	001304	000626	001548	000726	001792
000427	001064	.000527	001308	000627	001552	000727	001796
000420	001000	000500					
000430	001068	.000530	001312	000630	001556	000730	001800
000431	001075	000531	001310	000631	001560	000731	001804
000433	001079	000532	001319	000632	001567	000732	001808
000434	001083	000534	001323	000634	001571	000733	001815
000435	001087	000535	001331	000635	001575	000735	001819
000436	001091	.000536	001335	000636	001579	000736	001823
.000437	001094	.000537	001338	.000637	.001583	.000737	001827
000440	001099	000540	001242	0000040	001500	000740	
000441	001102	000541	001342	000640	001580	.000740	001831
000442	001106	000542	001350	000641	001590	000741	001834
000443	001110	000543	001354	000642	001594	000742	001838
000444	.001113	.000544	001358	000644	001602	000744	001846
000445	.001117	.000545	001361	000645	001605	000745	001850
000446	.001121	.000546	.001365	.000646	.001609	.000746	001853
000447	001125	.000547	.001369	.000647	.001613	.000747	001857
000450	.001129	.000550	001373	000650	001617	000750	001861
.000451	.001132	.000551	.001377	.000651	.001621	000751	001865
.000452	.001136	.000552	.001380	.000652	.001625	.000752	001869
.000453	.001140	.000553	.001384	.000653	.001628	.000753	.001873
000454	.001144	.000554	.001388	.000654	.001632	.000754	.001876
.000455	.001148	.000555	.001392	.000655	.001636	.000755	.001880
.000456	.001152	.000556	.001396	.000656	.001640	.000756	.001884
.000457	.001155	.000557	.001399	.000657	.001644	.000757	.001888
.000460	.001159	.000560	.001403	.000660	.001647	.000760	.001892
.000461	.001163	.000561	.001407	.000661	.001651	.000761	.001895
.000462	.001167	.000562	.001411	.000662	001655	.000762	.001899
000463	.001171	.000563	.001415	.000663	.001659	.000763	.001903
000464	001174	.000564	.001419	.000664	.001663	.000764	.001907
000465	001102	.000565	001422	.000665	.001667	.000765	.001911
.000467	001182	000565	001426	.000666	.001670	.000766	001914
			.001430		.001074	.000767	.001918
000470	.001190	.000570	.001434	.000670	.001678	.000770	.001922
000471	001194	000571	.001438	.000671	.001682	.000771	.001926
000472	001201	000572	001441	.000672	.001686	.000772	001930
.000474	.001205	000574	001449	000673	001689	.000773	.001934
.000475	.001209	.000575	001453	000675	001697	000775	001937
.000476	.001213	.000576	.001457	.000676	001701	000776	001945
.000477	.001216	.000577	.001461	.000677	.001705	.000777	.001949



ACE-S/C FUNCTIONAL DESCRIPTION

OBJECTIVES

To familiarize the student with:

- a. ACE-S/C system data flow.
- b. Major subsystem identification.
- c. Function and interface relationships of various equipment.
- d. Operating characteristics.

INTRODUCTION

The <u>ACE-S/C Operator's Manual</u> contains a functional description of the ACE-S/C. The student should read Chapter 1 of the <u>ACE-S/C Operator's Manual</u> and study the ACE-S/C system block diagram wall chart.

ACE-S/C PHYSICAL DESCRIPTION

OBJECTIVES

To familiarize the student with the physical identification and layout of the Acceptance Checkout Equipment - Spacecraft.

INTRODUCTION

GENERAL

The ACE-S/C equipment is divided into four physical areas: the control room, the computer room, the terminal facility room (usually shared by two or more ground stations), and the launch implacement area or spacecraft test area. This arrangement provides for logical equipment grouping and separation of personnel concerned with different aspects of system operation. Certain subsystems, of necessity, cut across these physical boundaries. Portions of these subsystems will, therefore, be found in more than one of the four areas.

CONTROL ROOM EQUIPMENT

The control room contains the primary controls and displays of the ACE-S/C station. These are arranged in a series of consoles, grouped according to functional spacecraft systems, providing a central location for stimulating and monitoring the performance of each spacecraft system.

The system consoles are arranged in the following groups: (Not all groups may be used in any given ground station.)

- a. Test Conductor Console (TC).
- b. Instrumentation Console (Inst).
- c. Communications Console (Comm).
- d. Environmental Control System Console (ECS).
- e. Fuel Cell and Cryogenics Console (FC and C).
- f. Power and Sequential Console (Pwr and Seq).
- g. Guidance and Navigation Console (G&N).
- h. Stabilization and Control (Stab and Cont).
- i. Propulsion and Reaction Control System Console (Prop and RCS).

- j. Aeromedical System Console.
- k. Thermostructures Facility Console.

COMPUTER ROOM EQUIPMENT

The computer room contains the Digital Acquisition and Decommutation Equipment (DADE), the command and display computer complex, the DTVC's, a roll-chart recorder group (at some stations this may be located in the terminal facility room), magnetic tape recorders, time interface units, and the ACE-S/C station checkout equipment.

The computer complex includes two computer consoles, two compute modules (the command and display computers), three auxiliary memory modules, three auxiliary input modules, and associated peripheral equipment.

The ACE-S/C checkout equipment includes a PCM simulator, an event recorder, and several analog recorders. The computer complex console contains START modules, displays, and controls employed in ACE-S/C station checkout as well as for monitor-ing system performance. An event distribution, recording, and patching unit is provided to drive the computer room event displays.

Wall clocks, displaying real and countdown time, and voice communication equipment are also provided in the computer room.

TERMINAL FACILITY ROOM EQUIPMENT

The terminal facility room provides a flexible interface between the remote spacecraft test areas and the ACE-S/C stations. It also provides certain support and interfacing functions within the stations.

The terminal facility room contains the terminal patch facility, the timing group, certain alphanumeric display system units, the CUE unit, and voice communication units.

The terminal patch facility serves as the external interface for all ACE-S/C station input and output data lines. It also permits the ACE-S/C control rooms and computer rooms to be cross-patched from one system to another. (Normally, the ACE-S/C stations will operate independently of each other; however, by means of cross-patching within the terminal facility room, any computer room can operate with any control room.)

410-0(104)

The timing group is composed of a time code generator, which drives various realtime displays in the stations, and countdown generators (one for each station), which drive countdown displays.

The SGS unit and (at locations where it is required) the DCCU are located in the terminal facility room. This equipment provides an interface between the display computer in the computer room and the CRT displays in the control room.

SPACECRAFT AND SPACECRAFT TEST AREA EQUIPMENT

The spacecraft and spacecraft test area contain the interface equipment that completes the checkout loop between the spacecraft and the ACE-S/C station. The interface equipment consists of Digital Test Command Systems (DTCS) and Digital Test Measurement Systems (DTMS).

The carry-on DTCS is physically located near the spacecraft and consists of a receiver-decoder, baseplates, and relay and DAC modules. The external DTCS and the Service Equipment (S/E) DTCS are physically located adjacent to the spacecraft. EXTERNAL The S/E DTCS interfaces with ground support equipment in the vicinity of the space-craft to provide remote control of command/service module or lunar excursion module.

The carry-on DTMS is physically located in the spacecraft and consists of three signal conditioning and sampling units and one pulse code modulation subsystem. The S/E DTMS system is physically located adjacent to the spacecraft and consists of the external signal conditioning unit and service equipment adapter. The data interleaver is located adjacent to the spacecraft.

ACE-S/C PHYSICAL CONFIGURATION AT NORTH AMERICAN AVIATION, INC., DOWNEY, CALIFORNIA

Three ACE-S/C ground stations are installed in Building 290 at North American Aviation, Inc., to accomplish acceptance checkout of the Apollo command and service modules. The equipment locations at these stations is shown in Figure 1.

ACE-S/C PHYSICAL CONFIGURATION AT GRUMMAN AIRCRAFT ENGINEERING CORPORATION, BETHPAGE, NEW YORK

Two ground stations are located at Grumman Aircraft Engineering Corporation to test the lunar excursion module. Figure 2 shows the equipment location at this installation.

ACE-S/C PHYSICAL CONFIGURATION AT NASA MANNED SPACECRAFT CENTER, HOUSTON, TEXAS

Two ACE-S/C ground stations are installed at MSC, Houston to support the command, service, and lunar excursion modules in simulated lunar missions. These stations are installed in Building 32. The equipment layout is shown in Figure 3.

ACE-S/C PHYSICAL CONFIGURATION AT MERRITT ISLAND LAUNCH AREA, FLORIDA

Five ACE-S/C stations are located in the O&C Building at MILA to accomplish receiving and launch readiness checkout of the command, service, and lunar excursion modules. Figure 4 shows the equipment layout at this location.


3C507781G1 3C507671G1 3C507646G1 3C507720G1	INSTRUMENTATION SYSTEM - LOW CABINETS* COMMUNICATION SYSTEM - LOW CABINETS ENVIRONMENTAL CONTROL SYSTEM - LOW CABINETS
3C507671G1 3C507646G1 3C507720G1	COMMUNICATION SYSTEM - LOW CABINETS ENVIRONMENTAL CONTROL SYSTEM - LOW CABINETS
3C507646G1 3C507720G1	ENVIRONMENTAL CONTROL SYSTEM - LOW CABINETS
3C507720G1	
	ENVIRONMENTAL CONTROL SYSTEM - HIGH CABINETS
3C507644G1	FUEL CELL AND CRYOGENICS - LOW CABINETS
BC507654G1 BE907543G1	FUEL CELL AND CRYOGENICS - HIGH CABINETS FUEL CELL AND CRYOGENICS - HIGH CABINETS
BC507641G1	POWER AND SEQUENTIAL SYSTEM - LOW CABINETS
BC507710G1 BE907525G1	POWER AND SEQUENTIAL SYSTEM - HIGH CABINETS POWER AND SEQUENTIAL SYSTEM - HIGH CABINETS
3C507640G1	GUIDANCE AND NAVIGATION - LOW CABINETS
C507709G1	GUIDANCE AND NAVIGATION - HIGH CABINETS
3C507643G1	STABILIZATION AND CONTROL SYSTEM - LOW CABINETS
C507652G1	STABILIZATION AND CONTROL SYSTEM - HIGH CABINETS
C507648G1	PROPULSION SPS AND RCS SYSTEMS - LOW CABINETS
C507679G1	PROPULSION SPS AND RCS SYSTEMS - HIGH CABINETS
C507677G1	TEST CONDUCTOR CONSOLE
C507658G1	EVENT STORAGE AND DISTRIBUTION UNIT/ DECOMMUTATOR DIST.
S. S	REAL AND COUNTDOWN WALL TIME DISPLAY
	REAL AND COUNTDOWN WALL TIME DISPLAY
	REAL AND COUNTDOWN WALL TIME DISPLAY
	C507654G1 E907543G1 C507641G1 C507710G1 E907525G1 C507640G1 C507643G1 C507652G1 C507652G1 C507679G1 C507679G1 C507658G1

L

410-0(104)

Figure 1. ACE-S/C Control Room Equipment Layout at NAA, Downey, Calif. (Sheet 1 of 3)

5/6



410-0(104)

NO.	NO. OF ENCLO- SURES	DESCRIPTION
100	4	DIGITAL ACQ. & DECOM. EQUIP. #1 & SIMULATOR
102	4	DIGITÀL ACQ. & DECOM. EQUIP. #2
103	1	SPARE CABINET
104	1	VIDEO DISTRIBUTION & TAPE TRANSPORT CONTROL UNIT
105	1	MAGNETIC TAPE RECORDER/REPRODUCER
106	1	MAGNETIC TAPE RECORDER/ REPRODUCER
107	1	MAGNETIC TAPE RECORDER/REPRODUCER
110	3	ANALOG RECORDER
113	I	EVENT DISTRIBUTION RECORDING AND PATCHING
116	1	TAPE RECORDER/COMP TIME DECODER & SEARCH UNIT
117	1	COUNTDOWN GENERATOR COMPUTER INTERFACE
119	1	COMPUTER CONSOLE
120	1	COMPUTER MODULE
121	1	TYPEWRITER
122	1	CARD READER
124	1	MAGNETIC TAPE CONTROLLER
125	1	MAGNETIC TAPE TRANSPORT
126	1	MAGNETIC TAPE TRANSPORT
127	2	D. T. V. C.
130	1	INPUT/OUTPUT UNIT (3 MODULES)
131	4	MEMORY UNIT (3 MODULES)
134	1	REAL & COUNTDOWN WALL TIME DISPLAY
135	1	REAL & COUNTDOWN WALL TIME DISPLAY
139	1	COMPUTER CONSOLE
140	1	COMPUTER MODULE
141	1	TYPEWRITER
142	1.	CARD READER
145	1	MAGNETIC TAPE TRANSPORT
146	1	MAGNETIC TAPE TRANSPORT
147	1	X-Y PLOTTER
148	1	X-Y PLOTTER
150	1	LINE PRINTER
151	1	PUNCH CONTROL & MAGNETIC TAPE CONTROLLER
152	1	CARD PUNCH
15.4	4	COMPUTER COMPLEX CONSOLE
165	1	F. M. DISCRIMINATOR UNIT
166	1	FM CALIBRATION UNIT

7/8





NOTE: I. 4TH STATION CUE WILL FIT INTO UNIT 204 IF REQUIRED. 2. 4TH STATION DCCU WILL FIT INTO UNIT 206 IF REQUIRED.

Figure 1. ACE-S/C Terminal Facility Room Equipment Layout At NAA, Downey, Calif. (Sheet 3 of 3)





FOR TRAINING PURPOSES ONLY

410-0(104)





Figure 3. ACE-S/C Equipment Layout at MSC Houston, Texas





-+

Figure 4. ACE-S/C Equipment Layout at Merritt Island Launch Area, Florida (Sheet 1 of 2)



410-0(104)

17/18

DATA ENTRY EQUIPMENT

OBJECTIVES

To familiarize the student with:

- a. Modes of operation.
- b. Data entry/computer interface.
- c. Theory of operation (block diagram).
- d. Controls displays.
- e. Confirmation codes.

INTRODUCTION

The data entry equipment is an integral part of the uplink loop and serves as a communications link between the test operator and the ACE-S/C computer complex. This equipment permits the simultaneous initiation of individual data and/or test commands to the computer. The computer processes these inputs, generates and transmits the test commands to the Digital Test Command System (DTCS), and returns the status of the test commands to the data entry equipment for display and operator evaluation.

The data entry equipment consists of six basic units:

- a. Communications Unit Executor (CUE).
- b. Junction Box (J-Box).
- c. Relay Start (R-START).
- d. R-START (Enclosure).
- e. Computer Communications Start (C-START).
- f. Keyboard Start (K-START).

The Selection To Activate Random Testing (START) modules are mounted in the control room consoles and are connected to CUE by means of J-Boxes, which are also located in the consoles. The data entry equipment operates under program control of the uplink computer. The CUE is the heart of the data entry equipment and serves as the interface between the START modules and the computer. The CUE can be selected for any one of four modes of operation by the uplink computer. The CUE normally operates in the manual mode; whereby, the operator manually inserts a test command into a START module. The START module is then executed, the CUE interrupts the

computer main program, and then transfers the START module information into the computer memory. The remaining three modes of operation are identified as automatic mode, where the information is prestored in the START modules, and the computer interrogates specific START modules under program control; maintenance mode, where the computer can communicate with the Command Monitor Unit (CMU) via the CUE; and the standby mode, which is defined as the idling mode of the CUE.

EXPLANATION

GENERAL

The data entry equipment makes it possible for a plurality of operators to initiate, simultaneously, test commands for the uplink computer to process. The subsystem is configured as shown in Figure 1, with the various START modules being the most basic item to the system. As shown in the diagram, each J-Box can service sixteen START modules in two groups of eight each. In a similar fashion, the CUE services sixteen J-Boxes also in two groups of eight each, so that the system can accommodate a total of 256 START modules.

There are three distinct types of START modules: R-START modules, which provide for manual control of discrete events or for subroutine callup; C-START modules, which provide for manual selection of computer subroutines and the parameters required by the subroutines; and a single K-START module, which provides manual and automatic means of inserting information into the Apollo Guidance Computer (AGC). Refer to Section 1 of the <u>ACE-S/C Operator's Manual</u> for detailed operating instructions.

Figure 2 is a functional block diagram of the data entry equipment, which illustrates the functional relationships between the various components making up the data entry equipment. This figure also shows the control signal and data flow that exists between the CUE and the uplink computer.

R-START

Each R-START module provides the operator with a means of manually initiating test commands that control individual relay action in subgroups of four at a time. In other words, there is a one-to-one correspondence between a given function switch and a relay in the sensor stimulation equipment of the DTCS. The operator sets the status of the relays under his control by depressing the proper combination of function switches on the R-START modules (see Figure 3). The lower half of the back-light, split-legend

SIMPLIFIED DATA ENTRY ADDRESSING DIAGRAM

	STARTS 0.7	GROUP O	J-BOX	1	CUE
STARTS 0-7		GROUP 1	0		
	STARTS 0-7	GROUP O	J-BOX		
STARTS 0.7		GROUP 1	1		
and a start of the	STARTS 0.7	GROUP 0	J-BOX		
STARTS 0-7		GROUP I	2		
	STARTS 0-7		J-BOX		
STARTS 0-7			. 3		
	STARTS 0-7	GROUP 1	J-BOX		
STARTS 0-7		GROUP O	4		
	STARTS 0.7	GROUP 1	J-BOX		
STARTS 0.7		GROUP O	J		
CTADIC 0.7	STARTS 0-1	GROUP 1	J-BOX	-•	
STARTS U-1	STAPTS 0.7	GROUP O			
STARTS 0.7	STARTS 04	GROUP 1	7	• • • • • • • • • • • • • • • • • • • •	Star A
Jinnis 07	STARTS 0.7	GROUP O	I.BOX	PATCH 1	
STARTS 0.7		GROUP 1	0		
Party and a low loss	STARTS 0.7	GROUP O	J-BOX		
STARTS 0.7		GROUP 1	1		
	STARTS 0.7	GROUP U	J-BOX		
STARTS 0-7			2		
	STARTS 0.7	GROUP 0	J-BOX		
STARTS 0.7		GROUP O	3		
A CONTRACTOR	STARTS 0.7	GROUP 1	J-BOX		
STARTS 0.7		GROUP O	4		
	STARTS 0.7	GROUP 1	J-BOX	-•	
STARTS 0.7		GROUP O	J		
STARTS 0.7	STAKIS U-1	GROUP 1	J-ROX	-•	
STARTS U-7	STARTS 0.7	GROUP O			
T O 2TARTS	STARTS U-7	GROUP 1	J-60A		
STARTS U.I	Contraction of the second s		Sector of the se	the build and the second second second	





4



410-0 (105)

410-0(105)

FOR TRAINING PURPOSES ONLY

function switches illuminates to provide the operator with a visual indication of the test command just inserted. The operator then depresses the XEQ switch sending a signal to the CUE that inhibits any C-START modules from being executed until all executed R-START modules have been serviced (see Figure 3). Group and unit translators in the CUE generate an enabling signal that permits the R-START to transmit an execute signal to the CUE. This execute signal performs three basic functions:

- a. Stops the CUE scanner on the address of the R-START.
- b. Gates the setting of the four function switches and the three least significant bits of the module address to the J-Box.

7

c. Causes the CUE to generate an Interrupt 30 to the uplink computer.

The J-Box adds the next four bits of address and the CUE adds the last or most significant bit. The four function bits from the R-START and the eight-bit scanner address are combined into a 12-bit word that is transferred to the computer on its command. Normally the response of the system to an execute will be the illumination or nonillumination of the upper half of the function switches, matching them to the state that had been set manually by the operator. The correspondence between the upper and lower portions of the function switches indicate to the operator that his command was successfully transmitted and accepted by the DTCS equipment. In response to certain predetermined conditions, the START modules may be logically isolated or SEALed from the system by commands originating in the computer. The Select Extend Allocate Lockout (SEAL) command causes the lower position of the XEQ switch to illuminate, informing the operator of the SEAL condition.

Figure 4 illustrates the relationship of the R-START module to the remainder of the data entry equipment and also shows the signal and data flow between the START modules and the computer. The input control signals to the START modules originate in the computer. Their function is described as follows:

- a. SEAL This signal inhibits the addressed START module from transmitting an execute signal to CUE.
- b. REMOVE SEAL The REMOVE SEAL signal is used in two ways: to either reset the CUE or to gate a confirming response to the START module.
- c. UNIT SELECT This signal is generated when the scanner count is the same as the address for a particular START module.
- d. Q This signal is transmitted when the data entry equipment is in the automatic mode of operation and enables preselected patterns of digital information in the R-START to be transmitted to the CUE for subsequent transfer to the computer.

FOR TRAINING PURPOSES ONLY

6



Figure 4. R-START/Data Entry Functional Diagram

7

4 BIT WORD SENT ADDRESS (105)

e. Four response code bits, F1 through F4, light the corresponding upper halves of the indicators when the relays are latched.

The four data bits from the computer via CUE are fanned into the four-bit receiver section of the addressed START module and are gated to the storage unit by the remove SEAL signal. From there the data bits are gated to the function light latches. In other words, the status of the upper half of the function switches always indicates the condition of the relays which they control. A lighted indicator corresponds to a relay latch condition.

C-START MODULE

The C-START panel contains ten 12-position selector switches, ten displays which indicate the selector switch settings, an XEQ switch indicator, Power On indicator, and four function indicator lights. Each individual switch position provides a four-bit binary-coded-decimal (BCD) (8-4-2-1) code for transmission to the computer. Thus, the command output of a C-START module is a 40-bit message. This output is used for setting discrete voltages in the D/A converters of the DTCS and to modify preprogramed subroutines.

The sequence of C-START operation is as follows:

- a. The operator sets up a predetermined code by means of the selector switches and verifies his selection by observation of the display on the C-START panel.
- b. When he is satisfied that the correct sequence of characters has been selected, he enters them into the computer by depressing the XEQ switch, which causes illumination of the upper half of the XEQ switch.
- ✓ c. The response of the system to a C-START execute will be to extinguish the upper half of the XEQ switch and to illuminate the four function lamps into codes that indicate various responses to the C-START command.

Figure 5 is a block diagram of a C-START module. As seen in the diagram, it is composed of function select switches, BCD converters, project indicators, and logic gating circuits.

Figure 6 illustrates the relationships of the C-START module to the remainder of the data entry equipment and also shows the signal and data flow between the START modules and the computer.



Figure 5. C-START Block Diagram

FOR TRAINING PURPOSES ONLY

410-0(105)

9



Figure 6. C-START/Data Entry Functional Diagram

FOR TRAINING PURPOSES ONLY

10

410-0(105)

410-0(105)

The logic involved in the operation of the C-START module is analogous to the R-START. An execute signal is generated by depression of the XEQ switch and is gated out of the module by the unit select enable signal from the CUE scanner. Whereas the R-START module produces only one 12-bit word, the C-START module generates four 12-bit words for each execute. Word transmission is controlled by the "C" and "D" word selection signals. The execute signal is used to gate the 40 data bits and the three least significant digits of the address out of the C-START module and into the appropriate J-Box.

Normally, module selection is on a first-come-first-served basis. However, priority logic inhibits the selection of C-START modules until all waiting R-START units have been serviced.

Unlike R-START modules, verification of a C-START is a function of the computer program and indicates to the operator, through the four function lights on the C-START panel, various combinations of lights with each defining a separate or distinct condition. The C-START verification codes are illustrated in Figure 7.

The SEAL, remove SEAL, unit select, and Q signals perform the same function as in the R-START.

K-START MODULE

The K-START module is a digital input device that supplies information to the computer from manually operated keyboard switches or automatically from a paper tape reader when selected by the operator. The K-START panel contains a pushbutton keyboard, six tape control switches, a tape input display, three status displays, and a bank of 24 AGC event displays. Figure 8 is a functional block diagram of a K-START module.

The data transmitted consists of four 12-bit words. The first word contains the 8-bit address of the K-START and a bit indicating whether the input is from key or tape. The second word contains the 5-bit data word, the stop and skip bits for tape input, and an odd parity bit, which indicates odd parity for the five data bits. The third and fourth words are all zeros. Table 1 shows the configurations of the 5-bit data words when using keyboard control. Table 2 shows the four-bit words as they are transmitted when using the tape input, and Table 3 shows the four 12-bit words that are transmitted when using the keyboard input.

FOR TRAINING PURPOSES ONLY

(-STAR) KEG BORND

6 TARE

CONTRA

TARE INPU

PISPLA

3 STATUS

EVENT

DISKR

TISPEM.



O LIT OUT

Figure 7. C-START Verification Indicator Codes

FOR TRAINING PURPOSES ONLY

410-0(105



C and D Sequentially Gate Words 1, 2, 3, &4 To J-Box

Figure 8. K-START Block Diagram

8 BITS ADDRESS -

13

	1		т	-	-
	я	n		ρ	
-	a	Ν	-	C	-

K-START Keyboard Word Format

Key Codes	Data Bits	Parity Bit (Odd)
0	10000	0
1	00001	0
2	00010	0
3	00011	1
4	00100	0
5	00101	1
6	00110	1
7	00111	0
8	01000	0
9	01001	1
Verb	10001	1
Noun	11111	0
+	11010	0
-	11011	1
Enter	11100	0
Clear	11110	1
Release	11001	0
Error Reset	10010	1

Table 2 K-START Tape Input Word Format

Data to CUE	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Word 1	Y	Y	Y	Y	Y	Y	Y	Y	0	0	0	1
Word 2	0	0	0	0	w	x	x	x	x	x	x	x
Word 3	0	0	0	0	0	0	0	0	0	0	0	0
Word 4	0	0	0	0	0	0	0	0	0	0	0	0
Y = Address X = Data W = Parity												

	Table 3	
Word	Format,	Key

Data to CUE	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	27	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Word 1	Y	Y	Y	Y	Y	Y	Y	Y	0	0	0	0
Word 2	0	0	0	0	w	0	0	x	x	x	x	X
Word 3	0	0	0	0	0	0	0	0	0	0	0	0
Word 4	0	0	0	0	0	0	0	0	0	0	0	0

TAPE INPUT

When the K-START module is in the Tape Input Mode, the tape reader delivers one 8-bit word to the K-START (Figure 9) and halts until it is commanded to read the next character word. Figure 10 shows the tape format and channel allocations. Channels 4 through 8 contain the five data bits used as the command. Channel 1 contains the parity punch for odd parity recognition of the five data bits. Channel 2 is the skip punch that, when punched, causes the tape reader to ignore that frame and to move to the next frame. Channel 3 contains the stop punch that, when punched, causes the tape motion to halt at that particular frame. A hole in the stop channel also causes the LOAD/INH switch to be set to the INH position, the TAPE/KEY switch to be set to the KEY position, and the indicator lamps (Figure 11) to display the 8-bit data word that is read from the tape. A hole in <u>both</u> the stop and skip channels causes the tape to travel to the next frame.

When the 8-bit word is delivered to the K-START from the paper tape reader, the word is then reassembled in the manner shown in Table 2. The resultant four 12-bit data words are then transmitted to the CUE.

KEY INPUT

In the key mode, the 5-bit character words are generated as a result of the depression of the keyboard switches on the K-START control panel. The 5-bit word configurations with the resultant parity bit are shown in Table 1. The transfer of the data words and the exchange of control signals between the K-START module and the CUE is the same as the tape input operation.



16



Figure 10. Tape Format

Depressing a given key automatically transmits the four 12-bit data words to the CUE. The K-START module encodes the key code output to eight bits, as in the case in the tape input mode. However, the skip and stop bits are zeros in the key mode of operation.

J-BOX (Figure 12)

The sixteen J-Boxes provide the interface between the START modules and CUE. Each J-Box supplies power to the two groups of eight modules associated with it. Each J-Box generates the 16 unit select signals (Figure 13), which are transmitted to the START modules associated with the J-Box by ANDing eight unit select and two group select signals. Also, each J-Box has a BCD switch that generates the three bits of the J-Box address, which is inserted in the address portion of the 12-bit data transfer from the START to the CUE. The J-Box also decodes a group "0" or "1" bit to be inserted. The CUE will generate the patch "0" or "1" bit.

COMMUNICATIONS UNIT EXECUTOR

The CUE serves as a central addressing and control unit between the START modules and the 160G computer. This unit controls the two-way communications path over which pass the START module data and/or test commands and the computer responses.

a. <u>Scanning</u> - A scanning counter, located within the unit, sequentially interrogates all 256 START addresses. If the presence of a START execute signal is sensed, the scanning ceases and an interrupt is sent to the computer. CUE causes the contents of the START module, as well as its address, to be gated to the computer.



Figure 11. K-START Character Bit

410-0(105)



Figure 12. J-Box



Figure 13. J-Box Block Diagram

20

FOR TRAINING PURPOSES ONLY

410-0(105)

- <u>Command Encoding</u> CUE encodes commands for introduction to the computer, such as START module data and address bits and status response codes. It determines which interrupt signal is to be generated and transmits it to the computer. It decodes the computer instructions (external function codes) into proper timing and operating sequences.
- c. When in the maintenance mode of operation the CUE allows the computer to communicate with the Command Monitor Unit (CMU).

Figure 14 is a block diagram of the CUE. This unit is composed of timing, scanner, unit and group translators, a control section, decode logic, and transmit/receive electronics. A self-contained power supply provides the dc voltage necessary to the logic operation.

The CUE scanner, which is used to generate sequential START module addressing, consists of a three-stage, gray code counter followed by an eight-stage binary counter. The three-stage, gray code counter receives its inputs from a 100 kc oscillator. The gray code counter counts down the clock pulses and in turn drives the binary counter. The output of the binary counter is utilized to develop the addresses of the various START modules in the data entry system. The most significant bit (2⁷) of the scanner address is used to define patch 1 or patch 0 of the CUE. Bits 2³ through 2⁶ are used to decode the group selection and bits 2⁹ through 2² decode the unit selection. As the scanner counts, it sequentially interrogates each START module looking for an execute signal.

COMPUTER GENERATED FUNCTION CODES

General

The CUE interprets and reacts to the following External Function (EF) codes from the computer. All EF codes are in octal notation, and the CUE is selected by a code of the form 37 XY. The 37 determines that the computer selected CUE. XY defines specific functions to be performed.

External Function Codes

The following are external function codes:

a. <u>3700 Status Request</u> - On request of this instruction, CUE transmits a status response code to the computer. Table 4 contains the status response codes for the data entry equipment.



Figure 14. CUE Functional Block Diagram

- <u>3701 SEAL</u> A response is not returned to the computer if the remote device takes too much time in processing the data, the computer issues a SEAL command. This command isolates or inhibits the use of that START module.
- c. <u>3702 Select Standby Mode</u> The standby mode is the idling mode of operation; however, CUE will not generate interrupts.
- d. <u>3703 Select Manual Mode</u> The manual mode is the normal working mode of operation for the CUE. The CUE is capable of transmitting data and/or commands in this mode of operation.
- e. <u>3704 Remove SEAL</u> The remove SEAL instruction is used in two ways: to remove the SEAL condition in a particular START module or to gate a confirming response to the START module.
- f. <u>3705 Compare</u> The logic of the CUE contains compare circuitry by which the address is checked for errors occuring during transmission between the CUE and the computer. It is used only if the original test data is of a critical nature.
 - <u>3706 Input Request</u> The computer selects the CUE for input by using the input instruction. This enables one or four 12-bit data words to be transmitted to the computer.
- h. <u>3707 Select Maintenance Mode</u> This mode of operation allows the computer to transmit two 12-bit words of data via the CUE to the CMU for display and operator evaluation.
- i. <u>3710 Select Automatic Mode</u> The selection of the automatic mode of operation permits the computer to select a particular START unit and to select which particular data word it wishes to interrogate.
- j. <u>3711 Read Scanner Address</u> The computer under program control can at any time issue a read scanner address instruction. Upon receipt of this command, the CUE automatically transmits the 8-bit address currently generated by the address scanner logic to the computer.

The 160G computer communicates with the CUE via external function codes and control signals (see Figure 15). The CUE will receive, decode, and act upon these external function codes. If the computer requests a status reply, the CUE will transfer a status word to the computer, which indicates a specific condition as described in the preceding listing.

Jamo

Table 4

Status Response Codes

Bit Position	Description
2 ⁰	Terminal Fault
2 ¹	Manual Mode
2 ²	Address Compares
2 ³	CMU Filled
2 ⁴	Data Compares
2 ⁵	Standby Mode
2 ⁶	Spare
27	Spare
2 ⁸	Spare
29	Interrupt 30
2 ¹⁰	Interrupt 40
2 ¹¹	CUE Generated Interrupt

COMMAND MONITOR UNIT

The CMU displays malfunction information pertaining to the DTCS, the computer peripheral equipment, and the data entry equipment. The data, which represents the nature of the malfunction, is generated by the ACE-S/C uplink computer and transferred to the CMU via the CUE for display (see Figure 16). The status information depicted by the CMU provides a means for operating personnel in the computer room to correlate digital test command malfunctions with the data entry equipment in the ACE-S/C control room, and also to take the appropriate action pertaining to computer peripheral equipment malfunctions. Only the equipment malfunctions that can be detected and handled by the computer will be displayed on the CMU. In the event of a data entry malfunction (CUE and START), the CUE scanner address will be displayed indicating the point during the scanning process the malfunction occurred.

The CMU is located in the computer complex console (Unit 154) in the computer room.

The command monitor unit has the capability to display the status of 16 computer peripheral equipments (see Figure 17). Each peripheral has an assigned indicator and will be lighted by data from the computer room upon the detection of a malfunction in that area. The indicator will only depict that a malfunction has occurred and not





410-0(105)





26

410-0(105)

410-0(105)



Figure 17. CMU Indicators

the nature of the malfunction. The types of peripheral equipment that can be monitored and displayed are listed as follows:

Uplink Peripherals

- a. 1 typewriter.
- b. 3 data transmitter and verification converters.
- c. 2 magnetic tape transports.
- d. 1 card reader.

Downlink Peripherals

- a. 1 typewriter.
- b. 1 data transmitter and verification converter.
- c. 2 magnetic tape transports.
- d. 1 line printer.
- e. 2 X-Y plotters.
- f. 1 card punch.
- g. 1 card reader.

DATA PROCESSING

OBJECTIVES

To familiarize the student with:

- a. The overall operation of the 160G computing system.
- b. Computer system programing.
- c. Operation of the 169G-3 memory unit.
- d. Operation of the 171G-3 input/output unit and associated peripheral devices.

PART I - COMPUTER FUNCTIONAL DESCRIPTION

The Acceptance Checkout Equipment - Spacecraft (ACE-S/C) ground station contains a data processing system that consists of two general-purpose Control Data Corporation 160G digital computers and associated peripheral and data transmission equipment. The two 160G computers are identical and are identified by their assigned function within the overall ACE-S/C system. Basically, the ACE-S/C system is divided into two functional loops: (1) the uplink or command loop and (2) the downlink or display loop. The uplink computer processes commands received from the data entry equipment, i.e., R-START, C-START, and K-START modules, which interface with the computer through the CUE. After the commands are processed, the uplink computer transmits them to the receiving equipment in the test bay via a data transmission system. The spacecraft's reactions to the commands are monitored by sensors and the resulting signals are commutated on a PCM telemetry carrier and returned to the decommutation equipment located in the computer room. The downlink data is then presented to the second 160G computer for tolerance checks, conversion to engineering units, and distribution to the downlink data transmission system for routing to the display equipment. This computer can also cause the data to be recorded for post-test analysis.

To fully understand the functional operation of the <u>160G</u> computing system, it is necessary to first understand basic computer concepts. <u>A general-purpose digital computer</u> consists of four major sections: (<u>1</u>) memory, (<u>2</u>) arithmetic, (<u>3</u>) control, and (<u>4</u>) input/ <u>output</u>. Any functional part of a general-purpose digital computer can be included in one of these major sections. Figure 1 is a block diagram of a general-purpose digital

1


Figure 1. Digital Computer Block Diagram

N

410-0 (106)

410-0(106)

128

computer showing these major sections. The following paragraphs present a functional description of each major section and its relationship to the other sections.

MEMORY

The memory section of a computer is composed of an array of permanent or semipermanent storage devices as its primary element. In modern high-speed computers, this device has generally been the ferrite core. The ferrite core has the capability of retaining information in one of two magnetic states, making it capable of storing one bit (binary digit) of information (see Figure 2A). The magnetic properties of the core allow it to maintain a magnetic state without the application of power (see Figure 2C) and enable this state to be changed upon the application of a magnetic field of the proper intensity and direction. The core can be switched from one magnetic state to the other very rapidly, approximately 1 to 2 microseconds. Since the cores are small is size (30 mils or so in outside diameter), a memory containing 100,000 cores or more can be built into a package not much larger than a textbook.

A common configuration for a core memory has 4096 cores mounted in a 64 by 64 matrix on each of a number of planes; the number of planes will be equal to the number of bits (length) of the word to be stored. Each plane stores one bit of the data word in any one of 4096 locations, as determined by the address associated with that data word. A memory composed of 13 planes of 4096 cores each then could store 4096 13-bit data words. The complete memory for a computer would be made up of one or more of these banks of memory.

Each core in a plane is threaded by four wires: a horizontal drive line, a vertical drive line, a sense line, and an inhibit line. For each plane of the memory described there are 64 horizontal drive lines, each threading 64 cores; 64 vertical drive lines, each threading 64 cores; a single sense line, threading all 4096 cores; and an inhibit line threading all 4096 cores. To complete the wiring of the memory, the corresponding horizontal drive lines of each plane are connected together in series electrically, and the corresponding vertical drive lines of each plane are connected together in series electric in series.

A given memory address, specifying a single core in each of the 13 planes, is selected by translation of the output of the address S register to select one horizontal drive line and one vertical drive line. Only one core in each plane is threaded by the selected horizontal and vertical drive lines and is, therefore, the core selected by that memory

1/2 CURRENT



Figure 2. Memory Section of a Computer

(C)

FOR TRAINING PURPOSES ONLY

(A)

4

address. When information is to be stored in memory or read out of memory, a half current (a current having only approximately one-half the amplitude required to switch a core) is applied to the selected drive lines.

All the cores that are threaded by only one of these wires will be disturbed by a current that is not sufficiently large to switch the cores, while the single core on each plane that is threaded by both of these wires will be disturbed by a current that is of sufficient amplitude to switch the magnetic state of the core.

During the readout of information from the memory, the magnetic state of each of the selected cores is switched to the zero state. If the selected core was initially in the one state, a voltage will be induced in the sense line when the core is switched to the zero state. If the selected core was initially in the zero state, it remains in that state and virtually no voltage is induced in the sense line. Therefore, by examining the sense line at an appropriate time after the drive lines are energized, it can be determined whether the selected core contains a zero or a one. The voltage pulses on the sense lines are amplified, shaped into standard logic pulses, and gated into the Z (data) register from whence they are transmitted to the other sections of the computer as needed. This method of reading the information from a core memory is known as destructive readout.

In a memory with destructive readout, the circuitry associated with the memory automatically takes the word from the Z register after readout and restores it in the selected cores in memory during the write portion of the memory reference. During the write operation, the direction of current through the selected horizontal and vertical drive lines is in a direction opposite to that during the read operation. Thus the selected core on each plane will be set to a one state unless an inhibit current equal to a half current and in a direction opposite to that of the write current is applied to the inhibit winding of the plane. The inhibit current is controlled by the contents of the Z register, and, therefore, a zero is written into memory for those data bits of Z that are a zero.

For a computer operation which is to write new information into memory, the memory again goes through both a read and a write cycle. During the read cycle, however, the transfer of information from the sense amplifiers to the Z register is inhibited. Instead, the Z register is set by a transfer of data from the computer or an input/output chassis to the Z register. During the write portion of the memory reference, then, the new information is written into the selected memory location.

410-0(106)

FOR TRAINING PURPOSES ONLY

The selection of the horizontal and vertical drive lines is controlled by the address associated with the word. Six address bits are necessary to select one of the 64 horizontal drive lines, and six address bits are necessary to select of the 64 vertical drive lines. The time from the initiation of a memory reference cycle until the information is in the Z register is known as the access time of the memory; the time required for the complete memory reference is known as the memory cycle time.

A typical computer memory is constructed of a number of these 4096-word banks of memory. The address is then composed of more than 12 bits. The upper bits are decoded to determine the bank of memory to be referenced, while the lower 12 bits specify the location in the selected memory bank.

In summary, the memory section requires only three things from the control section of the computer. These are:

- a. A transfer into the memory address register of the number indicating which word in memory is to be selected.
- b. An indication of the direction of the transfer of the word, either into or out of the memory.
- c. A signal to start the memory cycle, which in turn will energize the appropriate selection and drive signals to perform the transfer.

ARITHMETIC

The arithmetic section contains the circuitry necessary to perform mathematical and logical calculations on information. For this purpose, it has several registers to hold numbers and wired-in logic to allow the mathematical and logical manipulations of the numbers. The operation of any digital circuitry follows a pre-arranged set of logical steps. The logical operations of the arithmetic section of the computer are simple combinations of these logical steps, while the arithmetic operations are more complicated combinations of these basic steps. The shifting of an operand left or right in a register is one of the simpler applications of these basic steps.

The arithmetic section obtains the timing signals necessary to perform its various functions from the control section and, also, obtains the information on which it performs its various functions from the memory section. The results of its functional operations are generally transferred back to the memory section for storage in core memory.

6

410-0(106)

The heart of most computers is the adder. Arithmetic, as previously mentioned, is one of the more difficult operations to perform with the basic logical steps available in a digital computer. The adder, which performs an addition (or, by an inversion of one operand, a subtraction) in a near minimum time and with a near minimum of active components, is an optimum combination of these basic logical functions. It so happens that if certain control signals are not activated as two operands flow through the adder, various logical combinations of the two operands result; various logical instructions come essentially free, if the adder is in the arithmetic section. Multiply, divide, and shift instructions also make use of this adder portion of the arithmetic section.

CONTROL

The words stored in the memory of a computer can be classified as either instruction words or data words. The program of a computer consists of one or more series of instruction words; the control section of the computer reads these instruction words one by one and executes the instruction specified. If by mistake, a data word is read by the control section instead of an instruction word, the computer has no way of knowing that it is not an instruction word; the control interprets the bits of the word as an instruction and executes whatever instruction is specified. (This is why the operation code 00 is interpreted as a stop instruction in many computers; if the program jumps by mistake to a section of memory which has neither data nor instructions in it, the program will stop.)

The control section has the primary function of providing timing signals for the various internal information transfers. It provides these timing signals by translating or decoding the numerical computer instruction which it receives from the memory core storage. The instruction (word or words) is held in an instruction register, frequently referred to as the F register, while the translation and execution is taking place. The control section has its own register to determine the location in memory where each instruction is to be found. This register is called the program address register, abbreviated as P register. Since the computer instructions are found in sequential memory locations, the P register is incremented each time an instruction is executed. In some computers the incrementing is done by using the adder, and, in others, special circuitry is provided for this purpose.

The control section requires a signal from the computer operator to start; once this is done, it relies on instruction information from the core memory to determine which of the control and timing signals it should generate. These signals regulate the flow of information at all times within the computer and also control the initiation of information transfer external to the computer.

INPUT/OUTPUT

The Input/Output (I/O) section provides the temporary storage facility for information being transferred into or out of the computer. Incoming information is retained by the I/O section until that information has been stored in core memory. Outgoing information is retained by the I/O section until the receiving device is able to accept it. The timing for information transfers is provided from within the I/O section, but it is initiated by the control section. A primary function of the I/O section is one of compensating for the vastly different information flow rates found in the computer and external peripheral devices. It enables a computer, operating at transfer rates of several hundred thousand words per second, to communicate with peripheral devices operating as slowly as several words per second.

COMPUTER PROGRAMING

At the present state of the art, the term "Electronic Brain" for a general-purpose digital computer is a complete misnomer. Research is progressing on how to build a computer that will "think," but computers currently available are incapable of doing anything which could be called, by any stretch of the imagination, thinking. They merely work out what has already been though of beforehand by the designer and supplied to them in the form of instructions.

The current digital computer, therefore, is capable of doing only those operations which the programer tells it to do. It is safe to say that any problem whose solution can be described, step by step, before the solution is begun, can be programed for a digital computer. It immediately follows that the best person to program a mathematical problem is a mathematician, the best person to program an engineering problem is an engineer, and the best person to program a medical problem is a doctor (unless the engineer or doctor can reduce his problem to one of solving equations, in which case a mathematician is better qualified to program the problem).

Three significant advantages of a digital computer are:

a. The computer is orders of magnitude faster than a human being in solving a problem.

b. A computer does not make errors.

These advantages make it sound as if a digital computer is nothing but a super adding machine; it is this, but much more. A third advantage makes the digital computer considerably more than a super adding machine:

c. The ability to make (preprogramed) decisions.

The programing of a digital computer is composed of the following three basic steps:

- (1) Analyzing the problem.
- (2) Reducing the problem to separate simplified portions for ease of handling.
- (3) Writing instructions that will solve each portion and combining these.

An obvious means of translating these steps into the instructions which the computer uses is for the programer to program the problem directly in the machine's language. Machine-language coding, also known as absolute coding, can give a program of maximum efficiency - the resulting program will run in a minimum length of time. Unfortunately, a program written in machine language takes an unreasonable amount of computer time to check out; fewer and fewer programs are being written in machine language.

One interesting attempt to simplify the job of programing is through the use of compilers. A compiler is a computer program that allows the programer to write his program in a series of steps which are easily understood by him, but which have little or no relation to the machine-language instructions. The compiler then translates the program so written into machine instructions. Many of these compiler languages are so independent of machine language that they can be used on a variety of computers. (A separate computer program has to be written for each computer.) An example of a compiler is FORTRAN (a contraction of FORmula TRANslation), which uses a formulatype language to program the problem.

There are, for example, FORTRAN compilers written for the Control Data 1604 and the IBM 7090. The same problem, written in FORTRAN, can be computed to be run on either computer by using the appropriate compiler. A major advantage of compilers is this independence of the specific computer; a major disadvantage is that the programs written in compiler language will not run at the maximum speed because of the divorcement of the compiler language from the computer language. A compilergenerated program, assuming a well-written compiler and a computer well suited to the compiler language, will run 10 to 15 percent slower than if the program had been

FOR TRAINING PURPOSES ONLY

9

written in machine language. FORTRAN, ALGOL, and COBOL are examples of well-known compilers.

Between the two extremes of machine-language coding and compilers come assemblers. An assembler is like a compiler in that it puts a machine program between the writing of the program and the generation of the machine-language instructions. Strictly speaking, an assembler contains only pseudo-instructions which correspond, one to one, with the machine-language instructions. Actually, most assemblers have some pseudo-instructions which go beyond the instruction list of the computer and, hence, are simple compilers. Writing in assembly language is essentially writing in machine language with the corresponding advantage that programs so written will run at the maximum possible speed. The advantage of using an assembler is that it relieves the the programer of a considerable amount of drudgery, helps in debugging the program, and saves machine time. Assemblers are obviously not independent of the machine they are to be run on. Examples are OSAS, written for the CDC 160A, and GASS, written for the CDC 160G.

160G COMPUTING SYSTEM

The 160G computer module and its associated maintenance and operator console make up the basic 160G computer, but it can be expanded into a much larger system with the addition of 169G memory and 171G input/output modules. The following paragraphs present a general description of the 160G compute, 169G memory, and 171G input/ output modules. Figure 3 depicts a block diagram of the 160G compute module.

160G COMPUTE MODULE

Memory Section

The memory section of the 160G computer module provides a means of storing program instructions, data words, and various constants utilized in the spacecraft checkout. The heart of the 160G computer module (see Figure 3) memory section is the 8192, 14-bit magnetic core stack. The 160G computer utilizes a basic 13-bit instruction with the 14th bit being a parity bit. The memory restoration register (Z), a 14-bit register, temporarily holds data being transferred to and from the magnetic core memory. The Z register has associated with it, parity circuitry which generates a parity bit for each stored word during a write operation and then checks this parity bit when a read operation is performed.



Figure 3. 160G Compute Module Block Diagram

410-0(106)

11

410-0(106)

FOR TRAINING PURPOSES ONLY

A memory plane in the 160G compute module consists of four quadrants, each quadrant contains 4096 (64 by 64) ferrite cores. Each memory stack is composed of seven planes forming an 8192 word bank of memory. In the 160G computer system, the banks are numbered 0, 2, 4, 6, 10, etc., with bank 0 being located in the compute module. The first 4096 words of the bank are obtained by selection of a bit from each of two quadrants of the seven plane stack; the second 4096 words utilize the other two quadrants of the planes. The S' register, a 13-bit register, contains the address of the memory location currently being referenced in a specific bank. The least significant 12 bits specify the address in the pair of quadrants, while the most significant bit specifies the pair of quadrants.

Registers

Internal Memory Address Register (S')

When a memory reference is made to internal memory, the current memory address in the S register is placed in the S' register. The S' register provides outputs that condition the address selection logic to reference the correct address.

Memory Restoration Register (Z)

The 14-bit Z register operates with core memory. All data entering or leaving core memory is stored temporarily in the Z register. Data to be written into core memory is placed in the Z register and then written into the correct location. Data read from core memory is placed in the Z register. After this data has been transferred to another register, the data is gated from Z back into the same memory location. Thus, Z permits a memory reference to be nondestructive. The 14th bit of the Z register is a parity bit.

Memory Operation

Each 160G compute module contains a memory section of 8192 storage locations, which is the internal memory. Memory sections located in 169G memory modules are external memories. The physical arrangement of the core storage and method of readout, write-in, and address selection of the internal memory is practically identical with an external memory. The major differences lie in the access channels. The 160G memory section cannot be accessed by other 160G compute of 171G input/output modules; whereas, the 169G may be accessed by any combination of 160G compute or 171G input/output modules that total nine or less. Therefore, the 160G memory section does not need a scanning device.

FOR TRAINING PURPOSES ONLY

12

A maximum of 14 bits can be stored in a given memory location. Thirteen bits comprise the data or instruction word, and the 14th bit is a parity bit. The parity bit allows a malfunction of the memory to be detected.

The storage function, within a memory section, is controlled by a delay line for timing the Z and S' registers to effect directly a memory reference to a specific location. Control of readout and write-in within the memory section is accomplished by pulsing the delay line once each time a memory reference is made.

The control section of the 160G places a memory request, a select code, and a read, write, or partial-write command on the lines to all accessible memory modules including the internal memory. When the internal memory senses its select code and memory request, the following events occur:

- a. Transfer of the address from S to S'.
- b. Set the busy flip-flop to lock out other memory references for the remainder of the cycle.
- c. Set the gate, read drive, and discharge drive flip-flops to enable read currents to flow through the selected X and Y drive lines of the memory stack.
- d. Start a pulse down the delay line to time each function in the memory reference cycle.
- e. Clear the Z register in preparation for a transfer of 1's.

A mode command places the memory section in the write, read, or partial-write mode of operation.

In the write mode, the control section places data for a specific address into the X register. When the write gate is enabled, the data is transferred into the Z register of the memory section and stored in the core memory during the write portion of the memory reference.

In the read mode, the data from the memory address selected by the S' register appears on the outputs of the sense amplifiers during the read portion of the memory reference. When the read transfer occurs, the data is transferred into the Z register of the memory section. The output of the memory section Z register is then gated to the computer. The data word read from memory during the read portion of the memory reference is restored in memory during the write portion of the memory reference cycle. In the partial-write mode, both the read and write functions are employed in

one memory cycle. The upper seven bits of the 13-bit word are processed in the read mode, and the lower six bits plus parity are processed in the write mode. The result is that the lower six bits of the word are changed in the partial-write mode while the upper seven bits are not affected.

Address Selection

In order to accommodate a 14-bit word in a seven plane memory stack, two bits must be stored on each plane. This is done by dividing a plane into two banks, each consisting of one odd quadrant and one even quadrant. Bits 00, 02, through 12 are stored in the even quadrants of seven successive planes in a bank, and bits 01, 03 through 13 are stored in the odd quadrant of the same seven planes in the same bank. Storage across the seven planes of the other bank uses the remaining odd and even quadrant of each plane. Since a quadrant contains a 64 by 64 matrix of cores and two quadrants are used to store a word, each bank effectively accommodates 14-bit words in 4096 storage locations.

Since a memory stack contains two banks, $4096 \times 2 = 8192$, storage locations are available in a memory stack. For addressing purposes, the X drive lines run through the even quadrants of bank 00, continue through all the planes on the south side through the transposition plane and down through all the planes on the north side, and return to termination through the odd quadrant of bank 00, Figure 4. Therefore, 64 X drive lines thread all cores in all four quadrants of all seven planes in a memory stack. In the Y axis, 64 Y drive lines run through both quadrants of all seven planes and terminate. A second set of 64 Y drive lines thread through the odd and even quadrants of the seven planes of the 01 bank. Therefore, both banks are energized along the X axis and only one bank is energized along the Y axis so the Y drive lines serve to select the 00 or 01 bank. Addressing consequently energizes one of 64 lines in the X axis and one of 128 lines in the Y axis. The energized X line crosses the energized Y line once in the odd quadrant and once in the even quadrant of the seven planes of a selected bank. The drive lines are energized by turning on line-drive transformers, Figure 5.

Memory Arrangement

The maximum number of bits that can be stored in a given memory location is 14 bits, 13 bits contain information and 1 bit is used for parity checking. Information access time for the memory and its associated control and sensing circuits is approximately 0.5 microsecond, and the time for a complete memory reference cycle is 1.35 microseconds. Figure 4 shows the quadrants, planes, and X and Y drive lines arranged to





Figure 4. Memory Arrangement

FOR TRAINING PURPOSES ONLY

15



410-0(106)



410-0(106)

form a memory stack. Figure 5 shows a functional brief of memory cores with the drive lines, inhibit line, and sense line threaded through a set of four cores. All cores are wired in the same manner. The following paragraphs describe the circuits that are directly connected to these drive lines and effect storage, location, and removal of bits stored in the memory stack.

Core Storage

The memory operates in the coincident current mode, using currents of one direction to read, and the opposite direction to write.

Each core is threaded by four wires (see Figure 4), X and Y half-current drive lines, an inhibit line, and a sense line. When information is written into a core, the core is switched to the 1 state by two coincident currents on the X and T drive lines. Similarly, when information is read from a core, it is switched to the 0 state by two coincident currents of the opposite polarity. The inhibit line carries a current parallel to one of the drive lines, but in a direction opposite to the half-write current. If the inhibit current is flowing during a write phase, it cancels the effect of one of the half currents and, thereby, prevents any core through which the inhibit current passes from being switched from a 0 to 1 state. If the drive currents were not inhibited during the write phase, all cores would be switched to a 1 state. If the write coincident X and Y currents act to switch a core from 0 to 1, and if that core is already a 1, it remains a 1. Conversely, if the read coincident X and Y drive currents act to switch a core from 1 to 0, and if that core is already a 0, it remains a 0. The sense line is connected to a differential sense amplifier. When a core switches state in either direction, the sense amplifier produces an output; however, this output is sampled only during the memory read phase.

The memory core material has an approximately rectangular hysteresis loop. The high residual magnetization of the core enables it to function as a memory element. The magnetic properties of a core are represented in Figure 6 by its hysteresis loop in which magnetic flux density B is plotted as a function of field intensity H. If sufficient current flow to cause a field intensity of $+H_m$ is applied to the core, the flux density increases to saturation $+B_s$. When current is removed, the flux drops to residual value $+B_r$ and remains there. Sufficient current flow in the opposite direction to cause a field intensity of $-H_m$ reverses the flux density to $-B_s$. When current is removed, the flux density drops to the residual value $-B_r$.



Figure 6. Typical Hysteresis Loop

The basic memory cycle consists of half-current pulses capable of producing a field intensity of $H_m/2$. A half-current pulse is insufficient to switch a core; however, the coincidence of two half currents produces a net field intensity that is sufficient to switch the core.

Inhibit Circuits

Whenever an address is selected and the read drive is on, coincident currents are present on each core of that address. These currents attempt to switch all cores. Cores magnetized in the direction resulting from a previous 1 storage are switched, and cores magnetized in the direction resulting from a previous 0 are not switched. Inhibit currents are not used during read, those cores that switch are allowed to switch. If a core is switched, a small voltage is induced in the sense line threaded through that core and a pulse appears along the sense line (see Figure 4). The readout process switches every core containing a 1 to a 0; this is a destructive readout and the memory must be restored. The output of the sense line is amplified and gated into the memory register as 1's. During the write drive the information is written back into memory; at the end of the memory reference cycle, the contents of the particular selected address is restored.

Whenever an address is selected and the write drive is on, two coincident currents are present on each storage bit of that address. Unless the effect of one of these drive currents is cancelled out, every core in that address is switched to a 1. Because of the effect of the inhibit lines during the write phase of the memory cycle, only those bits which were 1's are switched back to 1's. In order to prevent coreswitching in cores that are not to store a 1, a current flowing in opposition to one of the drive currents is generated to cancel the effect of this drive current, thereby inhibiting a core from being switched. This function is performed by the inhibit circuits consisting of inhibit generators and inhibit lines.

Sense Circuits

Each sense circuit consists of the sense line threaded through all cores of a quadrant of a plane, and the sense amplifier which is tied to the two ends of the sense line. Whenever a core is switched, a pulse of about 35 millivolts appears on the sense line. This pulse may be either positive-going or negative-going depending on the direction the core was switched. The sense amplifier consists of a differential voltage amplifier and a discriminator. Regardless of the pulse polarity at the sense amplifier input, the output is always a positive-going pulse.

Parity Circuit

Bit 13 in each memory location is used to provide a comparison bit for parity checking. Bit 13 is generated by the parity logic and placed into the Z register before a word is written into memory.

The number of 1's contained in the Z register determines whether a parity bit should be generated by the parity logic as a 1 or 0. The parity check on the 160G memory operates on an odd-parity basis; that is, the word which is read out of or written into memory must contain an odd number of 1's. If the number of 1's in the operand is odd, a parity bit 0 is generated. If the number of 1's in the operand is even, a parity bit 1 is generated.

Memory Timing

The select code, mode command, address, data word, and memory request to a specific memory bank are originated by the computer to start a memory reference cycle. After a memory bank is selected, address transferred, and mode command received, a timing pulse starts down the delay line in the memory section. At this time, temporary control of the read, write, or partial-write reference is held by the memory section. The computer main timing control is inhibited until released by the memory section. At the end of the memory cycle, the memory section returns to its quiescent state until receipt of another memory request. The computer cannot make more than one memory reference at a time on one memory bank. However, several different memory banks may be in operation simultaneously.

Arithmetic Section

The arithmetic section (see Figure 3) contains an exchange register (X) which is used in most operations where data is transferred to or from the Z register. It is also used as an exchange path for many other transfers within the compute module. The arithmetic register (A) is used for nearly all arithmetic, logical, and shifting operations. In addition to the A register, the auxiliary arithmetic register (Q) is used to provide an extension to the A register. The two are connected to form a 26-bit AQ register in multiply, divide, and certain shifting operations. The auxiliary arithmetic register (A') is the receiver of all adder computations, and a secondary auxiliary arithmetic register (Q') provides a 13-bit second-rank Q in shifting a transfer operation.

410-0(106)

The actual arithmetic element is the adder. The adder has inputs from the A, Q, X, Q', P, and buffer entrance (BER) registers, and also has a standard +1 and +2 input. The input from the X register can be either the contents of X or the complement of the contents. If the positive contents of X are energized into one side of the adder and the contents of A into the other side, the result (which goes to A') will be (X) + (A) where the parththeses are read as "the contents of X" and "the contents of A." If the complemented contents of X are energized into one side of the adder and the contents of X are energized into one side of the adder and the contents of the contents of X are energized into one side of the adder and the contents of A into the other, the result will be (A) - (X). The +1 input is used in replace-add-one instructions and in advancing the program control register (the P register). The constant +2 is added to (P) in some instructions.

Control Section

The first functional element of the control section (see Figure 3) to be considered is the P register. This 13-bit register contains the address of the instruction being executed. The P register is updated through the adder; the contents of the P register are gated into one adder input and ± 1 , ± 2 , or input from the X register (for relative addressing) is used as the other input. The memory address register (S) holds the address of every memory reference. It has inputs from A', P, and X and outputs to P, S', or the external S' register in the 169G memory modules.

The function register (F) is a 13-bit register that holds 13 bits of the instructions being executed. It receives its inputs from the Z register and procedures its outputs to the translator, which performs the instruction translation and sends the proper signals to control the required operations. The F' register, an extension of F, is a 5-bit register and is used with the lower 5 bits of F as a decreasing counter in multiply, divide, and some shifting operations.

The main timing control issues commands to all sections of the compute module and governs all functions performed therein. One input to the main timing control is from the interrupt logic.

Certain internal and external conditions arise that make it necessary for the main program to be notified of their presence. An interrupt is the program signal that transfers control to some fixed location in memory without losing the information needed to return to the main program. 410-0(106)

FOR TRAINING PURPOSES ONLY

A signal, on any of the interrupt lines into the interrupt logic, results in a signal to the control logic that interrupts the routine presently being performed except under conditions where the interrupt function has been locked out. Upon interruption of the present routine, program control is transferred to the routine which services the active interrupt. Regardless of the type of interrupt, the same general procedure is followed. The compute module stores the address of the next instruction to be executed in the routine that has been interrupted and reads the instruction contained in the special storage location associated with the active interrupt. At the completion of the interrupt routine, the next instruction in the interrupted routine is read from memory and program control is returned to the interrupted routine.

Each compute module (Command and Display) has an associated control console. The console, consisting of a display panel and a switch panel, contains the controls and indicators necessary for maintenance and operation of the computer. The display panel contains three status indicator displays and four 13-bit register displays. The switch panel is a row of pushbuttons that are used to exercise manual control over the computer.

Input/Output Section

The input/output section utilizes two different types of information transfer: buffered transfer and nonbuffered transfer. A nonbuffered input/output transfer is one in which the execution of program instructions is halted while information is transferred between the computer memory and some external device. In this type of input/output operation, all the computer high-speed calculating and logic capabilities cease for as long as it takes to complete the information transfer. This method of transfer is efficient in transferring a few words of data at a time (it is most efficient when the transfer is performed at the rate of one word at a time). The nonbuffered input/output transfer uses the X register as an input/output register and uses the compute module main timing control to control the transfer.

A buffered input/output transfer interrupts the execution of computer instructions if the transfer is being made into or out of the same (8192 word) bank of memory in which the program is being run. If the same bank of memory is being utilized, a word transferred out of the computer memory takes one memory cycle from the computer program; on input, the time taken from the program is between one and two memory cycles. If difference memory banks are being used, no cycles are taken from the computer program on output, but one cycle is taken on input. (Note that these subtractions

FOR TRAINING PURPOSES ONLY

22

12512

BER

C.K. 4-12 BITS)

from the computer program are only for the buffered channel of the compute module for the other buffered channels, the times are one and one if the program and input/ output channel are using the same memory module and zero and zero if they are not.)

To perform a buffered transfer of data, the input/output channel must be informed of two things: 1/R- 8BITC w I

- The complete address of the first data word. a.
- The complete address of the last data word. b.

The numbers identifying these two quantities are placed into two special registers prior to starting the information transfer. The first register is called the buffer entrance register (BER); it holds the memory address of the work currently being transferred.

Each time another word is transferred, the number in this register is automatically incremented by one count. The second register is called the buffer exit register (BXR); the number it holds is the memory address of the last word to be transferred plus one. A buffer operation has been completed when the number in the BER has been incremented to a value that makes it equal to the number in the BXR. A special comparator in the I/O section senses for this condition of equality and generates a buffer termination signal when the condition appears.

In any buffer operation, the data being transferred is handled by a register called the BEP buffer data register (BFR). This register holds the data until the external device can BUFFER PATA recognize it and set itself up to process it (for an output transfer) or until the compute REGISTER module can be accessed (for an input transfer).

128×64

169G MEMORY MODULE

Each 169G external memory module contains 8192 (8k) words. The total memory cycle time of the 169G is the same as that of the internal memory (1.36 microseconds). Up to 15 external memory modules may be controlled by one compute module giving a maximum of 131,072 memory locations per compute module. Each memory module contains nine access channels, which may service either compute or input/output modules.

Figure 7 illustrates a block diagram of the 169G memory module. It contains circuitry for core storage address and bank selection, scanner, read-write, and parity. The



24

FOR TRAINING PURPOSES ONLY

410-0(106)

operation of these sections is explained in the following paragraphs. The core stack used in the 169G is the same as that used in the compute module. Address selection is accomplished by translation of the output of the address selection register (S') to select one X and one Y drive line of the core memory. This register receives its inputs from either the S register in the compute module or the buffer entrance register in the I/O module. The 13-bit address is divided into an upper 7 bits, which select one of 128 Y drive lines through the core stack and a lower 6 bits, which select one of 64 X drive lines through the stack. Since the X drive line threads all four quadrants in a plane, and the Y drive line selects two of the four quadrants in a plane, two cores are selected per plane. Thus, two data bits are stored per plane in the memory.

The memory module also contains a 4-bit bank selection circuit to differentiate each module from the 14 other modules and the internal memory that can be selected by the computer. The compute or I/O module transmits a 4-bit number to select one of the 15 external memory modules and this number, together with the 13-bit address, completely specifies any one of the maximum of 131,072 memory locations in the system.

A scanner sequentially examines each of the access channels to determine which channel has requested a memory reference. When a request is present, the scanner stops on that channel to process the request. Toward the end of the ensuing memory cycle, the scanner restarts from the point at which it stopped, thereby examining the next channel in sequence upon starting. The operation of the scanner is of the sequential rather than the return-to-start type; this prevents one access channel from hopping the scan.

When the scanner recognizes a request, it sends a signal to the memory cycle control, which starts the requested memory cycle. The memory cycle gates the address selection and read-write circuitry and then issues a resume signal to the computer or I/O module that requested the reference.

For a read operation from memory, the data is transferred from memory to the Z register (the data restoration register) by setting those bits of Z that receive a one from the sense amplifier during the read portion of the memory cycle. For a write into memory, data is transferred into the Z register during the read portion of the memory cycle from either the X register of the compute module or the BFR register of an input/output module. During the write portion of a memory cycle, the Z register controls the inhibit current to the core memory and, thereby, controls whether a one or zero is stored at the selected address.

The parity circuit monitors the 13 bits of Z in a write operation and writes a 14th bit such that the word stored in memory always contains an odd number of one bits (odd parity). In a read operation, the 14 bits are checked for odd parity, and should an error be detected, a signal is sent to the compute or input/output module that is being serviced at the time to inform it of the erroneous readout.

171G INPUT/OUTPUT MODULE

The 171G I/O module contains two buffered bidirectional data channels, each having its own control and interrupt circuitry. A maximum of three I/O modules may be controlled by a single compute module. The compute module has control of the I/O modules in the setting up and initiating of any I/O action. After the action has been initiated, control is maintained by the I/O module, and all data interchange is with memory modules. Each channel has the ability to perform an I/O operation independently with the use of a time-sharing memory request circuit for the two channels.

Figure 8 illustrates a block diagram of the 171G I/O module. It can be seen from this diagram that the interface connections between the 171G and the compute and memory modules are common to both channels of the 171G module.

The 171G and 160G interface consists of 13 bidirectional data lines. These lines are used to transmit function codes to the I/O module and response codes to the compute module. These are also used by the compute module in setting up the control registers in the 171G. There are also 26 control and indication lines used for channel selection, interrupt, and other control functions.

The 171G and 169G interface contains 13 bidirectional data lines that are used to transfer input and output data between the two modules. There are also 17 address selection lines (13-bit address, 4-bit bank) from the 171G to the 169G modules. Six control lines used for requests, resumes, etc., form the control portion of the interface between the two modules. These interface connections are time-shared by both channels within each 171G module.

The other circuitry contained in each channel is quite similar to that contained in the buffered channel of the compute module. Each channel contains a 13-bit BFR, BXR, BER, and a 4-bit buffer bank control register (BBC). The channels also contain control, comparison, and interrupt circuitry.



Figure 8. 171G External Input/Output Module Block Diagram

Since a channel in the 171G module is quite similar to the buffered channel of the compute module, its operation is also similar. The basic input/output process includes the following steps:

- a. Request and check status.
- b. Set up BER, BXR, BBC.
- c. Select equipment.
- d. Initiate action.

All these operations are the same as for the compute module buffer channel except that an I/O channel number must be specified.

On a typical output operation, after the equipment is selected and the BER, BXR, and BBC are set up, an initiate buffer output command will combine with the channel selection number to activate the proper channel. One started, the I/O channel circuitry will gate the contents of BER and BBC to the appropriate memory along with a memory request and a read signal. The memory word will be read from the selected memory and transmitted to the BFR in the 171G along with a resume signal. This data will then be passed on to the selected equipment, which will issue a resume back to the I/O module after receipt of the data. This resume from the equipment will cause the BER register to increase by one count, and the entire process will be repeated until the number in BER is equal to the number of BXR. At this time, a signal (BER=BXR) from the I/O module terminates the operation and causes a buffer termination interrupt signal to be sent to the compute module.

The input operation is set up in the same way as the output operation except that an initiate buffer input command starts operation. The 171G takes control and immediately sends a request for information to the selected external equipment. Data from the equipment is then transferred to the BFR along with a ready signal to the 171G I/O control. Data is then gated from BFR to the selected 169G along with a memory request and a write signal. The resume issued by the 169G indicates completion of the write operation and causes the BER to advance. The operation will then repeat until the signal (BER=BXR) terminates control and the buffer termination interrupt is sent to the compute module.

In addition to the input and output buffering capabilities that the 171G has, it also is able to provide the data path and control signals to transfer information between 169G memory modules. This transfer enables entire blocks of information to be exchanged between two 169G memory modules or within the same memory modules. The operation involves an input buffer on one channel and an output buffer on the other channel of a 171G I/O module. Figure 9 depicts the assignment of the various peripheral equipment to each of the input/output channels.

PROGRAMING

A digital computer, such as the Control Data Corporation (CDC) 160G, is incapable of performing useful operations on its own. To accomplish any operation or series of operations that the machine is capable of performing, the computer must be told, step by step in a language it is capable of understanding, <u>exactly</u> what to do and the order in which it is to do it. This process of telling the computer what to do is referred to as programing. Emphasis will be placed on data transfer and addressing rather than on specific instructions. For programing purposes, there are two types of information stored in memory, operands and instructions. The operand is the information that is acted upon (add, subtract, shift, etc.) and the instruction contains all information (command and address) necessary to perform the action.

OPERATING MODES

The original computer in the CDC 160 series of computers was the 160A. The 160G computers used in the ACE-S/C system have been designed and constructed to be compatible with the 160A computer. That is, any program written for the 160A may be used in the 160G without change. Thus, the 160G computer is said to be capable of operating in two modes, the A-mode and the G-mode. The A-mode may be selected either by a program instruction or by an A-mode select switch on the computer console. Upon execution of a master clear, the computer automatically reverts to the G-mode unless the A-mode select switch is depressed.

INSTRUCTION WORD FORMAT

An instruction in the 160G may be either 13 or 26 bits (see example). If the instruction is a 26-bit instruction, it is stored sequentially in two words of memory. The format of a 13-bit instruction and the format of word 1 of a 26-bit instruction are the same. The upper seven bits constitute a function code and is the F portion of the word. The lower six bits are the E portion of the word and may be an operand, an address, or part of the function code. Word 2 of a 26-bit instruction is the G portion of the instruction and may be an address or an operand. F16 9



Figure 9. Data Processing I/O Channel Assignment

2

30

FOR TRAINING PURPOSES ONLY

410-0 (106)

Word 1	F (7 Bits)	E (6 Bits)	
Word 2	G (13 Bits)		

STORAGE CONTROLS

A 160G compute module may address up to 15 banks of external memory. These, plus the internal bank, add up to 131,072 words of storage that the 160G may address directly. For a memory of this size, the compute module must provide a 17-bit address to specify uniquely any particular word in memory. To provide the additional bits necessary to give a 17-bit address, the storage bank control register is used.

STORAGE BANK CONTROL

A reference to memory may be classified as one of four types:

- a. To input or output information on a buffer I/O channel.
- b. To read in instructions or to locate a constant or counter that is associated with a program.
- c. To read or store an operand or data.
- d. To update an index register, an index register reading, or an address reference for indirect addressing.

The 20-bit storage bank control register is divided into four groups of five bits each. Each group is assigned to one and only one of the four types of memory reference. The 160G then automatically classifies each memory reference into one of the four types and uses the appropriate part of the storage bank control register to complete the 17-bit address. The four types of memory reference are referred to by the following names: Type 1 reference is the buffer bank; Type 2, the relative bank; Type 3, indirect bank; and Type 4, direct bank.

ADDRESSING MODES

The 160G has 14 basic data handling instructions. Each of these basic instructions may have as many as 12 variations or addressing modes.

INPUT/OUTPUT

The purpose of the I/O circuitry is to permit the transfer of data between memory and external equipment. This transfer of data may be either a normal or buffered operation. Normal data transfer completely ties up the compute module while a buffered operation allows the compute module to be free most of the time for other operations. When the compute module communicates with external equipment, it executes an External Function (EF) code which is a 12-bit code that is read from memory into the X register.

READ NEXT INSTRUCTION (RNI) AND ADVANCE P SEQUENCES

The RNI and advance P sequences are important because they are the part of each instruction that enables the computer to step sequentially from instruction to instruction. Since P contains the address of the current instruction and S contains the address of the next instruction, the usual flow of instruction addresses will be from S to P. The only exceptions to this flow are on an enter instruction, the initial instruction of a program, a Buffer 2 operation, and an output buffer operation.

The RNI sequence performs two important operations:

- a. A memory reference cycle is initiated and the instruction in the memory address given by the S register is transferred to the X and F registers.
- b. The P and S registers are updated.

At the end of an RNI:

- a. The E portion of the instructions is in the X register.
- b. The instruction is in the F register.
- c. P + 1 is in the A' register.

COMPUTER PERIPHERALS

There are several standard peripherals associated with the CDC 160G computers. They are:

- a. 4-606 Magnetic Tape Transports.
- b. 2-162G Magnetic Tape Synchronizers.
- c. 1-162G High Speed Printer.
- d. 2-165G X-Y Plotters.
- e. 2-176G Monitor Typewriters.
- f. 2-405/177G Card Readers.
- g. 1-IBM 523/170 Card Punch.

Peripherals are extensions of the computer - the voice and ears of the system. They are the only means available input information (programs and subroutines) efficiently into the computer and to record processed data from the computer. Some of the peripherals may be both input and output devices, and some are limited to either input or output operations, but not both.

606/162G MAGNETIC TAPE SYSTEMS

The magnetic tape transport (606) provides a high-speed medium for recording and retaining information or for delivering information to the computer. Information is read or written by passing the magnetic tape over read/write heads.

Information is written on the magnetic tape by using seven individual write heads. All seven heads write information simultaneously across the tape so that each frame of data is composed of a 6-bit character and a vertical parity bit. Tracks 0 through 5 contain the data, and track 6 contains a parity bit. These frames are formed into groups called records (program controlled) and at the end of each record a check character is written. This character is made up of seven longitudinal (horizontal) parity bits, one for each channel. Thus, parity is checked vertically, frame by frame, and horizontally, channel by channel.

A non-return-to-zero (NRZ), change on ones, recording method is used. For this method, a binary one is recorded by changing the magnetic flux direction on the tape. If, in a certain time period, the magnetic field does not change directions, a binary zero is indicated.

The magnetic tape synchronizer (162G) provides communications between the computer and the tape transports. The synchronizer can also provide communications between the tape transports and the high speed printer in an off-line condition. The 162G, controlled by EF codes from the computer:

- a. Controls the magnetic tape transports.
- b. Transfers information between the computer and the magnetic tape transports.
- c. Converts the data to a usable form.

Figure 10 shows the major communications between the 160G computer and its associated peripherals.



Figure 10. Signal Transfers Between 160G and Peripherals

1612G HIGH SPEED PRINTER

The 1612 high speed printer is a computer output device. The computer may transfer data to it for presentation, but it cannot input data to the computer.

The high speed printer accepts Binary-Coded-Decimal (BCD) information from the computer and prints the information out on fan-fold forms for observation and recording purposes. The 1612G can print up to 1000 lines per minute with each line containing 120 characters. A choice of 64 different characters, or symbols, are available on the print drum for selection.

Since the high speed printer cannot be used as a computer input device, only the signal transfers indicated in Groups (1) and (3) of Figure 10 will be utilized.

165G X-Y PLOTTER

The 165G X-Y plotter is a high-speed, two-axis recorder that can trace a visible plot of one variable against another. The plot is accomplished by means of a carriagemounted ballpoint pen, writing on paper placed on a bi-directional recording drum. The paper feed and take-up mechanism handles paper rolls 100 feet long and 12 inches wide. Recording drum sprocket teeth engage sprocket holes in the paper in order to drive the paper past the pen. The control section of the plotter provides the interface between the computer and the plotter mechanism.

Since the X-Y plotter is only a computer output device, the signal exchanges in Groups (1) and (3) of Figure 10 are applicable.

176G MONITOR TYPEWRITER

The 176G typewriter serves as both an input and an output device for the computer. A manual input to the computer may be accomplished from the keyboard, or a typewritten copy of specific computer memory locations may be derived by automatic computer instruction at a rate of about 10 characters per second. The typewriter is normally used to type out operator instructions when manual intervention is needed during a program.

Since the 176G may be used as an input and an output device, the signal transfers indicated in Groups (1), (2), and (3) of Figure 10 are applicable.

405/177G CARD READER AND CONTROLLER

The 405 card reader and controller provides a fast and efficient source of information to the computer. It can read up to 1200, 80-column cards or 1600, 50-column cards per minute. (Eighty-column cards are used in the ACE-S/C system.)

The card reader supply tray and primary receiving tray have capacities of 4000 cards. The secondary receiving tray, used as a limited sorter or to store rejected cards, has a capacity of 240 cards. The cards contain binary or Hollerith coded information, and the data is read from the cards by means of a photoelectric read station.

The card reader acts as an interface unit between the CDC 160G computer and the CDC 405 card reader. It provides the necessary control logic to transfer data from the 405 to the 160G and, upon computer instruction, tells the 405 what operation to perform (such as, read card binary, read card Hollerith, continuous read, single-cycle read, etc.). When the card reader is instructed to read binary data, the 177G transfers the information column (12 bits) by column to the computer as the computer requests an input. When the card reader is instructed to read Hollerith coded data, the 177G translates a Hollerith column (12 bits) to 6-bit BCD, temporarily stores the data, translates the next Hollerith column to 6-bit BCD, and then transmits the 12-bit word containing two BCD characters and representing two columns of information on the card to the computer. This process is known as "packing." A binary card may usually be recognized by the punch configuration in the first column. If rows 7 and 9 in the first column are both punched, the card contains binary information. If either row 7 or row 9 is not punched in the first column, the card may contain Hollerith coded information.

The 405/177G can only be used as a computer input device. Therefore, the signal exchanges indicated in Groups (1) and (2) of Figure 10 are applicable.

IBM 523/170 CARD PUNCH AND CONTROLLER

The IBM 523 card punch mechanically punches cards at a rate of 100 cards per minute. These cards are the 80-column type, but as many columns as desired, up to 80, may be punched on any one card.

The CDC 170G card punch controller interfaces the 160G to the 523. The controller provides the necessary signals, translations, and transfers for the computer to provide program instruction for the card punch. The controller provides temporary storage

for data from the computer to be punched onto cards. It also controls the transfer of data from the computer to the card punch. The 523/170G is strictly a computer output device, and, therefore, the signal exchanges shown in Groups (1) and (3) of Figure 10 are applicable.

PART II - SYSTEM PROGRAMING

In previous study guides, the command or uplink loop was discussed in terms of hardware functions. These discussions embraced the operation of the data entry equipment and the 160G Control Data Corporation computer and the functional relationship between these two entities. Since the command computer is a stored program processor, it now becomes necessary to discuss the command loop operation in light of the various programs that are stored in the computer's memory. In addition to discussing the functional aspects of the programs, it is necessary to understand the functional aspects of the programs, it is necessary to understand the general programing requirements, program structure, program preparation and verification, and a general understanding of the many terms utilized in conjunction with the programing effort. To enable the operator to understand program application in the ACE-S/C system, a working knowledge of the various terms used in describing program operation is necessary. A list of these terms follow:

<u>ABSOLUTE CODING</u>: Coding written in numeric language acceptable to the machine without further modification.

<u>ACCESS, RANDOM</u>: Access to storage under conditions in which the next position from which information is to be obtained is independent of the previous one.

<u>ACCESS TIME</u>: The time interval between the call for a unit of information from a storage device and the delivery of that information.

ADDER: A device capable of forming the sum of two quantities.

<u>ADDRESS</u>: A label, name, or number identifying a register, a storage location, or a device from which information is received or to which it is transmitted.

<u>ADDRESS</u>, <u>ABSOLUTE</u>: The label(s) assigned by the machine designers to a specific storage location.

<u>ADDRESS</u>, <u>BASE</u>: A number that appears as an address in a computer instruction, but which is to be modified; e.g., by adding the contents of one or more index registers before it is used.

<u>ADDRESS</u>, <u>DIRECT</u>: An address in a computer instruction that indicates the location where the referenced operand is to be found or stored.

<u>ADDRESS EFFECTIVE</u>: A modified address; the address actually used in a particular execution of a computer instruction.
<u>ADDRESS, INDIRECT</u>: An address in a computer instruction that indicates a location where the address of the referenced operand is to be found.

<u>ADDRESS, RELATIVE</u>: A number of the form of an address that specifies the position of a storage location with respect to some base address. The absolute address of the storage location is obtained by adding the relative address to the base address.

<u>ADDRESS, SYMBOLIC</u>: A label chosen to identify a particular work, function, or other information in a routine, independent of the location of the information within the routine.

<u>ALPHANUMERIC</u>: Characters that may be either letters of the alphabet, numerals, or special symbols.

<u>ARITHMETIC UNIT</u>: The part of a computer where logical and arithmetic operations are performed.

<u>ASSEMBLY PROGRAM</u>: A computer program that produces machine instructions from symbolic input.

<u>BANK</u>: A unit of core storage with provisions for storing 4096 or 8192 words. The use of more than one bank permits increasing the storage capacity of a computer without increasing the word length implicitly necessary to extend the range of storage addresses. In the 160A or the 160G, this address is effectively increased by set storage bank control instructions which determines which banks will be used during the program.

BCD: Binary Coded Decimal.

<u>BINARY CODED DECIMAL</u>: Representation of alphanumeric characters by combinations of binary digits.

<u>BLOCK</u>: A group of words considered or transported as a unit; in flow charts, an assembly of boxes, each box representing a logical unit of programing, usually requiring transfer to and from the high-speed storage.

<u>BOOTSTRAP</u>: The coded instructions at the beginning of an input medium (tape or cards), together with instructions inserted by switches or buttons into the computer, which are used to read programs into memory.

<u>BREAK-POINT</u>: A point in a routine at which special action is taken, such as a stop or a transfer, either as the result of the insertion of a special instructions or the setting of a console switch. Usually used in debugging.

<u>BUFFER</u>: A device in which data is stored temporarily in the course of transmission from one point to another.

<u>BUFFERED (INPUT/OUTPUT)</u>: A term indicating that the computer may carry on high-speed computation at the same time it is exchanging data with a peripheral device.

FOR TRAINING PURPOSES ONLY

BUG: A mistake in a routine; an equipment malfunction.

BYTE: A group of binary digits usually operated upon as a unit.

C-START: Computer communications START module.

<u>CALLING SEQUENCE</u>: A set of characters identifying a subroutine and containing information concerning parameters to be inserted in the subroutine, information to be used in generating the subroutine, or information related to the operands; a call-word when exactly one word is filled.

<u>CHANNEL</u>: A transmission path (e.g., one connecting the computer to external equipment).

<u>CHARACTER</u>: One of a set of symbols, usually restricted to a member of a specific alphabet or appropriate to a particular computer. The symbols may include the letters A through Z, digits 0 through 9, punctuation marks, operation symbols, or any other symbols which a computer may read, store, or write, more precisely, the coded computer representation of a symbol drawn from its alphabet (e.g., one might represent the symbol "A" as the character 100001 in a specific computer alphabet).

<u>CHECK SUM</u>: A check in which groups of digits are summed, usually without regard to overflow, and that sum checked against a previously computed sum to verify accuracy, also, the previously computed sum.

CLEAR: To reset a register by placing every stage in the "0" state.

<u>CODE</u>: (Verb) To perform that part of the programer's job that involves the writing down of the sequence of instructions that make up a computer program.

<u>COLLATE</u>: To merge items from two or more similarly sequenced files into one sequenced file without necessarily including all items from the original files.

<u>COMMAND</u>: A signal that performs a unit operation, such as transmitting contents of one register to another, shifting a register, setting a flip-flop.

<u>COMPILER</u>: A computer program that translates instructions written in a technical or problem-oriented language into machine language. Usually more than one machine instruction results from each symbolic instruction.

COMPLEMENT: See One's Complement or Two's Complement.

<u>CONTENT</u>: The quantity or word held in a register or storage location.

<u>CORE</u>: A small ferromagnetic toroid used as the bi-stable device for storing a bit in a memory plane.

<u>COUNTER</u>: A device, register, or storage location for storing integers, permitting these integers to be increased or decreased by unity or by an arbitrary integer, and capable of being reset to zero or to an arbitrary integer. CRT: Cathode Ray Tube. CSR: Check Status Reply.

CUE: Communications Unit Executor.

<u>DATA REDUCTION</u>: The process of transforming masses of raw test or any experimentally obtained data, usually gathered by instrumentation, into useful, ordered, and simplified intelligence.

DCCU: Digital Communications and Control Unit.

<u>DEBUG</u>: To isolate and remove all malfunctions from a device or all mistakes from a computer program.

<u>DENSITY</u>, <u>PACKING</u>: The number of units of useful information contained within a given linear dimension, usually expressed in units per inch, e.g., the number of bits stored on tape per linear inch on a single track by a single head.

<u>DIGITIZE</u>: To convert an analog measurement of a physical variable to a numerical value, expressing the quantity in digital form.

DIAGNOSTIC PROGRAM: See Maintenance Program.

<u>DOWNLINK CONTROL PROGRAM</u>: A computer program that receives, processes, and displays, in real time, telemetry data from the spacecraft.

DTCS: Digital Test Command System.

DTVC: Digital Transmission and Verification Converter.

<u>DUMP</u>: To copy the contents of part or all of some storage medium into another storage or display medium.

EBM: Execute DTCS buffer memory.

EDITOR: A routine to insert, delete, replace, or rearrange data.

<u>END-AROUND BORROW</u>: A borrow that is generated in the highest order stage of an accumulator or counter and sent directly to the lowest-order stage.

ENTER: To place manually a quantity into a register.

EXECUTION ADDRESS: Most often used to specify the storage address of an instruction or operand. Sometimes used as the operand.

EXTERNAL FUNCTION CODE: A 12-bit code used to select and specify that an external device; e.g., a printer or tape is to perform some specific function. FLIP-FLOP: A bi-stable storage device.

FUNCTION CODE: See Operation Code.

<u>GASS</u>: A general assembly system for the Control Data Corporation 160G computer system. GASS operates within MASS.

<u>HANG UP</u>: An unplanned computer stop or delay in problem solution, e.g., inability to escape from a loop.

<u>HOUSEKEEPING</u>: Operations in a routine that do not directly contribute to the solution of the problem at hand, but which are made necessary by the method of operation of the computer.

<u>INDEX REGISTER</u>: A register that contains a quantity, which may be used to automatically modify addresses (and for other purposes) under direction of the control section of the computer.

<u>INITIALIZE</u>: To set program variables, such as addresses, counters, etc., to the condition required in a routine prior to its use.

<u>INPUT/OUTPUT</u>: A collective designation for all communication facilities of a computer.

<u>INSTRUCTION</u>: A set of characters that, as a unit, cause a computer to perform one of its operations. Instructions may contain one or more addresses according to the number of references to operands in storage contained in the instruction. <u>INTERRUPT</u>: A signal (or class thereof) that, when received and recognized by the computer, forces the computer to forestall its current operation and jump to a subroutine, the starting address of which is determined by the class of the interrupt.

I/O: Input/Output.

<u>JUMP</u>: An instruction or signal that, conditionally or unconditionally, specifies the location of the next instruction and directs the computer to that instruction. K-START: Keyboard START module.

LBM: Load DTCS buffer memory.

<u>LIBRARY</u>: An ordered set or collection of standard and proven programs and subroutines used for data processing applications and the solution of problems. <u>LOAD</u>: To bring information into memory from an external storage medium and to place a quantity from storage into the A register.

LOCATION: A storage position in internal or shared memory.

<u>LOCKOUT</u>: Any function (usually of machine logic) that inhibits an action that would normally occur if the lockout were not imposed.

<u>LOGICAL OPERATIONS</u>: The computer operations that are logical in nature, such as logical <u>and</u>, <u>or</u>, <u>extract</u>, and <u>decisions</u>. This is in contrast to the arithmetic operations, such as add, subtract, multiply, and divide.

<u>LOOP</u>: A given sequence of instructions operated upon repeatly (normally, until a specified condition occurs).

<u>MACRO</u>: A symbolic instruction representing a frequently used sequence of machine language instructions.

<u>MAINTENANCE PROGRAM</u>: A diagnostic program to determine the operational readiness of any piece of computer or peripheral equipment and to isolate any malfunctions that occur.

<u>MANAGEMENT INFORMATION AND CONTROL PROGRAM</u>: A program that performs checking, processing, and/or analysis of data to furnish management with information for evaluation, control, and operation of activities for which it is responsible.

<u>MASK</u>: A prearranged pattern or configuration of bits in a computer word generally used for logical or bit manipulations.

<u>MASS</u>: A monitor and assembly system for the Control Data Corporation 160G computer system.

MICROSECOND: A millionth part of a second.

MILLISECOND: A thousandth part of a second.

<u>MNEMONIC OPERATION CODES</u>: Operation codes in symbolic notation, which are easier to remember than the actual operation codes of the machine.

<u>MONITOR</u>: A program that exercises supervisory control over some other programs or collections of programs. Also called executive routine or master routine.

NANOSECOND: A billionth part of a second.

<u>OBJECT PROGRAM</u>: A machine language program that is the final output of an assembly system.

OCTAL: Pertaining to the number base of eight.

<u>OFF-LINE</u>: Pertaining to the operation of devices that are under direct control of the computer.

<u>ON-LINE</u>: Pertaining to the operation of devices that are under direct control of the computer.

<u>ONE'S COMPLEMENT</u>: With reference to a binary number, it is that number which results from subtracting each bit of the given number from the bit "1."

<u>OPERAND</u>: Usually refers to the quantity specified by the execution address. This quantity is operated upon in the execution of the instruction.

<u>OPERATION CODE</u>: That part of an instruction designating the operation to be performed.

<u>OSAS-A</u>: A general assembly system for the Control Data Corporation 160A computer system.

<u>OVERFLOW</u>: The condition in which the capacity of a register is exceeded. <u>PARALLEL TRANSFER</u>: A system of data transfer in which elements of information are transferred simultaneously over a set of lines.

<u>PARAMETER</u>: A quantity to which values may be assigned; used in subroutines and generators to specify item size, decimal point, block arrangement, field length, sign position, etc. <u>PARITY CHECK</u>: A redundancy check technique based on an odd or even number of binary ones in some grouping of binary digits. In the binary representation of a character, a parity bit is made either zero or one, whichever is required to make the number of ones in the character an even number for even or an odd number for odd parity.

PARTIAL ADD: An addition without carries.

<u>PROGRAM</u>: A sequence of instructions that causes a data processing system to process a specific application; a plan for the solution of a problem.

<u>PSEUDO INSTRUCTION</u>: A symbolic representation of information to a compiler or interpreter; a group of characters having the same general form as a computer instruction, but never executed by the computer as an actual instruction.

<u>PYRAMID, BORROW</u>: A network of inverters that senses borrow conditions and produces borrow signals.

<u>R-START</u>: Relay selection START modules.

<u>RAW DATA</u>: Data that has not been processed; may or may not be in machinesensible form.

<u>READ</u>: To copy, usually from one form of storage to another, particularly from external or secondary storage to internal storage; to sense the presence of information on a recording medium.

<u>REAL-TIME PROCESS</u>: A process where the computer exists on-line in an environment that cannot be made subservient to computer control. Usually a continuous physical process is involved.

<u>RECORD</u>: A group of related facts or field of information that is treated as a unit. <u>RELOCATE</u>: To move a routine from one portion of internal storage to another and, in so doing, to automatically adjust the address references so that the routine can be executed in its new location.

<u>RETURN JUMP</u>: A jump instruction that enables program control to be returned to the original sequence upon transfer to and completion of a second sequence of instructions.

<u>ROUTINE</u>: Essentially synonymous with "program," although generally restricted to describing single-purpose programs.

<u>SEAL</u>: To lockout; in a START module, to inhibit transmission of information to the computer.

<u>SEGMENTATION</u>: Division of a routine into parts, one segment being the "main program" and other segments being subprograms. The segments are linked together by CALL-type statements and may be compiled and debugged separately. <u>SERIAL TRANSFER</u>: A system of data transfer in which elements of information are transferred in succession over a single line.

SGS: Symbol Generator System.

SHIFT: To move the bits of a quantity right or left.

<u>SIGN BIT</u>: The bit in the highest-order stage of the register (in registers where a quantity is treated as signed by use of ones complement notation). If the bit is "1," the quantity is negative; if the bit is "0," the quantity is positive.

<u>SIGN EXTENSION</u>: The duplication of the sign bit in the highest-order stages of a register.

<u>SOURCE PROGRAM</u>: A program coded in other than machine language that must be translated into machine language to be executed by a computer.

<u>SPACECRAFT TEST PROGRAM</u>: A computer program package containing the control programs, TEX's, etc., required to describe a single spacecraft test. <u>START</u>: Selections To Activate Random Testing.

<u>STATUS</u>: The condition of an external device, as reflected in the response given a status interrogation by the computer.

The condition of a device, such as a computer, as shown by visual displays on its console.

STORAGE: Any device into which units of information can be copied, which will hold this information, and from which the information can be obtained at a later time.

STORAGE, TEMPORARY: Internal storage locations reserved for intermediate and partial results.

<u>SUBPROGRAM</u>: A segment of a larger program capable of being compiled and debugged by itself.

<u>SUBROUTINE</u>: The set of instructions necessary to direct the computer to carry out a well-defined mathematical or logical operation; a subunit of a routine.

<u>SUBROUTINE, CLOSED</u>: A subroutine not stored in the main path of the routine. Such a subroutine is entered by a jump operation with provision made to return control to the main routine at the end of the operation.

<u>SUBROUTINE, OPEN</u>: Has been, in general, replaced by the term "Macro Instruction." It is a subroutine inserted directly into the main path of the routine, not entered by a jump. Such a subroutine must be re-copied at each point that it is needed.

<u>SUPERVISORY EXECUTIVE PROGRAM (SEP)</u>: The monitor program that exercises supervisory control over the use of spacecraft test programs during realtime testing of spacecraft.

<u>SYMBOLIC CODING</u>: Any coding system in which symbols other than machine addresses and machine language are used.

FOR TRAINING PURPOSES ONLY

<u>TABLE LOOKUP</u>: A coding technique or an instruction that locates the word in a table corresponding to a specified word, and usually obtains some other word that corresponds to the word located.

<u>TEST EXECUTIVE (TEX)</u>: A computer program or subprogram written specifically to meet spacecraft system test sequence requirements for real-time operation. <u>TEST FILE</u>: One or more spacecraft test programs on magnetic tape, limited only be length of tape.

<u>TWO'S COMPLEMENT</u>: The two's complement may be formed by complementing each bit of the given number and then adding one to the result, performing the required carries.

<u>UPLINK CONTROL PROGRAM</u>: A computer program that generates commands to the DTCS to provide stimuli to the spacecraft according to information received from the CUE.

<u>UTILITY PROGRAM</u>: A program normally used to assist in the operation of a data processing system (e.g., memory dump, card to tape, etc.).

<u>WORD</u>: A set of characters which occupies one storage location and is treated by the computer circuits as a unit. Ordinarily, a word is treated by the control unit as an instruction and by the arithmetic unit as a quantity.

<u>WRITE</u>: To transfer information to an output medium; to copy, usually from internal storage to external storage; to record information in a register, location, or other storage device or medium.

Figures 11 and 12 illustrate the various program and system flow chart symbols that are utilized in the programing effort for ACE-S/C. An understanding of the flow chart symbology will make it easier for the reader to understand the program flow charts included in this document.

PROGRAMING REQUIREMENTS

Table 1 depicts the general programing requirements for a typical ACE-S/C configuration. The requirements are broken down into seven distinct areas. The <u>Downlink</u> <u>Data Processing and Display</u> area involves the inputting of the PCM analog and event data words from the decommutation equipment and the selection or stripping out of the input words that are to be processed. In addition, the computer must be alerted as to the type of processing required so that the proper checks, conversions, formatting, and outputting routines can be accommodated. Downlink data processing will be discussed in more detail in a subsequent study guide. <u>The Uplink Command Generation</u> and Verification area involves the interrupt handling routines, command interpretation,





Figure 11. Program Flow Chart Symbols

410-0(106)



Figure 12. System Flow Chart Symbols

and the manner in which these commands are to be handled; for example, a relay closure or the callup of a subroutine that may initiate some other function. The program must also provide for the proper formatting of the commands and also for the transmission of the commands to the proper location in the test bay area. The remainder of the items in Table 1 are self-explanatory and they also will be covered in subsequent portions of this document.

Table 1

General Programing Requirements

No.	Program Requirements
1	DOWNLINK DATA PROCESSING AND DISPLAY Input and Selection Limit Checks and Adjustment Conversion Formatting and Outputting
2	UPLINK COMMAND GENERATION AND VERIFICATION Interrupt Handling Command Interpretation and Handling Formatting and Outputting Status Keeping
3	SELF-TEST
4	SUPERVISORY PROGRAMS
5	PROGRAM VERIFICATION
6	MAINTENANCE PROGRAMS
7	LIBRARY MAINTENANCE

PROGRAMING STRUCTURE

Figure 13 depicts the programing structure utilized in the conduct of spacecraft testing by ACE-S/C. The overall program is entitled Supervisory Executive Program (SEP). SEP is designed to exercise overall control and provide a means of rapidly changing computer loads to support ACE-S/C stations in all phases of operation. The function of this program is to locate the proper file on the test file tape and load the uplink program, uplink parameters, and the downlink program. It also loads the scope annotations, downlink parameters, calibration address tables, and the calibration data.



Figure 13. Programing Structure

When changes are called for in the course of operations, this program permits three types to be initiated by a single specified C-START. These three changes are as follows:

- a. Load an entire test.
- b. Load a new annotation into the entire SGS memory and load its associated downlink parameters.
- c. Change the engineering limits in a specified downlink parameter.

The SEP is loaded in the memory of the downlink computer. A test file tape is loaded with the SEP and the loading instructions being the first file on the magnetic tape. After the tape has begun loading the program, the uplink computer is started by the operator. The system is now fully automatic for the loading process and is under the control of SEP operating in the downlink computer. Unless errors (requiring operator intervention) occur, all further commands to the program are via SEP C-START. Further information concerning the operation of the SEP can be obtained from the ACE-S/C computer program document, Volume 5.

PROGRAM PREPARATION AND VERIFICATION (Figures 14 and 15)

The <u>Programing Standards Manual</u>, Part 4, Bulletin 2, defines the procedure to be followed in the preparation and verification of spacecraft test programs. This procedure is used to verify that each ACE-S/C test program and/or spacecraft test tape meets specified requirements and can be certified for use as an operational program to be incorporated into the official ACE-S/C computer program library. The spacecraft contractor submits to the General Electric Company a block specification which details the various parameters to be processed, sampling rates, parameter limits, type of processing and the page format for the alphanumeric display system.

After receiving the block specification, the information is analyzed for proper understanding and then the initial write-up and flow charts are developed. These flow charts are reviewed by the spacecraft contractor and NASA to insure the proper translation of the requirements. Upon the completion of the review, detailed flow charts are developed and then all real-time test programs are written in mnemonic language. The General Assembly System (GASS) will be used for the assembly of test programs on the CDC 160G computer. After the test program has been flow charted and coded, the debugging procedure is accomplished.







Figure 14. Spacecraft Test Programs - Program Preparation and Verification (Cont.)

.



410-0(106)

Figure 15. Acceptance Test Programs -Program Preparation, and Verification

After completion of the program preparation sequence, the verification phase is initiated. Figure 16 illustrates the general equipment configuration utilized during the verification phase of test program checkout. The uplink configuration will be as follows - Hardware configuration will remain standard from the START modules through the uplink computer and through the input to the assigned uplink Data Transmission and Verification Converter (DTVC). The output of the uplink DTVC will be disconnected from the Digital Test Command System (DTCS) and patched to the DTVC of the downlink computer.

The software configuration will be as follows:

- a. Load test program to be verified from the spacecraft test tape into the uplink computer.
- b. Load DTCS simulator program into the downlink computer.
- c. Mount usable tapes on other tape units of both computers.



Figure 16. Program. Verification

UPLINK PROGRAM ANALYSIS (Figure 17 - Main Uplink Control Program)

The command computer time is occupied by two separate types of operations that may be described as nonpriority and priority operations. The nonpriority operation is controlled by the executive program that maintains a logic flow of low-priority (nontime critical) processing tasks. These tasks serve the dual purpose of performing important maintenance and housekeeping functions while efficiently using the computer's spare time between priority operations. The priority operation may be best described as the handling of test operation request interrupts from the CUE. The priority operation is controlled by interrupt handling routines. The various interrupts are the key to the priority operation. The priority operation consists of processing these interrupts to determine what action is necessary to satisfy a test operation request.

The nonpriority computer operation consists of two main operations that are best termed initialization and housekeeping. During the initialization operation, normal command equipment operation is prevented while the computer receives parameters that are arranged into tables. The tables are then assembled, and the computer selects the operating status for external equipment. After this is accomplished, normal operation of the command equipment group is enabled, and the computer systematically performs low-priority information transfers and real-time maintenance checks. The housekeeping operation may be temporarily halted at any time by interrupts from the DTVC or CUE. When this occurs, the computer breaks into a priority operation.

The initialization operation begins when punched cards containing table parameters are read into the computer. The computer assembles these parameters into three unique tables (according to program control) and stores them in allocated memory locations. These tables are termed clock table, R-START table, and C-START table. The clock table is associated with timed interrupts to the computer from the tape recorder/computer time decoder and search control. The clock table is used to interpret these interrupts, call up the subroutine requiring attention, and set the clock for the next controlled interrupt. The R-START table is associated with Interrupt 30 from the CUE. This table is used to associate each R-START module with a group, baseplate, and module of the receiver-decoder. The R-START table is also used to control SEAL requests or reference an appropriate preroutine address. Additional information with respect to function switch status of the current R-START module is added to the data determined by the R-START table. The C-START table performs the same function as the R-START table insofar as it associates each C-START module with a group, baseplate, and module of the receiver-decoder. The C-START table performs





Figure 17. Uplink Control Program

table also controls SEAL request or references appropriate preroutine memory address for special analog functions. After the tables have been assembled, the computer initializes all equipment used during normal operation. This is accomplished by verifying that all peripheral equipment is ready and selecting the proper operating mode for each. If this cannot be accomplished, the computer types out an appropriate message and halts. After equipment initialization is completed, the computer sets all programed flags to their normal state, releases the lockout interrupt, and begins the housekeeping operation.

The housekeeping operation is actually a wait operation that efficiently uses the computer time to perform nonpriority tasks while the computer is waiting for priority operation requests. During this operation, the computer may perform a number of various operations that are designated by the program. Examples of these operations are the transfer of information between computers through shared memory or the performance of routine maintenance checks. The housekeeping operation can be interrupted at any time to perform priority operations. After the priority operation is completed, the housekeeping operation begins again at the point where the interruption occurred.

A priority operation is the functioning of the computer as a translator interface between the CUE and the DTCS. This operation begins as the result of an interrupt received from the CUE. After an interrupt occurs, the computer receives an input from the START module that generated the interrupt. The computer reads the START module input and generates one or more commands to be sent to the DTVC. The DTVC transmits the command from the computer to the DTCS. The DTCS performs a validity check on the command and returns a Check Status Reply (CSR) word to the DTVC. The DTVC relays the check status reply word to the computer, which uses it to determine the success or failure of the transmission. If the transmission was successful, the START module that originated the command is notified by a confirm or a SEAL from the computer. The confirm allows the START to enter new commands to the computer. The SEAL prevents further action from being initiated by that particular START until the preset command has been executed. If three transmissions of the command are unsuccessful, the computer will notify the CUE and diagnose the malfunction.

The computer is switched from housekeeping operation by interrupt signals from the external command equipment. During normal operation, these interrupts consist of Interrupt 30 and Interrupt 40 signals. The Interrupt 30 signal is applied to the computer by either an R-START module or a DTVC. The Interrupt 40 signal is applied to

the computer by a C-START, K-START, DTVC, or one of the I/O synchronizers. Either interrupt will cause the I (interrupt) flag to be set and the computer to respond in the same manner.

When an Interrupt 30 is sent to the computer, the first action performed is to save the accumulator contents so it may be used when housekeeping operations are resumed by the computer. The I flag is cleared so that the housekeeping operation may resume after the interrupt has been answered. Finally, the computer checks a series of routing flags to determine if the DTVC generated the interrupt. If none of the routing flags is set, the computer checks the status of the CUE. If the CUE did not generate the interrupt, the computer assumes the interrupt was generated by the DTVC and starts a priority operation by initiating a DTVC routine.

When an Interrupt 40 is sent to the computer, it reacts in the same way as it does when the Interrupt 30 is received. The only difference is a few additional steps are performed to determine if the interrupt came from the tape recorder/computer time decoder and search control. After the computer has determined which external unit has generated an interrupt, it will start a priority operation, which may be one of several routines. The routine will be determined by the equipment that generated the interrupt.

The R-START routine causes the computer to accept a coded R-START command word from the CUE, interpret the command word, and transmit commands to the DTCS via a DTVC.

If a command generated by the R-START module requires relay action only, the computer checks the DTVC for availability. If the DTVC is available for transmission, the command words are set into the output buffer and control is transferred to the DTVC output routine. If the DTVC is not available, the computer begins nonpriority operation until the DTVC is available. In either case, the appropriate routing flags are set to the proper state.

If a command generated by the R-START module is for a special function, the required special subroutine is recalled from memory and recorded on magnetic tape. The computer then returns the CUE to interrupt mode and clears the interrupt lockout logic. It then replaces the housekeeping operation with the special subroutine. The computer then runs the special subroutine and answers interrupts just as though it was performing the housekeeping operation. When the special subroutine has been completed, the

computer returns control to the R-START routine, which returns the computer to normal housekeeping operations.

The C-START routine causes the computer to accept four coded command words from the CUE, interpret the command words, and transmit commands to the DTCS via the DTVC. The C-START command words will contain up to ten decimal digits of parametric information to add to the uplink commands. The parametric information is added to one of three general subroutines that are called up by the first C-START input word. The subroutine can generate commands to apply stimuli and control relay closure sequence in the DTCS. This is accomplished through the sequence of computer operation described in the following paragraphs.

4

If the C-START input is for a normal function, the computer generates commands using the onboard addresses and other data contained in the input words. The computer then checks DTVC for availability. If the DTVC is not available for transmission, the computer returns to housekeeping operations until the DTVC is available. If the DTVC is ready to transmit, the command words are placed in the output buffer and computer control is transferred to the DTVC routine. In either case, appropriate routing flags are set the proper state.

If the C-START input is for a special function, the computer derives the test area equipment address and appropriate preroutine from the C-START table. The computer then loads the test area address into the A register and makes a return jump to the preroutine. After the preroutine has run, the A register contains the address of the routine that will perform the special function. This address is placed in the clock table. Then the initial interrupt time is calculated, and also placed in the clock table opposite the address. If this is the first entry in the clock table, the computer requests the first interrupt from the clock. Thereafter, this condition is handled by the clock servicing routine. The command is recorded on magnetic tape, and the CUE write mode is selected. This releases the scanner and returns the CUE to interrupt mode. After this, the computer returns to normal housekeeping operations.

The computer switches to the K-START routine from a C-START routine. This routine causes the command computer to interpret K-START inputs and generate command signals to be sent to the spacecraft Airborne Guidance Computer (AGC). The command computer receives four 12-bit words from the K-START module. The first word contains the unique address of the K-START module and a flag bit that indicates whether

the input originated at the K-START keyboard or at the paper tape reader. Words three and four are dummy words to make the K-START input format compatible with the C-START input.

The purpose of the DTVC routine is to transmit commands to the DTCS via a DTVC. This routine causes the computer to send Load Buffer Memory (LBM) words and Execute Buffer Memory (EBM) words to the DTVC for transmission. CSR words are received from the DTCS by the DTVC. The CSR words cause the DTVC to send an Interrupt 30 to the computer if the transmission was successful, and an Interrupt 40 if the transmission was unsuccessful. The DTVC will not transmit a command until the CSR of a previous command has been received.

The computer determines which DTVC is to be used to transmit from the START input, then stores the command in a rotating table. This table is large enough to control the largest backlog of command anticipated. The computer also stores the first word from the CUE and the previous function switch settings in the table. These are required in the event the transmission fails. In this case, the CUE word and the fail CSR word will be sent to the CUE maintenance panel, and the previous function switch settings will be sent to the requesting START module. After the command has been stored, the computer checks the DTVC status. If the DTVC is not busy, the computer moves data from the rotating table to the output block for transmission to the DTCS. After transmission, the computer converts the command from a load DTCS buffer memory to an execute DTCS buffer memory. When the I/O module buffer interrupt indicates the LBM has been transmitted, and when the CSR has been received, the computer will allow the EBM to be transmitted. When the I/O module indicates the EBM has been transmitted, the computer will select the DTVC to recognize the CSR word and generate an Interrupt 30 or 40 to indicate success or failure of the transmission. The computer performs interrupt operations between the steps explained previously to make efficient use of time required for the actual transmission. Success or failure of the transmission is determined by the DTVC. After reception of the CSR, the DTVC will generate an Interrupt 30 or 40 depending on the success or failure of the transmission. If the transmission has been a failure, an Interrupt 40 will be generated and the CSR will be inputted to the computer. The computer will check to determine if this is the third failure of this command. If it is, the computer will call up a maintenance routine. If not, transmission will be tried again. If an Interrupt 30 is generated by the DTVC indicating success of transmission, the computer will release the CUE to scan. The computer will also send a function code to the START module that originated

the command to light the upper half of the function switch pushbuttons. The computer then checks the rotating table for a backlog of commands. If a backlog exists, the DTVC routine will be called up. If a backlog does not exist, the DTVC will be set to "not busy."

The purpose of the clock servicing routine is to maintain a check on the special function routines. This is accomplished with clock interrupts that assure transfer of these routines at the appropriate time.

When the computer transfers control to the clock servicing routine, time is inputted from the real-time decoder. The computer applies this time to the clock table to find the routine that requires attention. If this function has output its last iteration, the computer clears this routine from the clock table and returns to normal housekeeping operation. If the routine is still available to be called, the computer updates the clock table and sets the clock for the next interrupt. Then it makes a return jump to the special subroutine that requires attention. After running the special subroutine, the computer checks to determine if the last iteration has been outputted for this function. If this was the last iteration, the routine is made unavailable for the next "call." The computer then checks the DTVC for availability. If the DTVC is not available for transmission, the computer returns to normal housekeeping operations. If the DTVC is available, the contents of the special routine storage locations are transferred into the output buffer, and control is transferred to the DTVC output routine. In either, case, the computer sets the appropriate routine flags to their proper positions.

The purpose of the exit routine is to return the computer operation to the point in the housekeeping routine where the interrupt occurred.

After the last required transmission is completed, the computer clears the E (error flag). If an interrupt has occurred during transmission of a command, the computer transfers control to the appropriate routine. (The clock servicing routine has first priority in this return.) If there are no routines that require processing, the I (interrupt) flag is checked. Then the computer sets the accumulator with the housekeeping data that was present when the interrupt occurred. Finally, the computer clears the interrupt lockout and makes a return jump to the housekeeping routine.

DATA TRANSMISSION AND VERIFICATION CONVERTER

OBJECTIVES

To familiarize the student with:

- a. Modes of operation.
- b. Theory of operation (block diagram).
- c. DTVC/computer interface.

INTRODUCTION

The Data Transmission and Verification Converter (DTVC) is an interconnecting communications device that provides long-distance serial data transfer between the computer and various remote units. Data flow between the computer and the remote units is maintained by a sequence of control signals. There are four DTVC units utilized in the ACE-S/C system, three in the uplink or command loop and one in the downlink or display loop. The DTVC's in the command loop relay the various commands from the computer to the stimuli generators located in the test bays. The commands are verified for correctness, and verification signals are then routed back from the test bay area to the command computer via the DTVC's. The selected DTVC accepts 12-bit parallel words from the computer, converts to serial format, and transmits as a 24-bit serial word over the hardlines. The DTVC receives a 24-bit serially coded word from the remote unit, assembles, and stores the first 12 bits, and then the DTVC performs a bit-by-bit check of the second 12 bits with the first 12 bits. The DTVC then presents a 12-bit, parallel-coded word to the computer whether correct or in error. When an error is detected, interrupt and status signals will be made available to the computer.

EXPLANATION

FUNCTIONAL DESCRIPTION

The DTVC operates under program control of a digital computer and communicates in parallel mode with the computer over a standard input/output communications channel. The DTVC communicates with other DTVC's or similar devices in serial mode over a long-distance communications link. Serial data is transmitted with 100-percent redundancy for verification by the receiving unit. The DTVC has three modes of operation,

410-0(107)

select transmit, select receive, and select interrupt. The unit remains in the monitor or receive mode until the computer is ready for a transmission. The DTVC operates under program control of a digital computer. The computer can select the DTVC to operate in any one of the following three modes:

- a. <u>Select Transmit</u> Prepares the equipment to receive 12-bit parallel words from the computer and transmit 24 serial bits for each word received on one of the available channels. The equipment remains in this mode until an interblock null is detected. After detection of the interblock null, the DTVC enters the monitor mode.
- b. <u>Select Receive</u> Prepares equipment to receive 24-bit words in serial mode on one channel, assemble and verify 12-bit words, and present the words in parallel to the computer. The monitor mode differs from the select receive in that the receive data will not be transferred to the computer until the select receive is enabled.
- c. <u>Select Interrupt</u> Prepares the equipment to monitor data on one channel and compares the upper six bits of the first word with the positions of a predetermined selection of six switches. If the two match and no error is detected, an interrupt signal is transferred to the computer.

In the transmit mode, data is received as a 12-bit parallel word and is transmitted as a 24-bit redundant serial word. Each word is placed in a register and the contents of consecutive stages of that register are transmitted over a preselected serial communications channel. When all 12 bits of the word have been transmitted, the contents of the register will be retransmitted to provide 100-percent redundancy with no delay between transmissions.

The DTVC in the receive mode receives a serial 24-bit word. The first 12 bits of each 24-bit word are loaded into a register. Each of the second 12 bits, as they are received, will be compared with the corresponding bit of the assembled word to verify the accuracy of the transmission. Upon detection of an error, an interrupt signal will be made available to the computer. All 12-bit words will be presented to the computer whether correct or in error. If insufficient bits are received to form a 12-bit word, the word shall be completed by the addition of 0's and presented to the computer.

TRANSMIT CYCLE

Figure 1 shows the DTVC operating in conjunction with the computer, acting as a communication link between the computer and the DTCS. In order for the computer

FOR TRAINING PURPOSES ONLY

RECEIVE DATA WORD 12-BIT START B, R, C. BIT 0 A TRANSMIT DEMODULATOR (BIT AND TIMING DETECTOR) FROM ONBOARD EQUIPMENT GATE BITS 0 - 11 SEQUENTIALLY TO A 24 SERIAL-BIT INPUT INPUT REQUEST INPUT READY FUNCTION READY OUTPUT RESUME START B. R. C. ERROR BAUD FUNCTION INFORMATION READY ON TRANSMIT INTERRUPT 30 OR 40 FUNCTION CODE (EF) COMPUTER MASTER CLEAR RECEIVE 24 SERIAL-BIT INPUT TO SERIAL CHANNEL BITS 12 - 23 MODULATOR (DRIVER) BITS 0 - 11 RECEIVE 12-BIT BITS 0 - 11 X REGISTER . DATA WORD BITS 0 - 11 BITS 12 - 23 REFER TO REDUNDANT WORD OR BITS 0 - 11 SENT SECOND TIME. NOTE: BITS 12 - 23 AND TRANSMIT PYRAMID Data Transmission and **Verification Converter Block** Diagram

Figure 1. DTVC Functional Block Diagram

FOR TRAINING PURPOSES ONLY

410-0(107)

ω

to provide data flow to the DTVC, preliminary conditions (channel selection, etc.), must be established between the two items of equipment and the DTVC must be placed in the transmit mode. This condition is attained through the use of control signals, which are essentially the raising or lowering of line voltages. Prior to entering a presentation on data flow and time-sequenced events, it is necessary that the following control signals be established:

- a. <u>Function Ready</u> This signal is generated by the computer indicating that an external function code is available for translation.
- b. <u>Information Ready</u> This signal is generated by the computer and is transferred to the DTVC indicating that a data word is available for transmission.
- c. <u>Output Resume</u> This signal is generated by the DTVC and is a response to receiving the function ready or information ready signals and indicating to the computer that the word has been accepted and the DTVC is ready for another word.
- d. <u>Input Ready</u> This signal is generated by the DTVC and is transferred to the computer indicating that the DTVC has a Check Status Reply (CSR) for the computer.
- e. <u>Input Request</u> This signal is generated by the computer and is transferred to the DTVC specifying that the computer is ready for an input word.
- f. <u>Interrupt</u> This signal is generated by the DTVC and is transferred to the computer indicating the status of the transmission. It causes the computer to interrupt the main program and to take action on the incoming word.
- g. <u>Master Clear</u> This signal is generated by the computer and is transferred to the DTVC to establish initial operating conditions.

If the computer has information to be transmitted over the serial communications channel, the computer must select the proper DTVC and determine which one of several serial channels is to be utilized. To facilitate this, the computer generates a 12-bit external function code, the most significant 6 bits select the proper DTVC, and the least significant 6 bits select the proper channel within the DTVC and the operation required. The following sequential steps indicate how the computer and the DTVC communicate to effect the proper conditions for a data word transmission (see Figure 2):

- a. The computer transmits a 12-bit External Function (EF) code to the DTVC over the data lines.
- b. A function-ready signal is transmitted to enable the DTVC to recognize the input function code.

FOR TRAINING PURPOSES ONLY

410-0(107)



Figure 2. Data Transmission and Verification Converter Operational Flow Chart

- c. The translation of the EF code places the DTVC into the select-transmit mode and selects the serial data channel to be utilized.
- d. An output resume signal is then transmitted to the computer to indicate that the DTVC is ready to receive the data word. The output-resume signal removes the function-ready signal, which, in turn, removes the output-resume signal.
- e. The computer generates an information-ready signal indicating to the DTVC that a 12-bit data word is available for transmission.

The DTVC is now in the condition to accept the 12-bit data word from the computer for transmission over the serial data channel selected.

The computer, after transmission of the EF code, places a 12-bit parallel data word on the output lines (see Figure 1). DTVC control logic (information ready) enables 12 parallel gates in the transmit gates in the transmit loop to facilitate the data transfer to the Assembly (A) register. The contents of the A register are immediately gated to the Exchange (X) register in parallel format. Upon completion of this transfer, the 12-bit word is now ready to be transmitted. The transmit or timing enable signal is sent from control to the timing unit to gate clock pulses out to the counter. The counter, a chain of flip-flops, sequentially gates the contents out of the X register, e.g., the contents of register No. 1 at time "1," register No. 2 at time "2," etc. By sequentially gating the contents of the 12-bit register, the parallel word is shifted to serial form. To perform the 100-percent redundancy required, the counter gates out the contents of the X register a second time. The serialized data is transferred to the transmit pyramid. The function of the transmit pyramid is to convert the 24-bit digital input to a split-phase modulated signal containing the intelligence transferred out of the X register. The output split-phase data is transferred to a line driver for transmission over the serial communications channel.

If the DTVC is utilized for transmission of data to the DTCS, then four 12-bit data words must be transferred out of the computer for transmission. In the previous discussion, a 12-bit word has been transferred to the DTVC and transmitted as a 24-bit redundant word. As the last bit is being gated out of the X register, the A and X register are cleared. The DTVC at this time generates an output-resume signal to the computer. This signal indicates to the computer that the first 12-bit word has been serialized, that redundancy has been performed, that the word was transmitted to the DTCS, and that the DTVC is ready for another 12-bit word. The computer

FOR TRAINING PURPOSES ONLY

generates an information-ready signal indicating to the DTVC that another data word is on the lines for transmission. For the second transmission the same steps will be repeated.

RECEIVE CYCLE

After the transmit cycle, the DTVC will, after an interword null, return to the monitor mode ready to receive data over the last channel selected; however, no data will be transferred to the computer until the select-receive circuit has been enabled. Prior to entering the receive cycle, the computer must transmit a 12-bit function code to the DTVC containing a select-receive instruction.

The split-phase data containing the information from the remote equipment is received by the bit and timing detector circuitry, which changes the incoming serial waveform to digital information and provides timing for word assembly and error detection. The output serial data is fed to the receive pyramid. Timing, a resultant of the first detected bit, is fed to the counter to start the gating cycle to transfer the serial data from the receive pyramid sequentially into stages number 1 to 12 of the A register. Each incoming bit causes the counter to change one step; therefore, bit No. 1 is gated into stage No. 1, bit No. 2 is gated into stage No. 2, etc., until all 12 stages have been set. This action converts the serial data to parallel data. The data is immediately gated into the X register as 12 parallel bits.

Bits number 12 to 24, that is, bits numbered 1 to 12 of the redundant portion of the 24-bit word, are gated into the error comparator to be compared with the 12 bits now contained in the X register. To expedite the data transfer, the contents of the X register are gated into the error comparator as the tenth bit of the redundant word is gated into the comparator. After comparison is made and no error is detected, the DTVC will generate an/interrupt 30 indicating to the computer that the redundancy checked. If redundancy failed, the DTVC will generate an interrupt 40 indicating to the computer that an error was detected.

As bit No. 12 is gated into the A register, the DTVC generates a control signal to the computer indicating that data is on line. If the computer is ready to receive data, an input-request signal will be generated by the computer to the DTVC. During the exchange of control signals between the computer and the DTVC, the transfer from the A to X register is effected. The contents of the X register will now be gated out to the computer by the receive enable from DTVC control.

Goon

DTVC INTERRUT

BAD

DTUC

A complete transmit and receive cycle has now been completed. Should the computer desire to transmit another word and/or words, an exchange of control signals will be initiated.

Study Guide

FOR TRAINING PURPOSES ONLY

DIGITAL TEST COMMAND SYSTEM

OBJECTIVES

The objective of this study guide is to familiarize the student with:

- a. Modes of operation.
- b. Theory of operation (block diagram).
- c. Spacecraft/DTCS interface.
- d. Application of stimuli.

INTRODUCTION

The basic function of the digital test command system (DTCS) is to receive serialdigital command data from a DTVC, decode the command data, convert the command data into stimuli and command signals, and route the commands and stimuli to the various systems under test. An additional function is to perform internal checks in decoding and selection to prevent double interrogation of equipment and to inform the ACE-S/C uplink computer of the status of the command transmission. The functional operation of each DTCS, external, carry-on, and ground service is the same; therefore, no specific one will be discussed.

A single DTCS consists of a receiver-decoder, baseplates, relay modules, analog modules, and a guidance and navigation buffer unit. The function of the receiverdecoder is to receive, format, time, and check the redundant serial command from the ACE-S/C uplink data transmission equipment. The baseplates house the relay and/or analog modules, and the baseplate logic performs decoding for baseplate selection. The relay modules provide relay closure outputs to the spacecraft or service equipment. The analog module is basically a digital-to-analog converter that produces an analog stimulus in accordance with the uplink test command.

DTCS CONFIGURATION

A single DTCS in its maximum configuration will contain one receiver-decoder, thirtytwo baseplates, and one guidance and navigation buffer unit. The thirty-two baseplates are divided into four groups of eight baseplates each. Each baseplate can contain four plug-in type modules. The plug-in modules provide system capability to be expanded or contracted to meet particular checkout requirements. Figure 1 shows the various

FOR TRAINING PURPOSES ONLY



410-0 (108)

FOR

TRAINING PURPOSES ONLY

Figure 1. DTCS Signal Flow

FOR TRAINING PURPOSES ONLY

N

modules that operate with the baseplate units. Conventional relay and latching relay modules provide programmable relay closures. Voltage mode digital-to-analog converter (VMDAC) modules provide programmable voltages. Current mode digital-toanalog converter (CMDAC) modules provide programmable currents. Each analog module contains one digital-to-analog converter, while each relay module contains sixteen relays.

The equipment within the DTCS is organized into various types of equipment groups. The various types include: receiver groups, baseplate groups, and command stimuli groups. The equipment groups designated here denote groupings of equipment associated with various types of enclosure units. (See Figure 2.)

The receiver group incorporates a receiver-decoder baseplate enclosure unit which houses a receiver-decoder, baseplate, and four modules. Each interconnected DTCS equipment configuration requires only one receiver group.

The baseplate groups incorporate a dual baseplate enclosure which houses two baseplate units and eight plug-in modules. The baseplate units in all enclosure units are connected in parallel to the receiver-decoder. The baseplate groups (either I, II, III, or IV) can accommodate a maximum of eight baseplates.

The command stimuli group consists of a baseplate unit and four standard modules, two of which must always be CR modules.

The command stimuli group has special stimuli equipment modules which include a 28-volt power supply module (power pack No. 1) a 9-volt power supply module (power pack No. 2), and a resistor bank module.

The principal types of stimuli outputs are:

- a. Selectable precision reference resistances.
- b. +28 vdc.
- c. ±9 vdc.
- d. Precision currents.

DTCS FUNCTIONAL DESCRIPTION

A DTVC interconnects with each DTCS receiver-decoder to transmit serial commands to the test bay. Each command sent to the receiver-decoder will contain 48 bits and

POSSIBLE DTCS EQUIPMENT CONFIGURATION



Figure 2. Possible DTCS Equipment Configuration

4

410-0(108)
410-0(108)

will consist of two words of 24 bits each. The first 12 bits of each word are repeated in the second half of that word to provide 100-percent redundancy in the message structure. Each 48-bit message therefore contains 24 bits of information (see Figure 3). The two 24-bit words are transmitted uplink a minimum of 4 microseconds apart and a maximum of 25 microseconds apart.

Upon receipt of the first word, the receiver-decoder gates 12 of the 24 bits into a register and checks for redundancy with the remaining 12 bits. The second word, transmitted approximately four microseconds later, is processed by the receiver-decoder in a similar manner. The command word is now in a 24-bit parallel format.

There are three different formats for the 24-bit command word. The type format depends upon the unit or module selected to supply an output to the spacecraft or ground service equipment. The data formats are:

- a. RELAY DATA FORMAT Used by the latching or conventional relay module. Generally this command is initiated by an R-START.
- b. ANALOG DATA FORMAT Used by the DAC module. This command is used for generating constant or varying analog signals. A C-START is generally used to initiate this command.
- c. GUIDANCE AND NAVIGATION BUFFER DATA FORMAT Used by the GN buffer unit. This command is initiated only by a K-START module.

Figure 4 shows the formats and functional assignments of each of the 24 bits to be decoded. Figure 5 shows where the bits are decoded for equipment or mode selection and indicates the various codes for particular functions. The following is an explanation of the use of the data bits in the various configurations.

CONFIGURATION FOR A RELAY COMMAND

<u>Reserved Bit</u> - Bit 23 is reserved and will always be a logical "1". V <u>Baseplate Group Select Bits</u> - Bits 19 through 22 are used to determine the legal baseplate group address.

<u>Baseplate Select Bits</u> - Bits 15 through 18 are used by the baseplate translation logic to select the appropriate baseplate.

<u>Module Select Bits</u> - Bits 12 through 14 are used to select the appropriate module. <u>Mode Select Bits</u> - Bits 10 and 11 are used to select the mode of operation. The modes of operation for the relay module are the load buffer memory mode (LBM) and the execute buffer memory mode (EBM). Normally, two 48-bit words are transmitted from

FOR TRAINING PURPOSES ONLY



6

410-0(108)



COMMAND MESSAGE FORMATS



-7

410-0 (108)

FOR

TRAINING

PURPOSES

ONLY

PROGRAMMING DIAGRAM



Figure 5. Programming Diagram

FOR TRAINING PURPOSES ONLY

00

the DTVC for each sequence of operations. The first transmission is called the LBM command. After receipt, this transmission is checked and loaded into a buffer memory register. The second transmission of data is called the EBM command. This transmission is checked against the LBM message previously transmitted. If the two transmissions compare, the command stored in the buffer memory register is executed. Relay Subgroup Select Bits - Bits 6 through 9 are used to select the appropriate subgroups, each of which contains four relays.

<u>Relay State Select Bits</u> - Bits 2 through 5 are used to energize or de-energize the appropriate latching or conventional relays.

CONFIGURATION FOR AN ANALOG COMMAND WORD

Note

An analog command word will be checked and decoded in the same manner as a relay command up to and including module selection.

<u>Sign Select Bits</u> - Bits 10 and 11 are used to determine whether the analog function is to be of a positive or negative polarity.

<u>Analog Output Bits</u> - Bits 2 through 9 represent the output voltage or current from the analog module.

<u>Mode Select Bits</u> - Bits 0 and 1 are used to select the mode of operation. The modes of operation are the load buffer memory mode (LBM), execute buffer memory mode (EBM) and the bypass buffer memory mode (BBM). In the LBM mode, data is loaded into a DAC buffer register. In the EBM mode the contents of the buffer register are checked against the LBM message. If the transmission compares, the DAC will provide an analog output. The BBM mode is used to provide an analog output immediately in direct response to a single command message. The function of this mode is to allow a higher rate of command words to be executed within a DAC to increase the frequency of an analog stimuli when generating a sine wave.

CONFIGURATION FOR GUIDANCE AND NAVIGATION COMPUTER WORD

<u>Reserved Bit</u> - Bit 23 is a reserve bit and will always be a logical "1". <u>G&N Select Bit</u> - Bits 19 through 22 are used to select the GN buffer unit. <u>GN Data Bit</u> - Bits 3 through 18 of the GN data format are transferred to the Apollo guidance computer.

FOR TRAINING PURPOSES ONLY 410-0(108)

Mode Select Bits - Bits 0 and 1 are used to select the mode of operation. The modes of operation are the LBM and the EBM modes. In the LBM mode the data bits are loaded in parallel into the buffer register. In the EBM mode the second data bit format is compared with the contents of the buffer register. If comparison is made, the contents in the buffer register are shifted serially into the Apollo guidance computer.

Figure 1 shows the flow of various return signals that are fed back to the receiverdecoder to indicate that legitimate bit transmission and equipment selection have been accomplished. The receiver-decoder encodes the return signals and produces a 12-bit check reply word which is sent redundantly to the DTVC. The check reply indicates that transmission and selection proceeded without error or, if an error occurred, the type of error is indicated. The error word codes are indicated in Table 1. Bit zero (2°) of the check reply word is used to give a gross indication of command transmission success or failure. In addition, if an error does occur, bits 2¹ through 2⁵ are coded to indicate the specific malfunction that caused the malfunction condition. Bits 2^6 through 2¹¹ comprise a code word used by the DTVC.

	Table	1	
Check	Reply	Format	

22	24	23	22	21	2	
)	0	0	0	0	0	Check Circuitry Error
)	0	1	1	1	0	Transmission Error
)	1	0	1	1	0	Group G&N Select Error
L	0	0	1	1	0	Baseplate Select Error
L	1	0	1	0	0	G&N Buffer Busy
1	1	1	0	0	0	Module Select Errors
)	1	1	1	0	0	Subgroup Select or DAC Sign Select Error
)	1	1	0	1	0	Mode Select Error (LBM-EX)
L 9	0	1	0	1	0	Buffer Check Error
L	1	1	1	1	1	No Error
2 ¹¹ through 2 ⁶ shall be fixed as follows (ICW)						

211 27 210 26 29 28

1 1 1 0 . 1 0

RECEIVER-DECODER UNIT

The receiver-decoder (R/D) receives the serially-transmitted, 48-bit word from the DTVC, places 24 of the bits in a staticizing register, communicates with the GN buffer unit and baseplate units, presents a parallel output of data bits to a selected baseplate unit or the GN unit, and redundantly transmits 12-bit serial status words back to the DTVC. The operation of the R/D is described in the following paragraphs. A simplified block diagram of the receiver-decoder is shown in Figure 6.

The bit detector and timing circuit senses each cycle of the input serial data and determines whether the cycle represents a "1" or "0" and whether the "1" or "0" bit is in the first-24-bit pulse train (word 1) or the second 24-bit pulse train (word 2) of the 48-bit transmission. In addition, the bit detector can detect the absence of data bits so that missing bits in the pulse train result in an error indication.

When all 48 bits have been received or when an error in the 48-bit format is detected, the control and clearing circuitry generates the enable signal for transmitting an error word and for clearing circuits to permit subsequent data bit reception.

The control and clearing logic contains the necessary circuitry for detecting a format work error caused by either a missing bit or by an improper inter-word space (message 4-25MS window). The inter-word space detector determines that the space between pulse trains (word 1 and word 2) is what is programmed. The circuitry contains a variable delay network that is adjusted according to the amount of time programmed between the last pulse of word 1 and the first pulse of word 2. The time can vary between four microseconds and 25 microseconds.

The control and clear circuitry also contains logic for detecting the end of word 1 and end of word 2. Detection of end of word 1 is necessary in format error detection and to implement proper routing of the bit detector outputs depending on whether word 1 or word 2 is being received. At the end of word 2 the baseplate group or GN selection circuitry is enabled.

. The staticizing register is a 24-bit exchange register that stores the actual message content of the 48-bit command. The redundant bits are not stored. The first 12 bits of word 1 are stored in one 12-bit section of the register. The next 12 bits of redundant data are compared bit-by-bit with the contents of the register. If the redundancy check fails, a transmission error signal is generated which is applied to the check status

FOR TRAINING PURPOSES ONLY

CELIAN

RECEIVER DECODER



Figure 6. Receiver Decoder

FOR TRAINING PURPOSES ONLY

12

410-0(108)

410-0(108)

register. If there is no error, the next 12 bits are stored in the second 12-bit section of the staticizing register and compared with the 12 redundant bits in the same manner. If an error is detected in the redundancy check of the second word, a transmission error signal is generated and an error code is transmitted to the DTVC. If no error is detected, an enable signal allows the R/D operation to continue as follows: Upon receiving enable signals from the control and clearing circuitry (end of word two) and the transmission error detector (NO ERROR) the baseplate group or GN select circuit decodes bits 19 through 22 and enables the baseplate group or GN select circuit to select a baseplate group or the GN unit. If only one selection is made by the baseplate group or GN select, the group check signal is produced and no error is indicated. Data bits 0 through 18 are furnished to a baseplate group or data bits 1 through 18 and their complements are furnished to the GN buffer.

The check word encoder encodes the various error signals, (buffer check return, mode check return, sign/subgroup check return, module select return, buffer not busy, baseplate select check, group check, transmit go) to provide a coded digital indication of no error or the type of error if an error occurs. The check word is registered in the check status register.

Checks to assure that one and only one of the 32 possible baseplates has been selected are performed by the baseplate select check and G/N select check logic. This logic monitors the outputs of the select decoders in all 32 baseplates. If more than one baseplate is selected, an error signal is sent to the error encoding logic to transmit an error code to the DTVC. If no error is detected, an enable signal (select check) is sent to the eight baseplates in the selected baseplate group.

The check status register (CRS) receives the error/no error signals from the check word encoder and sends a check reply word to the DTVC. The check reply is transmitted as a 12-bit word with redundant transmission in bi-phase form. Six of the 12 bits are of fixed format and the remaining six bits (Table 1) comprise the error. The CSR circuitry contains its own timing. A 1-Mc clock (not shown) is enabled by termination of a command message. The clock output triggers a 12-bit counter which causes the CSR to serially output the check reply word.

410-0(108) FOR TRAINING PURPOSES ONLY

BASEPLATE UNIT

The baseplate unit receives, decodes, and checks a portion of the data it receives from the receiver-decoder and gates the remaining data to the modules. The status check information is returned to the receiver-decoder. A simplified block diagram of the baseplate is shown in Figure 7.

The function of the baseplate select decoder is to determine if that baseplate has been addressed by the receiver-decoder. When a baseplate has been addressed, the baseplate select decoder circuit sends a return signal to the receiver-decoder and generates an enable signal to other circuits in the baseplate unit. Bits 15 through 18 are used for baseplate selection.

The module select decoder translates bits 12 through 14 into one of four possible combinations for one of four module selections. In addition to receiving the module select code, a baseplate select check signal from the receiver-decoder and an enable from the baseplate select decoder must also be received. Upon receipt of the required enabling signals and a valid module select code the module select decoder generates a select signal on one and only one of the output lines.

When the selected module receives the select signal it sends a select return signal to the module select check circuit. This circuit determines that one and only one module has responded to the select signal (has been selected). If the circuit is satisfied, a module select return signal is sent to the CSR encoder in the R/D indicating that no error was detected in module decoding, and a module select check signal is sent to all modules in the baseplate. If the circuit is not satisfied, an error signal is sent to the CSR encoder and a signal is sent to all modules in the baseplate to inhibit module operations.

After receiving the module select check signal the selected module will perform the operations described in the sections on the various types of modules. Status check signals from each module in the baseplate are received by the check return circuits in the baseplate. These circuits determine if one and only one module in the baseplate has performed the required operations (that is, selecting a subgroup or sign, selecting a mode, etc.). As the status check signals are received from the modules, the sign/ subgroup check return, mode check return, and buffer check return signals are sent to the receiver-decoder.

BASEPLATE UNIT



410-0(108)

410-0(108)

FOR TRAINING PURPOSES ONLY

RELAY MODULE

The relay modules provide relay closure outputs to the spacecraft or service equipment. The output may be a voltage from a power source in a system of GSE, from a <u>DAC</u>, or from a power supply in the DTCS. Each relay module contains four subgroups of relays. As pointed out earlier in this study guide, there are two types of relay modules, latching relay modules (LR) and conventional relay modules (CR). Each subgroup, whether LR or CR, contains four single-pole/double-throw type relays. The LR contacts remain closed after the voltage has been removed from the relay coils. The CR contacts remain closed only while voltage is applied to the relay coil. The relay module also contains circuitry to perform subgroup select, mode select, subgroup check, mode check, buffer, and buffer check circuitry. Diagrams of a CR relay module and a LR relay module are shown in Figures 8 and 9 respectively.

CONVENTIONAL RELAY (see Figure 8.)

The conventional relay module is selected to respond to input data bits when the associated baseplate unit furnishes a module select input. In response to the module select signal, the conventional relay module supplies a module select return to the baseplate. The module select return signal is used by the baseplate unit to check module selection. If two or more modules were erroneously selected, the baseplate unit would receive two or more module select return signals and determine that module selection was improper. If module selection proceeds properly, a module select check is received by the selected module from the baseplate. Upon receipt of both the module select and the module select check signals, decoding of the subgroup select bits proceeds. Then the decoding of subgroup select bits is complete and a subgroup check return signal is furnished to the baseplate unit indicating proper subgroup selection. This signal also enables the following subgroup action to continue. The conventional relay module has a load buffer memory (LBM) mode of operation and an execute buffer memory (EBM) mode of operation: LBM/EBM mode data bit decoding is performed to select one of the modes of operation. After a mode is selected and checked for one and only one mode, a mode check return signal is furnished to the baseplate indicating proper mode selection. The check signal is also used to enable the comparison of the relay state select bits with the corresponding bits in the load buffer memory. If the LBM mode was selected, the relay state select bits are loaded into the buffer memory when the mode check signal is generated.

CONVENTIONAL RELAY MODULE







Figure 9. Latching Relay Module

18

410-0(108)

If the input relay state select bits are the same configuration as bits being held in the buffer memory a buffer check signal is produced. The buffer check return signal is applied to the baseplate indicating a buffer comparison.

In the EBM mode, the data bits in the buffer memory are loaded into the execute memory via the transfer gates if the relay select bits of the EBM word correspond with the bits held in the buffer memory. The configuration of bits loaded in the execute memory determines relay energization configuration and thus relay closure output configuration.

LATCHING RELAY (see Figure 9.)

The operation of the LR module is similar to the operating of the CR module. In the load buffer memory, the data bits are loaded into the buffer memory. In the execute mode, the data bits in the buffer memory determine energization of latching relays if the relay select bits of the LBM word correspond with the bits held in the buffer memory. The bits determining the relay energization configuration determine the relay closure output configuration.

DIGITAL-TO-ANALOG CONVERTER MODULE

The voltage mode digital-to-analog converter (DAC) converts eight data bits plus two sign bits into one of 511 different voltage levels between -30 and +30 volts. The current mode digital-to-analog converter (CMDAC) converts eight data bits plus two sign bits into one of 511 different current levels, consisting of 256 current levels between 0 and 300 milliamperes at 0 to +10 vdc and 256 current levels between 0 and 300 milliamperes at 0 to -10 vdc.

A block diagram of the DAC module is shown in Figure 10. The logic circuitry is identical for both types of digital-to-analog converters. Each type of converter is capable of three modes of operation. In the load buffer mode (LBM), the incoming data is loaded into the buffer memory. In the execute mode (EBM), the data stored in the buffer memory is transferred to the execute memory, and is then converted into an analog voltage or current in the VMDAC or CMDAC output section. When the bypass buffer memory (BBM) is selected, the incoming data is gated directly into the execute memory.

VMDAC DAC OR CURRENT MODE DAC MODULE



Figure 10. VMDAC DAC or Current Mode DAC Module

FOR TRAINING PURPOSES ONLY

20

GUIDANCE AND NAVIGATION BUFFER UNIT

The guidance and navigation (GN) buffer receives data from the receiver-decoder in parallel form, stores the data, then changes the format of the data to serial form and sends it to the Apollo guidance computer (AGC).

The GN buffer unit receives the LBM word and the EBM word from the R/D unit. Data bits 3 through 18 of the LBM word are loaded into the buffer memory register. The EBM word causes the data bits to be shifted serially into the AGC. Data bits 1 and 2 are used for mode selection (LEM or EBM). The operation of the GN buffer is described in the following paragraphs. A simplified block diagram of the GN buffer unit is shown in Figure 11.

When the receiver-decoder unit selects the GN buffer, the buffer-not-busy circuit determines whether the GN buffer is shifting data into the AGC, or whether the GN buffer has completed the data shift-out and is ready to receive additional data from the receiver-decoder (buffer not busy).

Comparison is performed before the data is loaded into the buffer memory, so the buffer-check-return signal may or may not be generated. In either case, the incoming data will be loaded into the buffer memory. During the EBM word, the incoming data must be the same as the data stored in the buffer memory. If the incoming data is not the same as the stored data, then an error has occurred and no buffer-check-return signal is generated.

The execute control circuit determines when the GN buffer is ready to shift data into the AGC, then starts and controls the data shift-out. At the end of the EXC word, the 16 data bits stored in the GN buffer memory are shifted serially into the AGC. The shift-out is performed at the 1-kc rate, and lasts 16 milliseconds. At the end of this time, the execute control circuit is cleared.

The function of the counter is to determine when all the data has been shifted out of the buffer memory. The counter counts 16 shift-out pulses, then clears the execute control circuit. During shift-out the execute control circuit sends a buffer signal to the buffer-not-busy check circuit. GN BUFFER UNIT





FOR TRAINING PURPOSES ONLY

22

410-0(108)

DIGITAL TEST MEASUREMENT SYSTEM

OBJECTIVES

To familiarize the student with:

- a. Apollo PCM telemetry formats.
- b. Apollo/DTMS interfaces.
- c. Theory of operation (block diagram).
- d. Interleaver/ACE-S/C ground station interfaces.

INTRODUCTION

The primary purpose of the digital test measurement system (DTMS) is to acquire, condition, digitize, and interleave spacecraft and ground service equipment data and then to transmit this data over hard lines to the ACE-S/C ground station processing and display equipment. The DTMS is divided into four major equipment groups:

- a. Airborne (A/B) response system.
- b. Carry-on (C/O) response system.
- c. Servicing equipment (S/E) response system.
- d. Data Interleaving system.

Each response system contains commutating, encoding, and digital multiplexing equipment which is necessary to convert spacecraft and service equipment sensor outputs into a serial PCM signal. The three response systems outputs (airborne, carry-on, and service equipment) are fed to an interleaver that combines the three separate PCM input signals into a single interleaved (I/L) serial PCM output at a rate of 204.8 kilobits per second. The A/B PCM signal in addition to being interleaved with the other PCM inputs is also transmitted intact (at its original rate of 51.2 kilobits per second) to the ACE-S/C ground station. Figure 1 shows a simplified diagram of the digital test measurement system.

Note

Grumman Aircraft Engineering Corporation uses the generic prefix S92 when identifying DTMS equipment by model number instead of the C14 prefix used by North American Aviation, Inc. Therefore, the identification number of any unit

FOR TRAINING PURPOSES ONLY



Figure 1. Digital Test Measurement System

FOR TRAINING PURPOSES ONLY

6

N

described in this publication can be changed from the North American designation as used, by substituting S92 in front of the hyphenated three-number designator.

8BITS = 1WORD

The PCM bit stream output of the DTMS to the ACE-S/C ground station contains two types of data words - analog and event. The A/B and I/L PCM organization and formats are shown in Figure 2. Each data word, whether analog or event, contains eight data bits. An analog word represents only one analog measurement; that is, one sensor output is represented by a combination of eight PCM bits ("ones" and "zeros"). An event word, however, represents eight separate events, a "one" representing the occurrence of the event and a "zero" indicating the event has <u>not</u> occurred. For some given events, the opposite condition exists.

Each response system (airborne, carry-on, or service equipment) commutates the transducer output data at a rate of 50 prime frames per second and transmits the data at a rate of 51.2 kilobits per second with 128 words (analog or event) per prime frame. The output of each response system is applied to the interleaver and is commutated into a single serial bit train of 50 prime frames at 204.8 kilobits per second, with 512 words per prime frame. Thus, the interleaver commutates and transmits the PCM data to the ACE-S/C ground station at four times the input bit rate. The interleaver data is bi-phase modulated before transmission to the ACE-S/C ground station.

CARRY-ON RESPONSE SYSTEM

ſ.

The carry-on response system consists of a digital signal conditioner and multiplexer, an analog signal conditioner, a guidance and navigation analog signal conditioner, and a pulse code modulation system. The output format of the carry-on response system is 50 prime frames per major cycle - 128 words being equal to one prime frame at a rate of the 51.2 kilobits per second.

DIGITAL SIGNAL CONDITIONER AND MULTIPLEXER UNIT (C-14-211)

The digital signal conditioner and multiplexer unit time shares eight output lines from up to 320 digital input lines. The multiplexer divides the input lines into 40 groups of eight event inputs per group. Each group of eight events is referred to as an event word. The multiplexer samples the inputs, one word at a time in a time ordered sequence and sends the word on eight parallel lines to the PCM system.

0(110)

410-0(110)



Figure 2. A/B and I/L PCM Format

410-0(110)

Figure 3 shows a simplified block diagram of the digital signal conditioner and multiplexer unit. The counter and control bit network perform two independent functions. The counter will sequence through 50 unique states once per second to provide 50 prime frame timing signals. The word select logic generates enable signals representing selected word slots within selected prime frames to cause sampling of one of the forty 8-bit input words. The word select logic is controlled by the counter and by the sampling rate gates. The word select logic connects to the multiplexer gates to enable 8-bit words to be routed through the signal output network to the PCM system.

The signal output network contains the sampling rate gates, sync word and digital word standard logic, and the signal output logic. The sampling rate gates identify the primary gate control times during which the multiplexer may sample digital inputs. Sampling rate gates may be selected to cause the unit to sample event data at one sample per second, ten samples per second, 50 samples per second, 100 samples per second, and 200 samples per second. The 50,100, and 200 per second gates are presently not used, but are available for future expansion of the multiplexer. The sampling rate gates are driven by the primary gate control timing signal from C14-210 unit.

The digital word standard and sync word logic provide an 8-bit word with a fixed pattern for test purposes. This word will be inserted in word slot 121 of each prime frame. The circuit is also capable of providing a sync word in word slot one of each prime frame.

GUIDANCE AND NAVIGATION SIGNAL CONDITIONER AND SWITCHING UNIT (C14-213)

The guidance and navigation signal conditioner unit accepts up to 150 analog input signals from the guidance and navigation system. The unconditioned input signals are converted to a voltage level from 0 to 5 vdc that is proportional to the input signal. The conditioned signals are then subcommutated by three 50-channel subcommutators. In addition, 32 of the conditioned signals are applied to a switching matrix. The switching matrix provides a means of selecting conditioned analog signals, one at a time, to be sent directly to the PCM subsystem (C14-210). The switching matrix is controlled by commands that select a particular channel. These commands are developed by relays in the digital test command system. The output of the switching matrix is applied to the carry-on PCM system (C14-210) for high-speed sampling. Figure 4 shows a simplified diagram of the G&N signal conditioner and switching matrix unit.

FOR TRAINING PURPOSES ONLY

DIGITAL SIGNAL CONDITIONER AND MULTIPLEXER UNIT



6

FOR TRAINING PURPOSES ONLY

410-0(110)



410-0(110) FOR TRAINING PURPOSES ONLY

Each subcommutator can accept 50 analog channels in the 0- to 5-volt range and samples each channel sequentially upon receipt of an external timing signal, Primary Gate Control (PGC), from the PCM system (C14-210). Figure 5 shows a simplified diagram of a 50-channel subcommutator. The PGC inputs are fed to a ten input OR gate. The presence of a PGC signal causes the counter to advance to the next channel and sample that input channel. The major cycle sync pulse applied to the subcommutator causes the counter to reset to the channel 1 position. Each channel is normally sampled once each second, but it is also possible to sample each sample ten times each second.

ANALOG SIGNAL CONDITIONER (C14-212)

The analog signal conditioner unit (Figure 6) accepts up to 200 analog input signals of various amplitudes and frequencies and conditions them into a voltage level of zero to five volts which is proportional to the input signal. The signals are then applied to four 50-channel subcommutators for subcommutation at rates of one or ten samples per second depending upon the timing signals supplied by the PCM subsystem (C14-210). The output of each of the subcommutators is a serial train of nonreturn-to-zero (NRZ) pulse-amplitude-modulated (PAM) analog data that is routed to the PCM subsystem.

PULSE CODE MODULATION SYSTEM (C14-210)

The functions of the PCM system are to:

- a. Convert all analog data to an 8-bit digital word representative of the parameter input.
- b. Commutate preconditioned analog data.
- c. Multiplex the analog and event words into specific word locations within a major cycle.
- d. Convert the parallel digital data to a serial bit train for input to the interleaver.

Figure 7 shows a simplified diagram of the PCM system.

The PCM subsystem receives external timing signals from the data interleaver that regulates the entire operation of the carry-on response system. The external timing signals consisting of a 51.2-kilocycle square wave and a 1-pulse-per-second major cycle sync signal are used by the programer to develop 128 primary gate control pulses. The 128 primary gate control pulses are time coincident with 128 data words to make up a prime frame of data. The major cycle sync pulse occurs at the beginning of each major cycle to provide a zero time reference.

FOR TRAINING PURPOSES ONLY

410-0(110)

50-CHANNEL SUBCOMMUTATOR



Figure 5. 50-Channel Subcommutator (Simplified)

9



Figure 6. Analog Signal Conditioner Group (C14-212)

410-0(110)

FOR TRAINING PURPOSES ONLY



PCM SYSTEM



Figure 7. PCM System (C14-210)

FOR TRAINING PURPOSES ONLY

410-0(110) FOR TRAINING PURPOSES ONLY

The patchboard receives the 128 PGC's from the programer and forwards only those channels allocated in the PCM format for the operation and proper output of the carry-on response system. PGC No. 1 is used as a sync word enable pulse in the digital multiplexer. PGC 121 is used as a digital standard enable pulse in the digital multiplexer.

The function of the analog-to-digital converter is to convert the applied PAM data into eight-bit digital words. The control bit signal received from the digital multiplexer inhibits the output to the parallel-to-serial converter during those times when the analog-to-digital converter is not required to digitize analog data.

The parallel-to-serial converter receives parallel data from the A/D converter or unit C14-211 and transmits this data in an NRZ serial PCM train to the data interleaver.

SERVICE EQUIPMENT RESPONSE SYSTEM

The service equipment response systems performs the same functions for the service equipment and service module response signals as the carry-on system does for the command module or lunar excursion module response signals. The service equipment response system consists of an external signal conditioning unit and a spacecraft adapter. The external signal conditioning unit conditions analog signal voltages received from sensors or test points to a proportional 0- to 5-volt level, and event signal voltages to a 0- or 6-volt level. The spacecraft adapter receives the conditioned analog and event signals and converts these signals into a serial PCM format which is forwarded to the data interleaver. The spacecraft adapter has the capability of accepting 200 conditioned analog signals and 992 conditioned event signals. Figure 8 shows a simplified diagram of the service equipment response system.

MINIATURIZED DATA INTERLEAVING SYSTEM

The miniaturized data interleaving system (MDIS) performs the following functions:

- a. Supplies timing for synchronizing up to eight NRZ PCM systems.
- b. Receives and interleaves RZ PCM inputs. A. h.
- c. Receives and interleaves NRZ PCM inputs. Cho 210 provo 204.6
- d. Produces synthetic sync and ID code words.
- e. Transmits one interleaved serial output at 204.8 kilobits per second (bi-phase modulated).
- f. Transmits the two RZ inputs serially at 51.2 or 1.6 kilobits per second (biphase modulated).

FOR TRAINING PURPOSES ONLY

12

NRZ A. H. Y.Y.





410-0(110) FOR TRAINING PURPOSES ONLY

Figure 9 shows a simplified diagram of the data interleaver. In the Apollo application, only three of the possible ten inputs are used. The A/B PCM data feeds one of the two RZ inputs. The C/O PCM and S/E PCM data constitute two of the eight NRZ inputs.

Timing signals from the central timing equipment or airborne PCM system can be used to drive the internal timing circuits. In the event that neither of the external timing signals is used, or if the selected timing source fails, a phase-locked oscillator will provide the timing signals by operating as a free-running, crystal-controlled oscillator. Selection of input PCM signals and the timing signal source is made by a switching matrix. This matrix is normally controlled by remote switching via a DTCS; however, front panel manual switches are available for local control.

The programer receives the timing and enabling signals from the input circuitry and generates the necessary timing and control pulses for use within the MDIS. The programer also supplies data rate timing (51.2 kc) and major cycle sync (1 pps) via the output circuitry to each of the eight possible NRZ PCM data sources. In the present configuration the timing signals are applied to the carry-on response system and the service equipment response system.

The digital data to be interleaved is first conditioned and subinterleaved into four serial data trains. The data interleaver receives the data from the input circuitry and interleaves this data into a composite serial train. The interleaver also receives synthetic sync words to replace that normally supplied by a response system input if for some reason the data input has been deselected by the switching matrix. If the airborne or alternate RZ channel is open, it will be necessary to generate a synthetic sync word and a synthetic ID word. Figure 10 shows the input and output format of the interleaver. Only the first four sync words and the first ID word of the interleaver output are required by the decommutator in the ACE-S/C ground station.

The data outputs of the MDIS are converted to bi-phase formats in synchronism with timing signals from the programer. The bi-phase data is then conditioned by the line drivers for transmission by coaxial cable to the ACE-S/C ground station where it will be processed and displayed for spacecraft test engineer evaluation.

SUMMARY

The DTCS equipment that is described in Study Guide 410-0 (108) and the DTMS equipment covered by this study guide are frequently grouped together and referred to as the

FOR TRAINING PURPOSES ONLY

DATA INTERLEAVER SIMPLIFIED BLOCK DIAGRAM



MDIS DATA INPUT & OUTPUT FORMATS



Figure 10. MDIS Data Input and Output Formats

410-0(110)

ACE-S/C portable subsystem. Refer to Figure 11 which is a block diagram of the ACE-S/C portable subsystem illustrating the manner in which these systems interface with the ACE-S/C ground station, the Apollo spacecraft (S/C block) and to ground service equipment (service equipment block).

The ACE-S/C ground station interfaces are shown on the left side of the diagram. DTVC No. 1 outputs 24-bit serial commands via the terminal patch facility (not shown) to the C/O DTCS which converts the command into a stimulus and applies it to the addressed test point via the J-Box. The spacecraft response is routed through the J-box to the appropriate checkout signal conditioner which outputs the conditioned response to the checkout PCM unit where the conditioned response is digitized (if necessary) and commutated into the C/O PCM input to the MDIS.

The interface between the ACE-S/C portable subsystem and the ACE-S/C ground station is shown at the bottom left of the diagram. The I/L PCM and A/B PCM outputs of the MDIS are routed through the terminal patch facility (again not shown). The function of the terminal patch facility is to allow a given ACE-S/C ground station to service one of several spacecraft test bays. The video output signals (I/L PCM and A/B PCM) of the MDIS from the terminal patch facility are fed to a video distribution and tape transport control unit (VDTTC) located in the computer room of the ACE-S/C ground station. These two PCM signals along with the FM signal constitute the inputs to the data recording and display system. In subsequent lessons, this system will be described and analysed at a functional block diagram level.

ACE-S/C PORTABLE SUBSYSTEM



Figure 11. ACE-S/C Portable Subsystem

410-0(110)

FOR TRAINING PURPOSES ONLY
DATA ACQUISITION

OBJECTIVES

To familiarize the student with:

- a. Video distribution and tape transport control.
- b. Magnetic tape recorder/reproducer.
- c. PCM decommutators.
- d. FM/FM group.
- e. Direct access computer interface (DACI).

INTRODUCTION

The Data Acquisition and Decommutation Equipment (DADE) provides for the recording, synchronizing, decommutating, processing of programmed data, and distributing of the data transmitted from the spacecraft vicinity. Three data lines (A/B PCM, I/L PCM, and FM/FM) are routed to this equipment through a terminal patch facility. The DADE group is made up of the video distribution and tape transport control unit, magnetic tape transports, FM/FM equipment, and PCM decommutators. Figure 1 is a block diagram of the DADE.

The video distribution and tape transport control unit is the receiver and distributor of all incoming test data from the spacecraft test area. Three types of test data are received over separate transmission hardlines: (1) interleaved serial PCM digital words, (2) airborne PCM digital words, and (3) FM signals. The distribution of the received test data is accomplished by means of video distribution and tape transport control unit patch-panel assemblies and the appropriate patch-panel coaxial jumper connections. The distribution of the received data is as follows:

- a. Airborne PCM test data to one of the decommutators and to a recording channel on one of the three wideband magnetic tape recorders.
- b. Interleaved PCM test data to the other decommutator and to a recording channel on one of the tape recorders.
- c. FM test data to the FM discriminator and to a recording channel on one of the recorders.

The decommutator units synchronize with the PCM data they receive, decommutate it, perform limit checks, floating point checks, event transition checks, and convert it to several output forms that are then sent to the analog and event display units and to the display computer.

FOR TRAINING PURPOSES ONLY

Study Guide

The FM discriminator unit separates the test data contained in the FM signals it receives and it converts the data to analog voltages that are sent to the analog and event display units. The magnetic tape recorder units provide a permanent record of all test data received by the ACE-S/C system. The data recorded on magnetic tape can be played back as required. The playback PCM data is routed to the video distribution and tape transport control unit patch panels and is continuously distributed to the decommutator units. The playback FM data is also routed to the patch panels, but requires special patching connections to be sent on to the FM discriminator unit. The PCM test data received from the spacecraft test area via the terminal patch facility contains information obtained from sensors that are permanently installed in the spacecraft, from carry-on equipment that is removed prior to launch, and from ground service equipment. A composite signal containing all sensor information is developed by units in the spacecraft vicinity and is received at the input to the data acquisition and decommutation units as interleaved PCM test data. The test data obtained from the permanently installed spacecraft sensors also is received as a separate (second) PCM input and is called airborne PCM test data. Certain test data (e.g., outputs of vibration sensors), which is required in a raw form, is received in the form of FM signals.

VIDEO DISTRIBUTION AND TAPE TRANSPORT CONTROL UNIT

VIDEO DISTRIBUTION AND TAPE TRANSPORT CONTROL UNIT FUNCTIONS

The video distribution and tape transport control unit provides:

- a. The means to distribute selectively all incoming raw test data from the spacecraft test area, refined test data generated within the ACE-S/C system, and the support signals (time codes, voice, etc.) generated by the support equipment.
- b. The means to condition certain selected signals prior to their being recorded on magnetic tape.
- c. A magnetic tape recorder remote control switching capability.

The selective routing of test data signals is facilitated by patch panels. The signal mixer and reference mixer/oscillator subassemblies contained in the video distribution and tape transport control unit are used to modify certain selected signals prior to recording them on magnetic tape. The outputs of these subassemblies are routed to the magnetic tape recorders via the patch panels. The signal separator is used to process certain magnetic tape recorder playback signals prior to their distribution



Figure 1. Data Acquisition and Decommutation Equipment Functional Block Diagram

3/4

by the patch panels. The magnetic tape recorder relay control unit provides a means by which the magnetic tape recorder transport control unit may be remotely controlled from the computer complex console or from the tape search unit. This unit also is used to route the current status indications of the magnetic tape recorders to the computer complex console and to the tape search unit.

VIDEO DISTRIBUTION AND TAPE TRANSPORT CONTROL UNIT DESCRIPTION

The video distribution and tape transport control unit is composed of five physically identical patch panels. The routing of the signals available at the patch panel is accomplished by means of coaxial jumper cables. Some signals are available on more than one patch-panel connector, e.g., interleaved PCM test data. This availability is accomplished by means of T-connectors on the rear of the patch panel. The exact patch-panel jumper connections to be used are dependent upon specific test program needs and are not given here. With respect to maintenance, the patch panels provide a convenient and centrally located means to monitor many of the signals passed through the units of the ACE-S/C computer room.

The signal mixer, signal separator, reference oscillator/mixer, and magnetic tape recorder relay control units are functionally part of the magnetic tape recording equipment.

MAGNETIC TAPE RECORDER AND REPRODUCER UNITS

MAGNETIC TAPE RECORDER FUNCTIONS

There are three identical magnetic tape recorder units located in the computer room of an ACE-S/C system. They are used to record selected test data resulting from a spacecraft testing sequence. The recorded data is a permanent record of incoming PCM test data, FM test data, reconstructed decommutator PCM data, time code signals, and voice signals. The data stored on the magnetic tapes may be reproduced (played back) at any time to facilitate data reduction, ACE-S/C system preoperation checkout, and maintenance test procedures.

Each magnetic tape recorder is capable of recording and reproducing up to seven discrete channels of data. Each channel may record and reproduce data in either of two ways: Direct Record/Reproduce or Wide Bank Frequency Modulation (WBFM). The recorders are of modular construction and are designed for field modification to fourteen channels should greater capability be required at a later date.

MAGNETIC TAPE RECORDER INPUTS (See Figure 2)

All data signals to be recorded on magnetic tape are routed through the patch panels 'of the video distribution and tape transport control unit to the magnetic tape recorder units. Certain data, such as airborne PCM test data, is routed through the patch panels directly to a magnetic tape recorder. Other data, such as timing codes and voice, is first patched to a signal mixer unit (located in the video distribution and tape transport control unit), processed, and then patched to a magnetic tape recorder unit.

Each recorder also receives control signals from remote control units. The computer complex console contains three remote control units, one for each magnetic tape recorder unit. A tape search control unit (located in the tape recorder/computer time decoder and search control unit) also supplies remote control signals to the magnetic tape recorders. All remote control signals are fed to the magnetic tape recorders via a magnetic tape recorder switching control unit located in the video distribution and tape transport control unit. The switching function of the magnetic tape recorder switching control unit is controlled by the operator of the computer complex console.

MAGNETIC TAPE RECORDER OUTPUTS (See Figure 2)

All data signals reproduced (played back) by the magnetic tape recorder units are routed to the appropriate units of the ACE-S/C system by the patchboards of the video distribution and tape transport control unit. Certain test data (e.g., PCM test data) is routed through the patch panels directly to the appropriate ACE-S/C units. Some data (e.g., timing codes, voice, etc.) are first patched to a signal separator (located in the video distribution and tape transport control unit), processed, and then patched to an appropriate ACE-S/C unit.

MAGNETIC TAPE RECORDER DESCRIPTION

Each magnetic tape recorder provides seven channels for recording and reproducing wideband signal data. The tape used with the magnetic tape recorder is 0.5-inch wide, 1.0-mil thick, mylar-base magnetic tape on 14-inch reels. (For 14-channel operation, 1-inch tape is used.) The recorders have four record/reproduce speeds: 15, 30, 60, and 120 inches per second. Direct record frequency response is from 400 cps to 1.5 megacycles. Wideband FM record frequency response is 0 to 400 kilocycles. The basic components of the tape recorder are a precision four-speed tape transport, a control section to control the tape transport, and the record and reproduce signal circuits.

7



Figure 2. Magnetic Tape Recorder Input/Output Functional Block Diagram

FM GROUP

.

GENERAL

The telemetry system used to transmit FM data over an RF link is of the frequencydivision multiple type. That is, the radio-frequency carrier is modulated by a group of subcarriers, each of a different frequency. Each subcarrier is frequency modulated in a manner determined by the intelligence to be transmitted. One or more of the subcarriers can be modulated by a frequency-division multiplex scheme in order to increase considerably the number of individual data channels available in the system. The modulation technique used in this system is frequency modulation.

Multiplexing is a scheme of communication system organization whereby many independent channels of information are combined on a noninterfering basis into a common frequency band, for subsequent transmission over a band. In frequency division multiplexing, each individual channel occupies only a designated part of the band rather than the entire band as in time division multiplexing. Available within one carrier band are 18 subcarrier center frequencies, each capable of containing information up to a predetermined band limit.

The FM discriminator group is used in the detection of the FM signals transmitted from the spacecraft to the ACE-S/C ground station. The FM signal is routed to the magnetic tape recording units and to the FM groups simultaneously (see Figure 3). The recorded raw data on the magnetic tape unit is used for playback after testing and for the preservation of FM test data. During a spacecraft test, the received raw data is detected by the FM group, and the output signals representative of the input modulation frequency are recorded on analog paper recorders.

The FM group also contains a subcarrier oscillator and a frequency counter for checkout and alignment of the FM discriminators.

FM DISCRIMINATOR FUNCTIONS

The FM discriminator separates the incoming FM test data received from the video distribution and tape transport control unit and converts it to analog voltages that are sent to the analog and event display units. The unit contains 12 subcarrier discriminators. The inputs of seven of the discriminators are tied in parallel and receive a composite FM signal containing seven subcarrier frequencies from the spacecraft test area or a magnetic tape recorder via the video distribution and tape transport



Figure 3. FM Group FOR TRAINING PURPOSES ONLY

410-0(111) FOR TRAINING PURPOSES ONLY

control unit. The inputs of the remaining five discriminators are also tied in parallel and receive a composite FM signal containing five subcarrier frequencies from the signal separator assembly located in the video distribution and tape transport control unit. These signals received from the ACE-S/C system are AMR B-1, IRIG B, countdown time, voice, and a recorder reference signal.

PCM DECOMMUTATOR

The PCM decommutator (Figure 4) is capable of operating over a wide range of input telemetry data and can also accept a variety of types of PCM coding and various arrangements of parameter data specified by the telemetry system. To meet the demands of versatility in operating range and the requirements of recording, display, and data processing systems, the decommutator operates under program control. In the ACE-S/C configuration, both the interleaved and the airborne decommutation programs can be stored by the decommutator memory simultaneously. This gives the capability of rapid acquisition for each type of input available.

Although the decommutators are capable of versatility, only the operation pertaining to the ACE-S/C application will be mentioned. The interleaved and airborne inputs are of the configurations explained in the paragraphs pertaining to the digital test measuring system.

To obtain synchronization on the incoming data, the decommutator must be programmed with the criteria for bit synchronization, prime frame synchronization, and major cycle synchronization. Bit synchronization exists when the decommutator defines the exact same period of time as was generated by the telemetry system and decodes the weighted digit in its true form. Prime frame synchronization exists when the decommutator recognizes the beginning of a repetitive group of coded bits which divide a given amount of time into equal parts. In the ACE-S/C telemetry system this code appears 50 times per second; therefore, the system divides a one-second time span into 50 equal parity units. Major cycle synchronization is when the decommutator recognizes a specific prime frame and can then define the same real-time second as generated by the telemetry system. After completing these three steps of synchronization the decommutator memory is synchronous with the input data; therefore, the decommutation process can be initiated.



Figure 4. PCM Decommutator

FOR TRAINING PURPOSES ONLY

Study Guide

11

FOR TRAINING PURPOSES ONLY

Study Guide

The basic parts of the decommutator are the signal conditioner, the group synchronizer, the stored program processor (memory), the output rack, and the decom/computer interface (normal and DACI). All operate under program control of the particular program in operation.

SIGNAL CONDITIONER

The PCM signal conditioner (Figure 5) accepts the incoming split-phase pulse code modulated telemetry signal, conditions the pulses, and synchronizes with each bit to control the decommutator timing. The signal conditioner acts upon the incoming PCM signal to restore the data to a ground level and provide a stable output for the entire decom. This is performed to enable more efficient decommutation by the remaining sections of the decommutator.

Decommutation of the incoming PCM data can only be performed if the decommutator timing is synchronized with the bit rates of the commutation processes. Therefore, various time slots containing discrete words can be processed or decommutated to reproduce the exact data used in modulation during the commutation of the spacecraft parameters. The input signal to the decommutator when used in the ACE-S/C capacity is split, phase-C PCM data. This input signal is then converted to NRZ-C and RZ-M with the NRZ-C being sent to the frame synchronizer.

The signal conditioner consists of three principal subsystems:

- a. A dc restorer.
- b. A bit synchronizer.
- c. A bit detector.

The dc restorer accepts the serial data train as an input and supplies level-restorer signal to the bit synchronizer and bit detector. The bit synchronizer outputs are a clock at the bit rate of the data and timing signals from the system. The bit detector accepts the clock timing signals from the bit synchronizer and the data train from the dc restorer. It then produces reconstructed serial NRZ-C digital data as an output. Thus, the bit detector performs the basic decision of whether a binary "one" or "zero" exists for each bit.

For split-phase data, the clock defines only the carrier frequency although the bit location is subject to an ambiguity. The bit detector resolves this ambiguity, locates the bit position, and makes the bit polarity decision. The phase decision is made on the basis of several bits to reduce the probability of an error as a result of noise and



Figure 5. PCM Signal Conditioner

410-0(111)

FOR TRAINING PURPOSES ONLY

13

410-0(111) FOR TRAINING PURPOSES ONLY

uses as criteria the definition of SP-C data where two adjacent half cycles of a bit period are never equal.

GROUP SYNCHRONIZER

The group synchronizer performs two different types of synchronization. First, it must establish prime frame synchronization and then major cycle or ID synchronization. The information used as criteria to perform these functions must be programmed in memory and callup as instruction for the synchronizer as follows:

- a. Prime frame length.
- b. Prime frame pattern.
- c. ID counts up or down.
- d. Location of ID word.
- e. Number of errors accepted in synchronization.
- f. Number of prime frames to be checked.
- g. ID MSB/LSB first.

The serial data from the signal conditions is shifted through a shifter register (accumulator) of the frame synchronizer (Figure 6) where a bit-by-bit comparison of the input data is made with the pattern and length placed in storage after memory callup. When the pattern of the prime frame sync word (32 bits in ACE-S/C) matches the stored pattern, a first prime frame sync signal is generated and enables the check mode of operation. Heretofore, the synchronizer has been in the search mode looking for a correlating pattern. This first prime frame sync signal not only enables the check mode but informs memory that a pattern has been found. Since it is highly possible that a sync pattern can be found any place in a prime frame with an arbitrary group of data bits, memory must instruct the frame synchronizer where the next pattern is located. To do this, it generates a signal call operative which enables a prime frame sync pulse to be checked the next time it should appear. If the first sync pulse was a valid one, then the next prime frame sync pulse should fall within the operative; however, if the first sync pulse was invalid, it is extremely unlikely that at the same time in the next frame an arbitrary group of 32 bits will match the pattern and generate a sync pulse; therefore, the pulse would not fall within the operative and would generate an error. If this exceeds the number of errors allowed, then the system returns to the search mode to obtain the proper sync word.

After the proper sync word is obtained and the check mode entered, the synchronizer checks the sync word with the pattern a predetermined number of times to establish



Figure 6. Prime Frame Synchronizer

15

Study Guide

that proper synchronization has been obtained. After this mode, the ID synchronizer is enabled.

The function of the ID synchronizer (Figure 7) is to enable the unit to begin decommutation as readily as possible. Memory instructs the group synchronizer where the ID word occurs and enables the ID word to be detected. This detected word is sent to memory control where it jumps the memory sequence to the prime frame detected. At this point, major cycle sync has been obtained. Each prime frame contains an ID word and during this time slot the new ID is checked against the updated contents of the synchronizer. If these two do not correlate, the ID synchronizer returns to search.

STORED PROGRAM PROCESSOR

The stored program processor (Figure 8) provides storage for key instruction words used by the group synchronizer DACI and the output rack for processing data under program control. It also stored synchronized code information that enables the group synchronizer to get in step with the data train and to reacquire synchronization with a minimum of words of synchronization being lost. The stored program processor consists of random-access, core-memory, input/output devices for formatting, control logic for loading and unloading instructions, and a memory control panel for entering or selecting data manually. The core-memory has a storage capability for 8192, 40-bit words.

The stored program processor is capable of operating on one decommutation program while loading another into the memory on a priority basis. This is accomplished by arbitrarily dividing the core memory into eight program stored sections designated 1 through 8. If this arbitrary division is adhered to, each section of memory is capable of storing 1024, 40-bit words. Of course, it is entirely possible to have only one or two programs take up the entire 8192, 40-bit storage locations.

A program can be loaded into the stored program processor from a digital computer, the paper tape reader, or manually from the program control panel. For the program entry, a three-bit address for starting the loading is the first word in a given program. Thereafter, the stored program processor modifies the address for sequential loading of memory slots. A program can be loaded into one program section of memory, while the stored program processor is operating from another program section, provided the word being decommutated has a word length of at least seven bits.







18

410-0(111)

FOR TRAINING PURPOSES ONLY

Study Guide

Study Guide

FOR TRAINING PURPOSES ONLY

410 - 0(111)

Program instruction words from a computer and the paper tape reader are formatted into the instruction word format used by the stored program processor. If the instruction word is from a computer, it is furnished in the form of four words or characters, one 4-bit and three 120-bit words or characters. The words or characters are formatted into a 40-bit word by the formatting gates and the 40-bit word is loaded into the data register. Word formatting is controlled by the format counter and decoder. This functional area pulses the correct set of formatting gates based upon the number of words or characters transferred. For the first four-bit word or character transferred from the computer, the format counter pulses the first four most significant bit formatting gates. It notes the fact that a word has been transferred and when another word is ready, pulses the next set of formatting gates (corresponding to the 12 next most significant bits of the instruction word). Upon completion of word formatting, the word is transferred to the core-memory register by the master load gates. The word is subsequently stored in the address designated by the program. When this word is stored, the computer sends another instruction word, load/unload counter modifies the address, and another word is stored in the next sequential address of the memory. The process continues until a complete program is loaded.

A similar process is required for loading instruction words from the paper tape reader. The starting address for program loading is the first word on the tape. The tape reader furnishes input words in the form of one four-bit word or character and six 6-bit words or characters. These input words are formatted and stored in the memory by the same process described for computer inputs. The process continues until a completed program is loaded. Instruction words entered from the program control panel do not require formatting. The starting address for storing the words is manually entered at the program control panel. Thereafter, the load/unload counter modifies the address for sequential loading of the memory. No manual loading can be performed during decommutation; however, the address of stored instruction words can be changed using controls on the program control panel.

During the entire loading process, each 40-bit word is checked for parity and if an odd number of "ones" exists in the formatted word, a "one" is added in bit position zero. Thus, the stored program processor incorporates "even ones" parity.

The stored program processor operates in two basic modes - preacquisition and decommutation. In the preacquisition mode, all the criteria is called out of memory and is the criteria for memory control in the same manner discussed in the synchronizer.

Memory is controlled during the decommutation process by block counters which are jammed to the starting addresses of the data contained in prime frame one and prime frame two of the telemetry input format for a particular program. These block counters fall into two categories, ID and control and routing (Figure 9). When the ID word is verified, the ID block counters cause the block counters used for control and routing to be jammed to the address of the prime frame when major cycle synchronization is found. At this time, the exact location of every word is known in the major cycle.

The control and routing format contain instructions for memory control and the formatting process performed by the output rack. The next block instruction causes the block counters to access the next memory location applicable to the incoming data word. The instructions contained in a memory location are for the next incoming word. Therefore, the decommutator operates one word time ahead of the incoming data.

OUTPUT RACKS

The output format devices (Figure 10) are used to convert the NRZ-C data into the proper format determined by the equipment to receive the data word. The gating of the data words into the proper output register is determined by the program in the stored program processor. The output format control unit receives serial reconstructed NRZ-C data from the output of the PCM signal conditioner, timing from the group synchronizer, and program control instructions from the memory. The output format control unit provides analog and digital data outputs to the external units. Parallel binary and binary-coded-decimal (BCD) data are also provided to data displays on the system control panel, which gives the operator the capability of displaying any incoming data word in its time binary or decimal value.

The outputs of the digital-to-analog converter circuit are routed to the event distribution and recorder patching unit to be distributed to the analog recorders located in the computer room. The data routed to the downlink computer comes from the least significant bit truncated register and DACI where they are transferred as 12-bit and 30-bit parallel data words respectively. The data transmitted to the decommutator distribution and event storage and distribution unit, in the control room, are routed through the MSB parallel register. The addresses (from memory) applied to the data of the MSB parallel register are routed through the data address register. The remaining output devices are not used in the application with ACE-S/C.



Figure 9. Program Word Formats

FOR TRAINING PURPOSES ONLY

21

410-0(111)

FOR TRAINING PURPOSES ONLY

Study Guide

410-0(111) FOR TRAINING PURPOSES ONLY





22

DIGITAL-TO-ANALOG CONVERTERS

The digital-to-analog (D/A) converters convert the incoming digital data to analog voltages to be distributed to the event distribution and recorder patching unit. The decommutator contains a total of 60 D/A converters of which 40 are used in the transmission of data to the recording and patch unit. The D/A converters are selected by the stored program processor. The memory instruction performs three functions in controlling the D/A devices:

- a. Controlled designation of which D/A will convert the incoming data word.
- b. When the D/A will be selected.
- c. Synchronization of gating the incoming data into the converter.

MSB/LSB PARALLEL OUTPUTS

The function of this group is to provide as an output all data words in both MSB and LSB first formats at the same time. Any data word may be from 4 to 64 bits long. The different conditions under which the registers can accept data are:

- a. No parity or word synchronization code bits in the data word and either MSB or LSB first.
- b. Parity and word synchronization code bits present in the data word either at the beginning or the end of the word and either MSB or LSB first.

The program of the system being monitored dictates the mentioned conditions. The data is serial when received and is converted to parallel by a formatting process.

After the entire word has been formatted, the down data word is shifted left the number of places corresponding to the number of parity and word synchronization code pulses contained in the word. The action takes place if word parity and word sync are used. In the ACE-S/C application, word parity and word sync are not used.

The MSB formatting and parallel registers are composed of 33 stages while the LSB formatting and parallel registers are composed of 64 stages. The reason for this is that it is only necessary to acquire one more MSB bit than half the word length to determine the value of the measurand while the entire word in LSB form must be gathered to determine which bits are the MSB of the word.

Also contained in the MSB/LSB parallel registers logic is the 12-bit display address register which feeds the ESDU and the console control logic circuits. This address

410-0(111) FOR TRAINING PURPOSES ONLY

with a read pulse is gated out in parallel with the contents of the MSB/LSB parallel registers.

MSB/LSB TRUNCATED OUTPUTS

Truncate means to cut up or cut off. Truncation circuitry is used when the decommutator operates in conjunction with 160G computer. If the incoming data word is too large, the truncated output will be in characters whose lengths are compatible with the computer input. This allows the decommutator to maintain its versatility and still allow the remaining units of the ACE-S/C system to function at their specific capability. The MSB/LSB truncated unit operates basically identical to the MSB/LSB parallel unit with the exception of a calculator which divides the incoming word by a factor of two until a remainder is obtained. This remainder is outputted as the first truncated character which will vary in length with varying lengths of incoming data. However, the remaining characters will all be the same dependent upon the initial size of the incoming data word.

The ACE-S/C application utilizes the least significant truncated circuits and outputs the data words to the decommutator/computer interface unit.

DECIMAL AND BINARY DISPLAYS

Three decimal displays and one binary display provide the capabilities for selecting and displaying the decimal and binary values of words from registers in the output racks.

The three decimal displays operate independently; that is, all three can be used concurrently to select and display one word or three different words. Any word in the data train up to octal 7777 (decimal 4095) can be selected on any one display. The decimal displays are wired for word values up to 999,999; however, the displays only contain modules for word values up to 999.

The binary display provides the capabilities for selecting and displaying any of 4095 data words. A 64-bit word plus parity can be displayed. In addition, word synchronization is also displayed.

The decimal and binary displays function identically, except for the fact that the decimal displays must decode the BCD inputs. The decoding operation performed for decimal displays can be ignored when evaluating the operation of the binary display.

DECOMMUTATOR/COMPUTER INTERFACE

The computer interface unit is designed so that a free interchange of data and instructions can be carried on between the Radiation Series 540 PCM acquisition and stored program decommutation system and a digital computer. The unit converts the logic level of the computer to that required by the computer. The unit also decodes the various instructions from the computer and causes the decommutator to comply with them. In addition, the unit provides a path through which a complete program can be inserted into the decommutator memory or an existing program can be modified or checked. All interchange between the computer and the computer interface unit is performed by parallel transfer.

The decommutator sends two types of words to the computer through the computer interface unit. Both types of words are sent upon request of the computer. The two types are truncated data words (characters) with a maximum of 12 bits per character and a status word. The truncated characters are routed from the decommutator LSB truncated character register through the computer interface unit which converts the logic levels to be compatible with that required by the computer. The status word is partially generated within the decommutator and tells the computer the status of the decommutator at the time of receiving the request from the computer.

All data transferred into the computer memory from the decommutator and all data transferred from the computer into the decommutator memory must be under the direct and complete control of the computer program. The decommutator can be synchronized on the incoming data train and, in effect, to the entire decommutation process. However, no data is transferred through the interface unit until requested by the computer. Initiation of this transfer is effected by control words and control functions generated by the computer.

DIRECT ACCESS COMPUTER INTERFACE (DACI)

The DACI is essentially in parallel with the decommutator normal interface circuitry (Figure 11) and enables the ACE-S/C decommutator to input addressed data directly into the 169G external memory unit. The decommutator output circuitry (normal or DACI) will be selected by the preacquisition block of the decom program. The DACI is then enabled by the 160G downlink computer. The decommutator control and routing

FOR TRAINING PURPOSES ONLY

Study Guide

words defines which PCM words are to be transferred to the 169G. The information transfer from DACI to the 169G will be as follows:

a. 17 address bits: 4 Memory bank select

13 Memory address

- b. 13 data bits:
- 2 Blank
-

8 Data

3 Flags

The decommutator also has the capability to perform parameter limit checks, floating point checks, and event transition checks (Figure 12). The limit checks are performed on the upper and lower parameter values for each PCM word determined by the loaded decommutator program. The values for the upper and lower limits are predetermined and are preprogrammed into the decommutator memory prior to testing. Thus, the values provide unique checking for each telemetry word input into the PCM decommutator system.

The floating point check is performed on those parameters where the change is of significance rather than the exact upper or lower values. In this capability the last known value of a parameter is used as the next point of reference, thus the floating point technique. The event transition checking is performed in the same manner as the floating point technique in that the last event word input from the telemetry system is used as the next reference.

A flag is sent to the computer as part of the data word (Figure 13 bits 10, 11, 12) to tell the computer any time the limit check or floating point check was out of tolerance.



27

Study Guide

FOR TRAINING PURPOSES ONLY

To 169G

Flag Generator

Study Guide



MSB Parallel

Registers

Status Control and

Routing



► To DDU/ESDU

Fixed Limit

Check

Logic

Floating Point

Check

Logic

FOR TRAINING PURPOSES

VINO

Serial

from

PCM Data

Group

Synchronizer

Stored Program

Processor

(Decom Memory)



29

Study Guide

DISPLAY COMPUTER

OBJECTIVES

To familiarize the student with:

- a. Data inputs.
- b. Limit comparison.
- c. Generation of engineering units.
- d. Problem solving.
- e. Programing.
- f. Downlink programs.

INTRODUCTION

The display computer is a stored-program, high-speed, single-address, paralleloperation, modular, electronic data processor that has the same operating characteristics as the uplink or command computer. The primary functions of the display computer are data reduction, analysis, and preparation for display of test data derived from spacecraft tests.

The display computer receives raw data in the form of event and analog words from the decommutator units via a 171G input/output module. The computer performs the following functions in processing this data:

- a. Formatting of the data for processing.
- b. Comparison of words with programed values to determine whether the data is within predetermined limits.
- c. Conversion to engineering units.
- d. Comparing event status with previous status.
- e. Preparing and formatting processed data for display.

After the input data has been processed and formatted, the display computer selects the downlink DTVC and then transfers the parallel data words to the DTVC for transmission to the Symbol Generator and Storage (SGS) Unit. The local DTVC operates in conjunction with a Digital Communications and Control Unit (DCCU) to provide a data transmission path to the display producing unit. The processed data received by

the DCCU is then transferred to the SGS. The SGS stores the incoming data and converts the data into alphanumeric characters for display on the requesting CRT modules.

The incoming PCM test data is stored in computer memory and is then processed in preparation for display on an alphanumeric CRT display unit. Processing of the incoming PCM data includes:

- a. Selection of specific data from the incoming data.
- b. Comparison to determine whether the measurement represented by a digital word is within preprogramed limits.
- c. Conversion to engineering units.
- d. Conversion and formatting test data for display.
- e. Storage of selected parameters for trend analysis, etc.

In addition to driving the alphanumeric CRT displays, the display computer also supplies a number of peripheral units with processed data. The peripheral units include a high-speed printer, an X-Y plotter, tape unit, card punch, and a typewriter. These units can be used for the setup and checkout of the computer complex in preparation for a spacecraft testing sequence, as well as to provide a display and recording capability during the actual test operations. The general functions and operations of the display computer are best described in terms of the computer program.

The Supervisory Executive Program (SEP) organizes the display computer (as well as the command computer) program in preparation for processing test data. The SEP is recorded on a test file tape, along with certain common programs (such as ACE-S/C self-test programs), and all display executive programs that are part of a test series, spacecraft test subroutines, and test parameters. The test file tape may be placed on a command computer tape unit. The command computer then interrupts the display computer by means of a SEP bridge punched card placed in the display computer card reader. The SEP portion of the test file tape then selects a display computer executive program and loads its appropriate subroutines and parameters into the display computer memory. Prior to or during loading, any display computer parameter on the test file tape may be changed by using change cards. Changes called for by the change cards are not limited to load time but may be made at any point during the test sequence.

An ACE-S/C self-check program, included as part of the SEP, is readily accessible to the display computer. This self-check program provides the assurance that the

required ACE-S/C subsystems are in the ready mode prior to the actual test run and that they have the proper operational status while a test is in progress. Indications of a no-go nature are provided by this program, along with sufficient additional information to enable program callup of selected diagnostics for prompt decision as to corrective actions.

It is the purpose of the executive routine to control the sequence of data processing by the display computer. This routine may be divided into three major sections:

- a. Primary initialization.
- b. Subroutine linkage.
- c. Summary filing.

Primary initialization insures that all registers, counters, and other indexes used by the display computer executive routine are cleared and reset to the start conditions. This prepares the display computer for an interrupt from the decommutator units to commence the loading of PCM test data for subsequent processing. The subroutine linkage portions of the executive routine consist of fixed sets of instructions that control the exit from one subroutine and the entry to the next subroutine. By using the subroutine linkage instructions, the processing order is flexible and is easily changed, since only the linkage routines need to be rearranged to create a new and different subroutine processing order. Before the entry to a subroutine, the subroutine linkage instructions supply the new subroutine with the address of the first parameter for the data word to be processed by that particular subroutine. Upon exit from the subroutine, the linkage routine determines if there are any more data words to be processed by the subroutine and will cause the subroutine to repeat if necessary. Processed data, derived from display computer subroutine operations, is stored and transmitted to the appropriate peripheral units under the control of the summary filing portions of the executive routine.

In the following paragraphs, thumbnail sketches of some typical display computer subroutines are given. It is not the intent to list and describe every subroutine available in detail, but rather to demonstrate the function of the display computer in relationship to the alphanumeric display equipment and the overall ACE-S/C system.

The purpose of the PCM telemetry data subroutine is to allow the entry of PCM digital test data from the decommutator units into the display computer for processing (see figure 1). The data input sequence is initiated by an interrupt signal from the PCM



decommutator equipment. The incoming PCM data, in the form of 8-bit parallel event and analog words, is buffered into two separate areas of auxiliary memory. One prime frame of PCM data (512 eight-bit words) is read in at a time. There are 50 such prime frames to be read in each second. The following steps are required for a typical read-in process:

- a. Read first prime frame of 512 words into memory area number 1.
- b. Begin read-in of second prime frame of 512 words into memory area number 2 and start processing data in memory area number 1.
- c. Begin read-in of odd-numbered prime frames of data into memory area 1 and start processing data in memory area 2.
- d. Input process continues, inputting 50 prime frames per second alternately into areas 1 and 2.

This switching type of buffer allows time to transfer selected data to be processed, from one input area to a relocatable data table, while filling the other input area. Identification of data to be transferred is based primarily on the PCM data prime frame count. This program subroutine tests for synchronization in the last input area to receive test data. If an in-sync condition exists, all data to be processed is transferred to a relocatable data table. If a lost-sync condition exists, the relocation of data is bypassed and a flag is set. A real-time clock reading is stored in the computer so that a specific time can be related to each data prime frame received.

The engineering units subroutine converts the received PCM test data to the proper engineering units, determining analog percentages, and make limit checks. The data is processed in one of three ways:

- a. Type A the average of every Nth point.
- b. Type B process every Nth point.
- c. Type C process on significant change.

Prior to read-in of any PCM test data, all the necessary information required to convert the incoming PCM test data associated with a specific measurement will be read from magnetic tape and stored by the display computer. This information consists of a polynomial (or appropriate degree), the coefficient constants of the polynomial, the location of the binary points of the coefficients, the binary point of the upper and lower limits, and the specific upper- and lower-limit values. The polynomial and its associated coefficients are the mathematical expression for a curve to which the PCM data

is fitted. The general polynomial form is given as:

$$A_{1} + M[A_{1} + M[A_{3} + M(A_{4} + A_{5}M)]]$$

where A_0 , through A_5 are the coefficients and M is the 8-bit PCM data word associated with the measurements.

The display computer solves the polynomial expression and generates one 12-bit word. This 12-bit word is a solution to the polynomial expression and is in engineering units. The engineering units are appropriate for the measurement that was represented by PCM test data input. The engineering unit value for the measurement is stored and can be transmitted to the SGS for display on a CRT.

Following the conversion to the appropriate engineering unit value, the display computer may check this value against preprogramed limit tolerances. As previously stated, the specific upper-limit and lower-limit values of each measurement to be processed are read into the display computer prior to acceptance of any PCM test data. First, the measurement value is compared with the upper-limit value and then the lower-limit value. If the measurement value is within the tolerance limits, no further computations are made. If an out-of-tolerance condition is indicated, the display computer will flag the measurement value and cause this value to blink when displayed on a CRT.

Certain PCM data words are converted to engineering units and then only checked for an in-limits or out-of-limits indication. These measurement values are compared with the maximum and minimum values of operational limits in percent of full scale. The measurement values are compared, each time they are received, with the previous value to determine if they are going out of limits or coming into limits. Each time a measurement value changes status (goes out of limits or comes into limits), it is stored for transmission to the SGS and then to a CRT display.

The purpose of the event status check subroutine is to extract specific event information from certain incoming PCM test data words and to determine its state and disposition. Based on the bit position of the event, the display computer extracts the bit from the PCM data word. The computer then compares the state of this bit with the previous subframe state. If a transistion has occurred, the present state (on/off condition), the time of transition, and a flag indicating that a transition has occurred are stored for output to magnetic tape recording and printout. The programer also can cause the present on/off condition to be sent to the SGS and then to a CRT display. If a transition has not occurred, the present state of the event will not be updated on the CRT display since the previous state is still valid.

The purpose of the output data for CRT display subroutine is to output (via an external buffer) the information required to update the SGS memory and thus the CRT displays. This subroutine is required for one of the following types of CRT displays:

- a. A display of the engineering units of a measurement.
- b. A display of a measurement requiring only an in-limits or out-of-limits indication.
- c. A display of an event requiring only an on/off or open/closed type of indication.
- d. The display of an event and the time of a transition of state occurred.
- e. The display of decommutator loss of sync or its removal.
- f. Any other display of parameters deemed necessary by the programer to fulfill the current test requirements.

The data that the display computer has identified and processed is stored in the common output area of memory for scope updating as required. By means of a parameter table look-up, the stored parameters are identified fully and the CRT character code and positioning codes are prepared. The display will output the stored parameter values, CRT positioning codes, and any other instructions necessary for proper CRT displays as blocks of data. The blocks of data are groups of sequentially outputted 12-bit parallel words.

The purpose of the store information for periodic output subroutine is to store the processed data and its associated time codes, in/out limit indications, CRT display X and Y coordinates, status, and engineering unit values. This data is converted to a form appropriate for printing or plotting and is stored in a common output area. The data is also stored in the common output memory area in an unprocessed form for output to magnetic tape recorders. This data is transmitted to the appropriate peripheral units at the end of each prime frame (i.e., at the completion of processing 50 subframes), which occurs once every second.

The callup alternate CRT display data subroutine is used after each subframe is processed when a check is made by the display computer to see if a callup of alternate display data has been requested. When a callup has been requested and is recognized by the display computer, the time of callup is determined and is used to search for

the alternate displays requested. At the completion of the read-in of the alternate displays and the associated parameters and data, the new CRT character display codes are stored and transmitted to the SGS in the same manner as normal processed data.

Figure 2 contains flow charts of the downlink control program illustrating the various functions that are performed during the data input and processing cycles. Figure 1 contains a typical example of one of the subroutines utilized in the downlink data processing cycle.
410-0(112)



FOR TRAINING PURPOSES ONLY





FOR TRAINING PURPOSES ONLY

DATA TRANSMISSION DIGITAL COMMUNICATIONS AND CONTROL UNIT

OBJECTIVES

To familiarize the student with the Digital Communications and Control Unit (DCCU) and review the Data Transmission and Verification Converter (DTVC).

INTRODUCTION

The downlink data transmission system consists of a DTVC and a DCCU. This equipment facilitates the data transmission between the downlink computer and the Symbol Generator and Storage (SGS) Unit. The DCCU (Figure 1) is composed of a DTVC and a control unit adapter. The DCCU enables the downlink computer to communicate directly with the SGS via the serial data channel. By providing a 160G computer interface for the SGS and adapting it directly to the DTVC, it eliminates the need for a remote computer at stations where only input/output operations are being handled. In the case of the SGS, only input operations are affected.

EXPLANATION

DATA TRANSMISSION AND VERIFICATION CONVERTER

The DTVC operates under program control of a digital computer and communicates in parallel mode with a computer over a standard input/output communications channel. The DTVC communicates with other DTVC's or similar devices in serial mode over a long-distance communications link. Serial data is transmitted with 100-percent redundancy for verification by the receiving termination. The DTVC has three modes of operation:

- a. Select transmit.
- b. Select receive.
- c. Select interrupt.

The DTVC remains in the monitor or receive mode until the computer is ready for a transmission.

DIGITAL COMMUNICATIONS AND CONTROL UNIT

The downlink computer communicates with the DCCU (Figure 1) via the local DTVC utilizing control functions and control words. The control functions, constitute the function-ready, output-resume, information-ready, input-ready signals, etc. The control words are the External Function (EF) codes transmitted over the data lines and perform the function of unit selection, mode selection, and channel selection.

The local DTVC remains in the monitor mode during all idle periods and the control unit adapter maintains the remote DTVC in the select-receive and interrupt mode. The local DTVC transmission loop always communicates with the remote DTVC/ adapter receiver loop; therefore, from the aspect of data transmission, the two DTVC's are back to back.

The first 12-bit word transmitted out of the downlink computer is an external function code to address the local DTVC and select the proper operation. The following sequential steps perform this function:

- a. The downlink computer transmits a 12-bit external function code over the data lines to the local DTVC.
- b. The computer simultaneously transmits a function-ready signal, allowing the local DTVC to decode the EF code.
- c. The DTVC translates the EF code word and enables select transmit and the correct serial channel.
- d. The local DTVC transmits an output-resume signal to the computer, which in turn removes the function-ready signal, which in turn removes the output-resume signal.

The local DTVC is now in the proper mode to communicate with the remote DTVC/ adapter via the selected serial channel. The next word to be transmitted by the computer is another EF code; however, to the local DTVC this EF code is treated as a data word. This word is now converted to serial format and transmitted over the hardlines to the remote DTVC. As previously stated, the remote DTVC is in the select-receive and interrupt mode. The remote DTVC utilizes the interrupt-codeword method to determine what type of operation the control unit adapter is to perform.

The upper six bits of the incoming EF code designate the interrupt word for the DTVC/adapter combination. These six bits of information must match the setting of



Figure 1. DTVC/DCCU Transmission Link Functional Block Diagram six switches that have been preset to a particular configuration. The lower six bits of the incoming EF code designate the command requested for the adapter/SGS operation.

After the DTVC/adapter has been set up for an output operation to the SGS, the third 12-bit word from the display computer is transmitted over the serial channel. The DTVC/adapter treats this word as a function code for the SGS and will transmit this word out simultaneously with a function-ready signal. The function-ready signal allows the SGS to accept and translate the function code. The SGS translates the EF code and returns an output-resume signal to the control unit adapter. The DTVC/ control unit adapter will transmit all subsequent words to the SGS until an interblock null is detected or until an error is detected.

In detecting an interblock null, the control unit adapter returns to the monitor mode and awaits another EF code from the computer, and if another block of data is to be transferred to the SGS, the cycle will be repeated.

If during transmission an error in a control word or data word is detected, a "hold" will be generated by the control unit adapter, thereby preventing any erroneous data from being transferred to the external equipment. After an interblock null is detected, the adapter places the DTVC in the select-transmit mode and transmits a coded 12-bit word to the computer indicating status and error. The computer decodes the adapter word, determines the status and/or error, and then retransmits the block of data a predetermined number of times.

If for each time the display computer retransmits the block of data, the DCCU returns the same status and/or error indicating code, the display computer enters into a programed maintenance routine in an attempt to determine the exact nature of the problem.

ALPHANUMERIC DISPLAY SYSTEM

OBJECTIVES

To familiarize the student with:

- a. Inputs.
- b. Theory of operation.
- c. Display.
- d. Updating.
- e. CRT controls.

GENERAL

The alphanumeric display system provides a readout of results of exercises performed within the spacecraft. The display system receives formatted data and instructions from a digital computer, translates, stores, and displays this data in real time on cathode ray tubes (CRT). The data is displayed in alphanumeric form. The operator monitoring the CRT has the capability of choosing specific pages of data for display on his scope and also has available those controls necessary for individual comfort, i.e., focus, brightness, etc.

COMPONENTS

The alphanumeric cathode ray tube display system contains the following equipment:

- a. <u>Symbol Generator and Storage Unit (SGS)</u> This unit incorporates a highspeed, magnetic-core memory and control logic, symbol generators, position generator, central timing logic, page selection circuits, and maintenance panel.
- <u>Cathode Ray Tube and Callup Module</u> Up to twenty each, independent modules, containing a ten-inch diameter cathode ray tube with a raster size measuring 6 by 6 inches. Each module has switches allowing the operator to call up a full page of data at a time.

EXPLANATION

SYMBOL GENERATOR AND STORAGE UNIT (See Figure 1)

This unit receives 12-bit digital words from a digital computer. The 12-bit words are decoded and data words are stored in specific locations in memory according to logic performed on received-instruction words. The entire contents of memory is scanned at a rate sufficient to refresh all 20 cathode ray tubes at a minimum update rate of 30 cps. The unit receives and acts upon commands from the individual CRT callup keyboards in order to select page formatted data to be presented on the cathode ray tubes. The character repertoire of the SGS allows display of all alphanumeric characters to gether with a set of special symbols. A code to cause characters to blink or not to blink (at a rate that will be varied manually at the SGS maintenance panel) is incorporated. All characters stored in memory between the start-blink code and the noblink code will be displayed in a blinking manner. The blinking indicates an out-of-tolerance condition. The initial page format is as follows:

- a. Each page consists of 1024 characters displayed in 24 lines of 40 characters each.
- b. One 32-character line at the top of the display.
- c. One 32-character line at the bottom of the display.

A half-page consists of either top or bottom half of the preceding format. A display character requires 6 bits from core memory. All numeric characters available for display can be received by the SGS in either binary coded decimal (BCD) or octal form. Word entry to the SGS will be 12 bits in length; two octal-coded display characters or three BCD-coded display characters are contained in one word of input data. When in the BCD mode, the SGS automatically converts BCD characters to octal characters for memory storage.

HIGH-SPEED MAGNETIC CORE MEMORY AND CONTROL LOGIC

The memory located in the SGS is a core stack of 2048- by 60-bit words. The recycle time of the memory (read-write cycle) is 6.4 microseconds. The memory also includes the necessary horizontal and vertical drivers as well as sense circuitry. The memory allocation for half-page formats is shown in Figure 2. A very convenient means of determining the address of any character position in any of the 20 pages of data in the SGS is illustrated by comparing Figure 2 with Figure 3.

410-0(114)



Figure 1. A/N Display System Simplified Block Diagram

410-0(114)

FOR TRAINING PURPOSES ONLY

		Memo	ory Addre	888		
Octal	Decimal			Channel		
		0	1	2	3	4
7777	4095	В	В	B	B	В
7000	3584	4	8	12	10	20
6777	3583	Т	Т	T	T	Т
6000	3072	4	8	12	16	20
5777	3071	B	B 7	B 11	B 15	B 19
5000	2650	Ŭ				
4777	2559	T 3	T 7	T 11	T 15	T 19
4000	2650					
3777	2047	B 2	В 6	В 10	B 14	B 18
3000	1536					
2777	1535	Т 2	T 6	Т 10	T 14	T 18
2000	1024					
1777	1023	B	B	B	B 13	B 17
1000	512	•	J		10	
0777	511	T 1	T 5	T 9	T 13	T 17
0000	0		Ū	J	10	-
		0	1	2	3	4

To Symbol Generators

Figure 2. Memory Layout (Top- and Bottom-Half Pages)

FOR TRAINING PURPOSES ONLY

The second second second								and the second se		
0000	1234567	0010	1234567	0020	1234567	0030	1234567		第二法。 参考于	
0040		0050		0060		0070		0100	1234567	
0110		0120		0130		0140		0150		
0160		0170		0200		0210		0220		
0230		0240		0250		0260		0270		
0300		0310		0320		0330		0340	Upper	
0350		0360		0370		0400		0410	1/2	
0420		0430		0440		0450		0460	Page	
0470		0500		0510		0520		0530		
0540		0550		0560		0570		0600		
0610		0620		0630		0640		0650		
0660		0670		0700		0710		0720		
0730		0740		0750		0760		0770		
1000	1234567	1010	1234567	1020	1234567	1030	1234567	1040	1234567	
1050		1060		1070		1100		1110		
1120		1130		1140		1150		1160		
1170		1200		1210		1220		1230		
1240		1250		1260		1270		1300	Lower	
1310		1320		1330		1340		1350	1/2	
1360		1370		1400		1410		1420	Page	
1430		1440		1450		1460		1470	ruge	
1500		1510		1520		1530		1540		
1550		1560		1570		1600		1610		
1620		1630		1640		1650		1660		
1670		1700		1710		1720		1740	1234567	
1740	1234567	1750	1234567	1760	1234567	1770	1234567			
Pa	Pages 1, 5, 9, 13, 17, use as is. Pages 2, 6, 10, 14, 18, add 2000. Pages 3, 7, 11, 15, 19, add 4000. Pages 4, 8, 12, 16, 20, add 6000.									

Figure 3. SGS Raster to Address Conversion Chart

The SGS memory, upon receipt of an instruction and address, loads sequentially in a channel until receipt of a new instruction and address. In this manner, the computer is able to update any portion of any or all lines by changing the stored data.

There are four distinct types of words from the computer to the SGS. They are as follows: (Refer to Figure 4)

- a. <u>External-Function-Select Word</u> This word is used by the computer to uniquely select the display system for transfer of data. The octal code for the external function word is 0100.
- b. <u>SGS Control Word</u> This word selects either the BCD or octal-coded format, determines whether to write or not write over stored period-character codes, and selects the channel number.

The SGS control word will always be followed by a 12-bit address word. The most significant 6 bits of the control word will always be octal-code 75. Thus, the control word will be uniquely specified. The eighth bit from the Most Significant Bit (MSB) of the control word specifies the coding of the data words following the control word. There are two types of data words, BCD-coded and octal-coded. The ninth bit from the MSB of the control word is used to ascertain whether to write over periodcharacter codes that may or may not be stored in addresses specified by the block input following the control word. If the ninth bit is a zero, the contents of the selected initial address and of all sequential addresses will be tested for the presence of a period code. If the address contains a period-character code, the new information is received into the next sequential address containing no period code. If the ninth bit is present, period-character codes are written over with new information.

- c. <u>Address Word</u> This word always follows the SGS control word and always specifies the address, in the selected channel, that the computer will begin loading. The memory assigned to the selected channel will then be sequentially loaded until such time as the next control word is recognized.
- d. <u>Data Word</u> An address word will always be followed by one or more data words. Depending on the code identified in the control word, the data words will either contain three BCD-coded display characters or two octally coded display characters. (See Tables 1 and 2.)

410-0(114)



Figure 4. Computer Words to Symbol Generator and Storage Unit (SGS)

FOR TRAINING PURPOSES ONLY

Table 1

BCD Character Display Codes

BCD Code	Character
0001	1
0010	2
0011	3
0100	4
0101	5
0110	6
0111	7
1000	8
1001	9
1010	0
1011	*
1100	Space
1101	Blink
1110	No Blink
0000	Skip

A typical example of loading the SGS from the computer utilizing all four types of previously discussed words is as follows:

- a. 0100 (External Function Code) computer selects A/N display system.
- b. 7511 Octally coded character mode write over period, channel 1.
- c. 2004 Starting address for load, fifth character, page 6, channel 1.
- d. <u>4561</u> Load octal code for N in address 2004, load octal code for A in address 2005.

SYMBOL AND POSITION GENERATORS

The symbol generators receive 12-bit octal codes from the SGS memory and transform these codes into synchronized X- and Y-deflection signals. An unblank signal is also developed to unblank the CRT's during the generation of the required character(s). Each symbol generator receives 12-bit octal codes from a specific memory channel. Thus, each symbol generator generates the 4096 characters required to fill four full pages. The characters are generated as sequential locations of memory are read out. The memory is read out as 60-bit words; thus, five symbol generators are required. The symbol generator drives with sufficient power so that any or all 20 CRT's may select the same page or half page for display with no apparent degradation in quality of displayed data.

A position generator is incorporated in the SGS. This generator produces the analogdeflection signals for positioning the characters on each page and are summed with the

FOR TRAINING PURPOSES ONLY

Table 2

Octal Character Display Codes

Octal Code	Character	Octal Code		Character	
12	0	26			W
01	1	27			x
02	2	30			Y
03	3	31			Z
04	4	60			+
05	5	40			
06	6	13			
07	7	14			(space)
10	8	73			
11	9	21			1
61	А	52			%
62	В	77		(Degree)	0
63	С	00		(Skip)	
64	D	36		(Delta)	Δ
65	Е	34	Capitalized	(Theta)	θ
66	F	17		(Omega)	Ω
67	G	32		(Gamma)	γ
70	H	57		(Mu)	μ
71	I	53		(Sigma)	δ
41	J	35	Lower Case	(Phi)	φ
42	K	76		(Psi)	ψ
43	L	37		(Omega)	ω
44	М	74		(Lambda)	λ
45	N	72		(Angle)	2
46	0	33		(Comma)	,
47	Р	54		(Asterisk)	*
50	Q.	15		Start Blink	
51	R	16		No Blink	
22	S	55		Arrow	
23	Т	56		Arrow	
24	U				
25	V				

character-deflection signals in the deflection signal summing networks. The page format is preset by logic in the position generator.

HALF-PAGE CALLUP

The half-page callup receives the half-page command signals from the CRT callup keyboard. Upon receiving these signals, the switching logic selects the correct symbol generator(s) and the correct half pages (top and bottom) from memory for transmission to the requesting CRT module. It is possible to select any of 20 top half pages and any of 20 bottom half pages from any 20 CRT callup keyboards utilizing the central switching logic. (Refer to <u>ACE-S/C Operator's Manual</u>, for details of CRT module operation.)

Figure 5 is a simplified block diagram that illustrates character forming and positioning circuits to the alphanumeric cathode ray tube display.

CHARACTER FORMING AND POSITIONING CIRCUITS

The display on the face of the CRT consists of 26 lines of characters. The top and bottom lines of the page format contain 32 characters each. The other 24 lines contain 40 characters each.

In order to perform this operation, the positioning circuits operate so as to move the dot across the face of the scope as shown in Figure 6. Starting at the top left hand corner, the Y register will be cleared and the X register will step 32 counts horizontally.

The CRT will be unblanked at each stop. During the stop the character-forming network will cause the dot to move in such a manner as to paint a character on the face of the CRT.

At the end of the first line, the X register is cleared and the Y register advances one count. The X register now counts 40 steps across the face of the CRT and again the characters are painted at each step. This process is continued to the bottom line. At the count of 32 in the X register, both the X and Y registers will be cleared and the operation will be repeated starting at the upper left-hand corner.

Figure 5 shows the channels for moving the beam across the face of the scope. Also shown are the character forming circuits. The output of the character forming circuits

410-0(114)





is mixed with the X- and Y-positioning voltages on the lines between the amplifier and line driver blanks as shown in the diagram.

State State																
Y-0, X0-31	0	1	2	-	-	-	-	-	-	30	31	-	-	-	-	
Y-1, X0-39	0 •	1.	2.	-	-	-			-	-	-	-	-	-	39	
							1									
Y-24, X0-39	0	1	2	-	-	-	-	-	-	-	-	-	-	-	39	
Y-25, X0- 31	0	1	2	-	-	-	-	-	-	-	31	-	-	-	-	



Figure 7 depicts the steps involved in printing the letter "A" on the face of the alphanumeric cathode ray tube. After the preset voltage has moved the dot to the lower left corner, the moved voltages are gated through the diode matrix to move the beam in steps as indicated on the blank dots on the Figure 7.



Figure 7. Letter "A" Printed on Alphanumeric Cathode Ray Tube Display Surface

The inputs to the character forming inverters and line drivers consist of AND gates where the data for a page is gated through to the monitor from which the callup signals are arriving. There are 20 of these circuits, one for each monitor in the system. Study Guide

SPECIAL DISPLAY AND RECORDING EQUIPMENT

OBJECTIVES:

To familiarize the student with:

- a. Pulsed Integrating Pendulum Accelerometer (PIPA).
- b. Cardiograph.
- c. Digital cardiometer.

INTRODUCTION

The ACE-S/C system incorporates various special display devices utilized to process, record, and display designated parameters and certain astronaut physical information, such as heartbeat. The following paragraphs describe those displays and equipment which perform unique or special-purpose functions.

EXPLANATION

PULSED INTEGRATING PENDULUM ACCELEROMETER

The Pulsed Integrating Pendulum Accelerometer (PIPA) display equipment is located in the Guidance and Navigation System Console. The PIPA display equipment consists of a Hewlett-Packard 120B oscilloscope, a variable 0- to 360-degree resolver, a lowpass filter, a divide-by-64 frequency divider, an equalization circuit, and an amplifier. This equipment is used to evaluate the phase shift of the three PIPA signal generators which are part of the airborne guidance system located in the spacecraft test area. The phase shift is displayed as a Lissajous pattern by comparing one of the PIPA signal generator outputs with a 3.2-kc reference signal on the PIPA oscilloscope located in the Guidance and Navigation System Console. The PIPA oscilloscope is equipped with a self-contained Polaroid camera and camera housing. Thus, photographic recording with simultaneous viewing is provided.

Figure 1 is a block diagram of the PIPA display equipment. By means of a command from an R-START module located in the Guidance and Navigation System Console, one of the PIPA signals (X, Y, Z, or 3.2-kc calibration) at the spacecraft test area is selected. Any one of these signals is available for display on the PIPA oscilloscope by means of a hardline link to the Systems Patch Terminal Unit. The selected PIPA signal

FOR TRAINING PURPOSES ONLY





410-0(114A)

FOR TRAINING PURPOSES ONLY

Study Guide

is applied to a line equalization circuit contained in the Systems Patch Terminal Unit. The equalization circuit provides uniform gain and phase characteristics at a frequency of 3.2-kc. The axis of the PIPA oscilloscope is located in the Guidance and Navigation System Console.

In order to display the PIPA Lissajous pattern which takes the shape of a butterfly, a second 3.2-kc reference signal is applied to the X-axis input. The reference signal is established by frequency division of either the 204.8-kilobit (kb) or the 51.2-kilobit reconstructed clock signal output of PCM Decommutator. The reconstructed clock signals from both decommutators are routed through the Video Distribution and Tape Transport Control Unit and the Systems Patch Terminal Unit to a panel-mounted selector switch located on the Guidance and Navigation System Console.

The reconstructed clock signal is applied to a frequency divider. The panel-mounted selector switch permits the reconstructed clock signals to be applied to various stages of a frequency divider. When a 204.8-kilobit reconstructed clock signal is to be processed, the switch is set to route the clock signal through the stage, resulting in a division by 64. When a 51.2-kilobit reconstructed clock signal is to be processed, the switch is reset to route the signal to the stage that divides by 16. Thus, the reference signal output of the frequency divider will always be 3.2-kc regardless of the reconstructed clock signal frequency.

The 3.2-kc reference signal output from the frequency divider is converted to a sine wave and is applied to a resolver containing a quadrature winding. The resolver permits the reference signal phase angle to be adjusted from 0 to 360 degrees by means of a front-panel-mounted dial. In addition, the front panel contains a two-position 45° INCREMENT switch. When the switch is placed in the IN position, the quadrature winding of the resolver is connected providing a fixed phase shift of 45 degrees. When the switch is in the OUT position, the quadrature winding is disconnected.

The PIPA display equipment will have a test capability whereby the 51.2- and 204.8-kilobit signals can be generated from a source within the ACE-S/C ground station.

CARDIOGRAPH (MILA Only)

The Cardiograph located in the Aeromedical Console is a high-precision, direct-writing device used to provide a permanent record of astronaut heart-rate information. The Cardiograph is functionally similar to the eight-channel Analog Recorder. However,

FOR TRAINING PURPOSES ONLY

410-0(114A) FOR TRAINING PURPOSES ONLY

Study Guide

there are certain physical differences between the two. For example, the Cardiograph has chart speeds 50 percent lower than the Analog Recorder, the local remote switch is not available on the Cardiograph, and the Cardiograph uses a horizontally-mounted oscillograph as differentiated from the vertical oscillograph contained on the eight-channel Analog Recorder.

DIGITAL CARDIOMETER (MILA Only)

The astronaut's pulse rate is displayed to the Aeromedical Representatives by the Digital Cardiometer (Figure 2). To recognize rapid changes in pulse rate, the heartbeats are counted during either a 10-second or 15-second period and the resulting count is converted to a figure that represents pulses per minute.

This figure is displayed on projection-type numeric indicators located on the front panel of the Cardiometer located on the Aeromedical Console. Front panel controls are provided for selecting one of two signal inputs, resetting the internal counting circuits to zero, and for adjusting the instrument to trigger reliably from the input electrocardiogram signal. The input select control also allows selection of a calibrate test signal.

The circuits of the Cardiometer (Figure 2) may be divided into five major groups for purposes of discussion:

- a. Heart beat pulse generator.
- b. Sample gate generator.
- c. Pulse rate conversion counter.
- d. Display storage.
- e. Display conversion matrix.

In addition to the above, there are circuits for controlling the sample rate, resetting the instrument to zero, and displaying the pulse rate.

Electrocardiogram wavetrain signals are applied to the heart rate pulse generator circuits from the digital-to-analog converter circuits in the ACE-S/C Aeromedical Console. Because the wavetrain is not suitable for operating the counting circuits, the heartbeat pulse generator is used to generate the required uniform pulses to drive the counters. The heartbeat pulse generator circuits also contain the THRESHOLD AD-JUST control permitting adjustment of the Cardiometer so that it operates on the proper peak of the wavetrain.

FOR TRAINING PURPOSES ONLY



Figure 2. Digital Cardiometer Simplified Block Diagram

CI

410-0(114A) FOR TRAINING PURPOSES ONLY

Study Guide

To display a figure representing pulses per minute after counting the heart beat for only a 10-second or 15-second period, the pulses are multiplied by a factor of four or six. This conversion by multiplication is performed by a Pulse Rate Conversion Counter. For example, when the 10-second period is selected by the operator, the number of heart beats is multiplied by a factor of six. Thus, 11 heart beats would be converted to 66, a figure that represents the pulse-per-minute average. When the 15-second period is selected the heart beats are multiplied by a factor of four.

The operator selects the sample period by setting the front panel SAMPLE PERIOD control to either the 10 SECOND or 15 SECOND position. The time base for the Cardiometer is derived from the AMR B-1 time code by the sample gate generator. The AMR B-1 time code is composed of 1-pps pulses of varying widths. These 1-pps pulses are counted by the sample gate generator circuits to provide an update pulse every 10 or 15 seconds, depending on the setting of the SAMPLE RATE control.

The update pulse controls the pulse rate conversion counter and the display storage circuits. Each occurrence of the update pulse causes the content of the pulse rate conversion counter to be shifted to display storage and the count in the conversion counter to reset to zero.

The count in the display storage circuits is converted to decimal (10-line code) form by the display conversion matrix. This 10-line code is used by the lamp drivers to operate the numeric display.

The operator can reset the Cardiometer to zero by depressing the RESET pushbutton, thus causing the restart of the operation at any time. Depressing the RESET pushbutton causes the reset of the sample gate generator counters, the pulse rate conversion counter, and the display storage circuits.

CRT SWITCHING UNIT (MSC Only)

The CRT Switching Unit permits three of the alphanumeric display outputs from the SGS Unit to be switched between six console CRT modules. Three of the CRT modules are located in the Thermo Structures Facilities Console, while the remaining three CRT modules are individually located in the Service Propulsion and Reaction Control Console, the Stabilization and Control Console, and the Guidance and Navigation System Console. One of the CRT modules located in the Thermo Structures Facilities Console will be used to drive a slave CRT in the Solar Simulator Console.

FOR TRAINING PURPOSES ONLY

Study Guide

FOR TRAINING PURPOSES ONLY

410-0(114A)

The CRT Switching Unit (Figure 3) can be patched to provide alphanumeric display signals to the above-mentioned consoles, thereby denying alphanumeric display signals to the three CRT modules located in the Thermo Structures Facilities Console. The patching configuration can be rearranged to provide alphanumeric display signals to any or all of the CRT modules located in the Thermo Structures Facilities Console at the expense of denying such signals to the CRT modules in the consoles mentioned previously. The patch configuration to be employed will be established by the program test requirements.





Figure 3. CRT Switching Unit Panel at MSC FOR TRAINING PURPOSES ONLY

ANALOG AND EVENT DISTRIBUTION

OBJECTIVES

To familiarize the student with:

- a. Decommutator Distribution Unit.
- b. Event Storage and Distribution Unit.
- c. Digital-to-Analog converters.
- d. Recorders.
- e. Event modules and meter modules.
- f. Event and analog select panel.

INTRODUCTION

Units of the ACE-S/C system utilized to process, display, and record the addressed digital test data outputs of the decommutator units are shown in Figure 1. The Decommutator Distribution Unit (DDU) receives addressed digital test data from both decommutators via transmission hardline connections (one line per bit). Fan-out amplifiers within the DDU distribute the received test data word to the Event Storage and Distribution Unit (ESDU) and control consoles.

Within the ESDU, the test data event words are identified (by address recognition) and are routed to storage registers. The outputs of the storage registers, representing on-off event functions, are distributed to recording and/or display units (event indicators) mounted in the control consoles. Analog data words from the DDU are identified in a manner similar to that used for event data words and are stored by digital logic circuits contained within the control consoles. In this case, the storage register outputs are fed to Digital-to-Analog (D/A) converters. The resultant analog signals are routed, via a patchboard, to appropriate recording and/or display units (meter modules) mounted in the control consoles.

EVENT DATA DISPLAY FUNCTIONS

Event data words are selected from intermixed analog and event data words received from the decommutator distribution circuits in the event storage and distribution section of the DDU/ESDU. This selection (by address recognition) and the storage location



Figure 1. Analog and Event Data Distribution and Display

410-0(115)

FOR TRAINING PURPOSES ONLY

N

of each event bit is predetermined by the selection and arrangement of plug-in logic modules within the event storage and distribution circuits.

The ESDU will select and store 150 event words, each of which consists of eight discrete event functions (a total of 1200 events). The event words are gated into registers within the ESDU. The output of each bit position in a register represents the status of a specific event (whether it has or has not occurred).

The outputs of the storage registers are routed to a patch facility in the DDU/ESDU. The patching at this point determines the distribution of each event function to the various consoles and permits routing any specific event function to multiple locations. The outputs of the ESDU are fed to event recorders and/or lamp drivers (in the consoles), which cause event lamps to light.

Event modules are located on the various system control consoles. The front panel of an event module contains 24 lights arranged in three vertical rows of eight lights each. Each light is equipped with a colored lens engraved to identify the event function. These lenses are replaceable if it is necessary to change the display. A lamp test switch on the module tests the function of all lamps simultaneously.

Event recorders are utilized to provide permanent records of events where the time and/or duration of events are desired. Two types of event recorders are used: a 32-channel recorder providing a continuous-write, deflection-type presentation and a 100-channel recorder providing a write/no-write indication of event status. Both recorders have paper speed controls and each includes time recording channels.

ANALOG DATA DISPLAY FUNCTIONS

The intermixed analog and event data words from the decommutator distribution circuits of the DDU/ESDU are routed to all system control consoles. Each control console has address selection circuits that select the analog data words to be displayed at the particular console. The division between decommutator output and the selection of addresses that will be accepted is predetermined by the selection and arrangement of plug-in logic modules in each control console.

These address logic circuits decode the address portion of analog data words to gate the data portion of the word into a storage register. The storage register is connected to a D/A converter that operates a meter and/or a pen on an analog recorder. In some

consoles, the data to be displayed on a particular indicator can be selected from as many as four different addresses. This address selection is controllable by means of a selector switch on the console front panel.

DECOMMUTATOR DISTRIBUTION UNIT FUNCTIONS

The DDU simultaneously receives addressed digital test data words from the two PCM decommutators located in the computer room. The circuits of the DDU are identical for both decommutator inputs and provide the following functions:

- a. Sample the incoming data rate.
- b. Switch decommutator inputs in the event of a read pulse failure.
- c. Distribute the test data word received to the ESDU and various control consoles.

Each test data word received from the decommutators is in parallel format. Each word is composed of 12 binary bits representing the address, 8 binary bits representing data, and an associated read pulse. To receive a test data word, 21 lines are required, one for each bit of the word. Either analog or event information can be represented by the incoming test data words and they arrive at the DDU input in an intermixed form.

The test data words are routed from the decommutators through the terminal patch facility to the DDU via 42 hardlines (see Figures 1 and 2). Twenty-one of these lines carry Decommutator No. 1 data and 21 carry Decommutator No. 2 data. Each line is terminated at the DDU input and is applied to a set of switch gates. All switching gate circuits are identical. Each of the 42 switching gates receives a Decommutator No. 1 input line and a Decommutator No. 2 input line. Each read pulse line (one from each decommutator) is also fed to a read pulse detection circuit. The outputs of each read pulse detection circuit are switching signals used to control the status of their associated switching gates.

Half of the switching gates will normally pass Decommutator No. 1 test data words while the remaining half will normally pass Decommutator No. 2 test data words. This will be the case as long as both decommutators are supplying a read pulse to the DDU. If, for any reason, a decommutator ceases to supply a read pulse, the output of the read pulse detection circuit, associated with that particular decommutator, will change state. This change of state in the read pulse detection circuit output will cause the status of the associated switching gates to change. As a result, the switching gates associated with the nonoperative decommutator will pass the test data still being

FOR TRAINING PURPOSES ONLY

410-0(115)



Figure 2. Analog and Event Distribution

FOR TRAINING PURPOSES ONLY

supplied by the decommutator that is operative. For example, assume Decommutator No. 1 is not supplying an input but Decommutator No. 2 is, the Decommutator No. 1 read pulse detection circuit will cause the Decommutator No. 1 switching gates to accept and pass Decommutator No. 2 test data words. The Decommutator No. 2 switching gates will not change status and will continue to pass Decommutator No. 2 test data words. The switching function has three modes of operation: fully automatic, manual, or inhibited (that is, prevented from switching at any time) switching. Switches on the DDU allow maintenance personnel to select the desired mode of operation.

The test data word passed by a switching gate is fed to a set of associated distribution fanout amplifiers that generate 10 identical isolated outputs. The net result is that, for each test data word input, 10 identical test data words are presented to the DDU output for distribution. One test data word output is sent to the ESDU, eight of the outputs are sent to those control consoles that contain digital logic, and one output is used as a spare.

EVENT STORAGE AND DISTRIBUTION UNIT FUNCTIONS

The input to the ESDU is addressed digital test data words in a parallel format. These test data words are received from the two decommutator units via the Terminal Facility Patchboard and the DDU. A test data word may represent either analog or event information and is identified as one or the other by its associated address. The test data words arriving at the ESDU input are intermixed analog and event. The ESDU selects only the event words (by address recognition) and stores up to 150 such words, each consisting of eight discrete event functions for a total of 1200 events (see Figure 3).

Addressed digital test data is received from the DDU by the ESDU via 42 parallel data lines. One-half (21) of these lines carry Decommutator No. 1 data while the remaining half carry Decommutator No. 2 data. Each digital test data word received is composed of 20 parallel binary bits (12 address and 8 data) and a delayed timing read pulse. The test data words received are sent to distribution subassemblies where the address bits of the test data words are fed to two-stage logic-inverting distribution amplifiers. The data bit and read pulse portions of the test data words are fed to one-stage, logicinverting distribution amplifiers. The logic-inverting distribution amplifiers are identical for both decommutators.



ADDRESS DECODING FUNCTIONS

Upon receipt of a test data word, the 12 address bits of the word and their complements are fanned out to 150 address decoding circuits by the two-stage distribution amplifiers. Each address decoding circuit comprises four selectable plug-in logic modules. The selection and arrangement of these modules determine the following (1) the Decommutator No. 1 or Decommutator No. 2 address lines that will be monitored and (2) the 12-bit address code that will be recognized in the form of four binary-coded octal digits.

When the bit content of an address matches one of the preselected address codes set into the decoding circuit, the 12 output lines of that particular decoding circuit all will be a logic 0 simultaneously. The 12 output lines of each address decoding circuit are fed to an associated address and read pulse gate. A typical address decoding circuit is shown in Figure 4.

DATA AND READ PULSE SELECTION FUNCTIONS

The eight data bits and read pulse portions of the digital test data words received are distributed to 150 data and read pulse selection circuits. One selection circuit is associated with each address decoding circuit. The data and read pulse selection circuits consist of two jumper modules. The arrangement of these modules selects either the Decommutator No. 1 or Decommutator No. 2 data bits and read pulse to be passed. The decommutator input selected to pass is always the same as that which the associated address decoding circuit is currently accepting (see Figure 5).

ADDRESS AND READ PULSE GATE FUNCTIONS

Each address and read pulse gate receives 13 input lines: 12 representing a preselected octal address from an associated read pulse and data-selection circuit. The circuit functions as a 13-input AND gate and generates a "display" pulse whenever its associated address and read pulse input lines are simultaneously at logic 0. The display pulse is fed to an associated set pulse and trigger generator circuit.

SET PULSE AND TRIGGER GENERATOR FUNCTIONS

Upon receiving a display pulse, the set and trigger generator develops a set pulse. The set pulse is sent simultaneously to an associated storage register and to a triggerpulse generating circuit. The trigger pulses that are generated are slightly delayed from the set pulse and are sent to the associated storage register.



Figure 4. Typical Address Decoding Circuit

410-0(115)

FOR TRAINING PURPOSES ONLY




10

FOR TRAINING PURPOSES ONLY

410-0(115)

STORAGE REGISTER FUNCTIONS

The ESDU contains 150 storage registers, one for each addressed data word that can be recognized and processed by the ESDU. Each storage register is composed of eight flip-flops (bistable multivibrators), one for each data bit of a selected word. Each flip-flop receives a set pulse, trigger pulse, and one of eight selected data lines. Upon receipt of a set pulse, all flip-flops of the storage register are cleared of past data. After being cleared, the trigger pulse and any selected data present are ANDed at the input of each flip-flop and are loaded into the storage register. The output of each flip-flop represents one discrete on-off event. A logic 0 indicates the event has occurred, while a logic 1 indicates the event has not occurred or has ceased.

LINE DRIVER FUNCTIONS

The "false" output of each storage register flip-flop is applied to the input of a logic inverting line driver and then to the distribution patchboard. The purpose of the line drivers is to provide (1) the capability to drive relatively long cables and (2) signal isolation prior to distribution by the patchboard. Since there are 150 storage registers supplying eight event outputs each, there are 1200 line drivers. It should be noted that because of inversion by the line drivers, the signals received by the patchboard will be the complement of the storage register output signals.

PATCHBOARD FUNCTIONS

The patchboard contained in the ESDU provides a flexible means to selectively distribute the event signals to appropriate control consoles. The patchboard can be removed and programed as required. The input to the patchboard is 1200 separate events. Each event is coupled to the output of the patchboard by means of plug-in jumper connections. To change the distribution of an event, the patchboard is removed from the ESDU and the appropriate jumper connections are made. After completing the necessary jumper changes, the patchboard is returned to the ESDU.

By means of branching connectors (commoning blocks or squids), a single event input may be coupled to the several patchboard output connections. Each patchboard output pin is connected via hardline to predesignated control consoles.

CONTROL CONSOLE FUNCTIONS

Figure 6 is a block diagram for a typical control console. The inputs to the console are (1) Events from the ESDU and (2) addressed data (event and analog intermixed)



Figure 6. Typical Control Console Block Diagram

12

from the DDU. Each incoming event line is fed to a console patchboard. From the patchboard each event is routed to an associated lamp driver and/or event recorder channel for display. The analog words that are contained in the inputs from the DDU are recognized and stored. The recognition and storage process of analog data is the same as that used for event words in the ESDU. The exact number of analog words that can be accepted varies from console to console. The output of each storage register is applied to a D/A converter. All D/A converter outputs are fed to a console patch panel, which routes the analog signals to the appropriate meter module and/or analog recorder.

DIGITAL-TO-ANALOG CONVERTER

Each D/A converter receives eight binary bits from an associated storage register. A D/A converter is composed of eight voltage divider networks so connected as to form a resistive ladder (see Figure 7). Switching transistors control the input to each voltage divider network. The switching action is such that a logic 0 will cause -5 volts to be applied to a voltage divider and a logic 1 will ground the input to the voltage divider. The output of the D/A converter is taken across the entire resistive ladder. The voltage developed across the ladder will depend upon the bit combination received from the storage register. All "zeros" from the storage register will cause -5 volts to be developed across the ladder. This is the maximum voltage the D/A converter will produce.

CONVERTER CIRCUITS

The converter assemblies are special purpose and exist only in two of the control consoles, Power and Sequential System Console and the Communications Console. Each converter assembly contains eight identical converter circuits. Each converter circuit is composed of a NOR gate and a power inverter module. A typical converter circuit is illustrated in Figure 8.

As illustrated in Figure 8, the converter NOR gate monitors the "1" side of the three most-significant-bit flip-flops of an associated storage register. Whenever the input to the storage register is greater than 31 (00011111), at least one of the inputs to the NOR gate will be a logic 1. In this case, the NOR gate output will be a logic 0 that will be sent to the associated Power Inverter (PI) module. The PI module output then will be a logic 1 indicating that the parameter being monitored is above 12 percent of full scale (32 divided by 256). When the parameter being monitored is below 12 percent, the NOR gate output will be a logic 1 and the PI module output will be a logic 0.



Figure 7. Typical D/A Converter Circuit





Figure 8. Typical Converter Circuit

410-0(115)

410-0(115)

FOR TRAINING PURPOSES ONLY

The output of each converter circuit is treated as an event signal and is fed directly to the control console patchboard. At this point, the converter event signal is sent to an event module on that particular control console and/or to an event display device on the Test Conductor Console (TCC).

32-CHANNEL EVENT RECORDER

The 32-channel event recorder provides a means of permanently recording the time and duration of an event. It will accept and record up to 32 channels of event data simultaneously. In the ACE-S/C configuration, two channels (1 and 32) are reserved for time code data. All data is recorded in a continuous-write, deflection-type presentation. Chart speed can be selected from 12 available speeds. Useful frequency response is 100 cps.

100-CHANNEL EVENT RECORDER

The 100-channel event recorder is a write/no-write recorder providing on-off indicators for 100-event inputs (two of these are reserved for timing signals). Recording is done electrically on specifically sensitized paper. Maximum response time is 1.25 milliseconds.

8-CHANNEL ANALOG RECORDER

Selected analog data is recorded on eight-channel analog recorders. Two additional channels are provided for recording time code data. The record provided is the continuous-write, deflection variety. The recorders will operate at any of 12 speeds. Frequency response is flat to 75 cps and useful to 200 cps.

EVENT AND METER MODULES

Refer to <u>ACE-S/C Operator's Manual</u> for the operation of the meter modules. Section 1 of the <u>ACE-S/C Operator's Manual</u> will supply information on the operation of the various recorders located in the control room.

SUPPORT EQUIPMENT

OBJECTIVES

To familiarize the student with:

- a. Switching equipment function.
- b. Timing group equipment function.
- c. MILA related equipment function.
- d. Computer peripheral equipment function.

INTRODUCTION

This document will attempt to relate the various pieces of support equipment to the overall operation of the ACE-S/C ground station. The discussion on the support equipment will be broken down into four general areas:

- a. Automatic switching equipment.
- b. Timing group equipment.
- c. Merritt Island Launch Area (MILA) peculiar equipment.
- d. Computer peripherals.

EXPLANATION

SWITCHING EQUIPMENT

The ACE-S/C switching system is an addition to the ACE-S/C ground station designed to provide fast, accurate, reliable switchover of the various major components of the ground station. It provides easy access of any control room to any computer room and any computer to any one of ten test areas. In addition, it allows for the association of any CUE or DCCU to any control or computer room.

The switching system consists of a switching group, a power group, and a patching group. Figure 1 is a block diagram of the ACE-S/C switching system.

Switching Group

The switching group permits four discrete groups of cables, from as many as five separate ACE-S/C ground stations to be properly connected within a station or





410-0(116)

TEST BAY

9

TEST BAY

10

COMPUTER ROOM

5

CONTROL ROOM

5

FOR TRAINING PURPOSES ONLY

N

cross-connected between stations. Each group of cables is connected by means of a pushbutton control panel that activates reed relay switches. The following four functional cable groups may be connected to the appropriate termination points within an ACE-S/C station or cross-connected to similar terminations at any of four other ACE-S/C stations:

- a. Cables that carry signals to and from spacecraft test areas and are routed between the Systems Patch Terminal Unit and the ACE-S/C Station Computer Room.
- b. Cables that link an ACE-S/C Control Room to an ACE-S/C Computer Room.
- c. Cables that insert a selected CUE unit between a previously selected computer/ control room combination.
- d. Cables that insert a selected DCCU between a previously selected computer/ control room combination.

There are four control unit panels located on the switching unit (240): one for each of the four switched cable groups. Each control unit panel contains pushbutton switches arranged in a matrix format to permit selection of any switching arrangement of the respective cable group.

Figure 2 illustrates the computer room to control room control unit panel pushbutton matrix. The panel contains 25 pushbuttons arranged in rows and columns of five each (5 by 5). Each pushbutton contains a two-digit number to indicate the switching configuration that may be achieved by depressing that pushbutton. The first digit on each pushbutton indicates the control room selected while the second digit designates the computer room to which the other end of the cable group will be terminated. This twodigit nomenclature is a standard switching matrix designation where the first digit always represents the row and the second digit denotes the column.

As an example, the top row of pushbuttons, as illustrated in Figure 2, permits a control room designated as number one to be connected to any one of five possible computer rooms. It should be noted that the left column of pushbuttons permits the computer room, designated as number one, to be connected to any one of five possible control rooms.

The test area to computer room control unit panel contains a 5 by 10 pushbutton matrix (Figure 3). This is provided to facilitate switching ten groups of spacecraft test area signal cables from the Systems Patch Terminal Unit to as many as five ACE-S/C



Figure 2. Computer Room to Control Room Control Unit Panel Pushbutton Matrix

FOR TRAINING PURPOSES ONLY

4



Figure 3. Test Area to Computer Room Control Unit Panel Pushbutton Matrix



computer rooms. The principles of a 5 by 10 switching matrix are similar to those of a 5 by 5 matrix except that there are ten columns of five switches each instead of just five columns.

Control unit panels are also provided to permit the switching of various combinations of CUE's and DCCU's with the control room and computer room selections. These control unit panels contain 5 by 5 pushbutton matrixes as illustrated in Figure 4.

Power Group

The power group provides power supplies, nickel-cadmium batteries, inverters, and power control and status indication panels. Three 50-ampere power supplies provide the worst case continuous power required for the switching group. Nickel-cadmium batteries, through diode isolation, provide continuous, automatic power backup for a minimum of 30 minutes for the worst case continuous power requirements, which includes five complete configurations made, continuous operation, constant relay board status indication, and control function indication and operation. This backup duration increases rapidly as these worst case conditions are removed. An additional benefit of reed relays is the low "must break" voltage. This further increases the configuration operate time on a backup status. The inverters operate from battery dc supply or battery backup and provide all ac power for the amplifiers in the switch unit and patch group.

Patching Group

The patching group increases the flexibility of the switching system in the following manner:

- a. Accepts inputs from the test areas.
- b. Conditions these inputs as required.
 - (1) Amplifies.
 - (2) Equalizes.
 - (3) Attenuates.
 - (4) Matches impedance.
- c. Splits inputs to more than one recipient if required.
- d. Makes possible the inputting of like signals from more than one test area to one ground station.



Figure 4. Control Room to DCCU or CUE Control Unit Panel Pushbutton Matrix

7

The operational usage of the equipment is as follows:

- a. To connect a control room to a computer room (reference Figure 2).
 - (1) The test conductor determines that the control room is operational. He then activates the "control room connect ready" circuit by depressing the "connect ready initiate" switch on the test conductor console.
 - (2) The computer console operator determines that the computer room is ready to go "on line."

He then activates the "computer room connect ready" circuit by depressing the "connect ready initiate" switch on the computer complex console.

- (3) Once steps (1) and (2) are completed and upon command from the test conductor, the switching system operator inserts a key in the control room/computer room control panel, moves it to the "connect" position and depresses the switch in the matrix to connect the specified control room and computer room. He then moves the key back to the lock position and removes it. The configuration is then established and interlocked.
- b. To connect a CUE or DCCU to the computer room/control room combination (Figure 4):
 - (1) The test conductor must have given a connect ready signal that is combined in the control logic with a signal generated by the control room/ computer room crosspoint being made. This combination actuates a light on the CUE (DCCU) control panel entitled "control room ready."
 - (2) Once the maintenance man has determined that the CUE (DCCU) is ready to go "on line," he depresses a switch on the CUE (DCCU) rack that actuates a light on the control panel entitled "CUE (DCCU) connect ready."

These are most likely operational status indications that will normally indicate ready with no special action.

- (3) Once these two lights are lit and upon command from the test conductor, the switching system operator inserts the key in the CUE (DCCU) control panel, moves it to the connect position, and actuates the required matrix crosspoint to connect the specified CUE (DCCU) and control room. The other side of the CUE (DCCU) is automatically configured to the computer room connected to that control room by the control logic. He then moves the key to the lock position and removes it.
- c. To connect a test area to a computer room (Figure 3). Prerequisites are as follows:
 - (1) Control room/computer room connected.
 - (2) CUE connected (verified via intercom).

(3) DCCU connected (verified via intercom).

(4) Computer room programed and ready to accept data.

Once the prerequisites are met, the computer console operator actuates the "computer room connect ready" light on the computer room/test area control panel by depressing the "test area connect ready" switch on the computer complex console.

Once the switching operator completes and checks the patch unit connections for the test configuration, he actuates the "test area connect ready" light on the computer room/test area control panel by depressing the proper test area connect ready switch on the patch unit.

This test area connect ready signal indicates operational status and may be normally "on" for extended periods of time.

Once these two lights are lit and upon command from the computer console operator, the switching system operator inserts the key in the computer room/test area control panel, moves it to the connect position and actuates the crosspoint to connect the specified test area and computer room. He then moves the key to the lock position and removes it.

This describes the connection for one ACE-S/C ground station. It is now so configured and interlocked that no one can remove any component of the system without the test conductor's permission. Depressing any matrix crosspoint pertaining to any component that has been configured in this discussion will cause nothing to happen.

The following steps are required to disconnect a test configuration:

- a. To disconnect a test area -
 - Upon receipt of verbal instruction from the test conductor, the computer console operator actuates the "computer room disconnect ready" light on the computer room/test area control panel by depressing the "test area disconnect ready" switch on the computer console.
 - (2) The switching system operator then inserts the key, moves it to the disconnect position and actuates the matrix crosspoint, thereby disconnecting it.
- b. To disconnect a CUE or DCCU -
 - (1) The test conductor actuates the "control room disconnect ready" light on the control room/computer room, control room/CUE, and control

room/DCCU panels by depressing the "control room disconnect ready" switch on the test conductor's console.

(2) The switching system operator then inserts the key, moves it to the disconnect position and actuates the matrix crosspoint, thereby disconnecting the respective CUE or DCCU only.

The CUE and DCCU can also be automatically disconnected by procedure c.

- c. To disconnect a control room or computer room -
 - (1) The test conductor extends a "control room disconnect ready" light.
 - (2) The computer console operator extends a "computer room disconnect ready" light.
 - (3) The switching system operator then inserts the key in the control room/ computer room control panel, moves it to the disconnect position and depresses the matrix crosspoint, thereby disconnecting the control/computer room plus the associated CUE and DCCU if they are not already disconnected.

The following steps are required to replace a defective CUE or DCCU while maintaining the operational integrity of the ACE-S/C ground station.

a. The test conductor extends a "disconnect ready" signal that appears on the control room/computer room, control room/CUE and control room/DCCU control panels.

Note

The control room/computer room control panel is still interlocked since no disconnect ready signal has been received from the computer console operator.

- b. The switching system operator then uses the key and disconnects the matrix crosspoint.
- c. The test conductor then extends a connect ready signal.
- d. If it is not already on, the maintenance man extends a connect ready from the new CUE or DCCU to be used after he determines that it is operational.
- e. The switching system operator then operates the key and depresses the matrix crosspoint to connect the new CUE or DCCU into the circuit. He then removes the key and the new test configuration is operational, after validation of the new component.

TIMING GROUP EQUIPMENT

The acceptance checkout equipment - spacecraft (ACE-S/C) timing equipment consists of a time code generator, a countdown generator, a universal tape search system, and

a countdown time input/output synchronizer. The universal tape search system also contains a synchronizer that is utilized as a real-time input/output synchronizer. The primary function of timing equipment in the ACE-S/C ground station is the correlation of command data, spacecraft test data, and operational test sequences.

Three time codes are generated by the timing equipment:

- a. AMR "B-1" time code.
- b. IRIG Format "B" time code.
- c. ACE-S/C Countdown time code.

Also available within the ACE-S/C is a special time code that can be utilized during special testing and maintenance testing.

Although both real-time and countdown-time codes are necessary in the correlation of data, no central time unit is needed to facilitate the generation and transfer of commands or the transfer and processing of test data.

The time code generator generates Inter-Range Instrumentation Group (IRIG) Format "B" time code and the AMR "B-1" time code (see Figure 5). The IRIG code is used for data correlation on the high-speed recorders, and the AMR time code is used for data correlation on the slow paper recorders. The countdown generator generates the ACE-S/C countdown time code that is used for test correlation and can also be used to correlate test data in respect to real time. The universal tape search system electrically positions a magnetic tape transport to a predetermined point on the test tape for playback of test data. The input/output synchronizer performs the function of making available to the uplink and downlink computers real time and countdown time on an asrequired basis.

The IRIG "B" real time is sent to wall clocks to display in decimal form the time of year to one second and to the consoles as range time to display also in decimal form the time of year to one second. The IRIG "B" is sent to a time code distribution unit where it is disseminated to the following equipment:

- a. Oscillograph recorder.
- b. Video distribution and tape transport control.
- c. Tape recorder/computer time decoder and search unit.

During a magnetic tape playback operation the IRIG "B" time code distributed to the tape recorder/computer time decoder and search unit to be used by the universal tape



Figure 5. Timing System Block Diagram

12

410-0 (116)

search system in positioning the magnetic tape transport, to the input/output synchronizer for computer real/playback time and to the consoles as range/playback time.

The Time Code Generator, Model 6190, is located in the terminal facility room and is used to synchronize the countdown generator. In a two-station configuration only one time code generator is utilized. It synchronizes the countdown generators for both stations to an on-time accuracy of one millisecond. The countdown generator generates AMR "B-1" and the IRIG Format "B" time codes.

The Countdown Generator, Model 6350, also located in the terminal facility room, is physically a part of the two-station time generation equipment. The synchronization of the countdown generator to the time code generator is performed automatically; however, the start and stop of the generator is performed manually by either local or remote controls. The remote controls are located on the test conductor console and all countdown time functions during spacecraft tests are performed by the test conductor. The ACE-S/C countdown time code is a modified IRIG Format "B" time code.

The Countdown Time Input/Output Synchronizer, Model 6580, located in the computer room, is designated Countdown/Computer Interface/Translator, Unit 177. It is the function of this unit to make available to the ground station's uplink and downlink computers countdown time in binary form and at any time so designated by the computers. The countdown input/output synchronizer receives time from the countdown generator.

The Universal Tape Search System (UTSS), Model 6222, located in the computer room, is designated the Tape Recorder/Computer Time Decoder and Search Control Unit No. 116. The UTSS also contains a real time input/output synchronizer, which has the function of making available to the ground station's uplink and downlink computers real time in binary form and at any time so designated by the computer. The tape search system interfaces with the Ampex analog magnetic tape recorders and is used to position the tape to a designated prerecorded point for playback operations. The system uses IRIG "B" real-time information to perform the search positioning function and during playback modes the IRIG "B" real time previously recorded on the tape is displayed on the test conductors console as range time.

The time code generator is the basis for the ACE-S/C timing equipment and may (depending upon the requirement) be in synchronization with WWV or some Government time standard. The output of the generator consists of the following time 410-0(116)

FOR TRAINING PURPOSES ONLY

codes: AMR "B-1" and IRIG "B." The system generates the time by the use of Decimal Counting Units (DCU) and displays the contents in decimal form via "nixie" displays. The IRIG "B" time code is available in BCD and straight binary; BCD indicates time of year to a second and straight binary indicates time of day to a second. The AMR "B-1" time code is available only in straight binary and indicates time of day to a second.

The basic counting devices in the time code generator are the decimal counting units. These counters are connected in cascade form and are called minor, major, and days time counter. The minor time counter produces one pulse each second at the output for each 100,000 input pulses. The major counter produces one pulse each day with a one pulse-per-second input signal. The days counter counts the days pulses.

The Countdown (C/D) Generator generates the ACE-S/C countdown time code as shown in Figure 6. It also generates the countdown time displayed on the wall displays and console displays. The countdown time is synchronized to the time code generator by a 1-kc square-wave signal. The countdown generator generates time data from minus 999 hours, 59 minutes, and 59 seconds to plus 999 hours, 59 minutes, and 59 seconds.

It also generates a sign to distinguish between countdown time and countup time. During any moment that the time is disabled, a "hold" indication will replace the + or - sign.

The Computer Countdown Time Input/Output Synchronizer is a time-sharing device that provides the uplink and downlink computers with countdown time. The synchronizer transfers time to the computer upon request, and upon coincidence of countdown time and a preset time, it will interrupt the computer to enable a preprogramed subroutine to be performed. The input/output synchronizer receives the ACE-S/C countdown serial-modulated time code from the countdown generator, decodes, and translates the incoming signal to produce a binary word for use by the computer (see Figure 7).

The uplink computer uses countdown time to time-tag commands, which are recorded on magnetic tape. Therefore, time must be available for transfer from the synchronizer to the computer at all times during testing. The binary information representing hours, minutes, and seconds is transferred to the computer as two 12-bit parallel words. Word one contains the current seconds and minutes, and word two contains the current hours and the sign denoting countup time or countdown time. To request and



The ACE Countdown Time Code is a modification of the standard IRIG Format B. Countdown time in Sec., Min., Hr. is represented in BCD, 8-4-2-1 form. Two formats are actually used - during count up (+) the format is scanned least significant bit first for each sub-word. In the cound down (-) mode the format is scanned most significant bit first in each sub-word.



transfer the time, the computer (whether uplink or downlink) must use the external function control-word and control-line method to effect the transfer.

A second function of the input/output synchronizer is to interrupt the computer when countdown time corresponds to a preset time. This can be performed either by manually inserting into the synchronizer the preset time or from the computer through preprogramed routines. Both methods can be used during a countdown or a test. If countdown time corresponds to the manually preset time, an Interrupt 30 will be generated by the synchronizer, and if countdown time corresponds to the preset time specified by the computer, then an Interrupt 40 will be generated.

The Model 6580-600 Countdown Time Input/Output Synchronizer consists of two separate units: (1) a countdown time code translator and (2) an input/output synchronizer for two CDC 160G general-purpose computers. The two units are housed together for reasons of power supply and interface economy.

The UTSS receives serial time code information from a magnetic tape unit. The tape search unit compares the current time value recorded on the tape with a preset value of time and issues appropriate control signals to a magnetic tape transport unit. The control signals issued are used to start, stop, and control the search and playback drive of a tape transport. Thumbwheel switches are available on the tape search control unit to preset the desired playback start/stop time values. The search time resolution provided by the thumbwheel switches is days, hours, minutes, and seconds. The tape search control unit compares the time code preset into the thumbwheel switches with the time code recorded on a magnetic tape and instructs the tape transport to search in a forward or reverse direction for the location of the start time. When the start time is located, the tape search control unit instructs the tape transport to playback in the forward direction until the stop time is reached.

A tape search control unit mode selector switch is provided to select any one of four operating modes.

a. <u>Recycle Mode</u> - In the recycle mode, the tape search control unit will cause a tape transport to search in the conventional manner to the preset start time and then automatically reproduce (play back) to the preset stop time. This process will continue until a new control instruction is set into the tape search control unit.

- b. <u>Single-Cycle Mode</u> In the single-cycle mode, the tape search control unit functions the same way as in the recycle mode except that it halts the tape it transport being controlled when the preset stop time is reached.
- c. <u>Search-to-Start Mode</u> The search-to-start mode is similar to the singlecycle mode except that the tape transport being controlled is halted when the preset start time is reached. To cause the tape transport to commence playback operation toward the preset stop time, the unit must be placed in the playback mode.
- d. <u>Playback Mode</u> In the playback mode the tape unit starts and plays back the tape until the end of the tape is reached.

The UTSS contains an I/O synchronizer for use by the computers (uplink and downlink) during a tape playback operation. The I/O synchronizer gives IRIG "B" real time to either computer upon request. During a normal operation, i.e., when the Ampex tape recorders are in a record mode, the IRIG "B" real time is not made available to the computers.

The input/output synchronizer in the UTSS operates in the same manner as the countdown time Input/Output Synchronizer, Model 6580-600. However, the synchronizer in the UTSS obtains time from the time code generator and does not have the preset digital switches available to the operator for manual interrupt time.

The UTSS also contains circuitry for developing a serial time code of variable frame lengths to be used by the operator in special tests and various specific applications primarily during equipment maintenance operations.

The time codes generated by the timing equipment (AMR "B-1," IRIG "B," and ACE-S/C countdown time) are distributed to various equipment in ACE-S/C as shown in Figure 5. The input/output synchronizer performs the function of making available to the uplink and downlink computers real time and countdown time on an as-required basis.

IRIG "B" Real-Time Distribution

The IRIG "B" real time is sent to wall clocks to display in decimal form the time of year to one second and to the consoles as range time to display also in decimal form

18

the time of year to one second. The IRIG "B" is sent to a time code distribution unit where it is disseminated to the following equipment:

- a. Oscillograph recorder.
- b. Video distribution and tape transport control.
- c. Tape recorder/computer time decoder and search unit.

IRIG "B" Playback Time Distribution

During a magnetic tape playback operation the IRIG "B" time code is distributed to the tape recorder/computer time decoder and search unit to be used by the UTSS in positioning the magnetic input/output synchronizer for computer real/playback time and to the consoles as range/playback time.

AMR "B-1" Real-Time Distribution

The AMR "B-1" time code is disseminated to the following units to be recorded for data correlation:

- a. Strip chart recorders.
- b. Analog recorders.
- c. Video distribution and tape transport control.
- d. Oscillograph recorder.

AMR "B-1" playback time, that time recorded on the magnetic tape recorders, is distributed to the following units:

- a. Strip chart recorders.
- b. Analog recorders.
- c. Oscillograph recorder.

ACE-S/C countdown time code is displayed on wall clocks indicating countdown time to one second and is distributed to the following units to be used in data and test correlation:

- a. Computer input/output synchronizer.
- b. Magnetic tape transports.
- c. Test conductor console.
- d. Computer complex console.

ACE-S/C countdown time code is distributed to the following units during a playback operation:

- a. Test conductor console.
- b. Computer input/output synchronizer.

- c. Computer complex console.
- d. FM discriminators.

The ACE-S/C system employs five wall clock display units, three in the control room and two in the computer room and two console clocks. Each wall clock contains two sets of in-line decimal display of real time (actual or range time) and one set for the display of countdown time. The console clocks display either real or countdown time.

The real-time wall clock displays always show the current time of day or range time, never playback real time. The real-time wall clock display units consist of nine decimal in-line indicators: three for day, two for hours, two for minutes, and two for seconds.

The countdown time wall clock displays always show current countdown time, never playback countdown time. The countdown wall clock display units consist of eight inline decimal indicators: two for seconds, two for minutes, three for hours, and one to indicate plus, minus, or hold.

Both the computer complex console and the test conductor console contain front panel mounted real and countdown clock display subassemblies. The console real-time clock display units are capable of showing either current range time or the playback range time depending upon the present ACE-S/C operational mode. In like manner, the console countdown time clock display units are capable of showing either the current countdown time or playback time. The same number and type of indicating device as are used in the console clocks are used in the wall clock displays.

MERRITT ISLAND LAUNCH AREA PERIPHERAL EQUIPMENT

The following description paragraphs are applicable only to the ACE-S/C ground stations that are installed at the Merritt Island Launch Facility.

The ACE-S/C has the functional responsibility of performing a checkout of the entire Apollo spacecraft. Because of the complexity of the testing and the total number of parameters to be processed from each subsystem, the spacecraft is functionally divided into two categories for checkout operations - Command/Service Module (CM/SM) and Lunar Excursion Module (LEM). Two ACE-S/C stations are provided to perform this checkout function. The Saturn launch vehicle checkout is performed simultaneously with the spacecraft checkout, utilizing a different type of system. The checkout philosophy of the launch vehicle is different and the degree and complexity somewhat less than that of the spacecraft. The launch vehicle is of a standard booster configuration designed to boost a given spacecraft on a given mission. The Apollo spacecraft is designed for a particular mission and therefore must be man-rated to perform that mission, thus, the different philosophy and complexity of checkout.

However different, the checkout of the two vehicles must be integrated and highly coordinated during the final stages of prelaunch testing.

Blockhouses 34 and 37, Launch Control Center (LCC) 39, and the Operational and Control (O&C) Building contain the equipment necessary to perform the checkout integration of the launch and spacecraft vehicles.

During final prelaunch testing and countdown, the two ACE-S/C ground stations will be performing their separate functions of CM/SM and LEM checkout. These systems will be integrated and coordinated by the equipment remoted in the blockhouse. This integration must function in this manner because each ground station is operating under a different internal program control designed to check out two unrelated functional spacecraft subsystems. Additionally, during prelaunch testing and countdown, one of the ACE-S/C ground stations will be in direct communication with the launch vehicle checkout computer to perform programed coordination activities such as milestones and various selected event data. The functional relationship here is to coordinate the spacecraft and launch vehicle checkouts within milestone events, thereby resulting in a more highly integrated prelaunch test rather than coordination of subsystem Go/No Go status.

These methods of integration and coordination between the spacecraft checkout systems and the launch vehicle checkout system provide for a more unified checkout of the equipment as a system, thereby producing a more capable and more reliable vehicle to perform mission objectives (see Figure 8).

There is a direct link between the ACE-S/C (MILA) ground stations in the O&C Building and the peripheral equipment in Blockhouses 34 and 37 and LCC 39. Both Command/ Service Module and Lunar Excursion Module checkout data will be transmitted and displayed simultaneously within the capacities of the transmission equipment (see Figure 9).



Figure 8. MILA/ACE-S/C Interface

FOR TRAINING PURPOSES ONLY

22



Figure 9. MILA Peripheral Interconnection

The ACE-S/C MILA peripheral equipment in Blockhouse 37 will be functionally identical to that in Blockhouse 34. The LCC 39 system differs from Blockhouse 34 and 37 by the addition of one low-silhouette console to the Test Conductor's Console, containing one self-contained clock and one countdown time control.

Additional equipment is installed in the MILA O&C Building to provide data transmismission facilities for the MILA peripheral equipment. This equipment will serve Blockhouses 34 and 37 and LCC 39. This equipment will also transmit status and event signals from the ACE-S/C control rooms.

Within the ACE-S/C ground stations, parallel outputs provide the necessary signals that are transmitted to the blockhouses. These signals are displayed in the blockhouse simultaneously with the data being displayed in the ACE-S/C control room. The ACE-S/C ground station computer rooms will have additional transmission and verification equipment to facilitate a bidirectional flow of milestone and event data between the spacecraft checkout computer and the launch vehicle checkout computer.

TEST CONDUCTOR'S CONSOLE

The test conductor will utilize a console that provides a means of monitoring the status of all the spacecraft systems (CM/SM and LEM). An additional monitoring of milestone events, closed-circuit television presentations, countdown time, and alphanumeric summary test data enables the test conductor to be cognizant of all spacecraft checkout functions, thereby providing a highly functional spacecraft/launch vehicle integration task.

In addition to a monitoring function, the test conductor has the capability of controlling the arming and safe control of the CSM and LEM pyrotechnics.

ASSISTANT TEST CONDUCTOR'S CONSOLE

The assistant test conductor has the capability of monitoring closed-circuit television, intercommunications, countdown time, and alphanumeric test data. Utilizing the aforementioned displays, the assistant test conductor has the functional responsibility of controlling closed-circuit television presentation, countdown time, and alphanumeric test data, thus adding in the coordination of the overall integration.

AEROMEDICAL REPRESENTATIVE CONSOLE

The aeromedical representative utilizes the displays provided by the aeromedical console to monitor alphanumeric summary test data, system status, milestone events, and astronaut aeromedical functions. The aeromedical functions are pneumograph (respiration) and electrocardiogram (heart rate). With the astronaut aeromedical functions and other system test data, the aeromedical representative can coordinate the systems' Go/No Go status with that of the astronauts.

ASTROCOMMUNICATOR CONSOLE

The astrocommunicator utilizes the display devices on the astrocommunicator console for monitoring spacecraft communications and mission milestones.

DIGITAL COMMUNICATION AND CONTROL UNIT (DCCU)

The DCCU communicates via the A2A hardline with a MILA ACE-S/C ground station downlink computer and feeds alphanumeric data to the SGS. The DCCU allows the computer (Downlink 160G) to perform input/output operations at a remote location under local computer control. It also performs error verification of data transmissions.

SYMBOL GENERATOR AND STORAGE UNIT

The SGS receives digital words from the ACE-S/C downlink computer via a DCCU. As outputs, the SGS provides alphanumeric data to the CRT display monitors. Each CRT monitor is capable of controlling data callup from the SGS. The SGS utilized in the blockhouse control room is basically the same as that incorporated in the ACE-S/C ground station; however, it is limited to eight display units.

SIGNAL TRANSMISSION EQUIPMENT

This equipment, located in the O&C Building, facilitates the transmission of aeromedical, status, and event data to the remote consoles located in the blockhouse. The transmitting equipment utilizes both the frequency modulation and frequency-shift techniques in the transmission of data.

SIGNAL RECEIVING EQUIPMENT

This unit is the receiving terminal for status, event, and aeromedical analog data. As such, it consists primarily of tone receivers for demodulating frequency-shift transmissions and discriminators for demodulating frequency-modulated transmission. These components provide the capability to process status and event signals and aeromedical analog signals transmitted from the O&C Building via telephone lines and the distribution of these signals to console displays.

STATUS/EVENT AND AEROMEDICAL DATA DISTRIBUTION UNIT

This unit is patched to all the blockhouse consoles to provide data for respective display devices.

GLOSSARY OF TERMS

1

Study Guide

GLOSSARY OF TERMS

FOREWORD

This Glossary of Terms includes those terms and abbreviations commonly used in the ACE-S/C program.

Glossary

FOR TRAINING PURPOSES ONLY

ABSOLUTE CODING: Coding written in numeric language acceptable to the machine without further modification.

ACCESS RANDOM: Access to storage under conditions in which the next position from which information is to be obtained is independent of the previous one.

ACCESS TIME: The time interval between the call for a unit of information from a storage device and the delivery of that information.

ACCUMULATOR: A unit containing a register that stores a quantity when a second quantity is delivered to the unit (frequently only a storage register).

ACE-S/C: Acceptance Checkout Equipment - Spacecraft.

ADDEND: A number or quantity to be added to another.

ADDER: A device capable of forming the sum of two quantities.

ADDRESS: A label, name, or number identifying a register, a storage location, or a device from which information is received or to which it is transmitted.

ADDRESS, ABSOLUTE: The label(s) assigned by the machine designers to a specific storage location.

ADDRESS, BASE: A number that appears as an address in a computer instruction, but which is to be modified; for instance, by adding the contents of one or more index registers before it is used.

ADDRESS, DIRECT: An address in a computer instruction that indicates the location where the referenced operand is to be found or stored.

ADDRESS, EFFECTIVE: A modified address; the address actually used in a particular execution of a computer instruction.

ADDRESS, INDIRECT: An address in a computer instruction that indicates a location where the address of the referenced operand is to be found.
ADDRESS, RELATIVE: A number of the form of an address that specifies the position of a storage location with respect to some base address. The absolute address of the storage location is obtained by adding the relative address to the base address.

ADDRESS, SYMBOLIC: A label chosen to identify a particular work, function, or other information in a routine, independent of the location of the information within the routine.

ALPHANUMERIC: Characters that may be either letters of the alphabet, numerals, or special symbols.

AMR: Atlantic Missile Range.

ANALOG-TO-DIGITAL CONVERSION: A process by which a sample of analog information is transformed into a digital code.

ANALOG-TO-DIGITAL CONVERTER: A device to convert analog information to digital by means of coded information.

ANALOG VOLTAGE: A voltage that varies in a continuous fashion in accordance with the magnitude of a measured variable.

AND: A logical operation.

AND GATE: A circuit with two or more inputs which produces one output if all input signals are coincident and are of the correct, predetermined polarity.

ARITHMETIC OPERATIONS: Fundamental operations of arithmetic; that is, addition, multiplication, division, and subtraction.

ARITHMETIC UNIT: That portion of the hardware of an automatic computer in which arithmetic and logical operations are performed.

ASD: Apollo Support Department.

ASPO: Apollo Spacecraft Project Office (NASA-MSC - Houston, Texas).

Glossary

FOR TRAINING PURPOSES ONLY

Study Guide

ASSEMBLY PROGRAM: A computer program that produces machine instructions from symbolic input.

AUXILIARY STORAGE: A device (other than the main memory unit) with the capability of holding large amounts of information.

BANK: A unit of core storage with provisions for storing 4096 or 8192 words. The use of more than one bank permits increasing the storage capacity of a computer without increasing the work length implicitly necessary to extend the range of storage addresses. In the 160A or the 160G, this address is effectively increased by set storage bank control instructions which determine which banks will be used during the program.

BINARY: A mathematical system in which the base "2" numerical structure is used. It is used in computer logic because it is much easier to work with than the decimal system which is based on ten numbers.

BINARY NUMBER: A group of digits, written in binary code (utilizing the base "2" numbering system), representing a specific number in the decimal system.

BINARY CODED DECIMAL (BCD): Decimal notation in which the individual decimal digits are represented by some binary code; for example, in the 8-4-2-1 coded decimal notation, the number twelve is represented as 0001 0010 for 1 and 2, respectively. Whereas, in pure binary notation, it is represented as 1100.

BIT: A unit of information that is carried by an identifiable character, and that can exist in either of two states - a "one" or a "zero." (An abbreviation of binary digit.)

BIT RATE: The frequency derived from the period of time required to transmit one bit.

BLANK: The character which results in memory when an input record is read – such as the hole in a card.

BLOCK: A group of words transported as a unit.

BOOTSTRAP: The coded instructions at the beginning of an input medium (tape or cards), together with instructions inserted by switches or buttons into the computer, which are used to read programs into memory.

G-4

BREAK-POINT: A point in a routine at which special action is taken, such as a stop or a transfer, either as the result of the insertion of a special instruction or the setting of a console switch. Usually used in debugging.

BUFFER: A device in which data is stored temporarily in the course of transmission from one point to another.

BUFFERED (INPUT/OUTPUT): A term indicating that the computer may carry on high-speed computation at the same time it is exchanging data with a peripheral device.

C-START: Computer communications START module.

CALLING SEQUENCE: A set of characters identifying a subroutine and containing information concerning parameters to be inserted in the subroutine, information to be used in generating the subroutine, or information related to the operands; a call-word when exactly one word is filled.

CARRIER: A wave suitable for being modulated to transmit intelligence.

CCTV: Closed-circuit television.

CDC: Control Data Corporation (computer manufacturer).

CHANNEL: A transmission path; for instance, one connecting the computer to external equipment.

CHARACTER: One of a set of symbols, usually restricted to a member of a specific alphabet or appropriate to a particular computer. The symbols may include the letters A through Z, digits 0 through 9, punctuation marks, operation symbols, or any other symbols which a computer can read, store, or write; more precisely, the coded computer representation of a symbol drawn from its alphabet (one might represent the symbol "A" as the character 100001 in a specific computer alphabet).

CHECK SUM: A check in which groups of digits are summed, usually without regard to overflow. That sum is then checked against a previously computed sum to verify accuracy; also, the previously computed sum.

FOR TRAINING PURPOSES ONLY

Glossary

CLEAR: To reset a register by placing every stage in the "0" state.

CLOCK, MASTER: Central source of standard signals required for computer operations.

CLOCK PULSE: A pulse used for timing purposes. In PCM systems, a timing pulse that occurs at the bit repetition rate.

CLOSED-LOOP TELEMETRY: A telemetry system used as the indicating portion of a remote-control system. A system to check out a vehicle without radiation of RF energy.

CM or C/M: Command Module.

CODE: A system of symbols and their use in representing rules for handling the flow or processing of information.

COMMAND: A signal that performs a unit operation, such as transmitting contents.

COMMUTATION: Sequential sampling, on a repetitive time sharing basis, of multiple data sources for transmitting and/or recording on a single channel.

COMMUTATION FRAME PERIOD: Time required for sequential sampling of all input signals. This period would correspond to one revolution of a single multi-contact rotary switch.

COMMUTATION RATE: Number of commutation inputs sampled per second.

COMMUTATOR: A device used to accomplish time division, multiplying by repetitive sequential switching.

COMPILER: A computer program that translates instructions written in a technical or problem-oriented language into machine language. Usually more than one machine instruction results from each symbolic instruction.

COMPLEMENT: A quantity that is derived from a given quantity and which represents the negative of the given quantity.

FOR TRAINING PURPOSES ONLY

CONDITIONAL JUMP: A "jump" instruction which occurs only if a certain condition is present in the computer at the time the instruction is executed.

CONTENT: The quantity or word held in a register or storage location.

CONVERSION: Changing the form of representation of information.

CONVERTER: A unit that changes the language of information from one form to another.

CORE, MAGNETIC: A magnetic material capable of assuming and remaining at one of two or more conditions at magnetization, thus providing storage.

CORE STORAGE: High-speed storage in which information is represented by the magnetization of ferromagnetic cores.

COUNTER: A device, register, or storage location for storing integers, permitting these integers to be increased or decreased by unity or by an arbitrary integer, and capable of being reset to zero or to an arbitrary integer.

CSR: Check Status Register.

CUE: Communications Unit Executor.

CYCLE: A set of operations repeated as a unit.

D/A or DAC: Digital-to-Analog converter.

DADE: Data Acquisition and Decommutation Equipment.

DATA REDUCTION: The process of transforming masses of raw test or any experimentally obtained data, usually gathered by instrumentation, into useful, orderly, and simplified intelligence.

DCCU: Digital Communications and Control Unit.

DDI: Data Display, Inc.

FOR TRAINING PURPOSES ONLY

Glossary

DDS: Data Display Subsystem.

DDU: Decommutator Distribution Unit.

DEBUGGING: The process of determining the correctness of a computer routine and locating errors in a program.

DENSITY, PACKING: The number of units of useful information contained within a given linear dimension, usually expressed in units per inch; for example, the number of bits stored on tape per linear inch on a single track by a single head.

DECODING: Operation by which a unit or equipment determines the meaning of the operation code of an instruction.

DECOMMUTATION: Equipment for separation, demodulation, or demultiplexing commutated signals.

DEVIATION: In frequency modulation, the peak difference between the instantaneous frequency of the modulated wave and the carrier center frequency.

DIGIT, BINARY: A whole number in the binary scale of notations, either a "one" or a "zero."

DIGITAL: Expressing value in terms of numbers. Measurable in discrete, discontinuous steps.

DIGITAL MAGNETIC TAPE RECORDING: The method of recording binary coded information using two discrete flux levels.

DIGITAL OUTPUT: A transducer output that represents the magnitude of the measurand in the form of a series of discrete quantities coded in a system of notation.

DIS: Data Interleaving System.

DISCRIMINATOR, FM: A device that converts variations in frequency to proportional variations in voltage or current.

FOR TRAINING PURPOSES ONLY

Study Guide

FOR TRAINING PURPOSES ONLY

Glossary

DOWNLINK: That part of the ACE-S/C system that receives, processes, and displays the return data from the spacecraft.

DTCS: Digital Test Command System

DTMS: Digital Test Measurement System.

DTVC: Data Transmission and Verification Converter.

EBM: Execute Buffer Memory.

ECS: Environmental Control System.

EDITOR: A routine to insert, delete, replace, or rearrange data.

EPS: Electrical Power System.

ESDU: Event Storage and Distribution Unit.

ELS: Earth Landing System.

EXECUTION (XEQ): Performance of an instruction in which the steps are carried out by the code of the instruction.

EXTERNAL FUNCTION CODE: A 12-bit code used to select and specify that an external device, for example, a printer or tape, is to perform some specific function.

FIXED POINT: System of arithmetic where the quantities are expressed by a predetermined number of digits with the decimal point located at some predetermined position.

FLIP-FLOP (FF): A bistable device capable of storing a bit of information or of controlling gates.

FM: Frequency Modulation.

FM DISCRIMINATOR: A device that converts frequency variations to proportional variations in the amplitude of an electrical signal.

FOR TRAINING PURPOSES ONLY

Glossary

FOR TRAINING PURPOSES ONLY

FM/FM: Frequency modulation of a carrier by a subcarrier which is frequency modulated by information.

FORMAT: The predetermined arrangement of characters.

(EXTERNAL) FUNCTION CODE (EF): An external function code is a digital word used in addressing and selecting operating modes of equipment external to the computer. This code is generated by the computer.

FUNCTION READY: A signal transmitted by the computer, or such devices operating in a computer capacity, to external equipments to indicate that a function code is available.

GAEC: Grumman Aircraft Engineering Corporation.

G & N: Guidance and Navigation.

GASS: The generalized assembly system for the Control Data 160G Computer system.

GATE: A circuit with the ability to produce an output dependent upon a specified type and coincidence of inputs.

GFE: Government Furnished Equipment.

GSE: Ground Support Equipment.

INDEX REGISTER: A register that contains a quantity which may be used to automatically modify addresses (and for other purposes) under direction of the control section of the computer.

INDIRECT ADDRESSING: A second level of addressing - the address part of an instruction is the location in memory where the address of the operand may be formed or is stored.

INITIALIZE: To set all units, etc., to the desired initial values.

FOR TRAINING PURPOSES ONLY

INFORMATION READY: A signal transmitted by the computer to an external piece of equipment indicating data is available.

INPUT READY: A signal transmitted to the computer by external equipment indicating that data is available to the computer.

INPUT REQUEST: A signal transmitted to external equipment by the computer requesting data.

INSTRUCTION: A set of characters which define an operation, together with one or more addresses.

I/O: Input/Output - in reference to the computer.

IRIG: Inter-Range Instrumentation System.

JUMP: An instruction specifying the location of the next instruction and directing the computer to that instruction.

K-START: Keyboard START Module.

LBM: Load Buffer Memory.

LCC: Launch Control Center (MILA).

LEM: Lunar Excursion Module.

LES: Launch Escape System.

LIBRARY: An ordered set or collection of standard and proven programs and subroutines used for data processing applications and the solution of problems.

LINE-PRINTING: Printing an entire line of characters across a page as the page feeds in one direction past a type bar.

LOAD: To bring information into memory from an external storage medium and to place a quantity from storage into the A register.

FOR TRAINING PURPOSES ONLY

FOR TRAINING PURPOSES ONLY

Glossary

LOC: Launch Operation Center (Cape Kennedy).

LOCATION: A storage position in internal or shared memory.

LOCKOUT: Any function (usually of machine logic) that inhibits an action that would normally occur if the lockout were not imposed.

LOGIC CIRCUIT: A complex of "go /no-go" type circuitry arranged in such a pattern or matrix as to perform the various arithmetic functions on demand.

LOGICAL OPERATIONS: The computer operations that are logical in nature, such as logical AND, OR, extract, and decisions. This is in contrast to the arithmetic operations, such as add, subtract, multiply, and divide.

LOOP: A given sequence of instructions operated upon repeatedly (normally, until a specified condition occurs).

LV or L/V: Launch Vehicle.

MACRO: A symbolic instruction representing a frequently used sequence of machine language instructions.

MAINTENANCE PROGRAM: A diagnostic program to determine the operational readiness of any piece of computer or peripheral equipment and to isolate any malfunctions that occur.

MASK: A prearranged pattern or configuration of bits in a computer word generally used for logical or bit manipulations.

MASS: A monitor and assembly system for the Control Data Corporation 160G computer system.

MEMORY: Internal storage.

MESSAGE: A group of words transported to a unit specifying an operation.

MICROSECOND: A millionth part of a second.

G-12

Study Guide

FOR TRAINING PURPOSES ONLY

MILA: Merritt Island Launch Area (Cape Kennedy).

MILLISECOND: A thousandth part of a second.

MIT: Massachusetts Institute of Technology.

MITRE: The research division of the Massachusetts Institute of Technology.

MNEMONIC: The art of programming to improve the efficiency of the computer memory.

MNEMONIC OPERATION CODES: Operation codes in symbolic notation which are easier to remember than the actual operation codes of the machine.

MODULATION: The process of impressing information on a carrier for transmission.

MONITOR: A program that exercises supervisory control over some other programs or collections of programs. Also called executive routine or master routine.

MSC: Manned Spacecraft Center, Houston, Texas.

MULTIPLEXING: The simultaneous transmission of two or more signals within a single channel. The three basic methods of multiplexing involve the separation of signals by time division, frequency division, and phase division.

NASA: National Aeronautics and Space Administration.

OCTAL: Pertaining to the number base of eight.

OFF-LINE: Peripheral equipment not under direct computer control.

ONE: The representation of a binary digit; that is, a condition exists.

ONE'S COMPLEMENT: With reference to a binary number, that number which results from subtracting each bit of the given number from the bit 1. A negative number is expressed by the one's complement of the corresponding positive number.

FOR TRAINING PURPOSES ONLY

Glossary

FOR TRAINING PURPOSES ONLY

Study Guide

ON-LINE: Peripheral equipment under direct computer control.

OPERAND: Any one of the quantities entering or arising in an operation. An argument, a result, a parameter, or an indication of the location of the next instruction.

OSAS-A: A general assembly system for the Control Data Corporation 160A computer system.

OVERFLOW: The generation of a quantity beyond the capacity of a register.

PARALLEL TRANSFER: A system of data transfer in which elements of information are transferred simultaneously over a parallel set of lines.

PARAMETER: Measurand, a physical or electrical quantity which is measured.

PARITY BIT: A bit added to a binary code to facilitate a parity check.

PARITY CHECK: A self-checking code employing binary digits in which the total number of "ones" or "zeros" in each permissible code expression is always even or always odd. A check may be made for either even or odd parity.

PARTIAL ADD: An addition without carries.

PCM: Pulse Code Modulation (PCM) is the pulse modulation of a carrier by coded information. In PCM telemetry, information transmission is by means of a code representing a finite number of values of the information at the time sampling.

PERIPHERAL: Off-line devices concerned with the transfer of data. Usually under control of the computer.

PHASE-LOCK LOOP: An electrical servo system used either as a tracking filter or as a frequency discriminator.

PRIME CHANNELS: The channels which are sequentially sampled by the basic commutator of the system.

FOR TRAINING PURPOSES ONLY

Study Guide

PRIME FRAME: A group of words resulting from a complete sampling of the prime channel.

PROGRAM: A sequence of instructions that causes a data processing system to process a specific application; a plan for the solution of a problem.

PSEUDO INSTRUCTION: A symbolic representation of information to a compiler or interpreter; a group of characters having the same general form as a computer instruction, but never executed by the computer as an actual instruction.

PYRAMID, BORROW: A network of inverters that senses borrow conditions and produces borrow signals.

R-START: Relay selection START modules.

RAW-DATA: Data that has not been processed; it may or may not be in machinesensible form.

READ: To copy, usually from one form of storage to another, particularly from external or secondary storage to internal storage; to sense the presence of information on a recording medium.

REAL-TIME PROCESS: A process where the computer exists on line in an environment that cannot be made subservient to computer control. Usually a continuous physical process is involved.

RECORD: A group of related facts or a field of information that is treated as a unit.

RECORD HEAD: An electromagnetic transducer used during the recording process for inducing magnetic patterns into the magnetic tape.

REGISTER: A device for storing one or more computer words.

RELOCATE: To move a routine from one portion of internal storage to another and, in so doing, to automatically adjust the address references so that the routine can be executed in its new location.

REPRODUCE HEAD: An electronic transducer that converts the remanent flux patterns in a magnetic tape into electrical signals.

ROUTINE: Essentially synonymous with "program," although generally restricted to describing single-purpose programs.

ROUTINE, EXECUTIVE: A set of coded instructions designed to process and control other sets of coded instructions.

SCS: Stabilization and Control System.

SEAL: Select Extend Allocated Lockout.

SEGMENTATION: Division of a routine into parts, one segment being the "main program" and other segments being subprograms. The segments are linked together by CALL-type statements and may be compiled and debugged separately.

SENSE: To examine, particularly relative to a criterion; to determine the present arrangement of some element of hardware, especially a manually set switch.

SERIAL TRANSFER: A system of data transfer in which elements of information are transferred in succession over a single line.

SERIAL RECORDING, PCM: The technique of recording a train of bits on a single magnetic tape track.

SGS: Symbol Generator and Storage Unit.

SHIFT: To move the bits of a quantity right or left.

SIGN BIT: The bit in the highest-order stage of the register (in registers where a quantity is treated as signed by use of one's complement notation). If the bit is "1," the quantity is negative; if the bit is "0," the quantity is positive.

SIGN EXTENTION: The duplication of the sign bit in the highest-order stages of a register.

SKEW: Tape motion characterized by an angular velocity between the gap centerline and a line perpendicular to the tape centerline.

SM or S/M: Service Module.

SOURCE PROGRAM: A program coded in other than machine language that must be translated into machine language to be executed by a computer.

SPACECRAFT TEST PROGRAM: A computer program package containing the control programs, TEX's, etc., required to describe a single spacecraft test.

START: Selection to Activate Random Testing.

STATUS: The condition of an external device, as reflected in the response given a status interrogation by the computer.

STORAGE: Memory.

SUBCARRIER: A carrier which is applied as a modulating wave to modulate another carrier or an intermediate subcarrier.

SUBROUTINE: The set of instructions necessary to direct the computer to carry out a well-defined mathematical or logical operation.

SUBROUTINE, CLOSED: A subroutine not stored in the main path of the routine. Such a subroutine is entered by a jump operation with provision made to return control to the main routine at the end of the operation.

SUBROUTINE, OPEN: Has been, in general, replaced by the term "Macro Instruction." It is a subroutine inserted directly into the main path of the routine, not entered by a jump. Such a subroutine must be recopied at each point at which it is needed.

SUPERVISORY EXECUTIVE PROGRAM (SEP): The monitor program that exercises supervisory control over the use of spacecraft test programs during real-time testing of spacecraft. Glossary

FOR TRAINING PURPOSES ONLY

Study Guide

SUBCOMMUTATION: Commutation of additional channels with output applied to individual channels of the primary commutator.

SUBCOMMUTATION FRAME: In PCM systems, a recurring integral number of subcommutator words which includes a single subcommutation frame synchronization word.

SUBPROGRAM: A segment of a larger program capable of being compiled and debugged by itself.

SUPERCOMMUTATION: Commutation at higher rate by connection of single data input source to equally spaced contacts of the commutator.

SYMBOLIC CODING: Any coding system in which symbols other than machine addresses and machine language are used.

TABLE LOOKUP: A coding technique or an instruction that locates the word in a table corresponding to a specified word, and usually obtains some other word that corresponds to the word located.

TAPE, MAGNETIC: A tape or ribbon of some material impregnated or coated with magnetic material on which information can be placed in the form of magnetically polarized spots.

TAPE SPEED ERRORS: Any variation of the tape speed from its nominal speed over the record or reproduce head regardless of cause.

TELEMETRY (T/M): The science of measuring a quantity of quantities, transmitting the results to a distant station, and there interpreting, indicating, and/or recording the quantities measured.

TEST EXECUTIVE (TEX): A computer program or subprogram written specifically to meet spacecraft system test sequence requirements for real-time operation.

TEST FILE: One or more spacecraft test programs on magnetic tape, limited only by the length of the tape.

FOR TRAINING PURPOSES ONLY

Study Guide

TIMING SIGNAL: Any signal recorded simultaneously with data to provide a time index.

TRACKS: A portion of a magnetic tape the width and position of which on the magnetic tape is specified. A track extends throughout the entire length of a reel of tape and always exists regardless of its state of magnetization.

TWO'S COMPLEMENT: The two's complement may be formed by complementing each bit of the given number and then adding one to the result, performing the required carries.

UPLINK CONTROL PROGRAM: A computer program that generates commands to the DTCS to provide stimuli to the spacecraft according to information received from the CUE.

UTILITY PROGRAM: A program normally used to assist in the operation of a data processing system (memory dump, card-to-tape, etc.).

VDTTC: Video Distribution and Tape Transport Control Unit.

VIDEO RECORDING: The method of recording information having a bandwidth in excess of 500 kilocycles on a single track.

WORD: An ordered set of digits processed as a unit.

WOW and FLUTTER: Terms derived from disc and motion picture sound recording often used in reference to speed change errors in magnetic recording.

WRITE: To transfer information to an output recorder; to copy, usually from internal storage to external storage; to record information in a register, location, or other storage device.

SUPPLEMENTS

ACCEPTANCE CHECKOUT EQUIPMENT-SPACECRAFT (ACE-S/C)

FOR

TRAINING

URPOSES ONLY

ACE-S/C PROVIDES AN ADVANCED METHOD OF SEMI-AUTOMATIC CHECKOUT FOR APOLLO SPACECRAFT



,EE

FOR

TRAINING PURPOSES ONLY

ACCEPTANCE CHECKOUT EQUIPMENT - S/C SIMPLIFIED BLOCK DIAGRAM

(UPLINK)

ACCEPTANCE CHECKOUT EQUIPMENT -S/C



1-3

il mor

1

1-4

FOR

TRAINING PURPOSES ONLY



ACCEPTANCE CHECKOUT EQUIPMENT -S/C (DOWNLINK)

FOR

TRAINING PURPOSES ONLY

TOWNLINK

D	TC	S	AD	DRI	ESS	CO	DES	F	OR	CMU
				GR	OUP A	DDR	ESS			
2	11	210	29 (1	NORD	10.2)					
0		0	I 0			G	ROUP	NO. NO.	1 2	
 0 		0	0			0 0 0	ROUP ROUP ROUP	NO. NO. NO.	3 4 5 (G	BIN)
				BASE			DRESS			
5	.4	•	3 2	INOL						
2	2	2	2	(WOF	ID NO. I	1				
.0	0	0	1			E	ASEPL	ATE	NO. I	
0	0	0	0				ASEPL	ATE	NO. 2	
I I	0	0	0			E	ASEPL	ATE	NO. 4	
. 0	1	1	1			E	ASEPL	ATE	NO. 5	
1	0	1	1			E	ASEPL	ATE	NO. 6	
I	I	0	1			Ē	BASEPL	ATE	NO. 7	
I	1	1	0			E	BASEPL	ATE	NO. 8	
				мо	DULE	ADD	RESS			
2	8	<u>2</u> 7	<u>2</u> ⁶ (WORD	NO. 2)			•		
c	,	0	1			1	MODULE	NO	.1	
() .	1	0			1	MODULE	E NO	. 2	
۰. ۱	1	0	0			۱	NODULE	E NO	. 3	
	King	1	1			1	MODULI	E NO	. 4	
•				SUB	GROUP	ADI	DRESS			
-	5	24	23 (WORD	NO. 2)					
. (2	0	1				SUBGRO	UP	A	
()	1	0				SUBGRO	UP	В	
	1 3	0	0				SUBGRO	OUP	С	
(0	0	0				SUBGRO	OUP	D	

FOR TRAINING PURPOSES ONLY

FOR TRAINING PURPOSES ONLY

CMU DATA WORDS INPUTS

CUE/START STATUS WORDS





DTCS STATUS WORDS







PERIPHERAL STATUS WORDS



FOR TRAINING PURPOSES ONLY

2-2

K-START COMMAND FORMAT



2-3

R-START COMMAND FORMAT



FOR TRAINING PURPOSES ONLY

2-4

C-START COMMAND FORMAT



FOR TRAINING PURPOSES ONLY

2-5

PROGRAMING REQUIREMENTS

DOWNLINK DATA REDUCTION & DISPLAY UPLINK COMMAND GENERATION AUTOMATIC LIMIT ADJUSTMENT ACE SELF-TEST ACE DIAGNOSTICS PROGRAM VERIFICATION SUPERVISORY PROGRAM LIBRARY MAINTENANCE

PROGRAM VERIFICATION

ACCOMPLISHED WITHIN ACE, USING VERIFICATION PROGRAMS

FOR DOWNLINK PROGRAMS:-

UPLINK COMPUTER GENERATES SIMULATED INPUT DATA

OPERATION OF DOWNLINK PROGRAM ON KNOWN DATA IS CHECKED

FOR UPLINK PROGRAMS:-

UPLINK & DOWNLINK COMPUTERS CONNECTED VIA BACK-TO-BACK DTVC

DOWNLINK COMPUTER SINULATES REMOTE END OF Command links

UPLRIK COMMANDS, GENERATED IN PRESCRIBED ORDER, CHECKED BY DOWNLINK COMPUTER



UPLINK CARD 2 FORMAT

FOR

TRAINING

PURPOSES ONLY

a.	FIELD 12 - STIMULUS NUMBER
b.	FIELD 13 - CHANGE CODE
c.	FIELD 14 - C-START INSERT
d.	FIELD 15 - R-START INSERT
e.	FIELD 16 - REMARKS _ OCI - ETC
f.	FIELD 17 - TEST IDENTIFICATION
g.	FIELD 18 - RESERVED FOR GE
h.	FIELD 19 - MULTIPLE STIMULI LISTING
i.	FIELD 20 - CARD NUMBER

DOWNLINK CARD 1 FORMAT

- a. FIELD 1 MEASUREMENT ID
- b. FIELD 2 MEASUREMENT ID LINK
- c. FIELD 3 -" MULTI-DISPLAY
- d. FIELD 4 MEASUREMENT DESCRIPTION

FOR

TRAINING

PURPOSES

ONLY

- e. FIELD 5 FIRST PRIME FRAME
- f. FIELD 6 TIME SLOT V
- g. FIELD 7 WORD FRAGMENT
- h. FIELD 8 RATE
- i. FIELD 9 PRIME FRAME INCREMENT
- j. FIELD 10 OFF STATE
- k. FIELD 11 MODULE
- I. FIELD 12 RECORDER
- m. FIELD 13 CHANGE CODE
- n. FIELD 14 CARD NUMBER

DOWNLINK CARD 2 FORMAT

- a. FIELD 15 MEASUREMENT ID
- b. FIELD 16 MEASUREMENT ID LINK
- c. FIELD 17 MULTI-DISPLAY
- d. FIELD 18 SCOPE READOUT DISPLAY
- e. FIELD 19 ENGINEER UNITS
- f. FIELD 20 PAGE
- g. FIELD 21 LINE
- h. FIELD 22 DIGIT CONFIGURATION
- i. FIELD 23 SCOPE FORMAT ID

FOR

DOWNLINK CARD 2 FORMAT

	1902		-		-					-		-	1	-		-	-		-	-	-	-	-	-	-	-	-	-			-
-	4000		5		-			-				- 12			13			2015												Т	
	-				-				1_		1.00							1000						. 1							
			-	-		100		01				-	-				-				and the second		-		-		-	-	-		-

FOR

- k. FIELD 25 TEST ID
- I. FIELD 26 LIMITS
- m. FIELD 27 CATEGORY
- n. FIELD 28 OBSOLETE
- o. FIELD 29 SPECIAL
- p. FIELD 30 CHANGE CODE
- q. FIELD 31 CARD NUMBER

DOWNLINK CARD 3 FORMAT

-	FIELD	27 -	MEASI	DEMEN	UT ID
u.	LIEFA	JT -	MEAJO	REMEI	

- b. FIELD 33 MEASUREMENT 1D LINK
- c. FIELD 34 MULTI-DISPLAY
- d. FIELD 35 LABELING INFORMATION
- e. FIELD 36 NOT USED
- f. FIELD 37 METER SCALING
- g. FIELD 38 METER SCALE CODE
- h. FIELD 39 SECOND MODULE/RECORDER
- i. FIELD 40 ADDITIONAL MODULES CODE
- j. FIELD 41 RESERVED FOR G.E.
- k. FIELD 42 CHANGE CODE
- I. FIELD 43 CARD NUMBER

-01

DOWNLINK CARD 4 FORMAT

- a. FIELD 44 MEASUREMENT ID
- b. FIELD 45 MEASUREMENT ID LINK
- c. FIELD 46 MULTI-DISPLAY
- d. FIELD 47 MODULE/RECORDER
- e. FIELD 48 MODULE/RECORDER
- f. FIELD 49 REMARKS
- g. FIELD 50 CHANGE CODE
- h. FIELD 51 CARD NUMBER

FOR
DOWNLINK CARD 5 FORMAT

FOR

TRAINING

PURPOSES ONLY

- a. FIELD 52 MEASUREMENT 1D
- b. FIELD 53 MEASUREMENT 1D LINK
- c. FIELD 54 MULTI-DISPLAY
- d. FIELD 55 ADDITIONAL REMARKS
- e. FIELD 56 CHANGE CODE
- f. FIELD 57 CARD NUMBER

LIMIT CHANGE CARD 1 FORMAT

a. FIELD 1 - MEASUREMENT ID

b. FIELD 2 - MEASUREMENT ID LINK

FOR

TRAINING

PURPOSES

ONLY

- c. FIELD 3 MULTI-DISPLAY
- d. FIELD 4 NOT USED
- e. FIELD 5 LIMIT VALUE 1
- f. FIELD 6 LIMIT VALUE 2
- g. FIELD 7 NOT USED
- h. FIELD 8 DIGIT CONFIGURATION
- i. FIELD 9 REMARKS
- j. FIELD 10 VEHICLE ID
- k. FIELD 11 CHANGE CODE

SEPARATOR CARD 2 FORMAT

FOR TRAINING PURPOSES ONLY

a. FIELD 12 - SEPARATOR I.D.

b. FIELD 13 - REMARKS

CALIBRATION DATA CARD 3 FORMAT

a.	FIELD 14 - MEASUREMENT	Dh.	FIELD 21 - POINT VALUE 4
ь.	FIELD 15 - MEASUREMENT	i.	FIELD 22 - POINT VALUE
		i.	FIELD 23 - POINT VALUE
с.	FIELD 16 - MULTI-DISPLAY		
d.	FIELD 17 - SEGMENTS	K.	CONFIGURATION
e.	FIELD 18 - POINT VALUE 1		FIELD 25 - REMARKS
f.	FIELD 19 - POINT VALUE 2		FIELD 26 - VEHICLE ID
12			
g.	FIELD 20 - POINT VALUE 3	n.	FIELD 27 - CHANGE CODE

3-13

FOR

TRAINING

PURPOSES ONLY



FOR TRAINING PURPOSES ONLY

OPERATOR AND MAINTENANCE CONSOLE



UPLINK - DOWN LINK OHECK ? TALK TOGETHER THRU ? 169 G. MEMORY LINK 3-15





U0012 ACTIVATE RELAY SEQUENCE (R-START)









U0002 C-START ROUTINE



U0007 SINE WAVE GENERATION

"C" STREET







"C'START

U0007 SINE WAVE GENERATION











U0020 C-START ACTIVATE RELAY







LEM TEST AREA



410-92241 S/E DTCS 410-92484 EXTERNAL SIGNAL CONDITIONER 410-92240 SERVICE EQUIPMENT ADAPTER 410-92232 DATA INTERLEAVER SYSTEM (MDIS)

4-1

FOR

BASEPLATE GROUP



4-2

LATCHING, CONVENTIONAL RELAY AND DAC MODULES



RESISTOR BANK





RECEIVER GROUP



GUIDANCE AND NAVIGATION BUFFER UNIT



WORD SELECT SIMPLIFIED

FOR

TRAINING PURPOSES ONLY



C14-212 ANALOG SIGNAL CONDITIONER MODULES

PVR 200/201	POWER CONVERTER,
CAG 220	CARRIER SIGNAL GENERATOR
TER 210	TRANSDUCER EXCITATION POWER REGULATOR
REC 4/8/32	PSD REFERENCE CONDITIONER
REC 25.6	PSD REFERENCE CONDITIONER
REG 800/3200/25.6	PSD REFERENCE GENERATOR
PSD 51/52/53/55/56	PHASE SENSITIVE DEMODULATOR
ACD 40/41/42	AC TO DC CONVERTER
DCD 11/12/13	DC TO DC CONVERTER
ANC 130/131	AC NOISE GENERATOR
ISA 20/22	ISOLATION ATTENUATOR
EVA 70/71	EVENT ATTENUATOR
ASR 230	ANALOG STANDARD REGULATOR
FRD 60	FREQUENCY TO DC CONVERTER
DCA 02	DIRECT CURRENT AMPLIFIER
VRD 30	VARIABLE RESISTANCE TO DC CONVERTER



MDIS ENCLOSURE



5-4

DATA ACQUISITION SUBSYSTEM



FOR TRAINING PURPOSES ONLY

FOR TRAINING PURPOSES ONLY







ASPO ACE-S/C FORM No. 3-1

FOR TRAINING PURPOSES ONLY

			DI	S	P		41	,	9	SC	:0	PI	E	S	P	A (N	G	(СН		R	г		PR	HIC	LE	A	PO		o		TE	ST		6.	4			
										SYS														STE	M	R	CS				DA	TE 5	FEBRUARY 19								
LI	NE		F	EL	D			-	-	FIELD I													_						FI	EL	DI	ш				, 1¥					
	-	R	C	S		P	G		2		L	0	5											-							-			15		-		-			-
-	2									-		-	-	-										Т	A	N	K	-	A		T	A	N	K		B		T	a	-	
o	3	C	R	0	0	0	1		Н	E		P	R	E	S	S											5	•	4					5	•	3		P	2	1	A
P	4	C	R	0	0	0	3		H	E		T	E	M	Ρ										-	2	4	•	4			-	2	3		6		D	E	G	F
H	5	C	R	0	0	0	7		F	U	E	L		Q	U	A	N	T	I	T	Y	1				4	4		9				4	4		6		L	B	S	
	6	C	R	0	0	1	3		0	X	I	D	I	Z	E	R		Q	U	A	N	T		1		8	7		4				8	8		3		L	B	S	
F	7	С	R	0	5	0	2		H	E		R	E	G		0	U	Т				1					1	9	8					2	0	4		P	S	Ι	A
P	8		2.5			S	E		v	Ι	C	E		M	0	D	-	R	C	S								10		-											
A	9	S	R	5	0	0	1		H	E		P	R	E	S	S	2.4										5		6					5		7		P	S	Ι	A
E	10	S	R	5	0	0	5		H	E		Т	E	M	Р										-	3	1		2			-	3	0		4		D	E	G	F
	11	S	R	5	0	1	3		F	U	E	L		Q	U	A	N	T	I	Т	Y					5	0		0				4	9		9		L	В	S	
	12	S	R	5	0	2	5		0	x	I	D	I	z	E	R		Q	U	A	N	Т				8	6		4				8	7		2		L	B	S	
	13	S	R	5	0	6	5		E	N	G	I	N	E		P	A	C	K	A	G	E		1		6	7		3			1000	6	4		2		D	E	G	F
	14	T									T									2					B	U	S		A			B	U	S		В					Γ

US

BUS

2 4

2

2

2 4

3 1

3

2

4

2 3

1

4

3

2

4

9

8

1

5 6

6

3

7

2

2

08

4

2

7

9

0

B

PYRO

BUS

BUS

BUS

0

4

RO

G

C

С

PY

P

P Y L O

T E P Y

S A

ARM

B

LOGI

ER

LES

PY

Т

P

N

0

RO

GI

FE

US

RO

R

YRO

T W R L E S

 A
 D
 A

 L
 E
 S

 E
 L
 S

 M
 A
 I

 T
 W
 R

 L
 E
 S

ADAP

8 9

7

8 5

0 5

0 5

0 7

0 9

16

8

5

4

1

1

0

2

4

DISPLAY SCOPE SPACING CHART GIVING AN EXAMPLE

FOR TRAINING PURPOSES ONLY

AFRACE

15 16

17

18

21

22

23

25 26

BOTTOM

HALF 20 CD

P

AGE

Т D

С

T

D

D

CD

CD

CD

CD

CD

С

D

0 1

0

0

0 0

0 2

0 2

0 2

0 2

0 2

2 3

0

2

2 0

2

ASPO ACE-S/C FORM No. 3-1

3

1

4

9

7

0

2

2 5

3

3

2

5

2

6

0

4

7

7

6

2

9

V D C V D C

V D C V D C V D C

A M P S A M P S A M P S

С

C

VD VD



Real Countdown-Time Distribution Block Diagram (All Sites Except MILA)




THE AMR B-1 TIME CODE IS A 17-DIGIT WIDTH MODULATED CODE. THE CODE IS COMPOSED OF A REFERENCE MARKER, THREE SUB-CODE WORDS OF SECONDS, MINUTES AND HOURS AND INDEX MARKERS. EACH SUB-CODE WORD IS WEIGHTED IN BINARY FASHION.

THE LEADING EDGES OF ALL PULSES ARE PRECISELY SPACED AT 1-SECOND INTERVALS. THE CODE TIME FRAME IS 20 SECONDS. THE SUM OF THE CODED TIME REFERS TO THE LEADING EDGE OF THE CODE WORD REFER-ENCE MARKER.

THE CODE MAY BE USED TO AMPLITUDE MODULATE A SINE WAVE CARRIER. FRE-QUENCY SHOULD BE SPECIFIED. 1000 CPS OR 100 CPS IS RECOMMENDED. THE CODE FORMAT IS THEN REFERRED TO AS AMR B-2.



ACE-S/C Countdown-Time Code Format

FOR TRAINING PURPOSES ONLY

4-6

IRIG B TIME STANDARD CODE



RECOMMENDED FREQUENCY, 1000 CPS

Progress Is Our Most Important Product GENERAL B ELECTRIC

TECHNICAL PUBLICATIONS DB66G094