EVA Checklist

STS-116 Flight Supplement

Mission Operations Directorate EVA, Robotics, and Crew Systems Operations Division

Final November 15, 2006

NOTE

This supplement is to be integrated into the generic edition to provide a complete document for the specific flight. Some pages in the generic edition may be replaced with supplemental pages identified as 'TEMP'. These generic pages, if any, must be retained for use on future flights.

National Aeronautics and Space Administration

Lyndon B. Johnson Space Center Houston, Texas



MISSION OPERATIONS DIRECTORATE

EVA CHECKLIST STS-116 FLIGHT SUPPLEMENT

FINAL November 15, 2006

PREPARED BY:

Book Manager

APPROVED BY:

Tricia K. Mack

Lead, EVA Systems Group

Randall S. McDaniel Lead, EVA Task Group

/ Angela R. Prince

Chief, EVA and Crew Systems Operations Branch

This document is under the configuration control of the Crew Procedures Control Board (CPCB). All proposed changes must be submitted via FDF Workflow Crew Procedure Change Request (CR) to DO3/FDF Manager.

Additional distribution of this book, for official use only, may be requested in writing to DO3/PMO Administrator. The request must include justification and requester's name, organization, position, and phone number. Contractor requests are made through the NASA or DOD organization supported. Deletions, reduction in quantity, or change of address may be submitted to DO3/FDF Management Office, 281-244-1184.

		Incorporates the following:	
482#:	EVA-1721	EVA-1732	
	EVA-1725	EVA-1733	
	EVA-1726	EVA-1734	
	EVA-1727	EVA-1737	
	EVA-1728	EVA-1738	
	EVA-1729	EVA-1739	
	EVA-1730	EVA-1740	
	EVA-1731	EVA-1741	

AREAS OF TECHNICAL RESPONSIBILITY

Book Manager DX32/C. Hansen 281-483-7522

FS ii EVA/116/FIN

EVA CHECKLIST STS-116 FLIGHT SUPPLEMENT

LIST OF EFFECTIVE PAGES

FINAL 11/15/06

Sign Off*		FS 2-16	116/FIN
FS ii*	116/FIN	FS 2-17	116/FIN
iii*	generic	FS 2-18	116/FIN
iv*	generic	FS 2-19	116/FIN
FS v*	116/FIN	FS 2-20	116/FIN
FS vi*	116/FIN	FS 2-21	116/FIN
FS vii*	116/FIN	FS 2-22	116/FIN
FS viii*	116/FIN	FS 2-23	116/FIN
FS ix*	116/FIN	FS 2-24	116/FIN
FS x*	116/FIN	3-1	generic
FS xi*	116/FIN	3-2	generic
FS xii*	116/FIN	3-3	•
FS xiii	116/FIN		generic
FS xiv	116/FIN	3-4	generic
FS xv	116/FIN	3-5	generic
FS xvi	116/FIN	3-6	generic
FS xvii	116/FIN	3-7	generic
FS xviii	116/FIN	3-8	generic
FS xix	116/FIN	3-9	generic
FS xx	116/FIN	CC 3-10	generic
FS xxi	116/FIN	CC 3-11	generic
FS xxii	116/FIN	3-12	generic
1-1	generic	4-1	generic
1-2	generic	4-2	generic
1-3	generic	4-3	generic
1-4	generic	4-4	generic
	•	4-5	generic
1-5	generic	4-6	generic
1-6	generic	4-7	generic
1-7	generic	4-8	generic
1-8	generic	4-9	generic
1-9	generic	4-10	generic
1-10	generic		
TEMP FS 2-1	116/FIN	4-11	generic
TEMP FS 2-2	ALL/FIN	4-12	generic
2-3	generic	5-1	generic
2-4	generic	5-2 5-3	generic
TEMP FS 2-5	116/FIN		generic
TEMP FS 2-6	ALL/FIN	5-4 B6-1	generic
FS 2-7	116/FIN		generic
FS 2-8	116/FIN	CC B6-2	generic
FS 2-9	116/FIN	6-3	generic
FS 2-10	116/FIN	CC 6-4	generic
		FS 7-1	116/FIN
FS 2-11	116/FIN	FS 7-2	116/FIN
FS 2-12	116/FIN	FS 7-3	116/FIN
FS 2-13	116/FIN	FS 7-4	116/FIN
FS 2-14	116/FIN	FS 7-5	116/FIN
FS 2-15	116/FIN	FS 7-6	116/FIN

^{* –} Omit from flight book

50 7 7	4.40/5111	E0 7 00	4.40/511
FS 7-7	116/FIN	FS 7-60	116/FIN
FS 7-8	116/FIN	FS 7-61	116/FIN
FS 7-9	116/FIN	FS 7-62	116/FIN
FS 7-10	116/FIN	FS 7-63	116/FIN
FS 7-11	116/FIN	FS 7-64	116/FIN
FS 7-12	116/FIN	FS 7-65	116/FIN
FS 7-13	116/FIN	FS 7-66	116/FIN
FS 7-14	116/FIN	FS 7-67	116/FIN
FS 7-15	116/FIN	FS 7-68	116/FIN
FS 7-16	116/FIN	FS 7-69	116/FIN
FS 7-17	116/FIN	FS 7-70	116/FIN
			_
FS 7-18	116/FIN	FS 7-71	116/FIN
FS 7-19	116/FIN	FS 7-72	116/FIN
FS 7-20	116/FIN	FS 7-73	116/FIN
FS 7-21	116/FIN	FS 7-74	116/FIN
FS 7-22	116/FIN	FS 7-75	116/FIN
FS 7-23	116/FIN	FS 7-76	116/FIN
FS 7-24	116/FIN	FS 7-77	116/FIN
FS 7-25	116/FIN	FS 7-78	116/FIN
FS 7-26	116/FIN	FS 7-79	116/FIN
FS 7-27	116/FIN	FS 7-80	116/FIN
FS 7-28	116/FIN	FS 7-81	116/FIN
FS 7-29	116/FIN	FS 7-82	116/FIN
FS 7-30	116/FIN	FS 7-83	116/FIN
FS 7-31	116/FIN	FS 7-84	116/FIN
FS 7-32	116/FIN 116/FIN	FS 7-85	116/FIN
	-	FS 7-86	
FS 7-33	116/FIN		116/FIN
FS 7-34	116/FIN	FS 7-87	116/FIN
FS 7-35	116/FIN	FS 7-88	116/FIN
FS 7-36	116/FIN	FS 7-89	116/FIN
FS 7-37	116/FIN	FS 7-90	116/FIN
FS 7-38	116/FIN	FS 7-91	116/FIN
FS 7-39	116/FIN	FS 7-92	116/FIN
FS 7-40	116/FIN	FS 7-93	116/FIN
FS 7-41	116/FIN	FS 7-94	116/FIN
FS 7-42	116/FIN	FS 7-95	116/FIN
FS 7-43	116/FIN	FS 7-96	116/FIN
FS 7-44	116/FIN	TEMP FS 8-1	116/FIN
FS 7-45	116/FIN	TEMP FS 8-2	116/FIN
FS 7-46	116/FIN	8-3	generic
FS 7-47	116/FIN	8-4	generic
FS 7-48	116/FIN	8-5	generic
FS 7-49	116/FIN	8-6	generic
FS 7-50	116/FIN	FS 8-7	116/FIN
FS 7-51	116/FIN	FS 8-8	116/FIN
FS 7-52	116/FIN		116/FIN
		FS 8-9	_
FS 7-53	116/FIN	FS 8-10	116/FIN
FS 7-54	116/FIN	FS 8-11	116/FIN
FS 7-55	116/FIN	FS 8-12	116/FIN
FS 7-56	116/FIN	FS 8-13	116/FIN
FS 7-57	116/FIN	FS 8-14	116/FIN
FS 7-58	116/FIN	FS 8-15	116/FIN
FS 7-59	116/FIN	FS 8-16	116/FIN

EC 0 47	440/EINI	40.40	
FS 8-17	116/FIN	12-10	generic
FS 8-18	116/FIN	12-11	generic
FS 8-19	116/FIN	12-12	generic
FS 8-20	116/FIN	12-13	generic
FS 8-21	116/FIN	12-14	generic
FS 8-22	116/FIN	12-15	generic
FS 8-23	116/FIN	12-16	generic
FS 8-24	116/FIN	12-17	generic
FS 8-25	116/FIN	12-18	generic
FS 8-26	116/FIN	12-19	generic
FS 8-27	116/FIN	12-20	generic
FS 8-28	116/FIN	12-21	generic
FS 8-29	116/FIN	12-22	•
			generic
FS 8-30	116/FIN	12-23	generic
FS 8-31	116/FIN	12-24	generic
FS 8-32	116/FIN	12-25	generic
9-1	generic	12-26	generic
9-2	generic	FS 12-27	116/FIN
9-3	generic	FS 12-28	116/FIN
9-4	generic	FS 12-29	116/FIN
9-5	generic	FS 12-30	116/FIN
9-6	generic	FS 12-31	116/FIN
TEMP FS 10-1	116/FIN	FS 12-32	116/FIN
TEMP FS 10-2	ALL/FIN	FS 13-1	116/FIN
10-3	generic	FS 13-2	116/FIN
10-4	generic	14-1	generic
10-5	generic	14-2	generic
10-6	generic	14-3	generic
10-7	generic	14-4	generic
10-8	generic	14-5	generic
10-9	generic	14-6	generic
10-10	generic	14-7	generic
10-11	generic	14-8	generic
10-12	generic	14-9	generic
FS CC 10-13	116/FIN	14-10	generic
FS CC 10-14	116/FIN	14-11	generic
FS 10-15	116/FIN	14-12	generic
FS 10-16	116/FIN	14-13	generic
11-1	generic	14-14	-
	U	14-15	generic
11-2	generic		generic
11-3	generic	14-16	generic
11-4	generic	14-17	generic
12-i	generic	14-18	generic
12-ii	generic	14-19	generic
TEMP FS 12-1	116/FIN	14-20	generic
TEMP FS 12-2	ALL/FIN	14-21	generic
12-3	generic	14-22	generic
12-4	generic	15-1	generic
12-5	generic	15-2	generic
12-6	generic	15-3	generic
12-7	generic	15-4	generic
12-8	generic	15-5	generic
12-9	generic	15-6	generic
12 0	90110110	10 0	generie

15-7	generic	FS 16-44	116/FIN
15-8	generic	FS 16-45	116/FIN
15-9	generic	FS 16-46	116/FIN
15-10	generic	FS 16-47	116/FIN
15-11	generic	FS 16-48	116/FIN
	•		
15-12	generic	FS 16-49	116/FIN
15-13	generic	FS 16-50	116/FIN
15-14	generic	FS 16-51	116/FIN
16-i	generic	FS 16-52	116/FIN
16-ii	generic	FS 16-53	116/FIN
TEMP FS 16-1	116/FIN	FS 16-54	116/FIN
TEMP FS 16-2	ALL/FIN	FS 16-55	116/FIN
FS 16-3	116/FIN	FS 16-56	116/FIN
FS 16-4	116/FIN	FS 16-57	116/FIN
FS 16-5	116/FIN	FS 16-58	116/FIN
FS 16-6	116/FIN	FS 16-59	116/FIN
FS 16-7			
	116/FIN	FS 16-60	116/FIN
FS 16-8	116/FIN	FS 16-61	116/FIN
FS 16-9	116/FIN	FS 16-62	116/FIN
FS 16-10	116/FIN	FS 16-63	116/FIN
FS 16-11	116/FIN	FS 16-64	116/FIN
FS 16-12	116/FIN	FS 16-65	116/FIN
FS 16-13	116/FIN	FS 16-66	116/FIN
FS 16-14	116/FIN	FS 16-67	116/FIN
FS 16-15	116/FIN	FS 16-68	116/FIN
FS 16-16	116/FIN	FS 16-69	116/FIN
FS 16-17	116/FIN	FS 16-70	116/FIN
FS 16-18	116/FIN	FS 16-71	116/FIN
FS 16-19	116/FIN	FS 16-72	116/FIN
FS 16-20	116/FIN	FS 16-73	116/FIN
FS 16-21	116/FIN	FS 16-74	116/FIN
FS 16-22	116/FIN	FS 16-75	116/FIN
FS 16-23	116/FIN	FS 16-76	116/FIN
FS 16-24	116/FIN	FS 16-77	116/FIN
FS 16-25	116/FIN	FS 16-78	116/FIN
FS 16-26	116/FIN	FS 16-79	116/FIN
FS 16-27	116/FIN	FS 16-80	116/FIN
FS 16-28	116/FIN	FS 16-81	116/FIN
FS 16-29	116/FIN	FS 16-82	116/FIN
FS 16-30	116/FIN	FS 16-83	116/FIN
FS 16-31	116/FIN	FS 16-84	116/FIN
FS 16-32	116/FIN	FS 16-85	116/FIN
FS 16-33	116/FIN	FS 16-86	116/FIN
FS 16-34	116/FIN	FS 16-87	116/FIN
FS 16-35	116/FIN	FS 16-88	116/FIN
FS 16-36	116/FIN	FS 16-89	116/FIN
FS 16-37	116/FIN	FS 16-90	116/FIN
FS 16-38	116/FIN	FS 16-91	116/FIN
FS 16-39	116/FIN	FS 16-92	116/FIN
FS 16-40	116/FIN	FS 16-93	116/FIN
FS 16-41	116/FIN	FS 16-94	116/FIN
FS 16-42	116/FIN	FS 16-95	116/FIN
FS 16-43	116/FIN	FS 16-96	116/FIN

FS 16-97	116/FIN	FS 16-150	116/FIN
FS 16-98	116/FIN	FS 16-151	116/FIN
FS 16-99	116/FIN	FS 16-152	116/FIN
FS 16-100	116/FIN	FS 16-153	116/FIN
FS 16-101	116/FIN	FS 16-154	116/FIN
FS 16-102	116/FIN	FS 16-155	
			116/FIN
FS 16-103	116/FIN	FS 16-156	116/FIN
FS 16-104	116/FIN	FS 16-157	116/FIN
FS 16-105	116/FIN	FS 16-158	116/FIN
FS 16-106	116/FIN	FS 16-159	116/FIN
FS 16-107	116/FIN	FS 16-160	116/FIN
FS 16-108	116/FIN	FS 16-161	116/FIN
FS 16-109	116/FIN	FS 16-162	116/FIN
			-
FS 16-110	116/FIN	FS 16-163	116/FIN
FS 16-111	116/FIN	FS 16-164	116/FIN
FS 16-112	116/FIN	FS 16-165	116/FIN
FS 16-113	116/FIN	FS 16-166	116/FIN
FS 16-114	116/FIN	FS 16-167	116/FIN
FS 16-115	116/FIN	FS 16-168	116/FIN
FS 16-116	116/FIN	17-1	generic
FS 16-117	116/FIN	17-2	generic
FS 16-118	116/FIN	FS 18-1	116/FIN
FS 16-119	116/FIN	FS 18-2	116/FIN
FS 16-120	116/FIN	FS 18-3	116/FIN
FS 16-121	116/FIN	FS 18-4	116/FIN
FS 16-122	116/FIN	FS 18-5	116/FIN
FS 16-123	116/FIN	FS 18-6	116/FIN
	-		-
FS 16-124	116/FIN	FS 18-7	116/FIN
FS 16-125	116/FIN	FS 18-8	116/FIN
FS 16-126	116/FIN	FS 18-9	116/FIN
FS 16-127	116/FIN	FS 18-10	116/FIN
FS 16-128	116/FIN	FS 18-11	116/FIN
FS 16-129	116/FIN	FS 18-12	116/FIN
FS 16-130	116/FIN	FS 18-13	116/FIN
		FS 18-14	116/FIN
FS 16-131	116/FIN		
FS 16-132	116/FIN	FS 18-15	116/FIN
FS 16-133	116/FIN	FS 18-16	116/FIN
FS 16-134	116/FIN	FS 18-17	116/FIN
FS 16-135	116/FIN	FS 18-18	116/FIN
FS 16-136	116/FIN	FS 18-19	116/FIN
FS 16-137	116/FIN	FS 18-20	116/FIN
FS 16-138	116/FIN	FS 18-21	116/FIN
		FS 18-22	116/FIN
FS 16-139	116/FIN		
FS 16-140	116/FIN	FS 18-23	116/FIN
FS 16-141	116/FIN	FS 18-24	116/FIN
FS 16-142	116/FIN	FS 18-25	116/FIN
FS 16-143	116/FIN	FS 18-26	116/FIN
FS 16-144	116/FIN	FS 18-27	116/FIN
FS 16-145	116/FIN	FS 18-28	116/FIN
FS 16-146	116/FIN	FS 18-29	116/FIN
		FS 18-30	116/FIN
FS 16-147	116/FIN	FS 18-31	116/FIN
FS 16-148	116/FIN		
FS 16-149	116/FIN	FS 18-32	116/FIN

F0 40 00	440/511	FO 40 00	4.40/511
FS 18-33	116/FIN	FS 18-86	116/FIN
FS 18-34	116/FIN	FS 18-87	116/FIN
FS 18-35	116/FIN	FS 18-88	116/FIN
FS 18-36	116/FIN	FS 18-89	116/FIN
FS 18-37	116/FIN	FS 18-90	116/FIN
FS 18-38	116/FIN	FS 18-91	116/FIN
FS 18-39	116/FIN	FS 18-92	116/FIN
			_
FS 18-40	116/FIN	FS 18-93	116/FIN
FS 18-41	116/FIN	FS 18-94	116/FIN
FS 18-42	116/FIN	FS 18-95	116/FIN
FS 18-43	116/FIN	FS 18-96	116/FIN
FS 18-44	116/FIN	FS 18-97	116/FIN
FS 18-45	116/FIN	FS 18-98	116/FIN
FS 18-46	116/FIN	FS 18-99	116/FIN
FS 18-47	116/FIN	FS 18-100	116/FIN
FS 18-48	116/FIN	FS 18-101	116/FIN
	-	FS 18-102	_
FS 18-49	116/FIN		116/FIN
FS 18-50	116/FIN	FS 18-103	116/FIN
FS 18-51	116/FIN	FS 18-104	116/FIN
FS 18-52	116/FIN	FS 18-105	116/FIN
FS 18-53	116/FIN	FS 18-106	116/FIN
FS 18-54	116/FIN	FS 18-107	116/FIN
FS 18-55	116/FIN	FS 18-108	116/FIN
FS 18-56	116/FIN	FS 18-109	116/FIN
	-	FS 18-110	_
FS 18-57	116/FIN		116/FIN
FS 18-58	116/FIN	FS 18-111	116/FIN
FS 18-59	116/FIN	FS 18-112	116/FIN
FS 18-60	116/FIN	FS 18-113	116/FIN
FS 18-61	116/FIN	FS 18-114	116/FIN
FS 18-62	116/FIN	FS 18-115	116/FIN
FS 18-63	116/FIN	FS 18-116	116/FIN
FS 18-64	116/FIN	FS 18-117	116/FIN
FS 18-65	116/FIN	FS 18-118	116/FIN
FS 18-66	116/FIN	FS 18-119	116/FIN
FS 18-67	116/FIN	FS 18-120	116/FIN
FS 18-68	116/FIN	FS 18-121	116/FIN
FS 18-69	116/FIN	FS 18-122	116/FIN
FS 18-70	116/FIN	FS 18-123	116/FIN
FS 18-71	116/FIN	FS 18-124	116/FIN
FS 18-72	116/FIN	FS 18-125	116/FIN
FS 18-73	116/FIN	FS 18-126	116/FIN
FS 18-74	116/FIN	FS 18-127	116/FIN
FS 18-75	116/FIN	FS 18-128	116/FIN
FS 18-76	116/FIN	FS 18-129	116/FIN
FS 18-77	116/FIN	FS 18-130	116/FIN
		FS 18-131	
FS 18-78	116/FIN		116/FIN
FS 18-79	116/FIN	FS 18-132	116/FIN
FS 18-80	116/FIN	FS 18-133	116/FIN
FS 18-81	116/FIN	FS 18-134	116/FIN
FS 18-82	116/FIN	FS 18-135	116/FIN
FS 18-83	116/FIN	FS 18-136	116/FIN
FS 18-84	116/FIN	FS 18-137	116/FIN
FS 18-85	116/FIN	FS 18-138	116/FIN

FS 18-139	116/FIN
FS 18-140	116/FIN
FS 18-141	116/FIN
FS 18-142	116/FIN
FS 18-143	116/FIN
FS 18-144	116/FIN
FS 18-145	116/FIN
FS 18-146	116/FIN
FS 18-147	116/FIN
FS 18-148	116/FIN
FS 18-149	116/FIN
FS 18-150	116/FIN
FS 18-151	116/FIN
FS 18-152	116/FIN
19-i	generic
19-ii	generic
19-1	generic
19-2	generic
19-3	generic
19-4	generic
19-5	generic
19-6	generic
19-7	generic
19-8	generic
19-9	generic
19-10	generic
19-11	generic
19-12	generic
20-1* 20-2*	generic generic
∠∪-∠	genenc

EVA CUE CARDS

<u>Title</u>	Ref. Page	Card No.	
SAFER CHECKOUT RESULTS (Front)		generic	
SAFER STATUS TROUBLESHOOTING (Back)	. CC 3-11	generic	
DEPRESS/REPRESS (TNL) (Front)	. CC B6-2	generic	
FAILED LEAK CHECK			
(Back of DEPRESS/REPRESS)	. CC 6-4	generic	
STS-116 LOGISTICS CUE CARD	. FS CC 10-13	EVA-4a/116/O/A	ļ
(Back)	. FS CC 10-14	EVA-4b/116/O/A	- 1

FS xii EVA/116/FIN

<u>CONTENTS</u>		<u> </u>	<u>PAGE</u>
10.2 PSI CABIN			1-1
MASK PREBREATHE INITIATE			1-2
PREP FOR 10.2 PSI CABIN			1-3
CABIN DEPRESS TO 10.2 PSI			1-4
10.2 PSIA DEPRESS CHART			1-5
10.2 PSI CABIN CONFIG			1-6
MASK PREBREATHE TERMINATE			1-6
10.2 PSI MAINTENANCE			1-7
CABIN REPRESS TO 14.7 PSI			1-8
14.7 PSI CABIN CONFIG			1-9
7 1.7 7 01 07 IBIN 0010 10			. 0
AIRLOCK CONFIG		:	2-1
AIRLOCK PREP	TEMP	FS 2	2-2
EMU SWAP			2-3
BOOSTER FAN DEACTIVATION/REMOVAL			
BOOSTER FAN INSTALLATION/ACTIVATION			
EMU REMOVAL			2-4
EMU INSTALLATION			2-4
EMU CHECKOUT PREP			
LTA RESTRAINT STRAP REMOVAL			
LTA RESTRAINT STRAP INSTALLATION			
EMU AND EVA TRANSFER PREP			
EMU AND EVA TOOL TRANSFER AND RECONFIGURATION			
POST EVA RECONFIGURATION AND TRANSFER		FS 2	2-19
CHECKOUTS			3-1
EMU CHECKOUT			3-1 3-2
EMU POWERUP AND COMM CHECK			3-2 3-2
PRIMARY REGULATOR/FAN/PUMP CHECK			3-2 3-4
SOP CHECK			3- 5
BATTERY CHARGE CHECK INIT			3-6
BATTERY CHARGE CHECK TERM			3-6
EMU SWAP DURING CHECKOUT		`	3-7
POST EMU C/O RECONFIG			3-7
SAFER CHECKOUT			3-8
SELF TEST SEQUENCE			3-9
SAFER CHECKOUT RESULTS			
SAFER STATUS TROUBLESHOOTING			
REBA POWERED HARDWARE CHECKOUT			3-12
EVA PREP			4-1
MIDDECK PREP			4-2
EVA PREP			4-3
PREP FOR DONNING		'	4-3
EMU DONNING			4-5
EMU CHECK			4-7
EMU PURGE			4-7
EMU PREBREATHE			4-8
SAFER DONNING			4-8
EVA COMM CONFIG			4-10
EVA COMM DECONFIG			4-10
APPROVED NON-EMU HARDWARE MATRIX		4	4-11

EMU STATUS EMU STATUS	5-1 5-2
DEPRESS/REPRESSI	36-1
DEPRESS/REPRESS (TNL) CC I	
FAILED LEAK CHECK	
FAILED LEAK CHECK (5 PSI)	6-4
FAILED LEAK CHECK (31-37) CC	
· · · · · · · · · · · · · · · · · · ·	
TIMELINES FS EVA 1	7-1
EVA 1 NOTES, CAUTIONS, & WARNINGS FS	73
EVA 1 NOTES, CAOTIONS, & WARNINGSFS	
EVA 1 INHIBIT PADFS	
EVA 1 INTIBIT FADFS	
EVA 1 TOOL CONFIGFS	
	7-0 7-9
EGRESS FS P5 LAUNCH LOCK REMOVAL FS	
	_
P5 TO P4 ATTACHMENTFS	
PVRGF TRANSFER TO KEEL	
P5 TO P4 UTILITIY CONNECTIONS (GET AHEAD)FS	
CLA OPEN (GET AHEAD)FS	7-26
P5 PORT LÀUNCH LOCK REMOVAL (GET AHEAD)FS	
CP3 CAMERA R&R FS	
CLEANUPFS	
	7-36
EVA 2	
EVA 2 NOTES, CAUTIONS, & WARNINGSFS	
EVA 2 BRIEFING CARDFS	
	7-40
EVA 2 SUMMARY TIMELINE FS	
EVA 2 TOOL CONFIGFS	7-42
EGRESSFS	
CHANNEL 2/3 POWER RECONFIGURATION FS	7-44
CETA CART 2 RELOCATIONFS	7-49
CETA CART 1 RELOCATIONFS	7-52
SSRMS FMS MLI INSTALLATION FS	7-56
Z1-006 PATCH PANEL 2 RECONFIGURATION FS	7-58
STBD AND PORT QD BAG INSTALLATION FS	7-60
VTE AND PM JUMPER BAG INSTALLATION FS	
CLEANUPFS	7-62
INGRESSFS	
EVA 3	
EVA 3 NOTES, CAUTIONS, & WARNINGSFS	7-64
EVA 3 BRIEFING CARDFS	
EVA 3 INHIBIT PADFS	
EVA 3 SUMMARY TIMELINE FS	
EVA 3 TOOL CONFIGFS	
EGRESSFS	
CHANNEL 1/4 POWER RECONFIGURATIONFS	
SMDP TRANSFER FS	
Z1-005 PATCH PANEL 1 RECONFIGURATIONFS	
RUSSIAN POWER RECONFIGURATION FS	
AGB TRANSFER TO FHRC FS	
CLEANUP FS	
	7-9 4 7-95

TOOLS AND STOWAGE	TEMP FS	8-1
PGT CHECKOUT		8-3
760XD PGSC-PGT CONNECTION		8-4
PROGRAM PGT SETTINGS		
DOWNLOAD/ERASE EVENT LOG		8-5
PGT CONTINGENCIES		
APFR MANAGEMENT – STS-116 (12A.1)		
SAFETY TETHER CONFIGURATION		
PORT LIGHTWEIGHT TOOL STOWAGE ASSEMBLY		
TOOLBOX STOWAGE		
TOOLBOX PANEL AND SLOT LABELS	FS	8-11
Z1 TOOLBOX INTERNAL LAYOUT		
AIRLOCK TOOLBOX INTERNAL LAYOUT		
STBD QD BAG PACK		
PORT QD BAG PACK		
VTE BAG AND PUMP MODULE JUMPER BAG PACK		
EMU EQUIPMENT SORTED BY ITEM		
EMU EQUIPMENT SORTED BY LOCATION		
SHUTTLE EVA TOOLS SORTED BY TOOL NAME		
SHUTTLE EVA TOOLS SORTED BY LOCATION	FS	8-26
POST EVA		0.4
		9-1
POST EVA		9-2
SUIT DOFFING		9-2
SAFER DOFFING		9-2
EMU WATER RECHARGE		9-3
SAFER STOW		9-3
SUIT DRYING/SEAL WIPE		9-4
OXYGEN RECHARGE VERIFICATION		9-4
WATER FILL VERIFICATION		9-4
EMU POWERDOWN/OVERNIGHT STOW		9-5
EMU MAINT/RECHARGE		10-1
WATER RECHARGE		. • .
	_	-
EMU POWERUP		
WATER FILL		
WATER FILL VERIFICATION		
EMU LIOH CHANGEOUT		
MIDDECK EMU BATTERY RECHARGE/LIOH REPLACEMENT		
INITIATE		
TERMINATE		
IN-SUIT EMU BATTERY RECHARGE/CHARGE VERIFICATION		
INITIATE		
TERMINATE		
EMU POWERDOWN		
HELMET LIGHT/PGT BATTERY RECHARGE		
INITIATE		
TERMINATE		
REBA BATTERY INSTALLATION		
EMU BATTERY REMOVAL/INSTALL		
HELMET LIGHT BULB CHANGEOUT		10-11
REBA BATTERY RECHARGE		10-12
INITIATE		10-12
TERMINATE		
STS-116 LOGISTICS CUE CARD	FS CC	10-13
EMU BATTERY RECHARGE		

POST EVA ENTRY PREP	11-1
POST EVA ENTRY PREP	11-2
SAFER ENTRY STOW	11-2
POST ISS EVA ENTRY PREP	11-3
SAFER ENTRY STOW	11-3
	_
OFF-NOMINAL PROCEDURES	12-i
EMU CONTINGENCY PROCS	12-1
DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART) TEMP F	3 12-2
VACUUM H2O RECHARGE (MANNED) TEMP F5	3 12-2
LIOH REPLACEMENT (MANNED)	12-3
BATTERY REPLACEMENT (MANNED)	12-4
WATER DUMP	12-6
SCU SWAP (UNMANNED)	12-7
SCU SWAP (MANNED)	12-7
EMU COLD RESTART (MANNED)	12-7
12.1 STS EVA DECONTAMINATION	12-8
CONTAMINATION TEST	12-15
SAFER BATTERY CHANGEOUT	12-13
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (IN-SUIT)	12-10
	_
BTA PREP	12-19
BTA TREATMENT	12-19
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (POST	
SUIT DOFFING)	12-21
BTA PREP	12-21
BTA TREATMENT	12-21
EMU RESIZE	12-24
STS-116 NOMINAL EMU SIZING MATRIX FS	
STS-116 NOMINAL EMU SIZING MATRIX FS EMU CONTINGENCY RESIZE MATRIX FS	
	3 12-28
EMU CONTINGENCY RESIZE MATRIX FS PRE EVA 3 EMU RESIZE FS	6 12-28 6 12-29
EMU CONTINGENCY RESIZE MATRIX FS	6 12-28 6 12-29
EMU CONTINGENCY RESIZE MATRIXFS PRE EVA 3 EMU RESIZEFS TPS REPAIRFS	6 12-28 6 12-29 6 13-1
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2
EMU CONTINGENCY RESIZE MATRIX FS PRE EVA 3 EMU RESIZE FS TPS REPAIR FS ORBITER CONTINGENCY EVA. PAYLOAD BAY EVA NOMENCLATURE. RMS/PRLA CONTINGENCY EVA. 96 BOLT PRE-EVA TOOL CONFIG. 96 BOLT EVA TIMELINE CAPTURE LATCH MANUAL RELEASE (ODS/PMA). 96 BOLT EVA LAYOUT. PLBD LATCH TOOL PLACEMENT WITH DUAL LATCH GANG FAILURES. EVA CUFF CHECKLIST (CIL) NORMAL EVA STATUS. DCM CONFIGURATION	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-14 14-19 14-21 14-22 15-1 15-2 15-2
EMU CONTINGENCY RESIZE MATRIX FS PRE EVA 3 EMU RESIZE FS TPS REPAIR FS ORBITER CONTINGENCY EVA PAYLOAD BAY EVA NOMENCLATURE RMS/PRLA CONTINGENCY EVA 96 BOLT PRE-EVA TOOL CONFIG 96 BOLT EVA TIMELINE CAPTURE LATCH MANUAL RELEASE (ODS/PMA) 96 BOLT EVA LAYOUT PLBD LATCH TOOL PLACEMENT WITH DUAL LATCH GANG FAILURES EVA CUFF CHECKLIST (CIL) NORMAL EVA STATUS DCM CONFIGURATION EMU MALFUNCTION INDEX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-3
EMU CONTINGENCY RESIZE MATRIX	6 12-28 6 12-29 6 13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4
EMU CONTINGENCY RESIZE MATRIX	5 12-28 5 12-29 6 13-1 14-1 14-2 14-3 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4 15-4

FS xvi

SOP P LOW	15-5
O2 USE HIGH	15-5
SUBLM PRESS	15-6
H2O GP LOW	15-6
RESRV H2O ON	15-6
H2O WP HIGH	15-6
NO VENT FLOW	15-7
CO2 HIGH OR MONITOR CO2	15-7
	_
COMMENTATION	15-7
COMM FAILURE	15-7
AIR FLOW CONTAMINATION	15-8
LOSS OF COOLING	15-8
RLF V FAIL	15-8
MISC MSGS 1	15-8
MISC MSGS (CONT)/TIME LF	15-9
AIRLOCK LATCH DISCONNECT	15-9
AIRLOCK INGRESS	15-9
FOLLOWING PAGES NOT IN EV CUFF	
<u> </u>	
RADIATOR ACTUATOR DISCONNECT	15-9
PLBD DRIVE CUT	15-10
DOOR DRIVE RESTRAINT	15-10
DOOR DRIVE DISCONNECT	15-10
WINCH OPERATIONS	15-10
WINCH OPERATIONS (CONT)	15-11
3-PT TOOL INSTALLATION	15-11
CL LATCH TOOL	15-11
RMS JOINT ALIGN	15-11
MPM STOW/DEPLOY	15-12
RMS TIEDOWN	15-12
RMS FLIGHT RELEASABLE GRAPPLE FIXTURE RELEASE	15-12
PRLA OPEN/CLOSE	15-12
PRLA OPEN/CLOSE (CONT)	15-13
KU ANTENNA STOW	15-13
KU ANTENNA STOW (CONT)	15-13
AIRLOCK EGRESS	15-13
AIRLOUR EGRESS	15-15
ELICHT ODECIEIC DECEDENCE	16-i
FLIGHT SPECIFIC REFERENCE	
12A.1 WORKAROUNDS CRIBSHEET FS	
EVA 1 CONTINGENCIES	10-3
MANUAL EATCS N2 VENTING FS	16 15
	16-21
MRTAS PRIMARY BOLT CONTINGENCIES FS	
	16-25
SOLAR ARRAY	
MANUAL OVERRIDE TO RETRACT MAST FS	16-28
,	16-31
	16-34
EVA 2 CONTINGENCIES	
CHANNEL 2/3 CONNECTOR BACKOUT FS	
\	16-43
\	16-51
DDCU REMOVE AND REPLACE - CH 2/3 (EVA 2) FS	16-59
	16-67
	16-70

EVA 3 CONTINGENCIES		
CHANNEL 1/4 CONNECTOR BACKOUT	FS	16-96
MBSU REMOVE AND REPLACE – 1A1B (EVA 3)	FS	16-100
MBSU REMOVE AND REPLACE – 4A4B (EVA 3)	FS	16-108
DDCU REMOVE AND REPLACE - CH 1/4 (EVA 3)	FS	16-117
BCDU BACKOUT – CH 1/4 (EVA 3)		
S1 PUMP MODULE R&R SÙMMARY TIMELINE		
MISCELLANEOUS		
SSRMS JOINT DRIVE	FS	16-154
MSS EXTENSION CABLE INSTALL		16-156
PUMP MODULE MANUAL VENTING		
FAILED PUMP MODULE RETURN TO ICC		16-163
GENERIC EVA REFERENCE		17-1
FLIGHT SPECIFIC EVA REFERENCE	FS	18-1
12A.1 OVERVIEW		
12A.1 ISS OVERVIEW		18-5
PAYLOAD BAY OVERVIEW	FS	18-6
MT/CETA CART LOCATIONS PER EVA		18-7
12A.1 TRUSS WORKSITES	FS	18-8
12A.1 ICC OVERVIEW	FS	18-9
ICC WIF AND HANDRAIL LAYOUT - TOP		18-10
ICC WIF AND HANDRAIL LAYOUT - BOTTOM		18-11
ICC – FAILED PUMP MODULE RETURN CONFIG		-
ESP2 HANDRAILS AND WIFs – ZENITH		
ESP2 HANDRAILS AND WIFs – NADIR		18-14
EVA 1 OVERVIEW	. •	
P5 SAFETY TETHER SWAP OVERVIEW	FS	18-15
P5 PRE-INSTALL POSITION		
RTAS CORNER 2 CLEARANCES		18-17
RTAS CORNER 2 CLOSEUP VIEW OF CLEARANCES – SSU & P5		18-18
RTAS CORNERS 1&2 AND FINAL TORQUING		18-19
RTAS CORNERS 3&4 AND FINAL TORQUING		18-20
PVRGF OVERVIEW		18-21
PVRGF REMOVAL WORKSITE – P5 WIF 11		18-22
PVRGF STOWED ON KEEL		
CP3 OVERVIEW AND TRANSLATION PATH	LO LO	10-23
EVA 2 OVERVIEW	го	10-24
S0 WORKSITES – EVA 2	ГС	10.05
SAFETY TETHER SWAP LOCATION FOR P1 BAY 16 DDCU		
	_	
Z1 PP WORKSITES – EVA 2		
CETA CART RELOCATION – INITIAL POSN & SAFETY TETHER SWAP		
CETA CART RELOCATION	FS	18-29
CETA CART RELOCATION – FINAL POSN		
SSRMS FMS MLI INSTALL	FS	18-31
EVA 3 OVERVIEW		
S0 WORKSITES – EVA 3		
S1 BAY 15 DDCU WORKSITE AND TRANSLATION	FS	18-33
TRANSLATION PATH TO FACE 3 ACCESS FLAP FOR LAB 4A DDCU		
SECONDARY PWR		18-34
	_	18-35
Z1 PP WORKSITES – EVA 3		
APFR INGRESS LOCATION FOR SMDP TRANSFER		
TRANSLATION PATH AND SAFETY TETHER SWAP TO DLR	EC	10 30

FS xviii EVA/116/FIN

Z1-NODE 1 UMBILICALS WORKSITE OVERVIEW	FS	18-39
H-JUMPER WORKSITE	FS	18-40
P5/PVRGF		
P5 ISOMETRIC VIEW	FS	18-41
P5 HANDRAILS AND WIFs (PORT/FWD VIEW)		
P5 HANDRAILS AND WIFs (ZENITH/STBD VIEW)		
P5 HANDRAILS AND WIFs (NADIR/STBD VIEW)		
P5 HANDRAILS AND WIFs (FWD/PORT VIEW)		
P5 MRTAS – ACTIVE		
P5 EWIS LAYOUT		
RTAS HOUSING DIMENSIONS	FS	18-49
P4 MRTAS – PASSIVE		
P5 TO P4 MRTAS PRIMARY BOLT ENGAGED	FS	18-51
GAP CHECK TOOL		
P5-P4 CONNECTOR PANEL		
P5 CAPTURE LATCH ASSEMBLY (CLA)		
ETVCG	10	10 04
ETVCG – ASSEMBLED	FS	18-55
ETVCG MOUNTED ON STANCHION		
U.S. CONNECTIONS	1 0	10-30
S0 FORWARD AVIONICS PANEL WORKSITE	FS	18-57
S0 WORKSITES - PANELS 163 AND 165, MBSU RECONFIG		
S0 – PANELS 163 AND 165		
S0 CH 1/4 AND 2/3 JUMPERS		
MBSU BYPASS JUMPER RECONFIG – CH 1/4		
MBSU BYPASS JUMPER RECONFIG - CH 2/3		
CID PHOTOS0/N1 PWR CABLE WORKSITE OVERVIEW		
S0 PANEL A166 WORKSITES0 PANEL A166 WORKSITE		
DDCU COLDPLATE CONNECTOR BOX – GENERIC		
S0 AFT TRAY		
Z1-LAB-S0 CONNECTIONS (PRE-12A.1 CONFIG)		
Z1-LAB-S0 CONNECTIONS (POST-12A.1 CONFIG)		
RAT'S NEST ON NECTIONS CHANNEL 2/2		
RAT'S NEST CONNECTIONS – CHANNEL 2/3 RAT'S NEST CONNECTIONS – CHANNEL 1/4		
		18-72
PATCH PANELS 1 AND 2 – SPDA		
PATCH PANELS 5 AND 6 – DDCU		
P1 BAY 16 DDCU THERMAL COVER		
S1 DDCU THERMAL COVER	F5	18-78
CETA CART	го.	40.70
CETA CART – TOP VIEW	FS	18-79
CETA SWINGARM AND WIF MARKINGS		
CETA CART COUPLERS		
CETA CART WHEEL BOGIES	FS	18-82
SSRMS FMS MLI		
SSRMS FMS LOCATION		
SSRMS FMS MLI		
LATCHING END EFFECTOR (LEE)	FS	18-85
SMDP		40.0-
SMDP BUNDLE OVERVIEW		
SMDP TDK – LAUNCH CONFIG FOR BUNDLES 2 AND 3		
SMDP TDK – LANDING CONFIG FOR BUNDLES 2 AND 3		
SMDP TDK – LANDING CONFIG FOR BUNDLE 4		
TDK LANDING CONFIG – SIDE VIEW	FS	18-90

FS xix

TDK BOLT OVERVIEW WITH LABELS		
TDK BOLTS – NOMINAL AND CONTINGENCY	FS	18-92
SMDP ADAPTER	FS	18-93
CHRISTMAS TREE	FS	18-94
CHRISTMAS TREE STOWAGE ON PMA3	FS	18-95
RUSSIAN PWR RECONFIG		
S0/NODE 1 SWINGARM	FS	18-96
Z1-NODE CONNECTIONS – PRE 12A.1		
Z1-NODE 1 CONNECTIONS – POST 12A.1		
FGB/PMA1 H-JUMPER 2/3 CONFIG		
FGB/PMA1 CONFIG POST H-JUMPER REMOVAL		
ADJUSTABLE GRAPPLE BAR		
FHRC		
CONTINGENCIES	10	10-102
P1 PUMP MODULE WORKSITE OVERVIEW	F۵	18_103
P1 PM INSTALLED IN TRUSS		
S1 PUMP MODULE WORKSITE OVERVIEW		18-105
PUMP MODULE AND FSE OVERVIEW		18-106
	_	
LAPA AND REAR CONTINGENCY PINS		18-107
PUMP MODULE WITH FIXED GRAPPLE BAR AND MLI		18-108
FLUID QD BAIL LEVERS		18-109
QD CAP TOOLS		18-110
1.5-IN FLUID QD SPOOL POSITIONING DEVICE		
FLUID QD RELEASE TOOLS		
0.5-IN FLUID QD SPOOL POSITIONING DEVICE		
0.5-IN SPD BOOTIE EXTENSION		18-113
QD VENT TOOLS		18-114
VENT TOOL EXTENDER BAG		18-115
VTE AND VTE BAG DETAILS		18-116
PUMP MODULE NH3 JUMPER	FS	18-117
STATUS INDICATORS (MBSU, DDCU, BCDU)	FS	18-118
FAILED MBSU LOCATIONS		
CETA CART LOCATION FOR MBSU R&R		18-120
SPARE MBSU STOWED ON CETA GRID E WITH PORT TFR		
SWINGARM DEPLOYED	FS	18-121
MBSU ORU		
MBSU AND COLDPLATE	_	_
DDCU LOCATIONS		18-124
DC-TO-DC CONVERTER UNIT – EXTERNAL		18-125
SPARE DDCU S0-4B WORKSITE (S0 PORT WEDGE FACE) (EVA 3)		18-126
FAILED DDCU S1-4B WORKSITE (S1 BAY 15) (EVA 3)		18-127
FAILED DDCU S0-1A WORKSITE (S0 BAY 01) (EVA 3)		18-128
		18-129
SPARE DDCU S0-3B WORKSITE (S0 BAY 04) (EVA 2)		
FAILED DDCU S0-2B WORKSITE (S0 BAY 02) (EVA 2)		18-130
FAILED DDCU P1-3A WORKSITE (P1 BAY 16) (EVA 2)		18-131
P6 OVERVIEW FOR STBD BCDUs		18-132
P4 2A BCDU WORKSITE OVERVIEW		18-133
P4 4A BCDU WORKSITE OVERVIEW		18-134
BCDU		18-135
P6 2B STBD IEA (UPPER/NON-KEEL SIDE) ORU LABELS	FS	18-136
P6 4B PORT IEA (LOWER/KEEL SIDE) ORU LABELS		
P4 4A FWD IEA (UPPER/NON-KEEL SIDE) ORU LABELS		
P4 2A AFT IEA (LOWER/KEEL SIDE) ORU LABELS		18-139
4B MANUAL RETRACT – P6 WIF 37		18-140
SOLAR ARRAY LATCH/TENSION OVERRIDE – LEET BLANKET BOX	FS	18-141

FS xx EVA/116/FIN

SOLAR ARRAY JETTISON OVERVIEW	FS	18-142
MAST CANISTER MDA	FS	18-143
SABB MDA	FS	18-144
SOLAR ARRAY BLANKET BOX (SABB)	FS	18-145
FRAM/FSE/ORU ASSEMBLY		
ACTIVE FRAM SOFT CAPTURE MECHANISM	FS	18-147
FRAM CONTINGENCY BOLTS – SAPA		
P5 SOFT CAPTURE ASSY MANUAL OVERRIDE	FS	18-149
SMDP ADAPTER FAILED MAGNETIC SOCKET	FS	18-151
EVA EMERGENCY		19-i
EMERGENCY PROCEDURES		19-1
EMERGENCY AIRLOCK REPRESS		19-3
EMERGENCY AIRLOCK REPRESS		19-4
POST EMERGENCY AIRLOCK REPRESS		19-4
SAFER RESCUE		19-5
SAFER RESCUE		19-6
DAP/EVA RESCUE/RETRIEVE		19-7
EVA ORBITER CONFIG		19-7
EVA RESCUE/RETRIEVE		19-9
19.1 DCS TREATMENT		19-10
CHE CARD CONFICHDATION		20.4

This Page Intentionally Blank

AIRLOCK CONFIG

AIRLOCK CONFIG

AIRLOCK PREP	TEMP FS 2-2
EMU SWAP	2-3
BOOSTER FAN DEACTIVATION/REMOVAL	2-4
BOOSTER FAN INSTALLATION/ACTIVATION	2-4
EMU REMOVAL	2-4
EMU INSTALLATION	2-4
EMU CHECKOUT PREP	TEMP FS 2-5
LTA RESTRAINT STRAP REMOVAL	TEMP FS 2-6
LTA RESTRAINT STRAP INSTALLATION	TEMP FS 2-6
EMU AND EVA TRANSFER PREP	FS 2-7
EMU AND EVA TOOL TRANSFER AND RECONFIGURATION	FS 2-14
POST EVA RECONFIGURATION AND TRANSFER	FS 2-19

AIRLOCK PREP (50 min)

Retrieve or unstow following equipment:

MF28G 3/8-in breaker bar, 4-in ext w/3/8-in drive

IFM Tool Kit 1/2-in socket w/3/8-in drive

Vol H EMU Equipment Bag – attach to middeck wall

Helmet Lights EVA Bag

Contamination Detection Kit (location flight specific)

FDF Locker Cuff Checklists (2) – stow in EMU Equipment Bag

DEPRESS/REPRESS Cue Card

1. √Inner hatch Equal vlv (two) – OFF

AW18A

2. LTG FLOOD (four) - ON

3. Remove from airlock, as reqd:

Airlock Stowage Bag

Airlock Floor Pallet using 3/8-in breaker bar, 4-in ext w/3/8-in drive, and

1/2-in socket w/3/8-in drive

4. Stow Vol H Bags in Vol H

5. Transfer to airlock:

EVA Bag - install on airlock wall

DEPRESS/REPRESS Cue Card

Helmet Lights

Contamination Detection Kit – install on airlock wall

6. Install IVA foot restraint, as regd

7. Unbuckle SCU straps, Velcro SCU to wall

8. Install EMU lights on helmets (EMU 1,EMU 2)

9. Disconnect helmets from Airlock EMUs, temp stow

10. Remove comm caps from LTA Restraint Bags and connect to electrical harnesses

11. Install helmets (not regd if proceeding directly to EMU Checkout)

12. Remove LTA Restraint Bags

13. Disconnect waist rings; remove and stow any equipment stowed in HUT/LTA

14. Stow LTA Restraint Bags on AAPs

15. √Thermal cover clear of waist ring

16. Waist ring – engage posn

17. Connect LTA to HUT, lock

18. Remove 20-g Crash Bag from middeck EMU, as regd

AW18A

- 1. LTG FLOOD (four) ON
- 1. Remove Airlock Stowage Bag from airlock (as reqd)
- 3. Unbuckle SCU straps, Velcro SCU to wall
- 4. Disconnect helmets from airlock EMUs, temp stow
- 5. √DIDB restraint bags installed
- 6. Remove comm caps, s/n 1166 (Cr) and s/n 1203 (Fg) from LTA restraint bag kangaroo pouches and connect to electrical harnesses (Cr backup comm cap s/n 1165 will get stowed in Cr ECOK)
- 7. Remove LTA restraint bags
- 8. Disconnect waist rings; remove ECOKs, LCVGs, DIDBs, and arm ring protective cover (Fg only) stowed in HUT/LTA
- 9. Stow DIDBs, Cr backup comm cap, and arm ring protective cover in ECOKs (LCVGs will be used for EMU Checkout)
- 10. Retrieve EMU SYS TRANSFER BAG #2 from Curbeam ECOK, temp stow ECOKs

Vol H INBD11. Unstow:

EMU Servicing Kit (s/n 5002) – (yellow tagged for transfer to ISS) From EMU Equipment Bag:

- 2 SCOFs (s/n 1009, 1010) will be used for EMU Checkout, then xfer 2 Cooling Loop Jumpers (s/n 044, 046)
- 12. Stow Vol H Bag in Vol H
- 13. Stow EMU Servicing Kit (s/n 5002) in EMU SYS TRANSFER BAG #2
- 14. Stow 2 Cooling Loop Jumpers in EMU SYS TRANSFER BAG #2
- 15. Stow LTA restraint bags on AAPs
- 16. √Thermal cover clear of waist ring
- 17. Waist ring engage posn
- 18. Connect LTA to HUT, lock
- 19. Temp stow EMU SYS TRANSFER BAG #2 (used later for EMU and EVA Transfer Prep)

LTA RESTRAINT STRAP REMOVAL (15 min)

NOTE

May be performed on EMU 1 and 2 simultaneously. Perform steps as reqd for current EMU config


- 1. As reqd, remove comm cap from LTA Restraint Bag; temp stow
- 2. Remove EMU from AAP
- 3. Disconnect all restraint attachments from SAFER mount brackets (two)
- 4. Loosen cinch strap mechanism, remove SAFER mount brackets
- 5. Remove strap from PLSS
- 6. Stow strap in LTA Restraint Bag Pouch with D-rings (three) connected
- 7. Engage EMU in AAP
- 8. Stow LTA Restraint Bag/strap

LTA RESTRAINT STRAP INSTALLATION (15 min)

NOTE

May be performed on EMU 1 and 2 simultaneously. Perform steps as reqd for current EMU config. Procedure written to install in Launch/Landing config shown below

- 1. Unstow LTA Restraint Bag/strap
- 2. Remove EMU from AAP
- 3. Install SAFER mount brackets (two)
- 4. Install elastic band of strap around SOP
- 5. Tighten cinch strap mechanism
- 6. Attach strap French hooks (two) to SAFER mount brackets
- 7. Engage EMU in AAP
- 8. Stow LTA, suit arms inside LTA Restraint Bag
- 9. Connect upper spring hooks (two) over suit shoulders to upper AAP attachment rings (two)
- 10. Connect lower spring hooks (two) around suit arms to SAFER mount brackets (two)
- 11. Tighten all LTA bag straps with bag as high as possible on EMU



TEMP FS 2-6

mount brackets for launch and landing

116 EVA/ALL/FIN 1. Retrieve EMU SYS TRANSFER BAG #1 and #2 (#2 was temp stowed earlier, #1 is in Cr ECOK)

BOTH EMUs

- 2. √PWR SCU
- 3. √DCM PURGE vIv op (up)
- 4. √O2 ACT OFF
- 5. √WATER OFF, switch guard installed
- 6. √Helmet sun visors down, cover installed
- 7. Configure/verify items stowed in the table below

EMU 3003 (XL) (Cr)	EMU 3018 (M) (Fg)	
☐ Helmet (Cr) S/N 1061	☐ Helmet (Fg) S/N 1063	
☐ Valsalva	☐ Fresnel Lens	
☐ Helmet cover	□ Valsalva	
☐ LTA (Cr) (attached)	☐ Helmet cover	
☐ EV1 (Cr) gloves S/N 6238	□ LTA (Fg) (attached)	
☐ Wrist Mirrors (2)	☐ EV2 (Fg) gloves S/N 6197	
	☐ Wrist Mirrors (2)	
EMU Crew Options Kit (Cr)	EMU Crew Options Kit (Fg)	
☐ ECOK Mesh Bag (EV Crew Options Kit)	☐ ECOK Mesh Bag (EV Crew Options Kit)	
(Cr)	(Fg)	
□LCVG	□LCVG	
☐ Cr EVA #1 Ziplock Bag	☐ Fg EVA #1 Ziplock Bag	
□ MAG	□ MAG	
☐ Ziplock bag	☐ Ziplock bag	
☐ TCU (top)	☐ TCU (top)	
☐ TCU (bottom)	☐ TCU (bottom)	
☐ Wristlets	☐ Wristlets	
☐ Comfort gloves	☐ Comfort gloves	
☐ Thermax Sock Liners	☐ Tube Socks	
☐ Cr EVA #2 Bag (same as Cr	☐ Croakie	
EVA #1)	☐ Moleskin	
☐ Cr EVA #3 Bag (same as Cr	☐ Fg EVA #2 Bag (same as Fg	
EVA #1)	EVA #1)	
☐ Cr Contingency Bag	☐ Fg Contingency Bag	
□ 8 MAGs	□ 7 MAGs	
☐ 8 Ziplock bags	☐ 7 Ziplock bags	
☐ EV Crew ID stripes	☐ Fresnel Lens	
☐ EV Crew ID tags	□ Moleskin	
☐ Mission patch and flag	☐ EV Crew ID stripes	
□ 3 DIDBs	☐ EV Crew ID tags	
☐ Backup CCA (comm cap) S/N	☐ Mission patch and flag	
1165	□ 2 DIDBs	
	☐ Arm sizing ring protective	
	Cover	
	☐ Spare Mesh Bag	

- 8. Stow LTA, suit arms inside LTA Restraint Bag
- 9. Connect upper spring hooks (two) over suit shoulders to upper AAP attachment rings (two)
- 10. Connect lower spring hooks (two) around suit arms to SAFER mount brackets (two)
- 11. Tighten all LTA bag straps with bag as high as possible on EMU
- 12. Pack EMU SYS TRANSFER BAG #1 and #2 per table below:

EMU Sys Transfer Bag #1 & #2	Bag #
Vol H – Previously gathered ☐ EMU Servicing Kit (S/N 5002, Yellow Transfer Tag)	2
☐ 2 SCOFs (S/N 1009, 1010)	2
☐ 2 Cooling Loop Jumpers (S/N 044, 046)	2
Drug Subpack (MF28H)	
□ Aspirin	1
FDF/SODF Shared Locker (MF57H)	
☐ Ziplock bag labeled "EVA Procedures/Cue Cards"	1
Verify contents: ☐ STS-116 LOGISTICS Cue Card (1 of 1)	
☐ STS EVA Checklist (2 of 3 – PLT and MS3)	
☐ ISS EVA Systems Checklists (2 of 3 – PLT and CDR	
copies) ☐ Crewlock DEPRESS/REPRESS Cue Card (2 of 2)	
☐ EVA PREBREATHE Cue Card (1 of 2 – with STS 116	
exercise prescriptions filled in)	
☐ Ziplock bag labeled "ISS EVA Cuff Checklists" (in MF57H or	
MF71G) □ ISS EVA Cuff Checklist (3 of 3 – put Cr and Fg in bag 1,	1&2
W in bag 2)	102
Crew Personal Notes	
☐ Crew personal list of items to be in airlock for campout	1
External Airlock Floor Bag	
☐ 2 LiOH Cartridges (CCC) (S/N 2018, 2019)	1
☐ SAFER Latch Guards (qty 2 pr) ☐ EV3 (W) Prime Gloves (S/N 6047)	1 2
□ EV3 (W) B/U Gloves (S/N 6046)	2 2
□ EV3 (W) EMU Boots (S/N 203)	2
☐ EV3 (W) EMU Crew Options Kit (ECOK) Add:	N/A
□ DIDB	_
□ EV3 (W) LCVG (S/N 3141)	-
☐ EV3 (W) CCA (comm cap) (S/N 1194)	-
Verify:	
☐ 2 spare in-flight stowage restraint bags	-
☐ W EVA #1 STS-116 Ziplock Bag ☐ 2 MAGs	-
☐ 2 Ziplock bags	-
☐ TCÜ (top)	-
☐ TCU (bottom) ☐ Wristlets	-
☐ 2 pair Comfort gloves	- -
☐ Tube socks	-
☐ Moleskin	-
☐ STS-116 Mission Patch ☐ National Flag	-
☐ EV Crew ID stripes (EV2)	_
☐ EV Crew ID tags	-
☐ Crew personal items	-

FS 2-8 EVA/116/FIN

EMU Sys Transfer Bag #1 & #2 (Cont)	
Verify (Cont):	
☐ W EVA #1 Bag (same as W EVA #1 STS-116, but with	-
Inc 14 mission patch instead of STS-116 mission patch,	
and EV1 crew ID stripes)	
☐ W EVA #2 Bag (same as W EVA #1, but w/o mission	-
patch or flag)	-
☐ W EVA #3 Bag (same as W EVA #2)	-
☐ W Contingency Bag	-
□ 2 MAGs	-
☐ 2 Ziplock bags	-
□ Moleskin	-
□ Woodsman Socks	-
☐ Fresnel Lens	-
☐ Crew personal items	-
Locker MF43K	
☐ 1 BTA (S/N 1003)	2
	_
WCS	
□ Towels	1
MILL LEL OTER AR	
Middeck Floor STBD 1 Bag	
☐ Contamination Detection Kit (s/n 1002)	1
☐ ISS CSA-O2 Resupply Kit	1 1

FS 2-9 EVA/116/FIN

EVA 1 TOOLS AND HARDWARE

- 1. Retrieve the "EVA 2/3 Shuttle to ISS" Jettison Stowage Bag from AP01, temp stow (needed for EVA 2
- 2. Retrieve the "EVA 1 Shuttle to ISS" Jettison Stowage bag from AP01
- 3. Using the table below, obtain EVA 1 Tools from each stowage location and stow in the "EVA 1 Shuttle to ISS" Jettison Stowage Bag:

EVA 1 TOOLS					
Location	Item Description	Qty.	Part No.	Serial No.	Comments
AP01 (5 MLE bag)	"EV1" Jettison Stowage Bag	1	SEB13100134-304		
AP01 (5 MLE bag)	"EV2" Jettison Stowage Bag	1	SEB13100134-304		
AP01 (5 MLE bag)	"Return to Shuttle 1, 2, 3" Jettison Stowage Bags	□ 3	SEB13100134-304		Needed for EVA hardware cleanup
AC01 (1.0 CTB)	Sm-sm RET	9	SEG33106164-381	4057, 4070 4071, 4073 4075, 4170 4271, 4272 TBD (blue)	8 color coded yellow. Use for all 12A.1 EVAs 9th RET (blue) is being launched to replace 12A returned RET. It will go to tether staging area
AC01 (1.0 CTB)	Sm-sm RET w/PIP pin	□ 4	SEG33106164-383	4238, 4239 4240, 4241	Color coded yellow. Use for all EVAs
AC01 (1.0 CTB)	Lg-sm equip RET	□ 6	SEG33106164-385	4252, 4253 4254, 4255 4256, 4257	Color coded yellow. Use for all EVAs
AP07 (3.0 CTB)	Torque Wrench	□ 1	SEG33106948-301	1001	
AP07 (3.0 CTB)	Torque Wrench Bag	□ 1	SEG33110183-301	1001	
FC02 (1.0 CTB)	Velcro/Tape Caddy	□ 1	SED33104207-301	1019	Will relocate to the Staging Bag once on ISS. Needed for contingency only

- 4. Temp Stow "EVA 1 Shuttle to ISS" Jettison Stowage Bag5. Reference OSO procedure for details of ETVCG and Light assembly per EVA 1 Hardware table below. Reference Transfer procedures for details on transfer to ISS

	EVA 1 HARDWARE					
Location	Item Description	Qty.	Part No.	Serial No.	Comments	
PF01	ETVCG Assembly PanTilt Unit (PTU) Color TV Camera (CTVC) TV Camera Interface Converter (TVCIC) Video Luminaire Assembly (VLA/light)	□ 1	10033194-501	N/A	Beamer and Christer assemble all but light on FD2 (b/c light won't fit through hatch) (gloves reqd). Assy actually happens after transfer prep Billyo and Joanie install light on FD3 post dock and safety brief once on ISS (gloves reqd) ACO transfer controls transfer of this item	

EVA 2 TOOLS AND HARDWARE

- 1. Using the table below, perform the following steps to gather and temp stow EVA 2 tools:
 - a. Retrieve 5 MLE Bag from AP01
 - b. Retrieve 1.0 CTB from AC01, temp stow
 - c. Retrieve adjustable tethers (4) from FC02, stow in 1.0 CTB from AC01
 - d. Retrieve 1" NH3/N2 Vent Tool F from Middeck Floor Stbd 1 Bag; stow in 1.0 CTB from AC01

EVA 2 TOOLS						
Spacehab	Item Description	Q	ty.	Part No.	Serial No.	Comments
AP01 (5 MLE bag)	Port QD Bag		1 1 1	SEG33114667-301 1F98597-1 1F98591-1 1F98592-1	1001	1 set of vent tools will fly in place inside port QD bag. Other set are stowed separately in foam in 5 MLE bag
	7 1120/142 VCIII 100/1-1		1	1F98596-1	01	
			1	1F98593-1	02	
AP01 (5 MLE bag)	1/4" NH3/N2 Vent Tool – F		1	1F98592-1	01, 02	Will go into stbd QD bag once on orbit QD tool bag pack occurs on FD5 by Christer and Beamer
AP01 (5 MLE bag)	3/4" NH3/N2 Vent Tool – F		1	1F98597-1	01, 02	Will go into stbd QD bag once on orbit
AP01 (5 MLE bag)	1.5" NH3/N2 Vent Tool – F		1	1F98591-1	01, 02	Will go into stbd QD bag once on orbit
AP01 (5 MLE bag)	Vent Tool Adapter		2	SEG33119079-301	1001, 1002	Both will go into port QD bag on FD5
AC01 (1.0 CTB)	1/4" Button Depress Tool (BDT)		1	SEG33114984-301	001	One will go into port QD bag on FD5. Other will stay inside ISS (separate transfer item)
AC01 (1.0 CTB)	3/4" Button Depress Tool (BDT)		1	SEG33114986-301	001	One will go into port QD bag on FD5. Other will stay inside ISS (separate transfer item)
AC01 (1.0 CTB)	3/4" Anti-Kickback Tool (AKT)		1	SEG33114983-301	1001	One will go into port QD bag on FD5. Other will stay inside ISS (separate transfer item)
AC01 (1.0 CTB)	Gap spanners		3	SEG33109930-301 SEG33109930-303	1033,1036, 1037 1038	For QD tool bag external stowage (labeled, short, med, long-303)
FC02 (1.0 CTB)	Adjustable Tethers		4	SEG33106945-307	23, 24 25, 26	Needed for tools in port QD bag
Middeck Floor Stbd 1 Bag	1" NH3/N2 Vent Tool – F		1	1F98589-1		New item on manifest. Will be mated to VTE once on ISS

- 2. Retrieve the "EVA 2/3 Shuttle to ISS" Jettison Stowage Bag from temp stow location
- 3. Using the table below, obtain EVA 2 Hardware from each stowage location and stow in "EVA 2/3 Shuttle to ISS" Jettison Stowage Bag:

EVA 2 HARDWARE						
Spacehab	Item Description	Qty.	Part No.	Serial No.	Comments	
FC07 (1.0 CTB)	S0 CH 2/3 EVA Power Cable	□ 1	1F15343-1	NA	Our name: S0 CH 2/3 Jumper	
FC07 (1.0 CTB)	S0/N1 EVA SM Pri Power Cable	□ 1	1F15359-1		Our name: S0/N1 Pwr Cable	
FP04 (0.5 CTB)	SSRMS FMS MLI Shrouds	□ 2	51612-4031-351	202, 203		

4. Temp stow "EVA 2/3 Shuttle to ISS" Jettison Stowage Bag

5. Using the table below, retrieve the following EVA 2 GET-AHEAD HARDWARE from each stowage location:

EVA 2 GET-AHEAD HARDWARE						
Spacehab	Item Description	Qty.	Part No.	Serial No.	Comments	
AS01 (5 MLE Bag)	Vent Tool Extension Bag (VTEB 01)	1	SEG33119100-301	1001	Get-ahead for EVA 2 to install on airlock	
	Vent Tool Extender (VTE)	1	SEG33119090-301	1001	Will pack this bag with vent tool and MUT EE on FD5	
					Only needed for PM R&R	
AS01 (5 MLE Bag)	PM Jumper Bag (VTEB 02) PM Jumper	□ 1 □ 1	SEG33119100-301 1F15818-1	1002	Install PM Jumper into PM Jumper bag	
					Will pack this bag on FD5	
					Only needed for PM R&R	

6. Temp stow Vent Tool Extender Bag and PM Jumper Bag

EVA 3 HARDWARE

- 1. Using the table below, retrieve the S0 CH 1/4 Power Cable from its stowage location and stow in "EVA 2/3" Shuttle to ISS" Jettison Stowage Bag:
- 2. Refer to Transfer list for details regarding AGB transfer:

	EVA 3 HARDWARE					
Spacehab	Item Description	Qty.	Part No.	Serial No.	Comments	
FC07 (1.0 CTB)	S0 CH 1/4 EVA Power Cable	1	1F15341-1	NA	Our name: S0 CH 1/4 Jumper	
SF13	Adjustable Grapple Bar (AGB)	_ 1	1F82020-1	NA	AGB is launched in the unlocked position Immediately after unpacking, set the AGB to the NTA setting and push the T-Handle to Lock (no white lines visible) This will keep it from sliding in and out and will make it the smallest setting for egress ACO Transfer controls transfer of AGB	

SUMMARY OF EVA HARDWARE AND BAGS:

- "EVA 1 Shuttle to ISS" Jettison Stowage Bag
 5 MLE Bag
- 3. 1.0 CTB
- 4. Vent Tool Extender Bag
- 5. Pump Module Jumper Bag (labeled VTE Bag II)
- 6. "EVA 2/3 Shuttle to ISS" Jettison Stowage Bag

PRE-EVA 1 TRANSFER

NOTE

This procedure assumes that transfer items were preconfigured per EMU AND EVA TRANSFER PREP

1. Transfer the following EVA equipment to ISS:

Destination	Transfer Status				
EVA 1 Hardware					
E-Lk aft EDDA					
(Perform steps 3-9 below					
to install EMU in EDDA)					
E-Lk fwd EDDA					
(Perform steps 3-9 below					
to install EMU in EDDA)					
E-Lk					
E-Lk					
NODE					
NODE					
	E-Lk aft EDDA (Perform steps 3-9 below to install EMU in EDDA) E-Lk fwd EDDA (Perform steps 3-9 below to install EMU in EDDA) E-Lk E-Lk E-Lk E-Lk E-Lk NODE NODE NODE NODE				


2. Report transfer status to MCC

PRE-EVA 1 EMU RECONFIGURATION

LTA RESTRAINT REMOVAL

- 3. Remove LTA Restraint Bags
- 4. Disconnect all restraint attachments from SAFER mount brackets (two)
- 5. Loosen cinch strap mechanism, remove SAFER mount brackets
- 6. Remove strap from PLSS
- 7. Stow strap in LTA Restraint Bag Pouch with D-rings (three) connected
- 8. Engage EMU in EDDA
- 9. Stow LTA Restraint Bag/strap in ECOKs

EMU AND EVA TOOL TRANSFER AND RECONFIGURATION (100 min) (Cont)



NOTE
French hooks should be attached to SAFER mount brackets for launch and landing

REBA INSTALLATION INTO EMUs 3003 and 3018

- 10. Unstow REBAs S/N 1003 and 1011 from EVA 1 mesh bag
- BOTH 11. Rotate EDDA to access back of EMUs
 - 12. √Glove heater sw (two) OFF
 - 13. Unzip TMG to access REBA pouch and power cable
 - 14. Remove REBA J1 connector fabric cover
 - 15. Install REBA 1003 on EMU 3003(Cr), and REBA 1011 on EMU 3018(Fg)
 - 16. Configure REBA pull tabs through slots in TMG
 - 17. √REBA sw OFF, toward left arm of suit
 - 18. Connect EMU Power Harness (P1) to REBA (J1), gently perform pull test to verify connection
 - 19. Zip TMG closed
 - 20. Rotate EDDA closed

EMU TV (ERCA) INSTALLATION AND REBA HARDWARE CHECKOUT

- 21. Remove helmet lights (two) with EMU TVs (ERCA) from ISS EMU helmets
- 22. Verify EMU TV camera addresses and serial numbers below

	Address	Serial number
Curbeam – EV1	16	1010
Fuglesang – EV2	18	1007

- 23. Install helmet lights with EMU TVs (ERCA) on EV1 and EV2 helmets
- 24. Verify EMU TV cables covered with helmet light TMG
- PLSS 25. Unstow EMU TV power cable, disconnect from ground plug
 - 26. Mate EMU TV power cable to EMU TV
 - 27. √Lower arm power harness connected to upper arm power connectors
 - 28. √Glove heater sw (one per glove) OFF
 - 29. Connect lower arm power harness to gloves

FS 2-15

EVA/116/FIN

EMU AND EVA TOOL TRANSFER AND RECONFIGURATION (100 min) (Cont)

NOTE

To avoid excessive battery consumption and heat buildup, deactivate heaters once heat detected at fingertips

- 30. REBA sw (1 per EMU) ON, pull tab toward right arm of suit
- 31. Glove heater sw (one per glove) ON

When heat detected on all outside fingertips:

- 32. Glove heater sw (one per glove) OFF
- 33. EMU TV power pb press, √Green LED illuminated
- 34. EMU TV power pb press, √Green LED not illuminated
- 35. REBA sw (1 per EMU) OFF, pull tab toward left arm of suit
- 36. Disconnect lower arm power harness from gloves
- 37. Stow lower arm and glove power harness connectors under TMG
- 38. Disconnect EMU TV power cable from EMU TV
- PLSS 39. Connect EMU TV power cable to ground plug

AIRLOCK SETUP

- 40. Install ISS EVA Cuff Checklists on EV1 and EV2 EMUs from EMU SYS TRANSFER BAG #1
- 41. Remove SODF, FDF, and Cue Cards from EMU SYS TRANSFER BAG #1, position as desired (make sure one DEPRESS/REPRESS Cue Card located in E-Lk, and one DEPRESS/REPRESS Cue Card in C-Lk)
- 42. Locate/position as desired:

EVA 1, EVA 2, EVA 3 mesh bags

EMU Equipment Bag

EMU Servicing Kit s/n 5005 (old kit on ISS, use for all STS 116 EVAs)

- 43. Remove LiOHs (S/N 2018, 2019) (two) from EMU SYS TRANSFER BAG #1 and stow in EVA 2 mesh bag
- 44. Swap Contamination Detection Kit (s/n 1002) from EMU SYS TRANSFER BAG #1 with Contamination Detection Kit (s/n 1001) in Crewlock IV Bag
- 45. Stow the following items from EMU SYS TRANSFER BAG #1 into EMU Equipment Bag:

Aspirin

SAFER Latch Guards (to be installed on SAFERs during EMU Prebreathe)

46. Unstow CSA-O2s from EMU SYS TRANSFER BAG #1 and position/temp stow in Equipment Lock

EQUIPMENT LOCK PREP

- 47. Waist ring $\leftarrow \mid \rightarrow HUT$ (if items stowed in HUT for transfer)
- 48. Remove loose equipment from HUT
- 49. Waist ring → |← HUT
- 50. Stage crew preference items in EMU Equipment Bag as required
- 51. Helmet $\leftarrow \mid \rightarrow HUT$
- 52. Inspect comm cap MBEDs (two per comm cap) for damage
 Replace MBEDs as required (EMU Servicing Kit s/n 5005 old kit on ISS)
- 53. Remove DIDB restraint bag from HUT
- 54. Insert filled drink bag (from ECOK) into restraint bag. Install restraint bag in HUT
- 55. √Fresnel lenses, valsalva devices installed as desired

EMU AND EVA TOOL TRANSFER AND RECONFIGURATION (100 min) (Cont)

CAUTION

In order to preclude release of ethanol, after use, antifog wipes and packaging must be sealed in containment bag and disposed of in wet trash

56. Apply antifog (EMU Servicing Kit s/n 5005 – old kit on ISS) to the following: Helmet (not Fresnel lens)

EV Glasses

Thoroughly wipe off antifog

Seal used antifog wipes and packages in containment bag and dispose of in wet trash

- 57. Helmet $\rightarrow \mid \leftarrow HUT$
- Unstow four helmet light batteries from EVA 1 mesh bag Install Batteries in helmet lights per STS-116 LOGISTICS Cue Card
- 59. √Helmet light ops
- 60. Reposition EDDA for EMU donning as required
- 61. √PHA configuration (2 PHA bags) per figure 1 below



Figure 1.- Prebreathe Hose Assembly (PHA)

62. Visually inspect two PHAs, PHA Quick Don Masks for any damage

BOTH 63. Stow Quick Don Masks and 15 ft of hose in large side pocket of PHA Bags A/L1OA1 64. √Flexible Ventilation Duct attached to Conditioned Air Supply connection

VERIFYING EQUIPMENT IN AIRLOCK

<u>, </u>		VI IN AIREOCK
65.	Confirm	the following equipment is located in the Airlock
		PFE located in PFE locker
		√Pressure gauge needle in green zone (800 to 900 psig)
		PBA Quick Don Masks and bottles for every isolated crewmember (4 total for EVA 1)
		$\sqrt{\text{PBA Bottles}} \rightarrow \mid \leftarrow \text{Quick Don Masks for each non-EVA crewmember}$ in airlock
		√Oxygen bottle pressure ≥ 3000 psig for each bottle
		Hardcopy of Emergency Book (from FGB location)
		CSA-O2s (two for overnight campout)
		√Good Battery power on both CSA-O2s
		Inform MCC-H of CSA-O2 readings
		MCC-H will verify accuracy
		Two spare regenerated METOX canisters

FS 2-17 EVA/116/FIN

EMU AND EVA TOOL TRANSFER AND RECONFIGURATION (100 min) (Cont)

All required EMU components: HUTS LTAs Gloves Helmets LCVGs (with biomed) Comm Caps ECOKs Crew preference items	
 □ Dosimeter □ EMU Servicing Kit □ Flashlight □ Jeweler's Screwdriver (optional) □ Airlock Tool kit □ Earplugs □ Towel (EMU SYS TRANSFER BAG #1) □ Aspirin 	
WARNING EV crewmembers should minimize application of h and hydrocarbon-based products prior to EVA day introduction of irritants and combustibles into the E For acceptable items in EMU, refer to {5.110 APP NON-EMU HARDWARE}, all (SODF: ISS EVA SYREFERENCE), as required	to avoid MU. ROVED
☐ Personal Hygiene Items ☐ Egg Timers ☐ Vacuum Manometer (optional, √MCC-M for V	/M number)

FS 2-18 EVA/116/FIN

EMU RECONFIGURATION FOR TRANSFER

- Unstow two used LiOH canisters s/n 2018 and s/n 2019 (the ones without caps) and EMU Batteries s/n 2057 and s/n 2058 from EMU SYS TRANSFER BAG #1
- PLSS 2. Unzip thermal cover for EMUs 3015 (Fg), 3003 (Cr), and 3018 (W). Affix thermal cover to top of EMU with Velcro
 - 3. Remove used Metox from EMUs 3003 and 3018, install caps and stow in mesh bag labeled Expended Metox in EVA Prep and Ops M-02 bag (s/n 1038)
 - 4. Remove vent port plugs from EMU 3015, and install them in EMU 3018

UIA 5. $\sqrt{\text{sw PWR EV-1,2 (two)}} \rightarrow \text{OFF}$

DCM 6. √sw POWER – SCU

- PLSS 7. Remove used EMU Batteries from EMU 3003 and 3018, stow in 0.5 CTB labeled EMU Batteries in M-02 bag (s/n 1038)
 - 8. Install EMU Battery s/n 2057 in EMU 3003, and EMU Battery s/n 2058 in EMU 3015 (EMU 3018 (W) should have NO battery installed)
 - 9. Engage latch

While holding LiOH canister with silver plate label facing self:

10. Install LiOH s/n 2018 in EMU 3003 and s/n 2019 in EMU 3015 (attach Velcro Strap)

Latch canister in place

EMU 3003 11. √sw (pulltab) REBA – OFF

- 12. EMU Power Harness (P1) \leftarrow | \rightarrow REBA (J1)
- 13. Remove REBA from EMU
- 14. Install REBA J1 fabric cover
- 15. Stow REBA in M-02 bag (s/n 1038)
- PLSS 16. Close thermal cover zipper on EMUs 3003, 3015, and 3018
 - 17. Remove helmet lights and EMU TV from EMU 3003, and install them on EMU 3008 (La)
 - 18. Remove EVA Cuff Checklist from EMU 3003 and stow in EMU Equipment Bag
 - 19. √No tools or tethers installed on EMU 3003 or EMU 3015
 - 20. Remove LTA Restraint Straps and LTA Restraint Bags from Cr and Fg ECOKs
 - 21. Remove CCAs (comm caps) from Cr and Fg ECOKs
 - 22. On EMU 3003, remove helmet, disconnect CCA from electrical harness, connect helmet to HUT
 - 23. Stow prime and backup Cr CCAs in Cr LTA Restraint Bag kangaroo pouch, and Fg CCA in Fg LTA Restraint Bag kangaroo pouch (can be performed after LTA Restraint Bag installation if desired)
 - 24. Verify Cr and Fg ECOKs contain only the items listed in table 1

TABLE 1.- CR AND FG ECOK CONTENTS

EMU Crew Options Kit (Cr)	EMU Crew Options Kit (Fg)
☐ ECOK Mesh Bag (EV Crew Options Kit) (Cr)	☐ ECOK Mesh Bag (EV Crew Options Kit) (Fg)
□ LCVG	□ LCVG
☐ Cr EVA #1 Ziplock Bag	☐ Fg EVA #1 Ziplock Bag
☐ TCU (top)	☐ TCU (top)
☐ TCU (bottom)	☐ TCU (bottom)
☐ Wristlets	☐ Wristlets
☐ Comfort gloves	☐ Comfort gloves
☐ Thermax Sock Liners	☐ Tube Socks
☐ Cr EVA #2 Bag (same as Cr EVA #1)	☐ Croakie
☐ Cr EVA #3 Bag (same as Cr EVA #1)	☐ Moleskin
☐ Cr Contingency Bag	☐ Fg EVA #2 Bag (same as Fg EVA #1)
□ 8 MAGs	☐ Fg Contingency Bag
☐ 8 Ziplock bags	☐ 7 MAGs
☐ EV Crew ID stripes	☐ 7 Ziplock bags
☐ EV Crew ID tags	☐ Fresnel Lens
☐ Mission patch and flag	☐ Moleskin
	☐ EV Crew ID stripes
	☐ EV Crew ID tags
	☐ Mission patch and flag
	☐ Spare Mesh Bag

- 25. On EMU 3003 and 3015, disconnect LTAs
- 26. Stow Cr ECOK in EMU 3003 and Fg ECOK in EMU 3015
- 27. Connect LTAs to HUTs, and verify final configuration of both EMUs per lists below:

EMU 3003 (XL) FINAL RETURN CONFIG	EMU 3015 (L) FINAL RETURN CONFIG
,	
□ EMU 3003 – XL	□ EMU 3015 – L
☐ EMU Battery 2057	☐ EMU Battery 2058
☐ LiOH s/n 2018	☐ LiOH s/n 2019
□ LCVG (Cr)	□ LCVG (Fg)
☐ Mesh Bag (ECOK) (Cr)	☐ Mesh Bag (ECOK) (Fg)
☐ Gloves (Cr)	☐ Gloves (Fg)
□ LTA (Cr)	□ LTA
☐ Patches, Stripes, Flag (Cr)	☐ Patches, Stripes, Flag (Fg, or none – no need to install)
☐ Wrist Mirrors	☐ Wrist Mirrors
☐ Helmet (S/N 1061)	☐ Helmet (S/N 1063)
☐ Helmet cover installed	☐ Helmet cover installed
□ O2 ACT → OFF	□ O2 ACT → OFF
□ PWR → SCU	□ PWR → SCU
□ DCM Purge vlv → Op (up)	☐ DCM Purge vlv → Op (up)
□ WATER → OFF	☐ WATER → OFF
☐ WATER Switch Guard installed	☐ WATER Switch Guard installed
□ <u>No</u> Tethers/Tools	□ No Tethers/Tools
□ <u>No</u> Cuff Checklist	□ No Cuff Checklist
□ No EMU TV, Helmet Lights or REBA	□ No EMU TV, Helmet Lights or REBA

FS 2-20 EVA/116/FIN

Perform following on EMU 3003 and EMU 3015 to install the LTA Restraint Bag, reference LTA RESTRAINT STRAP INSTALLATION for diagrams as needed:

NOTE

If EMU 3015 already has an LTA Restraint Strap and LTA Restraint Bag installed on it, you may use that one and leave Fg LTA Restraint Strap and LTA Restraint Bag on ISS in M-02 bag s/n 1038. Make sure Fg CCA is stowed in LTA Restraint Bag kangaroo pouch on EMU 3015. If leaving Fg LTA Restraint Strap and Bag on ISS, inform MCC for stowage update purposes

- 28. VLTA Restraint Bag attached to LTA Restraint Strap D-rings (three)
- 29. Remove EMU from EDDA, as regd
- 30. LTA Restraint Strap SAFER mount brackets (two) → |← SAFER striker plate on PLSS
- 31. Install elastic band of LTA Restraint Strap around SOP
- 32. Tighten cinch strap mechanism
- 33. Engage EMU in EDDA as required to restrain EMU (will be pulled off of EDDA for transfer at the end of this procedure)
- 34. Stow LTA and suit arms inside LTA Restraint Bag
- 35. Upper spring hooks (two) →|← SAFER mount brackets (two) such that strap runs over shoulder
- 36. Lower spring hooks (two) \rightarrow | \leftarrow SAFER mount brackets (two)
- 37. Tighten all LTA Restraint Bag Straps with Bag as high as possible on EMU
- 38. Remove EMUs from EDDA as required to leave ISS airlock in the following config: EMU 3008 (La) on aft EDDA and EMU 3018 (W) on forward EDDA
- 39. Install helmet covers and temp stow EMU 3003 and EMU 3015 in Node (will be transferred to shuttle middeck at the end of this procedure)

EMU SYS TRANSFER BAG RECONFIGURATION FOR TRANSFER

40. Swap or transfer the following hardware per table 2 below

TABLE 2.- EVA SYSTEMS TRANSFER ITEMS

ITEM #	ITEM	CURRENT LOCATION	DESTINATION	STATUS
1a	EMU Servicing Kit (s/n 5002, yellow	EMU SYS TRANSFER BAG #2	EVA Prep and Ops M-02 bag (s/n 1038)	
	transfer tag)	DAG #2	W-02 bag (5/11 1030)	
1b	EMU Servicing Kit (s/n 5005)	EVA Prep and Ops M-02 bag (s/n 1038)	EMU SYS TRANSFER BAG #2	
2a	2 SCOFs	EMU SYS TRANSFER	ISS EMU Equipment	
	(s/n 1009, 1010)	BAG #2	Bag	
2b	2 SCOFs	ISS EMU Equipment Bag	EMU SYS TRANSFER	
	(s/n 1006, 1008)		BAG #2	
3a	2 Cooling Loop	EMU SYS TRANSFER	ISS EMU Equipment	
	Jumpers	BAG #2	Bag	
	(s/n 044, 046)			
3b	2 Cooling Loop	ISS EMU Equipment Bag	EMU SYS TRANSFER	
	Jumpers		BAG #2	
	(s/n 014, 051)			

TABLE 2.- EVA SYSTEMS TRANSFER ITEMS (Cont)

ITEM	ITEM	CURRENT LOCATION	DESTINATION	STATUS
#				
4	EMU Gloves W backup	EMU SYS TRANSFER	EMU Soft Goods	
	(s/n 6046)	BAG #2	M-02 bag (s/n 1010)	
5a	Bends Treatment	EMU SYS TRANSFER	EVA Prep and Ops	
	Adapter	BAG #2	M-02 bag (s/n 1038) – in	
	(s/n 1003)		outside pocket	
5b	Bends Treatment	EVA Prep and Ops	EMU SYS TRANSFER	
	Adapter	M-02 bag (s/n 1038) – in	BAG #2	
	(s/n 1009)	outside pocket		

41. Configure/verify final contents of EMU Sys Transfer Bags per table 3 below. Report any additional or missing hardware to MCC

TABLE 3.- EMU SYS TRANSFER BAG FINAL CONFIGURATION

EMU SYS TRANSFER BAG #1	EMU SYS TRANSFER BAG #2
 □ Aspirin (if any left over after EVAs) □ STS-116 Logistics Cue Card □ 2 STS EVA Checklists (PLT and MS3 copies) □ 2 LiOH Cartridges (CCC) (S/N 2024, 2025) □ Towels (brought over from WCS) □ Contamination Detection Kit (s/n 1001) 	 □ EMU Servicing Kit (s/n 5005) □ 2 ISS EVA Systems Checklists (CDR and PLT copies) □ EVA PREBREATHE Cue Card (with STS 116 protocol pen and inks) □ 1 BTA (s/n 1009) □ 2 SCOFs (s/n 1006, 1008) □ 2 Cooling Loop Jumpers (s/n 014, 051)

TRANSFER AND STOW

42. Transfer the items in table 4 to shuttle

TABLE 4.- TRANSFER TO STS

Item	Destination	Transfer Status
EMU 3003 (XL) with ECOK	Temp stow Middeck	
EMU 3015 (L) with ECOK	Temp stow Middeck	
EMU SYS TRANSFER BAG #1	Temp stow Middeck	
EMU SYS TRANSFER BAG #2	Temp stow Middeck	
"Return to Shuttle 1" Jettison	Temp stow Middeck	
Stowage Bag		
"Return to Shuttle 2" Jettison	Temp stow Middeck	
Stowage Bag		
"Return to Shuttle 3" Jettison	Temp stow Middeck	
Stowage Bag		
5 MLE bag (used for tool xfer)	Temp stow Middeck	
1.0 CTB (used for tool xfer)	Temp stow Middeck	

FS 2-22 EVA/116/FIN

43. Unpack and stow items from EMU Sys Transfer Bags per table 5 below; report status to MCC when complete:

TABLE 5.- EMU SYS TRANSFER BAG UNPACK AND STOW

Current Location	Item	Final Stowage Location	Status
EMU SYS TRANSFER BAG #1	Aspirin	Drug Subpack (MF28H)	
-	STS-116 Logistics Cue Card	FDF/SODF Locker (MF57H)	
-	STS EVA Checklists (2)	FDF/SODF Locker (MF57H)	
-	2 LiOH Cartridges (s/n 2024, 2025)	External Airlock Floor Bag	
-	Towels	Crew pref	
-	Contamination Detection Kit	Middeck Floor STBD 1 bag	
EMU SYS TRANSFER BAG #2	ISS EVA Systems Checklists (2)	FDF/SODF Locker (MF57H)	
-	EVA PREBREATHE Cue Card	FDF/SODF Locker (MF57H)	
-	BTA	MF43K	
-	EMU Servicing Kit	Volume H Inboard	
-	2 SCOFs	Volume H Inboard, inside EMU Equipment Bag	
-	2 Cooling Loop Jumpers	Volume H Inboard, inside EMU Equipment Bag	

This Page Intentionally Blank

<u>TIMELINES</u>

= \	VA 1	
	EVA 1 NOTES, CAUTIONS, & WARNINGS	FS 7-3
	EVA 1 BRIEFING CARD	FS 7-5
	EVA 1 INHIBIT PAD	FS 7-6
	EVA 1 SUMMARY TIMELINE	FS 7-7
	EVA 1 TOOL CONFIG	FS 7-8
	EGRESS	FS 7-9
	P5 LAUNCH LOCK REMOVAL	FS 7-10
	P5 TO P4 ATTACHMENT	FS 7-14
	PVRGF TRANSFER TO KEEL	FS 7-20
	P5 TO P4 UTILITIY CONNECTIONS (GET AHEAD)	FS 7-24
	CLA OPEN (GET AHEAD)	FS 7-26
	P5 PORT LAUNCH LOCK REMOVAL (GET AHEAD)	FS 7-28
	CP3 CAMERA R&R	FS 7-31
	CLEANUP	FS 7-35
	INGRESS	FS 7-36
Ξ١	VA 2	
	EVA 2 NOTES, CAUTIONS, & WARNINGS	FS 7-37
	EVA 2 BRIEFING CARD	FS 7-39
	EVA 2 INHIBIT PAD	FS 7-40
	EVA 2 SUMMARY TIMELINE	FS 7-41
	EVA 2 TOOL CONFIG	FS 7-42
	EGRESS	FS 7-43
	CHANNEL 2/3 POWER RECONFIGURATION	FS 7-44
	CETA CART 2 RELOCATION	FS 7-49
	CETA CART 1 RELOCATION	FS 7-52
	SSRMS FMS MLI INSTALLATION	FS 7-56
	Z1-006 PATCH PANEL 2 RECONFIGURATION	FS 7-58
	STBD AND PORT QD BAG INSTALLATION	FS 7-60
	VTE AND PM JUMPER BAG INSTALLATION	FS 7-61
	CLEANUP	FS 7-62
	INGRESS	FS 7-63
Ξ١	VA 3	
	EVA 3 NOTES, CAUTIONS, & WARNINGS	FS 7-64
	EVA 3 BRIEFING CARD	
	EVA 3 INHIBIT PAD	
	EVA 3 SUMMARY TIMELINE	FS 7-70
	EVA 3 TOOL CONFIG	FS 7-71
	EGRESS	FS 7-72
	CHANNEL 1/4 POWER RECONFIGURATION	FS 7-73
	SMDP TRANSFER	
	Z1-005 PATCH PANEL 1 RECONFIGURATION	FS 7-86
	RUSSIAN POWER RECONFIGURATION	FS 7-88
	AGB TRANSFER TO FHRC	
	CLEANUP	FS 7-94
	INGRESS	FS 7-95

This Page Intentionally Blank

EVA 1 NOTES, CAUTIONS, & WARNINGS

NOTES

- 1. Bolt release: report torque and turns if different from published range
- 2. EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD
- Inspect QDs for damage prior to mating (EETCS manual N2 venting)

CAUTION

ISS Constraints

- A. Avoid inadvertent contact with:
 - 1. Grapple fixture shafts
 - 2. PIP pins
 - 3. Passive UMAs
 - 4. MBS VDU, MCU, CRPCMs & Cameras (taped radiative surfaces, silver Teflon)
 - 5. Deployed TUS cable
- 6. SVS Targets with planned future use [S1, P1]
- 7. EETCS/PV Radiator bellows and panels [P6, P4, S4, S6]
- 8. SSRMS cameras
- B. Electrical cables:
- Avoid bend radii < 10 times cable diameter
- C. Fluid line flex hoses & QDs:
 - Avoid bend radii < 2 in for hoses with a diameter < 1 in
 - Avoid bend radii < 10 in for hoses with a diameter ≥ 1 in
 - Additional care should be taken to not exceed bend radii when applying loads at the flexible hose to rigid tube stub interfaces
- 4. Ensure fluid QD booties are fully closed prior to leaving worksite; wire tie if reqd

CAUTION (Cont)

ISS Constraints (Cont)

- D. For structural reasons:
 - Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
 - 2. Avoid performing shaking motions (sinusoidal functions) more than four cycles

E. Other:

- ITT Cannon connector: do not turn collar from WHITE to BLACK without a mating half attached
- Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners [P6,P4,S4,S6] can contaminate EMU

FS 7-3 EVA/116/FIN

EVA 1 NOTES, CAUTIONS, & WARNINGS (Cont)

WARNING

ISS Constraints

- A. Avoid inadvertent contact with:
 - 1. Grapple fixture targets and target pins
 - 2. SSU, ECU, beta gimbal platform, mast canister, SAW blanket boxes unless the beta gimbal is locked and the motor is turned off
 - 3. Stay inboard of SARJ when active
 - 4. Stay 5 ft from moving MT on face 1

B. Pinch:

- 1. NZGL connector linkage. Use caution when mating/locking
- 2. ITT Cannon Connector rotating housing
- EV side of IV hatch during hatch operation (also snag hazard) [A/L]

C. QDs:

- If QD is in FID when valve is opened (bail fwd), QD will leak and fluid line may whip
- 2. Do not rotate if in mated/valve open config

WARNING (Cont)

ISS Constraints (Cont)

- D. Sharp Edges:
 - 1. Inner edges of WIF sockets
 - Mating surfaces of EVA connectors.
 Avoid side loads during connector mating
 - 3. Back side of MMOD shield fasteners
 - Nickel coated braided copper Ground Straps may contain frayed wires [P6, P4, S4, S6]
 - 5. Solar Array Blanket Box [P6, S6]
 - Spring loaded captive EVA fasteners (e.g., 6B-boxes, BMRRM, RTAS ground strap bolt); the end of the spring may protrude

E. Thermal:

- EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
- Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on
- 3. Uncovered trunnion pins may be hot
- 4. SSRMS/MBS operating cameras/lights may radiate large amounts of heat
- 5. Do not touch EMU protective visor if temp has been < -134 for > 15 min
- 6. Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
- 7. Stay at least 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor up
- 8. Stay 0.5 ft away from PMA and MMOD shields > 325 degF

WARNING (Cont)

ISS Constraints (Cont)

- 9. No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF
- No EMU TMG contact of PMAs and MMOD shields when temp > 320 degF
- F. RF radiation exposure:
 - 1. Stay 3.6 ft from S-Band (SASA) high gain Antenna when powered [S1,P1,P6]
 - 2. Stay 1.3 ft from S-Band (SASA) low gain Antenna when powered [S1,P1,P6]
 - 3. Stay 1 ft from UHF Antenna when powered [Lab, P1]

FS 7-4 EVA/116/FIN

EVA 1 BRIEFING CARD

 1. EVA Prep Get-up Plan – clothing and EMU equipment bag Prebreathe protocol review Equipment lock activities Suit donning plan Airlock depress review 	 6. Emergencies Emergency suit doff and power down during EVA prep and post EV. CUFF checklist Abort and Terminate review – scenarios/protocols Hand signals
 Communications Overall setup: big loop, A/G2, S/G2, ICOM, Hardline, remind EV crew when mode swapping Use EV1(2) for DCM sw throws (all time in A/L) 	IV CHECKLIST VERIFICATION ITEMS
 3. EVA Procedure Review Order of tasks (summary timeline) Egress Plan Detailed Task Review Notes, Cautions, and Warnings Get ahead tasks P5-P4 Connections P5 CLA Cycle P5 Outboard LL Removal Ingress Plan Section 16 Contingencies 	 □ Day/Night Cycles and extended two-handed ops √Lights, heaters, visors, tools, tethers, gloves □ √Load Alleviating Strap on Safety Tethers not damaged □ √Safety Tether in good config
 4. Robotics SRMS/SSRMS initial position, maneuvers, clearances Coordinate Frames SSRMS/SRMS/IV comm protocol review 	 May get Lo Torque msg at bolt release Crew Report: "Torqued out, XX turns (or green light)" ¬Connectors for damage, bent pins, EMI band, FOD, cable bend rad Always receive GO from MCC prior to mating/demating electrical connections, review inhibits as reqd Crew Report: "Pins good, EMI band good, no FOD, bend radius OK"
 5. Post EVA Coldsoak Airlock Repress review Suit doffing responsibilities Post EVA plan 	□ Coordination between IV/EV/Robotics/Ground

FS 7-5 EVA/116/FIN

EVA 1 INHIBIT PAD

Orbiter

AII EVAs

TCS

L12 1. √TCS POWER – OFF

Ku-Band Antenna

MCC-H

- 1. √KU-BAND Mask active
- 2. √KU-BAND EVA Protect Box active

RCS

If EV crew < 27 ft from FRCS:

IV 1. √DAP: VERN, FREE, LO Z (flt specific √ with GNC)

O14,15,16 2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF

LOGIC (four) - OFF

MCC-H

3. √Above RCS config

4. √RCS F – ITEM 1 EXEC (*)

√JET DES F1U – ITEM 17 (*)

√F3U – ITEM 19 (*)

√F2U – ITEM 21 (*)

S-Band Antennas

NOTE

Possible loss of comm when forced LL FWD antenna

IV If EV crew < 1.6 ft from S-Band antenna:

A1R 1. S-BAND FM ANT – XMIT LOWER/RCVR UPPER

2. √MCC, lower antenna selected

If no comm, or on MCC call:

C3 3. S-BAND PM ANT – LL FWD

When EVA crewmember at least 1.6 ft away from all S-Band

upper antennas:

C3 4. S-BAND PM ANT – GPC

USOS

All EVAs

PCU

мсс-н

- 1. √PCUs (two) operational in discharge mode and one of the following:
 - A. CCS PCU EVA Hazard Control enabled
 - B. No more than two arrays unshunted
 - C. No more than two arrays pointed < 90 degrees from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
 - A. No more than two arrays unshunted
 - B. No more than two arrays pointed < 90 degrees from velocity vector

Ground Radar

MCC-H

1. √TOPO and FDO consoles, ground radar restrictions in place for EVA

Location Dependent Inhibits

SARJ

MCC-H

If EV crew working within 2 ft or outboard of SARJ:

- 1. √DLA (1) LOCKED
- 2. All motor setpoints set to zero
- 3. All motors deselected

OR

4. Both DLAs - LOCKED

RSOS

All EVAs

SM Antennas

MCC-M

1. Global Timing Sys 1(400.1 MHz) [GTS] – Deactivate

FS 7-6 EVA/116/FIN

EVA 1 SUMMARY TIMELINE

TIME	SSRMS	EV1 (FF)	EV2 (FF)
0:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)
0:05		EGRESS (00:25)	EGRESS (00:25)
0:30	SSRMS: 2.101 P5 INSTALL AND UNGRAPPLE	P5 LAUNCH LOCK REMOVAL (01:00)	P5 LAUNCH LOCK REMOVAL (01:00)
1:30	SSRMS: 2.101 P5 INSTALL AND UNGRAPPLE	P5 TO P4 ATTACHMENT (01:30) SSRMS GCA in to Soft Capture Bolt #1 Initial Torque (Fwd/Zenith) (Fixed) Bolt #3 Initial and Final Torque (Aft/Zenith) (Float) Ground Strap #3 Installation P4 Soft Capture Pin 3 Removal Bolt #1 Final Torque Ground Strap #1 Installation P4 Soft Capture Pin 1 Removal (Fwd/Zenith)	P5 TO P4 ATTACHMENT (01:30) SSRMS GCA in to Soft Capture Bolt #2 Initial Torque (Fwd/Nadir) (Y-Slider) Bolt #4 Initial and Final Torque (Aft/Nadir) (Float) Ground Strap #4 Installation P5 EWIS Connector Mate (at Corner 4) Bolt #2 Final Torque Ground Strap #2 Installation
3:00		PVRGF TRANSFER TO KEEL (01:00)	PVRGF TRANSFER TO KEEL (01:00)
4:00		CP3 CAMERA R&R (01:30)	CP3 CAMERA R&R (01:30) Camera Retrieval From Airlock Failed Camera Removal Spare Camera Install
5:30		CLEANUP (00:20)	CLEANUP (00:20)
5:50		INGRESS (00:20)	INGRESS (00:20)
6:10		PRE REPRESS (00:05)	PRE REPRESS (00:05)
6:15			

Assumptions: Get ahead P5 tasks (P5/P4 Connections, CLA Cycling, P5 Port Launch Lock Removal) will be added if time permits. The EVA will be extended to a maximum 6:30 duration in order to accommodate the get-aheads

FS 7-7 EVA/116/FIN

EVA 1 TOOL CONFIG

AIRLOCK	AIRLOCK ENDCONE Staging Bag	AIRLOCK INTERNAL D-RING D-ring extender
EMU 1 MWS, right swing arm Digital camera (inner right swing arm) BRT (left) w/2 wire ties & sm-sm RET T-Bar ISS trash bag (inner left) Socket caddy (outer right) RAD (s/n:)	Fish Stringer #3 Connector cleaner tool caddy Wire tie caddy (2) Pin straightener MWS Key strap Velcro/Tape caddy Spare PGT (s/n:); battery (s/n:) Pry Bar EVA Ratchet	UIA HANDRAILS: Fish Stringer #1 (laid across UIA HRs) Cannon Connector Tool (1 tool, no caddy) Torque Wrench (set to 57 ft-lb) (s/n:) (use both torque wrench and bag tether points) Spare safety tether (55') PGT (s/n:) w/RET; battery (s/n:)
7/16 x 6-in ext 5/8 x 7.8-in ext Sm-sm RET (left D-ring) Adj tether (left D-ring) Sm-sm RET w/PIP pin (right D-ring)	Probe IV Bag Contamination Detection Kit Hydrazine Detector (Gold Salt Coupon) (6) Color Chart (2)	Fish Stringer #2 (laid across UIA HRs) Torque Wrench (set to 57 ft-lb) (s/n:) (use both torque wrench and bag tether points) PGT (s/n:) w/RET; battery (s/n:)
Adj tether (right D-ring) D-ring ext – left 85' safety tether Waist tether – right SAFER	ISS Contamination Detection Sampler (2) Shuttle Contamination Detection Sampler (2) Nitrogen Dioxide Detector (Oxidizer Draeger Tube) (6) Ammonia Detector (NH3 Draeger Tube) (6) 2 towels with wire ties	ZEN/PORT CREWLOCK HR (or UIA HR) Config ETVCG as follows (s/n#:) Verify camera electrical cap is removed Light pre-installed on camera & conn mated Tedlar bag removed from light Camera stowed in Ig ORU bag w/round
EMU 2 MWS, right swing arm Digital camera (inner right swing arm) BRT (left) w/3 wire ties & sm-sm RET T-Bar ISS trash bag (outer right) Wire ties (2) around T-Bar Socket caddy (inner left)	DCM plug (2) (SAFER hardmount) GP caddy (2) Thermal mittens (2 pr) Socket Caddy (hatch contingencies) w/sm-sm RET 1/2 X 8-in socket (IV hatch) 7/16 X 6-in socket (spare) PRE-EVA 1 TOOL CONFIG 1. Configure/verify MWSs 2. Transfer RETs onto MWSs as listed	scoop installed, light hangs out of hinge on right side ETVCG tethered inside bag (RET) via light tether point or scoop 1 adj on bag HR (truss tether) Round scoop attached to bag fitting (2nd) Lg-sm RET for stowage inside A/L
RAD (s/n:) 7/16 x 6-in ext 5/8 x 7.8-in ext Sm-sm RET w/PIP pin (left D-ring) Adj tether (left D-ring) Sm-sm RET w/PIP pin (right D-ring) Adj tether (right D-ring)	 3. Relocate wire ties from staging bag onto MWS 4. Attach transferred Torque Wrench and MLI to fish stringer #2 5. Attach fish stringers #1& #2 to UIA tether point 6. Transfer Velcro/tape caddy to staging bag 7. Transfer remaining sm-sm RETs (3), sm-sm RET w/PIP Pin, and Lg-sm RETs (5) to tether 	POST EVA 1 TOOL CONFIG 1. Retrieve "Return to Shuttle 1" jett stow bag from "EVA 1 Shuttle to ISS" jett stow bag 2. Stow the following items in the "Return to Shuttle 1" jettison stowage bag P5 launch locks (4-8) (from trash bags & stringer) P4 EWIS cap
D-ring ext (2) 85' safety tether (left D-ring extender) Spare 55' safety tether to MWS (left D-ring ext) Waist tethers (2) (attach 1 to right D-ring extender) SAFER Total sm-sm RETs used (w/o PIP pin): 6 Total sm-sm RETs (w/PIP Pin) used: 3 Total lg-sm RETs used: 1 Total adj tethers used: 5	staging area 8. Verify IV and Staging Bag contents per list 9. Put ETVCG in airlock and config as listed 10. Stow MWSs in "EV1" and "EV2" jettison stow bags as reqd (from "EVA 1 Shuttle to ISS" bag) 11. Prior to EVA, inspect the following: RET cords for damage BRT and MWS toggles: loose fittings/screws Safety and waist tether load alleviating straps (no red band or damage)	 P5 soft capture assemblies (2) 3. Stow failed ETVCG TBD 4. Stow torque wrenches (2) in Staging Bag 5. Relocate PGT w/6-in socket from EV2's MWS to crewlock bag #2 (becomes spare PGT); stow socket on socket caddy 6. Relocate EV1's and EV2's socket caddy w/RAD and 5/8 x 7.8-in ext to Staging Bag

FS 7-8 EVA/116/FIN

EGRESS (00:25)

IV	EV1 (FF)	EV2 (FF)
NOTE For safety tether swaps, expect to hear: 1. Hook closed	√Right waist tether to airlock internal D-ring extender, verify ST config √85' safety tether attached to left D-ring extender, verify ST config	√Right waist tether to UIA panel fwd D-ring, verify ST config √85' safety tether attached to left D-ring extender, verify ST config
Slide locked Reel unlocked	 Thermal cover – open Egress airlock Inspect load alleviating straps on 55' safety tethers (2) Attach long strap of 85' safety tether to airlock fwd D-ring, verify ST config Release waist tether from internal D-ring extender Receive fish stringer's #1 and #2 from EV2 	Transfer fish stringers #1 and #2 to EV1
1. Start torque wrench thermal clock: (3.5 hr)	 7. Temp stow fish stringer #1 in between A/L port toolbox HR and stbd toolbox HR (stretched out) 8. Temp stow fish stringer #2 in between A/L HR 0560 (fwd/stbd/nadir) and HR 0555 (nadir of stbd toolbox) 	
	 9. Receive EV2's 85' safety tether, attach to airlock aft D-ring, verify ST config 10. Remove 55' safety tether from airlock fwd external D-ring, stow on fish stringer #1 	 Transfer long strap of 85' safety tether to EV1 Release right waist tether from UIA panel D-ring Egress airlock
2. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max (required after EV1 and EV2 egress airlock)	11. √EV2's SAFER MAN ISOL vlv – OP (dn) and HCM (dn)	 5. Close thermal cover 6. √EV1's SAFER MAN ISOL vlv – OP (dn) and HCM (dn) 7. Remove 55' safety tether from airlock aft external D-ring, stow on fish stringer #2
egress amount	 12. Relocate PGT (and RET) from fish stringer #1 to outer swingarm 13. Retrieve fish stringer #1; attach to MWS 14. Perform translation adaptation on S0 	8. Relocate PGT (and RET) from fish stringer #2 to outer swingarm 9. Retrieve fish stringer #2, attach to MWS 10. Perform translation adaptation on airlock spur

FS 7-9 EVA/116/FIN

P5 LAUNCH LOCK REMOVAL (01:00)

IV/SSRMS	EV1 (FF)	EV2 (FF)	
zenith 3 1 P5 port 2 P5 AND P4 CORNER DESIGNATION		1. Translate to P1 HR 3601 (P1 Bay 12, Face 1) 2. Perform safety tether swap onto HR 3601 with 55' safety tether, verify ST config 3. Translate to P4 HR 5133 (nadir IEA) NOTE EV2 translates nadir on P4 4. Perform safety tether swap onto P4 HR 5133 with remaining 55' safety tether, verify ST config 5. Translate to P4 corner 2 (fwd/nadir) 6. Temp stow fish stringer #2 on P4 HR 5154 & 5153 7. Assess need for fairlead around radiator, install as reqd 8. √P4 soft capture pin is set (pin is visible in alignment hole) SSRMS GCA IN TO 20 CM (~8 IN) 1. Get in position for GCA at corner 2 (fwd/nadir) (hold on to P4 HR 5149 by WIF 23) WARNING SSU and RTAS housing – do not allow RTAS housing clearance with SSU to fall below 3.0 cm (1.2 inches) SSU and P5 HR	
	RTAS housing and 4	4-bar linkage	

FS 7-10 EVA/116/FIN

P5 LAUNCH LOCK REMOVAL (01:00) (Cont)

	IV/SSRMS	EV1 (FF)	EV2 (FF)	
1.	2.101 P5 Install and Ungrapple (SODF: RBT FS: P5 Install - EVA 1) steps 3-3.4	GCA SSRMS into launch lock removal position LAUNCH LOCK REMOVAL FROM CORNER 3	GCA SSRMS into launch lock removal position LAUNCH LOCK REMOVAL FROM CORNER 2	
	zenith		ITION ight. Avoid contact with P5 and do not removing launch locks	
^	3	Do not exceed 72 turns (PGT), 36 turn or primary bolt can come free of self for		
stb	P4 P5 port	Hardware sensitive to crew loads. Do primary bolt. Damage to self-feeding		
	P5 AND P4 CORNER DESIGNATION			
2.	SSRMS operator: when brakes on, give EV crew	1. BRT to P4 HR 5136 (next to P4 WIF 17)	 Watch clearances between helmet and SSU BRT to P4 HR 5138 	
3.	GO to begin launch lock removal Record number of turns to	2. PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #3, 54 turns (PGT), 27 turns (bolt)	3. PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #2, 54 turns (PGT), 27 turns (bolt)	
	retract P5 primary bolt from launch lock	 3. Remove launch lock #3, stow in trash bag 4. √2-7 threads visible or bolt head recessed inside shear cylinder 	 4. Remove launch lock #2, stow on fish stringer #2 5. √2-7 threads visible or bolt head recessed inside shear cylinder 	
	#3 (EV1) turns #2 (EV2) turns	5. Remove RAD and 5/8" socket from PGT, temp stow on PIP pin in trash bag	6. Remove RAD and 5/8" socket from PGT, temp stow on PIP pin in trash bag	

FS 7-11 EVA/116/FIN

P5 LAUNCH LOCK REMOVAL (01:00) (Cont)

IV/SSRMS EV1 (FF)		EV2 (FF)
LL #1 (EV1) turns LL #4 (EV2) turns	 LAUNCH LOCK REMOVAL FROM CORNER 1 Translate to corner 1; BRT to P4 HR 5107 PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #1, 54 turns (PGT), 27 turns (bolt) ■ Remove launch lock #1, stow in trash bag √2-7 threads visible or bolt head recessed inside shear cylinder Remove RAD and 5/8" socket from PGT, temp stow on PIP pin in trash bag Verify P5 alignment at corner 1 	 LAUNCH LOCK REMOVAL/SETUP FROM CORNER 4 Translate to corner 4 (aft/nadir) √P4 soft capture pin is set (pin is visible in alignment hole) BRT to P4 HR 5137 PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #4, 54 turns (PGT), 27 turns (bolt) ✓ Remove launch lock #4, stow on fish stringer #2 √2-7 threads visible or bolt head recessed inside shear cylinder Remove RAD and 5/8" socket from PGT, temp stow on PIP pin in trash bag √APFR settings for P4 WIF 20: [6,WW,A,10] Verify P5 alignment at corner 4

FS 7-12 EVA/116/FIN

P5 LAUNCH LOCK REMOVAL TASK DATA SHEET

Tools:

EV1	EV2
PGT	PGT
RAD	RAD
5/8 x 7.8-in ext	5/8 x 7.8-in ext

Foot Restraints (Optional Use)

Task	WIF	APFR Setting		
P5 LL 3 Removal	(P4 WIF 17)	[5,RR,J,12]		
P5 LL 4 Removal	(P4 WIF 20)	[6,WW,A,10]		
	(P4 WIF 20)	OR [6,QQ,A,12]		
P5 LL 1 Removal	(P4 WIF 18)	[8,OO,D,12]		
P5 LL 2 Removal	(P4 WIF 19)	[6,PP,L,11]		
	OR	OR		
	(P4 WIF 26)	[12,NN,B,12]		

Alternate HRs to BRT:

Alternate files to Divi.				
Task	HR			
P5 LL 3 Removal	P4 HR 5142 (port) (SSU)			
P5 LL 4 Removal	P4 HR 5146 (nadir)			
P5 LL 1 Removal	P4 HR 5139 (trunnion)			
P5 LL 2 Removal	P4 HR 5150 (nadir)			

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
Primary Bolt	1	5/8"	1	12.0 (thru RAD) 25.5 (no RAD)	610	27 (bolt)	30
Primary Bolt	2	5/8"	1	same	610	27 (bolt)	30
Primary Bolt	3	5/8"	1	same	610	27 (bolt)	30
Primary Bolt	4	5/8"	1	same	610	27 (bolt)	30

EVA Connectors: N/A

Notes:

- 1. EV1 translates zenith on P4
- 2. EV2 translates nadir on P4
- 3. Primary bolt will come free of launch lock at ~ 38 turns (PGT), 19 turns (bolt) (KSC data)

Cautions:

- Tight clearances between BGA and P5; monitor: SSU and RTAS housing (for EV2, do not allow RTAS housing clearance with SSU to fall below 3.0 cm (1.2 inches), SSU and P5 handrail, RTAS housing and 4-bar linkage, PVRGF and Mast canister HR
- 2. Clearances between P4 and P5 are tight. Avoid contact with P5 and do not impart any loads into structure while removing launch locks
- 3. Do not exceed 72 turns (PGT), 36 turns (bolt) when removing launch locks or primary bolt can come free of self feeding nut
- 4. Hardware sensitive to crew loads. Do not apply a push or pull force on primary bolt. Damage to self-feeding nut may result

Warnings:

1. N/A

Timeline Considerations:

- P5 launch locks must be removed before P5 can be soft captured to P4
- 2. Torque wrench exposure is limited to 3.5 hr to maintain correct calibration. Thermal clock starts when tool is removed from airlock

RTAS Guidelines:


1. One crewmember can translate on P5 with any 2 diagonal corners in soft capture (TBR for two crewmembers)

FS 7-13 EVA/116/FIN

P5 TO P4 ATTACHMENT (01:30)

IV/SSRMS	EV1 (FF)	EV2 (FF)		
	SSRMS GCA IN TO SOFT CAPTURE 1. Translate to corner 3 (aft/zenith) 2. Get in position for GCA at corner 3	SSRMS GCA IN TO SOFT CAPTURE 1. Translate to corner 2 (fwd/nadir)		
	NOTE Monitor zenith corners (3 and 1) during GCA	<u>NOTE</u> Monitor nadir corners (2 and 4) during GCA		
1. 2.101 P5 Install and Ungrapple (SODF: RBT FS: P5 Install - EVA 1) step 3.5	 Verify P5 alignment with SSRMS operator prior to GCA GCA SSRMS into soft capture √P4 soft capture pin has engaged P5 coarse alignment cone at corner 3 √P4 soft capture pin has engaged P5 coarse alignment cone at corner 1 (fwd/zenith) 	 Verify P5 alignment with SSRMS operator prior to GCA GCA SSRMS into soft capture √P4 soft capture pin has engaged P5 coarse alignment cone at corner 2 √P4 soft capture pin has engaged P5 coarse alignment cone at corner 4 (aft/nadir) 		
zenith 3 1 P5 port 2 P5 AND P4 CORNER DESIGNATION				

FS 7-14 EVA/116/FIN



FS 7-15 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (FF)	
 4A. Verify initial torque complete on all 4 bolts prior to final torquing. Final bolt torquing may be completed in any order 4B. Verify EV1 and EV2 are clear of SSRMS ungrapple envelope 4C. 2.101 P5 Install and Ungrapple (SODF: RBT FS: P5 Install - EVA 1) step 5 (Give SSRMS operator GO to ungrapple) 4D. Record turn count for final 	 3. PGT [B1, CW2, 30.5]-RAD-7.8"-Ext-5/8: On EV2 GO: Drive bolt #3, 54 turns (PGT), 27 turns (bolt) 4. √Primary bolt shoulder seated (flush to large nut) 5. Stow RAD on socket caddy 6. Configure torque wrench w/7.8-Ext-5/8: √57 ft-lb; tighten primary bolt at corner 3 until torque wrench trips (~1/4 turn) 7. Perform gap check w/equipment hook 8. Remove 5/8-in socket from torque wrench, temp stow in trash bag (for translation) GROUND STRAP #3 INSTALLATION 1. Reconfigure PGT with 6-in socket 2. Egress APFR 3. BRT to P4 HR 5136 	BOLT #4 INITIAL AND FINAL TORQUE (AFT/NADIR) 1. Retrieve torque wrench from fish stringer #2, translate to corner 4 2. Ingress APFR in P4 WIF 20 3. PGT [B1, CW2, 30.5]-RAD-7.8 Ext-5/8: Drive bolt #4, 54 turns (PGT), 27 turns (bolt) 4. √Primary bolt shoulder seated (flush to large nut) 5. Stow RAD on socket caddy 5. Configure torque wrench w/7.8-Ext-5/8: √57 ft-lb; tighten primary bolt at corner 4 until torque wrench trips (~1/4 turn) 6. Perform gap check w/equipment hook 7. Remove 5/8-in socket from torque wrench, temp stow in trash bag (for translation) GROUND STRAP #4 INSTALLATION 1. Reconfigure PGT with 6-in socket 2. PGT [B3, CCW2, 30.5]-6"-Ext-7/16: Release ground strap from P4, 13 turns	
Bolt 3 (final) turn Bolt 4 (final) turn	4. PGT [B3, CCW2, 30.5]-6"-Ext-7/16: Release ground strap from P4, 13 turns CAUTI Ground straps are sensitive to cross threfor thread alignment and complete total total total straps. 5. PGT [B1, CW1, 30.5]-6"-Ext-7/16: Manually install ground strap to P5 ~1 turn; continue installing ground strap with PGT for total of ~ 9-12 turns (hard stop)	ON eading. Begin installation manually	

FS 7-16 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (FF)
5. √MCC EWIS inhibits in place: Open RPCM P42A-A, RPC8	P4 SOFT CAPTURE PIN 3 REMOVAL 1. PGT [A6, CCW2, 30.5]-6"-Ext-7/16: Release soft capture pin fasteners (4), 13-17 turns 2. Remove soft capture pin assembly 3. Stow on fish stringer #1 on way to corner 1 4. □ corner 3 final config BOLT #1 FINAL TORQUE	P5 EWIS CONNECTOR MATE (at corner 4) NOTE Check connectors for FOD, bent pins, bend radius, and EMI band Position body at P4 EWIS cap (by alignment cone) Demate cap from P4 J1, stow in trash bag Release TA clamps (2)
6. Give MCC GO for EWIS power up 1. Relocate APFR from P4 WIF 17 to P4 WIF 18 (fwd/zenith); configure to [8,OO,D,12] 2. Ingress APFR Bolt 2 (final) turn Bolt 1 (final) turn 4. Torque wrench w/7.8"-Ext-5/8: √57 ft-lb; tighten		 4. Demate P5 P1 from P5 J1, mate to P4 J1 ★ 5. Close TA clamps (2) 6. Install wire ties as reqd 7. □ connector final config
zenith	 4. Torque wrench w/7.8"-Ext-5/8: √57 ft-lb; tighten primary bolt until torque wrench trips (~1/4 turn) 5. Perform gap check w/equipment hook 6. Stow 7.8"-Ext-5/8" socket on socket caddy GROUND STRAP #1 INSTALLATION	BOLT #2 FINAL TORQUE 1. Relocate APFR from P4 WIF 20 to P4 WIF 19 (fwd/nadir); configure to [6,PP,K,11] 2. Ingress APFR
stb P4 P5 port	Release ground strap from P4, 13 turns 4. PGT [B1, CW1, 30.5]-6"-Ext-7/16: Manually install ground strap to P5 ~1 turn; continue installing ground strap with PGT	 Reconfigure torque wrench w/5/8-in socket Torque wrench w/7.8"-Ext-5/8: √57 ft-lb; tighten primary bolt until torque wrench trips (~1/4 turn) Perform gap check w/equipment hook Stow 7.8"-Ext-5/8" socket on socket caddy GROUND STRAP #2 INSTALLATION
P5 AND P4 CORNER DESIGNATION	for total of ~ 9-12 turns (hard stop)	1. PGT [B3, CCW2, 30.5]-6"-Ext-7/16: Release ground strap from P4, 13 turns

FS 7-17 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (FF)
	P4 SOFT CAPTURE PIN 1 REMOVAL (FWD/ZENITH)	2. PGT [B1, CW1, 30.5]-6"-Ext-7/16: Manually install ground strap to P5 ~1 turn
	1. PGT [A6, CCW2, 30.5]- 6"-Ext-7/16 : Release soft capture pin fasteners (4), 13-17 turns	Continue installing ground strap with PGT for total of ~ 9-12 turns (hard stop)
	2. Remove soft capture pin assembly, temp stow	3. Egress APFR
	3. □ corner 1 final config	4. □ corner 2 final config
	4. Stow torque wrench, soft capture pin assembly, and	5. Temp stow torque wrench on fish stringer #2
	socket caddy on fish stringer #1	

FS 7-18 EVA/116/FIN

P5 TO P4 ATTACHMENT TASK DATA SHEET

Tools:

EV1	EV2
PGT	PGT
RAD	RAD
5/8 x 7.8-in ext	5/8 x 7.8-in ext
7/16 x 6-in ext	7/16 x 6-in ext
Torque Wrench	Torque Wrench

Foot Restraints (Optional Use)

Task	WIF	APFR Setting
Bolt 1 Initial and Final Torque	P4 WIF 18	[8,OO,D,12]
Bolt 2 Initial and Final Torque	P4 WIF 19	[6,PP,K,11]
Bolt 2 Initial and Final Torque — alternate	(P4 WIF 26)	[3,PP,G,11]
Bolt 3 Initial and Final Torque	P4 WIF 17	[5,RR,J,12]
Bolt 4 Initial and Final Torque	P4 WIF 20	[6,WW,A,10]

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release/ Install Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RP M
RTAS Primary Fastener	1,2,3,4	5/8"	4	Install: 25.5 (initial) 57.0 (final)	105.3 (insert shear out)	27 (bolt)	30
Ground Straps	none	7/16"	4	Release: 18.4 Install: 12.0	Release: 31.1 Install: 26.4	Release: 11-13 Install: 8-12	30
Soft Capture Pin Assembly	none	7/16"	4	Release: 8.3	12.0	13-17	30
Gap check tool bolts	none	7/16"	2	Release: 8.3	Release: 12.2	12-14	30

EVA Connectors:

Connector	From	То	Clamps	Size	Function
P5 EWIS	P5 P1 (W5426)	P4 J1 (W5425)	2	15	EWIS heater

RTAS Guideline:

 P5 can be translated on by one crewmember after 2 diagonal corners are in soft capture (TBR for 2 crewmembers). Thus, P5 is in a safe config to be used as an ingress aid for final torquing of RTAS bolts (already have achieved initial torque)

Notes:

- Primary bolts must be fastened in the following order; Bolt 1 (fwd/zenith), Bolt 2 (fwd/nadir), Bolts 3 (aft/zenith) and 4 (aft/nadir) can be fastened in any order AFTER bolts 1 & 2
- For contingency gap check measurement using gap check tool, retrieve gap check tool from Corner 1 (see MRTAS Primary Bolt Contingencies procedure in section 16, step 3C). Tip of tool should not penetrate gap between RTAS housings past second line
- 3. Soft capture black indicator lines will NOT be visible when P4 soft capture pins have engaged P5 coarse alignment cones successfully
- 4. All 4 corners must have initial torque prior to final bolt torquing on any bolt. Final torquing can happen in any order
- 5. Tolerances for Coarse Align Cone Engagement (getting all 4 cones to go into the cups):
- Lateral: +/- 2.0 inches, Roll: +/- 1.7 degrees, Wobble: +/- 3.1 degrees
 - 6. Tolerances for Soft Capture Engagement (pin dropping into slot):
- Lateral: +/- 0.175 inches, Roll: +/- 0.15 degrees
 - 7. P4 HR 5138 serves as backup for EV2 ground strap 2 install

Cautions:

- Tight clearances between BGA and P5; monitor: SSU and RTAS housing (from pre-install to LL removal); SSU and P5 HR (from LL removal to soft capture); RTAS housing and 4-bar linkage (from LL removal to soft capture); PVRGF and mast canister HR
- Ground straps are sensitive to cross threading. Begin installation manually for thread alignment and complete total turns and torque with PGT
- Hardware sensitive to crew loads. Do not apply a push force on primary bolt.
 Damage to self-feeding nut may result

Timeline Considerations:

- The final torquing sequence and ground strap attach order in this procedure weighs socket swaps against APFR relocations as well as crew translations between corners
- Torque wrench exposure is limited to 3.5 hours to maintain correct calibration. Thermal clock starts when tool is removed from airlock
- The soft capture pin assembly at corner 1 is removed because of a future hardware interference between it and the outboard MT/CETA rail. The soft capture pin assembly at corner 3 is removed because EVA deployed wire harnesses W10 and W08 are eventually routed through this area between P4 and P5
- 4. Initial torque must be achieved at all 4 corners prior to giving SSRMS operator GO to ungrapple (conservative approach and pending new data, ungrapple may occur after 4 corners have achieved soft capture)
- EWIS thermal clock: The EWIS thermal clock begins once P5 is soft captured to P4; connector must then be mated within 6 hours

FS 7-19 EVA/116/FIN

PVRGF TRANSFER TO KEEL (01:00)

IV	EV1 (FF)	EV2 (FF)
H13 in MLI		NOTE EV2 remains nadir when translating to the PVRGF via nadir of 4A BGA JTION grapple pins and RMS targets
Zenith Zenith H13 H15 Stbd H16 H14 Nadir P5 WIF 11 (H16 HR removed) PVRGF BOLT PATTERN	RELEASE FASTENER H15 (Zenith/Port) 1. Translate to PVRGF fastener H15 (zenith/port); fair lead tether over APFR as reqd; BRT to HR 5203 2. PGT [B4, CCW2, 30.5]-6"-Ext-7/16: Release PVRGF fastener H15, 6-8 turns (do not go to hard stop at this torque) 3. Remove retaining washer, stow in TA clamp	 Relocate APFR from P4 WIF 19 (fwd/nadir) to P5 WIF 11 (nadir): configure APFR to [9,QQ,H,12] RELEASE GROUND STRAP FASTENER (H14) Attach waist tether to APFR roll pedal Ingress APFR in P5 WIF 11 PGT [B7, CCW2, 30.5]-6"-Ext-7/16: Release PVRGF ground strap fastener, G1 (at H14 corner), 11-13 turns Secure end in PVRGF TA clamp RELEASE FASTENER H14 (Nadir/Port) PGT [B4, CCW2, 30.5]-6"-Ext-7/16: Release PVRGF fastener H14, 6-8 turns (do not go to hard stop at this torque) Remove retaining washer, stow in adjacent P5 TA clamp

FS 7-20 EVA/116/FIN

PVRGF TRANSFER TO KEEL (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
1A. Verify SSRMS is clear of PVRGF removal plane 1B. Do not release H13 fastener until EV2 is holding PVRGF keel zenith		 RELEASE FASTENER H16 (Nadir/Stbd) Reconfigure PGT w/RAD and 6-in socket PGT [B1, CCW2, 30.5]-RAD-6"-Ext-7/16; Release PVRGF fastener H16 (nadir/stbd), 12-16 turns (PGT), 6-8 turns (bolt) (do not go to hard stop) Remove retaining washer, stow in adjacent P5 MLI flap
stbd H16 H14	Be aware of tight clearances between: • Nadir/stbd corner of PVRGF (faster platform cables	ner H16) with Mast Canister HR & BGA Mast Canister HR & BGA platform cables 4) and outbd RTAS housings
nadir P5 WIF 11 (H16 HR removed) PVRGF BOLT PATTERN	 RELEASE FASTENER H13 (Zenith/Stbd) Translate to PVRGF fastener H13 (zenith/stbd) Reposition body so feet are zenith/stbd (on your left side) BRT to HR 5202 PGT [B4, CCW2, 30.5]-6"-Ext-7/16: Release PVRGF fastener H13, 6-8 turns (do not go to hard stop at this torque) Remove retaining washer, stow in adjacent P5 MLI flap 	 Deconfigure RAD with 6-in (for translation) Roll APFR from H to G Tether to PVRGF HR next to H14 with RET Hold PVRGF HRs Give EV1 GO to begin releasing bolt H13
	Monitor clearances between port PVRGF corners and P5 outboard RTAS housing	9. Lift PVRGF off posts due forward while pitching port corners H14 and H15 ~ 10 degrees away from P5 outboard RTAS housing 10. Remove PVRGF

FS 7-21 EVA/116/FIN

PVRGF TRANSFER TO KEEL (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
IV NOTE EV1 and EV2's 1st HRs are not shown in picture	PVRGF STOWAGE ON KEEL 1. Translate to EV2 (go zenith, then aft to deconflict tethers) (zenith/fwd P5 HR 5241) 2. Assist EV2 with guiding PVRGF around corner 3. Translate to P5 HR 5240, attach BRT 4. Receive PVRGF from EV2, tether 5. Translate to P5 keel HR 5234 (zen/aft), attach BRT 7. Align PVRGF corner H14 with keel post H14 8. Slide spherical bearing onto keel post at corner H14 and along diagonal beam post #03 until fully seated 9. Install PIP pin at corner H14 10. Install PIP pin at diagonal beam #03 (on keel) EV2 2nd HR: 5238 FWD PVRGF STOWED ON KEEL	

FS 7-22 EVA/116/FIN

PVRGF RELOCATION TO KEEL TASK DATA SHEET

Tools:

EV1	EV2
PGT	PGT
7/16 x 6-in ext	RAD
	5/8 x 7.8-in ext
	7/16 x 6-in ext

Foot Restraints (Optional Use)

Task	WIF	APFR Setting
PVRGF Removal	P5 WIF 11	[9,QQ,H,12]

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
PVRGF Fastener	H13 H14 H15 H16	7/16"	4	Release: 19.4 (do not go to hard stop at this torque) (12.0 w/RAD)	8.3 (failure torque at hard stop)	6-8	30
Ground Strap	GS 1	7/16"	1	Release: 25.5 Install: 7.0		Release: 11-13 Install on keel: 11-13	30

PVRGF Mass = ~228 lbs/103 kg

Notes:

- EV1 remains zenith when translating to the PVRGF via zenith fwd edge of P4/P5
- EV2 remains nadir when translating to the PVRGF via nadir of 4A BGA
- For PVRGF spherical bearings: H13 (fixed), H16 (slotted), H14 (float), H15 (float)

Cautions:

- 1. Avoid contact with PVRGF grapple pins and SRMS targets
- 2. Be aware of tight clearances between:
- Nadir/stbd corner of PVRGF (fastener H16) with Mast Canister HR & BGA platform cables
- Nadir/stbd PIP pin on PVRGF with Mast Canister HR & BGA platform cables
- Port corners of PVRGF (H15 & H14) and outbd RTAS housings

Warnings:


1. N/A

Timeline Considerations:

- 1. PVRGF must be removed in order to rotate 4A BGA
- 2. The H16 HR on the PVRGF was removed pre-flight (to reduce clearance concerns with BGA during removal)
- 3. PVRGF bolts can be released in any order with the exception that EV2 must be holding the PVRGF prior to EV1 releasing the last bolt (H13)
- 4. PVRGF bolts are captive and will reach a hard stop when released all the way. Bolts can be re-driven (CW) up to 17 turns after washer removal; this can provide an additional 0.85" of clearance for PVRGF removal

FS 7-23 EVA/116/FIN

P5 TO P4 UTILITY CONNECTIONS (GET AHEAD) (00:45)



FS 7-24 EVA/116/FIN

P5 TO P4 UTILITY CONNECTIONS (GET AHEAD) TASK DATA SHEET

Tools:

EV1	EV2
Cannon Connector Tools	N/A

Foot Restraints (if BRT does not work):

Task	APFR Setting				
P5 to P4 Utility Connections		P5	Connector	APFR	
(in order they must occur)		WIF		Setting	
		04	P42	[9,UU,K,12]	
			J42	[4,PP,C,11]	
		04	P44	[9,UU,K,12]	
			J44	[4,PP,C,11]	
		03	P45	[4,SS,D,1]	
			J45	[4,RR,B,1]	
		03	P43	[4,SS,D,1]	
			J43	[4,RR,B,1]	
		04	P46	[9,UU,K,12]	
			J46	[4,PP,C,11]	
		03	P41	[4,SS,D,1]	
			J41	[4,RR,B,1]	

EVA Fasteners: N/A

EVA Connectors:

Connector	From	То	Clamps	Size	Function
W02-P42 (pin)	P5 J42	P4 J42	3	19	1553 Bus A (data)
W07-P41 (pin)	P5 J41	P4 J41	3	19	1553 Bus B (data)
W01-P46	P5 J46	P4 J46 (pin)	6	37	UPR Primary Power
W08-P45	P5 J45	P4 J45 (pin)	7	37	LPR Primary Power
W09-P44 (pin)	P5 J44	P4 J44	4	37	UPR MSC to UMA 1 (power)
W10-P43 (pin)	P5 J43	P4 J43	6	37	LPR MSC to UMA 2 (power)

Notes:

- 1. Check connectors for FOD, bent pins, bend radius, and EMI bands
- 2. Size 37 P4 caps (4) are dust caps. They are not keyed or labeled and can be mated to any size 37 P5 jack.
- Size 19 P4 caps (2) are terminator caps. They are not uniquely keyed and are identical and interchangeable with each other. They are, however, only keyed for 1553 lines, and thus cannot be installed on other size 19 functional connector receptacles other than the intended P5 jacks and associated P4 BMRRM jacks. They are both labeled: P1-T (W28)
- 4. P4 terminator plugs should be installed onto P5 jacks to protect for P4 contingencies (BMRRM R&R, etc.). Only the J41 and J42 terminator caps are regd for the BMRRM R&R.
- 5. For connector soft dock: white on white
- 6. For connector engage/lock: rotate 90 deg to white on black
- 7. W08-P45 excess cable line length does not meet required 11 inches; measured 7.75 inches
- 8. P5 cables were demated and mated at OOCT in the exact order as listed in the procedures to deconflict cable routing interferences
- 9. Connector inhibit rationale:
- Step 1 in the IV column provides inhibits for P42, P44, and P43; P45 and P46 are primary power feeds, but they're open circuit on EVA 1 so no inhibits required.
- Step 2 in the IV column provides inhibits for P41. It cannot be performed until after P42 is mated to J42. Also, it is listed a couple of steps before P41 to allow ODIN to inhibit it ahead of time

Cautions: N/A

Warnings: N/A

Timeline Considerations: N/A

FS 7-25 EVA/116/FIN

CLA OPEN (GET AHEAD) (00:15)

IV	EV2 (FF)
	P5 CLA OPEN
	CAUTION Avoid contact with PVRGF grapple pins and RMS target 1. Translate to P5 CLA (go zenith of PVRGF) 2. BRT to P5 HR 5239
	 PGT [A6, CCW3, 30.5]-6Ext-7/16: Open CLA, ~127 turns (hard stop) PGT [A6, CW2, 30.5]-6Ext-7/16: Partially close CLA, ~1 turn □ final CLA config

FS 7-26 EVA/116/FIN

CLA OPEN (GET AHEAD) TASK DATA SHEET

Tools:

EV1	EV2
N/A	PGT
	7/16 x 6-in ext

Foot Restraints: N/A

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
CLA Drive	CLA Drive	7/16"	1	8.3	14.6	127 (open)	60 (open)
						1 (close)	30 (close)

EVA Connectors: N/A

Notes:

1. N/A

Cautions:

1. Avoid contact with PVRGF grapple pins and RMS target

Warnings:

1. N/A

Timeline Considerations:

1. This task must be done prior to P6 install

FS 7-27 EVA/116/FIN

P5 PORT LAUNCH LOCK REMOVAL (GET AHEAD) (00:30)

IV	EV2 (FF)
IV NOTE There is no reqd order for LL	LAUNCH LOCK REMOVAL FROM CORNER 3
removal. The current order is based on crew preference	CAUTION Do not exceed 36 turns (bolt) when removing launch locks or primary bolt can come free of self feeding nut
	Hardware sensitive to crew loads. Do not apply a push or pull force on primary bolt. Damage to self-feeding nut may result
zenith stbd P4 P5 port	 Translate to corner 3 (aft/zenith) BRT to P5 HR 5224 if reqd PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #3, 27 turns Remove launch lock #3, stow in trash bag √2-7 threads visible or bolt head recessed inside shear cylinder
nadir	LAUNCH LOCK REMOVAL FROM CORNER 1
P5 AND P4 CORNER DESIGNATION	 Translate to corner 1 (fwd/zenith) BRT to P5 HR 5203 if reqd PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #1, 27 turns Remove launch lock #1, stow in trash bag √2-7 threads visible or bolt head recessed inside shear cylinder

FS 7-28 EVA/116/FIN

P5 PORT LAUNCH LOCK REMOVAL (GET AHEAD) (00:30) (Cont)

IV	EV2 (FF)
	LAUNCH LOCK REMOVAL FROM CORNER 4 1. Translate to corner 4 (aft/nadir) 2. BRT to P5 HR 5225 if reqd 3. PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #4, 27 turns 4. Remove launch lock #4, stow in trash bag 5. √2-7 threads visible or bolt head recessed inside shear cylinder
	 LAUNCH LOCK REMOVAL FROM CORNER 2 Translate to corner 2 (fwd/nadir) BRT to P5 HR 5226 if req'd PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Retract P5 primary bolt from launch lock #2, 54 turns (PGT), 27 turns (bolt) Remove launch lock #2, stow in trash bag √2-7 threads visible or bolt head recessed inside shear cylinder Deconfigure RAD and 5/8" socket from PGT

FS 7-29 EVA/116/FIN

P5 PORT LAUNCH LOCK REMOVAL (GET AHEAD) TASK DATA SHEET

Tools:

EV1	EV2
	PGT
	5/8 x 7.8-in
	RAD

Foot Restraints: N/A

HRs to BRT:

Task	HR
P5 LL 3 Removal	P4 5224
P5 LL 4 Removal	P4 5225
P5 LL 1 Removal	P4 5203
P5 LL 2 Removal	P4 5226

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
Primary Bolt	1	5/8"	1	12.0 (thru RAD) 25.5 (no RAD)	610	27 (bolt)	30
Primary Bolt	2	5/8"	1	same	610	27 (bolt)	30
Primary Bolt	3	5/8"	1	same	610	27 (bolt)	30
Primary Bolt	4	5/8"	1	same	610	27 (bolt)	30

Notes:

- 1. 6 LLs will fit in a small trash bag, but very tight
- 2. KSC fitcheck of PGT w/7.8" socket to P5 outboard RTAS bolts on 3/8/06:
- Corner 1: PGT with 7.8" socket can fit on bolt from a clearance standpoint, but gets very close to EWIS TAA. Can opt to use RAD here but does not look to be required
- Corner 2: PGT with 7.8" socket has hard interference with antenna; must use RAD at this corner
- > Corners 3 and 4: no hard interferences with EWIS hardware

Cautions:

- 1. Do not exceed 36 turns (bolt) when removing launch locks or primary bolt can come free of self feeding nut
- 2. Hardware sensitive to crew loads. Do not apply a push or pull force on primary bolt. Damage to self-feeding nut may result

Warnings: N/A

Timeline Considerations:

1. P5 launch locks must be removed prior to P6 install

FS 7-30 EVA/116/FIN

CP3 CAMERA R&R (01:30)

IV	EV1 (FF)		EV2 (FF)
1A. Verify w/MCC that CP3 is in park position (-180 deg pan and -90 deg tilt) 1B. Give MCC GO to put camera inhibits in place: RPCM S1-1A-A RPC 1 open RPCM S1-1A-A RPC 15 open RPCM S1-2B-A RPC 2 open RPCM S1-2B-A RPC 16 open 2. Start camera thermal clock: PET:	 CP3 WORKSITE SETUP Translate to P4 WIF 18 (fwd/ze Retrieve APFR from WIF 18, att Relocate connector tool to fish s Retrieve fish stringer #1, stow or Translate to P4 HR 5104, perfor swap onto 55' safety tether, ve Translate to CETA cart #2 (stbd Relocate APFR from BRT to CE (zen/stbd swingarm), configure Translate to P1 HR 3602, perform onto airlock safety tether, vering Temp stow fish stringer #1 near S0 HRs 3414 and 3415 Verify spare safety tethers (2) or Translate to CP3 (S1 bay 15, fact) √S1 nadir SVS targets are clear 	ach to BRT tringer #1 n MWS m safety tether erify ST config I most) ETA cart WIF 03 e to: [12,PP,F,6] form safety tether swap fy ST config ar airlock spur on fish stringer #1 fine 6 nadir) of ETVCG cables	 CAMERA RETRIEVAL FROM AIRLOCK Retrieve APFR from P5 WIF 11 Retrieve fish stringer #2 from P4 HRs 5154 & 5153 Translate to P4 HR 5133, perform safety tether swap onto 55' safety tether, verify ST config Translate to P1 HR 3601, perform safety tether swap onto airlock safety tether, verify ST config Translate to airlock Stow APFR in airlock toolbox 1 (stbd): [9,MM,F,12] Stow fish stringer #2 on A/L HRs 0560 and 0555 (stbd/nadir/fwd) Relocate spare 55' safety tethers (2), socket caddy (with RAD, 5/8", and 6-in sockets), and PGT (w/RET) to fish stringer #2 Open airlock thermal cover Retrieve spare camera from airlock, attach to BRT Close thermal cover Translate to CP3 (S1 bay 15, face 6 - nadir) Temp stow large ORU bag on S1 HR 3215 (use 2 adj tethers) - nadir tray HR

FS 7-31 EVA/116/FIN

CP3 CAMERA R&R (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
 √MCC Camera inhibits in place 		JTION light (Z-93 paint) and on)
·	FAILED CAMERA REMOVAL	FAILED CAMERA REMOVAL
	 Take camera pan/tilt lever to LOCKED (may have to assist with positioning camera to stowed posn) Tether to failed ETVCG light PGT [A7, CCW2, 30.5]-6Ext-7/16: Release outer bolts (2) ~ 12 turns PGT [A7, CCW2, 30.5]-6Ext-7/16: Release center jacking bolt ~ 30 turns Receive round scoop from EV2, attach to failed camera fitting Attach BRT to failed camera Remove failed camera (soft dock wedges) and position behind back 	 Transfer spare round scoop to EV1 Assist EV1 as req'd
	SPARE CAMERA INSTALL	SPARE CAMERA INSTALL
	Verify blind mate connector on stanchion mount is clear of FOD	
	 Receive spare camera from EV2 Install camera (soft dock wedges) Remove round scoop from camera fitting, transfer to EV2 	Remove spare camera from ORU bag, transfer to EV1, assist EV1 as reqd
	5. PGT [A7, CW2, 30.5]-6Ext-7/16: Drive center jacking bolt ~ 24-30 turns (hard stop)	

FS 7-32 EVA/116/FIN

CP3 CAMERA R&R (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
4. Inform MCC camera installed and RPCs for survival heater power can be closed: (RPCM S12B-A RPCs 2 and 16)	 6. PGT [A7, CW2, 30.5]-6Ext-7/16: Drive outer bolts (2) ~ 6-12 turns (hard stop) 7. Unlock camera pan/tilt unit (90 deg lever) 8. □□ ETVCG final config ■ □□ 9. Re-orient body prior to translating away from new ETVCG 	2. Retrieve ORU bag from truss, attach to BRT

FS 7-33 EVA/116/FIN

CP3 CAMERA R&R TASK DATA SHEET

Tools:

EV1	EV2
PGT	PGT
6-in ext x 7/16	6-in ext x 7/16
	Lg ORU bag with spare camera
	 1 rd scoop on spare
	camera fitting
	 1 rd scoop on bag fitting

Foot Restraints:

Task		WIF	APFR Setting
Failed Camera Remove Camera Install	al and Spare	(S1 WIF 32)	[12,GG,C,12]

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
Outer bolts	N/A	7/16"	2	9.2 (release)	14.8 (release) (shank failure)	6-12 (release)	30
				9.2 (install)	13.2 (install) (insert thread shear)	6-12 (install)	
Center jacking bolt	N/A	7/16"	1	9.2 (release)	14.8 (release) (shank failure)	24-30 (release)	30
				9.2 (install)	13.2 (install) (insert thread shear)	24-30 (install)	

Notes:

- 1. The camera bolts have no hard stop. They free spin when released
- 2. There is no anti-rotation device on the camera bolts
- 3. Camera soft dock force is ~ 10 lbs
- 4. An equipment hook will not fit around the camera tether point; the light tether point must be used
- 5. Pan/tilt unit lock lever requires a push to turn the lever 90 degrees to go from lock to unlock, and from unlock back to lock. Both the unlock and lock positions sit in detents
- 6. If the pan/tilt lock lever becomes unlocked, the pan/tilt joints can begin to move and back-drive the motor. This is undesirable and can damage the hardware
- 7. The pan/tilt lock lever can only be locked if the pan/tilt mechanism is in the home position (camera lens facing TVCIC bolt box)

Cautions:

- 1. Avoid contact with S1 SVS targets, RBVM fluid lines and QDs
- 2. Avoid contact with light (Z-93 paint) and camera (silver Teflon)

Warnings:

1. N/A

Timeline Considerations:

1. The spare ETVCG has a thermal clock of 2 hours once it leaves the A/L (no ORU bag). Clock is longer when inside bag

FS 7-34 EVA/116/FIN

CLEANUP (00:20)

IV	EV1 (FF)	EV2 (FF)
Give MCC GO to begin MT translation to WS 3	 Translate to S0 HRs 3414 and 3415, temp stow PGT on fish stringer #1 Retrieve fish stringer #1 Translate to airlock 	Translate to airlock Perform tool inventory
when EV1 and EV2 are at airlock	Perform tool inventory POST EVA TOOL CONFIG	POST EVA TOOL CONFIG
	□ Sm-sm RETs (3):	□ Sm-sm RETs (4): (1 from lg ORU bag)
	□ Adj tethers (2):	□ Adj tethers (3): (1 from lg ORU bag)
	□ Wire Ties (2):	□ Wire Ties (4):
	□ Trash bag: □ P5 launch locks (2)	□ Trash bag: □ P5 outboard launch locks (0-4) □ P4 EWIS connector cap
	□ BRT	□ BRT
	□ Camera:	□ Camera:
	□ Waist tether:	□ Waist tether (2):
	□ Fish Stringer #1: soft capture pin assys (2) □ torque wrench □ spare safety tether (2) □ socket caddy, RAD, 5/8" socket □ PGT w/6-in socket and RET:	□ Fish Stringer #2: □ torque wrench □ spare safety tether (2) □ P5 LLs (2) □ socket caddy with RAD, 5/8" and 6-in socket □ PGT with RET
	□ Failed camera □ Round scoop	□ Lg ORU Bag □ Round scoop

FS 7-35 EVA/116/FIN

INGRESS (00:20)

IV	EV1 (FF)	EV2 (FF)
1. Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)	 Receive EV2 safety tether; stow on airlock aft D-ring, √reel unlocked Transfer fish stringers #1 and #2 to EV2 Transfer failed camera to EV2 Connect right waist tether to D-ring extender on airlock internal D-ring, verify ST config Disconnect from airlock safety tether, stow on airlock fwd D-ring, √reel unlocked Ingress airlock Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF Hatch thermal cover – close, attach Velcro strap 	 Stow ORU bag inside airlock Ingress airlock Connect right waist tether to UIA panel fwd D-ring, verify ST config Disconnect from airlock safety tether, hand to EV1 Receive fish stringers #1 and #2 from EV1, temp stow Receive failed camera from EV1, stow in port/zenith side of crewlock Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF
		I <u>TION</u> MU water – OFF for 2 min
	11. Verify hardware clear of hatch12. Outer hatch – close and lock13. Go to PRE REPRESS	10. Go to PRE REPRESS

FS 7-36 EVA/116/FIN

EVA 2 NOTES, CAUTIONS, & WARNINGS

NOTES

- Bolt release: report torque and turns if different from published range
- EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD

CAUTION

ISS Constraints

- A. Avoid inadvertent contact with:
 - 1. Grapple fixture shafts
- 2. PIP pins
- 3. CETA Lights (Z-93 paint) [Lab, S1, Node 1]
- 4. Passive UMAs
- 5. MBS VDU, MCU, CRPCMs & Cameras (taped radiative surfaces, silver Teflon)
- 6. Deployed TUS cable
- 7. S0 aft face Radiator
- 8. GPS Antennas (S13 paint) [S0]
- 9. SVS Targets with planned future use [S1, P1]
- 10. UHF Antennas [Lab, P1]
- 11. ETCS Radiators [S1, P1]
- 12. SASA RF Group [Z1, S1, P6]
- 13. Heat pipe radiators [Z1]
- 14. PCU cathode and HCA ports [Z1]
- 15. Ku-Band Antenna (SGANT) dish [Z1]
- 16. CMG cover/shells [Z1]
- 17. SSRMS cameras
- B. Electrical cables:
 - Avoid bend radii < 10 times cable diameter

CAUTION (Cont)

ISS Constraints (Cont)

- C. For structural reasons:
- 1. Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
- 2. Avoid performing shaking motions (sinusoidal functions) more than four cycles
- 3. Avoid kicking S1/P1 radiator beam
 If any of these occur, wait 2-5 min to allow
 structural response to dissipate
- D. Other:
- 1. WIS Antennas: do not use as handholds [Node 1, P6, Z1]
- 2. Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners [P6,P4,S4,S6] can contaminate EMU

FS 7-37 EVA/116/FIN

EVA 2 NOTES, CAUTIONS, & WARNINGS (Cont)

WARNING

ISS Constraints

- A. Avoid inadvertent contact with:
 - 1. Grapple fixture targets and target pins
 - 2. Stay inboard of SARJ when active
 - 3. Stay 2 ft from S1/P1 radiator beam rotational envelope when beam is free to rotate
 - 4. Stay 5 ft from moving MT on face 1
- B. Pinch:
 - NZGL connector linkage. Use caution when mating/locking
 - 2. EV side of IV hatch during hatch operation (also snag hazard) [A/L]
- C. RF radiation exposure:
 - 1. Stay 3.6 ft from S-Band (SASA) high gain Antenna when powered [S1,P1,P6]
 - 2. Stay 1.3 ft from S-Band (SASA) low gain Antenna when powered [S1,P1,P6]
 - 3. Stay 1 ft from UHF Antenna when powered [Lab, P1]

WARNING (Cont)

ISS Constraints (Cont)

- D. Sharp Edges:
 - 1. Inner edges of WIF sockets
 - Mating surfaces of EVA connectors. Avoid side loads during connector mating
 - 3. Back side of MMOD shield fasteners
 - 4. Spring loaded captive EVA fasteners (e.g., 6B-boxes, BMRRM, RTAS ground strap bolt); the end of the spring may protrude
 - 5. Ku-Band upper handrail by the Ku boom launch restraint [Z1]

WARNING (Cont)

ISS Constraints (Cont)

E. Thermal:

- EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
- 2. Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on
- 3. Uncovered trunnion pins may be hot
- 4. SSRMS/MBS operating cameras/lights may radiate large amounts of heat
- 5. Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
- 6. Stay at least 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor up
- 7. Stay 0.5 ft away from PMA and MMOD shields > 325 degF
- 8. Do not touch EMU protective visor if temp has been < -134 for >15 min
- No EMU TMG contact of PMAs and MMOD shields when temp > 320 degF
- 10. No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF

FS 7-38 EVA/116/FIN

EVA 2 BRIEFING CARD

1. E'	VA Prep	6. Emergencies
	Get-up Plan – clothing and EMU equipment bag	 Emergency suit doff and power down during EVA prep
	Prebreathe protocol review	□ CUFF checklist
		 Abort and Terminate review – scenarios/protocols
	Suit donning plan	☐ Hand signals
	Airlock depress review	
		IV CHECKLIST VERIFICATION ITEMS
2. C	ommunications	
	Overall setup: big loop, A/G2, S/G2, ICOM, Hardline, remind EV	 Day/Night Cycles and extended two-handed ops
	crew when mode swapping	∘ √Lights, heaters, visors, tools, tethers, gloves
	Use EV1(2) for DCM sw throws (all time in A/L)	□ √Load Alleviating Strap on Safety Tethers not damaged
		□ √Safety Tether in good config
3. E	VA Procedure Review	 Crew Report: "Hook closed, slide locked, reel unlocked"
	Order of tasks (summary timeline)	□ √Both SAFER valves down at egress
		Crew Report: "Both handles down"
		□ √APFR locking collar Black-on-Black and pull test
	Notes, Cautions, and Warnings	 Clocking, pitch, roll, yaw
	Get ahead tasks	□ √PGT Green light on for bolt engage
	QD Bag install	o program, (C)CW, MTL setting
	o PM Jumper install	 PGT and sockets – pull test
	 VTE bag install 	 May get Lo Torque msg at bolt release
	ı Ingress Plan	 Crew Report: "Torqued out, XX turns (or green light)"
	Section 16 Contingencies	□ √Connectors for damage, bent pins, EMI band, FOD, cable bend radii
		 Always receive GO from MCC prior to mating/demating
4. R	obotics	electrical connections, review inhibits as regd
	SRMS/SSRMS initial position, maneuvers, clearances	 Crew Report: "Pins good, EMI band good, no FOD, bend
		radius OK"
	SSRMS/SRMS/IV comm protocol review	□ Coordination between IV/EV/Robotics/Ground
	,	
5. P	ost EVA	
	ı Coldsoak	
	Airlock Repress review	
	- 1	
_	Post EVA plan	
	•	

FS 7-39 EVA/116/FIN

EVA 2 INHIBIT PAD

Orbiter

All EVAs

TCS

L12 1. √TCS POWER – OFF

Ku-Band Antenna

MCC-H

- 1. √KU-BAND Mask active
- 2. √KU-BAND EVA Protect Box active

RCS

If EV crew < 27 ft from FRCS:

1. √DAP: VERN, FREE, LO Z (flt specific √ with GNC) IV

2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF O14.15.16

LOGIC (four) - OFF

MCC-H

IV

- 3. √Above RCS config
- 4. √RCS F ITEM 1 EXEC (*)

√JET DES F1U – ITEM 17 (*)

 $\sqrt{F3U}$ – ITEM 19 (*)

√F2U – ITEM 21 (*)

S-Band Antennas

NOTE

Possible loss of comm when forced LL FWD antenna

If EV crew < 1.6 ft from S-Band antenna: IV

A1R

1. S-BAND FM ANT – XMIT LOWER/RCVR UPPER

2. √MCC, lower antenna selected

If no comm, or on MCC call:

3. S-BAND PM ANT - LL FWD C3

When EVA crewmember at least 1.6 ft away from all S-Band

upper antennas:

4. S-BAND PM ANT - GPC C3

USOS

All EVAs

PCU

MCC-H

- 1. √PCUs (two) operational in discharge mode and one of the following:
 - A. CCS PCU EVA Hazard Control enabled
 - B. No more than two arrays unshunted
 - C. No more than two arrays pointed < 90 degrees from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
 - A. No more than two arrays unshunted
 - B. No more than two arrays pointed
 - < 90 degrees from velocity vector

Ground Radar

MCC-H

1. √TOPO and FDO consoles, ground radar restrictions in place for EVA

RSOS

All EVAs

SM Antennas

MCC-M

1. Global Timing Sys 1(400.1 MHz) [GTS] – Deactivate

FS 7-40 EVA/116/FIN

EVA 2 SUMMARY TIMELINE

TIME	SSRMS	EV1 (FF)	EV2 (SSRMS/FF)
0:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)
0:05		EGRESS (00:25)	EGRESS (00:25)
0:30		 CHANNEL 2/3 POWER RECONFIGURATION (1:30) S0 Fwd Stbd Avionics Reconfiguration (Panel A148) Lab 2A DDCU Secondary Power Disconnect from S0 (Panel A165) S0/N1 Pwr Cable Install (S0 Panel A166) 	CHANNEL 2/3 POWER RECONFIGURATION (01:00) • CIDS 3, 4, and 5 Removal/S0 Tray Connections • Z1-003 Patch Panel 5 Reconfiguration (DDCU HP 3B)
		 S0-2B DDCU Reconfiguration (Panel A70) MBSU Bypass Jumper (2/3) Reconfiguration (CID 7 Removal) P1-3A DDCU Reconfiguration (Panel A9) P1-3A DDCU Thermal Cover Removal 	CETA CART 2 RELOCATION (01:55) • CETA 2 Prep • Tip LEE FMS MLI Install
2:00	SSRMS: 4.101 STBD CETA CART 2 RELOCATION	CETA CART 2 RELOCATION (01:25) CETA 2 Prep CETA 2 Removal from S1 Bay 11	CETA 2 Removal from S1 Bay 11
		CETA 2 Install on S0 Bay 3	CETA 2 Install on S0 Bay 3
3:25	SSRMS: 4.102 STBD CETA CART 1 RELOCATION	CETA CART 1 RELOCATION (01:10) CETA 1 Removal from S1 Bay 9 CETA 1 Install on S0 Bay 1	CETA CART 1 RELOCATION (01:20) CETA 1 Removal from S1 Bay 9 CETA 1 Install on S0 Bay 1 SSRMS and CETA Cart Cleanup
4:35		SSRMS FMS MLI INSTALL (00:20) • Base LEE FMS MLI Install	STBD AND PORT QD BAG INSTALLATION (00:20)
4:55		Z1-006 PATCH PANEL 2 RECONFIG (00:20) (SPDA Z1-3B) • Assist with QD Bag Installation	VTE AND PM JUMPER BAG INSTALLATION (00:10)
5:15		CLEANUP (00:20)	CLEANUP (00:20)
5:35		INGRESS (00:20)	INGRESS (00:20)
5:55		PRE REPRESS (00:05)	PRE REPRESS (00:05)
6:00		•	

FS 7-41 EVA/116/FIN

EVA 2 TOOL CONFIG

AIRLOCK	AIRLOCK ENDCONE Staging Bag	AIRLOCK INTERNAL D-RING D-ring extender
EMU 1 MWS, right swing arm Digital camera (right swing arm) BRT (left) w/3 wire ties w/Sm-sm RET T-Bar ISS trash bag (inner left) Sm-sm RET (left D-ring) Adj tether (2) (left D-ring) Sm-sm RET w/PIP pin (right D-ring) Adj tether (right D-ring) D-ring ext – left Waist tether – right SAFER	Fish Stringer #3 Connector cleaner tool caddy Wire tie caddy (2) Pin straightener MWS Key strap Velcro/Tape caddy Torque Wrench (2) Pry bar EVA Ratchet Socket caddies(2) with RAD (2) & 5/8 x 7.8-in ext (2) Spare PGT (s/n:); (battery (s/n:N/A) Probe IV Bag Contamination Detection Kit Hydrazine Detector (Gold Salt Coupon) (6) Color Chart (2) ISS Contamination Detection Sampler (2)	UIA HANDRAILS Crewlock Bag #1 (for contingency) w/lg-sm RET Square scoop (MBSU or DDCU R&R) Ballstack (MBSU R&R, S1 DDCU R&R) Spare 55' safety tethers (2) (for P4 BCDU cont) MUT EEs (2) (SASA cont temp stow) Crewlock Bag #2 (for contingency) w/lg-sm RET CETA cart PIP pin (wheel bogie R&R) Socket caddy with 6-in socket and 2-in sockets (2) Spare PGT (prime) (s/n:); batt s/n: Spare WIF adapter Stbd QD Bag w/lg-sm RET and sm-sm RET Gap spanners (2), -303 (upper left), -301 (upper rt) (hook to hook) Port QD Bag w/lg-sm RET and sm-sm RET Gap spanners (2), -301 (upper left), -301 (upper rt)
EMU 2 MWS, right swing arm Digital camera (inner right swing arm) BRT (left) w/2 wire ties w/Sm-sm RET	Shuttle Contamination Detection Sampler (2) Nitrogen Dioxide Detector (Oxidizer Draeger Tube) (6) Ammonia Detector (NH3 Draeger Tube) (6) 2 towels with wire ties DCM plug (2) (SAFER hardmount) GP caddy (2)	(hook to hook) Pump Module Jumper Bag (VTEB 02) & Vent Tool Extension Bag (VTEB 01) (strapped together via integral bag hooks) Lg-sm RET Fish Stringer #1
T-Bar Wire ties (2) around T-Bar ISS trash bag (inner left) WIF adapter with adj tether Sm-sm RET (right D-ring) Adj tether (left D-ring) Sm-sm RET w/PIP pin (left D-ring) Adj tether (right D-ring)	Thermal mittens (2 pr) Socket Caddy (hatch contingencies) w/sm-sm RET 1/2 X 8-in socket (IV hatch) 7/16 X 6-in socket (spare) PRE EVA 2 TOOL CONFIG 1. Verify EVA 2 Tools and Hardware in equipment lock 2. Transfer WIF adapter from INC 14 packed "Tools for EVA 2 and EVA 3" bag to EV2 MWS	PGT (s/n:) w/6-in socket, sm-sm RET; batt s/n: Spare 55' safety tether (for P1 Bay 16) FMS MLI (2) S0 CH 2/3 Power Cable (jumper) (tether to both caps) S0/N1 Pwr Cable (tape removed from J342A connector; there is no cap) POST EVA 2 TOOL STOW 1. Retrieve "Return to Shuttle 2" jett stow bag
Fish Stringer #2 (empty) Spare 55' safety tether (for egress) D-ring ext – left D-ring ext – right Waist tether (gives extra reach/egress) Waist Tether – left SAFER	 3. Config MWSs 4. Verify Crewlock Bags 1 and 2, QD Bags, PM Jumper Bag, VTE Bag, and UIA tether point as listed 5. Verify IV and Staging Bag contents per list 6. Stow MWSs in "EV1" and "EV2" bags as reqd 7. Prior to EVA, inspect the following: RET cords for damage 	from "EVA 1 Shuttle to ISS" jett stow bag 2. Stow the following items in the "Return to Shuttle 2" Jettison Stowage Bag: CIDs 3,4, 5, and 7 P1 DDCU Thermal Cover S0 Channel 2/3 Jumper Caps (2) Panel A166 DF cap
Total sm-sm RETs used: 7 Total sm-sm RETs used (w/PIP pin): 2 Total adj tethers used: 6 Total lg-sm RETs used: 5	 BRT and MWS toggles: loose fittings/screws Safety and waist tether load alleviating straps (no red band or damage) Inspect ballstack (debris sleeve in tact) 	 3. Relocate RAD from staging bag to socket caddy in crewlock bag #2 4. Transfer PGT in staging bag to fish stringer #2; transfer 2-in socket from socket caddy in crewlock bag #2 to PGT on fish stringer #2

FS 7-42 EVA/116/FIN

EGRESS (00:25)

IV	EV1 (FF)	EV2 (FF)
NOTE For safety tether swaps, expect to hear: 1. Hook closed 2. Slide locked 3. Reel unlocked 1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max (required after EV1 and EV2 egress airlock)	 √Right waist tether to UIA panel fwd D-ring, verify ST config Transfer fish stringer #1 to EV2 Receive fwd airlock safety tether from EV2, attach to left D-ring extender, verify ST config Release right waist tether from UIA panel D-ring Egress airlock Close thermal cover √EV2's SAFER MAN ISOL vlv – OP (dn) and HCM (dn) Attach fish stringer #1 to MWS 	 √Right waist tether to airlock internal D-ring extender, verify ST config Thermal cover – open Egress airlock Inspect load alleviating straps on 85' safety tethers (2) Retrieve airlock safety tether from aft external D-ring, attach to left D-ring extender, verify ST config Release waist tether from internal D-ring extender Receive fish stringer #1 from EV1, temp stow in between port and stbd airlock toolbox HRs Transfer fwd airlock safety tether to EV1 Temp stow spare safety tether and WIF adapter (1 adj) on airlock HR 0512 (equip lock) (don't need until CETA) √EV1's SAFER MAN ISOL vlv – OP (dn) and HCM (dn)

FS 7-43 EVA/116/FIN

CHANNEL 2/3 POWER RECONFIGURATION (01:30)

IV EV1 (FF) EV2 (FF) 1. Verify w/MCC: Power Reconfig Inhibit NOTE √Connectors for damage, FOD, bent pins, cable bend radii, and EMI band Check (SODF: ASSY OPS: EPS CH 2/3 Powerdown for EVA 2, SO FWD STBD AVIONICS RECONFIGURATION CIDS 3, 4, AND 5 REMOVAL/S0 TRAY CONNECTIONS steps 6 and 7 complete (Panel A148) (DCSU 2B RBI 6 open) WARNING (DCSU 2A RBI 6 open) 1. Translate to S0 Bay 03, Face 1; temp stow fish stringer #1 Wire ties on CIDs may break and on S0 HR 3414 cause sharp edges and debris ZENITH 2. Translate to stbd S0 connector panel on Bay 01, Face 6 S BRT to S0 HR 3443 Т Remove DF cap from S0 J230 CAUTION Demate P230 (W9002) from S0 J238; mate to S0 J230 5. Avoid contact with SASA antennas Install DF cap on S0 J238 6. and S0 radiator □ connector closeout 1. Translate to stbd Lab/Z1 tray (go aft of airlock) LAB 2A DDCU SECONDARY PWR DISCONNECT FROM S0 Open TA clamps and remove wire ties as regd J238 J230 (Panel A165) BRT to HR 6007 S0 FWD/STBD CONNECTOR 4. Demate S0 P240 (W4034) from Z1 CID 5 J440; temp Retrieve S0 CH 2/3 jumper from fish stringer #1, attach to PANEL (PANEL A148) stow MWS Demate CID 5 P240 from Z1 tray J440 2. Translate to S0 Bay 01, face 1 HR 3463 Access zenith worksite through face 1 (looking port) 6. Mate S0 P240 to Z1 tray J440 BRT to S0 HR 3465 Remove CID 5 from Z1 tray, stow on fish stringer #2 8. Demate Z1 P316 (W24C) from CID 3 J216; mate to Open P338 (W4144) clamp Release cap from S0 CH 2/3 jumper J338A, temp stow Z1 J216 (tray), restrain in TA clamps Demate S0 P338 (W4144) from J338, mate to S0 CH 2/3 9. Demate Z1 P315 (W24B) from CID 4 J215; mate to Z1 J215 (tray), restrain in TA clamps jumper J338A 10. Demate CID 3 P316 from Lab J216, stow on fish stringer Release cap from S0 jumper P338A, temp stow Mate S0 CH 2/3 jumper P338A to S0 J338 11. Demate CID 4 P315 from Lab J215, stow on fish stringer 12. Release necessary TA clamps on port S0 tray, remove 10. Restrain S0 cable or jumper using TA clamp or wire tie cables, close clamps (panel A199) to HR 3463, close TA clamp 13. BRT to Lab HR 0213 J338A P338 P338A J338 11. □ connector closeout 14. Demate S0 P215 (W4014) from S0 J474; mate to S0 PANEL A165 12. Egress truss Lab J215 WITH SO JUMPER INSTALLED

FS 7-44 EVA/116/FIN

CHANNEL 2/3 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)		
DF Cap J342 P342	S0/N1 PWR CABLE INSTALL (S0 Panel A166) 1. Translate to fish stringer #1, stow caps (2) 2. Retrieve S0/N1 Pwr Cable from S0 HR 3414 3. Translate to S0 Bay 02, access through face 1	 15. Demate S0 P216 (W4012) from S0 J475; mate to Lab J216 16. Demate S0 P242 (W4186) from S0 J478; mate to Z1 J442 17. Temp stow fish stringer #2 on dog house HR 18. □ connector closeout 		
	 Access panel A166 in S0 Bay 02 (face 2 tri-truss, stbd) BRT to HR 3502 Retrieve EMU scissors (right side) Cut lacing cord connecting bails of P342 and DF cap J342 (outboard), stow scissors in trash bag Release TA clamp as reqd 	Z1-003 PATCH PANEL 5 RECONFIGURATION (DDCU HP 3B) CAUTION Avoid contact with Z1 DDCU		
S0 PANEL A166	9. Take S0 P342 (stbd) to soft dock posn10. Demate DF cap J342 from S0 P342 (port), temp stow on RET	heat pipes and SASA antennas		
P2/J2 J1 Fwd zenit	 Release S0/N1 Pwr Cable cable tie #1 (captive) Mate S0/N1 Pwr Cable J342A to S0 P342 (no cap) Take S0 P342 to hard dock Pass cable bundle through face 3 bulkhead cutout, temp stow bundle with wire tie onto HR 3499 Captive Captive Captive	 Translate to Z1 stbd face, zenith panel Fold back thermal shroud (STD SHRD Z1/02/04-03), release Velcro straps from HRs 6005 and 6024 Demate Z1 P2 (W21) from Z1 J2, temp stow Remove connector cap from Z1 J1, mate to Z1 J2 Mate Z1 P2 (W21) to Z1 J1 \[\] connector closeout 		
Z1 PP 5 (ZENITH PANEL)	 (Panel A70) Access coldplate connector panel on face 1 (still Bay 02) Remove connector cap from J7 on DDCU coldplate connector box; temp stow (lanyarded to panel) If required, release P574 from TA clamp Demate S0 P574 (W4144) from DDCU CP J8; mate to J7 Install connector cap on J8 Close TA clamp if reqd \[\sum_{\text{\text{\text{Close TA clamp if reqd}}}}\] 	7. Reinstall thermal shroud8. Retrieve fish stringer #2 from dog house HR		

FS 7-45 EVA/116/FIN

CHANNEL 2/3 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
	EV1 (FF) MBSU BYPASS JUMPER (2/3) RECONFIGURATION (CID 7 Removal) 1. Translate to S0 Bay 04 WARNING Wire ties on CIDs may break and cause sharp edges and debris 2. Access MBSU nadir reconfig worksite through face 1 3. Attach MWS EE to HR 3536 as reqd (panel A260) 4. Remove connector cap from J488; temp stow 5. Demate S0 P488 from CID 7 J487; mate to S0 J488 6. Demate CID 7 P488 from S0 J487, attach to MWS 7. Release old wire tie from CID 7, stow in trash bag 8. If needed, remove P487 (W4032) from TA clamp; close clamp 9. Demate S0 P487 from S0 J490 (panel A303); mate to S0 J487 (panel A260) 10. Install connector cap on J490 11. Calconnector closeout 12. Translate to fish stringer #1: Retrieve spare safety tether and attach to MWS Stow CID 7 and J342 DF cap Retrieve PGT w/RET from fish stringer	EV2 (FF)
	P1-3A DDCU RECONFIGURATION (Panel A9) 1. Translate to P1 HR 3602 (P1 Bay 14, Face 1) 2. Perform safety tether swap onto HR 3602 with 55' safety tether, verify ST config	

FS 7-46 EVA/116/FIN

CHANNEL 2/3 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
	 Translate to P1 Bay 16, enter face 1 Remove connector cap from J7 on DDCU coldplate connector box, temp stow (lanyarded to panel) If required, release P169 from TA clamp Demate P1 P169 (W5113) from J8; mate to J7 Install connector cap on J8 □ connector closeout 	
When EV1's and EV2's connections complete, give MCC GO for power up	P1-3A DDCU THERMAL COVER REMOVAL	
	 Attach MWS EE to HR 3680 (zenith rail for ground release) PGT [A1, CCW2, 30.5]-6"-Ext-7/16: Release DDCU thermal cover grounding strap fastener (zenith), 10-16 turns Release Velcro straps (3) Using handhold, pull thermal cover away from DDCU until straps are free Tend cover using existing straps and 1 adjustable tether; temp stow on MWS 	

FS 7-47 EVA/116/FIN

CHANNEL 2/3 POWER RECONFIGURATION TASK DATA SHEET

Tools:

EV1	EV2
PGT w/6-in	

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
P1 DDCU thermal cover		7/16	1	3.8	4.7 (shank	9-10	30
ground strap					failure)		

EVA Connectors:

Connector	From	То	Clamps	Size	Function
S0 P230 (W9002)	S0 J238	S0 J230		25	Primary Power MBSU
,					2 to DDCU LA2A
S0 P338 (W4144)	S0 J338	S0 CH 2/3 Pwr Cable J338a		37	Disconnect DDCU LA2A Power to Truss
S0 CH 2/3 Pwr cable P338a		S0 J338			
S0 P574 (W4144)	J8	J7		33	DDCU S02B 2ndary Power to Core Bus
S0 P240 (W4034)	CID 5 J440	Z1 tray J440		33	2B Primary Power to MBSU 2 CID 5 Removal (2B
CID 5 P240	Z1 J440 (tray) CID 3			33	Primary Power)
Z1 P316 (W24C)	J216	Z1 J216 (tray)		25	Dcnct DDCU LA2B from Z1 IDA
Z1 P315 (W24B)	CID 4 J215	Z1 J215 (tray)		25	Dcnct DDCU LA3B from Z1 IDA
CID 3 P316	Lab J216			25	CID 3 Removal
CID 4 P315	Lab J215			25	CID 4 Removal
S0 P215 (W4014)	S0 J474	Lab J215		25	Primary Power MBSU 3 to DDCU LA3B
S0 P216 (W4012)	S0 J475	Lab J216		25	Primary Power MBSU 2 to DDCU LA2B
S0 P242 (W4186)	S0 J478	Z1 J442		33	2ndary Power DDCU S03B to SPDA Z13B
S0 P488	CID 7 J487	S0 J488		37	Primary Power DCSU 2A to MBSU 2
CID 7 P488	S0 J487				CID 7 Removal
S0 P487	S0 J490	S0 J487			Primary Power DCSU 2B to MBSU 2
P1 P169 (W5113)	J8	J7		33	DDCU P13A 2ndary Power to Utility Bus
Z1 P2 (W21)	Z1 J2	Z1 J1		25	Primary Power MBSU 3 to DDCU Z13B

Notes:

- √connectors for damage, FOD, bent pins, and cable bend radii, and EMI band
- 2. It is possible for the DDCU thermal cover to get caught on coldplate legs during removal

Cautions:

- 1. Avoid contact with SASA antennas and S0 Radiator
- 2. Avoid contact with Z1 DDCU Heatpipes

Warnings:

1. Wire ties may break and cause sharp edges and debris

Timeline Considerations:

- 1. At least one CETA cart must be relocated port of the MT to support failed MBSU or DDCU R&Rs
- 2. CH 2/3 Connections can be completed in any order

FS 7-48 EVA/116/FIN

CETA CART 2 RELOCATION (01:25)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)		
 4.101 Stbd CETA Cart 2 Relocation (SODF: ROBO: EVA 2) Give SSRMS operator GO to take BRAKES→ON 	onto airlock safety tether, verify ST config Translate to S0 HR 3493 (S0 Bay 00), stow DDCU thermal cover w/adj tether, spare safety tether, and PGT w/RET on fish stringer #1	CETA 2 PREP 1. Translate to airlock, temp stow fish stringer #2 on airlock HR 0543 (equipment lock, nadir) 2. Retrieve the following items and stow on MWS: □ spare safety tether □ WIF adapter w/adj tether 3. Translate to fish stringer #1 on S0 HR 3414, retrieve FMS MLI 4. Translate to CETA 2 (~ S1 Bay 11) 5. Prep CETA 2 for transfer □ √Brake handles (4) straight and collars locked □ √Swingarms stowed (3) □ Take CETA 1 coupler to UNLOCK □ Translate CETA 2 stbd ~ 2 ft, align with SSRMS □ Engage CETA 2 parking brake (left handle) □ Take CETA 1 coupler to CAPTURE TIP LEE FMS MLI INSTALL 1. GCA SSRMS for FMS install ▼ □ CAUTION 1. Avoid no touch areas on tip LEE 2. Do not fold or crease FMS MLI 2. Translate onto tip LEE 3. Attach waist tether onto LEE HR 4. Release CLA ground strap Velcro flaps (2) 5. Attach FMS MLI grounding flaps to CLA grounding points (Velcro) 6. Re-install CLA Velcro flaps onto FMS MLI grounding flaps, and press to ensure good grounding path 7. Unroll FMS MLI around LEE FMS		

FS 7-49 EVA/116/FIN

CETA CART 2 RELOCATION (01:25) (Cont)

IV/SSRMS		EV1 (FF)	EV2 (SSRMS)
3. Give SSRMS operator GO to take BRAKES→OFF	1. Translate to	NO Ire safety tethers are clear of CETA cart during /AL FROM S1 BAY 11 Poport side of CETA 2 s reqd for ingress boots engaged in APFR heel clips	 8. Tighten and secure inner Velcro strap until diamonds are aligned** 9. Attach single flap end of MLI in between double flap end and attach Velcro 10. Verify that grounding flaps are still secure and re-press to ensure proper grounding path** 11. Ensure all Velcro flaps are closed (flap 1 and flap 2)** 12. □ closeout of shroud install 13. Translate onto CETA cart ■ Install with adapter on SRMS; tether point on Wife adapter points toward end effector 3. Relocate APFR from CETA 2 Wife 03 to SSRMS; √settings: [12,PP,F,6] 4. Perform safety tether swap onto SSRMS w/spare safety tether, verify ST config; temp stow airlock safety tether on S1 HR 3246 (face 6 stbd of CETA 2) 5. GCA SSRMS for ingress 6. Install local waist tether onto APFR 7. Ingress SSRMS using grid H (head nadir, facing cart) 8. SSRMS mnvr to CETA 2 removal position 9. Tether to CETA 2 at grids B and H (heads nadir)
		CAUTION Do not impart loads into CETA cart with less the	nan 3 of 4 wheel bogies engaged

FS 7-50 EVA/116/FIN

CETA CART 2 RELOCATION (01:25) (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 Release CETA 2 brakes (tap pedal twice) Release CETA 2 wheel bogies (4); give EV2 GO to remove CETA 2 from rails Assist EV2/M1 with clearances as reqd; verify CETA 2 is clear of structure prior to EV2 re-positioning cart in hands 	 12. Give EV1 GO to release wheel bogies 13. Remove CETA 2 from MT rails; lift CETA cart from rails due forward until wheel bogies clear rail 14. At SSRMS clearance posn, reposition CETA 2 such that right hand is on CETA 2 zenith HR and left hand is on grid F
	CETA 2 INSTALL ON S0 BAY 3	CETA 2 INSTALL ON S0 BAY 3
4. IV monitor clearances between CETA 2 and Orbiter nose cap through flight deck windows	 Translate to port side of MT and CETA 2 install location Monitor EV2 and CETA 2 cart clearances with: P6 fwd radiator Orbiter nose cap 	Mnvr to port side of MT
	<u> </u>	OTE
	Ensure safety tethers are clear of s	structure during CETA cart Install
	 At SSRMS port install posn, GCA EV2 and CETA cart for initial alignment with rails Guide CETA cart onto nadir rail Install wheel bogies (4) 	 Install CETA 2 on MT rail (~S0 Bay 01) due aft Release tether
	CETA to MT max coupling rate is 0.5 ft/sec	
	6. √CETA 2 coupler in CAPTURE 7. Couple CETA 2 to MT; take CETA 2 coupler to LOCK	

FS 7-51 EVA/116/FIN

CETA CART 1 RELOCATION (01:10)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)	
1A. √MCC: Status of MBSU pwr	CETA 1 REMOVAL FROM S1 BAY 9	CETA 1 REMOVAL FROM S1 BAY 9 ←	
up prior to SSRMS mnvr to stbd side of MT for CETA 1 relocation (easier arm trans to ESP2 to pick up spare MBSU from port side of MT) 1B. 4.102 Stbd CETA Cart 1 Relocation (SODF:ROBO:	 Translate to CETA 1 (S1 Bay 9) Prep CETA 1 for transfer 	SSRMS mnvr to CETA 1 removal position	
EVA 2) swingarms (3) zenith	NC Ensure safety tethers are clear of CETA	OTE A cart during CETA cart relocation	
F WF4		 GCA SSRMS to CETA 1 removal posn Tether to CETA 1 with RET Hold CETA 1 at grids B and H (heads down) 	
stbd WF39 B H	Do not impart loads into CETA cart with le		
WEZ WEZ	 3. Release CETA 1 brakes (tap pedal twice) 4. Release CETA 1 wheel bogies (4); give EV2 GO to release CETA 1 from rails 	5. Give EV1 GO to release wheel bogies	
Active Dynamic Brake coupler handle handles (4)	 Assist EV2/M1 with clearances as reqd; verify CETA 1 is clear of structure prior to EV2 re-positioning cart in hands 	 6. Remove CETA 1 from MT rails; lift CETA 1 from rails due forward until wheel bogies clear rail 7. At SSRMS clearance posn, reposition CETA 1 such that right hand is on CETA 1 zenith HR and left hand is on grid F 	

FS 7-52 EVA/116/FIN

CETA CART 1 RELOCATION (01:10) (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	CETA 1 INSTALL ON S0 BAY 1	CETA 1 INSTALL ON S0 BAY 1
2. IV monitor clearances between CETA cart and Orbiter nose cap through flight deck windows	 Tether to EV2's airlock safety tether, retrieve from S1 HR 3246, attach to MWS (to move down to S0) Temp stow EV2's safety tether on CETA 2 nadir HR Translate to port side of MT/CETA 2 and CETA 1 install location Monitor EV2 and CETA 1 cart clearances with: P6 fwd radiator Orbiter nose cap 	1. Mnvr to port side of MT/CETA 2
	NC Ensure safety tethers are clear of	OTE
	Ensure safety tetriers are clear or	structure during CETA cart install
	 5. GCA EV2 and CETA cart for initial alignment with rails 6. Guide CETA cart onto nadir rail 7. Install wheel bogies (4) 	2. Install CETA 1 on MT rail (~S0 Bay 01) due aft
	8. Engage CETA parking brake (left handle)	3. Release tether
 Give SSRMS operator GO to take BRAKES→ON (EV1 can translate on base LEE) 		SSRMS AND CETA CART CLEANUP 1. Egress SSRMS (using CETA 1) 2. GCA SSRMS to APFR cleanup and safety tether swap positions (same posn) 3. Remove APFR, temp stow in CETA 1 WIF 04 4. Remove WIF adapter, stow on MWS 5. Perform safety tether swap onto airlock safety tether, verify ST config, retrieve spare from SSRMS 6. √CETA 1 coupler in CAPTURE

FS 7-53 EVA/116/FIN

CETA CART 1 RELOCATION (01:10) (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
		CAUTION CETA to CETA max coupling rate is 1 inch/sec 7. Release CETA cart brakes (tap petal twice) 8. Couple CETA 1 to CETA 2; take CETA 1 coupler to LOCK 9. Retrieve fish stringer #1 from S0 HR 3444 10. Retrieve APFR from CETA WIF, attach to BRT 11. Translate to airlock 12. Transfer WIF adapter (w/adj tether) and spare safety tether to fish stringer #2
		13. Stow APFR in ESP2 WIF 8; configure to: [3,PP,F,12]

FS 7-54 EVA/116/FIN

CETA CART RELOCATION TASK DATA SHEET

Tools: N/A

Foot Restraints

Task	WIF	APFR Setting
CETA Cart Removal/Install	SSRMS	12,PP,F,6

EVA Fasteners: N/A

EVA Connectors: N/A

CETA cart Mass = ~ 560 lb (with launch bolts)/254 kg

Notes:

- Ensure safety tethers are clear of CETA cart during safety tether swap, CETA cart relocation, and CETA cart install
- 2. 3 of 4 wheel bogies are required to be installed prior to untethering (from a safety, fault-tolerance standpoint)
- SSRMS brakes must be on before EV2 translates onto tip LEE for FMS MLI install

Cautions:

- Do not impart loads into CETA cart with less than 3 of 4 wheel bogies engaged
- 2. CETA to MT max coupling rate is 0.5 ft/sec
- 3. CETA to CETA max coupling rate is 1 inch/sec

Warnings: N/A

Timeline Considerations:

- Both CETA carts must be relocated to port side of the MT in order to checkout MT worksite 2
- If both carts are not on the port side of the MT, the MT will not reach worksite 2 because of the S1 MT stop and the S1 Bay 15 DDCU thermal cover
- The MT can reach worksite 2 with no interferences even if the S1 Bay 15 DDCU thermal cover is still installed as long as both CETA carts have been relocated to the port side of the MT
- 4. At least one CETA cart is reqd to be on the port side of the MT to support realtime failed MBSU or DDCU R&Rs during EVAs 2 and 3

FS 7-55 EVA/116/FIN

SSRMS FMS MLI INSTALLATION (00:20)

IV/SSRMS	EV1 (FF)	EV2 (FF)
1. Receive GO from EV2 that all SSRMS motion has stopped and brakes are ON prior to translating on base LEE	CAUTION Avoid no touch areas on base LEE 1. Retrieve FMS MLI from fish stringer #1 (S0 HR 3444) 2. Translate to MBS PDGF #3 (zenith/port) CAUTION Do not fold or crease the FMS MLI 3. Translate onto base LEE 4. Attach MWS EE to LEE HR 5. Release CLA ground strap Velcro flaps (2) (zenith) 6. Attach FMS MLI grounding flaps to CLA grounding points (Velcro) 7. Re-install CLA Velcro flaps onto FMS MLI grounding flaps, and press to ensure good grounding path 8. Unroll FMS MLI around LEE FMS 9. Tighten and secure inner Velcro strap until diamonds are aligned** 10. Attach single flap end of MLI in between double flap end and attach Velcro 11. Verify that grounding flaps are still secure and	EV2 (FF)
	re-press to ensure proper grounding path** 12. Ensure all Velcro flaps are closed (flap 1 and flap 2) ** 13. A closeout of shroud install 14. When clear of base LEE joints, give SSRMS operator GO to move SSRMS to stow posn 15. Retrieve fish stringer #1, stow on MWS	

FS 7-56 EVA/116/FIN

SSRMS FMS MLI INSTALLATION TASK DATA SHEET

Tools: N/A

Foot Restraints: N/A

EVA Fasteners: N/A

EVA Connectors:N/A

Notes:

- 1. ** CSA requests verbal confirmation that these steps are completed
- 2. An APFR installed in A/L Toolbox WIF 2 interferes with airlock ops

Cautions:

- 1. CETA to CETA max coupling rate is 1 inch/sec
- 2. Do not fold or crease the FMS MLI
- 3. Avoid no touch areas for base and tip LEE:

For Base LEE (EV1), avoid contact with:

- 1. MCAS latches (zenith)
- 2. POA curvic coupling
- 3. POA stowage bracket curvic coupling
- 4. PDGF grapple pins and targets
- 5. Base LEE CLA and POA CLA lens
- 6. Silver Teflon surfaces:
 - a. MBS Camera
 - b. POA camera
 - c. Base LEE CLA
 - d. Base LEE electronics units (2)

For Tip LEE (EV2), avoid contact with:

- 1. Tip LEE curvic coupling and latch openings
- 2. Tip LEE CLA lens and silver Teflon coating
- 3. Tip LEE electronics units (silver Teflon coating)

Warnings: N/A

Timeline Considerations: N/A

FS 7-57 EVA/116/FIN

Z1-006 PATCH PANEL 2 RECONFIGURATION (00:20)

IV	EV1 (FF)	
	Z1-006 PATCH PANEL 2 RECONFIGURATION (SPDA Z1-3B) (zenith panel) 1. Translate to airlock, temp stow fish stringer #1 on toolboxes	
	NOTE Check connectors for FOD, bent pins, bend radius, and EMI bands	
1. Verify w/MCC: Z1 PP 2 inhibits in place: (SODF: ASSY OPS: Z1 CPP X2 (SPDA Z1-3B) Reconfig, steps 3 and 4 complete) (RPCM 2B-B RPC 1 open) (DDCU S03B Conv Off) Verify 2B array >15 degrees to wake	2. Translate to Z1 port face; attach poorman's fairlead above Z1 MBM at P6 HR 5308 3. Translate to zenith patch panel CAUTION Avoid contact with PCU grates and S0 radiator (silver Teflon coating)	
Z1-006 PP 2 J3 Z E N I T	NOTE J3 label is missing on patch panel 2 4. BRT to HR 6011 5. Remove connector cap from J1; temp stow 6. Demate Z1 P1 (W05) from Z1 J3; mate to Z1 J1 7. Install connector cap on J3	
J1 2. Inform MCC connections complete	8. Connector closeout	

FS 7-58 EVA/116/FIN

Z1-006 PATCH PANEL 2 RECONFIGURATION TASK DATA SHEET

Tools: N/A Notes:

1. Check connectors for FOD, bent pins, bend radius, and EMI bands

2. J3 label is missing on patch panel 2

Foot Restraints: N/A Cautions:

1. Avoid contact with PCU grates and S0 Radiator (silver Teflon coating)

EVA Fasteners: N/A Warnings: N/A

EVA Connectors:


Connector	From	То	Clamps	Size	Function
Z1 P1	Z1 J3	Z1		25	secondary Power DDCU S03B
(W05)		J1			to SPDA Z13B

Timeline Considerations:

1. This task must be completed separate from the main ISS powerdown due to shorter thermal clocks for KU-Band hardware


FS 7-59 EVA/116/FIN

STBD AND PORT QD BAG INSTALLATION (00:20)



FS 7-60 EVA/116/FIN

VTE AND PM JUMPER BAG INSTALLATION (00:10)



FS 7-61 EVA/116/FIN

CLEANUP (00:20)

IV	EV1 (FF)	EV2 (FF)	
	Translate to airlock Perform tool inventory	Translate to airlock Perform tool inventory	
NOTE Someone will have two extra sm-sm RETs from the QD Bag	POST EVA TOOL CONFIG MWS Sm-sm RETs (2) Adj Tether (2) Trash Bag Camera Waist Tether	POST EVA TOOL CONFIG MWS Sm-sm RETs (2) Adj Tethers (2) Trash Bag Camera	
	BRT Sm-sm RET Wire Ties (2)	□ Waist Tethers (2) □ Wire Ties (2) BRT □ Sm-sm RET □ Wire Ties (2)	
	Fish Stringer #1: PGT w/6-in socket w/RET P1 DDCU Thermal Cover, w/adj S0 CH 2/3 jumper caps (2) spare safety tether CID 7 spare safety tether WIF adapter w/adj tether Panel A166 DF cap	Fish Stringer #2: CIDs 3, 4, and 5	

FS 7-62 EVA/116/FIN

INGRESS (00:20)

IV	EV1 (FF)	EV2 (FF)
1. Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)	 Ingress airlock Connect right waist tether UIA panel fwd D-ring, verify ST config Disconnect from airlock safety tether, hand to EV2 Receive fish stringers (2) from EV2 Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF 	 Receive EV1 safety tether; stow on airlock fwd D-ring, √reel unlocked Transfer fish stringers (2) to EV1 Connect left waist tether to D-ring extender on airlock internal D-ring, verify ST config Disconnect from airlock safety tether, stow on airlock aft D-ring, √reel unlocked Ingress airlock Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF Hatch thermal cover – close; attach Velcro strap

FS 7-63 EVA/116/FIN

EVA 3 NOTES, CAUTIONS, & WARNINGS

NOTES

- 1. Bolt release: report torque and turns if different from published range
- 2. EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD

CAUTION

ISS Constraints

- A. Avoid inadvertent contact with:
- 1. Grapple fixture shafts
- 2. PIP pins
- 3. MDM sunshade [PMA 1]
- 4. EVA Crane [PMA 1]
- 5. TCS Reflectors [PMA 2, PMA 3]
- 6. APAS hardware [PMA 2, PMA 3]
- 7. CETA Lights (Z-93 paint) [Lab, S1, Node 1]
- 8. Passive UMAs
- 9. MBS VDU, MCU, CRPCMs & Cameras (taped radiative surfaces, silver Teflon)
- 10. Deployed TUS cable
- 11. S0 aft face Radiator
- 12. GPS Antennas (S13 paint) [S0]
- 13. SVS Targets with planned future use [S1, P1]
- 14. UHF Antennas [Lab, P1]
- 15. ETCS Radiators [S1, P1]
- 16. SASA RF Group [Z1, S1, P6]
- 17. Heat pipe radiators [Z1]
- 18. PCU cathode and HCA ports [Z1]
- 19. Ku-Band Antenna (SGANT) dish [Z1]
- 20. CMG cover/shells [Z1]
- 21. SSRMS cameras

B. Electrical cables:

1. Avoid bend radii < 10 times cable diameter

CAUTION (Cont)

ISS Constraints (Cont)

- C. For structural reasons:
 - Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
 - 2. Avoid performing shaking motions (sinusoidal functions) more than four cycles
 - 3. Avoid kicking S1/P1 radiator beam
 If any of these occur, wait 2-5 min to allow
 structural response to dissipate
- D. Other:
 - 1. WIS Antennas: do not use as handholds [Node 1, P6, Z1]
 - Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners [P6,P4,S4,S6] can contaminate EMU

FS 7-64 EVA/116/FIN

EVA 3 NOTES, CAUTIONS, & WARNINGS (Cont)

CAUTION (Cont)

Shuttle Constraints

- E. Avoid contact with:
- 1. OBSS and SRMS Composite Sections and Cable Harnesses
- 2. LCS/IDC (silver Teflon) and LDRI (silver Teflon) and ITVC (gold foil) [OBSS]
- 3. WVS Antenna [ODS]
- 4. Payload Bay wire harnesses, cables and connectors
- 5. LDRI diffuser [OBSS]
- 6. OBSS saddle contacts (when OBSS unberthed) [OBSS]
- OBSS LDRI, LSC, and IDC camera lenses; scratches degrade sensor performance
- 8. Monkey fur [PLB]
- 9. Cameras: metallic surfaces [PLB]
- 10. Ku-Band Antenna black dish and gold thermal blankets [PLB]

FS 7-65 EVA/116/FIN

EVA 3 NOTES, CAUTIONS, & WARNINGS (Cont)

WARNING

ISS Constraints

- A. Avoid inadvertent contact with:
 - 1. Grapple fixture targets and target pins
 - 2. Lab window shutter during operation
 - 3. Stay inboard of SARJ when active
 - 4. Stay 2 ft from S1/P1 radiator beam rotational envelope when beam is free to rotate
 - 5. Stay 5 ft from moving MT on face 1

B. Pinch:

- 1. NZGL connector linkage. Use caution when mating/locking
- 2. EV side of IV hatch during hatch operation (also snag hazard) [A/L]

C. RF radiation exposure:

- 1. Stay 3.6 ft from S-Band (SASA) high gain Antenna when powered [S1,P1,P6]
- 2. Stay 1.3 ft from S-Band (SASA) low gain Antenna when powered [S1,P1,P6]
- 3. Stay 1 ft from UHF Antenna when powered [Lab, P1]

WARNING (Cont)

ISS Constraints (Cont)

D. Sharp Edges:

- 1. Inner edges of WIF sockets
- Mating surfaces of EVA connectors. Avoid side loads during connector mating
- 3. Back side of MMOD shield fasteners
- 4. Spring loaded captive EVA fasteners (e.g., 6B-boxes, BMRRM); the end of the spring may protrude
- 5. PMA umbilical launch restraintsexposed bolt threads
- 6. Ku-Band upper handrail by the Ku boom launch restraint [Z1]

WARNING (Cont)

ISS Constraints (Cont)

E. Thermal:

- EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
- 2. PMA handrails may be hot. Handling may need to be limited
- 3. Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on
- 4. Uncovered trunnion pins may be hot
- 5. SSRMS/MBS operating cameras/lights may radiate large amounts of heat
- Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
- 7. Stay at least 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor up
- 8. Stay 0.5 ft away from PMA and MMOD shields > 325 degF
- 9. Do not touch EMU protective visor if temp has been < -134 for > 15 min
- No EMU TMG contact of PMAs & MMOD shields when temp > 320 degF
- 11. No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF

FS 7-66 EVA/116/FIN

EVA 3 NOTES, CAUTIONS, & WARNINGS (Cont)

WARNING (Cont)

Shuttle Constraints

- H. Arcing/Molten Debris:
 - Stay ≥ 2 ft from exposed EFGF connector when OBSS berthed, powered, and EFGF not grappled [PLB]
 - 2. Stay ≥ 2 ft from Stbd Fwd MPM contacts [PLB]
- I. Pinch:
 - 1. PRLA operation [PLB]
- J. RF radiation exposure:
 - 1. Stay 3.28 ft from S-Band Antenna when powered
 - 2. Stay 1 ft from top and side of UHF PLB
 Antenna radome surface when in high
 powered mode [ODS truss]
 - 3. Stay 0.33 ft from top and side of UHF PLB Antenna radome surface when in low powered mode [ODS truss]
 - Remain below the level of the PLB door mold line for first 20 in aft of fwd bulkhead when S-Band Antenna powered [PLB]
 - Remain on the inboard side of the Stbd slidewire (sill handrails if slidewire not installed) for first 20 ft aft of fwd bulkhead when Ku-Band Antenna powered [PLB]

WARNING (Cont)

Shuttle Constraints (Cont)

- K. Sharp Edges:
 - 1. PRLA grounding wipers [PLB]
 - 2. LDRI baffles. They also pose an entrapment hazard [OBSS]
- L. Thermal:
 - 1. Illuminated PLB lights, do not touch
 - 2. OBSS grapple fixture shafts/cams may be hot. Limit handling if required
- M. Thruster Contamination:
 - 1. Stay out of the immediate vicinity of leaking jet or APU
 - 2. Stay 27 ft from PRCS when powered
 - 3. Stay 3 ft from VRCS when powered
 - 4. Stay 3 ft from APU when operating

N. Other:

1. Do not look at the LDRI diffuser

FS 7-67 EVA/116/FIN

EVA 3 BRIEFING CARD

1. EVA Prep Get-up Plan – cloth Prebreathe protoco Equipment lock act Suit donning plan Airlock depress rev	ivities	 6. Emergencies Emergency suit doff and power down during EVA prep CUFF checklist Abort and Terminate review – scenarios/protocols Hand signals
crew when mode s	oop, A/G2, S/G2, ICOM, Hardline, remind EV wapping M sw throws (all time in A/L)	
3. EVA Procedure Review Order of tasks (sur Egress Plan Detailed Task Revi Notes, Cautions, a Ingress Plan Section 16 Conting	ew nd Warnings	IV CHECKLIST VERIFICATION ITEMS □ Day/Night Cycles and extended two-handed ops □ √Lights, heaters, visors, tools, tethers, gloves □ √Load Alleviating Strap on Safety Tethers not damaged □ √Safety Tether in good config
Coordinate Frames	al position, maneuvers, clearances comm protocol review	 ○ Crew Report: "Hook closed, slide locked, reel unlocked" □ √Both SAFER valves down at egress ○ Crew Report: "Both handles down" □ √APFR locking collar Black-on-Black and pull test ○ Clocking, pitch, roll, yaw
5. Post EVA Coldsoak Airlock Repress red Suit doffing respon Post EVA plan		□ √PGT Green light on for bolt engage □ program, (C)CW, MTL setting □ PGT and sockets – pull test □ May get Lo Torque msg at bolt release □ Crew Report: "Torqued out, XX turns (or green light)" □ √Connectors for damage, bent pins, EMI band, FOD, cable bend radii □ Always receive GO from MCC prior to mating/demating electrical connections, review inhibits as reqd □ Crew Report: "Pins good, EMI band good, no FOD, bend radius OK" □ Coordination between IV/EV/Robotics/Ground

FS 7-68 EVA/116/FIN

EVA 3 INHIBIT PAD

Orbiter

ΑII	EV	As
-----	----	----

TCS

L12 1. √TCS POWER – OFF

Ku-Band Antenna

MCC-H

1. √KU-BAND Mask – active

2. √KU-BAND EVA Protect Box – active

RCS

If EV crew < 27 ft from FRCS:

IV 1. √DAP: VERN, FREE, LO Z (flt specific √ with GNC)

O14,15,16 2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF

LOGIC (four) - OFF

MCC-H

3. √Above RCS config

4. √RCS F – ITEM 1 EXEC (*)

 $\sqrt{\text{JET DES F1U}}$ – ITEM 17 (*)

√F3U – ITEM 19 (*)

√F2U – ITEM 21 (*)

S-Band Antennas

NOTE

Possible loss of comm when forced LL FWD antenna

IV If EV crew < 1.6 ft from S-Band antenna:

A1R 1. S-BAND FM ANT – XMIT LOWER/RCVR UPPER

2. √MCC, lower antenna selected

If no comm, or on MCC call:

C3 3. S-BAND PM ANT – LL FWD

When EVA crewmember at least 1.6 ft away from all S-Band

upper antennas:

C3 4. S-BAND PM ANT – GPC

USOS

All EVAs

PCU

MCC-H

- 1. √PCUs (two) operational in discharge mode and one of the following:
 - A. CCS PCU EVA Hazard Control enabled
 - B. No more than two arrays unshunted
 - C. No more than two arrays pointed < 90 degrees from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
 - A. No more than two arrays unshunted
 - B. No more than two arrays pointed

< 90 degrees from velocity vector

Ground Radar

MCC-H

1. √TOPO and FDO consoles, ground radar restrictions in place for EVA

Location Dependent Inhibits

LAB Window

IV

If EV crew less than 10 ft/3.5 m from window or in window FOV close window shutter

RSOS

All EVAs

SM Antennas

MCC-M

1. Global Timing Sys 1(400.1 MHz) [GTS] – Deactivate

FS 7-69 EVA/116/FIN

EVA 3 SUMMARY TIMELINE

TIME	SRMS	EV1 (FF)	EV2 (FF/SRMS)
00:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)
00:05		EGRESS (00:25)	EGRESS (00:25)
00:30		CHANNEL 1/4 POWER RECONFIGURATION (01:30) S0 Fwd Stbd Avionics Reconfiguration (Panel A148) S1-4B DDCU Reconfiguration S1-4B DDCU Thermal Cover Removal S0-1A DDCU Reconfiguration (A27) Lab 4A DDCU Secondary Power Disconnect from S0 (Panel A163) S0/N1 Pwr Cable Routing (S0 Routing) S0-4B Port Wedge Face DDCU Thermal Cover Removal MBSU Bypass Jumper (1/4) Reconfiguration	CHANNEL 1/4 POWER RECONFIGURATION (01:00) CIDs 1 and 2 Removal/S0 Tray Connections (Panel A199) Z1-003 Patch Panel 6 Reconfiguration (DDCU HP4B)
		in Edd Bypadd damper (171) Neddinigaration	SMDP TRANSFER (02:40)
02:00	SRMS: SMDP Assembly	SMDP TRANSFER (02:00) • Setup	SRMS SetupSMDP Adapter Prep
	SRMS: SMDP Stow SRMS: APFR Egress/Removal	 TDK #4 Stow TDK #3 Stow TDK #2 Stow SMDP Stow on PMA3 	 Bundle #4 Retrieval and Stow Bundle #3 Retrieval and Stow Bundle #2 Retrieval and Stow SMDP Stow on PMA3
04:00	3	Z1-005 PATCH PANEL 1 RECONFIG (00:10) (SPDA Z1-4B)	SRMS Cleanup
04:10		RUSSIAN POWER RECONFIG (00:30) • Z1 to Node 1 Connections • S0 to Node 1 Connections	RUSSIAN POWER RECONFIG (00:30) • H-jumper Removal (Channel 2/3) – Stbd
04:40		AGB TRANSFER TO FHRC (00:45)	AGB TRANSFER TO FHRC (00:45)
05:25		CLEANUP (00:20) • Get-ahead	CLEANUP (00:20) • Get-ahead
05:45		INGRESS (00:20)	INGRESS (00:20)
06:05		PRE REPRESS (00:05)	PRE REPRESS (00:05)
06:10		,	

FS 7-70 EVA/116/FIN

EVA 3 TOOL CONFIG

<u>AIRLOCK</u>		AIRLOCK INTERNAL D-RING
	AIRLOCK ENDCONE	D-RIng Extender
EMU 1	Staging Bag	
MWS, right swing arm	Fish Stringer #3	UIA HANDRAILS
Digital Camera (inner rt swingarm)- 28 mm	Connector cleaner tool caddy	AGB, 2 adj tethers (stay in A/L for EVA)
BRT (left) w/4 wire ties	Wire tie caddy (2)	
w/sm-sm RET	Pin straightener	Crewlock Bag #1 (for contingency) w/lg-sm RET
T-Bar	MWS Key strap	Square scoop (MBSU or DDCU R&R)
ISS trash bag (inner left)	Velcro/Tape caddy	Ballstack (MBSU R&R)
Sm-sm RET (left D-ring)	Torque Wrench (2)	Spare 55' safety tethers (2) (for BCDU cont)
Adj tether (left D-ring) (2)	Socket Caddy (2) w/RAD (1) and 5/8 x 7.8-in ext (2)	MUT EEs (2) (S1 Bay 15 DDCU or SASA cont temp stow)
Sm-sm RET w/PIP pin (right D-ring)		
		Crowlook Dog #2 (for contingency) w/lg cm DET
Adj tether (right D-ring)	EVA Ratchet	Crewlock Bag #2 (for contingency) w/lg-sm RET
D-ring ext – left	Probe	CETA cart PIP pin (wheel bogie R&R)
Waist tether – right	IV Bag	Socket caddy with 6-in, RAD s/n: (AGB cont) and
SAFER	Contamination Detection Kit	2-inch socket
	Hydrazine Detector (Gold Salt Coupon) (6)	Russian adj tethers (2) (SMDP contingencies)
	Color Chart (2)	Russian fixed-length tether (SMDP contingencies)
	ISS Contamination Detection Sampler (2)	Spare PGT (s/n:); batt s/n:
EMU 2	Shuttle Contamination Detection Sampler (2)	Spare WIF adapter
MWS, right swing arm	Nitrogen Dioxide Detector (Oxidizer Draeger	<u> </u>
Digital Camera (inner rt swing arm)- 28 mm	Tube) (6)	Fish stringer # 1
BRT (left)	Ammonia Detector (NH3 Draeger Tube) (6)	Spare 55' safety tether
w/1 short wire tie and 2 long wire ties	2 towels with wire ties	S0 Channel 1/4 Pwr Cable (jumper) (tether to both caps)
w/Sm-sm RET	DCM plug (2) (SAFER hardmount)	PGT w/6-in ext (s/n:), RET; batt s/n:
T-Bar	GP caddy (2)	Fish stringer # 2
ISS trash bag (inner left)	Thermal mittens (2 pr)	PGT w/2-in ext (s/n:), RET w/PIP pin & adj;
Wire ties (2) around T-Bar	Socket Caddy (hatch contingencies) w/sm-sm RET	batt s/n:
Lg-sm RÈT (SMDP adapter) (right D-ring)	1/2 X 8-in socket (IV hatch)	Spare 55' safety tether
Adj tether (left D-ring)	7/16 X 6-in socket (spare)	PAD w/WIF adapter, adj tether
Adj tether (right D-ring)	(0)	
Sm-sm RET w/PIP pin (left D-ring)	PRE EVA 3 TOOL CONFIG	POST EVA 3 TOOL STOW
D-ring ext – left	Verify EVA 3 Hardware in equipment lock	1. Retrieve "Return to Shuttle 3" jett stow bag
D-ring ext – right	2. Transfer PAD from INC "EVA2-3 tools" bag to FS#2	from "EVA 1 Shuttle to ISS" jett stow bag
Waist tether – right D-ring ext	3. Config MWSs (see INC packed "Tools for EVA2-3"	
SAFER	bag for long wire ties)	Shuttle 3" Jettison Stowage Bag:
	4. Verify crewlock bags 1 & 2 and UIA tether point as	"EV1" and "EV2" jettison stowage bags
Total sm-sm RETs used: 4	listed (see INC packed "Tools for EVA2-3" bag)	"EVA 1 Shuttle to ISS" jettison stowage bag
Total sm-sm RETs w/PIP Pin used: 3	5. Verify IV and Staging Bag contents per list	"EVA 2/3 Shuttle to ISS" jettison stowage bag
Total adj tethers used: 9	6. Stow MWSs in "EV1" and "EV2" bags as reqd	CIDs 1 and 2
Total Ig-sm RETs used: 3	7. Prior to EVA, inspect the following:	S1 DDCU Thermal Cover
	RET cords for damage	S0 Channel 1/4 Pwr Jumper Caps (2)
	 □ BRT and MWS toggles: loose fittings/screws □ Safety and waist tether load alleviating 	CH 2/3 H-Jumper
	 Safety and waist tether load alleviating straps (no red band or damage) 	SMDP adapter magnetic latch covers (3)
	Stians the ice pails of salitase)	I I SIVIDE AUADICI HIAUHCHO IAICH COVEIS (3)

FS 7-71 EVA/116/FIN

EGRESS (00:25)

IV	EV1 (FF)	EV2 (FF)
NOTE For safety tether swaps, expect to hear: 1. Hook closed 2. Slide locked 3. Reel unlocked	 √Right waist tether to airlock internal D-ring extender, verify ST config Thermal cover – open Egress airlock Inspect load alleviating straps on 85' safety tethers (2) Retrieve airlock safety tether from fwd external D-ring, 	√Right waist tether to UIA panel fwd D-ring, verify ST config
1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max (required after EV1 and EV2 egress airlock)	 attach to left D-ring extender, verify ST config Release waist tether from internal D-ring extender Receive fish stringer #1 and #2 from EV2 Temp stow fish stringer #1 in between A/L port toolbox HR and stbd toolbox HR (stretched out) Temp stow fish stringer #2 in between A/L HR 0560 (fwd/stbd/nadir) and HR 0555 (nadir of stbd toolbox) Transfer aft airlock safety tether to EV2 Transfer PGT w/RET from fish stringer #1 to right swingarm Transfer spare safety tether from fish stringer #1 to airlock toolbox #1 (stbd) HR Attach fish stringer #1 to MWS √EV2's SAFER MAN ISOL vIv – OP (dn) and HCM (dn) 	 Transfer fish stringer #1 and #2 to EV1 Receive airlock safety tether from EV1, attach to left D-ring extender, verify ST config Release right waist tether from UIA panel D-ring Egress airlock Close thermal cover √EV1's SAFER MAN ISOL vlv – OP (dn) and HCM (dn) Temp stow spare safety tether, PAD with WIF adapter (1 adj), and PGT (1 RET, 1 adj) on airlock HR 0555 (don't need until SMDPs) Retrieve fish stringer #2 Perform translation adaptation on equipment lock

FS 7-72 EVA/116/FIN

CHANNEL 1/4 POWER RECONFIGURATION (01:30)

IV EV1 (FF) EV2 (FF) Verify w/MCC: Power Reconfia NOTE Inhibit Check (SODF: √Connectors for damage, FOD, bent pins, cable bend radius, and EMI bands ASSY OPS:EPS CH 1/4) Powerdown for EVA 3, S0 FWD STBD AVIONICS RECONFIGURATION CIDS 1 AND 2 REMOVAL/S0 TRAY CONNECTIONS (panel A199) steps 6 and 7) complete (Panel A148) (DCSU 4B RBI 6 open) WARNING (DCSU 4A RBI 6 open) 1. Translate to S0 Bay 03, Face 1; temp stow fish stringer #1 Wire ties may break and cause sharp edges on CETA 2 (stbd most) square grid and debris Translate to stbd S0 connector panel on Bay 01, Face 6 BRT to HR 3443 Remove DF cap from J226 **CAUTION** Avoid contact with SASA antennas and S0 Demate S0 P226 (W9003) from S0 J237; mate to S0 J226 Radiator 6. Install DF cap on S0 J237 7. Connector closeout 1. Translate to port Lab/Z1 tray (go aft of airlock); J226 J237 fairlead above Z1 MBM at P6 HR 5308 S0 FWD/STBD CONNECTOR Open TA clamps and remove wire ties as regd PANEL (PANEL A148) S1-4B DDCU RECONFIGURATION (S1 BAY 15) Demate S0 P232 from S0 J460; mate to Z1 J432 BRT to Lab HR 0211 Demate Z1 P301 (W26B) from CID 1 J201: mate to 1. Translate to S1 Bay 15 Attach MWS EE to S1 HR 3200 (nadir HR) Z1 J201 (tray) 6. Demate Z1 P302 (W26C) from CID 2 J202; mate to 3. Remove connector cap from J7 on DDCU coldplate Z1 J202 (tray) connector box (panel A9); temp stow (lanyarded to panel) If required, release P169 from TA clamp Demate CID 1 P301 from Lab J201; temp stow on Demate S1 P169 (W5113) from DDCU CP J8; mate to J7 fish stringer #2 Install cap on J8 8. Demate CID 2 P302 from Lab J202; temp stow on connector closeout fish stringer #2 Release necessary TA clamps on port S0 tray. remove cables, close clamps (panel A199) 10. Demate S0 P201 from S0 J462; mate to Lab J201 11. Demate S0 P202 from S0 J463; mate to Lab J202 12. Close TA clamps as regd 13. 🗀 connector closeout DDCU COLDPLATE CONNECTOR BOX

CHANNEL 1/4 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)		
Zenith P2/J4 J3 Z1 PP 6 (NADIR PANEL)	S1-4B DDCU THERMAL COVER REMOVAL 1. Attach MWS EE to S1 HR 3200 (nadir HR) 2. PGT [A1, CCW2, 30.5]-6"-Ext-7/16: Release DDCU thermal cover grounding strap fastener, 10-15 turns 3. Release Velcro straps (3) 4. Pull thermal cover away from DDCU until straps are free 5. Tend cover using integral straps and adj tether; tether to MWS S0-1A DDCU RECONFIGURATION (panel A27) 1. Translate to CETA 2, temp stow S1 DDCU thermal cover w/adj tether and PGT w/RET on fish stringer #1 2. Translate to port-most CETA cart (CETA 1) 3. Rotate CETA 1 coupler to UNLOCK, slide CETA port until clear of S0 Bay 01 4. Engage parking brake (left handle) 5. Rotate CETA 1 coupler to CAPTURE 6. Translate to S0 Bay 01, access through face 1 7. Remove connector cap from J7 on DDCU coldplate connector box, temp stow (lanyarded to panel) 8. If required, release P157 from TA clamp 9. Demate S0 P157 to S0 J7 12. Sa connector closeout 13. Release CETA parking brake (tap pedal twice) CAUTION CETA to CETA 1 to CETA 2, take CETA 1 coupler to LOCK	Z1-003 PATCH PANEL 6 RECONFIGURATION (DDCU HP 4B) 1. Translate to Z1 patch panel 6 (stbd face, nadir panel) 2. Temp stow fish stringer #2 on doghouse HR (or airlock HR 0521) CAUTION Avoid contact with Z1 DDCU Heatpipes and SASA antennas 3. Fold back thermal shroud (STD SHRD Z1/02/04-03), release Velcro straps from Z1 HRs 6005 and 6024 4. Demate Z1 P2 (W23) from Z1 J4; temp stow 5. Remove connector cap from Z1 J3, mate to Z1 J4 6. Mate Z1 P2 (W23) to Z1 J3 7. □ Connector closeout 8. Reinstall thermal shroud 9. Retrieve fish stringer #2 from doghouse HR		
	15. Relocate S0 CH 1/4 Jumper from fish stringer #1 to MWS			

FS 7-74 EVA/116/FIN

CHANNEL 1/4 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
P333/J333 PANEL A163	EV1 (FF) LAB 4A DDCU SECONDARY POWER DISCONNECT FROM SO (Panel A163) (look port) CAUTION Avoid contact with GPS antennas and S0 Radiator 1. Translate to S0 Bay 00, access through face 03 door 2. Open MLI door 3. Ingress truss (feet first) 4. BRT to HR 3500 5. If reqd, release S0 P333 (W4145) TA clamp 6. Release cap from S0 CH 1/4 jumper J333A, temp stow 7. Demate S0 P333 (W4145) from S0 J333; mate to S0 CH 1/4 jumper J333A 8. Deconflict routing with S0/N1 Pwr cable 9. Release cap from S0 CH 1/4 jumper P333A, temp stow 10. Mate S0 CH 1/4 jumper P333A to S0 J333 11. Restrain S0 cable or jumper using TA clamp or wire tie to HR 3499, close TA clamp 12. So/N1 PWR CABLE ROUTING (S0 ROUTING) 1. Translate to S0/N1 Pwr Cable on port bulkhead (still bay 00) 2. Release cable ties as reqd 3. Route S0/N1 Pwr Cable toward aft S0 tray and wire tie cable to S0 internal HRs: 3500 3480 3478 4. Open S0 Face 5 MLI shroud as reqd (Velcroes) 5. Pass S0/N1 Pwr Cable through shroud opening onto S0 tray	Shroud Cutout (for At Lab Utilities) W4020 (shown in green) HR 3499 HR 3478 S0 Panel A166 S0/N1 PWR CABLE ROUTING
	6. Close MLI shroud as regd	CONTI THE CABLE ROOTING

FS 7-75 EVA/116/FIN

CHANNEL 1/4 POWER RECONFIGURATION (01:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
J482	7. Egress truss 8. Close Face 3 door S0-4B PORT WEDGE FACE DDCU THERMAL COVER REMOVAL 1. Translate to S0 port wedge face CAUTION Avoid contact with TERA stanchion grapple fixture and target 2. Attach MWS EE to S0 HR 3541 3. Release cover strap and remove cover 4. Translate to S0 HR 3519, wrap cover with adj tether and stow on MWS 5. Translate to CETA 2, temp stow S0 DDCU thermal cover w/adj tether and S0 jumper caps (2) on fish stringer #1	EV2 (FF)
P484 J484 J485 Z E N I T H P485 MBSU BYPASS JUMPER PANEL	MBSU BYPASS JUMPER (1/4) RECONFIGURATION (zenith panel) 1. Translate to S0 Bay 04 2. Access MBSU zenith reconfig worksite through face 1 3. BRT to S0 HR 3533 as reqd (Panel A200) 4. Remove connector cap from S0 J485; temp stow 5. Demate S0 P485 from S0 J484 (A302); mate to S0 J485 (Panel A200) 6. If needed, remove P484 (W4033) from TA clamp; close clamp 7. Demate S0 P484 from S0 J482; mate to S0 J484 (A200) 8. Install connector cap on J482 (A302) 9. □ connector closeout	
When EV1's and EV2's connections complete, give MCC GO for power up	10. Retrieve fish stringer #1 from CETA 2, stow on MWS	

FS 7-76 EVA/116/FIN

CHANNEL 1/4 POWER RECONFIGURATION TASK DATA SHEET

Tools:

EV1	EV2
PGT w/6-in	

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
S1 DDCU thermal cover ground strap		7/16	1	3.8	4.7 (shank failure)	10-15	30

Connector	From	То	Clamps	Size	Function
S0 P230	Z1 CID 6	Z1 tray J430		33	4B Primary
(W4035)	J430				Power to MBSU 4
Z1 P301	CID 1 J201	Z1 J201 (tray)		25	Disconnects
(W26B)	CID 1 3201	21 3201 (liay)		23	DDCU LA1A
(202)					from Z1 IDA
Z1 P302	CID 2 J202	Z1 J202 (tray)		25	Disconnects
(W26C)					DDCU LA1B
					from Z1 IDA
CID 1 P301	Lab J201			25	CID 1
					Removal
					(4B Primary
					Power)
CI D 2 P302	Lab J202			25	CID 2
					Removal
					(4B Primary
					Power)
S0 P201	S0 J462	Lab J201		25	Primary
					Power
					MBSU 1 to
00.000	00.1100				DDCU LA1A
S0 P202	S0 J463	Lab J202		25	Primary
					Power
					MBSU 1 to
					DDCU LA1B

Notes:

- 1. √connectors for damage, FOD, bent pins, and cable bend radii, and EMI bands
- 2. It is possible for the DDCU thermal cover to get caught on coldplate legs during removal

Cautions:

- 1. Avoid contact with SASA antennas and S0 Radiator
- 2. Avoid contact with GPS antennas
- 3. Avoid contact with Z1 DDCU Heatpipes
- 4. Avoid contact with TERA stanchion grapple fixture and target5. CETA to CETA max coupling rate is 1 inch/sec

Warnings:

1. Wire ties may break and cause sharp edges and debris

Timeline Considerations:

- 1. 1/4 Connections can be completed in any order
- 2. CIDs 6 and 8 were removed on 12A

FS 7-77 EVA/116/FIN

CHANNEL 1/4 POWER RECONFIGURATION TASK DATA SHEET (Cont)

Connector	From	То	Clamps	Size	Function
S0 P232	S0 J460	Z1 J432		33	Secon Power DDCU S04B to SPDA Z14B
S1 P169 (W5113)	J8	J7		33	DDCU S14B 2ndary Power to Utility Bus
S0 P157 (W4145)	J8	J7		33	DDCU S01A 2ndary Power to Core Bus
S0 P333 (W4145)	S0 J333	S0 CH 1/4 pwr cable J333a		37	Disconnect DDCU LA4A Power to Truss
S0 CH 1/4 Pwr Cable P333a		S0 J333		37	
S0 P485	S0 J484	S0 J485		37	Primary Power DCSU 4A to MBSU 4
S0 P484	S0 J482	S0 J484		37	Primary Power DCSU 4B to MBSU 4
S0 P226 (W9003)	S0 J237 Cap has bail	S0 J226		25	MBSU 4 power to DDCU LA4A

FS 7-78 EVA/116/FIN

SMDP TRANSFER (02:00)

	IV/SRMS	EV1 (FF)	EV2 (SRMS)
1	. (PDRS: EVA 3, APFR Install/ Ingress)	 SETUP Translate to airlock Temp stow fish stringer #1 in between A/L port toolbox HR and stbd toolbox HR (stretched out) Retrieve spare safety tether from toolbox HR and stow on MWS Retrieve PGT w/RET and stow on MWS Translate to ICC via the following path to ensure safety tether is clear of SRMS trajectory: Translate to Lab nadir/stbd HRs Install poorman's fairlead under ODS light Translate to port ODS truss HR and perform safety tether swap onto spare safety tether, verify ST config Translate along Orbiter port sill to ICC Translate to bundle #4 (aft/stbd) 	1. Translate to airlock 2. Temp stow fish stringer #2 in between A/L HR 0560 (fwd/stbd/nadir) and HR 0555 (nadir of stbd toolbox) 3. Retrieve the following tools from airlock HR 0555 and stow on MWS: PAD with WIF adapter (w/adj tether) PGT with 2-in socket (w/RET and adj tether) Spare safety tether (55') 4. Retrieve APFR from airlock toolbox 1 WIF (stbd), stow on BRT 5. Translate to Lab HR 0245 (nadir/aft/port) 6. If reqd, temp stow APFR in Lab WIF 05 or 04 7. GCA as reqd for PAD and APFR install 8. Verify PAD J-hook unlocked prior to opening jaws 9. Install PAD w/WIF adapter onto SRMS, PFR socket toward end effector 10. Lock PAD J-hook 11. Perform safety tether swap onto SRMS black D-ring, verify ST config 12. Install APFR onto PAD, configure to: [12,PP,F,6] 13. GCA as reqd for APFR ingress 14. Install local waist tether onto APFR 15. Ingress APFR
2	2. SRMS mnvr to ICC pallet (PDRS: EVA 3, SMDP Assembly, step 1)		 SRMS mnvr to SMDP adapter Remove magnetic latch covers (3), stow in trash bag Check magnetic latches (3) for FOD Retrieve EMU scissors from right pocket Cut fishing line on magnetic latches (3) Stow EMU scissors in trash bag

FS 7-79 EVA/116/FIN

IV/SRMS	EV1 (FF)	EV2 (SRMS)	
3. √MCC: successful power up of channel 1/4 connections prior to releasing any TDK bolts B1 B2 Tie		 Rotate lock lever open; cycle magnetic latches (3) from OPEN to CLOSE to OPEN BUNDLE #4 RETRIEVAL AND STOW GCA to bundle #4 (aft/stbd) as reqd to access fixator Handles Tether to bundle #4 Rotate fixator handles A1 and A2 (6 total) to OPEN (hard stop) PGT [A5, CCW1, 30.5]-2"-Ext-7/16: Release B1 and B2 bolts (6 total) 2 turns max 	
Rod I Tie Rod II Tie Rod III Tie Rod III TDK #4 BOLT STATUS	The SMDP tie rods do not withstand	ITION I 125 lb kick-loads in the open config RNING Idown beams are potential pinch point on SMDP bundle orange straps.	
	2. Flip TDK tie rod #2 turnbuckle lever 90°; release tie rod NOTE There is not a soft dock to hold the SMDP bundle in place once the tie rods are released 3. Flip TDK tie rod #3 turnbuckle lever 90°; release tie rod		

FS 7-80 EVA/116/FIN

IV/SRMS	EV1 (FF)	EV2 (SRMS)
B1 B2 Tie Rod I Tie Rod II Tie	 4. Config TDK for landing: stow short tie rods (3), pull test stow long tie rods (3), pull test flip turnbuckle levers on short rods (3) 90° configure wire ties for landing (tension) 	 Retrieve bundle #4 from TDK GCA SRMS to SMDP adapter Install bundle #4 onto adapter magnetic socket #4, uneven end up; jiggle until magnetic socket turns Verify magnetic socket fully to CLOSE (no distinct hard stop); rotate lock lever to locked position BUNDLE #3 RETRIEVAL AND STOW GCA SRMS to bundle #3 (fwd/center)
TDK #3 BOLT STATUS	TDK #3 STOW	 Tether to bundle #3 Rotate fixator handles A1 and A2 (6 total) to OPEN (hard stop) PGT [A5, CCW1, 30.5]-2"-Ext-7/16: Release B1 and B2 bolts (6 total) 2 turns max
	 Flip TDK tie rod #1 (fwd-most) turnbuckle lever 90°; release tie rod from stbd (opens toward port sill) Flip TDK tie rod #2 turnbuckle lever 90°; release tie rod Flip TDK tie rod #3 turnbuckle lever 90°; release tie rod 	
B1 B2 Tie Rod I Tie Rod II Tie	 4. Config TDK for landing: stow long tie rods (3), attach short rods to sides do pull test to ensure rods are latched flip turnbuckle levers (3) 90° configure wire ties for landing (tension) 	 Retrieve bundle #3 from TDK GCA SRMS to SMDP adapter Install bundle #3 onto adapter magnetic socket #3, uneven end up; jiggle until magnetic socket turns Verify magnetic socket fully to CLOSE (no distinct hard stop); rotate lock lever to locked position BUNDLE #2 RETRIEVAL AND STOW
TDK #2 BOLT STATUS		 GCA SRMS to bundle #2 (fwd/port) Tether to bundle #2 Rotate fixator handles A1 and A2 (6) to OPEN (hard stop) PGT [A5, CCW1, 30.5]-2"-Ext-7/16: Release B1 and B2 bolts (6 total) 2 turns max

FS 7-81 EVA/116/FIN

IV/SRMS	EV1 (FF)	EV2 (SRMS)
	 TDK #2 STOW Flip TDK tie rod #1 (fwd-most) turnbuckle lever 90°; release tie rod from stbd (opens toward port sill) Flip TDK tie rod #2 turnbuckle lever 90°; release tie rod Flip TDK tie rod #3 turnbuckle lever 90°; release tie rod Config TDK for landing: stow long tie rods (3), attach short rods to sides do pull test to ensure rods are latched flip turnbuckle levers (3) 90° configure wire ties for landing (tension) 	5. Retrieve bundle #2 from TDK NOTE Be aware of tight clearances between the OBSS and bundle #2 during installation onto the SMDP adapter 6. GCA SRMS to SMDP adapter 7. Install bundle #2 onto adapter magnetic socket #2, uneven end up; jiggle until magnetic socket turns 8. Verify magnetic socket fully to CLOSE (no distinct hard stop); rotate lock lever to locked position
	SMDP STOW ON PMA3 1. Translate to stbd side of SMDP adapter (Christmas tree)	SMDP STOW ON PMA3 1. GCA SRMS to fwd of SMDP adapter (Christmas tree)
		2. Tether to Christmas tree (Ig-sm RET to fit adapter HR)3. Hold Christmas tree HRs
	There is not a soft dock in between	OTE n the SMDP adapter and the ICC

FS 7-82 EVA/116/FIN

IV/SRMS	EV1 (FF)	EV2 (SRMS)
4. SRMS mnvr to PMA3 (PDRS: EVA 3, SMDP Stow)	 Release Christmas tree from ICC: Flip lock lever up (to unlock it) Pull out on handle and rotate to OPEN Translate to port ODS HR; perform safety tether swap onto airlock safety tether, verify ST config, retrieve spare safety tether Translate to airlock via Lab stbd sill Transfer spare safety tether and PGT w/6-in socket to fish stringer #1 	4. Release Christmas tree from ICC 5. SRMS mnvr to aft grapple fixture on PMA 3 (pre-stow posn)
	CAUTION Avoid contact with S0 Radiator	
	 6. Translate to PMA3 aft grapple fixture via Rat's Nest; fairlead above Z1 MBM at P6 HR 5308 7. Assist EV2 with clearances as reqd NOTE Monitor clearances between Christmas tree and Node 1 	 6. At SRMS pre-stow posn, verify Christmas tree is oriented such that: Corner of Bundles #4 (smallest) and #2 are closest to Node 1 Right hand is holding right vertical HR Left hand is holding left vertical HR or circular HR
	 8. GCA EV2/SRMS until Christmas tree is fully seated in Strela Adapter, assist with install as reqd 9. Pull out on handle and rotate to CLOSE 10. Flip lock lever down (to lock it) 	7. Install Christmas tree onto Strela adapter
		8. Release tether from Christmas tree9. □ Christmas Tree closeout

FS 7-83 EVA/116/FIN

IV/SRMS	EV1 (FF)	EV2 (SRMS)
5. SRMS mnvr Lab for SRMS cleanup (PDRS: EVA 3, APFR Egress/Removal, steps 1 and 2)		 SRMS mnvr to Lab HR 0245 (nadir/aft/port) Egress SRMS GCA as reqd to remove APFR and PAD Remove APFR from WIF adapter, stow on BRT Remove PAD and WIF adapter from SRMS, attach to MWS GCA as reqd to perform safety tether swap Perform safety tether swap onto airlock safety tether, verify ST config, attach spare tether to MWS Translate to airlock Stow APFR in airlock toolbox 1 (stbd) WIF; configure to: [9,MM,F,12] Stow PAD with WIF adapter (with adj) and spare safety tether on fish stringer #2

FS 7-84 EVA/116/FIN

SMDP TRANSFER TASK DATA SHEET

Tools:

EV1	EV2
PGT with 6-in x 7/16	PGT with 2-in x 7/16
	PAD with WIF Adapter, APFR
	EMU Scissors

Foot Restraints

Task	WIF	APFR Setti	APFR Setting	
SMDP Transfer	SRMS	12,PP,F,6		

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
A1 (fixator handle and override bolt)	A1	7/16"	9	0.38	N/A	~1/4 (90 ⁰)	PGT- ratchet
A2 (fixator handle and override bolt)	A2	7/16"	9	0.38	N/A	~1/4 (90°)	PGT- ratchet
B1 (nominal)	B1	7/16"	9	4.34	7.2 (bolt tooth breakage)	2 max	10
B2 (nominal)	B2	7/16"	9	4.34	7.2 (bolt tooth breakage)	2 max	10
Open 1 (cont)	Open 1	7/16"	9	0.38	N/A	~ 1/9 (40 ⁰)	PGT- ratchet
Open 2 (cont)	Open 2	7/16"	9	3.26	N/A	~ 1/2 (170 ⁰)	PGT- ratchet
Cont bolts to release SMDP adapter and NHP plate from ICC	No label	7/16"	4	25.3	50.6 (bolt fracture along thread)		

Notes:

- There is not a soft dock to hold the SMDP bundles in place once the tie rods are released
- 2. Be aware of tight clearances between the OBSS and bundle #2 during installation onto the SMDP adapter
- 3. There is not a soft dock in between the SMDP adapter and the ICC
- 4. Monitor clearances between Christmas tree and Node 1
- For the B1 and B2 primary bolts, release the bolt a maximum of two turns. Do not go to the hard stop. If more than two turns is exceeded, the protruding bolt could potentially hinder correct stowage of the TDK hold down beam onto the frame for TDK's 2 and 3

Cautions:

- 1. The SMDP tie rods do not withstand 125 lb kick-loads in the open config (can only withstand 22 lbs)
- 2. Avoid contact with S0 Radiator

Warnings:

- 1. The TDK tie rods and hold down beams are potential pinch point hazards at hinges
- 2. Avoid contact with buckles on SMDP bundle orange straps. They have sharp edges

Timeline Considerations:

- 1. Once any bolts are untorqued, TDK is not certified for landing. SMDP adapter magnetic latches can be cycled and TDK fixator handles can be opened prior to CH 1/4 power up
- 2. Wire Ties are reqd for TDK landing loads
- 3. SMDP bundles can be released from ICC and attached to SMDP adapter in any order
- 4. TDK primary bolts and tie rods can be released in any order
- 5. Bundles are required to be installed at specific, labeled sockets on SMDP adapter to accommodate clearances on PMA 3

SMDP Mass:

Bundle #2: 48 kg (106 lbs) Bundle #3: 56 kg (123 lbs) Bundle #4: 45 kg (99 lbs) SMDP Adapter: 24 kg (53 lbs) Christmas Tree: 173 kg (380 lbs)

FS 7-85 EVA/116/FIN

Z1-005 PATCH PANEL 1 RECONFIGURATION (00:10)

IV	EV1 (FF)	
1. Verify w/MCC: Z1 PP 1 inhibits in place: (SODF: ASSY OPS: Z1 CPP X1 (SPDA Z14B) Reconfig, steps 3 and 4) complete (DDCU S04B Conv – off) Verify 2B array > 15 deg to wake	1. Translate to Z1 port face 2. Translate to nadir patch panel NOTE √Connectors for damage, FOD, bent pins, and cable bend radii, and EMI band CAUTION Avoid contact with PCU grates and S0 radiator 3. BRT to HR Z1 6011 as reqd 4. Remove connector cap from J1; temp stow 5. Demate Z1 P1 (W10) from Z1 J3; mate to Z1 J1 6. Install connector cap on J3 7. □ connector closeout	
J1 Z1-005 PP 1 2. Notify MCC Z1-005 PP 1 connections complete	✓ Connector closeout	

FS 7-86 EVA/116/FIN

Z1-005 PATCH PANEL 1 RECONFIGURATION TASK DATA SHEET

Tools: N/A Notes:

es:

1. √Connectors for damage, FOD, bent pins, and cable bend radii, and EMI band

EVA Fasteners: N/A

Cautions:

1. Avoid contact with PCU grates and S0 radiator

Warnings: N/A

EVA Connections:


Connector	From	То	Clamps	Size	Function
Z1 P1	Z1 J3	Z1	3	25	Secondary Pwr DDCU S04B to
(W10)		J1			SPDA Z14B

Timeline Considerations:

1. Z1 Patch Panel 1 Reconfig must be performed as a separate power down from 1/4 Reconfig. This is due to the short thermal clock for the KU-Band antenna

FS 7-87 EVA/116/FIN

RUSSIAN POWER RECONFIGURATION (00:30)



FS 7-88 EVA/116/FIN

RUSSIAN POWER RECONFIGURATION (00:30) (Cont)

IV	EV1 (FF)	EV2 (FF)
		☐ FGB P20 to PMA1 J20 ☐ FGB P21 to PMA1 J21 9. Take PMA1 connectors to hard dock: ☐ PMA1 P20 to J20 ☐ PMA1 P21 to J21 10. ☐ connector closeout 11. Re-install thermal booties
Inform MCC when EV1 and EV2 Russian connections complete		

FS 7-89 EVA/116/FIN

RUSSIAN POWER RECONFIGURATION TASK DATA SHEET

Tools: N/A

EVA Fasteners: N/A

EVA Connections:

Connector	From	То	Clamps	Size	Function
Z1 P151 (W32C)	Node 1 J651	Z1 J651	4	25	Dcnct SM Power from Z1 SPDA
S0 P651 (W4014)	S0 J872	Node 1 J651		25	Cnct SM Power to MBSU 3
PMA1 P20	Softdock			25	
PMA1 P21	Softdock			25	
Jumper J20a	FGB P20			25	H-Jumper Removal (PMA 1B SEC PWR)
Jumper J21a	FGB P21			25	H-Jumper Removal (PMA 1D PRI PWR)
Jumper P20a	PMA 1 J20			25	H-Jumper Removal (PMA 1B SEC PWR)
Jumper P21a	PMA1 J21			25	H-Jumper Removal (PMA 1D PRI PWR)
FGB P20		PMA1 J20		25	FGB ARCU power from Z1 SPDA
FGB P21		PMA1 J21		25	SM CHT power from MBSU 3
PMA1 P20		J20		25	FGB ARCU power from Z1 SPDA
PMA1 P21		J21		25	SM CHT power from MBSU 3
S0/N1 Pwr Cable P651A		Node 1 J651 (stage)		25	Not performed on 12A.1

Notes:

- √Connectors for damage, FOD, bent pins, and cable bend radii, and EMI band
- 2. H-Jumper Note:
 - J20a is a pin; P20 is a socket
 - P20a is a socket; J20 is a pin
 - J21a is a pin; P21 is a socket
 - P21a is a socket; J21 is a pin

Cautions:

- 1. Avoid contact with S0 radiator and SASA antennas
- 2. Avoid contact with MDM sunshade

Warnings:

1. Wire ties may break and cause sharp edges and debris

Timeline Considerations:

- 1. Russian Reconfig must be performed as a separate power down from 1/4 Reconfig
- 2. The CH 1/4 H-Jumper will only be removed if the "S0/N1 SM Pri Pwr EVA Cable" gets plugged into the Node during EVA 3 (not the current plan)
- 3. Per FOR, the Z1 P150 and S0 P650 connections will not be performed; this is based on the fact that the CH 1/4 H-jumper is still installed (the 4B tasks are deleted here)

FS 7-90 EVA/116/FIN

AGB TRANSFER TO FHRC (00:45)

IV	EV1 ((FF)	EV2 (FF)			
	RETRIEVE AGB FROM AIR 1. Translate to airlock 2. Ingress airlock	<u>RLOCK</u>	1. Translate to airlock 2. Stow H-jumper on fish stringer #2			
			TION arget pin and grapple shaft			
	 3. Retrieve AGB using the Release adjustable to Maintain constant vistarget pin Holding AGB, egress 4. Attach AGB to BRT 	tethers (2) from AGB sual on grapple shaft and	Assist EV1 as reqd Close airlock thermal co	over		
	AGB INSTALL ONTO FHRO	2	AGB INSTALL ONTO FHRC			
	Translate to stbd side of (fwd/nadir/center)	f FHRC on ESP2	 Translate to port side o (fwd/nadir/center) Release AGB attach fla 	of FHRC on ESP2 saps (3) (velcro holds them		
	 Orient AGB such that T- Pull T-handle out to unlo Extend AGB out to posit 	ock (see 2 white lines)	open)			
	5. Slide single pin end into aligned with FHRC pos6. Push T-handle in to lock	stbd receptacle until	Install AGB 2-pin side in FHRC (soft dock), rea	-		

FS 7-91 EVA/116/FIN

AGB TRANSFER TO FHRC (00:45) (Cont)

IV	EV1 (FF)	EV2 (FF)
	7. Release tether	
	8. Receive PGT from EV2	4. Transfer PGT to EV1 (stay tethered)
	9. PGT [A2, CW2, 30.5]-2"-Ext-7/16:	
	Drive AGB bolt, 2-4 turns (hard stop)	
	(preps it for grapple)	
	10. Take digital stills of AGB from various angles,	5. Take digital stills of AGB from various angles,
	specifically the RMS target pin	specifically the RMS target pin

FS 7-92 EVA/116/FIN

AGB TRANSFER TO FHRC TASK DATA SHEET

Tools:

EV1	EV2
	PGT with 2-in x 7/16

Foot Restraints: N/A

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
Center Drive Pin	4	7/16"	1	3.8	5.7 (overload fwd leg pin & retainer)	~2-4	30 CW

AGB Mass: 34 kg (75 lbs)

Notes:

- 1. The AGB is tethered inside the A/L using 2 adj tethers:
- □ AGB grapple pin shall be low-profile and not block IV hatch (determine best config on-orbit)
- Single pin side is tethered from AGB tether point to TBD zenith HR and back onto AGB tether point
- □ Double pin side is tethered from AGB HR to UIA HR
- 2. A RAD with 2-inch socket may be needed to access AGB bolt because of tight clearances with UTA on ESP2

Cautions:

1. Avoid contact with AGB target pin and grapple shaft

Warnings: N/A

Other: The flight AGB retracted length (NTA setting) is: ~38.4"

The NBL AGB retracted length (NTA setting) -s: ~37.3"

FS 7-93 EVA/116/FIN

CLEANUP (00:20)

IV	EV1 (FF)	EV2 (FF)				
	Translate to airlock Perform tool inventory	Translate to airlock Transfer PGT w/2-in (w/RET & adj) to fish stringer 2 Perform tool inventory				
	POST EVA TOOL CONFIG	POST EVA TOOL CONFIG				
	□ Sm-sm RETs (3):	□ Sm-sm RETs (2):				
	□ Adj tether:	□ Lg-sm RET:				
	□ Wire Ties (0): (used for S0/N1 pwr cable)	□ Adj tethers (3):				
	☐ Trash bag: ☐ (may_have a broken wire tie)	□ Short Wire Ties (3):Long Wire Ties (2)				
	(may have a broken wire tie)	□ Trash bag: □ (may have broken wire ties) □ Strela Adapter latch covers (3)				
	□ Camera:	□ Camera:				
	□ BRT	□ BRT				
	□ Waist tether:	□ Waist tether:				
	□ Fish Stringer #1: □ PGT w/6-in socket w/RET □ S1 DDCU Thermal Cover w/adj □ S0 DDCU Thermal Cover w/adj □ S0 CH 1/4 jumper caps (2) □ 55' safety tether □ 85' safety tether (still wearing)	□ Fish Stringer #2: □ 55' safety tether □ CIDs 1 and 2 □ PAD w/WIF adapter □ 85' safety tether (still wearing) □ PGT w/2-in socket (w/RET and adj) □ H-Jumper (CH 2-3)				
	<u>GET-AHEAD</u>	<u>GET-AHEAD</u>				
	Relocate APFR from A/L WIF 1 to CETA 2 WIF 1 (on port TFR), configure to: [1,NN,E,1]	Relocate APFR from ESP2 WIF 8 to CETA 2 WIF 2 (on stbd TFR), configure to: [3,TT,F,12]				

FS 7-94 EVA/116/FIN

INGRESS (00:20)

IV	EV1 (FF)	EV2 (FF)
Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)	 Disconnect EV2's 85' safety tether from airlock external aft D-ring, transfer to EV2 Transfer fish stringer's #1 and #2 to EV2 Connect right waist tether to D-ring extender on airlock internal D-ring, verify ST config Disconnect 85' safety tether from airlock external fwd D-ring, stow on MWS Ingress airlock Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF Hatch thermal cover – close; attach Velcro strap 	 Ingress airlock Connect right waist tether UIA panel fwd D-ring, verify ST config Receive 85' safety tether from EV1, stow in airlock Receive fish stringer's #1 and #2 from EV1, temp stow Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF
	Do not close hatch until EN 10. Verify hardware clear of hatch 11. Outer hatch – close and lock 12. Go to PRE REPRESS	

FS 7-95 EVA/116/FIN

This Page Intentionally Blank

FS 7-96 EVA/116/FIN

TOOLS AND STOWAGE

PGT CHECKOUT		8-3
760XD PGSC-PGT CONNECTION		8-4
PROGRAM PGT SETTINGS		8-4
DOWNLOAD/ERASE EVENT LOG		8-5
PGT CONTINGENCIES		8-6
APFR MANAGEMENT – STS-116 (12A.1)	FS	8-7
SAFETY TETHER CONFIGURATION	FS	8-8
PORT LIGHTWEIGHT TOOL STOWAGE ASSEMBLY	_	8-9
TOOLBOX STOWAGE		8-10
TOOLBOX PANEL AND SLOT LABELS	FS	8-11
Z1 TOOLBOX INTERNAL LAYOUT		8-12
AIRLOCK TOOLBOX INTERNAL LAYOUT		8-13
STBD QD BAG PACK		8-14
PORT QD BAG PACK		8-15
VTE BAG AND PUMP MODULE JUMPER BAG PACK	FS	8-16
EMU EQUIPMENT SORTED BY ITEM	FS	8-17
EMU EQUIPMENT SORTED BY LOCATION	FS	8-19
SHUTTLE EVA TOOLS SORTED BY TOOL NAME		8-21
SHUTTLE EVA TOOLS SORTED BY LOCATION	FS	8-26

This Page Intentionally Blank

APFR MANAGEMENT – STS-116 (12A.1)

APFR	APFR 1	APFR 2	APFR 3 S/N 1005	APFR 4 TS. old ORU	APFR 5 TS. old ORU	APFR 6	APFR 7 S/N 1008	IAPFR 1	IAPFR 2	CRANE (ballstack, old	TS	ORU stanchion/T
DESIGNATOR	(8A Pitch knob		no pitch knob	tether	tether	(heat shield)	S/N 1008			ORU tether)		ERA
	problem)		prob 9A-	(heat shield)	(heat shield)					ONO tetrier)		(headless)
	problemy		inc12	(near sinera)	(ricat silicia)							(ricadicoo)
			Ingress aid									
EVA 1	P4 WIF 17	P4 WIF 20	Z1 WIF 11	Node WIF 5	PMA1 WIF 2	PMA1 WIF 4	S0 WIF 07	Z1 WIF 1	Z1 WIF 3	PMA1 WIF 5	S0 port	S0 port
	[5,RR,J,12]	[6,WW,A,10]	[2,TT,H,11]	[6,PP,B,12]	[12,KK,F,6]	[4,PP,A,6]	[5,NN,L,12]	[12,PP,F,12]	[6,PP,F,12]		wedge	wedge face
					TS pointed						face	
					along node 1,							
Final Targuing	P4 WIF 17				zen/stbd dir							
Final Torquing (RTAS corner 3)	[5,RR,J,12]											
Final Torquing	[3,KK,3,12]	P4 WIF 20										
(RTAS corner 4)		[6,WW,A,10]										
Final Torquing	P4 WIF 18	[-,,.,.,.										
(RTAS corner 1)	[8,OO,D,12]											
Final Torquing		P4 WIF 19										
(RTAS corner 2)		[6,PP,L,11]										
PVRGF Transfer to		P5 WIF 11										
SSRMS	0574 0 14/15	[9,QQ,H,12]										
Get-ahead: EVA 2 (CETA Cart)	CETA 2 WIF	Airlock Toolbox 1										
EVA 3 (SMDP)	[12,PP,F,6]	WIF										
LVA 3 (OMBI)	[12,11,1,0]	[9.MM.F.12]										
EVA 2	CETA 2 WIF	Airlock	Z1 WIF 11	Node WIF 5	PMA1 WIF 2	PMA1 WIF 4	S0 WIF 07	Z1 WIF 1	Z1 WIF 3	PMA1 WIF 5	S0 port	S0 port
,,,,	03	Toolbox 1	[2,TT,H,11]	[6,PP,B,12]	[12,KK,F,6]	[4,PP,A,6]	[5,NN,L,12]	[12,PP,F,12]	[6,PP,F,12]		wedge	wedge face
	[12,PP,F,6]	[9,MM,F,12]									face	
CETA Cart Relocation	SSRMS WIF											
	[12,PP,F,6]											
Cleanup	ESP 2											
	WIF 8											
=>/^	[3,PP,F,12]	A toda a la	74 \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	N \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	DMAA A MUE O		00 1445 07	74 \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	74 14/15 0		00	00
EVA 3	ESP 2 WIF 8	Airlock Toolbox 1	Z1 WIF 11 [2,TT,H,11]	Node WIF 5 [6,PP,B,12]	PMA1 WIF 2 [12,KK,F,6]	PMA1 WIF 4 [4,PP,A,6]	S0 WIF 07 [5,NN,L,12]	Z1 WIF 1 [12,PP,F,12]	Z1 WIF 3 [6,PP,F,12]	PMA1 WIF 5	S0 port wedge	S0 port wedge face
	[3,PP,F,12]	WIF	[2,11,11,11]	[0,22,6,12]	[12,KK,F,0]	[4,PP,A,6]	[5,1111,L,12]	[12,PP,F,12]	[0,22,7,12]		face	wedge lace
	[3,11,1,12]	[9,MM,F,12]									lace	
PAD Setup		SRMS										
		[12,PP,F,6]										
PAD Cleanup		Airlock										
		Toolbox 1										
	505.0	[9,MM,F,12]	74.1405.4		B. 44 4 14 17 2	5144414	0011115		74.1405	51444145	00	
Post-EVA 3	ESP 2 WIF 8	Airlock Toolbox 1	Z1 WIF 11	Node WIF 5	PMA1 WIF 2		S0 WIF 07	Z1 WIF 1	Z1 WIF 3	PMA1 WIF 5	S0 port	S0 port
	[3,PP,F,12]	[9,MM,F,12]	[2,TT,H,11]	[6,PP,B,12]	[12,KK,F,6]	[4,PP,A,6]	[5,NN,L,12]	[12,PP,F,12]	[6,PP,F,12]		wedge face	wedge face
	[3,55,1,12]	[3,101101,1 ,12]									lace	


FS 8-7 EVA/116/FIN

SAFETY TETHER CONFIGURATION – 116

	#60 or #70 SN 1008 or 1020 Lg-sm Locking hooks	#60 or #70 SN 1008 or 1020 Lg-sm Locking hooks	#59 SN 1007 Sm-sm Locking hooks	#72 SN 1022 Lg-sm Locking hooks	#73 SN 1023 (or 1015) Locking hooks	#71 SN 1021 Lg-sm Locking hooks	#66 SN 1016 Sm-sm Locking hooks	#22 SN 1002 85-ft Tether Sm-sm Locking hooks	#26 SN 1006 85-ft Tether Lg-sm Locking hooks	#25 SN 1005 85-ft	#28 SN 1008 85-ft
Pre EVA1	S0 HH 3529	S0 HH 3530	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	A/L Ext D- ring and A/L HH 0506	A/L Ext D- ring and A/L HH 0506	INSIDE A/L Interior	INSIDE A/L Interior	Shuttle Middeck	Shuttle Middeck
Post EVA 1			INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	A/L Ext D- ring and A/L HH 0506	A/L Ext D- ring and A/L HH 0506		
Post EVA 2			INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	A/L Ext D- ring and A/L HH 0506	A/L Ext D- ring and A/L HH 0506		
Post EVA 3	S0 HH 3529	S0 HH 3530	INSIDE A/L Interio	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	INSIDE A/L Interior	Shuttle Middeck	Shuttle Middeck

FS 8-8 EVA/116/FIN

PORT LIGHTWEIGHT TOOL STOWAGE ASSEMBLY



Forward Tray layout and Labels

Aft Tray Layout and Labels



FS 8-9 EVA/116/FIN


TOOLBOX STOWAGE

	Z1 PORT TOOLBOX	Z1 STBD TOOLBOX	A/L TOOLBOX 1 (STBD)	A/L TOOLBOX 2 (PORT)
SLOT#1	SQUARE TM BOARD SQ TORQUE MULTIPLIER 7/16" FLUSH SQ SOCKET 7/16" PROUD SQ SOCKET 7/16" RECESSED SQ SOCKET	SQUARE TM BOARD SQ TORQUE MULTIPLIER 7/16" FLUSH SQ SOCKET 7/16" PROUD SQ SOCKET 7/16" RECESSED SQ SOCKET	HAMMER BOARD HAMMER	CABLE CUTTER BOARD COMPOUND CUTTERS (SM) SCISSORS
SLOT # 2		QD BAIL TOOL BOARD BMRRM LATCH TOOL QD BAIL DRIVE TOOL (1")	PLIERS BOARD NEEDLE NOSE PLIERS	
SLOT #3	RATCHET BOARD 3/8" DRIVE RATCHET 7/16" X 12" WOBBLE SOCKET 7/16" X 2" RIGID SOCKET	RATCHET BOARD 3/8" DRIVE RATCHET 7/16" X 6" WOBBLE SOCKET		
SLOT # 4				
SLOT #5	ROUND TM BOARD RND TORQUE MULTIPLIER 5/8" PROUD RND SOCKET 7/16" FLUSH RND SOCKET 7/16" PROUD RND SOCKET	ROUND TM BOARD 7/16" FLUSH RND SOCKET 7/16" PROUD RND SOCKET	ADJ WRENCH BOARD FORCEPS WRENCH, ADJ	T-HANDLE TOOL BOARD 1-3" T-TOOLS 2-8" T-TOOLS
SLOT#6	TRASH BAG BOARD LARGE TRASH BAG SMALL TRASH BAG	TRASH BAG BOARD	HYDRAZINE BRUSH BOARD HYDRAZINE BRUSH	
SLOT #7	SOCKET BOARD 5/32" BALL END ALLEN DR 1/2" X 8" WOBBLE SOCKET 5/16" X 7" RIGID SOCKET	SOCKET BOARD 5/32" BALL END ALLEN DR 1/2" X 8" WOBBLE SOCKET 5/16" X 7" RIGID SOCKET	PRD (Toolboard) PRD	PRD (Toolboard) PRD
PANEL #8	CHEATER BAR PANEL ADJ EQUIP TETHER	CHEATER BAR PANEL CHEATER BAR ADJ EQUIP TETHER	TOOL CADDY PANEL CADDY, ISS (BUNGEE)	
PANEL # 9	18" SOCKET PANEL 7/16" X 18" WOBBLE SOCKET	18" SOCKET PANEL	BOLT PULLER PANEL BOLT PULLER MECHANICAL FINGER	LARGE CUTTER PANEL GP CUTTER (LARGE)
EXTERNAL	1 SQUARE SCOOP 1 ROUND SCOOP D-HANDLE	2 SQUARE SCOOPs D-HANDLE		

FS 8-10 EVA/116/FIN


NOTE

- A/L Toolbox: Slider feature located in center slot only (#3)
- CETA Toolbox: Slider feature located in all slots




FS 8-11 EVA/116/FIN

Z1 TOOLBOX INTERNAL LAYOUT



DOORS SHOWN REMOVED AND ROTATED 180".
FROM CLOSED POSITION FOR CLARITY.



FS 8-13 EVA/116/FIN

STBD QD BAG PACK


NOTE


QD tools in rows 1 through 10 that are grayed out have been pre-packed by ISS crew

- 1. Retrieve INC 14 pre-packed "STBD QD BAG" from temp stow area
- Retrieve "5 MLE bag" from temp stow area
- 3. Remove Port QD Bag from 5 MLE bag, temp stow (leave all foam in 5 MLE bag)
- 4. Pack "STBD QD BAG" using vent tools (3) in rows 11-13 from "5 MLE Bag" per table below
 5. Add gap spanners to Port and Stbd QD bags per EVA 2 tool config
- 6. Perform photo closeout of internal stowage of Stbd QD Bag when complete

	STBD QD BAG (SEG33114667-301)							
#	# TOOL PART# LOCATION IN BAG							
1.	1/4" cap tool	GD2043725	☐ 1/4" cap tool (pocket)					
2.	1/2" cap tool	GD2043730	□ 1/2" cap tool (pocket)					
3.	1" cap tool	GD2043325	□ 1" cap tool (pocket)					
4.	3/4" & 1' QD Bail Drive lever	SDG33113838-703	□ 3/4" & 1' QD Bail Drive Lever pouch on lid					
5.	1.5" QD Bail Drive Lever	SDG33113837-701	☐ 1.5" QD bail Drive Lever pouch on lid					
6.	1.5" QRT & FID Gauge	SEG33114617-701	☐ 1.5" QRT & FID Gauge (pocket)					
7.	3/4" & 1" QRT & FID Gauge	SEG33114616-701	□ 3/4" & 1" QRT & FID Gauge (pocket)					
8.	1" H20/N2 Vent Tool – F	1F98593-1	□ 1" H20/N2 Vent Tool – F (pocket)					
9.	1" NH3/N2 Vent Tool – F	1F98589-1	□ 1" NH3/N2 Vent Tool – F (pocket)					
10.	1" NH3/N2 Vent Tool – M	1F98596-1	□ 1" NH3/N2 Vent Tool – M (pocket)					
11.	1.5" NH3/N2 Vent Tool – F	1F9859-1	□ 1.5" NH3/N2 Vent Tool – F (pocket)					
12.	3/4" NH3/N2 Vent Tool – F	1F98597-1	□ 3/4" NH3/N2 Vent Tool – F (pocket)					
13.	1/4" NH3/N2 Vent Tool – F	1F98592-1	□ 1/4" NH3/N2 Vent Tool – F (pocket)					

- Ensure cap tools (3) are friction fitted
- Close all QRT tool flaps (2)
- Close all vent tool flaps (6)





FS 8-14 EVA/116/FIN PORT QD BAG PACK

QD vent tools in rows 3 thru 7 that are grayed out launch in place inside Port QD Bag

- Retrieve "PORT QD BAG" from 5 MLE Bag, re-attach insert velcro to bag wall velcro, temp stow bag (leave all foam in 5 MLE bag)
- Retrieve 1.0 CTB, temp stow


- Retrieve 1.0 CTB, temp stow
 Retrieve adjustable tethers (4) and gap spanners (4) from 1.0 CTB, temp stow
 Retrieve "PORT QD BAG and VTE BAG" that INC 14 crew pre-packed from temp stow area
 Retrieve remaining QD tools from 5 MLE Bag and "PORT QD Bag and VTE Bag" and pack into port QD bag per table below:
 Add gap spanners to Port and Stbd QD bags per EVA 2 tool config
 Perform photo closeout of internal stowage of Port QD Bag when complete

	PORT QD BAG (SEG33114667-301/1001)								
#	TOOL	PART#	LOCATION IN BAG						
1.	1/4" cap tool	GD2043725	□ 1/4" cap tool (pocket)						
2.	1/2" cap tool	GD2043730	□ 1/2" cap tool (pocket)						
3.	1.5" NH3/N2 Vent Tool – F	1F9859-1	□ 1.5" NH3/N2 Vent Tool – F (pocket)						
4.	1" H20/N2 Vent Tool – F	1F98593-1	□ 1" H20/N2 Vent Tool – F (pocket)						
5.	3/4" NH3/N2 Vent Tool – F	1F98597-1	□ 3/4" NH3/N2 Vent Tool – F (pocket)						
6.	1" NH3/N2 Vent Tool – M	1F98596-1	□ 1" NH3/N2 Vent Tool – M (pocket)						
7.	1/4" NH3/N2 Vent Tool – F	1F98592-1	□ 1/4" NH3/N2 Vent Tool – F (pocket)						
8.	Vent Tool Adapters (2)	SEG33119079-301	☐ One VTA goes in the 3/4" & 1" QRT & FID Gauge pouch; the other goes in the 1.5"						
			QRT & FID Gauge pouch						
			□ Each VTA must be tethered inside the bag using 1 adj tether for each						
			□ See picture B						
9.	1/4" BDT	SEG33114984-301	□ Stowed on top of 1/4" Vent Tool						
			☐ Must be tethered to inside of bag using 1 adj						
			□ See picture A						
10.	3/4" BDT	SEG33114986-301	□ Stowed on top of 1/4" Vent Tool, tethers to bag internal loops using BDT integral tether						
			□ See picture A						
11.	3/4" AKT	SEG33114983-301	□ Stowed with vent tool adapters in QRT & FID pouches						
			Must be tethered to inside of bag using 1 adj						
			□ See picture A						

3/4" BDT is tethered to internal bag loop using integral tool tether

3/4" AKT stowed with VTAs in QRT & FID pouch

1/4" and 3/4" BDTs are stowed on top of 1/4" vent tool



PICTURE A: BDT AND AKT STOWAGE



PICTURE B: VENT TOOL ADAPTER STOWAGE



Port QD Bag launch config with insert peeled back



Port QD Bag with insert re-attached to bag wall

FS 8-15 EVA/116/FIN

VTE BAG AND PUMP MODULE JUMPER BAG PACK

- 1. Retrieve "VTE BAG" (VTEB 01) from temp stow area
- 2. Retrieve "Pump Module Jumper Bag" (VTEB 02) from temp stow area
- 3. Retrieve the 1-in NH3/N2 Vent Tool F (1F98589-1) from the 1.0 CTB
- 4. Retrieve MUT EE from INC 14 pre-packed "PORT QD BAG & VTE BAG"
- 5. Perform photo closeout of internal stowage of both bags when complete

VTE BAG PACK

- 1. Remove VTE from VTE Bag
- 2. Perform visual check that 1-in vent tool nozzle will protrude past VTE internal seals:
 - □ Hold vent tool nozzle against VTE external alignment groove (vent tool hook should contact VTE connector)
 - □ √Nozzle tip is past thin black alignment line
- 3. Install 1-in vent tool nozzle into VTE connector via the following steps:
 - □ Rotate lock lever to unlock (hard stop detent very loose)
 - □ Depress lever to hard stop (2-10 lb)
 - ☐ Insert vent tool nozzle into connector tube (vent tool hook will contact front of connector, go to hard stop)
 - □ Release lever and rotate lock
- 4. Install MUT EE onto VTE nozzle 90 degree bracket ECOM fitting
- 5. Install 1-in vent tool and VTE inside VTE bag, install internal Velcro straps and tethers
- 6. Close bag lid



VTE Seal Check





Vent tool & VTE Installed in VTE Bag



Vent tool & VTE Installed in VTE Bag – pouch view

PM JUMPER BAG PACK

- 1. Open Pump Module Jumper bag lid
- 2. Verify Pump Module Jumper tethered inside bag using integral hooks
- 3. Close bag lid

FS 8-16 EVA/116/FIN

EMU EQUIPMENT SORTED BY ITEM

ITEM	LOCATION	QTY	S/N
3/8 Drive Ratchet w/7/16 Socket	EVA Airlock Accessory Bag (Shuttle) 1014	1	108
Arm Sizing Ring Protective Pouch (0.5")	EMU 3018 (Fg/W)	1	100
Bends Treatment Adapter (BTA)	MF43K	1	1003
Boots (pr) – (W)	EXT A/L Floor Bag	1	203
BSC Contingency Tool	EMU Equip Bag Assy	1	5015
Comfort Gloves – custom (pr)	ECOK (Fg)	2	0010
Comfort Gloves – Spectra (-04) (pr)	ECOK (W)	4	
Comfort Gloves – Spectra (-08) (pr)	ECOK (W)	4	
Comfort Gloves – Spectra (pr)	ECOK (Cr)	3	
Comm Cap Assy (CCA) – (Cr prime & b/u)	EMU 3003 (Cr)	2	1166 (pr)
(6. p 6. p		-	1165(b/u)
Comm Cap Assy (CCA) – (Fg prime)	EMU 3018 (Fg/W)	1	1203
Comm Cap Assy (CCA) – (W prime)	EXT A/L Floor Bag	1	1194
Contaminant Control Cartridge (CCC), EMU LiOH	EMU 3003 (Cr)	1	2024
Sometiment Some Section Section 3	EMU 3018 (Fg/W)	1	2025
	EXT A/L Floor Bag	2	2018
	EXT /VET 1001 Bag	_	2019
	MD CEIL (PORT 1)	6	2014
	mb sele (i sixi i)		2016
			2020
			2021
			2022
			2023
Contamination Detection Kit (CDK)	MD FLOOR (STBD 1)	1	1002
Crewlock DEPRESS/REPRESS Cue Card	MF57H	2	
Crewlock DEPRESS/REPRESS Without IV Cue Card	MF57H	1	
Croakie (MOD)	ECOK (Fg)	2	
Disposable In-Suit Drink Bags (DIDB)	EXT A/L Floor Bag	1	
	EMU 3003 (Cr)	3	
	EMU 3018 (Fg/W)	2	
	MD CEIL (STBD 2)	6	
	MF57C	6	
Disposable In-Suit Drink Bags (DIDB) Restraint	EMU 3003 (Cr)	1	
Bag	EMU 3018 (Fg/W)	1	
EMU – 3003	Ext A/L Starboard	1	3003
EMU – 3018	Ext A/L Port	1	3018
EMU 3-Micron Filter	EXT A/L Floor Bag	3	1026
			1027
			1028
EMU Battery (ICB)	EMU 3003 (Cr)	1	2057
	EMU 3018 (Fg/W)	1	2058
	EXT A/L Floor Bag	1	2061
EMU Battery (ICB) Charger	EXT A/L Floor Bag	1	1001
EMU Equip Bag Crew Specific Compartment	Volume H, OTBD	2	1033
	,		1038
EMU Equip Bag Trash Bag	EMU Equip Bag Assy	1	1036
EMU Equip Bag Trash Liner	EMU Equip Bag Assy	5	
EMU Equipment Bag Assy	Volume H, INBD	1	1031
EMU Helmet/EVVA	EMU 3003 (Cr)	1	1061
	EMU 3018 (Fg/W)	1	1063
EMU Mirror Assy	EMU 3003 (Cr)	2	1009
·		<u> </u>	1013
	EMU 3018 (Fg/W)	2	5011
			5028
EMU Servicing Kit	Volume H, INBD	1	5002
EMU Water Processing Kit	MD FLOOR (STBD 1)	1	
EVA Adjustable Wrench	EVA Airlock Accessory Bag (Shuttle) 1015	1	116
EVA Airland Annanam Day (Chuttle)	= tritrimiteit ricesessi j = ag (eriatas)		4044
EVA Airlock Accessory Bag (Shuttle)	Volume H, OTBD	1	1014
EVA Alriock Accessory Bag (Snuttle) EVA Crew Options Kit (ECOK) – (Cr)		1	1014
	Volume H, OTBD		1014

EMU EQUIPMENT SORTED BY ITEM (Cont)

ITEM	LOCATION	QTY	S/N
EVA Cuff Checklist – ISS (or located in MF71G)	MF57H	3	
EVA Cuff Checklist – STS	MF57H	3	
EVA PREBREATHE Cue Card	MF57H	2	
Fresnel Lens (-005)	ECOK (W)	1	
Fresnel Lens (-015)	ECOK (Fg)	1	
Gloves (pr) – (Cr & Fg b/u)	MD CEIL (STBD 1)	2	6207 6209
Gloves (pr) – (Cr prime)	EMU 3003 (Cr)	1	6238
Gloves (pr) – (Fg prime)	EMU 3018 (Fg/W)	1	6197
Gloves (pr) – (W prime & b/u))	EXT A/L Floor Bag	2	6047 6046
Helmet Light (EHIP)	Volume H, INBD	1	
	Volume H, OTBD	1	
Helmet Light (EHIP) Battery Pack	Volume H, INBD	2	
, ,	Volume H, OTBD	2	
ISS CSA-O2 Resupply Kit	MD FLOOR (STBD 1)	1	
ISS EVA Systems Checklist	MF57H	3	
LCVG (Cr b/u & Fg b/u)	MD CEIL (STBD 1)	2	3204
	<u>, , , , , , , , , , , , , , , , , , , </u>		3137
LCVG w/Biomed Hdwr – (Cr prime)	EMU 3003 (Cr)	1	3132
LCVG w/Biomed Hdwr – (Fg prime)	EMU 3018 (Fg/W)	1	3196
LCVG w/Biomed Hdwr – (W prime)	EXT A/L Floor Bag	1	3141
Leg Sizing Ring Protective Pouch (1.5")	EXT A/L Floor Bag	1	
Lower Arm – (Sw)	Spacehab	2	213
			214
Lower Torso Assembly (LTA)	EMU 3003 (Cr)	1	2041
	EMU 3018 (Fg/W)	1	2057
LTA Donning Handle (pr)	EMU Equip Bag Assy	1	131 134
LTA Restraint Bag	EMU 3003 (Cr)	1	1012
	EMU 3018 (Fg/W)	1	1013
Maximum Absorption Garment (MAG)	ECOK (Cr)	11	
	ECOK (Fg)	9	
	ECOK (W)	10	
Moleskin	ECOK (Fg)	24	
MWC Flight Cover Jumper (Cooling Loop Jumper)	EMU Equip Bag Assy	2	046 044
PGT/EHIP Y-Power Charger Cable	EXT A/L Floor Bag	1	1024
SAFER (includes 1 pair of latch guards)	Spacehab	1	1006
SAFER Hand Controller Mount (DCM Plug)	EXT A/L Floor Bag	1	00006
SAFER Latch Guard, Port	EXT A/L Floor Bag	2	
	SAFER 1006	1	
SAFER Latch Guard, Starboard	EXT A/L Floor Bag	2	
	SAFER 1007	1	
Scissors	EMU Equip Bag Assy	1	
Scissors with tether	EMU 3003 (Cr)	1	
	EMU 3018 (Fg/W)	1	
Sock Liners, Thermax (pr)	ECOK (Cr)	3	
Socks, Thermal Woodsman (pr)	ECOK (W)	1	
Socks, Tube (pr)	ECOK (Fg)	2	
00000	ECOK (W)	4	1000
SOP Checkout Fixture (SCOF)	EMU Equip Bag Assy	2	1009 1010
STS EVA Checklist	MF57H	3	
STS-116 LOGISTICS Cue Card	MF57H	1	
Thermal Comfort Undergarment (TCU-top &	ECOK (Cr)	3	
bottom)	ECOK (Fg)	2	
Wristlets (pr)	ECOK (W) ECOK (Cr)	3	
πιοιοίο (ρι)	ECOK (Cr)	2	
1	ECOK (W)	4	

EMU EQUIPMENT SORTED BY LOCATION

LOCATION	ITEM	QTY	S/N
ECOK (Cr)	Comfort Gloves – Spectra (pr)	3	
	Maximum Absorption Garment (MAG)	11	
	Sock Liners, Thermax (pr)	3	
	Thermal Comfort Undergarment (TCU-top & bottom)	3	
	Wristlets (pr)	3	
ECOK (Fg)	Comfort Gloves – custom (pr)	2	
	Croakie (MOD)	2	
	Fresnel Lens (-015)	1	
	Maximum Absorption Garment (MAG)	9	
	Moleskin	24	
	Socks, Tube (pr)	2	
	Thermal Comfort Undergarment (TCU-top & bottom)	2	
FCOK (M)	Wristlets (pr)	2	
ECOK (W)	Comfort Gloves – Spectra (-04) (pr)	4	
	Comfort Gloves – Spectra (-08) (pr) Fresnel Lens (-005)		
	Maximum Absorption Garment (MAG)	10	
		10	
	Socks, Thermal Woodsman (pr) Socks, Tube (pr)	4	
	Thermal Comfort Undergarment (TCU-top & bottom)	4	
	Wristlets (pr)	4	
EMU 3003 (Cr)	Comm Cap Assy (CCA) – (Cr prime & b/u)	2	1166 (pr)
LWO 3003 (CI)	Commit Cap Assy (CCA) – (Or prime & brd)		1165(b/u)
	Contaminant Control Cartridge (CCC), EMU LiOH	1	2024
	Disposable In-Suit Drink Bags (DIDB)	3	
	Disposable In-Suit Drink Bags (DIDB) Restraint Bag	1	
	EMU Battery (ICB)	1	2057
	EMU Helmet/EVVA	1	1061
	EMU Mirror Assy	2	1009
			1013
	EVA Crew Options Kit (ECOK) – (Cr)	1	
	Gloves (pr) – (Cr prime)	1	6238
	LCVG w/ Biomed Hdwr – (Cr prime)	1	3132
	Lower Torso Assembly (LTA)	1	2041
	LTA Restraint Bag	1	1012
	Scissors with tether	1	
EMU 3018 (Fg/W)	Arm Sizing Ring Protective Pouch (0.5")	1	
	Comm Cap Assy (CCA) – (Fg prime)	1	1203
	Contaminant Control Cartridge (CCC), EMU LiOH	1	2025
	Disposable In-Suit Drink Bags (DIDB)	2	
	Disposable In-Suit Drink Bags (DIDB) Restraint Bag	1	
	EMU Battery (ICB)	1	2058
	EMU Helmet/EVVA	1	1063
	EMU Mirror Assy	2	5011 5028
	EVA Crew Options Kit (ECOK) – (Fg)	1	5020
	Gloves (pr) – (Fg prime)	1	6197
	LCVG w/ Biomed Hdwr – (Fg prime)	1	3196
	Lower Torso Assembly (LTA)	1	2057
	LTA Restraint Bag	1	1013
	Scissors with tether	1	1010
EMU Equip Bag Assy	BSC Contingency Tool	1	5015
5 _qa.p 5ag / 60j	EMU Equip Bag Trash Bag	1	1036
	EMU Equip Bag Trash Liner	5	.500
	LTA Donning Handle (pr)	1	131
	MWC Flight Cover Jumper (Cooling Loop Jumper)	2	134 046 044
	Scissors	1	UTT
	SOP Checkout Fixture (SCOF)	2	1009
	oo onomat intaio (oooi)	-	1010

EMU EQUIPMENT SORTED BY LOCATION (Cont)

Ext Al. Port	LOCATION	ITEM	QTY	S/N
Bools (pr) – (W)			1	3018
Comm Cap Assy (CCA) – (W prime)	Ext A/L Starboard		1	3003
Comm Cap Assy (CCA) – (W prime)	EXT A/L Floor Bag	Boots (pr) – (W)	1	203
EMU Battery (ICB)	•		1	1194
EMU Battery (ICB)		EMU 3-Micron Filter	3	1026
EMU Battery (ICB)				
EMU Battery (ICB) Charger				1028
EMU Battery (ICB) Charger		EMU Battery (ICB)	1	2061
EVA Crew Options Kit (ECOK) - (W)				
Contaminant Control Cartridge (CCC), EMU LiOH 2 2018 2019				
Disposable In-Suit Drink Bag (DIDB) 1				2018
Disposable In-Suit Drink Bag (DIDB)		Somethinant Someth Saturage (SSS), Elite Elem	_	
Gloves (pr) - (W prime & blu) 2 6046		Disposable In-Suit Drink Bag (DIDB)	1	2010
CVG w/ Biomed Hdwr - (W prime)				6047
LCVG W/ Biomed Hdwr - (W prime)		Gloves (pr) = (vv prime & b/u))		
Leg Sizing Ring Protective Pouch (1.5") 1		LCVC w/ Pigmod Hdwr (W primo)	1	
PGT/EHIP Y-Power Charger Cable		Log Ciring Ding Protective Develop (4.5")		3141
SAFER Hand Controller Mount (DCM Plug)				1004
SAFER Latch Guard, Port 2 2 2 2 2 2 2 2 2				
SAFER Latch Guard, Starboard 2				00006
MD CEIL (PORT 1) Contaminant Control Cartridge (CCC), EMU LiOH 2014 2016 2020 2021 2022 2023 2022 2023 2023 2024 2022 2023 2024 2022 2023 2024 2022 2023 2024 2025 2026 202				
MD CEIL (STBD 1) Gloves (pr) – (Cr & Fg b/u) 2 6207 2022 2023				
MD CEIL (STBD 1) Gloves (pr) - (Cr & Fg b/u) 2 6207 6209	MD CEIL (PORT 1)	Contaminant Control Cartridge (CCC), EMU LiOH	6	
MD CEIL (STBD 1)				
MD CEIL (STBD 1)				
MD CEIL (STBD 1) Gloves (pr) – (Cr & Fg b/u) 2 6207 6209				
MD CEIL (STBD 1) Gloves (pr) – (Cr & Fg b/u) 2 6207 6209				
LCVG (Cr b/u & Fg b/u) 2 3204				
LCVG (Cr b/u & Fg b/u) 2 3204 3137	MD CEIL (STBD 1)	Gloves (pr) – (Cr & Fg b/u)	2	
MD CEIL (STBD 2)				6209
MD CEIL (STBD 2)		LCVG (Cr b/u & Fg b/u)	2	3204
MD FLOOR (STBD 1)				3137
MD FLOOR (STBD 1)	MD CEIL (STBD 2)	Disposable In-Suit Drink Bags (DIDB)	6	
EMU Water Processing Kit	MD FLOOR (STBD 1)		1	1002
ISS CSA-02 Resupply Kit	,		1	
MF43K Bends Treatment Adapter (BTA) 1 1003			1	
MF57C	MF43K			1003
Crewlock DEPRESS/REPRESS Cue Card 2 Crewlock DEPRESS/REPRESS Without IV Cue Card 1 EVA Cuff Checklist – ISS (or located in MF71G) 3 EVA Cuff Checklist – ISS (or located in MF71G) 3 EVA Cuff Checklist – STS 3 EVA PREBREATHE Cue Card 2 ISS EVA Systems Checklist 3 STS EVA PREBREATHE Cue Card 1 EVA Cuff Checklist 3 STS EVA Checklist 1 1 EVA Cuff Checklist – ISS (or located in MF57H) 3 3 8 Drive Ratchet w/7/16 Socket 1 108 EVA Adjustable Wrench 1 116 EVA Adjustable Wrench 1 116 SAFER Latch Guard, Port 1 SAFER Latch Guard, Port 1 SAFER Latch Guard, Starboard 1 SAFER Latch Guard, Starboard 1 SAFER (includes 1 pair of latch guards) 1 1006 EMU Equipment Bag Assy 1 1031 EMU Servicing Kit 1 5002 EMU Servicing Kit 1 5002 EMU Servicing Kit 1 1031 EMU Servicing Kit 1 1031 EMU Equip Bag Crew Specific Compartment 2 1033 1038 EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1 1 1014 Helmet Light (EHIP) 1 1 1 1 1 1 1 1 1				1000
Crewlock DEPRESS/REPRESS Without IV Cue Card 1 EVA Cuff Checklist - ISS (or located in MF71G) 3 EVA Cuff Checklist - ISS (or located in MF71G) 3 EVA Cuff Checklist - STS 3 EVA PREBREATHE Cue Card 2 ISS EVA Systems Checklist 3 STS EVA Checklist 5 STS EVA Checklist		Crewlock DEPRESS/REPRESS Cue Card		
EVA Cuff Checklist – ISS (or located in MF71G) 3	WII 3711			
EVA Cuff Checklist - STS		E) / A O : # Ob a ablicat 100 / a a base ablica ME740)		
ISS EVA Systems Checklist 3 3 3 3 3 3 3 3 3		EVA Cuff Checklist – STS		
STS EVA Ćhecklist STS-116 LOGISTICS Cue Card 1		EVA PREBREATHE Cue Card		
STS-116 LOGISTICS Cue Card 1		ISS EVA Systems Checklist		
BVA Airlock Accessory Bag (Shuttle) 1014 3/8 Drive Ratchet w/7/16 Socket 1 108				
SAFER 1006 SAFER Latch Guard, Port 1 108	MEZAO			
EVA Adjustable Wrench				100
SAFER 1006 SAFER Latch Guard, Port 1 SAFER Latch Guard, Starboard 1 SAFER Latch Guard, Starboard 1 SAFER Latch Guard, Starboard 1 213 214 SAFER (includes 1 pair of latch guards) 1 1006	EVA Alliock accessory Bag (Snuttle) 1014	S/O DIIVE Kalchet W///10 SOCKET		
SAFER Latch Guard, Starboard 1	SAFER 1006			110
Lower Arm - (Sw) 2 213 214	0/11 ETC 1000			
214 SAFER (includes 1 pair of latch guards) 1 1006 Volume H, INBD EMU Equipment Bag Assy 1 1031 EMU Servicing Kit 1 5002 Helmet Light (EHIP) 1 Helmet Light (EHIP) Battery Pack 2 Volume H, OTBD EMU Equip Bag Crew Specific Compartment 2 1033 EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1	Spacehab			213
SAFER (includes 1 pair of latch guards) 1 1006	- h	, ,	-	214
Volume H, INBD EMU Equipment Bag Assy 1 1031 EMU Servicing Kit 1 5002 Helmet Light (EHIP) 1 Helmet Light (EHIP) Battery Pack 2 Volume H, OTBD EMU Equip Bag Crew Specific Compartment 2 1033 EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1 1			1	1006
Helmet Light (EHIP)	Volume H, INBD	EMU Equipment Bag Assy		
Helmet Light (EHIP) Battery Pack 2		EMU Servicing Kit		
Volume H, OTBD EMU Equip Bag Crew Specific Compartment 2 1033 1038 EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1		Helmet Light (EHIP)		· · · · · · · · · · · · · · · · · · ·
EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1				
EVA Airlock Accessory Bag (Shuttle) 1 1014 Helmet Light (EHIP) 1	Volume H, OTBD	EMU Equip Bag Crew Specific Compartment	2	
Helmet Light (EHIP) 1		EVA Airlook Accessory Dog (Chuttle)	1	1038
Helmet Light (EUID) Pattery Pools				1014
		Helmet Light (EHIP) Helmet Light (EHIP) Battery Pack	2	

ITEM	COMMENT	UP	DN	LOCATION
3 Point Latch Tool	sn 1003, 1007	2	2	PLB TSA port
35 mm Camera Mounting Bracket	sn 1003,1008	2	0	SHAB SF21 (3.0 CTB)
5/32 in short Ball End Allen Driver	TPS RCC plug sn 1012	1	1	MDK Bag, Ceil Stbd 1, "G"
Adjustable Grapple Bar Assembly		1	0	SHAB SF13
Adjustable Thermal Mitten (in caddy)	sn 007	2	2	PLB TSA port, fwd tray
Adjustable Thermal Mitten (in caddy)	sn 018	2	2	PLB TSA port, fwd tray
Bag, 3 Point Latch Tool Stowage	sn HG3-366	1	1	PLB TSA port
Bag, Centerline Latch Tool	sn HF9-046A	1	1	PLB TSA port
Bag, CIPAA Containment	sn 1001	1	1	MDK MF28E/G
Bag, Crack Repair Outer Bag Assy, Crack Repair Bag Crack Repair Bag Assy ETS Module, Crack Repair Bag Inner Bag Assy, Crack Repair Bag	sn (all parts, 1004)	1	1	MDK Bag, Ceil Stbd 2, "H"
Bag, EVA Accessory (EVA Airlock Access Bag)	sn 1014	1	1	MDK Vol H, OBD
Bag, EVA Trash	sn 1005	1	1	PLB TSA port, fwd tray
Bag, Jettison Stowage – EVA 2/3 Shuttle to ISS		1	2	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – EVA 1 Shuttle to ISS		1		SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – EV1		1	1	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – EV2		1	1	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – Return to Shuttle 1, 2, 3		3	3	SHAB AP01 (5 MLE Bag)
Bag, Port QD	sn 1001 (Port written above label by crew)	1	0	SHAB AP01 (5 MLE Bag)
Bag, Pump Module Jumper (VTEB 02)	sn 1002	1	0	SHAB AS01 (5 MLE Bag)
Bag, Torque Wrench	sn 1001	1	0	SHAB AP07 (3.0 CTB)
Bag, EVA Large Trash	TPS sn 1009	1	1	MDK Bag, ceil port 1, "E"
Bag, Vent Tool Extension	sn 1001	1	1	SHAB AS01 (5 MLE Bag)
Body Restraint Tether (BRT)	sn TBD001	1	1	MDK Bag, Ceil Port 1, "E"
Bolt Puller	sn 102	1	1	PLB TSA port, fwd tray
Bolt Puller/Vise Grip Pliers Tool Caddy	sn 102	1	1	PLB TSA port, fwd tray
Brush Assembly, 1 inch (Sylgard)	TPS	9	9	MDK Bag, Ceil Stbd 1, "G"; in Gel Brush Kit
Brush Assembly, 1 inch (Sylgard)	TPS	4	4	MDK Bag, Ceil Stbd 1, "G"; in 1/2 Gel Br Kt
Brush Assembly, 3 inch (Sylgard)	TPS	9	9	MDK Bag, Ceil Stbd 1, "G"; in Gel Brush Kit
Brush Assembly, 3 inch (Sylgard)	TPS	4	4	MDK Bag, Ceil Stbd 1, "G"; in 1/2 Gel Br Kt
Brush Assembly, Pencil Tip (Sylgard)	TPS	3	3	MDK Bag, Ceil Stbd 1, "G"; in Gel Brush Kit
Brush Assembly, Pencil Tip (Sylgard)	TPS	3	3	MDK Bag, Ceil Stbd 1, "G"; in 1/2 Gel Br Kt
Brush Handle Assembly	TPS	1	1	MDK Bag, Ceil Port 1, "E"; Part of EWAK
Brush Handle Assembly	TPS	1	1	MDK Bag, Ceil Port 1, "E"; Part of EWAK
Brush Handle Assembly	TPS	1	1	MDK Bag, Ceil Stbd 1, "G"; in Gel Brush Kit

ITEM	COMMENT	UP	DN	LOCATION
				MDK Bag, Ceil Stbd 1, "G"; in
Brush Handle Assembly	TPS	1	1	1/2 Gel Br Kt
Caddy, 1/2 in. Box Ratchet Tool	sn 108	1	1	PLB TSA port, aft tray
Caddy, Compund Cutter/Needle Nose	100			DID TO A month of continuous
Pliers Tool	sn 108	1	1	PLB TSA port, fwd tray
Caddy, Emittance Wash Applicator	TPS sn 1002	1	1	MDK Bag, Ceil Port 1, "E";
Caddy, Emittance Wash Applicator	TPS sn 1003	1	1	MDK Bag, Ceil Port 1, "E";
Caddy, EVA Adjustable Wrench/4 in Ratchet Ext. Tool	sn 102	1	1	PLB TSA port, fwd tray
Natchet Ext. 1001	sn 1002 (for Adjustable	'	'	LD 13A port, Iwa tray
Caddy, General Purpose Tool (GP Tool	Thermal Mittens			
Caddy)	sn007)	1	1	PLT TSA port, fwd tray
	sn 1013 (for Adjustable			
Caddy, General Purpose Tool (GP Tool	Thermal Mittens			
Caddy)	sn018)	1	1	PLT TSA port, fwd tray
Caddy, General Purpose Tool (GP tool	Cn 1002	4	4	MDK VALH OPD
caddy) Caddy, Hammer/Chisel Long Probe Tool	Sn 1003 sn 107	1	1	MDK Vol H, OBD PLB TSA port, fwd tray
Caddy, MWS Tool Stowage (Broom clip	SII 107	1	1	PLB TSA port, Iwa tray
caddy)	TPS sn 1002	1	1	MDK Bag, ceil port 1, "E"
Caddy, PDU Disc/Loop Pin Puller Tool	sn 104	1	1	PLB TSA port, fwd tray
Caddy, Prybar/EVA Forceps Tool	sn 106	1	1	PLB TSA port, aft tray
Caddy, Radiator Extension/Drive Ratchet	011 100		i i	1 25 107 (port, air day
Tool	sn 107	1	1	PLB TSA port, aft tray
	sn 1017,1022,1023,			
Caddy, Tool	1076, 5009,5041,5042,	7	7	PLB TSA port
				PLB TSA port, fwd tray;
Caddy Valera/Tana	on 1010: 1010	2	1	SHAB FC02 (1.0 CTB) - EVA
Caddy, Velcro/Tape	sn 1010; 1019 sn 107	1	1	replaces
Chisel-Long Probe CIPAA Sack Assy (TRAD Sack)	No serial #s	2	2	PLB TSA port, fwd tray MDK MF28E/G
Compund Cutter (Small Cutter)	sn 1009	1	1	
Contamination Detection Kit	sn 1009	1	1	PLB TSA port, fwd tray MDK Bag, Floor Stbd 1, "C"
		2	0	SHAB FP04 (0.5 CTB)
Cover Assembly, Flap (1) Cover Assembly, Flap (1/2)	sn N/A1,N/A2 sn N/A1,N/A2	2	0	
		2	0	,
Cover Assembly, Flap (3/4) Crack Repair Gun Cartridge (Manual)	sn N/A1,N/A2 TBD	2	2	SHAB FP04 (0.5 CTB)
Crack Repair Gun Cartridge (Manual) Crack Repair Gun, Manual (w/thermal	עמו			MDK MA9D
cover)	TPS sn 1008,1009	2	2	MDK Bag, Ceil Stbd 1, "G"
Crack Repair Palette Assy	TPS sn 1003, 1006	2	2	MDK Bag, Ceil Stbd 1, "G"
Oracic repair raiotte ricey	11 0 011 1000, 1000	_	_	MDK Bag, Ceil Port 1, "E";
Emittance Wash Applicator	TPS sn XXXX in kit X	1	1	Part of EWAK
				MDK Bag, Ceil Port 1, "E";
Emittance Wash Applicator	TPS sn XXXX in kit X	1	1	Part of EWAK
ET Umbilical Door Tool	sn 1004	1	1	PLB TSA port, fwd tray
ETVCG Assembly	sn N/A1	1	0	SHAB PF01
				MDK Bag, Ceil Port 1, "E";
		6	6	Part of EWA Kits
EVA Wipe	TPS sn 1001-1005	5	5	MDK Bag, Ceil Stbd 1, "G"
Flow Shut Off Valve Assy	TPS sn 1010,1009	2	2	MDK Bag, Ceil Stbd 1, "G"
Fluid Leak Indicator (FLI)	sn 1003,1004	2	0	SHAB AS01 (5 MLE Bag)
Foom Drugh Hood Access 4 Street	TDC on VVVV	_		MDK Bag, Ceil Port 1, "E";
Foam Brush Head Assy, 1 inch	TPS sn XXXX	1	1	Part of EWAK

Foam Brush Head Assy, 1 inch	TPS sn XXXX	1		MDK Bag, Ceil Port 1, "E";
Foam Brush Head Assy, 1 inch	TPS sn XXXX	1		
	<u> </u>	1	1	Part of EWAK
	TD0 \\000\\000\\	_	_	MDK Bag, Ceil Stbd 1, "G"; in
Foam Brush Head Assy, 1 inch	TPS sn XXXX-XXXX	5	5	1/2 Gel Br Kt
Foom Pruch Hood Apply 2 inch	TPS sn XXXX-XXXX	5	5	MDK Bag, Ceil Stbd 1, "G"; in 1/2 Gel Br Kt
Foam Brush Head Assy, 3 inch	sn 106	1	1	PLB TSA port, aft tray
Forceps	511 100	1	1	SHAB AC01 (1.0 CTB)
				(labeled "short," "short,"
Gap Spanner (orbit installed, 18-21")	No serial #s	3	0	"medium")
				SHAB AC01 (1.0 CTB)
Gap Spanner (orbit installed, 21-30")	No serial #s	1	0	(labeled "long-303")
Gel Brush Kit (1/2 gel, 1/2 foam)	TPS sn 1005	1	1	MDK Bag, Ceil Stbd 1, "G"
Gel Brush Kit (Full Gel)	TPS sn 1001	1	1	MDK Bag, Ceil Stbd 1, "G"
General Purpose Cutter	sn 1010	1	1	PLB TSA port, fwd tray
Hammer	sn 103	1	1	PLB TSA port, fwd tray
Loop Pin Extractor Puller	sn 107	1	1	PLB TSA port, fwd tray
Modular Mini-Workstation Key Strap				-
Assembly	sn 1006	1	1	MDK Bag, Ext A/L Floor
Madalar MANO Dagarlata Assa	4004 4000			MDK Bag, Ext A/L Floor; w/
Modular MWS Baseplate Assy	sn 1001,1003	2	2	gimbal assy
Modular MWS Gimbal Assy	sn 1006,1029	2	2	MDK Bag, Ext A/L Floor; w/baseplates
Modular MWS LH Swingarm Assy	sn 1011,1012,1013	3	0	SHAB SF21 (3.0 CTB)
Wodular WWS Err Swingarin Assy	511 1011, 1012, 1013	3	U	SHAB SF21 (3.0 CTB); MDK
Modular MWS RH Swingarm Assy	sn 1002	1	0	Bag, Ceil Port 1, "E"
Modular MWS Retracting End Effector				
□ Reel housing				
□ Hook	sn 1005,1013	1	0	SHAB SF21 (3.0 CTB)
MPM Ratchet Wrench	sn 1005	1	1	PLB TSA port, fwd tray
Needle Nose Pliers	sn 1003	1	1	PLB TSA port, fwd tray
Payload Retention Device (PRD)	sn 1006, 1016	2	2	PLB TSA port, aft tray
PB Articulating Socket	sn 1010	1	1	PLB TSA port
PDU Disconnect Tool	sn 104	1	1	PLB TSA port, fwd tray
PFR	sn 4001	1	1	PLB Blkhd Fwd
PFR Attachment Device (PAD, unpainted)	sn 1008	1	1	PLB TSA port
	sn 1004, 1005,1008			
Pistol Grip Tool (ISS Power Tool)	(# 1, #5, #8)	3	0	SHAB FC02 (1), PF25 (2)
PGT Program Cable RS422	sn 1003,1004	2	0	SHAB TBD
Pry Bar	sn 106	1	1	PLB TSA port, aft tray
Donne Madala Lorenza	04		_	SHAB AS01 (5 MLE Bag); in
Pump Module Jumper	sn 01	1	0	VTE Bag sn 1002
Punch Tool Assy, EVA	sn 1004	1	1	MDK Bag, Ceil Stbd 1, "G"
QD Anti-Kickback Tool (ATK) Assy, 0.75"	sn 1001,1002	2	0	SHAB ACO1 (1.0 CTB)
QD Button Depress Tool, 0.25"	sn 1001, 1002	2	0	SHAB AC01 (1.0 CTB), SHAB FP08 (1.0 CTB)
QD Button Depress Tool, 0.75"	sn 1002,1003	2	0	SHAB AC01 (1.0 CTB)
QD Trainer Assembly (housing with male	511 1002,1000			
QDs)	sn 1001	1	0	SHAB FP08 (1.0 CTB)
,	sn 1001	1	0	SHAB FP08 (1.0 CTB)
QD Trainer (3/4" female QD)	311 100 1			
QD Trainer (3/4" female QD) QD Trainer (1.5" female QD)	sn 1002	1	0	SHAB FP08 (1.0 CTB)

ITEM	COMMENT	UP	DN	LOCATION
RCC CRM Scraper, 5" wide (in ziplock bag)	TPS sn 1016,1017	2	2	MDK Bag, Ceil Stbd 1, "G"
RMS Shoulder Brace Release Hand Tool	sn 301	1	1	PLB TSA port, aft tray
Ruler and Protuberance Gauge	sn 1001	1	1	MDK Bag, Ceil Stbd 1, "G"
S0 Channel 1/4 Power Cable	sn N/A1	1	0	SHAB FC07 (1.0 CTB)
S0 Channel 2/3 Power Cable	sn N/A1	1	0	SHAB FC07 (1.0 CTB)
S0/N1 EVA SM PRI PWR Cable	sn TBD001	1	0	SHAB FC07 (1.0 CTB)
SPD, 1.0"	sn 1022-1025	4	0	SHAB FP08 (1.0 CTB)
•				` '
SPD, 1.0" (QD Trainer Assembly)	sn 1003	1	0	SHAB FP08 (1.0 CTB)
SPD, 1.5" (QD Trainer Assembly)	sn 1004	1	0	SHAB FP08 (1.0 CTB)
Seal Assy – Fluid Line Anchor Patch 0.25	am NI/A4 NI/AO	2	_	CLIAD EDO4 (0.5 CTD)
in OD (0.25 in Flap) Seal Assy – Fluid Line Anchor Patch 0.375	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
in OD (0.375 in Flap)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Seal Assy – Fluid Line Anchor Patch 1.5 in	311 IV/A 1,IV/AZ		U	SHABTT 04 (0.5 CTB)
OD (1.5 in Flap)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Snatch Block	sn 1013, 1014	2	2	PLB TSA port, aft tray
Socket Extension 6" w/7/16" Wobble	sn 1001	1	0	SHAB TBD
SSRMS FMS MLI Shrouds	sn 202,203	2	0	SHAB FP04 (0.5 CTB)
33KW3 FW3 WLI 31110uus	\$11 202,203		U	Ext A/L Floor Bag (qty 2);
	TBD 012-015; TBD			MDK Bag, Ceil Port 1, "E" (qty
Tether, Adjustable Equipment (Eq-Eq	023-026; sn			4); SHAB FC02 (1.0 CTB)
w/slide lock)	1019,1038, 1067,1068	10	6	(qty 4 - for QD bag)
Tether, Adjustable Equipment (Sm-Sm)	sn 1027, 1028	2	2	PLB TSA port, aft tray
Tether, Adjustable Fuse (Eq hooks w/slide	311 1021, 1020			TED TOA port, art tray
lock)	sn TBD008	1	1	MDK Bag, Ceil Port 1, "E"
Tether Extension	sn 1001	1	1	MDK Bag, Ceil Port 1, "E"
Tetrior Extension	Yellow tethers (8)	<u>'</u>	'	Wibit bag, cent of ti, E
	sn 4057,4070,4071,			
	4073,4075, 4170,4271,			
	4272; Blue tether (1)			
	sn 4272; Late			
	Inspection Black			SHAB AC01 (1.0 CTB) (qty
	Tethers (7) sn TBD;			8); SHAB AC01 (1.0 CTB)
	ISS Black tethers (3)			(qty 1); MDK Bag, Ceil Port 1,
Tether, Retractable Equipment (Eq-Eq	sn 4062, 4063, 4073	40	_	"E" (qty 7); External A/L Floor
w/slide lock) (-381)	Mallace table are as	19	7	Bag (qty 3)
Tether, Retractable Equipment (Eq-Eq/pip w/slide lock) (-383)	Yellow tethers sn 4238-4241	4	0	SHAB AC01 (1.0 CTB)
Tether, Retractable Equipment (Lg-Eq	Yellow tethers sn	4	U	SHAB ACOT (1.0 CTB)
w/slide lock) (-385)	4252-4257	6	0	SHAB AC01 (1.0 CTB)
Wishde lock) (-505)	sn 1005 (25),1007 (27)	-	0	GIABACOT (1.0 CTB)
Tether, 85' Safety (-307)	(Lg-sm)	1	1	MDK Bag, Ceil Stbd 2, "H"
realist, se ealety (ser)	sn 1033,1035,1048,	ľ		merceag, con casa 2, 11
	1058 (moved off			
Tether, Waist (w/slide lock)	EMUs)	4	4	MDK Bag, Ext A/L Floor
Thermal Sensor, EVA (w/ goose neck	,			-
probe)	TPS sn 1002	1	1	MDK Bag, Ceil Stbd 1, "G"
Tile Repair Ablator Assembly (TRAD)	sn 1001	1	1	MDK MF28E/G
Torque Wrench	sn 1001	1	0	SHAB AP07 (3.0 CTB)
Tube Cutter	sn 1006	1	1	PLB TSA port, fwd tray
Vent Tool Adapter	N/A	2	0	SHAB AP01 (5 MLE Bag)
Vent Tool Assy, 1/4" NH3/N2 - F	N/A	2	0	SHAB AP01 (5 MLE Bag)
Vent Tool Assy, 3/4" NH3/N2 - F	N/A	2	0	, ,
VEHL TOOLASSY, 3/4 INFI3/INZ - F	IN//1		U	SHAB AP01 (5 MLE Bag)

ITEM	COMMENT	UP	DN	LOCATION
Vent Tool Assy, 1.5" NH3/N2 - F	N/A	2	0	SHAB AP01 (5 MLE Bag)
	N/A			Middeck Floor Stbd 1 Bag (5
Vent Tool Assy, 1" NH3/N2 - F		1		MLE Bag)
Vent Tool H2O-N2, 1" - F	N/A	1	0	SHAB AP01 (5 MLE Bag)
Vent Tool, 1" N2-M	N/A	1	0	SHAB AP01 (5 MLE Bag)
Vent Tool Extender	sn 1001	1	0	SHAB AS01 (5 MLE Bag); in VTE Bag sn 1001
Vise Grip Pliers	sn 102	1	1	PLB TSA port, fwd tray
Winch and Mount Assy, Aft (w/4 ball pip pin)	sn 1004	1	1	PLB Blkhd Aft
Winch and Mount Assy, Fwd (w/4 ball pip	011 100 1	i i	•	. LD Billia / lit
pin)	sn 5006	1	1	PLB Blkhd Fwd
Winch Hook Adapter (RMS Rope Reel)	sn 1003	1	1	PLB TSA port
Wire Tie, Long (32")	N/A102-108,N/A110- 125,N/A127	24	0	SHAB TBD
Wire Tie, Short (16")	N/A12,13,16,18,148, 199,200, 201,202-217	24	0	SHAB TBD
Wrench, 1/2 in. box end	sn 103	1	1	PLB TSA port, aft tray
				MDK Vol H, OBD; PLB TSA
Wrench, Adjustable	sn 116; 103	2	2	port, fwd tray
Wrench, EVA Ratchet (palm wheel)	sn 1013	1	1	SHAB TBD
Wrench, 3/8" Ratchet with 2-in 7/16"				
pinned socket	sn 108	1	1	MDK Vol H, OBD
Wrench, Ratchet 4 in Extension, 7/16 in socket	sn 102	1	1	PLB TSA port, fwd tray
Wrench, Ratchet Radiator Extension, 3/8"	sn 107	1	1	PLB TSA port, aft tray

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Tether, Retractable Equipment (Eq-Eq w/slide lock)	sn 4062, 4063, 4073 (black RETs)	3	0	A/L External Floor Bag
Modular Mini-Workstation Key Strap Assembly	sn 1006	1	1	MDK Bag, Ext A/L Floor
Modular MWS Baseplate Assy Modular MWS Gimbal Assy	sn 1001, 1003 sn 1006, 1029	2 2	2 2	MDK Bag, Ext A/L Floor; w/ gimbal assy MDK Bag, Ext A/L Floor; w/baseplates
Tether, Adjustable Equipment (Eq-Eq w/slide lock)	sn 1019,1038	2	2	MDK Bag, Ext A/L Floor
Tether, Waist (w/slide lock) sn 1033,1035,1048, 1058	removed from EMU	4	4	MDK Bag, Ext A/L Floor
Bag, EVA Large Trash	TPS sn 1001	1	1	MDK Bag, Ceil Port 1, "E"
Caddy, MWS Tool Stowage (Broom clip caddy)	TPS sn 1002	1	1	MDK Bag, Ceil Port 1, "E"
Emittance Wash Applicator Caddy 1 in. Foam Brush Assy Brush Handle Assembly Emittance Wash Applicator EVA Wipes (3)	TPS sn 1002,1003	2 2 2 2 2 2	2 2 2 2 2	MDK Bag, Ceil Port 1, "E"
Modular MWS RH Swingarm Assy	1037,1039 (transfer)	2	2	MDK Bag, Ceil Port 1, "E"
Tether, Adjustable Equipment (Eq-Eq w/slide lock)	sn TBD012-015	4	4	MDK Bag, Ceil Port 1, "E"
Tether, Adjustable Fuse (Eq hooks w/slide lock)	sn TBD008	1	1	MDK Bag, Ceil Port 1, "E"
Tether, Body Restraint (BRT)	sn TBD001	1	1	MDK Bag, Ceil Port 1, "E"
Tether Extension	sn 1001	1	1	MDK Bag, Ceil Port 1, "E"
Tether, Retractable Equipment (Eq-Eq w/slide lock)	Late Inspection (-381) sn TBD	7	7	MDK Bag, Ceil Port 1, "E"
5/32 in short Ball End Allen Driver	TPS RCC plug sn 1012 (none on ISS)	1	1	MDK Bag, Ceil Stbd 1, "G"
Crack Repair Gun, Manual (w/thermal cover)	TPS sn 1008, 1009	2	2	MDK Bag, Ceil Stbd 1, "G"
Crack Repair Palette Assy	TPS sn 1003, 1006	2	2	MDK Bag, Ceil Stbd 1, "G"
Thermal Sensor, EVA (w/goose neck probe)	TPS sn 1002	1	1	MDK Bag, Ceil Stbd 1, "G"
EVA Wipe	TPS sn 1001-1005	5	5	MDK Bag, Ceil Stbd 1, "G"

FS 8-26 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Flow Shut Off Valve Assy	TPS sn 1010,1009	2	2	MDK Bag, Ceil Stbd 1, "G"
Gel Brush Kit (1/2 gel, 1/2 foam) 1 in. Foam Brush Assy (5) 1 in. Silicone Gel Brush (4) (Sylgard br) 3 in Silicone Gel Brush (4) (Sylgard br) Foam Brush Head Assy, 3" (5) Pencil Tip Gel Brush (3) (Sylgard br)	TPS sn 1005	1	1	MDK Bag, Ceil Stbd 1, "G"
Brush Handle Assembly Gel Brush Kit (Full Gel) 1 in. Silicone Gel Brush (9) (Sylgard br) 3 in Silicone Gel Brush (9) (Sylgard br) Pencil Tip Gel Brush (3) (Sylgard br) Brush Handle Assembly	TPS sn 1001	1	1	MDK Bag, Ceil Stbd 1, "G"
RCC CRM Scraper, 2" stiff (in ziplock bag)	TPS sn 1004-1007	4	4	MDK Bag, Ceil Stbd 1, "G"
RCC CRM Scraper, 5" wide (in ziplock bag)	TPS sn 1016,1017	2	2	MDK Bag, Ceil Stbd 1, "G"
Ruler and Protuberance Gauge	sn 1001	1	1	MDK Bag, Ceil Stbd 1, "G"
Punch Tool Assy, EVA	TPS sn 1004	1	1	MDK Bag, Ceil Stbd 1, "G"
Bag, Crack Repair Outer Bag Assy, Crack Repair Bag Crack Repair Bag Assy ETS Module, Crack Repair Bag Inner Bag Assy, Crack Repair Bag	TPS sn 1004	1	1	MDK Bag, Ceil Stbd 2, "H"
Tether, 85' Safety (-307)	sn 1005,1007 (Lg-sm)	2	2	MDK Bag, Ceil Stbd 2, "H"
Vent Tool Assy, 1" NH3/N2 – F	N/A	1	0	MDK Bag, Floor Stbd 1
Crack Repair Gun Cartridge (Manual)	sn N/A1,N/A2	2	2	MDK MA9D
Bag, CIPAA Containment	sn 1001	1	1	MDK MF28E/G
CIPAA Sack Assy (TRAD Sack)	No serial #s	2	2	MDK MF28E/G
Tile Repair Ablator Assembly (TRAD)	sn 1001	1	1	MDK MF28E/G

FS 8-27 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Volume H Container Assy, Inboard		1	1	MDK Vol H
EHIP Light	sn 1008			
EHIP Battery Pack Assy (2 up, 2 dn)	sn 1001, 1002			
Volume H Container Assy, Outboard		1	1	MDK Vol H
Bag, EVA Accessory	sn 1014			
Wrench, Adjustable	sn 116			
Ratchet w/7/16 in. socket (pinned)	sn 108			
EHIP Light	sn 1003			
EHIP Battery Pack Assy (2 up, 2 dn)	sn 1003, 1005			
Caddy, General Purpose Tool (GP tool Caddy)	sn 1003			
Winch and Mount Assy, Aft (w/4 ball pip pin)	sn 1004	1	1	PLB Blkhd Aft
PFR	sn 4001	1	1	PLB Blkhd Fwd
Winch and Mount Assy, Fwd (w/4 ball pip pin)	sn 5006	1	1	PLB Blkhd Fwd
3 Point Latch Tool Stowage Bag	sn HG3-366	1	1	PLB TSA port
3 Point Latch Tools (2)	sn 1003, 1007			
	sn 1017,1022,1023,			
Caddy, Tool	1076, 5009,5041,5042	7	7	PLB TSA port
Centerline Latch Tool Bag	sn HF9-046A	1	1	PLB TSA port
Centerline Latch Tools (2)	Sn 1009, 1010			
PB Articulating Socket	sn 1010	1	1	PLB TSA port
PFR Attachment Device (PAD, unpainted)	sn 1008	1	1	PLB TSA port
Winch Hook Adapter (RMS Rope Reel)	sn 1003	1	1	PLB TSA port
1/2 in. Box Ratchet Tool Caddy	sn 108	1	1	PLB TSA port, aft tray
1/2 in. Box Socket Wrench	sn 103			
Payload Retention Device (PRD)	sn 1006, 1016	2	2	PLB TSA port, aft tray
Prybar/EVA Forceps Tool Caddy	sn 106	1	1	PLB TSA port, aft tray
Forceps	sn 106			_
Pry Bar	sn 106			

FS 8-28 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Radiator Extension/Drive Ratchet Tool Caddy	sn 107	1	1	PLB TSA port, aft tray
Radiator Extension Ratchet	sn 107 sn 105			
RMS Shoulder Brace Release Hand Tool	sn 301	1	1	PLB TSA port, aft tray
Snatch Block	sn 1013, 1014	2	2	PLB TSA port, aft tray
Tether, Adjustable Equipment (Sm-Sm)	sn 1027, 1028	2	2	PLB TSA port, aft tray
Bag, EVA Trash	sn 1005	2	2	PLB TSA port, fwd tray
Bolt Puller/Vise Grip Pliers Tool Caddy	sn 102	1	1	PLB TSA port, fwd tray
Bolt Puller	sn 102			
Vise Grip Pliers Caddy, Velcro/Tape	sn 102 sn 1010	1	1	PLB TSA port, fwd tray
Compund Cutter/Needle Nose Pliers Tool Caddy	sn 108	1	1	PLB TSA port, fwd tray
Compund Cutter/Needle Nose Filers Tool Caddy Compund Cutter (Small Cutter)	sn 1009	'		PLB 13A poit, Iwa ilay
Needle Nose Pliers	sn 1003			
ET Umbilical Door Tool	sn 1004	1	1	PLB TSA port, fwd tray
EVA Adjustable Wrench/4 in Ratchet Ext. Tool caddy	sn 102	1	1	PLB TSA port, fwd tray
Ratchet, 4 in Extension, 7/16 in socket	sn 102			
EVA Adjustable Wrench	sn 103			
General Purpose Cutter	sn 1010	1	1	PLB TSA port, fwd tray
General Purpose Tool Caddy (GP tool caddy)	sn 1002,1013	2	2	PLB TSA port, fwd tray
Adjustable Thermal Mitten (2)	sn 007,018			,
Hammer/Chisel Long Probe Tool Caddy	sn 107	1	1	PLB TSA port, fwd tray
Chisel-Long Probe	sn 107 sn 103			
Hammer		4	4	DID TO A part find trans
MPM Ratchet Wrench	sn 1005	1	1	PLB TSA port, fwd tray
PDU Disc/Loop Pin Puller Tool Caddy Loop Pin Extractor Puller	sn 104 sn 107	1	1	PLB TSA port, fwd tray
PDU Disconnect Tool	sn 104			

FS 8-29 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Tube Cutter	sn 1006	1	1	PLB TSA port, fwd tray
Gap Spanner (orbit installed, 18-21")	No serial #s	3	0	SHAB AC01 (1.0 CTB) (labeled "short," "short," "medium") (for QD bags)
Gap Spanner (orbit installed, 21-30")	No serial #s	1	0	SHAB AC01 (1.0 CTB) (labeled "long-303") (for QD bags)
QD Anti-Kickback Tool (AKT) Assy, 0.75"	sn 1001,1002	2	0	SHAB AC01 (1.0 CTB)
QD Button Depress Tool, 0.25"	sn 1001	1	0	SHAB AC01 (1.0 CTB)
QD Button Depress Tool, 0.75"	sn 1002,1003	2	0	SHAB AC01 (1.0 CTB)
Tether, Retractable Equipment (Eq-Eq w/slide lock)	Yellow tethers (-381) sn 4057,4070,4071, 4073,4075,4170, 4271, 4272	8	0	SHAB AC01 (1.0 CTB)
Tether, Retractable Equipment (Eq-Eq w/slide lock)	Blue tethers (-381) sn 4272	1	0	SHAB AC01 (1.0 CTB)
Tether, Retractable Equipment (Eq-Eq/pip w/slide lock)	Yellow tethers (-383) sn 4238-4241	4	0	SHAB AC01 (1.0 CTB)
Tether, Retractable Equipment (Lg-Eq w/slide lock)	Yellow tethers(-385) sn 4252-4257	6	0	SHAB AC01 (1.0 CTB)
Vent Tool Adapter	sn 1001,1002	2	0	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage	sn N/A5,N/A6	2	2	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – EV1		1	1	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – EV2		1	1	SHAB AP01 (5 MLE Bag)
Bag, Jettison Stowage – Return to Shuttle 1, 2, 3		3	3	SHAB AP01 (5 MLE Bag)
Bag, Port QD	sn 1001 (Port written above label by crew)	1	0	SHAB AP01 (5 MLE Bag)
Vent Tool Assy, 1/4" NH3/N2 – F	N/A	2	0	SHAB AP01 (5 MLE Bag)
Vent Tool Assy, 3/4" NH3/N2 – F	N/A	2	0	SHAB AP01 (5 MLE Bag)
Vent Tool Assy, 1.5" NH3/N2 – F	N/A	2	0	SHAB AP01 (5 MLE Bag)

FS 8-30 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
Vent Tool H2O-N2, 1" – F	N/A	1	0	SHAB AP01 (5 MLE Bag)
Vent Tool, 1" N2-M	N/A	1	0	SHAB AP01 (5 MLE Bag)
Bag, Torque Wrench	sn 1001	1	0	SHAB AP07 (3.0 CTB) (EVA add)
Torque Wrench	sn 1001	1	0	SHAB AP07 (3.0 CTB) (EVA add)
Bag, Pump Module Jumper (VTEB 02)	sn 1002	1	0	SHAB AS01 (5 MLE Bag)
Bag, Vent Tool Extension	sn 1001	1	1	SHAB AS01 (5 MLE Bag)
Fluid Leak Indicator (FLI)	sn 1003,1004	2	0	SHAB AS01 (5 MLE Bag) (transfer only)
Pump Module Jumper	sn 01	1	0	SHAB AS01 (5 MLE Bag); in VTE Bag sn 1002
Vent Tool Extender	sn 1001	1	0	SHAB AS01 (5 MLE Bag); in VTE Bag sn 1001
Caddy, Velcro/Tape	sn 1019	1	0	SHAB FC02 (1.0 CTB) (EVA replace)
Pistol Grip Tool (ISS Power Tool)	sn 1004	1	0	SHAB FC02 (1.0 CTB) (transfer only)
Tether, Adjustable Equipment (Eq-Eq w/slide lock)	sn 1067, 1068, 1019, 1038	4	0	SHAB FC02 (1.0 CTB)
S0 Channel 1/4 Power Cable	sn N/A1	1	0	SHAB FC07 (1.0 CTB)
S0 Channel 2/3 Power Cable	sn N/A1	1	0	SHAB FC07 (1.0 CTB)
S0/N1 EVA SM PRI PWR Cable	sn TBD001	1	0	SHAB FC07 (1.0 CTB)
Cover Assembly, Flap (1)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Cover Assembly, Flap (1/2)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Cover Assembly, Flap (3/4)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Seal Assy – Fluid Line Anchor Patch 0.25 in OD (0.25 in Flap)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Seal Assy – Fluid Line Anchor Patch 0.375 in OD (0.375 in Flap)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
Seal Assy – Fluid Line Anchor Patch 1.5 in OD (1.5 in Flap)	sn N/A1,N/A2	2	0	SHAB FP04 (0.5 CTB)
SSRMS FMS MLI Shrouds	sn 202,203	2	0	SHAB FP04 (0.5 CTB)
SPD, 1.0"	sn 1022-1025	4	0	SHAB FP08 (1.0 CTB)
SPD, 1.5" (QD Trainer Assembly)	sn 1004	1	0	SHAB FP08 (1.0 CTB)

FS 8-31 EVA/116/FIN

NOTE: pp = pre-positioned for, = stowed as a kit

ITEM	COMMENT	UP	DN	LOCATION
SPD, 1.0" (QD Trainer Assembly)	sn 1003	1	0	SHAB FP08 (1.0 CTB)
QD Trainer Assembly (housing with 3 male QDs)	sn 1001	1	0	SHAB FP08 (1.0 CTB)
QD Trainer (3/4" female QD)	sn 1001	1	0	SHAB FP08 (1.0 CTB)
QD Trainer (1.5" female QD)	sn 1002	1	0	SHAB FP08 (1.0 CTB)
QD Button Depress Tool, 0.25"	sn 1002	1	0	SHAB FP08 (1.0 CTB)
ETVCG Assembly	sn N/A1	1	0	SHAB PF01
Pistol Grip Tool (ISS Power Tool)	sn 1005,1008	2	0	SHAB PF25 (1.0 CTB) (transfer only)
Adjustable Grapple Bar Assembly		1	0	SHAB SF13
35mm Camera Mounting Bracket	sn 1003,1008	2	0	SHAB SF21 (3.0 CTB) (transfer only)
Modular MWS LH Swingarm Assy	sn 1011,1012,1013	3	0	SHAB SF21 (3.0 CTB) (transfer only)
Modular MWS RH Swingarm Assy	sn 1002	1	0	SHAB SF21 (3.0 CTB) (transfer only)
Modular MWS Retracting End Effector □ Reel housing				
☐ Hook	sn 1005,1013	1	0	SHAB SF21 (3.0 CTB) (transfer only)
PGT Program Cable RS422	sn 1003,1004	2	0	SHAB TBD
Wrench, EVA Ratchet	sn 1013	1	0	SHAB TBD (transfer only)
Socket Extension, 6" w/7/16" Wobble	sn 1001	1	0	SHAB TBD (transfer only)
Wire Tie, Long (32")	N/A102-108,N/A110- 125,N/A127	24	0	SHAB TBD (transfer only)
Wire Tie, Short (16")	N/A202-217	16	0	SHAB TBD (transfer only)
Wire Tie, Short (16")	N/A12,13,16,18,148, 199,200, 201	8	0	SHAB TBD (transfer only)

FS 8-32 EVA/116/FIN

EMU MAINT

EMU MAINT/RECHARGE

WATER RECHARGE	TEMP FS	10-2
EMU POWERUP	TEMP FS	10-2
WATER FILL		
WATER FILL VERIFICATION	TEMP FS	10-2
EMU LIOH CHANGEOUT		10-4
MIDDECK EMU BATTERY RECHARGE/LIOH REPLACEMENT		10-5
INITIATE		10-5
TERMINATE		10-6
IN-SUIT EMU BATTERY RECHARGE/CHARGE VERIFICATION		10-7
INITIATE		10-7
TERMINATE		10-7
EMU POWERDOWN		
HELMET LIGHT/PGT BATTERY RECHARGE		10-8
INITIATE		10-8
TERMINATE		10-9
REBA BATTERY INSTALLATION		
EMU BATTERY REMOVAL/INSTALL		
HELMET LIGHT BULB CHANGEOUT		
REBA BATTERY RECHARGE		
INITIATE		
TERMINATE		10-12
STS-116 LOGISTICS CUE CARD	FS CC	10-13
EMIL BATTERY RECHARGE	FS	10-15

IF EMU NOT ALREADY POWERED UP:

EMU POWERUP

IBOTH DCM

- 1. Retrieve, position SCUs; remove DCM covers
- 2. Connect SCUs to DCM, √locked
- 3. PWR BATT

CAUTION

EMU must be on BATT pwr when airlock pwr supply is turned on

AW18H 4. PWR/BATT CHGR EMU 1,2 MODE (two) – PWR

BUS SEL (two) - MNA(MNB)

MD(flr) 5. √EMU O2 ISOL VLV – OP

AW82B 6. EV1,2 O2 vlv (two) - OP

DCM 7. PWR - SCU

WATER FILL

MO13Q 8. √ARLK H2O S/O VLV – OPEN (tb-OP)

R11L 9. √SPLY H2O TKA OUTLET – CL (tb-CL)

SM 60 TABLE MAINT

CRT 10. Use TKB quantity:

PARAM ID - ITEM 1 + <u>0</u> <u>6</u> <u>2</u> <u>0</u> <u>4</u> <u>2</u> <u>0</u> EXEC

11. Log value before recharge

Recharge #	H2O TKB %
1	
2	
3	
4	
5	

AW82D 12. √EMU 1,2 H2O WASTE tb (two) – CL

SPLY (two) – OP (tb-OP)

13. √H2O TKB quantity decreasing

NOTE

Full charge requires ~15 min

WATER FILL VERIFICATION

DCM 14. √STATUS: |H2O WP | 8-15 psi and stable for ~30 sec (indicates charging complete)

SM 60 TABLE MAINT


CRT 15. Use TKB quantity:

PARAM ID - ITEM 1 + 0 6 2 0 4 2 0 EXEC

16. Log value after recharge

Recharge #	H2O TKB %
1	
2	
3	
4	
5	

Cont next page



FS CC 10-13 EVA/116/FIN

TOP BACK OF 'STS-116 LOGISTICS CUE CARD'

HOOK VELCRO


STS-116 LOGISTICS CUE CARD

HOOK VELCRO

AIRLOCK
Operations

EVA	METOX For 10.2 Ops (S/Ns) (B/Cs)	PWR (EMU Water Bag) (S/N) <u>Floor Bins</u>	IRU EMU Fill Quantity; Post EVA (lb)	CWC (for EMU water dump) (S/N)
1	0007/0011+ 7802J/7792J	1013^		1026
2	0012/ 0013↔ 7812J/7794J (Regen)	1013^ / 1018 ^		1026
3	0015/0016*** 7686J/7796J	1018^		1026

Location Key					
*	EMU				
٨	Floor Bins				
"	ISS Airlock				
+	EVA 1 bag				
++	EVA 2 bag				
+++EVA 3 bag					



EVA	LiOH (S/N) (B/C)	METOX (S/N) (B/C)	EMU BATTERY	REBA (S/N)	Helmet Light Battery (S/N)	ERCA (Address) (S/N)	SAFER (S/N)	PGT (S/N)	PGT Spare (S/N)
1	2024* EMUD08J	N/A	2057* (recharge)	1003+ (recharge)	1011/1012+ (recharge)	16" 1010	1003"	5011+ (recharge)	5013+ (recharge)
2	2018++ EMUD97J	N/A	2031++	1003* (recharge)	1015/1017++ (recharge)	16* 1010	1003"	5014++ (recharge)	5015** (recharge)
3	N/A	0017*** 7811J (Regen)	2059***	1003*	1011/1012 +++	16* 1010	1003"	5011+++	5013***



EVA	LiOH (S/N) (B/C)	METOX (S/N) (B/C)	EMU BATTERY	REBA (S/N)	Helmet Light Battery (S/N)	ERCA (Address) (S/N)	SAFER (S/N)	PGT (S/N)
1	2025* EMUF09J	N/A	2058* (recharge)	1011+ (recharge)	1013/1014+ (recharge)	18" 1007	1005"	5012+ (recharge)
2	2019++ EMUF27J	N/A	2036++	1011* (recharge)	1019/1021++ (recharge)	18* 1007	1005"	
3	N/A	0019*** 7807J (Regen)	2060***	1011*	1013/1014***	18* 1007	1005"	5012+++

HOOK VELCRO

EVA-4b/116/O/A

HOOK VELCRO

(reduced copy)

FS CC 10-14 EVA/116/FIN

INITIATE (20 min)

- 1. Unstow middeck battery charger from External Airlock Floor Bag
- ML85E
- 2. √DC UTIL PWR OFF on J23 utility outlet
- (MUP)
- 3. Affix batteries to charger using Velcro straps on charger
- 4. Connect charger cables to batteries
- 5. Stow batteries/charger for charge
- 6. Connect charger power cable to MUP J23 utility outlet
- 7. √CB5 closed for J23 utility outlet
- 8. DC UTIL PWR (S5) ON

Charger

9. √ON LEDs (red) – ON

√READY LEDs (green) – ON (for 10 sec at startup)

√READY LEDs (green) – blinking

NOTE

EMU batteries may experience a false charge completion due to passivation within the battery. The passivation is removed with repeated attempts (two to three times) at charging the battery

After 15 min charging, verify charging is continuing:

Charger 10. √ON LEDs (red) – ON

√READY LEDs (green) – blinking

- * If ON LED (red) is OFF and READY LED (green) is ON (non-blinking):
- 1. DC UTIL PWR OFF (3 sec) 2. DC UTIL PWR - ON

 - 3. √ON LEDs (red) ON

Charger


- √READY LEDs (green) ON 10 sec at startup
- √READY LEDs (green) blinking
 - 4. Report anomaly to MCC

NOTE

The absence of any active LEDs represents an overcurrent or overvoltage condition that has caused the charger to shut down, or the charger has not been properly powered from the DC Utility Outlet. All protective conditions are resettable by taking the DC UTILITY POWER to OFF.

During the charge, the red ON LED will be illuminated and the green READY LED will continue to blink, giving positive indication that the charger is still charging

EMU BATTERY RECHARGE (Cont)



TERMINATE (10 min)

NOTE

When a nominal charge is complete, the red ON LED will extinguish and the green READY LED will illuminate without blinking. The red ON LED will be illuminated only when the positive current flow into the battery is greater than 0.6A

11. When charge complete:

Charger

√ON LEDs (red) – OFF

√READY LEDs (green) – ON

ML85E (MUP) DC UTIL PWR (S5) – OFF

Disconnect cables from batteries

- 12. Disconnect charger power cable from utility outlet
- 13. Stow charger back in External Airlock Floor Bag
- 14. Take EMU batteries back to ISS, stow in EMU SYS TRANSFER BAG #1 (these batteries will be installed in the EMUs during POST EVA RECONFIGURATION AND TRANSFER)

EMU CONTINGENCY PROCS

DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART) TEMF	P FS	12-2
VACUUM H2O RECHARGE (MANNED) TEMF	P FS	12-2
LIOH REPLACEMENT (MANNED)		12-3
BATTERY REPLACEMENT (MANNED)		12-4
WATER DUMP		12-6
SCU SWAP (UNMANNED)		12-7
SCU SWAP (MANNED)		12-7
EMU COLD RESTART (MANNED)		12-7
12.1 STS EVA DECONTAMINATION		12-8
CONTAMINATION TEST		12-15
SAFER BATTERY CHANGEOUT		12-18
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (IN-SUIT)		12-19
BTA PREP		12-19
BTA TREATMENT		12-19
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (POST		
SUIT DOFFING)		12-21
BTA PREP		12-21
BTA TREATMENT		12-21
EMU RESIZE		
STS-116 NOMINAL EMU SIZING MATRIX	FS	12-27
EMU CONTINGENCY RESIZE MATRIX	FS	12-28
DDE EVA 3 EMIL DESIZE	F۵	12-20

DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART)

If PWR - BATT and SCU connected: DCM

AW18H 1. √PWR/BATT CHGR EMU 1(2) BUS SEL – OFF

DCM If PWR – SCU:

2. PWR – BATT

AW18H 3. PWR/BATT CHGR EMU 1(2) BUS SEL - OFF

WARNING

Fan will be off from steps 4 to 9 during which time CO2 buildup is a concern

Affected EMU will be without comm after step 6. Steps 6 and 7 should be read together before step 6 is performed

4. FAN – OFF (expect FAN SW OFF msg, DISP – PRO) DCM

IV 5. Inform affected EV crewmember of impending comm loss

6. PWR - SCU (7 sec) DCM

7. PWR - BATT

When power restart complete:

8. √Display – O2 POS XX, expect FAN SW OFF msg, DISP – PRO

9. As read. FAN - ON

If display blank or locked up:

10. Contact MCC If SCU power desired:

11. √SCU connected to DCM

12. PWR/BATT CHGR EMU 1(2) MODE - PWR AW18H

BUS SEL - MNA(MNB)

13. $\sqrt{\text{EMU INPUT 1(2) Volts}} = 18.0 - 20.0$

DCM 14. PWR - SCU

DCM 15. √Display – O2 POS XX

VACUUM H2O RECHARGE (MANNED)

WARNING

Procedure should be used only if performing a contingency EVA

ΕV Perform AIRLOCK INGRESS, Cuff C/L, 30 (Close hatch, partially engage) latches)

√Helmet purge vlv – cl, locked

DCM 3. √PURGE vlv – cl (dn)

4. √WATER – OFF

IV MO13Q 5. √ARLK H2O S/O VLV – OPEN (tb-OP)

> MD(flr) 6. √EMU O2 ISOL VLV – OP

ML86B:C 7. √cb MNC EXT ARLK HTR LINE ZN 1,2 (two) – op

AW82B 8. √EV-1(EV-2) O2 vlv – OP

ΕV AW18H 9. PWR/BATT CHGR EMU 1(2) BUS SEL – MNA(MNB)

DCM 10. PWR – SCU (fwd), WARN TONE

IV If SPLY H2O XOVR VLV closed (tb-CL or bp) (water transfer config): R11L

11. SPLY H2O TKA OUTLET – CL (tb-CL)

If SPLY H2O XOVR VLV open (tb-OP) (nominal config):

12. √RAD CNTLR OUT TEMP – NORM L1

13. √FLASH EVAP CNTLR PRI A,B (two) – OFF


ML31C 14. SPLY H2O TKD OUTLET – CL (tb-CL) R11L 15. SPLY H2O TKB OUTLET – CL (tb-CL)

> √TKA OUTLET – CL (tb-CL) TKC INLET - CL (tb-CL)

TKC OUTLET - OP (tb-OP)

EVA/ALL/FIN

STS-116 NOMINAL EMU SIZING MATRIX



 $\frac{\text{NOTE}}{\text{Note any changes made in-flight to EMU size; record in EVA C/L}}$

SEMU	Helmet	HUT Size/ SEMU #	(1) Arm Sizing Ring	(2a) Arm Cam	(2) Lower Arm	(2b) Wrist Cam	PhaseVI Glove
Curbeam	1061	XL / 3003	0.5 inch (s/n 140/141)	Short	04 (s/n 335/336)	Long	6CR (s/n 6238)
Fuglesang up	1063	M / 3018	0.5 inch (s/n 167/168)	Long	03 (s/n 217/218)	Long	6FG (s/n 6197)
Fuglesang down	1063	L / 3015	None	Short	03 (s/n 241/242)	Long	6FG (s/n 6197)
Williams	1071	M / 3018	None	Short	03 (s/n 217/218)	Long	6WS (s/n 6047)

LTA	(3a) Brief Upper Cam	(3) Waist Brief	(3b) Brief Lower Cam	(4) Thigh Sizing Ring	(5a) Leg Upper Cam	(5) Leg Segment	(5b) Leg Lower Cam	(6) Leg Sizing Ring	(7) Boot/Insert
Curbeam	Long	02 (s/n 2041)	Long	None	Short	03 (s/n 191/192)	Long	None	02 / None (s/n 220)
Fuglesang - up	Long	01 (s/n 2057)	Long	None	Short	03 (s/n 185/186)	Long	1.0-inch (s/n 117/118)	02 / None (s/n 215)
Fugelsang - dn	Long	01 (s/n 2074)	Long	None	Short	03 (s/n 173/174)	Long	1.0-inch (s/n 119/120)	02 / None (s/n 212)
Williams	Short	01 (s/n 2053)	Short	None	Short	02 (s/n 153/154)	Long	None	01 / 03 (s/n 203)

Crew Options: Size (Serial #)	CCA/ CCEM	MAG	TCU top / bottom	Comfort Gloves / Wristlets	LCVG / AVD / LVD / BLVD	OBS	Boot Liner / Sock	Comments
Curbeam	05 / 323 (s/n 1166/1050)	711	XL / M	XL, Thick [-14] / Yes	05 / 14 / 08 / 07 (s/n 3132)	pr:122 b/u:117	Thermax Liners [L] Thermal Slipper (07) 1/4" Heel Pads on sides only	fresnel lens: none
Fuglesang	03 / 327 (s/n 1203/1070)	711	M / M	Flat Pattern [MM] / Yes	05 / 13 / 07 / 05 (s/n 3196)	pr:106 b/u:103	Tube sock Thermal Slipper (07) 1/4" Heel Pads on sides only	fresnel lens: 3.5 diopter (-015) modified croakie [M]
Williams	01 / 323 (s/n 1194/1036)	709	S/M	M, Thin [-04] S, Thick [-08] / Yes	02 / 13 / 05 / 03 (s/n 3141)	pr:121	Tube sock	Fresnel lens: none

FS 12-27 EVA/116/FIN

EMU CONTINGENCY RESIZE MATRIX

LOSS OF:	EV1 Curbeam (Cr)	EV2 (Fuglesang)	EV3 (Williams)
CCA	(05/323 - 1166/1050)	(03/327 - 1203/1070)	(01/323 - 1194/1036)
	1. Use Cr b/u CCA (05/3231165/1046)	1. Use Ta CCA (03/327 -1177/1060)	TBD
LCVG	(05 - 3132)	(05 - 3196)	(02 - 3141)
	1. Use Cr b/u LCVG (05 - 3204)	1. Use Fg b/u LCVG (05 - 3137)	TBD
	2. Transfer: biomed & dosimeter	2. Transfer: biomed & dosimeter	
HUT/PLSS	(XL - EMU 3003) 1. Use La HUT 3008 (XL) 2. Install Cr arm sizing ring, lower arms, & gloves 3. Use Cr CCA 4. Use Cr Helmet 5. Use Cr LTA	(M - EMU 3018) 1. Use Rei HUT 3015 (L) 2. Remove EMU 3015 arm sizing rings (138/139) 3. Reinstall EMU 3015 lower arms (03 - 241/242) 4. Verify cams: S/L 5. Install Fg gloves 6. Use Fg CCA 7. Use Fg Helmet 8. Use Fg LTA	(M - EMU 3018) 1. Use ISS HUT 3006 (L) 2. Use Sw lower arm segments (02 213/214) 3. Set arm segment cams: S/S 4. Install W gloves (6WS 6047) 5. Use W CCA 6. Use W Helmet 7. Use W LTA
Arm Sizing	(0.5" - 140/141)	(0.5" - 167/168)	N/A
Ring (1)	1. Use EMU 3015 arm sizing ring (0.5" - 138/139)	1. Use EMU 3015 arm sizing ring (0.5" - 138/139)	
Lower Arm	(04, S/L - 335/336)	(03, L/L - 217/218)	(03, S/L - 217/218)
Segment (2)	1. Use EMU 3006 lower arm segments (04 - 225/226)	1. Use EMU 3015 lower arm segments (03 -	1. Use EMU 3015 lower arm segments (03 - 241/242)
& cams (2a/2b)	2. Verify cams: S/L	241/242)	2. Verify cams: S/L
		2. Set cams: L/L	
Gloves	(6CR - 6238)	(6FG - 6197)	(6WS - 6047)
	1. Use Cr b/u gloves (6CR - 6207)	1. Use Fg b/u gloves (6FG - 6209) 2. Set arm segment upper cams: S	1. Use W b/u gloves (6WS 6046)
Waist Brief (3) & cams (3a/3b)	(02, L/L - 2041) 1. Use EMU 3006 waist brief (02 - 2056) 2. Set cams: L/L 3. Install Cr leg segments (03) & Cr boots (02)	(01, L/L - 2057) 1. Use EMU 3015 LTA (waist brief: 01 - 2074) 2. Verify waist brief cams: L/L 3. Verify leg cams: S/L	(01, S/S - 2053) 1. Use Fg waist brief (01 - 2057) 2. Set cams: S/S 3. Install W leg segments (02 - 153/154) & W boots (01 - 203)
Leg	(03, S/L - 191/192	(03, S/L - 185/186)	(02, S/L - 153/154)
Segment (5)	1. Use EMU 3015 leg segments (03 - 173/174)	1. Use EMU 3015 LTA (waist brief: 01 - 2074)	TBD
& cams (5a/5b)	2. Verify cams: S/L	2. Verify waist brief cams: L/L	
		3. Verify leg cams: S/L	
Leg Sizing Ring (6)	N/A	(1.0" - 117/118) 1. Use EMU 3015 LTA (waist brief: 01 - 2074) 2. Verify waist brief cams: L/L 3. Verify leg cams: S/L	N/A
Boot/BSI (7)	(02/none - 220)	(02/none - 215)	(01/03 - 203)
	1. Use EMU 3015 boot (02/none - 212)	1. Use EMU 3015 LTA (waist brief: 01 - 2074)	1. Use spare ISS boot (prepack - Pi)
	Verify no BSI or toe cap installed in boot	2. Verify waist brief cams: L/L	(01/none -222) 2. Remove BSI's and toe caps from boots
		3. Verify leg cams: S/L	(W) (203)
			3. Install BSI's (03) and toe caps into spare ISS boot (222)

FS 12-28 EVA/116/FIN

OBJECTIVE

This procedure will reconfigure **EMU 3018 for S. Williams** per Figure 1 and complete final reconfiguration of **EMU 3015 for C. Fuglesang (return contingency EMU)** per Figure 2.

NOTE

- Reference {1.550 EMU RESIZE} (SODF: ISS EVA SYS: EMU MAINTENANCE) for component changeout steps.
- Reference {5.115 EMU BARCODE LOCATION REFERENCE} (SODF: ISS EVA SYS: REFERENCE) for barcode and EMU serial number locations. The CCA (comm cap) serial number is located on a tag above the left earphone.
- 3. EMU may be installed in EDDAs as needed to perform resize.
- Place covers on all EMU softgoods components prior to stowage. (Covers located in A/L1D0, bag labeled EMU COVERS VARIOUS SIZES).

CAUTION

- 1. Remove rings and other jewelry before exposing EMU bladder.
- 2. √all seals are clean and free of debris before making connections
- 1. Retrieve W waist brief (01 Waist 021) from A/L1O1, M-02 bag (1010) labeled "EMU Soft Goods".
- 2. Retrieve W leg segments (02 s/n 153/154) from "EMU Soft Goods" M-02 bag (s/n 1010), may already be attached to W waist brief.
- 3. Install W leg segments (02 s/n 153/154) onto W waist brief (01 Waist 021), if not already installed.
- 4. Configure W leg segments cams and W waist brief cams per Figure 1.
- 5. Remove Fg LTA (waist brief: 01 Waist 007) from EMU 3018.
- Install LTA BSC cover from W LTA (waist brief: 01 Waist 021) onto Fg LTA (waist brief: 01 – Waist 007).
- 7. Stow Fg LTA in "EMU Soft Goods" M-02 bag (s/n 1010). May need to disassemble LTA to fit in bag (if so, cover components per Note 4 above).
- 8. Install W LTA (waist brief: 01 Waist 021) onto EMU 3018.
- 9. Install W boots (01/BSI s/n 203) from EMU SYS TRANSFER BAG #2 onto EMU 3018.
- 10. Remove Fg gloves (6FG s/n 6197) from EMU 3018.

PRE EVA 3 EMU RESIZE (Cont)

- 11. Install Fg gloves (6FG s/n 6197) onto EMU 3015, stow arm covers from EMU 3015 in "EMU Covers (Various sizes)" 1.0 CTB s/n 1163 (located A/L1D0).
- 12. Disconnect lower arm power cable from upper arm power harness (both arms) on EMU 3018.
- 13. Remove Fg arm sizing rings (0.5" s/n 167/168) from EMU 3018, then reinstall lower arms.
- 14. Connect Fg arm sizing ring (0.5" s/n 167) to sizing ring (0.5" s/n 168).
- 15. Stow sizing rings (0.5" s/n 167/168) in sizing ring protective pouch from Fg ECOK, then stow in "EMU Soft Goods" M-02 bag (s/n 1010).
- 16. Adjust arm segments upper cams (2 per arm) to short position on EMU 3018, see Figure 1.
- 17. Connect lower arm power cable to upper arm power harness (both arms) on EMU 3018.
- 18. Install W gloves (6WS s/n 6047) from EMU SYS TRANSFER BAG #2 onto EMU 3018.
- 19. Remove W helmet (s/n 1071) from EMU 3015.
- 20. Remove Fg helmet (s/n 1063) from EMU 3018.
- 21. Install Fg helmet (s/n 1063) onto EMU 3015.
- 22. Disconnect Fg CCA (s/n 1203) from EMU 3018 electrical harness.
- 23. Stow Fg CCA (s/n 1203) in Fg ECOK.
- 24. Connect W CCA (s/n 1194) from EMU SYS TRANSFER BAG #2 to EMU 3018 electrical harness, stow comm cap in arm of EMU.
- 25. Install W helmet (s/n 1071) onto EMU 3018.
- Verify wrist mirrors on both EMU 3018 & EMU 3015.
- 27. Remove ISS Cuff Checklist containing Fg notes from EMU 3018, stow in EMU Equipment Bag (stays on ISS).
- 28. Install ISS Cuff Checklist containing W notes from EMU SYS TRANSFER BAG #2 onto EMU 3018.
- Remove helmet lights and EMU TV from Fg helmet and install on W helmet.
- 30. Remove Fg STS 116 patch and Swedish flag from EMU 3018, stow in ECOK or install on EMU 3015.
- 31. Install W STS 116 patch and US flag (from ECOK EVA #1 STS-116 bag) on EMU 3018.
- 32. Verify final configuration per Figures 1 and 2 below.

PRE EVA 3 EMU RESIZE (Cont)

NOTE

- 1. All labels show serial numbers on top and barcodes in parentheses.
- 2. **BLACK** font indicates hardware <u>already installed</u> on **EMU** 3018.
- 3. GREEN font indicates hardware stowed on ISS.
- 4. BLUE font indicates hardware delivered on STS-116/12A.1.
- 5. **RED** font indicates adjustments to hardware.




FIGURE 1 - FINAL EMU 3018 (W) CONFIG (viewed from front)

PRE EVA 3 EMU RESIZE (Cont)

NOTE

- 1. All labels show serial numbers on top and barcodes in parentheses.
- 2. **BLACK** font indicates hardware <u>already installed</u> on **EMU** 3015.
- 3. BLUE font indicates hardware delivered on STS-116/12A.1.




FIGURE 2 - FINAL EMU 3015 (Fg) CONFIG (viewed from front)

TPS REPAIR

The TPS Repair procedures listed below are not published in the hardcopy EVA Flight Supplement. These procedures will be uplinked realtime if they are required.

A PDF and a WORD version of the procedures can be found at: http://mod.jsc.nasa.gov/do3/FDF/FDFBooks/Status%20Sheets/index.html. Select the "As Flown" Status sheet for STS-116 and the link to the procedures can be found with the link to the EVA FS. The procedures can also be found on the FDF Books CD provided to the FAO console

BOOM TPS INSPECTION	
BOOM POINT INSPECTION SUMMARY TIMELINE	FS 13-3
BOOM POINT INSPECTION TOOL CONFIG	
BOOM POINT INSPECTION	
BOOM WLE MAPPING SUMMARY TIMELINE	
BOOM WLE MAPPING TOOL CONFIG	
BOOM WLE MAPPING	
EVA WLE MAPPING INSPECTION	FS 13-24
SAFER TPS INSPECTION	10102
SAFER TPS INSPECTION SUMMARY TIMELINE	FS 13-20
SAFER TPS INSPECTION TOOL CONFIG	
SAFER TPS INSPECTION	
BOOM CONTINGENCY	10 1001
BOOM FRGF SHAFT RELEASE	FS 13-37
BOOM FRGF SHAFT INSTALLATION	
BOOM EFGF SHAFT RELEASE	
BOOM MPM STOW/DEPLOY	
BOOM ASSISTED LATCHING	
TILE REPAIR	10 10-40
EMU PREP FOR TPS REPAIR	FS 13-44
POST TPS REPAIR DOFFING	
EWA MATERIAL MIXING	
EWA REF DATA	
EWA TILE REPAIR - DOCKED/ORM SUMMARY TIMELINE	
EWA TILE REPAIR – DOCKED/ORM TOOL CONFIG	
EWA TILE REPAIR – DOCKED/ORM	
SSRMS GAP FILLER REMOVAL SUMMARY TIMELINE	
BOOM GAP FILLER REMOVAL SUMMARY TIMELINE	
GAP FILLER REMOVAL	
RCC REPAIR	1 3 13-00
RCC CRACK REPAIR BAG ASSEMBLY	FS 13-6F
TEMP SENSOR DISASSEMBLY POST-EVA	
RCC CRACK REPAIR BAG DISASSEMBLY POST-EVA	
TEMPERATURE PROBE ASSEMBLY	
CRM APPLICATOR ASSEMBLY	
CRM APPLICATOR NOZZLE INSTALLATION (DAY OF EVA)	FS 13-72
NOTES, CAUTIONS, WARNINGS	10 10 72
EVA TPS INSPECTION/REPAIR INHIBIT PAD	FS 13-73
ORM WARNINGS AND NOTES	
TPS REPAIR CAUTIONS AND WARNINGS	
TPS REPAIR NOTES	FS 13-77
BOOM OPERATIONAL WARNINGS	FS 13-79
BOOM OPERATIONAL NOTES	FS 13-80

TPS REF DATA	FO. 40	. 04
PREFERRED EMU POSITIONING FOR TPS REPAIR		
EVA TPS REACH AND ACCESSPOINT INSPECTION REACH AND ACCESS WHILE DOCKED.	FS 13	3-82
WLE MAPPING INSPECTION WHILE DOCKED		
TILE LAYUP	FS 13	
85-FOOT SAFETY TETHER		
PFR ATTACHMENT DEVICE (PAD)		
WIF EXTENDER		
EVA DIGITAL CAMERA		
EVA IR CAMERA		
OVERLAY TILE REPAIR SYSTEM (OTRS)	FS 13	3-94
OTRS MARKING TEMPLATE AND INSULATION BAGS		
AUGER HOUSING	FS 13	3-96
OTRS RELEASED CONFIGURATION		
ORU BAG INSERT FOR OTRS	FS 13	3-98
BOOM REF DATA	F0.40	
RTF BOOM OVERVIEW	FS 13	3-99
BOOM TRANSITIONS WITH MLI		
BOOM BASE END AND MODIFIED EFGF		_
BOOM BASE END EFGF ADAPTER PLATE		
EVA-ASSISTED EFGF CONNECTOR DEMATE		
BOOM BASE END SADDLE AND MPM		_
BOOM MID SECTION AND MODIFIED FRGF		
BOOM MID SECTION FRGF ADAPTER PLATE		
BOOM TIP END AND SENSORS		
BOOM SENSOR DETAILS		
SENSOR PACKAGE 1 (SP1): LDRI/ITVC	FS 13	3-111
SENSOR PACKAGE 2 (SP2): LCS	FS 13	3-113
POSSIBLE PRD ROUTING FOR EVA ASSISTED LATCHING	F0.40	
OF BOOM IN MPMS		
BOOM CONTINGENCIES		
GRAPPLE SHAFTS		
PDGF GRAPPLE SHAFT COVER		
BOOM FRGF FSE	FS 13	3-119

UNSCHEDULED/CONTINGENCY EVA TASKS

12A.1 WORKAROUNDS CRIBSHEET	FS 16-3
EVA 1 CONTINGENCIES	EO 40 45
MANUAL EATCS N2 VENTING	FS 16-15
SOFT CAPTURE MANUAL OVERRIDE	
MRTAS PRIMARY BOLT CONTINGENCIES	
MRTAS CONTINGENCY BOLT INSTALL	FS 16-25
SOLAR ARRAY	
MANUAL OVERRIDE TO RETRACT MAST	FS 16-28
MANUAL OVERRIDE TO LATCH/UNLATCH (TENSION) 4B SABB	FS 16-31
SOLAR ARRAY JETTISON	FS 16-34
EVA 2 CONTINGENCIES	
CHANNEL 2/3 CONNECTOR BACKOUT	FS 16-40
MBSU REMOVE AND REPLACE – 2A2B (EVA 2)	FS 16-43
MBSU REMOVE AND REPLACE – 3A3B (EVA 2)	FS 16-51
DDCU REMOVE AND REPLACE – CH 2/3 (EVA 2)	
BCDU BACKOUT – CH 2/3 (EVA 2)	
P1 PUMP MODULE R&R SUMMARY TIMELINE	
EVA 3 CONTINGENCIES	
CHANNEL 1/4 CONNECTOR BACKOUT	FS 16-96
MBSU REMOVE AND REPLACE – 1A1B (EVA 3)	
MBSU REMOVE AND REPLACE – 4A4B (EVA 3)	
DDCU REMOVE AND REPLACE – CH 1/4 (EVA 3)	
BCDU BACKOUT – CH 1/4 (EVA 3)	
S1 PUMP MODULE R&R SUMMARY TIMELINE	
MISCELLANEOUS	10 10-130
SSRMS JOINT DRIVE	FS 16-154
MSS EXTENSION CABLE INSTALL	
PUMP MODULE MANUAL VENTING	
FAILED PUMP MODULE RETURN TO ICC	
FAILED PUMP MODULE RETURN TO ICC	FS 16-163

This Page Intentionally Blank

12A.1 WORKAROUNDS CRIBSHEET

GENERIC

NZGL CONNECTOR

NZGL CONNECTOR	
A. Connector fails to demate	 Verify bail fully thrown and undamaged Inspect connector/bail for FOD Check alignment/side loads Wiggle/jiggle connector, pull on connector back shell away from cap/jack for additional leverage Attach 2 hooks from adjustable tether to connector bail, use adjustable strap to pull bail into demated position (this works better after bail/linkage has passed over-center feature) Check for harness interference Increase force on bail
B. Connector fails to soft dock	 Verify bail fully aft Verify plug half shell is aligned with jack half shell, avoid rolling/rocking plug onto jack (this could possibly unseat soft dock springs; it is also possible for keying feature to prevent soft dock). Once half shells are aligned, connector should snap into soft dock position with little force
C. Connector fails to mate	1. Detach from soft dock and inspect the following: a. Pins b. FOD c. EMI band d. bend radius e. bail linkages/rivets f. soft dock springs g. O-ring seal on non-active side or main joint gasket inside receptacle h. connector keying features 2. Cycle bail while disconnected, push on connector back shell toward cap/jack for additional leverage 3. Verify half-shells are fully seated on both sides
D. Connector pin bent (16,20,22 gauge)	 Rotate connector to bail up position, describe pin condition. If possible, obtain WVS view or interface On MCC GO, retrieve pin straightener (A/L staging bag) or needle nose pliers (stbd A/L toolbox, slot 2); attempt pin repair (this is based on pin size and MCC will verify actual pin size prior to retrieving tool)
E. Connector FOD	On MCC GO, obtain connector cleaner tool from A/L staging bag; use entire cartridge prior to re-entry to the airlock NOTE One N2 cartridge is already captured onto the CCT (the other is lanyarded inside caddy). In order to puncture cartridge, it must be threaded into CCT until indicator line passes out of sight under the collar of the CCT
F. Connector EMI band bent	On MCC GO, obtain needle nose pliers (stbd A/L toolbox, slot 2) or forceps to remove band
G. Connector bail linkage failure	On MCC GO, re-attempt connector mate with broken bail. Vice grips may be used for additional leverage or hand on backshell (hand on back shell is easiest once linkage/bail has passed over-center feature)
H. Connector soft dock spring bent	On MCC GO, obtain needle nose pliers (stbd A/L toolbox, slot 2); attempt to remove bent spring

FS 16-3 EVA/116/FIN

Connector O-ring or Main Joint Gasket	Remove seal with tether hook
seal loose	2. If no joy, on MCC GO, obtain needle nose pliers
(used as a moisture seal in 1G only, not needed on orbit)	(stbd A/L toolbox, slot 2) to remove seal
J. Twist cap will not release	On MCC GO, increase force
	On MCC GO, attach equipment hook to cap tether point and use strap of adj tether to assist with cap release

TA Clamp

TA clamp fails to release	Use tether hook to open clamp (do not use as a prying
	mechanism)

TSA

A.	Latch fails to open	Release 7/16" EVA bolt on latch bracket, rotate bracket clear of latch tongue
B.	Latch fails to close	Close remaining latches (3 of 4 required for landing)

APFR

ALLIX	
A. APFR fails to install in WIF	Verify APFR collar in install position
	Check for FOD in WIF or structural interference
	3. Attempt APFR install in alternate position. If no joy
	(APFR failure), use another APFR
B. Joint fails to actuate	Verify no load is applied to joint
	Increase force applied to free joint
C. EMU boot becomes stuck in bootplate	PGT[B1, CCW2, 30.5]-6"-ext-7/16": Release EVA
	bolts on heel plate, 5 turns

SAFETY TETHER

	*/ !: = : : : = : ::=:::			
A.	55' safety tether fails to retract/tend	 Verify reel is unlocked Verify tether reel opening is clear of FOD Pull out small amount of cable, allow reel to retract while holding cable slightly tensioned 		
B.	85' safety tether fails to retract/tend	 Verify reel is unlocked Verify tether reel opening and cable guide is clear of FOD (ensure nothing is blocking cable from retracting) Pull out small amount of cable, allow reel to retract while holding cable slightly tensioned 		
C.	Safety tether red stripe showing (any length)	Safety tether cannot be used. Replace with spare safety tether from Crewlock Bag #1		

PAD

-	· / · ·				
	For PAD install, release knob fails to rotate to close	1. 2.	Verify knob unlocked and in release position Stow PAD in A/L, retrieve backup PAD from port TSA		
	B. For PAD remove, release knob fails to rotate to open		Verify knob unlocked and in release position Attempt to rotate release knob using 7/16" Ratchet on knob's 7/16" hex stud To remove PAD from SRMS, PGT[A6, CCW2, 30.5]-6-in ext: Release contingency release bar by rotating 7/16" captive release bolts (2) ccw, 5 turns		

FS 16-4 EVA/116/FIN

TORQUE MULTIPLIER

A.	Torque Multiplier fails to release from	1.	Verify anti-backlash feature in neutral; if not:
	fitting		PGT[RCW, MTL 30.5]: Apply cw torque and push
			anti-backlash button to neutral posn
		2.	PGT[A5, 2.5 ft-lb, CCW2, 30.5]-5/32" allen driver:
			Release torque multiplier contingency release band
			pin 20 turns (do not exceed 28 turns)
		3.	When contingency band springs open, remove TM

SCOOPS

A. Scoop will not release from fitting	PGT[A2, CCW2, 30.5] -5/32" allen driver: Remove
	screws (not captive), 5 turns each

FLIGHT SPECIFIC - NOMINAL TASKS

EVA 1

P5/P4

P5/	· 	
A.	P5 launch lock will not release because primary bolt torques out	 Check worksite for FOD Retrieve EVA Ratchet Wrench from Staging Bag in A/L, install 7.8" x 5/8" socket on ratchet Attempt to break torque (ccw) on launch lock Use PGT with RAD to continue driving bolt through running torque to nominal turn count NOTE Boeing has given the GO to use B7 from a truss hardware standpoint, but we are limited to a setting of B1 with the RAD
B.	P5 launch lock will not release from P5 when PIP pin is pulled	Verify PGT turn count. Is primary bolt free of launch lock threads? If no joy, drive primary bolt additional turns, not to exceed 36
C.	P5 launch lock PIP pin will not release	 Check worksite for FOD or damage to PIP pin Increase removal force and try again Retrieve needle nose pliers or vice grips and re-attempt
D.	P5-P4 Soft Capture not achieved at any of the 4 corners	SSRMS re-attempts per flight rules EVA perform SOFT CAPTURE MANUAL OVERRIDE from section 16
	For any of the following P5 Primary Bolt contingencies: a. Does not achieve full torque b. Bolt shoulder has a gap (is not seated against nut) c. Gap check at corner's 1 and 2 does not pass	EVA perform MRTAS PRIMARY BOLT CONTINGENCIES from section 16
	P5 gap check tool (inboard) will not release from corner 1	 Check worksite for FOD If bolt did not turn, increase PGT setting to B7, drive one turn only, then return to original PGT setting Retrieve gap check tool from outboard corner 1
G.	P4 ground strap will not release from P4 launch position	 Check worksite for FOD Increase PGT setting to B5 If bolt did not turn, increase PGT setting to B7, drive one turn only, then return to B5
H.	P4 ground strap cross threads during install onto P5 lug	Ensure EV crew begins installation manually, back-off thread engagement and re-attempt

FS 16-5 EVA/116/FIN

I.	P4 ground strap will not seat properly onto P5 lug (ground strap is not flush to surface or PGT stalls)	 Check ground strap alignment Increase PGT torque setting to B4
J.	P4 soft capture pin bolts will not release	 Check worksite for FOD If bolt did not turn, increase PGT setting to B7, drive 1 turn only, then return to original PGT setting
K.	Primary bolt free spins and does not advance into P4 nut (PGT does not "see" torque) (possible broken self-feeding nut)	If bolt free spins, push P5 bolt axially toward P4 while driving PGT until bolt threads begin to engage P4 nut (under load)

PVRGF

	PVRGF bolts (H13, H14, and H15) won't release	2.	Check worksite for FOD Increase PGT torque setting to B7, re-attempt If no joy: PGT – off Ratchet ccw, (MTL: 30.5) Attempt to break torque
B.	PVRGF bolt H16 won't release (RAD used at this corner)	3.	Check worksite for FOD Retrieve the following tools: EVA Ratchet Wrench from Staging Bag in A/L, install 6-inch socket on Ratchet Cheater Bar from Z1 port toolbox, panel 8 Using Ratchet Wrench, attempt to break torque (ccw) on launch lock (keep downward pressure on wobble socket while breaking torque). If no joy, install cheater bar on Ratchet Wrench and re-attempt to break torque Use PGT with RAD to continue driving bolt through running torque to nominal turn count
C.	PVRGF ground strap bolt won't release (corner H14)		Check worksite for FOD Use PGT in ratchet mode: PGT – off Ratchet ccw, (MTL: 30.5) Attempt to break torque
D.	Corner H16 (nadir/stbd) on PVRGF is interfering with 4A BGA during removal	2.	Drive H16 bolt CW up to 17 turns with PGT setting of A5 toward structure to provide an additional 0.85" of clearance at that corner for removal, re-attempt PVRGF removal Remove PIP pin from PVRGF at H16 corner (lanyarded), re-attempt removal
E.	PVRGF ground strap bolt will not install onto P5 Keel lug (cross thread problem)		Check worksite for FOD Back-off thread engagement and re-attempt installation manually
F.	PVRGF ground strap will not seat properly onto P5 keel lug (ground strap is not flush to surface or PGT stalls)		Check worksite for FOD Release bolt at B7, re-align and attempt installation at nominal installation PGT setting

ETVCG

A.	Failed ETVCG is not oriented correctly for removal (should be in park position) or will not pan to park position (camera lens should point zenith and directly toward TVCIC structure (bolt housing))	1. 2.	Contact MCC Manually align (pan/tilt lock lever will not lock unless camera is in home position)
B.	Failed ETVCG pan/tilt lever won't rotate	1. 2.	Check worksite for FOD Increase force, re-attempt
		3.	Contact MCC
C.	Failed ETVCG outer bolt does not release	1.	Check worksite for FOD
		2.	Increase PGT setting to B7 for ONE turn only.
			Reset PGT to A7 for full run-out of bolt

FS 16-6 EVA/116/FIN

D.	Failed ETVCG center jacking bolt does not release	Check worksite for FOD Check outer bolts to make sure they are fully backed out Increase PGT torque setting to B7 for ONE turn only. Reset PGT to A7 for full run-out of bolt
E.	Spare ETVCG center jacking bolt does not engage	Remove camera, inspect rail and bolt interface from damage, attempt re-installation, ensure outer bolts are retracted
F.	Spare ETVCG center jacking bolt does not reach minimum turn count (24 turns)	Increase PGT torque setting to B1; re-attempt
G.	Spare ETVCG outer bolt does not engage	Check worksite for FOD Engage opposite outer bolt, re-attempt driving failed bolt Increase PGT torque setting to B1, re-attempt Contact MCC

EVA 2

P1 DDCU THERMAL COVER GROUND STRAP

A.	Ground bolt fails to release		olt did not turn, increase PGT setting to B7, drive	
		one	turn only, then return to original PGT setting	
B.	If bolt still fails to release at new setting	1.	Using EMU scissors, cut ground strap close to bolt	
			-OR-	
		2.	On MCC GO, shear bolt	

Z1-003 PATCH PANEL 5 RECONFIGURATION

A. Cannot reach connectors on Z1 stbd	Contact MCC for SASA removal and temp stow:
patch panel due to SASA interference	Retrieve ballstack and MUT EEs (2) from crewlock bag #1
	b. Reconfig Z1-01 IAPFR settings to: [3,RR,F,12], ingress IAPFR
	c. PGT [B7 25.5 ft-lb, CCW3 60 RPM, 30.5]-6"-
	ext-7/16: Release SASA stanchion storage
	bolts (2) ~ 9 turns; If no joy with B7:
	PGT[RCCW, MTL 30.5]-6 ext 7/16:
	Re-attempt fastener release d. Release SASA from soft dock (if difficult,
	wiggle/jiggle SASA from soft dock)
	e. Temp stow SASA via MUT-ballstack-MUT to
	adjacent Z1 HR
	K0101
	If SASA heater cable length prevents SASA removal
	and temp stow:
	Contact MCC to put Z1 SASA inhibits in place: RPCM Z14B B RPC1 – OPEN, CLOSE CMD INH
	2. Demate EAS W200A-P33 from SASA J3 (starts
	thermal clock)
	Re-attempt temp stow

CETA CART

CETA CART	
A. Wheel bogie fails to release from truss	Perform CETA Cart Wheel Bogie R&R procedure from section 16; there is no spare bogie on orbit, so remove the failed one from the cart, relocate the cart onto the truss, and then re-install the same wheel bogie
B. Wheel bogie fails to install onto truss	There are no spares on-orbit; it is acceptable to perform the following actions with an unsecured or missing wheel bogie:
C. Parking brake fails to engage/disengage	 Retry using other side Contact MCC
D. Dynamic brake fails to engage	 Limit translation rates for manual stopping or use parking brake as dynamic brake Try other side
E. CETA active coupler fails to capture and lock (CETA cart safing) Starboard LDTDT Similari Starboard Config. Starboard LDTDT Similari Starboar	 Translate CETA cart to TBD location on truss (not over truss segment joint) Pull parking brake (left handle) Retrieve two long duration tie-down tethers (LDTDT) from P6 Aux bag (fwd face of P6) Route one LDTDT on stbd side of CETA cart per the following details: Attach one hook to zenith brake handle support tether point Loop tether strap around CETA rail HR standoff and back toward nadir brake handle support tether point Attach second hook to nadir brake handle support tether point Lightly cinch straps, snap buckle over Close MLI flap over buckle and any excess strap length Repeat sequence for port side of CETA cart
F. Coupler knob fails to lock	The CETA cart coupler cannot be left in the CAPTURE position and allowed to translate with the MT. In the event the coupler fails to LOCK: Perform steps 1 through 5 in section E above
G. Coupler knob fails to unlock	Remove coupler: remove wire ties (2) and PIP pins to release active coupler or single EVA bolt to release passive coupler
H. Swing arm fails to rotate	Do not force swing arm into position; use alternate swing arm/WIF
Swing arm fails to lock	Wire tie in stowed position

FS 16-8 EVA/116/FIN

EVA 3

S1 DDCU THERMAL COVER GROUND STRAP

A.	Ground bolt fails to release	If bolt did not turn, increase PGT setting to B7, d	rive
		one turn only, then return to original PGT setting	
B.	If bolt still fails to release at new setting	1. Using EMU scissors, cut ground strap close	to bolt
		-OR-	
		2. On MCC GO, shear bolt	

Z1-003 PATCH PANEL 6 RECONFIGURATION

21-000 I ATOTT ANEE O RECONTINUITATION	
A. Cannot reach connectors on Z1 stbd patch panel due to SASA interference	 Contact MCC for SASA removal and temp stow: Retrieve ballstack and MUT EEs (2) from crewlock bag #1 Reconfig Z1-01 IAPFR settings to: [3,RR,F,12], ingress IAPFR PGT [B7 25.5 ft-lb, CCW3 60 RPM, 30.5]-6"-ext-7/16: Release SASA stanchion storage bolts (2) ~ 9 turns; If no joy with B7: PGT[RCCW, MTL 30.5]-6 ext 7/16: Reattempt fastener release Release SASA from soft dock (if difficult, wiggle/jiggle SASA from soft dock) Temp stow SASA via MUT-ballstack-MUT to adjacent Z1 HR
	If SASA heater cable length prevents SASA removal and temp stow: 1. Contact MCC to put Z1 SASA inhibits in place: RPCM Z14B B RPC1 – OPEN, CLOSE CMD INH 2. Demate EAS W200A-P33 from SASA J3 (starts thermal clock) 3. Re-attempt temp stow

SMDP

<u> </u>	OMDI			
A. Fixator handle fails to rotate by hand	1. PGT – off 2. If A1: a. Ratchet cw (MTL: 30.5) b. Release fixator handle override bolt A1 3. If A2: a. Ratchet ccw (MTL: 30.5) b. Release fixator handle override bolt A2			
B. Crew cannot access contingency A1 or A2 bolts because adjacent tie rod is still installed and blocks PGT access to bolts	Release adjacent tie rod that is still installed via nominal procedure, re-attempt release of A1/A2 bolts			
C. B1/B2 bolt fails to release	 If it's first bolt on tie rod attempted, Release other bolt Attempt to release tie rod from failed bolt side (~15 kg force) If no joy, attempt to release tie rod from successful bolt side (~15 kg force) Go to row D If it's second bolt on tie rod attempted, Attempt to release tie rod from failed bolt side (~15 kg force) If no joy, attempt to release tie rod from successful bolt side (~15 kg force) Go to row D 			

FS 16-9 EVA/116/FIN

D. B1/B2 bolt fails to release and cannot release tie rod using procedure in C	 Cut fishing line at hinge contingency override bolt (2 places) (either side of hold down beam) Rotate "Open 1" fixator handle 40° (drops in detent); if handle does not rotate, take PGT to ratchet cw or ccw as needed (MTL: 30.5) Tether to ring PGT – off; ratchet cw or ccw as needed (MTL: 30.5): Rotate "Open 2" 180° in direction of arrow (drops in detent) Release tie rod Pull pin out, stow in trash bag
E. SMDP Adapter handle unable to move from launch position	Perform the following steps to release SMDP adapter contingency bolts (4) and tie down to Lab nadir HRs: 1. PGT [B7, CCW2, 30.5] 6"-ext-7/16: Release EVA contingency override bolts, (4) 16 turns (bolts are lanyarded) (no soft dock once bolts are released) (if access is poor with 6-in socket, use RAD with 2-in, MCC to re-calculate torque setting) 2. EV2 remove SMDP adapter from ICC (will have ICC NHP plate attached to it with hex probe) 3. Perform steps 7 through 10 in row F


F. SMDP Adapter handle jams in intermediate position upon releasing SMDP Adapter from ICC




WIRE TIE CONFIG FOR HANDLE



WIRE TIE CONFIG FOR HANDLE




TIE DOWN CONFIG ON LAB
(first tether)



TIE DOWN CONFIG ON LAB (second and third tethers)

Perform the following steps to secure the SMDP adapter handle toward the Closed position:

- 1. EV1 retrieve long wire tie from EV2
- 2. Wrap one end of wire tie around SMDP adapter handle, then around the HR support structure and back onto handle
- 3. Wrap both ends of wire tie around handle twice
- 4. Wrap remaining loops around each other 3 times



SMDP ADAPTER TIE DOWN OVERVIEW

Perform the following steps to release SMDP adapter contingency bolts (4) and tie down to Lab nadir HRs. NOTE: Tiedown is not a certified method:

- 5. **PGT [B7, CCW2, 30.5] 6"-ext-7/16**: Release EVA contingency override bolts, (4) 16 turns (bolts are lanyarded) (no soft dock once bolts are released) (if access is poor with 6-in socket, use RAD with 2-in, re-calculate torque setting)
- 6. EV2 remove SMDP adapter from ICC (will have ICC NHP plate attached to it with hex probe)
- 7. SRMS mnvr to contingency tie-down location (Lab nadir/aft/port) near APFR setup/cleanup wkst)
- 8. EV1 retrieve 3 long duration tie-down tethers from P6 Aux Bag (located on P6 forward face); translate to tie-down worksite on Lab aft/nadir
- Using 3 long duration tie-down tethers, strap SMDP adapter to Lab HRs using SMDP adapter vertical HRs, cinch down. See photos above and on left:
- Stow excess strap inside buckle and install MLI over buckle

G. Magnetic socket fails to lock	Perform the following steps to secure SMDP bundle to a magnetic socket that fails to lock: 1. Retrieve Russian adjustable and fixed length tether from crewlock bag #2 (airlock) 2. Attach 1st hook of fixed-length tether to SMDP bundle HR 3. Attach 2nd hook of fixed-length tether to 1st hook of fixed-length tether (see adjacent photo) 4. Attach 1st hook of adj tether to 2nd hook of fixed-length tether (3 hooks in a row) 5. Route 2nd hook of adj tether through SMDP adapter HRs to SMDP bundle HR on opposite side of adapter, cinch tether
H. SMDP Adapter handle jams in intermediate position while attaching it to Strela adapter on PMA3	Perform the following steps to remove SMDP adapter, Strela adapter, and PMA3 grapple fixture shaft from PMA3 and stow on Lab HRs: 1. Retrieve the following tools:

AGB

A.	T-handle fails to unlock to allow AGB to extend	1. 2.	Check interface for FOD or damage Increase force and re-attempt, contact MCC if no joy
B.	T-Handle pin does not drop into AGB alignment hole during installation onto FHRC	1.	Slide AGB single pin side in and out a few centimeters while simultaneously tapping the T-handle into position Contact MCC
C.	AGB center drive pin does not install	1. 2. 3.	Check for FOD If bolt did not turn, increase PGT setting to B7, drive one turn only, then return to original PGT setting If no joy, AGB is in good config for on orbit loads and can be left as is, but cannot be grappled to by RMS

FLIGHT SPECIFIC - CONTINGENCY TASKS

GENERIC EPS ORUS (MBSU, DDCU, BCDU)

	ELICIO EL O ORGO (MBSO, DDCO, BCDO)		DOT ID4 0011/0 00 II 0 4 II/0 D 1 110
Α.	Box binds during H2 fastener install		PGT: [B1, CCW2, 30.5]-6ext-7/16: Drive H2 fastener ccw same # of turns that bolt was driven in PGT: [B1, CW2, 30.5]-6ext-7/16: Drive H2 fastener cw TBD turns while simultaneously putting light pressure on H1 side of box. This helps keep box level to preclude box canting and bolt binding
B.	H2 status indicator slot does not properly align with UNLOCK silver mark	1.	Verify that indicator slot is to the left or right of UNLOCK silver mark by a distance no greater than width of black stripe: a. If yes, proceed with R&R b. If no, contact MCC. Status indicators are not reliable, rely on torque and turns
C.	H2 status indicator slot does not properly align with LOCK silver mark	1.	Verify that indicator slot is to the left or right of LOCK silver mark by a distance no greater than width of black stripe: a. If yes, proceed with R&R b. If no, contact MCC. Status indicators are not reliable, rely on torque and turns
D.	H1 status indicator slot does not properly align with UNLOCK silver mark	1.	Verify that indicator slot is to the left or right of UNLOCK silver mark by a distance no greater than width of black stripe: a. If yes, proceed with R&R b. If no, contact MCC. Status indicators are not reliable, rely on torque and turns
E.	H1 status indicator slot does not properly align with LOCK silver mark	1.	Verify that indicator slot is to the left of LOCK silver mark by a distance no greater than width of black stripe: a. If yes, proceed with R&R b. If no, contact MCC. Status indicators are not reliable, rely on torque and turns

PUMP MODULE

	OWI MODULE		
A.	FGB to PM attach bolt fails to release	1. 2.	PGT – off Ratchet ccw (MTL: 30.5), re-attempt fastener release
B.	FGB fails to install onto PM	1. 2.	Verify no MLI interference; re-attempt Release bolts an additional 5 turns as required to increase clearance in between FGB and PM
C.	FGB to PM attach bolt fails to engage	1.	PGT: B7, CCW2, 30.5: Back bolt out 5 turns, inspect for FOD; re-attempt engagement (A7, CW2, 30.5) If no joy, back out problematic bolt, back out remaining 3 bolts 10 turns, engage bolts in cross pattern 3 turns at a time
D.	PM Integrated Assy fails to install on ICC passive FRAM	1. 2.	Check alignment pins/cones free of FOD; re-attempt installation Notify MCC
E.	Ball plunger soft dock feature at GP3 location on FGB is stuck, precluding installation onto PM	1. 2.	Apply more force when attempting to slide FGB baseplate past bolts Attempt to depress/unstick plunger using EVA hook, or bolt puller from TSA

FRAM

FR/	FRAM		
A.	Primary FRAM bolt fails to release	Contact MCC	
B.	Primary FRAM bolt fails to engage	 Verify active FRAM fully seated on passive FRAM, check for FOD, back out primary FRAM bolt (A7, CCW2, 30.5) fully; re-attempt engagement (A7, CW2, 30.5) Engage contingency locking pins (4) FRAM FWD Cont Pins (SAPA and LAPA): PGT: TBD, TBD turns (see equation) FRAM AFT Cont Pins (SAPA/MBSU) (see equation) FRAM AFT Cont Pins (LAPA/PM) (see equation) Turns = 14.11 – (1.25 x Primary bolt turns) AFT CONT PINS (SAPA): The rear cont pin can be installed if the primary turn count is 6.5 turns or less With greater than 6.5 turn on the primary bolt, the cont pin is not needed, and in some cases where most turns have been engaged by the primary bolt, cannot be installed AFT CONT PINS (LAPA): Turns = 16.858 – (1.25 x Primary bolt turns) 	

MANUAL EATCS N2 VENTING

IV	EV1 (FF)	
IV 1. √MCC, GO for manual venting	SO PORT EATCS VENT INITIATE (~ 20 min at wkst) 1. Translate to S0 Bay 04 Face 6 2. Open thermal shrouds to access port shunt jumper 3. Release jumper TA clamps (3) (TBD) 4. BRT to HR 3539 CAUTION When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing 5. Perform the following steps to close valve and demate S0 QD-F212 from S0-A508-M5: a. Remove thermal booty b. Push bail toward open posn (toward male half) w/great force (unsticks male sleeve seals) c. Remove SPD, temp stow d. Align flexhose/QDs to remove sideloads e. Depress detent button f. Close valve (pull bail aft) g. √Detent button up h. √Fwd white band visible i. Rotate locking collar to LOCKED j. Demate QD, temp stow (adjustable?) 6. Demate cap from 1.0" female vent tool 7. Perform the following steps to mate 1.0" vent tool to S0-A508-M5:	PORT SHUNT JUMPER WKST
	 f. Close valve (pull bail aft) g. √Detent button up h. √Fwd white band visible i. Rotate locking collar to LOCKED j. Demate QD, temp stow (adjustable?) 6. Demate cap from 1.0" female vent tool 7. Perform the following steps to mate 1.0" vent tool 	

EVA 1 CONTINGENCY

MANUAL EATCS N2 VENTING (Cont)

IV	EV1 (FF)
	8. Attach 1.0" female vent tool nozzle to HR 3543
IV: Record GMT start time for venting:	←—□
ioi venting.	 9. Perform the following steps to open valve on vent tool: a. Align flexhose/QDs to remove sideloads b. Depress detent button c. Open valve (push bail fwd) d. √Aft white band visible and detent button up
	S0 PORT EATCS VENT TERMINATE (~ 20 min at wkst)
3A. √MCC, GO to terminate venting3B. IV: Record GMT end time for venting:	←
ioi venting.	 Perform the following steps to close vent tool valve: a. Verify aft white band is visible b. Align flexhose/QDs to remove sideloads c. Depress detent button d. Close valve (pull bail aft) e. √Detent button up f. √Fwd white band visible Perform the following steps to demate vent tool from S0-A508-M5: a. Assess sideload potential
	 b. Demate vent tool, temp stow 3. Perform the following steps to mate and open valve on S0 QD-F212 to S0-A508-M5: a. Inspect QDs for debris or damage b. √Detent button up c. √Release ring retracted (fwd white band not visible) d. Mate QD e. √Fwd white band visible (snapback, pull and gap√) f. Rotate locking collar to unlock g. Depress detent button h. Open valve (push bail fwd) i. √Aft white band visible and detent button up

FS 16-16 EVA/116/FIN

MANUAL EATCS N2 VENTING (Cont)

IV	EV1 (FF)	
	j. Install 1" SPD — push down on latch tabs — √4 capture points – collar boss (2), bail boss (2), 2 line indicators — pull test √Button depressed by moving bail aft, then fwd k. Install thermal booty 4. Close S0 thermal shrouds	
1. √MCC, GO for manual venting	←	
	S0 STBD EATCS VENT INITIATE (~ 20 min at wkst)	
	 Translate to S0 Bay 03 Face 6 Open thermal shrouds to access stbd shunt jumper 	
	CAUTION When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing	
	4. Perform the following steps to close valve and demate S0 QD-F211 from S0-A505-M4: a. Remove thermal booty b. Push bail toward open posn (toward male half) w/great force (unsticks male sleeve seals)	STBD SHUNT JUMPER WKST
	c. Remove SPD, temp stow d. Align flexhose/QDs to remove sideloads e. Depress detent button f. Close valve (pull bail aft) g. √Detent button up h. √Fwd white band visible i. Rotate locking collar to LOCKED	

FS 16-17 EVA/116/FIN

MANUAL EATCS N2 VENTING (Cont)

IV	EV1 (FF)	
	 j. Demate QD, temp stow on S0 HR 3438 5. Demate cap from 1.0" female vent tool 6. Perform the following steps to mate 1.0" vent tool to S0-A505-M4: a. Inspect QDs for debris or damage b. √Detent button up c. √Release ring retracted (fwd white band not visible) d. Mate vent tool e. √Fwd white band visible (snapback, pull and gap√) 7. Attach 1.0" female vent tool nozzle to HR TBD 	
IV: Record GMT start time for venting:	 8. Perform the following steps to open valve on vent tool: a. Align flexhose/QDs to remove sideloads b. Depress detent button c. Open valve (push bail fwd) d. √Aft white band visible and detent button up 	
3A. √MCC, GO to terminate venting 3B. IV: Record GMT end time	S0 STBD EATCS VENT TERMINATE (~ 20 min at wkst) ← □	
for venting:	 Perform the following steps to close vent tool valve: a. Verify aft white band is visible b. Align flexhose/QDs to remove sideloads c. Depress detent button d. Close valve (pull bail aft) e. √Detent button up f. √Fwd white band visible Perform the following steps to demate vent tool from S0-A505-M4: a. Assess sideload potential b. Demate vent tool, temp stow Perform the following steps to mate and open valve on S0 QD-F211 to S0-A505-M4: a. Inspect QDs for debris or damage 	

FS 16-18 EVA/116/FIN

MANUAL EATCS N2 VENTING (Cont)

IV	EV1 (FF)	
	 b. √Detent button up c. √Release ring retracted (fwd white band not visible) d. Mate QD e. √Fwd white band visible (snapback, pull and gap√) f. Rotate locking collar to unlock g. Depress detent button h. Open valve (push bail fwd) i. √Aft white band visible and detent button up j. Install 1" SPD – push down on latch tabs – √4 capture points – collar boss (2), bail boss (2), 2 line indicators – pull test √Button depressed by moving bail aft, then fwd k. Install thermal booty 4. Close S0 thermal shrouds 	

FS 16-19 EVA/116/FIN

MANUAL EATCS N2 VENTING TASK DATA SHEET

Tools:

EV1 (FF)	EV2 (FF)
1.0" vent tool	
(1.0" cap tool)	
(1.0" bail lever tool)	
(1.0" QRT/FID gauge)	

EVA Fasteners: N/A

EVA Connectors: N/A

Foot Restraints: N/A

Notes:

 The shunt jumper has 2 female QDs and is attached to two male QDs on the truss. For manual N2 venting, any of the 2 male QDs can be used, so EV can demate either and of the jumper

Cautions:

 When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing

Warnings: N/A

Assumptions:

- 1. SPDs are already installed on shunt jumpers
- 2. Venting can be performed from either of the 2 males
- 3. QD tools must be pre-staged in the crewlock prior to EVA 1 in order to support manual venting. This failure would be known prior to EVA 1:
- □ Crewlock bag (for QD tools)
- □ 1.0" NH3/N2 Female Vent Tool
- □ 1.0" cap tool (contingency only)
- □ 1.0" bail lever tool (contingency only)
- □ 1.0" QRT/FID gauge (contingency only)

FS 16-20 EVA/116/FIN

SOFT CAPTURE MANUAL OVERRIDE

IV/SSRMS	EV1 (FF)	EV2 (FF)
1. ROBO: √SSRMS in limp mode	←	
ISS Fwd View	Depending on which corner fails soft ca for APFR ops, and the other will assist	apture, one crewmember will be prime
Port Port	 If necessary, temp stow tools Translate to failed corner Install APFR, configure settings per APFR INFO in IV column Ingress APFR Using P5 HRs, manually attempt to pull P5 into soft capture; √P4 soft capture pin has engaged P5 coarse alignment cone Pull out ~ 6 inches of excess strap (~ length of PRD) and ratchet strap a minimum of 14 strokes to ensure strap won't slip under tension Ratchet PRD to achieve proper preload 	 If no joy with soft capture pin set, translate to A/L Toolbox 1 (stbd), retrieve PRD from slot 7 Translate to failed corner at P5 Route PRD between P5 and P4 Hold PRD housing flush against structure adjacent to P5 HR Route retractable strap around P5 trunnion strut and back around P4 soft capture assy housing Hook straps together and remove excess slack Ensure strap is flush to structure and not twisted Ensure strap is not routed over HRs
	8. √P4 soft capture pin has engaged P5 coarse alignment cone9. Egress APFR	4. Remove PRD

FS 16-21 EVA/116/FIN

SOFT CAPTURE MANUAL OVERRIDE TASK DATA SHEET

Tools: Backup tool shown in ()

EV1	EV2
PRD	
APFR	

Foot Restraints

Task	WIF	APFR Setting
Corner 1 PRD routing	P4 WIF 18	[8,OO,D,12]
Corner 2 PRD routing	P4 WIF 19	[6,PP,K,11]
Corner 3 PRD routing	P4 WIF 17	[5,RR,J,12]
Corner 4 PRD routing	P4 WIF 20	[6,WW,A,10]

EVA Fasteners: NA

Notes:

1. Depending on which corner fails soft capture, one crewmember will be prime for APFR ops, and the other will assist with PRD routing as necessary

Cautions:

1. P5 can be translated on with any 2 diagonal corners in soft capture

Warnings:

1. NA

FS 16-22 EVA/116/FIN

MRTAS PRIMARY BOLT CONTINGENCIES

IV	EV1/EV2 (FF)				
	Failure of a primary bolt is defined as not meeting any 1 of the following 3 criteria: A. Full torque achieved B. Bolt shoulder has no gap C. Equipment hook gap check is good (applies to corner's 1 and 2 only)				
A. Record Torque: PRD ROUTING 1. Route PRD between P5 and P4 Hold PRD housing flush against structure adjacent to P5 HR Route retractable strap around P5 trunnion strut and back around P4 soft capture assy housing Hook straps together and remove excess slack Ensure strap is flush to structure and not twisted Ensure strap is not routed over HRs Ingress APFR if reqd Pull out ~ 6 inches of excess strap (~ length of PRD) and ratchet strap a minimum of 14 strokes to ensure strap won't slip under tension	1. PGT [B1, CCW2, 30.5]-RAD-7.8"-Ext-5/8: Loosen primary bolt same # of turns that bolt was driven (allowable torque for RAD) Floot galling has occurred, and primary bolt will not loosen, go to step 3b Check cases a-d to determine next steps: a. If all primary bolt criteria passes, proceed to next MRTAS corner b. If bolt galling has occurred and the primary bolt cannot be used, go to MRTAS CONTINGENCY BOLT INSTALL procedure c. If gap check fails, retrieve gap check tool from corner 1: PGT [A6, CCW2, 30.5]-6"-Ext-7/16: Release gap check tool bolts (2), 12-14 turns Perform gap check. Report to MCC gap check tool depth If gap check passes and remaining criteria passes, proceed to next MRTAS corner If gap check passes and remaining criteria passes, proceed to next MRTAS corner If gap check fails, go to step 4 d. If any other primary bolt criteria fails, go to step 4 4. Retrieve PRD from A/L Toolbox 1 (stbd) slot 7; Install PRD and apply preload – reference IV column, PRD ROUTING PRD ROUTING				
Ratchet PRD to achieve proper preload	7. PGT [B1, CW2, 30.5]- RAD-7.8"-Ext-5/8: Drive primary bolt 54 turns (PGT), 27 turns (bolt)				
B. Record torque:	If all criteria are met, proceed to next RTAS corner If any criteria fail, go to MRTAS CONTINGENCY BOLT INSTALL procedure				

FS 16-23 EVA/116/FIN

MRTAS PRIMARY BOLT CONTINGENCIES TASK DATA SHEET

Tools:

	•
EV1	EV2
PGT	PGT
RAD	RAD
7.8-in ext x 5/8	7.8-in ext x 5/8
Torque Wrench	Torque Wrench

Foot Restraints:

Task	WIF	APFR Setting
Bolt 1 PRD routing	P4 WIF 18	[8,OO,D,12]
Bolt 2 PRD routing	P4 WIF 19	[6,PP,K,11]
Bolt 3 PRD routing	P4 WIF 17	[5,RR,J,12]
Bolt 4 PRD routing	P4 WIF 20	[6,WW,A,10]

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
RTAS Primary Fastener	1,2,3,4	5/8"	4	12.0 (w/RAD)	105.3	27 (bolt)	30
Gap check tool bolts	none	7/16"	2	8.3	12.2	12-14	30

Notes:

- 1. Primary bolt engagement criteria is the following:
 - > Full torque achieved
 - Bolt shoulder has no gap
 - ➤ Equipment hook gap check is good. If gap check using equip hook fails, retrieve gap check tool from corner 1 to perform more accurate gap check

Cautions:

- Primary bolts must be fastened in the following order; Bolt 1 (fwd/zenith), Bolt 2 (fwd/nadir), Bolts 3 (aft/zenith) and 4 (aft/nadir) can be fastened in any order AFTER bolts 1 and 2. This also applies in the event of any primary bolt contingencies. Each corner must be secured in the required order regardless of whether a primary bolt or contingency bolt is used
- 2. Hardware sensitive to crew loads. Do not apply a push force on primary bolt. Damage to self-feeding nut may result

Warnings:

1. N/A

Other:

1. If primary bolt fails at corner 3 or 4 (whichever is driven first), attempt primary bolt at next corner (3 or 4) prior to installing contingency bolt at failed corner. If the second bolt drives successfully, the contingency bolt may be installed at the failed corner without installing a PRD

FS 16-24 EVA/116/FIN

MRTAS CONTINGENCY BOLT INSTALL

IV	EV1/EV2 (FF)
APFR INFO For corner 4 (P4 WIF 20): √settings: [6,WW,A,10] For corner 2 (P4 WIF 19), relocate APFR from WIF 20 to WIF19: reconfigure to: [6,PP,K,11] For corner 3 (P4 WIF 17), √settings: [5,RR,J,12] For corner 1 (P4 WIF 18), relocate APFR from WIF 17 to WIF 18; reconfigure to: [8,OO,D,12]	If a primary bolt contingency required the use of a PRD at the failed corner, steps 1 through 3 are not required for the contingency bolt procedure 1. If reqd, install APFR for PRD ops at failed corner, configure settings per APFR INFO in IV column 2. Retrieve PRD from A/L Toolbox 1 (stbd) slot 7; install PRD and apply preload – reference IV column, PRD ROUTING NOTE Gap Check Criteria: • For equip tether hook, tip of hook should not pass through or penetrate gap between RTAS housings • For gap check tool, tip of tool should not penetrate gap between RTAS housings past second line 3 Perform gap check using equip tether hook 4. Verify contingency nuts centered and aligned within anti-rotation slots > If not centered, adjust by jiggling w/gloved hand 5. PGT [B2, CCW1, 30.5]-6"-Ext-7/16: Loosen spacer locking device bolt, ~ 1 turn 6. Tighten spacer sleeve by hand until snug, ~ 10 turns (CW)
Record which contingency sleeve used:	
PRD ROUTING 1. Route PRD between P5 and P4 Hold PRD housing flush against structure adjacent to P5 HR Route retractable strap around P5 trunnion strut and back around P4 soft capture assy housing Hook straps together and remove excess slack	 7. Verify sleeve aligned w/in nut by attempting to jiggle back side of nut If spacer does not seat in nut, back out and re-attempt 8. PGT [A6, CCW2, 30.5]-6"-Ext-7/16: Release gap check tool bolts (2) from corner 1, 12-14 turns (possibly done) 9. Install gap check tool around contingency spacer sleeve (friction fit) NOTE Contingency Bolt Engagement Criteria:
 Ensure strap is flush to structure and not twisted Ensure strap is not routed over HRs Ingress APFR if reqd 	10. PGT [B1, CW2, 30.5]-6"-Ext-7/16: Drive contingency bolt 7-9 turns to clear launch threads Push bolt ~ .5-in to contact nut (no turns reqd) Drive contingency bolt 9-11 turns to fully engage nut

FS 16-25 EVA/116/FIN

MRTAS CONTINGENCY BOLT INSTALL (Cont)

	IV	EV1/EV2 (FF)
4.	strap (~ length of PRD) and ratchet strap a minimum of 14 strokes to ensure strap won't slip under Tension	
5.	Record torque and turns: Torque: Turns:	 11. Perform gap check using equip tether hook 12. Check cases A and B to determine next steps: a. If all contingency bolt criteria pass, go to step 13 b. If any contingency bolt criteria fail, go to next contingency bolt, and pick up at step 6 13. PGT [A5, CCW2, 30.5]-6"-Ext-7/16: Release nut locking plate bolt, 12-14 turns 14. Remove nut locking plate (lanyarded), wire tie to adjacent structure 15. Remove gap check tool from spacer sleeve, attach to MWS 16. PGT [B2, CW1, 30.5]-6"-Ext-7/16: Tighten contingency spacer locking device bolt, ~ 1 turn (do not exceed 1 turn) 17. Remove PRD, temp stow
		NOTE After all 4 RTAS corners have initial torque, perform final torquing on contingency bolt 18. Configure torque wrench w/7.8-Ext-5/8: set to 52 ft-lb; tighten contingency bolt until torque wrench trips (~1/4 turn)

FS 16-26 EVA/116/FIN

MRTAS CONTINGENCY BOLT INSTALL TASK DATA SHEET

Tools: Backup tool shown in ()

EV1	EV2	
PGT	PGT	
RAD	RAD	
7.8-in ext x 5/8	7.8-in ext x 5/8	
Torque Wrench	Torque Wrench	

Foot Restraints:

Task	WIF	APFR Setting
Bolt 1 PRD routing	P4 WIF 18	[8,OO,D,12]
Bolt 2 PRD routing	P4 WIF 19	[6,PP,K,11]
Bolt 3 PRD routing	P4 WIF 17	[5,RR,J,12]
Bolt 4 PRD routing	P4 WIF 20	[6,WW,A,10]

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
RTAS Cont Bolts	1,2,3,4	5/8"	4	Install: 52.0		7-9 (launch threads) 9-11 (P4 nut)	30
Cont Spacer Sleeve Locking Device Bolt	none	7/16"	1	Release: 16.0 Install: 16.0	31.1	.5-1	30
Gap check tool bolts	none	7/16"	2	Release: 8.3	12.2	12-14	30
Cont Nut Locking Plate Bolts	none	7/16"	2	Release: 7.0	12.2	12-14	30

Notes:

- 1. Contingency bolt engagement criteria is the following:
 - > Full torque achieved
 - > Minimum turn count (after bolt drops out of launch threads)
 - Equipment hook gap check is good (this applies to corner's 1 and 2 only). If gap check using equip hook fails, retrieve gap check tool from corner 1 to perform more accurate gap check

Cautions:

- Primary bolts must be fastened in the following order; Bolt 1
 (fwd/zenith), Bolt 2 (fwd/nadir), Bolts 3 (aft/zenith) and 4 (aft/nadir)
 can be fastened in any order AFTER bolts 1 and 2. This also applies
 in the event of any primary bolt contingencies. <u>Each corner must be</u>
 secured in the required order regardless of whether a primary bolt or
 contingency bolt is used
- 2. Hardware sensitive to crew loads. Do not apply a push force on primary bolt. Damage to self-feeding nut may result

Warnings:

1. N/A

FS 16-27 EVA/116/FIN

SOLAR ARRAY

MANUAL OVERRIDE TO RETRACT MAST (~ 02:30)

IV	EV1 (FF)	EV2 (FF)
1A. √MCC inhibits in place: (SODF:EPS:MALFUNCTION: PRIMARY POWER, FAILURE TO RETRACT MAST REMOTELY)		
1B. Verify mast canister MDA facing nadir and BGA latched; 4B BGA = 180.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched		
1C. √MCC free drift or CMG	MANUAL OVERRIDE TO RETRACT MAST	MANUAL OVERRIDE TO RETRACT MAST
control prior to mast retraction	 Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge BRT to mast canister HR Ratchet-2"-Ext-7/16: Rotate Manual Override Actuator Shaft on left side of MDA 180 deg to disengage MDA, Indicator – MANUAL NOTE Expect ~ 1300 turns per PGT battery. A spare battery will be required for a manual retract of an array that fails at a position that is more than half deployed. Prior to removing PGT from MDA backup fastener, engage ratchet w/2-in socket onto bolt on side of MDA and rotate 180 deg to AUTOMATIC 	1. Assist EV1 as reqd

FS 16-28 EVA/116/FIN

MANUAL OVERRIDE TO RETRACT MAST (~ 02:30) (Cont)

IV	EV1 (FF)	EV2 (FF)		
IV: check limit switch indication that array has fully retracted;	4. PGT [A7, CW3, 10.5]-2"-Ext-7/16: Drive MDA backup fastener 2460 turns (for full retract) (hard stop)			
give EV go to re-engage MDA clutch	 5. Perform the following steps to re-engage MDA clutch: Keep the PGT with 2-in socket installed on the backup drive fastener Install the ratchet with 2-in socket onto the Manual Override Actuator Bolt Rotate Manual Override Actuator Shaft 180 deg to disengage MDA, indicator – AUTOMATIC 6. Remove PGT and ratchet, stow on MWS 7. Translate to airlock 	2. Translate to airlock		

FS 16-29 EVA/116/FIN

MANUAL OVERRIDE TO RETRACT MAST TASK DATA SHEET

Tools: Backup tool shown in ()

EV1 (FF)	EV2 (FF)
Ratchet with 2-in	
PGT with 2-in	
Spare PGT battery	
(APFR)	(MCHD)
	 Located in Mast Canister Bag on aft/stbd Node

EVA Fasteners:

Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Backup drive fastener (MDA fastener)		7/16	1		9	13.3	Up to 2461	60
Mast Canister manual Override Actuator Bolt		7/16	2 per	2.5	NA	50	.5	10
MCDH Fasteners		7/16	4	10	NA	TBD	Zip	10

EVA Connectors:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

Foot Restraints: Backup tool shown in ()

Task	WIF	APFR Setting
(4B solar array manual retract) (keel side)	P6-37	[12,FF,F,12]

Notes:

- The Mast Canister Handling Device (MCHD) is located in the Mast Canister Bag on the aft/stbd Node. It is available for the crew to use in the event they must do a complete manual retraction and want to reduce overall PGT operations
- Depending on crew comfort, either an APFR can be used for the manual retract, or they can directly BRT to the Mast Canister HRs
- 3. The right side mast canister manual override actuator shaft bolt can be used but a PGT with 6-in socket must be used and the bolt is accessed from under the adjacent HR
- 4. Rationale for leaving the PGT installed on the MDA bolt while taking the override actuator bolt back to AUTO: Sunnyvale is concerned that once the PGT is removed, the Solar array will tend to backdrive and re-extend the mast off of the hard stop (and thus move the blankets out of the latching capture envelope). The PGT serves to keep the array itself from backdriving, and sort of acts like a locking mechanism for the bolt

Cautions:

 Avoid contact with blanket box latches and mechanisms on underside of blanket box

Warnings:

- Sharp edge/pich point entrapment hazard: avoid contact with outboard underside of SABB due to exposed reels, guide wire, and tension mechanisms
- 2. Avoid contact with blacket box latches during manual override operation

Timeline Considerations:

- Retrieving the MCHD from the mast canister bag will add time to the EVA. Perform the following steps to unfold and install the MCHD:
 - a. Deploy MCHD PGT swingarm and appendages
 - b. Install MCHD onto mast canister, install zip nuts (4)
 - c. **PGT [A7 9.2, CW2, 10.5]-2"-Ext-7/16:** Secure MCHD fasteners (4) to hardstop
 - d. Place PGT in MCHD swingarm when reqd

Assumptions:

- 1. 85' safety tether will reach P6 4B
- 2. Crew will BRT for task, but APFR position is available if reqd

FS 16-30 EVA/116/FIN

MANUAL OVERRIDE TO LATCH/UNLATCH (TENSION) 4B SABB

1A. √MCC Inhibits in place: Perform {TBD SAW XX FAILURE TO LATCH (TENSION) SABB REMOTELY} (SODF: EPS: MALFUNCTION: PRI PWR) 1B. Verify affected SABB positioned over IEA and BGA latched: Verify: Left SABB: Actual angle, deg = 270.000 (+/- 0.5) OR Right SABB: Actual angle, deg = 90.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched 1C. √MCC free drift or CMG control prior to mast retraction 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard) 1. Insert PIP pin into lock lever position	IV	EV1 (FF)	EV2 (FF)
1B. Verify affected SABB positioned over IEA and BGA latched: Verify: Left SABB: Actual angle, deg = 270.000 (+/- 0.5) OR Right SABB: Actual angle, deg = 90.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched 1C. √MCC free drift or CMG control prior to mast retraction 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override operation Moving equipment. Avoid contact with blanket box latches and mechanisms on underside of blanket box Equipment damage. Avoid contact with blanket box latches and mechanisms on underside of blanket box MARNING Sharp edge/pinch point/entrapment hazard. Avoid contact with underside of SABB due to exposed reels, guide-wire, and tensio mechanisms 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard)	Perform {TBD SAW XX FAILURE TO LATCH (TENSION) SABB REMOTELY} (SODF: EPS:		
Left ŚABB: Actual angle, deg = 270.000 (+/- 0.5) OR Right SABB: Actual angle, deg = 90.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched 1C. √MCC free drift or CMG control prior to mast retraction 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard)	Verify affected SABB positioned over IEA and BGA latched:	Moving equipment. Avoid contact w	
Right SABB: Actual angle, deg = 90.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched 1C. VMCC free drift or CMG control prior to mast retraction 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard)	Left SABB: Actual angle, deg = 270.000 (+/- 0.5)		
control prior to mast retraction 1. Translate to P6 4B (port) mast canister HRs (nadir) via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard)	Right SABB: Actual angle, deg = 90.000 (+/- 0.5) Motor State – OFF Latch 1 Pin Status – Latched	Sharp edge/pinch point/entrapment underside of SABB due to exposed	t hazard. Avoid contact with
CAUTION Moving equipment. Avoid contact with blanket box latches during manual override operation 6. PGT [A6, CW2, 10.5]-2"-Ext-7/16: (or 6-in socket) Push to engage MDA drive fastener (3-10 lb); drive		via P6 stbd/aft edge 2. BRT to mast canister HR 3. Release PIP pin from backup position lever 4. Move override lever to MANUAL position (hard) 5. Insert PIP pin into lock lever position CAUTION Moving equipment. Avoid contact with blanket box latches during manual override operation 6. PGT [A6, CW2, 10.5]-2"-Ext-7/16: (or 6-in socket)	1. Assist EV1 as reqd

FS 16-31 EVA/116/FIN

MANUAL OVERRIDE TO LATCH/UNLATCH (TENSION) 4B SABB (Cont)

IV	EV1 (FF)	EV2 (FF)
	(Latches along blanket box are visible and will move to engaged posn) 7. Release PIP pin from override positioning lever 8. Move override lever to AUTOMATIC posn 9. Insert PIP pin into lock lever posn 10. PGT [RCCW, 10.5]-2"-Ext-7/16: (or 6-in socket) Push to engage MDA drive fastener (3-10 lb); drive fastener 1/4 turn to engage clutch pins (may "feel" pins drop in)	

FS 16-32 EVA/116/FIN

MANUAL OVERRIDE TO LATCH (TENSION) 4B SABB TASK DATA SHEET

Tools: Backup tool shown in ()

EV1 (FF)	EV2 (FF)
PGT w/6-in or 2-in socket	PGT w/6-in or 2-in socket
(APFR)	

EVA Fasteners:

Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Backup drive fastener		7/16	1		9		48 +/- 1 turns	10

EVA Connectors: NA

Foot Restraints:

Task	WIF	APFR Setting
4B solar array latch override	P6-37 (near P6	Left SABB: [12,FF,F,9] Right SABB: [12,FF,F,3]
	IEA keel)	(Ingress aid required for ingress)

Notes:

- 1. Hi-tension = latch = cw Low-tension = unlatch = ccw
- 2. The 1/4 turn at the end of the override will always be in the opposite direction as the initial turning
- 3. SABB location designator: The right and left SABBs are defined by standing with one's back toward the mast canister on the solar array active side (the side where the blanket boxes are initially together for launch, opposite the SSU) with one's head outboard toward the array. The left SABB is then on one's left side and the right SABB is on one's right side
- 4. PIP pin not reqd to lock MDA override lever into MANUAL posn
- 5. The additional 1/4 turn at the end of the manual latching is required in order to re-align the pins with the slots on the gear mechanisms. Once the 1/4 turn is made, the spring-loaded mechanism will push the slots on the torque shaft gear onto the pins on the motor gear
- 6. BRT to the mast canister HR will be the nominal plan for latching override; APFR use is a backup

Cautions:

 Equipment damage. Avoid contact with blanket box latches and mechanisms on underside of blanket box

Warnings:

 Sharp edge/pinch point/entrapment hazard. Avoid contact with underside of SABB due to exposed reels, guide-wire, and tension mechanisms

Assumptions:

- 1. 85' safety tether will reach P6 4B
- 2. Crew will BRT for task, but APFR position is available if regd

FS 16-33 EVA/116/FIN

SOLAR ARRAY JETTISON

IV	EV1 (FF)	EV2 (FF)
IV 1A. √MCC SSU inhibits in place: Configure SSU inhibits: Perform {TBD SSU TBD SAFING FOR REMOVAL} (SODF: EPS: CORRECTIVE: PR PWR) 1B. Mnvr ISS for SAW jettison 1C. Posn and safe SAW for SSU Removal. Perform {2.106 PVM CONFIG BGA P6 4B TO SAFE LOCK MODE} (SODF: EPS: NOMINAL: PRI PWR), using the following: BGA 4B Cmded Angle = 270 BGA 4B Latch Select = 1	Electrical shock hazard: Voltage hazard en prior to removal and must only be removed. Protrusion hazard: SSU alignment post probetween structure and self during SSU rendered Electric shock hazard: SSU Shunt Plug instance Crew must wait the specified time period work crew will need to move away from exposed Collision hazard: Solar array motion should collision hazard with the EV crew if the EV TOOL RETRIEVAL AND SETUP 1. Translate to Z1 stbd toolbox 2. Open right door 3. Retrieve square TM w/7/16 recessed socket from	WARNING xists at the connectors of the SSU; SSU must be safed during orbit eclipse otrudes beyond the mast canister. Maintain clearances noval stallation and SSU removal must occur during eclipse. Thile voltage drops to safe levels before proceeding. EV delectrical receptacles during day pass deprevented by locking the BGA. This avoids a crew is within 24 inches of the array rotational envelope TOOL RETRIEVAL AND SETUP 1. Translate to Mast Canister/Aux bag (PMA1 stbd by Node bag) 2. Retrieve mast canister handling device (MCDH);
	 slot 1, stow on MWS (release slider lock only) Close door – both latches reqd if not coming back Retrieve square scoop from lid If required, translate to Z1 forward face and demate Cannon connector cap from Z1 J259 or J260, stow Retrieve APFR from TBD, attach to BRT Translate to P6 WIF 33 (aft/port/zenith trunnion) via P6 stbd/aft edge Install APFR into WIF 33, configure to: [4,PP,G,9] 	attach to BRT 3. Translate to TBD WIF, retrieve APFR, attach to BRT NOTE It may be difficult to translate with both the APFR and the mast canister handling device. Two trips up to P6 may be required to get both tools to the worksite 4. Translate to P6 WIF 33 (aft/port/zenith trunnion) via P6 stbd/aft edge 5. Temp stow APFR, MCDH, and SSU cover 6. Translate to port BMRRM

FS 16-34 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
2. √MCC GO for BMRRM J1 demate and SSU shunt plug Installation (orbit eclipse)	1. During orbit eclipse (2 min wait after transition from insolation to eclipse), remove mast canister ground test port caps (2) and stow in trash bag 2. During orbit eclipse, position MLI shroud as shown below	1. Remove BMRRM thermal shroud (peels back) 2. During orbit eclipse, demate connector from BMRRM J1 3. During orbit eclipse, mate Cannon connector cap to BMRRM J1
3. √MCC GO for SSU Removal (orbit eclipse)	 3. During orbit eclipse, install SSU shunt plug adapter with bails facing outward (not against mast canister) 4. Install MLI shroud 5. Ingress APFR in WIF 33 6. Install square TM onto SSU square microfixture, √anti-backlash neutral 	

FS 16-35 EVA/116/FIN

IV	EV1 (FF	=)	EV2 (FF)
	11. Egress APFR and report when clear of worksite		 4. Receive SSU, install cover or temp stow in ORU bag 5. Translate away from BGA rotation plane and report when clear of worksite
		WAR Moving equipment hazard mast canister/beta gimba	
4A. Posn and safe SAW for ECU Removal. Perform {2.106 PVM CONFIG BGA P6 4B TO SAFE LOCK MODE} (SODF: EPS: NOMINAL: PRI PWR), using the following: BGA 4B Cmded Angle = 180 BGA 4B Latch Select = 1			
4B. When BGA latched, give EV crew GO to ingress ECU worksite	ECU REMOVAL (if reqd) 1. Relocate APFR to P6 WIF 37 Configure to: [8,00,A,3] 2. Ingress APFR	(port IEA by keel),	BMRRM FASTENER/CONNECTOR RELEASE 1. Translate to 4B BMRRM
 √MCC ECU and BMRRM cable demate inhibits in place: PCS: Remove ECU Power PVM: EPS: BGA 4B 			

FS 16-36 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
BGA 4B sel RPCM XX A RPC 02 RPCM XX A RPC 02 Cmd RPC Position – Open (Verify - Op) (Expect Caution Message: BGA 4B Loss of Comm)	 PGT [A7, CCW2, 10.5]-sq TM w/7/16" REC: Release fastener, 1 turn Remove TM, install square scoop on ECU PGT [A7, CCW2, 10.5]-6"-Ext-7/16: Release fastener, 10 +/- 2 turns √Status indicator – UNLOCK Remove ECU, transfer to EV2 	 Remove BMRRM thermal shroud (peels back) BRT to BGA housing HR PGT [A5, CCW2, 10.5]-6"-Ext-7/16: Release BMRRM center fastener 10 +/- 2 turns On MCC GO, disconnect the following connectors from the BMRRM: Demate connector from J3 Demate connector from J2 Receive ECU from EV1, temp stow
6. √MCC GO for SAW Jettison	P6 4B SAW JETTISON PREP 1. Egress APFR 2. Reconfigure APFR to: [12,FF,F,12] (still WIF 37)	P6 4B SAW JETTISON PREP 1. Install APFR into P6 WIF 33, configure to: [4,PP,H,9]
	 Ingress APFR Receive MCHD from EV2 Deploy MCHD appendages Install MCHD on mast canister (4 zip nuts) PGT [A7, CW2, 10.5]-6"-Ext-7/16: Fasten MCHD corner attach fasteners (4) to hard stop Hold MCHD HRs, give EV2 GO to release vice clamp fastener 	 Transfer MCHD to EV1 Ingress APFR On EV1 GO: PGT [A5, CCW2, 10.5]-6"-Ext-7/16: Release platform vice clamp fastener, 19 turns (hard stop)

FS 16-37 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	Using MCDH, move canister away from beta gimbal at a velocity less than 1 ft/min. Move mast canister 2 feet from beta gimbal separation plane. Correct wing attitude as reqd to achieve stability *** TBD release plan***	Assist EV1 to separate mast canister from beta gimbal and control SAW using handholds on BGA housing and BGA platform. Call out separation distance until 2 ft separation achieved Release BGA platform handholds, egress and move clear of predicted SAW separation direction *** TBD release plan***

FS 16-38 EVA/116/FIN

SOLAR ARRAY JETTISON TASK DATA SHEET

Tools:

EV1 (FF)	EV2 (FF)
APFR	APFR
PGT with 6" socket	MCHD (TBD)
Square scoops (2)	SSU cover or large ORU bag (SSU)
Square TM with 7/16" REC socket	Med ORU bag (ECU)
SSU shunt plug adapter and plugs (2)	
Cannon connector tool	
Cannon connector cap (size 37)	

EVA Fasteners:

Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
SSU Fastener	NA	7/16	1	NA	45	TBD	11+/-2	
ECU Fastener	NA	7/16	1	NA	35	50	11+/-2	
BMRRM Center Fastener	NA	7/16	1	NA	7.5	TBD	10+/-2	
MCHD Fasteners	NA	7/16	4	2.5-3.3	2.5-3.3	TBD	zip	
Vice Clamp	NA	7/16	1	NA	7.5	TBD	19+/-2	

EVA Connectors:

Harness	From	То	Clamps (#)	Conn Size	Function
W05 P23 J3		BMRRM P3		25	ECU feed; SSU control pwr; 1553B
W06 P22 J2		BMRRM P2		25	ECU cross feed
		BMRRM P1		37	Primary Power

Foot Restraints:

Task	WIF	APFR Setting
4B SSU access	P6-33	[4,PP,G,9]
4B ECU access	P6-37	[8,OO,A,3]
4B BMRRM access	P6-33	[4,PP,H,9]
4B Jettison	P6-37	[12,FF,F,12]
4B Vice Clamp Release	P6-33	[4,PP,H,9]

SAW Mass: ~ 2500 lbs (1133.9 kg)

Notes:

- If SSU Removal is done from P6 WIF 33 at a BGA of 270, an ingress will be needed for ingress
- 2. If SSU remains installed, the MCHD should be used (better reach and HR options); if SSU is removed, the MCHD may not be needed
- 3. Caps are not needed for BMRRM J2 and J3 since they are not hot

Warnings:

- 1. Electrical shock hazard: remove SSU only during orbit eclipse
- Protrusion hazard: SSU alignment post protrudes beyond the mast canister. Maintain clearances between structure and self during SSU removal
- Moving equipment hazard. Avoid contact with mast canister/beta gimbal during rotation of SAW

Timeline Considerations:

- The SAW jettison timeline PET can be reduced by not removing the SSU and ECU
- The SSU Removal does not necessarily have to be removed at a BGA of 270; it could possibly be done at 180 and FF; this would eliminate an entire BGA rotation prior to jettison

Assumptions:

- EV1 gets square scoops (2) from inside ISS (scoops needed for SSU and ECU removal if performed)
- 2. EV2 gets square TM from stbd Z1 toolbox
- 3. 85' safety tethers will reach P6 worksite
- 4. EV2 has SSU cover from inside ISS (or Ig ORU bag)
- SSU shunting plug remains installed and gets jettisoned along with SAW
- If no size 37 Cannon connector cap inside, EV crew will need to retrieve one from Z1 during EVA

Prior to EVA, complete the following setup steps:

- 1. Retrieve SSU shunt plug adapter and SSU shunt plugs (2) from TBD
- 2. Remove SSU shunt plug adapter caps (2, J5A and J6A) from adapter, and mate SSU shunt plugs (2, J5A and J6A) to adapter jacks (plugs can go to either adapter jacks)
- 3. Remove caps (2) from adapter ground service equipment jacks
- 4. Stow SSU shunt plug adapter with plugs and Cannon connector tool in crewlock bag

EVA 2 CONTINGENCY

CHANNEL 2/3 CONNECTOR BACKOUT (01:00)

IV	EV1 (FF)	EV2 (FF)				
Verify w/MCC inhibits in place: Power Reconfig Inhibit Check (SODF: ASSY OPS: EPS CH 2/3 Powerdown for EVA 2, steps 6 and 7 complete (DCSU 2B RBI 6 open) (DCSU 2A RBI 6 open)	VConnectors for damage, EMI band, F P1-3A DDCU RECONFIGURATION (Panel A9)					
	 Translate to P1 HR 3602 (P1 Bay 14, Face 1) Perform safety tether swap onto HR 3602 with 55' safety tether, verify ST config Translate to P1 Bay 16, enter face 1 Remove connector cap from J8 on DDCU coldplate connector box (cap is lanyarded to panel) Demate P1 P169 (W5113) from J7; mate to J8 Install connector cap on J7 □ connector closeout MBSU BYPASS JUMPER (2/3) RECONFIGURATION (CID 7 Removal) Translate to P1 HR 3602 (P1 Bay 14, Face 1) Perform safety tether swap onto airlock safety tether, retrieve spare, verify ST config Translate to S0 Bay 04 Access MBSU nadir reconfig worksite thru face 1 Attach MWS EE to HR 3536 Remove connector cap from J490; temp stow Demate S0 P487 from S0 J487; mate to S0 J490 Demate S0 P488 from S0 J488, mate to S0 J487 Install connector cap on J488 □ connector closeout 	NOTE Avoid contact with S0 radiator 2. Demate S0 P215 (W4014) from Lab J215; mate to S0 J474 3. Demate S0 P216 (W4012) from Lab J216; mate to S0 J475 4. Demate S0 P242 (W4186) from Z1 J442; mate to S0 J478 5. Demate Z1 P316 (W24C) from Z1 J216 (tray), mate to Lab J216 (CID removed) 6. Demate Z1 P315 (W24B) from Z1 J215 (tray), mate to Lab J215 (CID removed) 7. □ connector closeout				

FS 16-40 EVA/116/FIN

CHANNEL 2/3 CONNECTOR BACKOUT (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
	S0-2B DDCU RECONFIGURATION (Panel A70) 1. Translate to S0 Bay 02, access thru face 1 2. Remove connector cap from J8 on DDCU coldplate connector box (cap is lanyarded to panel) 3. Demate S0 P574 (W4144) from J7; mate to J8 4. Install connector cap on J7 LAB 2A DDCU SECONDARY PWR DISCONNECT FROM S0	Z1-003 PATCH PANEL 5 RECONFIGURATION (DDCU HP 3B) (zenith panel) CAUTION Avoid contact with Z1 heat pipes and SASA antennas
When EV2's connections complete, notify MCC	 (Panel A165) Translate to S0 Bay 01 Access worksite through face 1 (looking port) Demate S0 P338 (W4144) from S0 CH 2/3 pwr cable J338A Demate S0 CH 2/3 pwr cable P338A from S0 J338 Mate S0 P338 to S0 J338 Retrieve pwr cable, stow on MWS □ connector closeout 	 Translate to Z1 stbd face Fold back thermal shroud (STD SHRD Z1/02/04-03), release Velcro straps from HRs 6005 and 6024 6005 and 6024 Remove connector cap from J2 Demate Z1 P2 (W21) from Z1 J1; mate to Z1 J2 Install connector cap on J1 Cap connector closeout Reinstall thermal shroud
	S0 FWD STBD AVIONICS RECONFIGURATION (Panel A148) 1. Translate to stbd S0 connector panel (Bay 01, Face 6) 2. BRT to S0 HR 3443 3. Remove DF cap from S0 J238 4. Demate P230 (W9002) from S0 J230; mate to S0 J238 5. Install DFcap on S0 J230 6.	
When all EV1's connections complete, notify MCC		

FS 16-41 EVA/116/FIN

CHANNEL 2/3 CONNECTOR BACKOUT (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
	NOTE Z1-006 PP 2 Reconfig will not be backed out since the nominal reconfig will be skipped in the event of either an MBSU or DDCU R&R. The steps are listed for info only	
	Z1-006 PATCH PANEL 2 RECONFIGURATION (SPDA Z1-3B) (zenith panel)	
	Translate to Z1 port face; fairlead above Z1, MBM P6 HR 5308	
	CAUTION Avoid contact with PCUs and S0 Radiator	
	NOTE J3 label is missing off of patch panel 2	
	 Remove connector cap from J3; temp stow Demate Z1 P1 (W05) from Z1 J1; mate to Z1 J3 Install connector cap on J1 □ connector closeout 	

FS 16-42 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
Verify w/MCC ESP2 inhibits in place: RPCM N1RS2-B RPC10 – open and close INHIBITED RPCM S04B F RPC 12 – open and close INHIBITED	CETA CART PREP 1. Transfer PGT w/6-in to EV2 2. Translate to port-most CETA cart (S0 Bay 03) 3. Deploy port brake handles on CETA cart (down) 4. Take CETA coupler to UNLOCK 5. Mnvr CETA cart port ~ 5 feet 6. Deploy stbd brake handles on CETA cart (down) 7. √CETA brakes by pulling parking brake (left handle) 8. Take CETA coupler to CAPTURE 9. Release CETA brakes (tap pedal twice) 10. Translate CETA to S0 Bay 00 (by hand): ■ Stop when stbd TFR is port of CETA marker 7650 11. Engage parking brake – left handle 12. Rotate port TFR swing arm to 15	SPARE MBSU RETRIEVAL FROM ESP2 1. Receive PGT w/6-in from EV1, stow on swingarm 2. Stow 6-in socket in trash bag 3. SSRMS mnvr to ESP2 for MBSU retrieval (~ 30 min)
	 Translate to airlock Retrieve crewlock bag #1, BRT Retrieve spare PGT and 6-in socket from crewlock bag #2 Translate to Z1 stbd toolbox Retrieve 2 sq scoops from toolbox lid: Stow 1 sq scoop on MWS Stow 1 sq scoop in crewlock bag #1 (may have to relocate D-Handle to get sq scoop) Open right door Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS (release slider lock only) Close door – both latches reqd if not coming back 	

FS 16-43 EVA/116/FIN

	IV/SSRMS	EV1 (FF)	EV2 (SSRMS)			
Zenith S T B		SPARE MBSU RETRIEVAL FROM ESP2 1. Translate to ESP2, temp stow crewlock bag #1 on CETA spur 2. Attach BRT to ESP2 HR 8003 (aft face, stbd side) 3. Engage FRAM soft capture lever (slides down) 4. PGT [A4, CCW2, 10.5]-6"-Ext-7/16: Release primary FRAM bolt 11 turns (hard stop) 5. Using vertical HRs on FRAM, remove MBSU from ESP2 (magnetic soft dock to overcome) 6. Transfer MBSU to EV2 7. Retrieve crewlock bag #1 from CETA spur, BRT	Receive MBSU from EV1 (body is parallel to stbd side of ESP2 with head aft and face port)			
	Nadir	TEMP STOW SPARE MBSU ON CETA CART	TEMP STOW SPARE MBSU ON CETA CART			
MBSU ORIENTATION ON CETA CART GRID E		 Translate to port CETA cart on S0 Bay 00 Temp stow crewlock bag #1 on port side of CETA cart, S0 HR 3494 Retrieve ballstack from crewlock bag #1, install on port TFR swingarm ECOM fitting 	 SSRMS mnvr to port CETA cart on S0 Bay 00 Rotate MBSU until FRAM primary bolt faces ISS zenith 			
		 4. Position body to see grid E 5. Assist EV2 with clearances 6. PGT [A4, CW2, 10.5]-6"- Ext-7/16: Drive primary FRAM bolt 11 turns (hard stop) 	Install MBSU/FRAM onto grid E (zenith center) (rock FRAM square grid into place)			
		7. Retrieve sq scoop from crewlock bag #1, transfer to EV2	4. Receive sq scoop from EV1, stow on MWS			

FS 16-44 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)			
2. Verify w/MCC S0 inhibits in place: DCSU P4 2A RBI 6 Op (Cl Inh) DCSU P6 2B RBI 6 Op (Cl Inh) MBSU 3 RBI 7 Op (Cl Inh) MBSU 1 RBI 6 Op (Cl Inh) MBSU 1 RBI 14 Op (Cl Inh) 3. Record failed MBSU serial #: zenith H1	MBSU REMOVAL FROM S0 FACE 6 (2A2B) 1. Translate to failed MBSU (port nadir) 2. Install square TM onto H1 fitting, √anti-backlash neutral 3. Get in posn to assist EV2	MBSU REMOVAL FROM S0 FACE 6 (2A2B) 1. SSRMS mnvr to failed MBSU wkst (port nadir) CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 2. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt) 3. Remove sq TM from H1, install onto H2 √Anti-backlash neutral 4. Install sq scoop onto H1, handle points zenith 5. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 6. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 7. Remove sq TM from H2, stow on MWS 8. Install sq scoop onto H2, handle points zenith 9. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK			

FS 16-45 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)		
		NOTE Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE		
		WARNING Fins on bottom of MBSU and coldplate are no-touch		
Zenith	4. Assist EV2 w/clearances5. Translate to port side of CETA cart6. Assist EV2	 10. Remove MBSU from coldplate 11.√Status indicator on H1 in LOCK 12. SSRMS mnvr to port side of CETA cart 13. Attach MBSU to ballstack 14. Remove free sq scoop from MBSU, stow on MWS 		
$\begin{bmatrix} T \\ B \\ D \end{bmatrix}$ \diamondsuit	SPARE MBSU REMOVAL FROM FRAM	SPARE MBSU REMOVAL FROM FRAM		
H1 H2	 Release MBSU thermal cover: Release velcro tabs on front, side, and back corners of ORU base Release integral strap from underside of fwd flap 	SSRMS mnvr to spare MBSU (head nadir)		
MBSU ORIENTATION ON CETA CART GRID E	□ Fold or roll cover toward back of MBSU, attach strap to Velcro mating swatch on back side of MLI (can also attach strap to adjacent structure) □ Using side straps from front of MLI, secure rest of MLI as reqd	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur		
4. Record spare MBSU serial #: ————	2. Remove 3rd sq scoop from crewlock bag #1, transfer	 Install sq TM onto H1 fitting, √anti-backlash neutral PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt) Remove sq TM from H1, install onto H2 √Anti-backlash neutral Receive sq scoop from EV1, install onto H1 fitting 		
	to EV2	5. Receive sq scoop from EV I, install onto HT litting		

FS 16-46 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith H1		6. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 7. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 8. Remove sq TM from H2, stow on MWS or handoff to EV1 9. Install sq scoop onto H2 10. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK NOTE Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE WARNING Fins on bottom of MBSU are no-touch
	3. Assist EV2 w/clearances	11. Remove MBSU from FRAM 12. √Status indicator on H1 in LOCK
	SPARE MBSU INSTALLATION ONTO SO	SPARE MBSU INSTALLATION ONTO SO
	 When EV1 clear of CETA cart, articulate ball stack and failed MBSU stbd over CETA cart (clears EV2's trajectory toward MBSU install onto nadir/port coldplate) Translate to port nadir MBSU coldplate 	 SRMS mnvr to S0 wkst (port nadir MBSU) (heads nadir) Orient MBSU such that blind-mate connectors and H2 fitting are nadir

FS 16-47 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	3. GCA EV2 as required	NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto coldplate 3. Install MBSU onto coldplate 4. √Status indicator on H1 is in UNLOCK
zenith H1		CAUTION H2 bolt must always be installed first or damage to ORU and underlying structure will occur
nadir MBSU ORIENTATION ON FACE 6 5. Inform MCC MBSU Installed		 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
		7. Remove sq scoops from MBSU, stow on MWS
	INSTALLATION OF FAILED MBSU ONTO FRAM	INSTALLATION OF FAILED MBSU ONTO FRAM
	Translate to port TFR swingarm	 SSRMS mnvr to failed MBSU on port TFR swingarm Release MBSU from ballstack Orient MBSU such that H2 fitting is port
	 2. Remove ballstack from port swingarm, stow in crewlock bag #1 3. Stow port swingarm (rotate to 0) 	4. SSRMS mnvr to FRAM NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto FRAM

FS 16-48 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)		
Zenith S T	 Receive sq scoop from EV2, stow on MWS (or in crewlock bag #1) Receive sq scoop from EV2, stow on MWS (or in crewlock bag #1) Install MBSU thermal cover Relocate EV2's airlock safety tether from stbd of MT to port of MT (EV2 egress posn) 	 Install failed MBSU onto FRAM (ball detent soft dock on primary bolt and stanchion) √Status indicator on H1 is in UNLOCK PGT [B2, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H2 jack screw ~ 18 turns √Status indicator – LOCK Remove square scoop from H2, transfer to EV1 Remove square scoop from H1, transfer to EV1 PGT [B2, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H1 acme screw ~ 8 turns √Status indicator – LOCK 		
	CETA CART CLEANUP	SSRMS CLEANUP		
	1. If necessary, stow CETA cart swingarms 2. Release brake pedal (tap pedal twice) 3. Translate CETA cart to S0 Bay 01 4. Stow stbd brake handles (up) CAUTION CETA to MT max coupling rate is .5 ft/sec	 SSRMS mnvr to egress posn (port of MT) Egress SSRMS Remove APFR from SSRMS Remove WIF adapter from SSRMS, stow on MWS Perform safety tether swap onto airlock safety tether, verify ST config; retrieve spare from SSRMS Translate to airlock, stow APFR in Toolbox WIF 1 		
	 Couple CETA to MT Take CETA coupler to LOCK Stow port brake handles (UP) Retrieve crewlock bag #1 Translate to airlock 			

FS 16-49 EVA/116/FIN

MBSU REMOVE AND REPLACE - 2A2B (EVA 2) TASK DATA SHEET

Tools:

EV1	EV2
PGT w-6-in	PGT
Crewlock bag #1	
Sq TM w/7/16 recessed socket	
Ballstack	
3 sq scoops	

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			12.0 (pgt) RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

Foot Restraints:

Task	WIF	Swingarm Setting	P/Y Fitting	APFR Setting
MBSU R&R	SSRMS			[12,PP,F,6]

Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- 2. Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. CETA to MT max coupling rate is .5 ft/sec
- 4. There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H1 bolt must always be released first or damage to ORU and underlying structure will occur
- 4. H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

ORU Weight with FRAM = ~ 500 lbs

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

EVA Connectors: N/A

Assumptions:

- 1. Failure discovered during 1st CETA cart move, finish 1st CETA cart move prior to starting MBSU task (need 1 cart port to support R&R)
- 2. EV1 uses 85' safety tethers from airlock D-ring, EV2 on SSRMS tether
- 3. MT @ WS 3, SSRMS is already setup because of CETA Relocate task
- 4. TM not reqd for on-orbit loads
- 5. Failed MBSU left on CETA cart at end of EVA (CETA is coupled to MT)
- 6. Due to long SSRMS times, EV1 will do all setup tasks
- EV1 gives EV2 his PGT (to free his swingarm) and retrieves spare PGT from airlock

FS 16-50 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. Verify w/MCC ESP2 inhibits in place: RPCM N1RS2-B RPC10 – OPEN AND CLOSE INHIBITED RPCM S04B F RPC 12 – OPEN AND CLOSE INHIBITED	CETA CART PREP 1. Transfer PGT w/6-in to EV2 2. Translate to port-most CETA cart (S0 Bay 03) 3. Deploy port brake handles on CETA cart (down) 4. Take CETA coupler to UNLOCK 5. Mnvr CETA cart port ~ 5 feet 6. Deploy stbd brake handles on CETA 1 (down) 7. √CETA brakes by pulling parking brake (left handle) 8. Take CETA coupler to CAPTURE 9. Release CETA brakes (tap pedal twice) 10. Translate CETA to S0 Bay 00 (by hand): ■ Stop when stbd TFR is port of CETA marker 7650 11. Engage parking brake – left handle 12. Rotate port TFR swing arm to 15	SPARE MBSU RETRIEVAL FROM ESP2 1. Receive PGT w/6-in from EV1, stow on swingarm 2. Stow 6-in socket in trash bag 3. SSRMS mnvr to ESP2 for MBSU retrieval (~ 30 min)
	 Translate to airlock Retrieve crewlock bag #1, BRT Retrieve spare PGT and 6-in socket from crewlock bag #2, stow on swingarm Translate to Z1 stbd toolbox Retrieve 2 sq scoops from toolbox lid: Stow 1 sq scoop on MWS Stow 1 sq scoop in crewlock bag #1 (may have to relocate D-Handle to get sq scoop) Open right door Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS (release slider lock only) Close door – both latches reqd if not coming back 	

FS 16-51 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
Zenith S T B O H1 H2	 SPARE MBSU RETRIEVAL FROM ESP2 Translate to ESP2, temp stow crewlock bag #1 on CETA spur Attach BRT to ESP2 HR 8003 (aft face, stbd side) Engage FRAM soft capture lever (slides down) PGT [A4, CCW2, 10.5]-6"-Ext-7/16: Release primary FRAM bolt 11 turns (hard stop) Using vertical HRs on FRAM, remove MBSU from ESP2 (magnetic soft dock to overcome) Transfer MBSU to EV2 Retrieve crewlock bag #1 from CETA spur, BRT 	Receive MBSU from EV1 (body is parallel to stbd side of ESP2 with head aft and face port)
Nadir	TEMP STOW SPARE MBSU ON CETA CART	TEMP STOW SPARE MBSU ON CETA CART
MBSU ORIENTATION ON CETA CART GRID E	 Translate to port CETA cart on S0 Bay 00 Temp stow crewlock bag #1 on port side of CETA cart, S0 HR 3494 Retrieve ballstack from crewlock bag #1, install on port TFR swingarm ECOM fitting 	SSRMS mnvr to port CETA cart on S0 Bay 00 Rotate MBSU until FRAM primary bolt faces ISS zenith
	 4. Position body to see grid E 5. Assist EV2 with clearances 6. PGT [A4, CW2, 10.5]-6"- Ext-7/16:	3. Install MBSU/FRAM onto grid E (zenith center) (rock FRAM square grid into place) 4. Description of account from EVA status of MWC.
	Retrieve sq scoop from crewlock bag #1, transfer to EV2	4. Receive sq scoop from EV1, stow on MWS

FS 16-52 EVA/116/FIN

IV/SSRMS EV1 (FF)	EV2 (SSRMS)
2. Verify w/MCC S0 inhibits in place: MBSU 2 RBI 7 Op (CI Inh) MBSU 4 RBI 14 Op (CI Inh) 3. Record failed MBSU serial #: zenith H1 which is place: MBSU 2 RBI 6 Op (CI Inh) MBSU 4 RBI 14 Op (CI Inh) 3. Record failed MBSU serial #: zenith H1 which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Install square TM onto H1 fitting, vant Attach BRT to stbd Lab/S0 strut, head which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Attach BRSU (stbd nadir) which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Attach BRSU (stbd nadir) which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Attach BRSU (stbd nadir) which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Attach BRSU (stbd nadir) which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Attach BRSU (stbd nadir) which is place: MBSU REMOVAL FROM S0 FACE 6 (3A: Install square TM onto H1 fitting, vant and in manufact NATION ON FACE 6	SSRMS mnvr to failed MBSU wkst (stbd nadir) acklash neutral CAUTION

FS 16-53 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
Zenith S T	4. Assist EV2 w/clearances 5. Translate to port side of CETA cart 6. Assist EV2 SPARE MBSU REMOVAL FROM FRAM 1. Release MBSU thermal cover: Release velcro tabs on front, side, and back corners of ORU base Release integral strap from underside of fwd flap Fold or roll cover toward back of MBSU, attach strap to Velcro mating swatch on back side of MLI (can also attach strap to adjacent structure) Using side straps from front of MLI, secure rest of MLI as reqd 2. Remove 3rd sq scoop from crewlock bag #1, transfer	NOTE Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE WARNING Fins on bottom of MBSU and coldplate are no-touch 10. Remove MBSU from coldplate 11.√Status indicator on H1 in LOCK 12. SSRMS mnvr to port side of CETA cart 13. Attach MBSU to ballstack 14. Remove free sq scoop from MBSU, stow on MWS SPARE MBSU REMOVAL FROM FRAM 1. SSRMS mnvr to spare MBSU (head nadir) CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 2. Install sq TM onto H1 fitting, √anti-backlash neutral 3. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt) 4. Remove sq TM from H1, install onto H2 √Anti-backlash neutral 5. Receive sq scoop from EV1, install onto H1 fitting
	to EV2	

FS 16-54 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
		 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) Remove sq TM from H2, stow on MWS or handoff to EV1 Install sq scoop onto H2 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK
zenith H1		NOTE Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE
H2 nadir		WARNING Fins on bottom of MBSU are no-touch
MBSU ORIENTATION ON FACE 6	3. Assist EV2 w/clearances	11. Remove MBSU from FRAM 12.√Status indicator on H1 in LOCK
	SPARE MBSU INSTALLATION ONTO SO	SPARE MBSU INSTALLATION ONTO S0
	Translate to stbd nadir MBSU coldplate	 SSRMS mnvr to S0 wkst (stbd nadir MBSU) (head nadir) Orient MBSU such that blind-mate connectors and H2 fitting are nadir

FS 16-55 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith H1	2. GCA EV2 as required	NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto coldplate 3. Install MBSU onto coldplate 4. √Status indicator on H1 is in UNLOCK CAUTION H2 bolt must always be installed first or damage to ORU and underlying structure will occur 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
	 INSTALLATION OF FAILED MBSU ONTO FRAM 1. Translate to port TFR swingarm 2. Remove ballstack from port swingarm, stow in crewlock bag #1 3. Stow port swingarm (rotate to 0) 	7. Remove sq scoops from MBSU, stow on MWS INSTALLATION OF FAILED MBSU ONTO FRAM 1. SSRMS mnvr to failed MBSU on port TFR swingarm 2. Release MBSU from ballstack 3. Orient MBSU such that H2 fitting is port 4. SSRMS mnvr to FRAM
		NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto FRAM

FS 16-56 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
Zenith S T	 4. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 5. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 6. Install MBSU thermal cover 7. Relocate EV2's airlock safety tether from stbd of MT to port of MT (EV2 egress posn) 	 Install failed MBSU onto FRAM (ball detent soft dock on primary bolt and stanchion) √Status indicator on H1 is in UNLOCK PGT [B2, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H2 jack screw ~ 18 turns √Status indicator – LOCK Remove square scoop from H2, transfer to EV2 Remove square scoop from H1, transfer to EV2 PGT [B2, CW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
	CETA CART CLEANUP	SSRMS CLEANUP
	1. If necessary, stow CETA cart swingarms 2. Release brake pedal (tap pedal twice) 3. Translate CETA cart to S0 Bay 01 4. Stow stbd brake handles (up) CAUTION CETA to MT max coupling rate is .5 ft/sec 5. Couple CETA to MT 6. Take CETA coupler to LOCK 7. Stow port brake handles (UP) 8. Retrieve crewlock bag #1	 SSRMS mnvr to egress posn (port of MT) Egress SSRMS Remove APFR from SSRMS Remove WIF adapter from SSRMS, stow on MWS Perform safety tether swap onto airlock safety tether, verify ST config; retrieve spare from SSRMS Translate to airlock

FS 16-57 EVA/116/FIN

Tools:

EV1	EV2
PGT w-6-in	PGT
Crewlock bag #1	
Sq TM w/7/16 recessed socket	
Ballstack	
3 sq scoops	

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		22.8 (bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal) 27.8	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

Foot Restraints:

Task	WIF	Swingarm Setting	P/Y Fitting	APFR Setting
MBSU R&R	SSRMS			[12,PP,F,6]

Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- 2. Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. CETA to MT max coupling rate is .5 ft/sec
- 4. There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H2 bolt (jack screw) must always be released last or damage to ORU and underlying structure will occur
- 4. H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- 5. Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

ORU Weight with FRAM = ~ 500 lbs

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

EVA Connectors: N/A

Assumptions:

- Failure discovered during 1st CETA cart move, finish 1st CETA cart move prior to starting MBSU task (need 1 cart port to support R&R)
- 2. EV1 uses 85' safety tethers from airlock D-ring, EV2 on SSRMS tether
- 3. MT @ WS 3, SSRMS is already setup because of CETA Relocate task
- 4. TM not reqd for on-orbit loads
- 5. Failed MBSU left on CETA cart at end of EVA (CETA is coupled to MT)
- 6. Due to long SSRMS times, EV1 will do all setup tasks
- 7. EV1 gives EV2 his PGT (to free his swingarm) and retrieves spare PGT from airlock

FS 16-58 EVA/116/FIN

DDCU REMOVE AND REPLACE – CH 2/3 (EVA 2)

IV	EV1 (FF)	EV2 (FF)
	 CETA CART PREP Retrieve spare safety tether and PGT with 6-in socket from fish stringer #1 (if reqd) Receive APFR from EV2, install into CETA WIF 04 (zen/port) configure to: [12,FF,A,4]; P/Y fitting: P=GG, Y=12 Deploy port brake handles (down) Take CETA/MT coupler to UNLOCK (if necessary) Mnvr CETA port a few feet, deploy stbd brake handles Take CETA/MT coupler to CAPTURE √CETA brakes by pulling parking brake (left handle) Translate CETA 1 to S0 Bay 00 (by hand): Stop when stbd TFR is port of CETA marker 8040 (gets CETA cart to spare DDCU retrieval worksite) Engage parking brake – left handle 	 SSRMS CLEANUP SSRMS mnvr to EV2 egress position on port side of MT Egress SSRMS; perform safety tether swap onto airlock safety tether, verify ST config; retrieve spare from SSRMS Remove APFR, transfer to EV1 Remove WIF adapter, temp stow on MWS TOOL RETRIEVAL Translate to airlock Retrieve spare PGT (no socket) from crewlock bag #2, and retrieve crewlock bag #1, attach to BRT Translate to Z1 stbd toolbox Retrieve 2 square scoops from toolbox lid: Stow 1 square scoop on MWS Stow 1 square scoop in crewlock bag #1 Open right door Retrieve square TM w/7/16 recessed socket from slot 1, stow on MWS (release slider lock only) Close door – both latches reqd if not coming back
Verify w/MCC inhibits in place: MBSU 3 RBI 13 Op (CI Inh)	SPARE DDCU REMOVAL (DDCU S0-3B) (S0 Bay 04) 1. Ingress APFR in WIF 04 2. Receive square TM from EV2 3. Receive square scoops (3) from EV2	SPARE DDCU REMOVAL (DDCU S0-3B) (S0 Bay 04) 1. Translate to S0 Bay 04 2. Temp stow crewlock bag #1 near EV1 (CETA HR) 3. Transfer square TM w/7/16" recessed socket to EV1 4. Transfer square scoops (3) to EV1

FS 16-59 EVA/116/FIN

	IV	EV1 (FF)	EV2 (FF)
	David and DDOH and M	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur	
2.	Record spare DDCU serial #:	 4. Install TM onto H1 fitting, √anti-backlash neutral 5. PGT [B2, CCW2, 30.5]-sq TM: (use EV2 spare PGT) Break torque on H1, 5 turns (PGT), 1 turn (bolt) 6. Remove TM from H1, install onto H2 √Anti-backlash neutral 7. Install square scoop onto H1 fitting 8. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 9. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 10. Remove TM from H2, stow on MWS 11. Install square scoop on H2 fitting 12. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw ~ 18 turns √Status indicator – UNLOCK 	
		NOTE Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during DDCU removal from FSE	

FS 16-60 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)	
3. Verify w/MCC inhibits in place: MBSU 3 RBI 4 Op (CI Inh)	WARNING Fins on bottom of DDCU and coldplate are no-touch 13. Remove DDCU from coldplate 14.√Status indicator on H1 in LOCK 15. Attach spare DDCU to EV2's BRT 16. Egress APFR 17. Remove free scoop from spare DDCU, attach to MWS FAILED DDCU REMOVAL For DDCU P1-3A (P1 Bay 16): ■ □ 1. Ingress port TFR 2. Release CETA brakes (tap petal twice) 3. Translate to P1 HR 3602 (P1 Bay 14, Face 1), perform safety tether swap onto spare tether, verify ST config 4. At CETA marker 9760, engage parking brake — (left handle); cart is ~ 2 feet stbd of DDCU, proceed to	 5. Get in position to receive spare DDCU from EV1 6. Attach spare DDCU to BRT FAILED DDCU REMOVAL For DDCU P1-3A (P1 Bay 16): 1. Translate to P1 Bay 16, perform safety tether swap onto P1 HR 3601 as reqd, verify ST config; proceed to step 2 	
4. Verify w/MCC inhibits in place: MBSU 2 RBI 12 Op (CI Inh)	For DDCU S0-2B (S0 Bay 02): Ingress port TFR Release CETA brakes (tap petal twice) Translate to S0 Bay 00 At CETA marker 7980 on S0, engage parking brake – (left handle); cart is ~ 2 feet stbd of DDCU, proceed to step 5	For DDCU S0-2B (S0 Bay 02): 1. Translate to S0 Bay 02; proceed to step 2	

FS 16-61 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
5. Record failed DDCU serial #:	EV1 (FF) 5. Install square TM onto H1 fitting, √anti-backlash neutral CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 6. Ingress APFR in WIF 04 7. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H1, 5 turns (PGT), 1 turn (bolt) 8. Remove square TM from H1, install onto H2 √Anti-backlash neutral 9. Install sq scoop on H1 10. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 11. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 12. Remove square TM from H2, stow on MWS 13. Install square scoop on H2 fitting 14. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw ~ 18 turns √Status indicator – UNLOCK	EV2 (FF)
	NOTE Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK.	
	Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during DDCU removal from FSE	
	WARNING Fins on bottom of DDCU and coldplate are no-touch	

FS 16-62 EVA/116/FIN

IV EV1 (FF)		EV2 (FF)
	15. Remove DDCU from coldplate 16. √Status indicator on H1 in LOCK 17. Attach failed DDCU to BRT 18. Receive free square scoop from EV2 SPARE DDCU INSTALL 1. Install square scoop onto spare DDCU (on EV2's BRT) 2. Remove spare DDCU from EV2's BRT NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during DDCU installation onto coldplate 3. Install DDCU onto coldplate 4. √Status indicator on H1 is in UNLOCK CAUTION H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK 7. Remove square scoops from DDCU, stow on MWS 8. Egress APFR	2. Assist EV1, remove free scoop 3. Transfer free square scoop to EV1 SPARE DDCU INSTALL 1. Assist EV1 2. Retrieve crewlock bag #1, BRT

FS 16-63 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)	
6. Verify w/MCC inhibits in place: MBSU 3 RBI 13 Op (Cl Inh) 56	FAILED DDCU INSTALL (S0 Bay 04) (to protect coldplate) 1. Release CETA 1 parking brake (tap pedal twice) 2. Translate CETA 1 to S0 Bay 00 (by hand): □ Stop when stbd TFR is port of CETA marker 8040 (gets CETA cart to spare DDCU retrieval worksite) 3. Engage parking brake – left handle 4. Ingress APFR in WIF 04 NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during DDCU installation onto coldplate 5. Install DDCU onto coldplate 6. √Status indicator on H1 is in UNLOCK CAUTION H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur 7. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 8. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK 9. Remove square scoops from DDCU, stow on MWS 10. Egress APFR (APFR left on CETA cart)	FAILED DDCU INSTALL (S0 Bay 04) (to protect coldplate) 1. Translate to DDCU coldplate in S0 bay 04 2. Install square scoop onto failed DDCU (on EV1's BRT) 3. Assist EV1	

FS 16-64 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	1. Translate to airlock 2. Perform safety tether swap onto airlock safety tether if reqd, verify ST config, retrieve spare 3. Perform tool inventory	CETA CART CLEANUP 1. If necessary, stow CETA cart swingarms 2. Stow all brake handles (up) 3. Release brake pedal (tap pedal twice) 4. Translate CETA cart to S0 Bay 01, perform safety tether swap onto airlock safety tether if reqd, verify ST config, retrieve spare CAUTION CETA to CETA max coupling rate is 1 inch/sec 5. Couple CETA 2 to MT (or CETA 1 to CETA 2) 6. Take MT/CETA coupler to LOCK 7. Translate to airlock 8. Perform tool inventory

FS 16-65 EVA/116/FIN

DDCU REMOVE AND REPLACE - CH 2/3 TASK DATA SHEET

Tools: Backup tool shown in ()

EV1	EV2
PGT w/6-in	PGT
APFR Crewlock bag #1	
	Square TM w/7/6" TM
	3 square scoops

Foot Restraints (Optional Use)

Task	WIF	APFR Setting	Comments
DDCU Remove and Replace (nominal)	CETA 1 WIF 04	12,FF,A,4 P=GG, Y=12	
DDCU S03B (S0 Bay 04)	(S0 WIF 45)	10,SS,F,12	
DDCU S02B (S0 Bay 02)	(S0 WIF 21) (S0 WIF 24)	9,00,H,12 8,NN,F,12	Can't reach H1 Can't reach H2
DDCU P13A (P1 Bay 16)	(P3 WIF 06)	2,NN,F,12	Side mounted WIF, not great access to both bolts

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt) RUNNING TORQUE (very little, just picked 12.0)	4.8 (bolt)	188.4 (bolt) (removal) 27.8 (bolt) (install)	18	30

Notes:

- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin
- Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. Primary stanchion (H2) has a 15-20 lb soft dock

Cautions:

- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin
- H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- 3. Fins on bottom of DDCU and coldplate are no-touch
- H1 bolt must always be released first or damage to ORU and underlying structure will occur
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

Assumptions:

- 1. Learn of failure ~ 20-30 min after CH 2/3 powerup
- 2. CETA cart is used as work platform for APFRs. There are back-up truss WIFs in the task data sheet, however CETA cart was chosen as the primary means for the R&R b/c the CETA cart WIFs give very good access to both H1 and H2 bolts at all worksites. The truss WIFs are not ideal, and often only provide good access to only 1 of the bolts. Also, when using the CETA cart, you only setup 1 APFR that can be used to both retrieve the spare and R&R the failed. Without the cart, you automatically have to setup up two APFR worksites (balance this with CETA cart setup and translation)
- 3. Spare DDCU is DDCU S0-3B (in S0 Bay 04). Skip Z1 PP if any of the 2/3 DDCU fails and you use the S03B DDCU as a spare (or it fails itself)
- 4. TM not used on spare DDCU for on-orbit loads
- 5. All tools retrieved from Z1 toolbox come inside after EVA
- 6. Failed DDCU is installed into spare site
- 7. MT @ WS 3 w/at least one CETA cart coupled to port side
- 8. If the S0-3B spare fails during pwr up, the R&R will be skipped, and so will the PP. That is why there is no option in the above procedures to R&R S0-3B. None of the other DDCUs can be used as the spare, so the R&R will occur on another day using the internal spare
- EV2 has spare safety tether from CETA Relocate and EV1 can pick up his spare from fish stringer #1 (for the P1 bay 16 DDCU) or crewlock bag #1
- EV2 retrieves spare PGT from airlock for more efficient PGT ops. This is not reqd, and EV1 can socket swap throughout the R&R, temp stowing the socket in his trash bag

FS 16-66 EVA/116/FIN

BCDU BACKOUT - CH 2/3 (EVA 2)

IV	EV1 (FF)	EV2 (FF)
1A. √Verify SARJ locked at 35 deg 1B. √MCC inhibits in place: BCDU 4A1 1. DCSU 4A RBI 2 Op, CI Inh 2. BCDU 2A1 CP RBI Op - OR - BCDU 4A2 1. DCSU 4A RBI 3 Op, CI Inh 2. BCDU 2A2 CP RBI Op - OR - BCDU 4A3 1. DCSU 4A RBI 4 Op, CI Inh 2. BCDU 2A3 CP RBI Op	FAILED P4 4A BCDU BACK-OUT 1. Translate to airlock 2. Retrieve spare 55' safety tether from crewlock bag #1, stow on MWS 3. Translate to Z1 stbd toolbox 4. Open right door 5. Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS 6. Close door – 1 latch reqd 7. Translate to fish stringer #1, retrieve second 55' safety tether and PGT w/6-in, stow on MWS 8. Translate to P1 HR 3602 (Bay 14); perform safety tether swap using 55' spare safety tether, verify ST config 9. Translate to P4 HR 5104 (zenith IEA) 10. Perform safety tether swap onto P4 HR 5104 with remaining 55' safety tether, verify ST config 11. Translate to failed BCDU on P4 (P4 fwd,TBD BCDU)	FAILED P4 4A BCDU BACK-OUT 1. Finish current CETA cart task 2. GCA SSRMS for APFR egress 3. Assist EV1 as reqd
2. IV record serial # of failed box:	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 12. Install TM onto H1 fitting, √anti-backlash neutral 13. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, ~ 1 turn 14. Remove TM from H1, install onto H2 √Anti-backlash neutral	

FS 16-67 EVA/116/FIN

BCDU BACKOUT - CH 2/3 (EVA 2) (Cont)

IV	EV1 (FF)	EV2 (FF)
	 15. Reconfigure PGT with 6-in socket 16. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 17. Remove socket from PGT 18. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, ~ 1 turn 19. Remove TM from H2, stow on MWS 20. Reconfigure PGT with 6-in socket 21. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw 5 turns 22. □ BCDU final config 23. Translate to airlock 	

FS 16-68 EVA/116/FIN

BCDU BACKOUT - CH 2/3 (EVA 2) TASK DATA SHEET

Tools:

EV1 (FF)	EV2 (FF)
PGT w/6-in socket	
Square TM w/7/16 in Rec Socket	

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal) 27.8	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

EVA Connectors: NA

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

Foot Restraints: NA

Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- 2. Removing BCDU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. The BCDU backout procedure does not actually remove the ORU from the truss, it just backs the H2 bolt out enough to demate the blind-mate connectors

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H1 bolt must always be released first or damage to ORU and underlying structure will occur
- 4. Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads
- T-handle on connector cover poses a tether snag point.
 Connector cover could become loose debris if advertently snagged by EVA tether

Warnings:

1. Hazard voltage exist at the connectors of the BCDU. BCDU must be safed before removal

ORU Mass: 234 lbs

Assumptions:

- 1. This failure would happen on EVA 2 (CH 2/3), and protects for P4 4A BCDUs only (only channel carrying core loads)
- 2. SARJ must be stopped and locked
- EV2 would be starting SSRMS setup and CETA cart relocate, so it would be easier for EV1 to break away from his task to support BCDU back-out. EV2 will complete current CETA cart task and then egress APFR to assist EV1 as reqd. EV2 needs EV1 for GCA assist and so cannot continue with CETA cart tasks until EV1 is back
- 4. All bolts are driven FF
- 5. EV is on 85' safety tether from airlock

FS 16-69 EVA/116/FIN

P1 PUMP MODULE R&R SUMMARY TIMELINE

TIME	IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
00:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)
00:05		EGRESS (00:20)	EGRESS (00:20)
00:25	SSRMS: PM R&R SRMS: PM R&R	FAILED PM REMOVAL FROM P1 (01:30) Setup PM Prep for FGB Install PM QD Operations PM Jumper N2 Vent and Install PM Electrical Connections Release PM Bolts Temp Stow Failed PM on SRMS	FAILED PM REMOVAL FROM P1 (01:30) SSRMS Setup FGB Removal from Spare PM Break Torque on PM Bolts PM Jumper N2 Vent and Install FGB Install Release PM Bolts Temp Stow Failed PM on SRMS
01:55		SPARE PM RETRIEVAL FROM ESP2 (01:30) • Spare PM Electrical Connections	SPARE PM RETRIEVAL FROM ESP2 (01:30) • Break Torque on PM Bolts • Release PM Bolts
03:25		SPARE PM INSTALL ON P1 (02:00) P1 PM Install PM Electrical Connections PM Jumper NH3 Vent and Removal P1 PM N2 vent PM QD Operations CETA Cart Cleanup	SPARE PM INSTALL ON P1 (02:00) P1 PM Install PM Bolt Initial Torque PM Jumper NH3 Vent and Removal PM Bolt Final Torque
		*** BREAKOUT POINT IF REQD ***	
05:25		FAILED PM INSTALL ONTO ESP2 (01:30) Retrieve Failed PM from SRMS Install Failed PM onto ESP2 PM Electrical Connections Cleanup	FAILED PM INSTALL ONTO ESP2 (01:30) Retrieve Failed PM from SRMS Install Failed PM onto ESP2 PM Bolt Initial Torque PM Bolt Final Torque SSRMS Cleanup
06:55		INGRESS (00:20)	INGRESS (00:20)
07:05		PRE REPRESS (00:05)	PRE REPRESS (00:05)
07:25		•	·

FS 16-70 EVA/116/FIN

P1 PUMP MODULE R&R TOOL CONFIG

AIRLOCK		
EMU1	AIRLOCK ENDCONE	AIRLOCK INTERNAL D-RING
MWS, right swing arm	Staging Bag	D-Ring Extender
Camera (inner right swing arm)	Fish Stringer #3	<u> </u>
BRT (left)	Connector cleaner tool caddy	UIA HANDRAILS:
w/3 wire ties and sm-sm RET	Wire tie caddy (2)	Fish Stringer #1 (layed across UIA HRs)
T-Bar	Pin straightener	PGT with 7/16 x 6-in ext (s/n:) w/RET
ISS trash bag (inner left)	MWS Key strap	· ——
Sm-sm RET (left D-ring)	Velcro/Tape caddy	Torque Wrench (set to 37 ft-lbs) (need for PM Return
Adj tethers (2) (left D-ring)	Pry bar	Lg-sm RET
Sm-sm RET w/PIP pin (right D-ring)	EVA Ratchet	<u> </u>
Adj tethers (2) (right D-ring)	Socket caddy (inner right)	Fish Stringer #2
D-ring ext – left	5/8 x 7.8-in ext	PGT with 7/16 x 6-in ext (s/n:) w/RET
Waist tether – right	Spare 55' safety tethers (2)	Round TM w/5/8 proud socket
SAFER		
		Crewlock bag #1 (empty) – for QD cont tools if needed
	IV Bag	Lg-sm RET
	Contamination Detection Kit	
	Hydrazine Detector (Gold Salt Coupon) (6)	EXTERNALLY STOWED QD TOOLS:
EMU2	Color Chart (2)	(INFO ONLY)
MWS, right swing arm	ISS Contamination Detection Sampler (2)	DM Jumper Dec
Camera (inner right swing arm) BRT (left)	Shuttle Contamination Detection Sampler (2) Nitrogen Dioxide Detector (Oxidizer Draeger	PM Jumper Bag PM Jumper
w/3 wire ties and sm-sm RET	Tube) (6)	
T-Bar	Ammonia Detector (NH3 Draeger Tube) (6)	
ISS trash bag (inner right)	2 towels with wire ties	VTE Bag (only needed if EVA NH3 vent is reqd)
Wire ties (2) around T-Bar	DCM plug (2) (SAFER hardmount)	1.0" vent tool mated to vent tool extender
Socket caddy (inner left)	GP caddy (2)	MUT EE
5/8 x 7.8-in ext	Thermal mittens (2 pr)	
Sm-sm RET w/PIP pin (left D-ring)	Socket Caddy (hatch contingencies) w/sm-sm RET	Cthd OD Box (OD cont tools)
Adj tether (left D-ring) Sm-sm RET w/PIP pin (right D-ring)	1/2 X 8-in socket (IV hatch) 7/16 X 6-in socket (spare)	Stbd QD Bag (QD cont tools) 1.5" QRT/FID gauge
Adj tethers (2) (right D-ring)	17 To X 0-III socket (spare)	1.5" Bail drive lever
Lg-sm RETs (2) (need for PM HRs)	PRE EVA TOOL CONFIG	.5" cap tool
D-ring ext (2)	Prior to EVA, inspect the following:	
Spare 55' safety tether to MWS (left D-ring extender)	RET cords for damage	
Waist tethers (2)	■ BRT and MWS toggles: loose	NOTE
SAFER	fittings/screws	Only need vent tool and VTE for specific failures
	 Safety and waist tether load alleviating 	where MCC cannot remotely vent PM NH3
	straps (no red band or damage)	through truss aft vent panel

FS 16-71 EVA/116/FIN

EGRESS (00:25)

IV	EV1 (FF)	EV2 (FF)
NOTE For safety tether swaps, expect to hear: 1. Hook closed 2. Slide locked 3. Reel unlocked 1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max (required after EV1 and EV2 egress airlock)	FV1 (FF) √Right waist tether to airlock internal D-ring extender, verify ST config 1. Thermal cover – open 2. Egress airlock 3. Inspect load alleviating straps on 85' safety tethers (2) 4. Retrieve airlock safety tether from fwd external D-ring, attach to left D-ring extender, verify ST config 5. Release waist tether from internal D-ring extender 6. Receive fish stringer #1 and #2 from EV2 7. Temp stow fish stringer #1 in between A/L port toolbox HR and stbd toolbox HR (stretched out) 8. Temp stow fish stringer #2 in between A/L HR 0560 (fwd/stbd/nadir) and HR 0555 (nadir of stbd toolbox) 9. Transfer aft airlock safety tether to EV2 10. Transfer PGT from fish stringer #1 to right swingarm 11. Retrieve fish stringer #1	FV2 (FF) √Right waist tether to UIA panel fwd D-ring, verify ST config 1. Transfer fish stringer #1 and #2 to EV1 2. Receive airlock safety tether from EV1, attach to left D-ring extender, verify ST config 3. Release right waist tether from UIA panel D-ring 4. Egress airlock ✓

FS 16-72 EVA/116/FIN

FAILED PUMP MODULE REMOVAL FROM P1

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. P1 PM R&R (SODF: RBT FS: APFR Install/APFR Ingress) GP 4	MORKSITE SETUP 1. Translate to PM Jumper bag on crewlock 2. Retrieve PM Jumper bag, attach to BRT 3. Translate to CETA 1 (port) (S0 Bay 02) – MT @ WS 4 4. Stow fish stringer #1 and PM Jumper bag on CETA cart square grid 5. Prep CETA 1 for transfer to port side of P1 PM □ √Brake handles (4) straight and collars locked □ Deploy CETA 1 port brake handles (down) □ √Swingarms stowed (3) □ Take CETA 1 coupler to UNLOCK □ Translate CETA port a few inches; engage parking brake (left handle) – to verify that brakes work □ Release CETA brakes (tap pedal twice) □ Translate CETA 1 to ~ P1 Bay 10 (stbd brake pedal between CETA marker 8850 and 8820) □ Engage CETA 1 parking brake (left handle) □ Take CETA 1 coupler to CAPTURE □ Rotate zenith swingarm clear of CETA cart stbd HR 6. Open face 1 shroud (velcroes) (opens toward port) PUMP MODULE PREP FOR FGB INSTALL 1. Read failed PM serial # to IV ▼ □ □ 2. Open MLI flap on integral PM cover (FGB bolts) 3. PGT [B7, CCW2, 30.5]-6-Ext-7/16: □ Disengage FGB to Pump Module mounting bolts (4) 17-20 turns CAUTION Use extreme caution when manipulating F-171 (zen) and F-177 (nad) prior to P-Clamp release; minimize loads input into QD hard lines and QDs	1. Retrieve APFR from A/L Toolbox #1 (stbd) 2. Translate to ESP2 fwd/zenith 3. GCA SSRMS for APFR setup 4. Install WIF adapter (tether point facing same direction as LEE) into SSRMS 5. Install APFR on WIF adapter: configure to: [12,PP,F,6] 6. Perform safety tether swap onto SSRMS safety tether; temp stow airlock safety tether on VSSA FRAM HR (fwd) FGB REMOVAL FROM SPARE PUMP MODULE CAUTION Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used 1. Temp stow fish stringer #2 on ESP2 2. Release Velcro strap on fwd face of PM MLI 3. Open forward flap on PM MLI tent, attach velcro flaps (2) 4. GCA SSRMS for ingress 5. Attach waist tether to APFR, ingress SSRMS (head zenith) CAUTION Avoid contact with FGB grapple pin and RMS target 6. Attach fish stringer #2 to PM fwd HRs (clear of FGB)
3. P1 PM R&R (SODF: RBT FS: FGB Removal)4. √MCC GO to begin QD ops	PUMP MODULE QD OPERATIONS	 7. SSRMS mnvr to FGB bolt release 8. Tether to FGB 9. PGT [B7, CCW2, 30.5]-6-Ext-7/16: Release FGB to Pump Module mounting bolts (4) 8-11

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
5. P1 PM R&R (SODF: RBT FS: FGB Install)	 PGT [A7, CCW2, 30.5]-6-Ext-7/16: Release F171, F170, and F176 P-clamps, 12-14 turns Release F171, F170, and F176 TA clamps from flexlines Remove wire tie (1) from 1.5" SPDs, temp stow Remove SPDs from QDs (4), stow on fish stringer #1 Check QD buttons installed (4) Stow PGT on fish stringer #1 	turns (any order) 10. Remove FGB from Pump Module (soft dock) 11. Attach FGB to BRT 12. SSRMS mnvr to failed PM (P1 Face 1, Bay 08) (head zenith) BREAK TORQUE ON PUMP MODULE BOLTS
	CAUTION When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing; perform necessary actions to counteract sideloads as reqd	 GCA SSRMS to Bolt 1 (nadir-most) Perform the following steps to break torque on PM bolts 1, 2, 3, and 4:
	While demating F-171 from M1, do not exceed 20 lb of force in the forward, zenith, and nadir direction	 □ Install round TM w/5/8" proud socket on PM Bolt □ √Anti-backlash neutral
	Once F-171 is demated from M1, do not use the QD to manipulate the line out of the way (use the hard line)	 PGT [B6, CCW1, 30.5]-rd TM: Break torque on Bolt ~ 1 turn (of bolt) GCA to next bolt as regd
zenith B4 B3 J4 Stbd F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 D3 D4 D4 D4 D5 D4 D7	 BRT to stbd HR on CETA cart Perform the following steps to close valve and demate P1-F171/PM M1: (zenith-most) A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Demate P1-F171 from M1 (using release trigger) F. Restrain P1-F171 clear of PM using adj tether Perform the following steps to close valve and demate P1-F170/PM M2: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible 	 Remove TM from Bolt 4, stow on MWS Reconfigure PGT with 6-inch socket (FGB ops)
P1 PM – FACE 1	E. Demate P1-F170 from M2 (using release trigger)F. Restrain P1-F170 clear of PM using adj tethers	

FS 16-74 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)
zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 nadir P1 PM – Face 1	10. Perform the following steps to close valve and demate P1-F176/PM M3: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Demate P1-F176 from M3 (using release trigger) F. Restrain P1-F176 clear of PM using adj tethers
6. Inform MCC 1.5" QDs (3) are demated (valve change) (00:08 min vent thru vent panel)	CAUTION During valve closure and demate, F-177 (nad) can only be handled from the fwd end of the QD to a point halfway between the QD and P-clamp Use extreme caution when manipulating F-177 (nad) in the fwd, zenith, and nadir directions (during demate only)
7. √MCC GO to close valve on P1-F177 (.5" QD) and that IV venting of PM is complete	11. PGT [A7, CCW2, 30.5]-6-Ext-7/16: Release F177 P-clamp, 12-14 turns 12. Perform the following steps to close valve and demate P1-F177/PM M4: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft)
	C. Verify detent button up D. Verify fwd white line visible E. Rotate locking collar to lock

FS 16-75 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
Pump Module Jumper CETA Cart CCETA CART CCE	F. Demate P1-F177 from M4 G. Restrain P1-F177 clear of PM using adj tethers PM JUMPER N2 VENT AND INSTALL 1. Retrieve PM Jumper from PM Jumper bag 2. Transfer PM Jumper to EV2 3. Attach BRT to CETA cart stbd HR 4. Perform the following steps to mate P1-F176 to PM Jumper M3: A. Demate cap from PM Jumper M3 (lanyarded to box) B. Inspect male and female QDs for debris or damage C. √Button up D. √Release ring retracted (fwd white band not visible) E. Mate P1-F176 to PM jumper M3 F. √Fwd white band visible (snapback, pull and gap√) 5. Perform the following steps to mate P1-F177 to PM Jumper M4: A. Demate cap from PM Jumper M4 (lanyarded to box) B. Inspect male and female QDs for debris or damage C. Verify detent button up D. √Release ring retracted (fwd white band not visible) E. Mate P1-F177 to PM Jumper M4 F. √Fwd white band visible (snapback, pull and gap√) 6. Restrain PM jumper clear of PM removal space; mnvr jumper straight out of truss and stow on CETA cart using adjustables CAUTION Minimize loads to F-177 (nad) when the line is mated/valve open to PM Jumper M4 and pressurized. The line must only be handled halfway in between the QD and P-clamp	PM JUMPER N2 VENT AND INSTALL 1. GCA SSRMS to assist EV1 with PM Jumper 2. Receive PM Jumper from EV1 3. Orient PM jumper such that male QDs face ISS port, M4 nadir 4. React QD loads as reqd

FS 16-76 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
8A. Inform MCC that F44 valve is open (~ 1 min to vent N2) 8B. When N2 venting complete, give MCC go to take NH3 Iso vent valve to close	 7. Perform the following steps to open valve on P1-F177/PM Jumper M4: A. Depress detent button and open valve (push bail fwd) B. √Aft white band visible and detent button up (if this does not happen prior to opening valve on M3, system NH3 would be dumped overboard thru vent panel) 8. On MCC GO, perform the following steps to open valve on P1-F176/PM Jumper M3: A. Depress detent button and open valve (push bail fwd) B. √Aft white band visible and detent button up 9. Assist EV1 with FGB install as reqd 	stbd zenith GP 4 (3rd) stbd GP 1 (4th) GP 2 (1st) FGB ORIENTATION ON P1 PM
9. Record turns and torque for FGB to PM mounting bolts: GP2: turns ft-lb GP3: turns ft-lb GP4: turns ft-lb GP1: turns ft-lb	PUMP MODULE ELECTRICAL CONNECTIONS NOTE Check connectors for damage, emi band, FOD, bent pins, and cable bend radii	 When EV1 complete with QD ops, GCA to FGB install Orient FGB such that RMS target is facing port Put one hand on PM nadir HR and one on FGB HR Soft dock FGB to P1 Pump Module CAUTION GP2 (zen/stbd) must be the first bolt torqued during installation. Remaining bolts torqued in a star pattern PGT [A7, CW2, 30.5]-6-Ext-7/16: Engage PM to FGB mounting bolts (4) 8-11 turns; GP2, GP3, GP4, GP1 Stow 6-in socket on socket caddy Reconfig PGT with 5/8" socket

FS 16-77 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith B4 B3 F171/M1 F170/M2 Stbd F176/M3 F177/M4 B2 B1 nadir P1 PM – FACE 1	 Release TA clamps as reqd Demate the following connectors from the PM and restrain clear of PM using adjustable tethers: P1 P525 from PM J5 (zenith) P1 P524 from PM J4, temp stow P1 P523 from PM J3, temp stow P1 P522 from PM J2, temp stow P1 P521 from PM J1, temp stow Inform EV2 electrical connections complete (give EV2 GO to release last bolt) 	PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolts 4, 3, and 2, 14-17 turns (bolt pops out) Tether to PM
11. P1 PM R&R (SODF: RBT FS: PM Removal)	RELEASE PUMP MODULE BOLTS 1. Assist EV2 as required 2. Monitor clearances between PM and truss as reqd PM HANDOFF POSITION	 On EV1's GO (electricals finished): PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolt 1 14-17 turns (bolt pops out) Holding PM fwd HR and FGB HR, pull PM from truss in forward direction (slides along rails) At SSRMS clearance posn, orient the PM such that: FGB is toward your head You are holding the bottom HRs
12. P1 PM R&R (SODF: RBT FS: Mnvr to handoff)13. P1 PM Handoff (PDRS, Contingency Support)		 TEMP STOW FAILED PUMP MODULE ON SRMS 1. SSRMS mnvr to PM temp stow position 2. While holding PM steady, give SRMS operator GO to capture PM, release tether (leave RET on PM HR) hold PM parallel to chest SRMS will back away to a clearance posn (ISS nad/por)

FS 16-78 EVA/116/FIN

SPARE PUMP MODULE RETRIEVAL FROM ESP2

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	SPARE PUMP MODULE ELECTRICAL CONNECTIONS	BREAK TORQUE ON PUMP MODULE BOLTS
P1 PM R&R (SODF: RBT FS: Spare PM Retrieval)	1. Translate to ESP2, monitor clearances between EV2, LEE, and Lab CAUTION Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used 2. Fold back remaining flaps of MLI tent (front flap already folded back) Release three 1/4 turn fasteners on stbd flap and fold up toward top of PM, attach velcro flaps (2) Release three 1/4 fasteners on aft flap Release MLI strap from top of PM (velcroes) Using strap, pull MLI tent away from PM in port direction, attach to S0/Lab aft struts	 SSRMS mnvr to ESP2 Stow 5/8" socket onto socket caddy GCA SSRMS to PM bolt release worksite (bolt 4) Perform the following steps to break torque on PM bolts 4, 3, 2, and 1: Install round TM w/5/8" proud socket on PM Bolt √Anti-backlash neutral PGT [B6, CCW1, 30.5]-rd TM: Break torque on Bolt ~ 1 turn (of bolt) GCA to next bolt as reqd Remove TM from Bolt 1, stow on MWS Reconfigure PGT w/5/8-in socket
2A. Start PM thermal clock MET:	•	
2B. Record serial #:	 Close FGB-PM mounting bolts thermal cover Read serial # to IV Remove 4 QD caps from M1, M2, M3, and M4 Stow caps on fish stringer #2 Release tape from PM fwd/stbd HR (3 pieces) and fwd/port HR (3 pieces), fold in half, stow in trash bag 	RELEASE PUMP MODULE BOLTS 1. PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolts 1, 2, and 3, 14-17 turns (bolts pop out)
3. √MCC inhibits in place for electrical connections	 8. Demate M/W J5 (P11) from PM J5, temp stow 9. Demate M/W J4 (P10) from PM J4, temp stow 	

FS 16-79 EVA/116/FIN

SPARE PUMP MODULE RETRIEVAL FROM ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 Demate conn cap from from J3, stow on fish stringer #2 Demate conn cap from from J2, stow on fish stringer #2 Demate M/W J1 (P12) from PM J1, temp stow cable on ESP2 HR 8013 Remove fish stringer #2 from PM HRs, stow on VSSA FRAM HR Give EV2 GO to release remaining bolt Monitor clearances as reqd 	 Receive GO from EV1 to release last bolt Tether to PM PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolt 4, 14-17 turns (bolt pops out) Using PM forward HRs, remove PM from FRAM (slides fwd along LAPA guide rails), GCA SSRMS as reqd At clearance position, rotate PM to hold bottom HRs (low-profile config is required for translation past UHF antenna and wrist cluster)

FS 16-80 EVA/116/FIN

SPARE PUMP MODULE INSTALL ON P1

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
P1 PM R&R (SODF: RBT FS: Spare PM Install)	 P1 PM INSTALL Translate to P1 Bay 08 GCA as required Check with EV2 at least 1 bolt installed prior to beginning electrical ops (structural reasons) 	1. SSRMS mnvr to P1 Bay 08 (feet nadir) 2. At truss clearance posn, re-orient PM so that bolts point stbd 3. Install PM into truss, GCA SSRMS as reqd
2. √MCC electrical inhibits in place zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 J2 J1	PUMP MODULE ELECTRICAL CONNECTIONS NOTE Check connectors for damage, FOD, emi band, bent pins, and cable bend radii Mate P1 P521 to PM J1, close TA clamps as required Mate P1 P522 to PM J2, close TA clamps as required Mate P1 P523 to PM J3, close TA clamps as required Mate P1 P524 to PM J4, close TA clamps as required Mate P1 P525 to PM J5, close TA clamps as required Mate P1 P525 to PM J5, close TA clamps as required Inform MCC connectors mated	PM BOLT INITIAL TORQUE 1. GCA SSRMS to PM Bolt 1 (nadir) (reqd to do first) 2. PGT [B7, CW2, 30.5]-7.8"-Ext-5/8: Drive PM Bolts 1, 2, 3, and 4, 14-17 turns 3. Give EV1 GO to begin electricals 4. Release PM tether 5. Remove 5-8" socket from PGT, stow on caddy
nadir P1 PM – FACE 1	PM JUMPER NH3 VENT AND REMOVAL 1. Attach BRT to CETA cart stbd HR 2. Perform the following steps to close valve on P1-F176/PM Jumper M3: A. Close valve (depress button, pull bail aft) B. Verify detent button up	PM JUMPER NH3 VENT AND REMOVAL 1. GCA SSRMS to PM Jumper removal wkst 2. Hold PM Jumper to react loads (Jumper cannot be moved until vented due to loads constraints on M4 line when pressurized)

FS 16-81 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
3A. Give MCC GO for PM Jumper venting (~ 5 min) 3B. Receive GO from MCC: PM Jumper NH3 venting complete; GO for PM Jumper removal zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 nadir P1 PM – FACE 1	C. Verify fwd white line visible 3. Release PM Jumper from CETA cart 4. Transfer PM Jumper to EV2 5. Perform the following steps to close valve and demate P1 F177/PM Jumper M4: A. Close valve (depress button, pull bail aft) B. Verify detent button up C. Verify fwd white line visible D. Rotate locking collar to lock E. Demate P1-F177 from PM Jumper M4 6. Temp stow P1-F177 7. Perform the following step to demate P1-F176 from PM Jumper M3: A. Demate P1-F176 from PM Jumper M3 (using release trigger) CAUTION When mating P1-F176 to PM M3, do not open valve until all N2 has been vented from the PM. Otherwise, undesired mixing of NH3 and N2 will occur inside the PM 8. Perform the following steps to mate P1-F176 to PM M3: A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate P1-F176 to PM M3 E. √Fwd white band visible (snapback, pull and gap√)	 Receive PM Jumper from EV1, react loads as reqd Temp stow PM Jumper

FS 16-82 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)	
4. Receive GO from MCC to mate/open valve on F177 (.5" QD) ~ 12 min (begin MCC venting of N2) zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 nadir P1 PM – FACE 1	P1 PUMP MODULE N2 VENT CAUTION Use extreme caution when manipulating F-177 (nad) in the fwd, zenith, and nadir directions During mate and valve opening, F-177 (nad) can only be handled from the fwd end of the QD to a point halfway between the QD and P-clamp 1. Perform the following steps to mate and open valve on P1-F177/PM M4: A. Inspect male and female QDs for debris or damage B. Verify detent button up; √collar locked C. √Release ring retracted (fwd white band not visible) D. Mate P1-F177 to PM M4 E. √Fwd white band visible (snapback, pull and gap √) F. Rotate locking collar to unlock G. Depress detent button and open valve (push bail fwd) H. √Aft white band visible and detent button up	PM BOLT FINAL TORQUE 1. Perform the following steps for final torquing of PM bolts 1, 2, 3, and 4: □ Install round TM w/5/8" proud socket on PM bolt □ √Anti-backlash neutral □ PGT [A4, CW1, 30.5]-rd TM: Drive PGT ~ 1 turn (of bolt), 5 turns (PGT) □ GCA to next bolt as reqd □ Remove TM from Bolt 4, stow on MWS	

FS 16-83 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
5. √MCC GO to mate/open valve for F171, F170, and F176 (N2 venting complete)	PUMP MODULE QD OPERATIONS CAUTION P1-F177/M4 P-Clamp must be installed prior to opening valve on P1-F176/M3 to preclude damage to P1-F177 QD (weld damage)	
zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 J2 J1 nadir	 PGT [A7, CW2, 30.5]-6-Ext-7/16: Re-install P1-F177 P-Clamp, 12-14 turns Perform the following steps to open valve on P1-F176/PM M3: A. Depress detent button and open valve (push bail fwd) B. √Aft white band visible and detent button up Perform the following steps to mate and open valve on P1-F170/PM M2: A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate P1-F170 to PM M2 E. √Fwd white band visible (snapback, pull and gap√) F. Depress detent button and open valve (push bail fwd) G. √Aft white band visible and detent button up CAUTION Do not use the QD on F-171 (zen) when re-orienting the line to the mate position (use the hard line) When mating F-171 to M1, do not exceed 20 lbs of force in the forward, zenith, and nadir direction 	
P1 PM – FACE 1	Perform the following steps to mate and open valve on P1-F171/PM M1:	

FS 16-84 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith B4 B3 F171/M1 F170/M2 F176/M3 F177/M4 B2 B1 nadir P1 PM - FACE 1	A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate P1-F171 to PM M1 E. √Fwd white band visible (snapback, pull and gap√) F. Depress detent button and open valve (push bail fwd) G. √Aft white band visible and detent button up 5. Retrieve fish stringer #1 from CETA cart 6. Install 1.5" SPDs (3): Install aft part of SPD (black fwd) Depress button and pull bail aft against SPD Install fwd part of SPD (black to black) Push bail against fwd SPD; √button down 7. Install wire tie on three 1.5" SPDs, attach to QD bail, fluid line, or surrounding structure 8. Install .5" SPD: Pull bail aft ~ 1/4 inch (until aft white line hidden Install SPD (slider aft) Push SPD slider forward Secure bail in SPD slider; engage lock button	
Inform MCC when QD ops complete	CETA CART CLEANUP 1. √CETA 1 coupler in CAPTURE 2. Release CETA 1 parking brake (tap pedal twice) 3. Slide CETA 1 toward CETA 2 CAUTION CETA to CETA max coupling rate is 1 inch/sec 4. Couple CETA 1 to CETA 2; take CETA 1 coupler to LOCK 5. Retrieve fish stringer #1 and PM Jumper bag	

FS 16-85 EVA/116/FIN

FAILED PUMP MODULE INSTALL ONTO ESP2

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
 P1 PM R&R (SODF: RBT FS: PM Retrieval) P1 PM Handoff (PDRS, Contingency Support) 		1. SSRMS mnvr to SRMS (clearance posn) 2. GCA SSRMS to PM retrieval posn 3. Grasp PM using bottom HRs (head nearest to FGB), use RET left on PM to tether 4. Give SRMS operator GO for PM ungrapple 5. Give SRMS operator GO to mnvr to clearance posn
 3. P1 PM R&R (SODF: RBT FS: Failed PM Install on ESP2) 4. Start torque wrench 	 INSTALL FAILED PUMP MODULE ONTO ESP2 1. Translate to airlock, temp stow fish stringer #1 and PM Jumper 2. Retrieve torque wrench from inside airlock 	1. SSRMS mnvr to ESP2 failed PM install posn
thermal clock :	 Translate to ESP2 Monitor clearances between EV2, LEE, and Lab BRT to ESP2 HR 8012 (fwd) GCA as required Retrieve fish stringer #2 from VSSA FRAM HRs Retrieve M/W J4 and J5 connectors 	 Reorient PM so FGB interface is fwd Install PM onto PM FSE, GCA SSRMS as reqd PM BOLT INITIAL TORQUE GCA SSRMS to PM bolts PGT [B7, CW2, 30.5]-7.8"-Ext-5/8: Drive PM Bolt 1, 14-17 turns (reqd to do first)

FS 16-86 EVA/116/FIN

FAILED PUMP MODULE INSTALL ONTO ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	9. Receive GO from EV2 to translate on PM 10. Install fish stringer #2 on PM HRs	 Give EV1 GO to translate on PM Drive PM Bolts 2, 3, and 4, 14-17 turns Remove 5/8" socket from PGT, temp stow Release PM tether
5. √MCC electrical inhibits in place	PM ELECTRICAL CONNECTIONS 1. Mate M/W J5 (P11) to PM J5	
	 Mate M/W J4 (P10) to PM J4 Retrieve J3 cap from fish stringer #2, mate to J3 Retrieve J2 cap from fish stringer #2, mate to J2 Transfer torque wrench to EV2 Retrieve M/W J1 connector, mate M/W J1 (P12) to PM J1 Inform IV when connections complete 	PM BOLT FINAL TORQUE 1. Receive torque wrench from EV1, verify set to 37 ft-lbs 2. Install 5/8" socket onto wrench 3. Tighten PM bolts (4) until torque wrench trips (any order)
6. Give MCC GO to power up PM on ESP2 after EV1 and EV2 connections complete	8. Retrieve QD caps (4) from fish stringer NOTE QD cap lock tab may not fully engage. If tab does not fully engage after several attempts to seat, leave QD uncapped 9. Install QD caps onto M1, M2, M3, and M4	SSRMS CLEANUP 1. SSRMS mnvr to ESP2 egress posn 2. Egress SSRMS 3. Perform safety tether swap onto airlock safety tether, verify ST config 4. Relocate APFR from SSRMS to A/L Toolbox #1; reconfigure to: [9,MM,F,12]
7. P1 PM R&R (SODF: RBT FS: APFR Egress)8. P1 PM R&R (SODF: RBT FS: APFR Removal)	 10. Retrieve fish stringer #2 from PM HRs 11. Release MLI strap from S0/Lab struts and re-install MLI onto PM Attach aft 1/4 turn fasteners (3) Release stbd flap from top of MLI (2 straps) 	 Remove WIF adapter, stow on MWS Translate to airlock Perform tool inventory Stow torque wrench on fish stringer #1

FS 16-87 EVA/116/FIN

FAILED PUMP MODULE INSTALL ONTO ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	□ Verify Velcro from Flap 3 is attached □ Attach stbd 1/4 turn fasteners (2) 12. When EV2 complete w/bolts, reinstall MLI tent 13. Ensure all Velcro flaps are covered, and fwd Velcro strap installed	
	CLEANUP	
	 Translate to crewlock and stow PM Jumper bag Translate to airlock Perform tool inventory 	

FS 16-88 EVA/116/FIN

INGRESS

IV	EV1 (FF)	EV2 (FF)
Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)	 Receive EV2 safety tether; stow on airlock aft D-ring, √reel unlocked Transfer fish stringers #1 and #2 to EV2 Connect right waist tether to D-ring extender on airlock internal D-ring, verify ST config Disconnect from airlock safety tether, stow on airlock fwd 	 Ingress airlock Connect right waist tether to UIA panel fwd D-ring, verify ST config Disconnect from airlock safety tether, hand to EV1 Receive fish stringers #1 and #2 from EV1
	 D-ring, √reel unlocked Ingress airlock Retrieve SCU, remove DCM cover Connect SCU to DCM, √locked DCM: water – OFF Hatch thermal cover – close, attach Velcro strap 	 5. Retrieve SCU, remove DCM cover 6. Connect SCU to DCM, √locked 7. DCM: water – OFF
		JTION EMU water – OFF for 2 min 8. Go to PRE REPRESS

FS 16-89 EVA/116/FIN

P1 PUMP MODULE R&R TASK DATA SHEET

Tools:

EV1	EV2
PGT w/6-in	PGT w/6-in
PM Jumper	Round TM w/58" proud socket
(1.5" vent tool)	Torque Wrench

Foot Restraints:

Task	WIF	APFR Setting
PM R&R	SSRMS	12, PP, F,6

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release Torque	Failure Torque	Turns	RPM
Name		Oize		(ft-lbs)	(ft-lbs)		
FGB-PM mounting bolts	GP1, GP2, GP3, GP4	7/16"	4	Release: 25.5 Install: 9.2		Release: 17-20 Install: 8-11 (w/FGB inplace)	30
PM Attach Bolts (truss)	Bolt 1, 2, 3,4	5/8"	4	Release: 25 (w/TM) Install: 6.3 (w/TM)		Release: 14-17 Install: 14-17	30
PM Attach Bolts (FSE)	Bolt 1, 2, 3,4	5/8"	4	Release: 24 (w/TM) Install: 37 – torq wren		Release: 14-17 Install: 14-17	30
P-Clamp Bolts	NA	7/16"	4	Release: 9.2 Install: 7.0		Release: 12-14 Install: 12-14	30

EVA Connectors:

Connector	From	То	Clamps	Size	Function
P1 P525		PM J5	1		
P1 P524		PM J4	1		
P1 P523		PM J3	1		
P1 P522		PM J2	1		
P1 P521		PM J1	1		
ESP2 M/W J5 (P11)		PM J5			
ESP2 M/W J4 (P10)		PM J4			
ESP2 M/W J1 (P12)		PM J1			

Notes:

- Check connectors for damage, emi band, FOD, bent pins, and cable bend radii
- 2. Original vent time of 00:25 for failed PM NH3 vent given by TCS community. New time of 00:08 minutes given by Boeing TCS

Cautions:

- 1. When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing
- 2. Avoid contact with FGB grapple pin and RMS target
- 3. Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used
- 4. GP2 must be the first bolt torqued during installation. Remaining bolts torqued in a star pattern
- 5. When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing
- 6. PM Installation bolts (for initial torque) must be installed in the following order: bolt 1 first, and then bolts 2-4 in any order (due to nut plate tolerances). There is no required order for bolt release, and no required order for torque multiplier operations (KSC)

Warnings:

1. N/A


Timeline Considerations:

 The PM thermal clock begins when the PM MLI tent is removed on ESP2

Connector	From	То	Clamps	Size	Function
P1 F171	NA	PM M1	1 P,	1.5"	Bypass outlet
			1 TA		
P1 F170	NA	PM M2	1 P,	1.5"	Radiator return
			1 TA		
P1 F176	NA	PM M3	1 P,	1.5"	Pump Outlet
			1 TA		
P1 F177	NA	PM M4	1 P,	.5"	Ammonia supply
			1 TA		

FS 16-90 EVA/116/FIN

P1 PUMP MODULE R&R TASK DATA SHEET



FS 16-91 EVA/116/FIN

NOTES

Assumptions:

- MT @ WS 4; CETA carts coupled to port side of MT
- SSRMS on Lab PDGF
- SSRMS on MBS PDGF 3
- Temp stow failed PM on SRMS
- Keep crew separated from each other during failed PM venting ops to minimize contamination
- Plan to leave all cont tools in airlock
- Plan to remove 4 QD caps and 2 remaining electrical dust caps at ESP2 and leave them there for PM translation to S1
- EV1 FF/EV2 SSRMS
- EV1 on 85' safety tether
- Use second set of QD tools that are inside to save time during EVA (won't have to go to QD tool bag) OR go to bag??? Have to get extender from outside anyway or does 12A.1 launch?
- SSRMS translation times will be longer than S1 (from ESP2 to truss and back)
- Should not need to do a safety tether swap if on 85 footer
- For venting: the procedure is written assuming that IV can vent through the vent panel, and that no EVA venting of the NH3 from the failed PM is required. It also assumes we vent the PM jumper of Nitrogen using the vent panel and not the vent tool
- Need 2 crewmembers for all PM jumper operations, including N2 venting of jumper
- If EV crew vents N2 from spare PM on ESP2 (~12 min)
- The procedure is baselined to allow MCC to vent the N2 from the spare PM while it's in the truss. There is no additional EVA time needed for this. As soon as the PM gets installed into the truss, EV1 will mate and open valve on the .5: QD; no electricals are reqd for this since the valves are already configured to allow the N2 to vented through the ATA panel. No additional EVA time is needed

FS 16-92 EVA/116/FIN

CETA CART WHEEL BOGIE R&R

Objective: Removal of a wheel bogie to allow relocation of the CETA cart in a failure case where a wheel bogie failed to pivot clear of the MT/CETA rail. Once the cart is relocated the wheel bogie is reinstalled

Wheel Bogie Removal

- 1. Retrieve CETA cart PIP pin (SEG 33108659-705) from crewlock bag #2
- 2. √Parking brake off
- 3. √CETA cart coupled to MT or restrained prior to bogie release
- 4. Insert PIP pin to restrain brake linkages
- 5. PGT [A7, CCW2, 30.5]-6"-Ext-7/16:
 Disengage ORU bolts (4) ~8 turns (bolts pop out)
- 6. Remove wheel bogie

Wheel Bogie Installation

NOTE

Pip-pin installation ensures proper brake pad alignment. If brake pad misaligned, wheel bogie cannot be installed due to interference with MT rails.

If CETA cart is not on rails during bogie installation, wheel bogie can be installed such that brake mechanism is not connected

- 1. Install CETA cart on rails; engage other bogies
- 2. √CETA/MT Coupler set to capture, couple CETA cart to MT
- 3. Take coupler to locked
- 4. √Parking brake released
- 5. Install wheel bogie into tray guides
 - * If brake cable mechanical coupler interferes (wheel bogie
 * will not install fully):
 * Pull dynamic brake handle while reattempting install
 *
 * If no PIP pin used and bogie will not fully install:
 * Remove bogie, realign brake pad linkage and reattempt
- 6. **PGT:** [A7, CW2 30.5]-6"-Ext-7/16:

Engage ORU bolts (4) ~8 turns


7. Remove PIP pin

CETA CART WHEEL BOGIE TASK DATA SHEET


EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Wheel bogie ORU bolt	none	7/16	4	7-10	10		8	30 Max

WHEEL BOGIE R&R - REFERENCE



WHEEL BOGIE INSTALLED - OUTBOARD VIEW




WHEEL BOGIE REMOVED - INBOARD VIEW

Brake Linkage Slot (Slot A) △

FS 16-94 EVA/116/FIN


WHEEL BOGIE R&R - REFERENCE (Cont)

WHEEL BOGIE REMOVED - OUTBOARD VIEW



Brake Linkage Engagement Tab (tab A)

WHEEL BOGIE PARTIALLY INSTALLED - INBOARD VIEW



Cutout in rail not fight like

FS 16-95 EVA/116/FIN

EVA 3 CONTINGENCY

CHANNEL 1/4 CONNECTOR BACKOUT (01:00)

IV	EV1 (FF)	EV2 (FF)
1. Verify w/MCC inhibits in place: Power Reconfig Inhibit Check (SODF: ASSY OPS: EPS CH 1/4) Powerdown for EVA 3, steps 6 and 7) complete (DCSU 4B RBI 6 open) (DCSU 4A RBI 6 open)		DTE band, bent pins, and cable bend radii CIDS 1 AND 2 REMOVAL/S0 TRAY CONNECTIONS 1. Perform safety tether swap onto airlock safety tether as reqd, verify ST config NOTE Avoid contact with S0 radiator 2. Translate to port Z1-S0 tray area; fairlead above Z1 MBM, P6 HR 5308 3. Demate S0 P201 from Lab J201; mate to S0 J462 4. Demate S0 P202 from Lab J202; mate to S0 J463 5. Demate S0 P232 from Z1 J432; mate to S0 J460 6. Demate Z1 P301 (W26B) from Z1 J201 (tray), mate to Lab J201 (CID removed) 7. Demate Z1 P302 (W26C) from Z1 J202 (tray), mate to Lab J202 (CID removed)

FS 16-96 EVA/116/FIN

CHANNEL 1/4 CONNECTOR BACKOUT (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
2. When all EV2's connections complete, notify MCC	LAB 4A DDCU SECONDARY POWER DISCONNECT FROM SO CAUTION Avoid contact with GPS antennas and S0 radiator 1. Translate to S0 Bay 00, access through face 3 2. Open MLI door 3. Attach fairlead to HR 3414, ingress truss 4. Demate S0 P333 from S0 CH 1/4 pwr cable J333A 5. Demate S0 CH 1/4 pwr cable P333A from S0 J333 6. Mate S0 P333 to S0 J333 7. Egress truss, remove fairlead 8. Close MLI door 9. Retrieve jumper, stow on MWS 10. □□□ connector closeout S0-1A DDCU RECONFIGURATION (Panel A27) 1. Translate to CETA 2 2. Translate to port-most CETA cart (CETA 1) 3. Rotate CETA 1 coupler to UNLOCK, slide CETA port until clear of S0 Bay 01 4. Engage parking brake (left handle) 5. Rotate CETA 1 coupler to CAPTURE 6. Translate to S0 Bay 01 7. Access worksite through face 1 8. Remove connector cap from J8 on DDCU coldplate connector box (cap is lanyarded to panel) 9. Demate S0 P157 (W4145) from J7; mate to J8 10. Install connector cap on J7 11. □□□ connector closeout 12. Release CETA parking brake (tap pedal twice)	Z1-003 PATCH PANEL 6 RECONFIGURATION (DDCU HP 4B) (nadir panel) 1. Translate to Z1 PP6 (stbd face) CAUTION Avoid contact with Z1 heat pipes and SASA antennas 2. Fold back thermal shroud (STD SHRD Z1/02/04-03), release Velcro straps from HRs 6005 and 6024 3. Remove connector cap from J4 4. Demate Z1 P2 (W23) from Z1 J3; mate to Z1 J4 5. Install connector cap on J3 6. □□ connector closeout 7. Reinstall thermal shroud

FS 16-97 EVA/116/FIN

CHANNEL 1/4 CONNECTOR BACKOUT (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
When all EV1's connections complete, notify MCC	CAUTION CETA to CETA max coupling rate is 1 inch/sec 13. Couple CETA 1 to CETA 2, take CETA 1 coupler to LOCK SO FWD STBD AVIONICS RECONFIGURATION (Panel A148) 1. Translate to stbd S0 connector panel (Bay 01, Face 6) 2. BRT to HR 3443 3. Remove DF cap from S0 J237 4. Demate P226 (W9003) from S0 J226; mate to S0 J237 5. Install DF cap on S0 J226	
	NOTE Z1-005 PP 1 Reconfig will not be backed out since the nominal reconfig will be skipped in the event of either an MBSU or DDCU R&R. The steps are listed for info only	
	Z1-005 PATCH PANEL 1 RECONFIGURATION (SPDA Z1-4B) (nadir panel) 1. Translate to Z1 port face; fairlead above Z1, MBM P6 HR 5308	

FS 16-98 EVA/116/FIN

CHANNEL 1/4 CONNECTOR BACKOUT (01:00) (Cont)

IV	EV1 (FF)	EV2 (FF)
	CAUTION Avoid contact with PCUs and S0 radiator NOTE J3 label is missing off of patch panel 2 Remove connector cap from J3; temp stow Demate Z1 P1 (W10) from Z1 J1; mate to Z1 J3 Install connector cap on J1	

FS 16-99 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. Verify w/MCC ESP2 inhibits in place: RPCM N1RS2-B RPC10 – OPEN AND CLOSE INHIBITED RPCM S04B F RPC 12 – OPEN AND CLOSE INHIBITED	CETA CART PREP 1. Translate to port-most CETA cart (CETA 1)(S0 Bay 01) 2. Deploy port brake handles on CETA 1 (down) 3. Take CETA coupler to UNLOCK 4. Mnvr CETA 1 port ~ 5 feet 5. Deploy stbd brake handles on CETA 1 (down) 6. √CETA 1 brakes by pulling parking brake (left handle) 7. Take CETA 1 coupler to CAPTURE 8. Release CETA 1 brakes (tap pedal twice) 9. Translate CETA 1 to S0 Bay 00 (by hand): ■ Stop when stbd TFR is port of CETA marker 7650 10. Engage parking brake – left handle 11. Rotate port TFR swing arm to 15	 SSRMS SETUP Translate to airlock Retrieve spare safety tether, WIF adapter, and PGT w/RET from airlock HR 0560, stow on MWS Retrieve APFR from airlock toolbox 1 WIF (if reqd), attach to BRT Translate to ESP2 Install WIF adapter onto SSRMS, tether point oriented toward EE Install APFR into WIF adapter: configure to: [12,PP,F,6] Perform safety tether swap onto SSRMS, verify ST config; stow spare tether clear of MBSU removal envelope and ESP2 trajectory Ingress SSRMS (head aft, face port)
	TOOL RETRIEVAL 1. Translate to airlock 2. Retrieve crewlock bag #1, BRT 3. Translate to Z1 stbd toolbox 4. Retrieve 2 sq scoops from toolbox lid: □ Stow 1 sq scoop on MWS □ Stow 1 sq scoop in crewlock bag #1 (may have to relocate D-Handle to get sq scoop) 5. Open right door 6. Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS (release slider lock only) 7. Close door – both latches reqd if not coming back	

FS 16-100 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	SPARE MBSU RETRIEVAL FROM ESP2	SPARE MBSU RETRIEVAL FROM ESP2
Zenith S T	 Translate to ESP2, temp stow crewlock bag #1 on CETA spur Attach BRT to ESP2 HR 8003 (aft face, stbd side) Engage FRAM soft capture lever (slides down) PGT [A4, CCW2, 10.5]-6"-Ext-7/16: Release primary FRAM bolt 11 turns (hard stop) Using vertical HRs on FRAM, remove MBSU from ESP2 (magnetic soft dock to overcome) Transfer MBSU to EV2 GCA EV2 and SSRMS clear of ESP2 Retrieve EV2's airlock safety tether from ESP2, attach to MWS Retrieve crewlock bag #1 from CETA spur, attach to BRT 	Receive MBSU from EV1 (body is parallel to stbd side of ESP2 with head aft and face port)
Nadir	TEMP STOW SPARE MBSU ON CETA CART	TEMP STOW SPARE MBSU ON CETA CART
MBSU ORIENTATION ON CETA CART GRID E	 Translate to CETA 1 on S0 Bay 00 Temp stow crewlock bag #1 on port side of CETA cart, S0 HR 3494 Temp stow EV2's airlock safety tether on port S0/Lab strut clear of SSRMS trajectory Retrieve ballstack from crewlock bag #1, install on port TFR swingarm ECOM fitting Position body to see grid E 	 SSRMS mnvr to CETA 1 on S0 Bay 00 Rotate MBSU until FRAM primary bolt faces ISS zenith Install MBSU/FRAM onto grid E (zenith center)
	 6. Assist EV2 with clearances 7. PGT [A4, CW2, 10.5]-6"- Ext-7/16: Drive primary FRAM bolt 11 turns (hard stop) 8. Retrieve sq scoop from crewlock bag #1, transfer to EV2 	(rock FRAM square grid into place) 4. Receive sq scoop from EV1, stow on MWS

FS 16-101 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
2. Verify w/MCC S0 inhibits in place: MBSU 4 RBI 7 Op (CI Inh) MBSU 4 RBI 6 Op (CI Inh) MBSU 2 RBI 14 Op (CI Inh) 3. Record failed MBSU serial #: zenith H2 nadir MBSU ORIENTATION ON FACE 2	MBSU REMOVAL FROM S0 FACE 2 (1A1B) 1. Translate to failed MBSU (stbd zenith) 2. Install sq TM onto H1 fitting, √anti-backlash neutral 3. Get in posn to assist EV2	MBSU REMOVAL FROM S0 FACE 2 (1A1B) 1. SSRMS mnvr to failed MBSU wkst (stbd zenith) CAUTION

FS 16-102 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	4. Assist EV2 w/clearances	NOTE Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE WARNING Fins on bottom of MBSU and coldplate are no-touch 11. Remove MBSU from coldplate
Zenith	5. Translate to port side of CETA cart6. Assist EV2	12.√Status indicator on H1 in LOCK 13. SSRMS mnvr to port side of CETA cart 14. Attach MBSU to ballstack 15. Remove free sq scoop from MBSU, stow on MWS
S T B O	SPARE MBSU REMOVAL FROM FRAM	SPARE MBSU REMOVAL FROM FRAM
Nadir MBSU ORIENTATION ON	 1. Release MBSU thermal cover: Release velcro tabs on front, side, and back corners of ORU base Release integral strap from underside of fwd flap Fold or roll cover toward back of MBSU, attach strap to Velcro mating swatch on back side of MLI (can also attach strap to adjacent structure) 	SRMS mnvr to spare MBSU (head nadir) CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur
CETA CART GRID E 4. Record spare MBSU serial #:	☐ Using side straps from front of MLI, secure rest MLI as reqd ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	2. Demons and an accomplished the settle to	 Install sq TM onto H1 fitting, √anti-backlash neutral PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt) Remove sq TM from H1, install onto H2 √Anti-backlash neutral
	Remove 3rd sq scoop from crewlock bag #1, transfer to EV2	5. Receive sq scoop from EV1, install onto H1 fitting

FS 16-103 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith		 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) Remove sq TM from H2, stow on MWS or handoff to EV1 Install sq scoop onto H2 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK
H2		NOTE Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE
nadir MBSU ORIENTATION ON FACE 2		WARNING Fins on bottom of MBSU are no-touch
	3. Assist EV2 w/clearances	11. Remove MBSU from FRAM 12.√Status indicator on H1 in LOCK
	SPARE MBSU INSTALLATION ONTO SO	SPARE MBSU INSTALLATION ONTO SO
	Translate to stbd zenith MBSU coldplate	 SSRMS mnvr to S0 wkst (stbd zenith MBSU) Orient MBSU such that blind-mate connectors and H2 fitting are zenith

FS 16-104 EVA/116/FIN

MBSU REMOVE AND REPLACE – 1A1B (EVA 3) (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	2. GCA EV2 as required	NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto coldplate 3. Install MBSU onto coldplate 4. √Status indicator on H1 is in UNLOCK
H1 \bigcirc		CAUTION H2 bolt must always be installed first or damage to ORU and underlying structure will occur 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK
nadir MBSU ORIENTATION ON FACE 2		6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
5. Inform MCC MBSU installed		7. Remove sq scoops from MBSU, stow on MWS
Zenith S T B D H1 H2 Nadir	 INSTALLATION OF FAILED MBSU ONTO FRAM Translate to port TFR swingarm Remove ballstack from port swingarm, stow in crewlock bag #1 Stow port swingarm (rotate to 0) 	INSTALLATION OF FAILED MBSU ONTO FRAM 1. SSRMS mnvr to failed MBSU on port TFR swingarm 2. Release MBSU from ballstack 3. Orient MBSU such that H2 fitting is port 4. SSRMS mnvr to FRAM NOTE
MBSU ORIENTATION ON CETA CART GRID E		Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto FRAM

FS 16-105 EVA/116/FIN

MBSU REMOVE AND REPLACE – 1A1B (EVA 3) (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 4. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 5. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 6. Install MBSU thermal cover 	 Install failed MBSU onto FRAM (ball detent soft dock on primary bolt and stanchion) √Status indicator on H1 is in UNLOCK PGT [B2, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK Remove square scoop from H2, transfer to EV2 Remove square scoop from H1, transfer to EV2 PGT [B2, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
	1. If necessary, stow CETA 1 swingarms 2. Release brake pedal (tap pedal twice) 3. Translate CETA 1 to S0 Bay 01 4. Stow stbd brake handles (up) CAUTION CETA to CETA max coupling rate is 1 inch/sec 5. Couple CETA 1 to CETA 2 6. Take CETA 1 coupler to LOCK 7. Stow port brake handles (UP) 8. Retrieve crewlock bag #1 9. Translate to airlock	 SSRMS mnvr to egress posn on S0 (port of MT) Egress SSRMS (on CETA cart) Remove APFR from SSRMS, attach to BRT Remove WIF adapter from SSRMS, stow on MWS Perform safety tether swap onto airlock safety tether, verify ST config; retrieve spare from SSRMS Translate to airlock Stow APFR in airlock toolbox 1 (stbd) WIF; configure to: [9,MM,F,12]

FS 16-106 EVA/116/FIN

MBSU REMOVE AND REPLACE - 1A1B (EVA 3) TASK DATA SHEET

Tools:

	-
EV1	EV2
PGT w-6-in	PGT
Crewlock bag #1	APFR
Sq TM w/7/16 recessed socket	
Ballstack	
3 sq scoops	

EVA Fasteners:

Fastanan	_	04.	Dalassa	14-11	F-!!	T	DDM
Fastener	Head	Qty	Release	Install	Failure	Turns	RPM
Name/Label	Size		Torque	Torque	Torque		
			(ft-lbs)	-	(ft-lbs)		
H1	7/16	1	BREAK TORQUE 60.0 (bolt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			12.0 (pgt)		22.8		
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

Foot Restraints:

Task	WIF	Swingarm Setting	P/Y Fitting	APFR Setting
MBSU R&R	SSRMS			[12,PP,F,6]

Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- 2. Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. CETA to CETA max coupling rate is 1 inch/sec
- 4. There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H1 bolt must always be released first or damage to ORU and underlying structure will occur
- 4. H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

ORU Weight with FRAM = ~ 500 lbs

EVA Connectors: N/A

Assumptions:

- 1. Both CETA carts are port and MT is @ WS 3
- 2. Using 85' safety tethers from airlock D-rings
- 3. Failure discovered on way to SMDP task: EV1 on way to ICC, EV2 has not ingressed SRMS for SMDPs yet
- 4. TM not reqd for on-orbit loads
- 5. Failed MBSU left on CETA cart at end of EVA (CETA is coupled to MT)
- 6. Due to long SSRMS times, EV1 will do all setup tasks
- 7. EV2 gets spare PGT from airlock, has APFR on BRT
- 8. EV1 already has a PGT

FS 16-107 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. Verify w/MCC ESP2 inhibits in place: RPCM N1RS2-B RPC10 – OPEN AND CLOSE INHIBITED RPCM S04B F RPC 12 – OPEN AND CLOSE INHIBITED	CETA CART PREP 1. Translate to port-most CETA cart (CETA 1)(S0 Bay 01) 2. Deploy port brake handles on CETA 1 (down) 3. Take CETA coupler to UNLOCK 4. Mnvr CETA 1 port ~ 5 feet 5. Deploy stbd brake handles on CETA 1 (down) 6. √CETA 1 brakes by pulling parking brake (left handle) 7. Take CETA 1 coupler to CAPTURE 8. Release CETA 1 brakes (tap pedal twice) 9. Translate CETA 1 to S0 Bay 00 (by hand):	 SSRMS SETUP Translate to airlock Retrieve spare safety tether, WIF adapter, and PGT w/RET from airlock HR 0560, stow on MWS Retrieve APFR from airlock toolbox 1 WIF (if reqd), attach to BRT Translate to ESP2 Install WIF adapter onto SSRMS, tether point oriented toward EE Install APFR into WIF adapter: configure to: [12,PP,F,6] Perform safety tether swap onto SSRMS, verify ST config; stow spare tether on ESP2 HR 8002 clear of MBSU removal envelope and ESP2 trajectory Ingress SSRMS (head aft, face port)
	TOOL RETRIEVAL 1. Translate to airlock 2. Retrieve crewlock bag #1, BRT 3. Translate to Z1 stbd toolbox 4. Retrieve 2 sq scoops from toolbox lid: □ Stow 1 sq scoop on MWS □ Stow 1 sq scoop in crewlock bag #1 (may have to relocate D-Handle to get sq scoop) 5. Open right door 6. Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS (release slider locks only) 7. Close door – both latches reqd if not coming back	

FS 16-108 EVA/116/FIN

IV/SSRMS		EV1 (FF)	EV2 (SSRMS)
		SPARE MBSU RETRIEVAL FROM ESP2	SPARE MBSU RETRIEVAL FROM ESP2
STB	Zenith 🔷	 Translate to ESP2, temp stow crewlock bag #1 on CETA spur Attach BRT to ESP2 HR 8003 (aft face, stbd side) Engage FRAM soft capture lever (slides down) PGT [A4, CCW2, 10.5]-6"-Ext-7/16: Release primary FRAM bolt 11 turns (hard stop) Using vertical HRs on FRAM, remove MBSU from ESP2 (magnetic soft dock to overcome) Transfer MBSU to EV2 GCA EV2 and SSRMS clear of ESP2 Retrieve EV2's airlock safety tether from ESP2, attach to MWS Retrieve crewlock bag #1 from CETA spur, attach to BRT 	Receive MBSU from EV1 (body is parallel to stbd side of ESP2 with head aft and face port)
D	H1 H2	TEMP STOW SPARE MBSU ON CETA CART	TEMP STOW SPARE MBSU ON CETA CART
	Nadir BSU ORIENTATION ON CETA CART GRID E	 Translate to CETA 1 on S0 Bay 00 Temp stow crewlock bag #1 on port side of CETA cart, S0 HR 3494 Temp stow EV2's airlock safety tether on port S0/Lab strut clear of SSRMS trajectory Retrieve ballstack from crewlock bag #1, install on port TFR swingarm ECOM fitting Position body to see grid E Assist EV2 with clearances PGT [A4, CW2, 10.5]-6"- Ext-7/16: Drive primary FRAM bolt 11 turns (hard stop) Retrieve sq scoop from crewlock bag #1, transfer to EV2 	1. SSRMS mnvr to CETA 1 on S0 Bay 00 2. Rotate MBSU until FRAM primary bolt faces ISS zenith 3. Install MBSU/FRAM onto grid E (zenith center) (rock FRAM square grid into place) 4. Receive sq scoop from EV1, stow on MWS

FS 16-109 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
2. Verify w/MCC S0 inhibits in place: DCSU P4 4A RBI 6 Op (Cl Inh) DCSU P6 4B RBI 6 Op (Cl Inh) MBSU 3 RBI 6 Op (Cl Inh) MBSU 3 RBI 6 Op (Cl Inh) MBSU 3 RBI 14 Op (Cl Inh)	MBSU REMOVAL FROM S0 FACE 2 (4A4B) 1. Translate to failed MBSU (port zenith)	MBSU REMOVAL FROM S0 FACE 2 (4A4B) 1. SSRMS mnvr to failed MBSU wkst (port zenith)
zenith H2 H1 nadir MBSU ORIENTATION ON FACE 2	 2. Install sq TM onto H1 fitting, √anti-backlash neutral 3. Get in posn to assist EV2 	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 2. Temp stow 2-in socket on PIP pin in trash bag 3. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt) 4. Remove sq TM from H1, install onto H2 √Anti-backlash neutral 5. Install sq scoop onto H1, handle points zenith 6. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 7. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 8. Remove sq TM from H2, stow on MWS 9. Install sq scoop onto H2, handle points zenith 10. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK

FS 16-110 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
		NOTE Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE
		WARNING Fins on bottom of MBSU and coldplate are no-touch
	4. Assist EV2 w/clearances5. Translate to port side of CETA cart6. Assist EV2	 11. Remove MBSU from coldplate 12.√Status indicator on H1 in LOCK 13. SSRMS mnvr to port side of CETA cart 14. Attach MBSU to ballstack 15. Remove free sq scoop from MBSU, stow on MWS
Zenith S T	SPARE MBSU REMOVAL FROM FRAM 1. Release MBSU thermal cover: Release velcro tabs on front, side, and back corners of ORU base Release integral strap from underside of fwd flap Fold or roll cover toward back of MBSU, attach strap to Velcro mating swatch on back side of MLI	SPARE MBSU REMOVAL FROM FRAM 1. SSRMS mnvr to spare MBSU (head nadir) CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur
4. Record spare MBSU serial #: ————	(can also attach strap to adjacent structure) □ Using side straps from front of MLI, secure rest MLI as reqd □	 Install sq TM onto H1 fitting, √anti-backlash neutral PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, 5 turns (PGT), 1 turn (bolt)

FS 16-111 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	Remove 3rd sq scoop from crewlock bag #1, transfer to EV2	 4. Remove sq TM from H1, install onto H2 √Anti-backlash neutral 5. Receive sq scoop from EV1, install onto H1 fitting
zenith		 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) Remove sqTM from H2, stow on MWS or handoff to EV1 Install sq scoop onto H2 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: (use EV1's PGT) Release H2 acme screw ~ 18 turns √Status indicator – UNLOCK
H2 🔷		NOTE Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal from FSE
nadir MBSU ORIENTATION ON FACE 2		WARNING Fins on bottom of MBSU are no-touch
	3. Assist EV2 w/clearances	11. Remove MBSU from FRAM 12.√Status indicator on H1 in LOCK

FS 16-112 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	SPARE MBSU INSTALLATION ONTO SO	SPARE MBSU INSTALLATION ONTO SO
	Translate to port zenith MBSU coldplate	 SRMS mnvr to S0 wkst (port zenith MBSU) Orient MBSU such that blind-mate connectors and H2 fitting are zenith
zenith		NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto coldplate
H2 A	2. GCA EV2 as required	3. Install MBSU onto coldplate4. √Status indicator on H1 is in UNLOCK
H1 🔷		CAUTION H2 bolt must always be installed first or damage to ORU and underlying structure will occur
nadir MBSU ORIENTATION ON FACE 2		 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
Inform MCC MBSU Installed		7. Remove sq scoops from MBSU, stow on MWS
	INSTALLATION OF FAILED MBSU ONTO FRAM	INSTALLATION OF FAILED MBSU ONTO FRAM
	Translate to port TFR swingarm	SSRMS mnvr to failed MBSU on port TFR swingarm Release MBSU from ballstack

FS 16-113 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 2. Remove ballstack from port swingarm, stow in crewlock bag #1 3. Stow port swingarm (rotate to 0) 	Orient MBSU such that H2 fitting is port SRMS mnvr to FRAM NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during MBSU installation onto FRAM
Zenith S T B D H1 H2 Nadir MBSU ORIENTATION ON CETA CART GRID E	 4. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 5. Receive sq scoop from EV1, stow on MWS (or in crewlock bag #1) 6. Install MBSU thermal cover 	 Install failed MBSU onto FRAM (ball detent soft dock on primary bolt and stanchion) √Status indicator on H1 is in UNLOCK PGT [B2, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK Remove square scoop from H2, transfer to EV2 Remove square scoop from H1, transfer to EV2 PGT [B2, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK
	1. If necessary, stow CETA 1 swingarms 2. Release brake pedal (tap pedal twice) 3. Translate CETA 1 to S0 Bay 01 4. Stow stbd brake handles (up) CAUTION CETA to CETA max coupling rate is 1 inch/sec	 SSRMS mnvr to egress posn on S0 (port of MT) Egress SSRMS (on CETA cart) Remove APFR from SSRMS, attach to BRT Remove WIF adapter from SSRMS, stow on MWS Perform safety tether swap onto airlock safety tether, verify ST config; retrieve spare from SSRMS Translate to airlock Stow APFR in airlock toolbox 1 (stbd) WIF; configure to: [9,MM,F,12]

FS 16-114 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 5. Couple CETA 1 to CETA 2 6. Take CETA 1 coupler to LOCK 7. Stow port brake handles (UP) 8. Retrieve crewlock bag #1 9. Translate to airlock 	

FS 16-115 EVA/116/FIN

MBSU REMOVE AND REPLACE - 4A4B (EVA 3) TASK DATA SHEET

Tools:

EV1	EV2
PGT w-6-in	PGT
Crewlock bag #1	APFR
Sq TM w/7/16 recessed socket	
Ballstack	
3 sq scoops	

EVA Fasteners:

Fastener	Head	Qty	Release	Install	Failure	Turns	RPM
Name/Label	Size		Torque	Torque	Torque		
			(ft-lbs)		(ft-lbs)		
H1	7/16	1	BREAK	4.8	190.3	1	30
			TORQUE	(bolt)	(bolt) (removal)		
			60.0 (bolt)		,		
			12.0 (pgt)		22.8		
			RUNNING		(bolt)	8	
			TORQUE		(install)		
			(very little,				
			just picked				
H2	7/16	1	12.0)	4.0	100.4	1	30
П2	7/16	ı	BREAK TORQUE	4.8 (bolt)	188.4 (bolt)	1	30
			TORQUE	(DOIL)	(removal)		
			60.0 (bolt)		,		
			12.0 (pgt)		27.8		
			RUNNING		(bolt)	18	
			TORQUE		(install)		
			(very little,				
			just picked				
			12.0)				

Foot Restraints:

Task	WIF	Swingarm Setting	P/Y Fitting	APFR Setting
MBSU R&R	SSRMS			[12,PP,F,6]

Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- 2. Removing MBSU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. CETA to CETA max coupling rate is 1 inch/sec
- 4. There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H1 bolt must always be released first or damage to ORU and underlying structure will occur
- 4. H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

ORU Weight with FRAM = ~ 500 lbs

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

EVA Connectors: N/A

Assumptions:

- 1. Both CETA carts are port and MT is @ WS 3
- 2. Using 85' safety tethers from airlock D-rings
- 3. Failure discovered on way to SMDP task: EV1 on way to ICC, EV2 has not ingressed SRMS for SMDPs yet
- 4. TM not reqd for on-orbit loads
- 5. Failed MBSU left on CETA cart at end of EVA (CETA is coupled to MT)
- 6. Due to long SSRMS times, EV1 will do all setup tasks
- 7. EV2 gets spare PGT from airlock HR, has APFR on BRT
- 8. EV1 already has a PGT

FS 16-116 EVA/116/FIN

DDCU REMOVE AND REPLACE – CH 1/4 (EVA 3)

IV	EV1 (FF)	EV2 (FF)
	1. Retrieve APFR from TBD 2. Translate to S0 port wedge face 3. Install APFR in S0 WIF 41; configure to: [7,QQ,E,1]	 TOOL RETRIEVAL Translate to airlock Retrieve crewlock bag #1, BRT (use either spare PGT or temp stow your 6-in socket in trash) Translate to Z1 stbd toolbox Retrieve 2 square scoops from toolbox lid: Stow 1 square scoop on MWS Stow 1 square scoop in crewlock bag #1 Open right door Retrieve square TM w/7/16 recessed socket from slot 1, stow on MWS (release slider lock only) Close door – both latches reqd if not coming back
Verify w/MCC inhibits in place: MBSU 4 RBI 12 Op (Cl Inh)	SPARE DDCU REMOVAL (DDCU S0-4B) (S0 port wedge face) 1. Ingress APFR in S0 WIF 41	SPARE DDCU REMOVAL (DDCU S0-4B) (S0 port wedge face) 1. Translate to S0 port wedge face (zenith HRs on S0 and P1 worked well in pool) 2. Tomp stow growlook bag poor EV1 (he'll pick up later)
2. Record spare DDCU serial #:	CAUTION H2 bolt (jack screw) must always be released last or damage to ORU and underlying structure will occur 2. Receive sq TM from EV2, install onto H1 fitting, √Anti-backlash neutral 3. PGT [B2, CCW2, 30.5]-sq TM: (stow 6-in socket in trash) Break torque on H1, 5 turns (PGT), 1 turn (bolt) 4. Remove square TM from H1, install onto H2 √Anti-backlash neutral	Temp stow crewlock bag near EV1 (he'll pick up later) Transfer square TM to EV1

FS 16-117 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	 5. Receive square scoop from EV2, install onto H1 fitting 6. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 7. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) 8. Remove square TM from H2, stow on MWS 	4. Transfer square scoop to EV1
	 9. Receive square scoop from EV2, install onto H2 fitting 10. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw ~ 18 turns √Status indicator – UNLOCK 	5. Transfer square scoop to EV1
	NOTE Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK.	
	Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during DDCU removal from FSE	
	CAUTION Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads	
	WARNING Fins on bottom of DDCU and coldplate are no-touch	
	 11. Remove DDCU from coldplate 12.√Status indicator on H1 in LOCK 13. Attach failed DDCU to EV2's BRT 14. Remove free sq scoop from failed DDCU, stow on MWS 15. Egress APFR 	6. Position BRT toward EV1

FS 16-118 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	16. Retrieve crewlock bag, attach to BRT FAILED DDCU REMOVAL	FAILED DDCU REMOVAL
	For DDCU S0-1A (S0 Bay 01):	For DDCU S0-1A (S0 Bay 01):
3. Verify w/MCC inhibits in place: MBSU 1 RBI 4 Op (Cl Inh)	 Remove APFR from WIF 41, stow on BRT Translate to S0 Bay 01 Install APFR into S0 WIF 21 (side-mounted WIF); configure to: [3,00,G,12] Ingress APFR 	 Translate to CETA carts (must be slid port of DDCU in bay 01 for access to DDCU removal worksite) Take CETA 2 coupler to unlock (will move both carts together as one unit, so carts will stay coupled together) Mnvr CETA carts port a few feet to clear S0 Bay 01 wkst Take CETA 2 coupler to CAPTURE Engage CETA 2 parking brake (left handle)
4. Record failed DDCU serial #:	H1 bolt must always be released first or damage to ORU and underlying structure will occur	
	 Install square TM onto H1 fitting, √anti-backlash neutral PGT [B2, CCW2, 30.5]-sq TM: Break torque on H1, 5 turns (PGT), 1 turn (bolt) Remove square TM from H1, install onto H2 (may require EV2's help, access from APFR not ideal) √Anti-backlash neutral Install square scoop on H1 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) Remove square TM from H2, stow on MWS 	
	12. Receive square scoop from EV2, install onto H2 fitting 13. PGT [B1, CCW2, 30.5]-6"-Ext-7/16:	6. Transfer square scoop to EV1

FS 16-119 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	Release H2 jack screw ~ 18 turns √Status indicator – UNLOCK	
	NOTE Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during DDCU removal from FSE	
	WARNING Fins on bottom of DDCU and coldplate are no-touch	
	14. Remove DDCU from coldplate 15.√Status indicator on H1 in LOCK 16. Attach failed DDCU to BRT 17. Receive free square scoop from EV2	7. Assist EV1, remove free scoop 8. Transfer free square scoop to EV1 CAUTION CETA to MT max coupling rate is 0.5 ft/sec 9. Couple CETA 2 (both carts) to MT 10. Take CETA 2 coupler to LOCK 11. Translate to airlock 12. Perform tool inventory

FS 16-120 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
5. Verify w/MCC inhibits in place: MBSU 4 RBI 11 Op (Cl Inh)	For DDCU S1-4B (S1 Bay 15): 1. Retrieve crewlock bag #1 (EV2 has spare DDCU) 2. Translate to S1 Bay 15 (APFR not needed for this DDCU, there are no adjacent WIFs to support) 3. Retrieve MUT EE and ballstack from crewlock bag #1 4. Attach MUT EE and ballstack to S1 Bay 15 zenith HR 3208 (for temp stow of failed DDCU) 5. Temp stow crewlock bag #1 on Bay 15 zenith HR 6. Retrieve sq scoop from crewlock bag #1, attach to MWS 7. Translate to face 6 (nadir) 8. Attach BRT to S1 Bay 15 nadir HR 3217 (very far reach) CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur	EV2 (FF) For DDCU S1-4B (S1 Bay 15): 1. Translate to S1 Bay 15, face 2 (zenith) 2. Assist EV1
	 Install square TM onto H1 fitting, √anti-backlash neutral PGT [B2, CCW2, 30.5]-sq TM: Break torque on H1, 5 turns (PGT), 1 turn (bolt) Remove square TM from H1, install onto H2 (may require EV2's help, access from APFR not ideal) √Anti-backlash neutral Install square scoop on H1 PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, 5 turns (PGT), 1 turn (bolt) Remove square TM from H2, stow on MWS Install square scoop onto H2 fitting PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw ~ 18 turns √Status indicator – UNLOCK 	

FS 16-121 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	NOTE Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK. Primary stanchion (H2) has ~ 15-20 lb soft dock	
	force to overcome during DDCU removal from FSE	
	<u>WARNING</u> Fins on bottom of DDCU and coldplate are no-touch	
	 18. Remove DDCU from coldplate 19.√Status indicator on H1 in LOCK 20. Transfer DDCU to EV2 21. Translate to face 2 	3. Receive DDCU from EV1
	22. Receive DDCU from EV223. Temp stow DDCU on ballstack24. Remove free square scoop from failed DDCU	4. Transfer DDCU to EV1
	SPARE DDCU INSTALL	SPARE DDCU INSTALL
	 Install square scoop onto spare DDCU (EV2's BRT) Remove spare DDCU from EV2's BRT 	1. Assist EV1
	NOTE Primary stanchion has ~ 15-20 lb soft dock force to overcome during DDCU installation onto coldplate	
	3. Install DDCU onto coldplate4. √Status indicator on H1 is in UNLOCK	 Assist EV1 Retrieve MUT EE and ballstack (S1-4B DDCU only), stow in crewlock bag #1) Retrieve crewlock bag #1

FS 16-122 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
6. Verify w/MCC inhibits in place: MBSU 4 RBI 12 Op (Cl Inh)	CAUTION H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur 5. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 6. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK 7. Remove square scoops from DDCU, stow on MWS 8. Egress APFR FAILED DDCU INSTALL (S0 port wedge face) (to protect coldplate) 1. If DDCU failure was S0-1A, APFR must be relocated from S0 WIF 21 back to S0 WIF 41 4. Install square scoop onto failed DDCU (on EV2's BRT) 5. Ingress APFR in S0 WIF 41 6. Remove DDCU from EV2's BRT NOTE Primary stanchion has ~ 15-20 lb soft dock force to	FAILED DDCU INSTALL (S0 port wedge face) (to protect coldplate) 1. Translate to S0 port wedge face
	overcome during DDCU installation onto coldplate 7. Install DDCU onto coldplate 8. √Status indicator on H1 is in UNLOCK	3. Assist EV1

FS 16-123 EVA/116/FIN

IV	EV1 (FF)	EV2 (FF)
	CAUTION H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur 9. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H2 jack screw ~ 18 turns √Status indicator – LOCK 10. PGT [A3, CW2, 30.5]-6"-Ext-7/16: Drive H1 acme screw ~ 8 turns √Status indicator – LOCK 11. Remove square scoops from DDCU, stow on MWS 12. Egress APFR (APFR left in S0 WIF 41) 13. Translate to airlock 14. Perform tool inventory	4. Translate to airlock5. Perform tool inventory

FS 16-124 EVA/116/FIN

DDCU REMOVE AND REPLACE - CH 1/4 (EVA 3) TASK DATA SHEET

Tools:

EV1	EV2	
PGT w/6-in	PGT	
APFR	Crewlock bag #1	
	Square TM w/7/6" TM	
	3 square scoops	

Foot Restraints:

Task	WIF	APFR Setting
DDCU S0-4B (spare)	S0 WIF 41	7,QQ,E,1
DDCU S0-1A	S0 WIF 21	3,00,G,12
(S0 Bay 01)	(side mounted)	
	CETA cart WIF 4	
	(zen/port)	TBD settings
DDCU S1-4B	No available WIFs	
(S1 Bay 15)	or CETA cart	

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			12.0 (pgt) RUNNING TORQUE (very little, just picked 12.0)		22.8 (bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal)	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

Notes:

- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin
- Removing DDCU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. Primary stanchion (H2) has a 15-20 lb soft dock

Cautions:

- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin
- H2 bolt (jack screw) must always be installed first or damage to ORU and underlying structure will occur
- 3. Fins on bottom of DDCU and coldplate are no-touch
- H1 bolt must always be released first or damage to ORU and underlying structure will occur
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

Timeline Considerations:

1. Decision to perform R&R is based on limiting consumables

Assumptions:

- 1. Learn of failure ~ 20-30 min after CH 1/4 powerup
- 2. Spare DDCU is DDCU S0-4B (on S0 port wedge face). Skip Z1 PP if any of the 1/4 DDCU fails and you use the S04B DDCU as a spare (or it fails itself)
- 3. TM not used on spare DDCU for on-orbit loads
- 4. All tools retrieved from Z1 toolbox come inside at end of EVA
- 5. Need to determine where APFR is coming from
- MT @ WS 3 w/both CETA carts coupled to port side nominal location for 1/4 powerup
 - If the S0-4B spare fails during pwr up, the R&R will be skipped, and so will the PP. That is why there is no option in the above procedures to R&R S0-4B. None of the other DDCUs can be used as the spare, so the R&R will occur on another day using the internal spare
- 7. For the 1/4 DDCU R&Rs, truss WIFs are used, with the exception of the S1 Bay 15 DDCU (no near-by WIFs). This decision was made because the CETA cart can only be used to support 1 of the 3 DDCU failures (S0-1A) for this channel, so it would be inefficient to both use a truss WIF and set up the cart
- 8. Neither crewmember has a socket caddy, so either EV1 or EV2 will have to temp stow their socket in the trash bag for TM ops (don't necessarily get spare PGT from crewlock bag (too many tools to manage)
- 9. Failed DDCU gets installed into spare worksite
- 10. Don't need spare safety tether to reach these DDCUs (the 85 footer from airlock works for all DDCUs)

FS 16-125 EVA/116/FIN

BCDU BACKOUT - CH 1/4 (EVA 3)

IV	EV1 (FF)	EV2 (FF)
1. √MCC inhibits in place: BCDU 2B1 1. DCSU 2B RBI 2 Op, Cl Inh 2. BCDU 4B1 CP RBI Op - OR - BCDU 2B2 1. DCSU 2B RBI 3 Op, Cl Inh 2. BCDU 4B2 CP RBI Op - OR - BCDU 2B3 1. DCSU 2B RBI 4 Op, Cl Inh 2. BCDU 4B3 CP RBI Op	FAILED P6 2B BCDU BACK-OUT 1. Translate to airlock 2. Translate to Z1 stbd toolbox 3. Open right door 4. Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS 5. Close door – 1 latch reqd 6. Translate to fish stringer #1, retrieve PGT with 6-in, stow on MWS 7. Translate to P6 BCDU TBD on stbd face of P6 (via P6 stbd/aft P6 edge)	FAILED P6 2B BCDU BACK-OUT 1. Assist EV1 as reqd (continue with SMDPs unless EV1 needs assistance
2. IV record serial # of failed box:	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur 8. Install TM onto H1 fitting, √anti-backlash neutral 9. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, ~ 1 turn 10. Remove TM from H1, install onto H2 √Anti-backlash neutral 11. Reconfigure PGT with 6-in socket 12. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 13. Remove socket from PGT 14. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, ~ 1 turn	

FS 16-126 EVA/116/FIN

BCDU BACKOUT - CH 1/4 (EVA 3) (Cont)

IV	EV1 (FF)	EV2 (FF)
	 15. Remove TM from H2, stow on MWS 16. Reconfigure PGT with 6-in socket 17. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw 5 turns 18. EBCDU final config 19. Translate to airlock 	
	FAILED P4 2A BCDU BACK-OUT	FAILED P4 2A BCDU BACK-OUT
1A. √SARJ locked at 205 deg 1B. √MCC inhibits in place: BCDU 2A1 1. DCSU 2A RBI 2 Op, CI Inh 2. BCDU 4A1 CP RBI Op - OR - BCDU 2A2 1. DCSU 2A RBI 3 Op, CI Inh 2. BCDU 4A2 CP RBI Op - OR - BCDU 2A3 1. DCSU 2A RBI 4 Op, CI Inh 2. BCDU 4A3 CP RBI Op	 Translate to airlock Retrieve spare 55' safety tether from crewlock bag #1, stow on MWS Translate to Z1 stbd toolbox Open right door Retrieve sq TM w/7/16 recessed socket from slot 1, stow on MWS Close door – 1 latch reqd Translate to fish stringer #1, retrieve second 55' safety tether and PGT w/6-in, stow on MWS Translate to P1 HR 3602 (Bay 14); perform safety tether swap using 55' spare safety tether, verify ST Config Translate to P4 HR 5104 (zenith IEA) Perform safety tether swap onto P4 HR 5104 with remaining 55' safety tether, verify ST config Translate to failed BCDU on P4 (P4 aft, TBD BCDU) 	Assist EV1 as reqd (continue with SMDPs unless EV1 needs assistance
IV record serial # of failed box:		

FS 16-127 EVA/116/FIN

BCDU BACKOUT - CH 1/4 (EVA 3) (Cont)

IV	EV1 (FF)	EV2 (FF)
	CAUTION H1 bolt must always be released first or damage to ORU and underlying structure will occur	
	 12. Install TM onto H1 fitting, √anti-backlash neutral 13. PGT [B2, CCW2, 30.5]-sq TM: Release acme screw H1, ~ 1 turn 14. Remove TM from H1, install onto H2 √Anti-backlash neutral 15. Reconfigure PGT with 6-in socket 16. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H1 acme screw ~ 8 turns √Status indicator – UNLOCK 17. Remove socket from PGT 18. PGT [B2, CCW2, 30.5]-sq TM: Break torque on H2, ~ 1 turn 	
	 19. Remove TM from H2, stow on MWS 20. Reconfigure PGT with 6-in socket 21. PGT [B1, CCW2, 30.5]-6"-Ext-7/16: Release H2 jack screw 5 turns 22. BCDU final config 23. Translate to airlock 	

FS 16-128 EVA/116/FIN

BCDU BACKOUT - CH 1/4 (EVA 3) TASK DATA SHEET

Tools:

EV1 (FF)	EV2 (FF)
PGT w/6-in socket	
Square TM w/7/16 in Rec Socket	

EVA Fasteners:

Fastener Name/Label	Head Size	Qty	Release Torque (ft-lbs)	Install Torque	Failure Torque (ft-lbs)	Turns	RPM
H1	7/16	1	BREAK TORQUE 60.0 (bolt)	4.8 (bolt)	190.3 (bolt) (removal)	1	30
			12.0 (pgt)		22.8		
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	8	
H2	7/16	1	BREAK TORQUE 60.0 (bolt) 12.0 (pgt)	4.8 (bolt)	188.4 (bolt) (removal) 27.8	1	30
			RUNNING TORQUE (very little, just picked 12.0)		(bolt) (install)	18	

EVA Connectors: NA

Foot Restraints: NA

Notes:

1. H1 is secondary bolt, H2 is primary bolt

- 2. Removing BCDU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- 3. The BCDU backout procedure does not actually remove the ORU from the truss, it just backs the H2 bolt out enough to demate the blind-mate connectors

Cautions:

- 1. Fins on bottom of MBSU and coldplate are no touch
- 2. Primary stanchion (H2) has ~ 15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE and coldplate
- 3. H1 bolt must always be released first or damage to ORU and underlying structure will occur
- 4. Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads
- 5. T-handle on connector cover poses a tether snag point. Connector cover could become loose debris if advertently snagged by EVA tether

Warnings:

 Hazard voltage exist at the connectors of the BCDU. BCDU must be safed before removal

ORU Mass: 234 lbs

Assumptions:

- 1. This failure would happen on EVA 3 (CH 1/4); we would primarily protect for P6 2B (since it carries the primary core loads), but EPS may want us to protect for P4 2A (utility loads only)
- EV2 would be starting SRMS setup and SMDP transfer, so it would be easier for EV1 to break away from his task to support BCDU back-out. EV2 does not require EV1 for GCA assist until just prior to Christmas tree release from ICC
- Each EV is reqd to have 2 spare 55' safety tethers to reach all possible P4 BCDUs. The P6 BCDUs can be reached from the 85' airlock safety tether (no swaps read)

4. All bolts are driven FF

FS 16-129 EVA/116/FIN

S1 PUMP MODULE R&R SUMMARY TIMELINE

TIME	IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
00:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)
00:05		EGRESS (00:20)	EGRESS (00:20)
00:25	SSRMS: PM R&R SRMS: PM R&R	FAILED PM REMOVAL FROM S1 (01:30) Setup PM Prep for FGB Install PM QD Operations PM Jumper N2 Vent and Install PM Electrical Connections Release PM Bolts Temp Stow Failed PM on SRMS	FAILED PM REMOVAL FROM S1 (01:30) SSRMS Setup FGB Removal from Spare PM Break Torque on PM Bolts PM Jumper N2 Vent and Install FGB Install Release PM Bolts Temp Stow Failed PM on SRMS
01:55		SPARE PM RETRIEVAL FROM ESP2 (01:30) • Spare PM Electrical Connections	SPARE PM RETRIEVAL FROM ESP2 (01:30) • Break Torque on PM Bolts • Release PM Bolts
03:25	SSRMS: PM R&R	SPARE PM INSTALL ON S1 (02:00) S1 PM Install PM Electrical Connections PM Jumper NH3 Vent and Removal S1 PM N2 vent PM QD Operations CETA Cart Cleanup	SPARE PM INSTALL ON S1 (02:00) S1 PM Install PM Bolt Initial Torque PM Jumper NH3 Vent and Removal PM Bolt Final Torque
		*** BREAKOUT POINT IF REQD ***	
05:25	SSRMS: PM R&R SRMS: PM R&R	FAILED PM INSTALL ONTO ESP2 (01:30) Retrieve Failed PM from SRMS Install Failed PM onto ESP2 PM Electrical Connections Cleanup	FAILED PM INSTALL ONTO ESP2 (01:30) Retrieve Failed PM from SRMS Install Failed PM onto ESP2 PM Bolt Initial Torque PM Bolt Final Torque SSRMS Cleanup
06:55		INGRESS (00:20)	INGRESS (00:20)
07:05		PRE REPRESS (00:05)	PRE REPRESS (00:05)
07:25		<u>'</u>	'

FS 16-130 EVA/116/FIN

TOOL CONFIG

	<u>AIRLOCK</u>		AIRLO	CK ENDCONE		AIRLOCK INTERNAL D-RING
	TEMU1		Staging	Bag		D-Ring Extender
	MWS, right swing arm			Stringer #3		- ·g =
	Digital Camera (inner right swing arm)			nector cleaner tool caddy		
	BRT (left)			e tie caddy (2)		UIA HANDRAILS:
	w/3 wire ties and sm-sm RET			straightener		Fish Stringer #1 (layed across UIA HRs)
	T-Bar	+		S Key strap		PGT with 7/16 x 6-in ext (s/n:) w/RET
	ISS trash bag (inner left)			ro/Tape caddy	шш	(<u></u> ,
	Sm-sm RET (left D-ring)		Pry b			Torque Wrench (set to 37 ft-lbs) (need for PM Return
	Adj tethers (2) (left D-ring)		•	Ratchet	\Box	Lg-sm RET
	Sm-sm RET w/PIP pin (right D-ring)	+++		ket caddy (inner right)	ш	<u> </u>
	Adj tethers (2) (right D-ring)	+++		5/8 x 7.8-in ext		Fish Stringer #2
-	D-ring ext – left	++		re 55' safety tethers (2)		PGT with 7/16 x 6-in ext (s/n:) w/RET
	Waist tether – right		Opui	c co salety tetriors (2)	шш	1 31 WILL 17 10 X 3 III 3X (5/11) W/X21
	SAFER					Crewlock bag #1 (empty) – for QD cont tools if needed
Ш	JANLIN				+	Lg-sm RET
			IV Bag		ШШ	Lg-Siff(L)
				ination Detection Kit		
				azine Detector (Gold Salt Coupon) (6)		EXTERNALLY STOWED QD TOOLS:
	EMU2		Color	Chart (2)		(INFO ONLY)
	MWS, right swing arm			Contamination Detection Sampler (2)		,
	Digital Camera (inner right swing arm)			le Contamination Detection Sampler (2)		PM Jumper Bag
	BRT (left)			gen Dioxide Detector (Oxidizer Draeger		PM Jumper
	w/3 wire ties and sm-sm RET		Tube			
	T-Bar	Ш.		onia Detector (NH3 Draeger Tube) (6)		NATE DO A 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	ISS trash bag (inner right)			s with wire ties		VTE Bag (only needed if EVA NH3 vent is reqd)
	Wire ties (2) around T-Bar	1	DCM bi	ug (2) (SAFER hardmount)		1.0" vent tool mated to vent tool extender
	Socket caddy (inner left) 5/8 x 7.8-in ext	Н-	GP cad		Ш	MUT EE
-	Round TM w/5/8 proud socket (outer right)	Н.		nal mittens (2 pr) Caddy (hatch contingencies) w/sm-sm RET		
	Sm-sm RET w/PIP pin (left D-ring)	H '		8-in socket (IV hatch)	П	Stbd QD Bag (QD cont tools)
	Adj tether (left D-ring)	+		X 6-in socket (spare)	H	1.5" QRT/FID gauge
	Sm-sm RET w/PIP pin (right D-ring)		7710	A o III oodkot (oparo)	H	1.5" Bail drive lever
	Adj tethers (2) (right D-ring)		PRE EV	/A TOOL CONFIG	H	.5" cap tool
	Lg-sm RETs (2) (need for PM HRs)			r to EVA, inspect the following:		
	D-ring ext (2)	Ш		RET cords for damage		
H	Spare 55' safety tether to MWS (left D-ring extender)		ā	BRT and MWS toggles: loose		NOTE
H	Waist tethers (2)			fittings/screws		Only need vent tool and VTE for specific failures
	SAFER			Safety and waist tether load alleviating		where MCC cannot remotely vent PM NH3
	-			straps (no red band or damage)		through truss aft vent panel

FS 16-131 EVA/116/FIN

EGRESS (00:25)

IV	EV1 (FF)	EV2 (FF)
NOTE For safety tether swaps, expect to hear:	√Right waist tether to airlock internal D-ring extender, verify ST config	√Right waist tether to UIA panel fwd D-ring, verify ST config
Hook closed Slide locked Reel unlocked	 Thermal cover – open Egress airlock Inspect load alleviating straps on 85' safety tethers (2) Retrieve airlock safety tether from fwd external D-ring, attach to left D-ring extender, verify ST config Release waist tether from internal D-ring extender Receive fish stringer #1 and #2 from EV2 Temp stow fish stringer #1 in between A/L port toolbox HR and stbd toolbox HR (stretched out) Temp stow fish stringer #2 in between A/L HR 0560 (fwd/stbd/nadir) and HR 0555 (nadir of stbd toolbox) Transfer aft airlock safety tether to EV2 Transfer PGT from fish stringer #1 to right swingarm Retrieve fish stringer #1 	 Transfer fish stringer #1 and #2 to EV1 Receive airlock safety tether from EV1, attach to left D-ring extender, verify ST config Release right waist tether from UIA panel D-ring Egress airlock
1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max (required after EV1 and EV2 egress airlock)	12.√EV2's SAFER MAN ISOL vIv – OP (dn) and HCM (dn)	5. Close thermal cover 6. √EV1's SAFER MAN ISOL vIv – OP (dn) and HCM (dn) 7. Transfer PGT from fish stringer #2 to right swingarm 8. Transfer Round TM from fish stringer #2 to MWS 9. Retrieve fish stringer #2

FS 16-132 EVA/116/FIN

FAILED PUMP MODULE REMOVAL FROM S1

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. S1 PM R&R (SODF: RBT FS: APFR Install/APFR Ingress) GP 4	<u>SETUP</u>	SSRMS SETUP 1. Retrieve APFR from A/L Toolbox #1 (stbd) 2. Translate to ESP2 fwd/zenith 3. GCA SSRMS for APFR setup 4. Install WIF adapter (tether point facing same direction as LEE) into SSRMS 5. Install APFR on WIF adapter: configure to: [12,PP,F,6] 6. Perform safety tether swap onto SSRMS safety tether; temp stow airlock safety tether on VSSA FRAM HR (fwd) FGB REMOVAL FROM SPARE PUMP MODULE CAUTION Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used 1. Temp stow fish stringer #2 on ESP2 2. Release velcro strap on fwd face of PM MLI 3. Open forward flap on PM MLI tent, attach velcro flaps (2) 4. GCA SSRMS for ingress 5. Attach waist tether to APFR, ingress SSRMS (head nadir) CAUTION Avoid contact with FGB grapple pin and RMS target
3. √MCC GO to begin QD ops	CAUTION Use extreme caution when manipulating F-49 (zen) and F-44 (nad) prior to P-Clamp release; minimize loads input into QD hard lines and QDs PUMP MODULE QD OPERATIONS ■ 1. PGT [A7, CCW2, 30.5]-6-Ext-7/16: Release F44, F45, and F48 P-clamps, 12-14 turns (nadir)	 Attach fish stringer #2 to PM fwd HRs (clear of FGB) SSRMS mnvr to FGB bolt release Tether to FGB PGT [B7, CCW2, 30.5]-6-Ext-7/16: Release FGB to Pump Module mounting bolts (4) 8-11 turns (any order) Remove FGB from Pump Module (soft dock) Attach FGB to BRT

FS 16-133 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 Release F44, F45, and F48 TA clamps from flexlines Remove wire tie (1) from 1.5" SPDs, temp stow Remove SPDs from QDs (4), stow on fish stringer #1 Check QD buttons installed (4) Stow PGT on fish stringer #1 	SSRMS mnvr to failed PM (S1 Face 1, Bay 07) (head nadir) BREAK TORQUE ON PUMP MODULE BOLTS
4. S1 PM R&R (SODF: RBT FS: FGB Removal)	CAUTION When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing	 GCA SSRMS to Bolt 1 (zenith-most) Perform the following steps to break torque on PM bolts 1, 2, 3, and 4:
i Ob Neilloval)	While demating F-44 from M1, do not exceed 20 lbs of force in the forward, zenith, and nadir direction	☐ Install round TM w/5/8" proud socket on PM Bolt☐ √Anti-backlash neutral
5. S1 PM R&R (SODF: RBT FS:	Once F-44 is demated from M1, do not use the QD to manipulate the line out of the way (use the hard line)	□ PGT [B6, CCW1, 30.5]-rd TM: Break torque on Bolt ~ 1 turn (of bolt)
zenith J1 J2 stbd M4/F49 M3/F48 M2/F45 M1/F44 J5 nadir S1 PM - FACE 1	 BRT to port HR on CETA cart Perform the following steps to close valve and demate S1-F44/PM M1: (nadir-most) A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Demate S1-F44 from M1 (using release trigger) F. Restrain S1-F44 clear of PM using adj tether Perform the following steps to close valve and demate S1-F45/PM M2: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Demate S1-F45 from M2 (using release trigger) F. Restrain S1-F45 clear of PM using adj tether Perform the following steps to close valve and demate S1-F48/PM M3: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) 	

FS 16-134 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
6. Inform MCC 1.5" QDs (3) are demated (valve change)	B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Demate S1-F48 from M3 (using release trigger) F. Restrain S1-F48 clear of PM using adj tether	
(00:08 min vent thru vent panel)	CAUTION During valve closure and demate, F-49 (zen) can only be handled from the fwd end of the QD to a point halfway between the QD and P-clamp Use extreme caution when manipulating F-49 (zen) in the	
7. √MCC GO to close valve on S1-F49 (.5" QD) and that IV venting of PM is complete zenith J1	fwd, zenith, and nadir directions (during demate only) 11. PGT [A7, CCW2, 30.5]-6-Ext-7/16: Release F-49 P-clamp, 12-14 turns 12. Perform the following steps to close valve and demate S1-F49/PM M4: A. Take valve to full open (push fwd, button pops up) (unsticks male sleeve seals) B. Depress button and close valve (pull bail aft) C. Verify detent button up D. Verify fwd white line visible E. Rotate locking collar to lock F. Demate S1-F49 from M4 G. Restrain S1-F49 clear of PM using adj tethers	

FS 16-135 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith J1 J2 M4/F49 M3/F48 M2/F45 M1/F44 J3 J5 Nadir S1 PM – FACE 1 Pump Module Janger Pump Module Janger Pump Module Pump Module Refer Cart Cetta Cart Coupler Pump Module S1 PM – FACE 1 Pump Module Refer Cart Refer Cart S1 PM – FACE 1 Refer Cart Refer Cart Refer Cart Refer Cart Refer Cart Refer Cart Cetta Cart Cetta Cart Cetta Cart Coupler Refer Cart Refer Cart Refer Cart Refer Cart Refer Cart Cetta Cart Refer Cart Cetta Cart Coupler Refer Cart Refer	PM JUMPER N2 VENT AND INSTALL 1. Retrieve PM Jumper from PM Jumper bag 2. Transfer PM Jumper to EV2 3. Attach BRT to CETA cart port HR 4. Perform the following steps to mate S1-F48 to PM Jumper M3: A. Demate cap from PM Jumper M3 (lanyarded to box) B. Inspect male and female QDs for debris or damage C. √Button up D. √Release ring retracted (fwd white band not visible) E. Mate S1-F48 to PM jumper M3 F. √Fwd white band visible (snapback, pull and gap√) 5. Perform the following steps to mate S1-F44 to PM Jumper M4: A. Demate cap from PM Jumper M4 (lanyarded to box) B. Inspect male and female QDs for debris or damage C. Verify detent button up D. √Release ring retracted (fwd white band not visible) E. Mate S1-F44 to PM Jumper M4 F. √Fwd white band visible (snapback, pull and gap√) 6. Restrain PM jumper clear of PM removal space; mnvr jumper straight out of truss and stow on CETA cart using adjustables 7. Perform the following steps to open valve on S1-F44/PM Jumper M4: A. Depress detent button and open valve (push bail fwd) B. √Aft white band visible and detent button up	PM JUMPER N2 VENT AND INSTALL 1. GCA SSRMS to assist EV1 with PM Jumper 2. Receive PM Jumper from EV1 3. Orient PM jumper such that male QDs face ISS stbd, M4 zenith 4. React QD loads as reqd zenith GP 1 (4th) stbd GP 3 (2nd) nadir FGB TO PM BOLT LABELS
open (~ 1 minute to vent N2)		

FS 16-136 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
8B. MCC: When N2 venting	(if valve change does not happen prior to opening valve on M3,	
complete, Thor to take	system NH3 would be dumped overboard thru vent panel)	
NH3 Iso vent valve to close	8. On MCC GO, perform the following steps to open valve on S1-F48/PM Jumper M3:	FGB INSTALL
	A. Depress detent button and open valve (push bail fwd)	When EV1 complete with QD ops, GCA to FGB install
	B. √Aft white band visible and detent button up	2. Orient FGB such that RMS target is facing stbd
	9. Assist EV2 with FGB install	3. Soft dock FGB to S1 Pump Module
√With MCC inhibits in place for electrical connections	PUMP MODULE ELECTRICAL CONNECTIONS	CAUTION GP2 (zen/stbd) must be the first bolt torqued during installation. Remaining bolts torqued in a star pattern
10. Record turns and torque for	<u>NOTE</u>	←
FGB to PM mounting bolts:	Check connectors for damage, emi band,	4. PGT [A7, CW2, 30.5]-6-Ext-7/16 : Engage PM to FGB
GP2: turnsft-lb	FOD, bent pins, and cable bend radii	mounting bolts (4) 8-11 turns; GP2, GP3, GP4, GP1
GP3: turns ft-lb	Release TA clamps as reqd	5. Stow 6-in socket on socket caddy
GP4: turns ft-lb	2. Demate the following connectors from the PM and	6. Reconfig PGT with 5/8" socket
GP1: turns ft-lb	restrain clear of PM using adjustable tethers:	
zenith	□ S1 P525 from PM J5 (nadir most)	RELEASE PUMP MODULE BOLTS
J1 O B1	□ S1 P524 from PM J4	
J2 O	□ S1 P523 from PM J3	1. PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8:
M4/F49	□ S1 P522 from PM J2	Release PM Bolts 4, 3, and 2, 14-17 turns (bolt pops out)
M3/F48 port	□ S1 P521 from PM J1	2. Tether to PM
J3 M1/F44	3. Inform EV2 electrical connections complete (give GO to	
J4 O B3 B4	release last bolt)	3. On EV1's Go (electricals finished):
J5 ()		PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8 : Release PM
nadir	RELEASE PUMP MODULE BOLTS	Bolt 1, 14-17 turns (bolt pops out)
S1 PM – FACE 1		4. Holding PM fwd HR and FGB HR, pull PM from
	Assist EV2 as required	truss in forward direction (slides along rails)
11. S1 PM R&R (SODF: RBT	2. Monitor clearances between PM and truss as reqd	5. GCA SSRMS operator as reqd to pull PM free of rails
FS: PM Removal)		and truss

FS 16-137 EVA/116/FIN

IV/SRMS/SSRMS	EV1 (FF)	EV2 (SSRMS)
 12. S1 PM R&R (SODF: RBT FS: Mnvr to handoff) 13. S1 PM Handoff (PDRS, Contingency Support) 	PM HANDOFF POSITION	 6. At SSRMS clearance posn, orient the PM such that: — FGB is toward your head — You are holding the bottom HRs TEMP STOW FAILED PUMP MODULE ON SRMS 1. SSRMS mnvr to PM handoff position 2. While holding PM steady, give SRMS operator GO to capture PM, release tether (leave RET on PM HR) — hold PM parallel to chest — SRMS will back away to a clearance posn (ISS nad/por)

FS 16-138 EVA/116/FIN

SPARE PUMP MODULE RETRIEVAL FROM ESP2

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	SPARE PUMP MODULE ELECTRICAL CONNECTIONS	BREAK TORQUE ON PUMP MODULE BOLTS
S1 PM R&R (SODF: RBT FS: Spare PM Retrieval)	1. Translate to ESP2, monitor clearances between EV2, LEE, and Lab CAUTION Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used 2. Fold back remaining flaps of MLI tent (front flap already folded back) Release three 1/4 turn fasteners on stbd flap and fold up toward top of PM, attach velcro flaps (2) Release three 1/4 fasteners on aft flap Release MLI strap from top of PM (velcroes) Using strap, pull MLI tent away from PM in port direction, attach to S0/Lab aft struts	 SSRMS mnvr to ESP2 Stow 5/8" socket onto socket caddy GCA SSRMS to PM bolt release worksite (bolt 4) Perform the following steps to break torque on PM bolts 4, 3, 2, and 1: Install round TM w/5/8" proud socket on PM Bolt √Anti-backlash neutral PGT [B6, CCW1, 30.5]-rd TM: Break torque on Bolt ~ 1 turn (of bolt) GCA to next bolt as reqd Remove TM from Bolt 1, stow on MWS Reconfigure PGT w/5/8-in socket
2A. Start PM thermal clock MET:	3. Close FGB-PM mounting bolts thermal cover	
2B. Record serial #:	 Read serial # to IV Remove 4 QD caps from M1, M2, M3, and M4 Stow caps on fish stringer #2 Release tape from PM fwd/stbd HR (3 pieces) and fwd/port HR (3 pieces), fold in half, stow in trash bag 	 RELEASE PUMP MODULE BOLTS 1. PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolts 1, 2, and 3, 14-17 turns (bolts pop out)
3. √MCC inhibits in place for electrical connections	8. Demate M/W J5 (P11) from PM J5, temp stow 9. Demate M/W J4 (P10) from PM J4, temp stow	

FS 16-139 EVA/116/FIN

SPARE PUMP MODULE RETRIEVAL FROM ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 Demate conn cap from from J3, stow on fish stringer #2 Demate conn cap from from J2, stow on fish stringer #2 Demate M/W J1 (P12) from PM J1, temp stow cable on ESP2 HR 8013 Remove fish stringer #2 from PM HRs, stow on VSSA FRAM HR Give EV2 GO to release remaining bolt Monitor clearances as reqd 	 Receive GO from EV1 to release last bolt Tether to PM PGT [B7, CCW2, 30.5]-7.8"-Ext-5/8: Release PM Bolt 4, 14-17 turns (bolt pops out) Using PM forward HRs, remove PM from FRAM (slides fwd along LAPA guide rails), GCA SSRMS as reqd (rotating does not help here)

FS 16-140 EVA/116/FIN

SPARE PUMP MODULE INSTALL ON S1

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. S1 PM R&R (SODF: RBT FS: Spare PM Install) zenith J1 J2 M4/F49 M3/F48 M2/F45 M1/F44 B3 B4 nadir S1 PM − FACE 1 2. √MCC electrical inhibits in place	2. GCA as required 3. Check with EV2 at least 1 bolt installed prior to beginning electrical ops (structural reasons) PUMP MODULE ELECTRICAL CONNECTIONS NOTE Check connectors for damage, FOD, emi band, bent pins, and cable bend radii Mate S1 P521 to PM J1, close TA clamps as required Mate S1 P522 to PM J2, close TA clamps as required Mate S1 P523 to PM J3, close TA clamps as required Mate S1 P524 to PM J4, close TA clamps as required Mate S1 P524 to PM J4, close TA clamps as required Mate S1 P524 to PM J4, close TA clamps as required	 SSRMS mnvr to S1 Bay 07 At truss clearance posn, re-orient PM such that bolts point port Install PM into truss (slides along rails), GCA SSRMS as reqd PM BOLT INITIAL TORQUE GCA SSRMS to PM Bolt 1 (zen, reqd to do first) PGT [B7, CW2, 30.5]-7.8"-Ext-5/8: Drive PM Bolts 1, 2, 3, and 4, 14-17 turns Give EV1 GO to begin electricals Release PM tether Remove 5-8" socket from PGT, stow on caddy

FS 16-141 EVA/116/FIN

IV/SSRMS EV1 (FF)		EV2 (SSRMS)
	PM JUMPER NH3 VENT AND REMOVAL	PM JUMPER NH3 VENT AND REMOVAL
3A. Give MCC GO for PM	 Attach BRT to CETA cart port HR Perform the following steps to close valve on S1-F48/PM Jumper M3: A. Close valve (depress button, pull bail aft) B. Verify detent button up C. Verify fwd white line visible 	GCA SSRMS to PM Jumper removal wkst Hold PM Jumper to react loads (Jumper cannot be moved until vented due to loads constraints on M4 line when pressurized)
Jumper venting (~ 5 min) 3B. Receive GO from MCC: PM Jumper NH3 venting		
zenith J1 J2 M4/F49 M3/F48 M2/F45 M1/F44 J3 nadir S1 PM – FACE 1	 Release PM Jumper from CETA cart Transfer PM Jumper to EV2 Perform the following steps to close valve and demate S1 F49/PM Jumper M4: A. Close valve (depress button, pull bail aft) B. Verify detent button up C. Verify fwd white line visible D. Rotate locking collar to lock E. Demate S1-F49 from PM Jumper M4 Temp stow S1-F49 Perform the following step to demate S1-F48 from PM Jumper M3: A. Demate S1-F48 from PM Jumper M3 (using release trigger) 	Receive PM Jumper from EV1, react loads as reqd
		4. Temp stow PM Jumper

FS 16-142 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
zenith J1 J2 M4/F49 M3/F48 M2/F45 M1/F44 B3 B4 nadir S1 PM – FACE 1 4. Receive GO from MCC to mate/open valve on F49 (.5" QD) ~ 12 min (begin MCC venting of N2)	CAUTION When mating S1-F48 to PM M3, do not open valve until all N2 has been vented from the PM. Otherwise, undesired mixing of NH3 and N2 will occur inside the PM 8. Perform the following steps to mate S1-F48 to PM M3: A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate S1-F48 to PM M3 E. √Fwd white band visible (snapback, pull and gap√) S1 PUMP MODULE N2 VENT CAUTION Use extreme caution when manipulating F-49 (zen) in the fwd, zenith, and nadir directions During mate and valve opening, F-49 (zen) can only be handled from the fwd end of the QD to a point halfway between the QD and P-clamp 1. Perform the following steps to mate and open valve on S1-F49/PM M4: A. Inspect male and female QDs for debris or damage B. Verify detent button up; √collar locked C. √Release ring retracted (fwd white band not visible) D. Mate S1-F49 to PM M4 E. √Fwd white band visible (snapback, pull and gap √) F. Rotate locking collar to unlock G. Depress detent button and open valve (push bail fwd)	PM BOLT FINAL TORQUE 1. Perform the following steps for final torquing of PM bolts 1, 2, 3, and 4: □ Install round TM w/5/8" proud socket on PM bolt □ √Anti-backlash neutral □ PGT [A4, CW1, 30.5]-rd TM: Drive PGT ~ 1 turn (of bolt), 5 turns (PGT) □ GCA to next bolt as reqd 2. Remove TM from Bolt 4, stow on MWS

FS 16-143 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
5. √MCC GO to mate/open valve for F48, F44, and F45 (N2 venting complete)	H. √Aft white band visible and detent button up PUMP MODULE QD OPERATIONS CAUTION S1-F49/M4 P-Clamp must be installed prior to opening valve on S1-F48/M3 to preclude damage to S1-F49 QD	
zenith J1	 PGT [A7, CW2, 30.5]-6-Ext-7/16: Re-install S1-F49 P-Clamp, 12-14 turns Perform the following steps to open valve on S1-F48/PM M3: A. Depress detent button and open valve (push bail fwd) B. √Aft white band visible and detent button up Perform the following steps to mate and open valve on S1-F45/PM M2: A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate S1-F45 to PM M2 E. √Fwd white band visible (snapback, pull and gap√) F. Depress detent button and open valve (push bail fwd) G. √Aft white band visible and detent button up 	

FS 16-144 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	CAUTION Do not use the QD on F-44 (nad) when re-orienting the line to the mate position (use the hard line) When mating F-44 to M1, do not exceed 20 lbs of force in the forward, zenith, and nadir direction 4. Perform the following steps to mate and open valve on S1-F44/PM M1: A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible)	
zenith J1	D. Mate S1-F44 to PM M1 E. √Fwd white band visible (snapback, pull and gap√) F. Depress detent button and open valve (push bail fwd) G. √Aft white band visible and detent button up 5. Retrieve fish stringer #1 from CETA cart 6. Install 1.5" SPDs (3): — Install aft part of SPD (black fwd) — Depress button and pull bail aft against SPD — Install fwd part of SPD (black to black) — Push bail against fwd SPD; √button down 7. Install wire tie on three 1.5" SPDs, attach to QD bail,	
nadir S1 PM – FACE 1	fluid line, or surrounding structure 8. Install .5" SPD: — Pull bail aft ~ 1/4 inch (until aft white line hidden — Install SPD (slider aft) — Push SPD slider forward — Secure bail in SPD slider; engage lock button	

FS 16-145 EVA/116/FIN

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
Inform MCC when QD ops complete	CETA CART CLEANUP 1. √CETA 2 coupler in CAPTURE 2. Release CETA 2 parking brake (tap pedal twice) CAUTION CETA to MT max coupling rate is 0.5 ft/sec 3. Couple CETA 2 to MT; take CETA 2 coupler to LOCK 4. √CETA 1 coupler in CAPTURE 5. Release CETA 1 parking brake (tap pedal twice) 6. Slide CETA 1 toward CETA 2 CAUTION CETA to CETA max coupling rate is 1 inch/sec 7. Couple CETA 1 to CETA 2; take CETA 1 coupler to LOCK	
	8. Retrieve fish stringer #1 and PM Jumper bag	

FS 16-146 EVA/116/FIN

INSTALLATION OF FAILED PUMP MODULE ONTO ESP2

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
S1 PM R&R (SODF: RBT FS: PM Retrieval)		1. SSRMS mnvr to SRMS (clearance posn) 2. GCA SSRMS to PM retrieval posn 3. Grasp PM using bottom HRs (head nearest to FGB),
S1 PM Handoff (PDRS, Contingency Support)		use RET left on PM to tether 4. Give SRMS operator GO for PM ungrapple 5. Give SRMS operator GO to mnvr to clearance posn
 S1 PM R&R (SODF: RBT FS: Failed PM Install on ESP2) Start torque wrench thermal clock:	 INSTALL FAILED PUMP MODULE ONTO ESP2 1. Translate to airlock, temp stow fish stringer #1 and PM Jumper 2. Retrieve torque wrench from inside airlock 	INSTALL FAILED PUMP MODULE ONTO ESP2 SSRMS mnvr to ESP2 failed PM install posn
zenith J1	 Translate to ESP2 Monitor clearances between EV2, LEE, and Lab BRT to ESP2 HR 8012 (fwd) GCA as required Retrieve fish stringer #2 from VSSA FRAM HRs Retrieve M/W J4 and J5 connectors 	2. Reorient PM so FGB interface is fwd 3. Install PM onto PM FSE, GCA SSRMS as reqd PM BOLT INITIAL TORQUE 1. GCA SSRMS to PM bolts
nadir S1 PM – FACE 1	Receive GO from EV2 to translate on PM	 GCA SSRMS to PM boits PGT [B7, CW2, 30.5]-7.8"-Ext-5/8: Drive PM Bolt 1, 14-17 turns (reqd to do first) Give EV1 GO to translate on PM

FS 16-147 EVA/116/FIN

INSTALLATION OF FAILED PUMP MODULE ONTO ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	10. Install fish stringer #2 on PM HRs	 4. Drive PM Bolts 2, 3, and 4, 14-17 turns 5. Remove 5/8" socket from PGT, temp stow 6. Release PM tether
	PM ELECTRICAL CONNECTIONS	
 √MCC electrical inhibits in place 	1. Mate M/W J5 (P11) to PM J5 2. Mate M/W J4 (P10) to PM J4	
	 3. Retrieve J3 cap from fish stringer #2, mate to J3 4. Retrieve J2 cap from fish stringer #2, mate to J2 5. Transfer torque wrench to EV2 	PM BOLT FINAL TORQUE 1. Receive torque wrench from EV1, verify set to 37 ft-lbs
	6. Retrieve M/W J1 connector, mate M/W J1 (P12) to PM J17. Inform IV when connections complete	 Install 5/8" socket onto wrench Tighten PM bolts (4) until torque wrench trips (any order)
a a: Maa aa i		SSRMS CLEANUP
6. Give MCC GO to power up PM on ESP2 after EV1 and EV2 connections complete	8. Retrieve QD caps (4) from fish stringer	 SSRMS mnvr to ESP2 egress posn Egress SSRMS Perform safety tether swap onto airlock safety tether,
	NOTE QD cap lock tab may not fully engage. If tab does not fully engage after several attempts to seat, leave QD uncapped	verify ST config 4. Relocate APFR from SSRMS to A/L Toolbox #1; reconfigure to: [9,MM,F,12]
7. S1 PM R&R (SODF: RBT	Q Install OD caps onto M1 M2 M3 and M4	5. Remove WIF adapter, stow on MWS6. Translate to airlock
FS: APFR Egress) 8. S1 PM R&R (SODF: RBT FS: APFR Removal)	 9. Install QD caps onto M1, M2, M3, and M4 10. Retrieve fish stringer #2 from PM HRs 11. Release MLI strap from S0/Lab struts and re-install MLI onto PM 	6. Translate to airlock7. Perform tool inventory8. Stow torque wrench on fish stringer #1
	□ Attach aft 1/4 turn fasteners (3)	

FS 16-148 EVA/116/FIN

INSTALLATION OF FAILED PUMP MODULE ONTO ESP2 (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	□ Release stbd flap from top of MLI (2 straps) □ Verify Velcro from Flap 3 is attached □ Attach stbd 1/4 turn fasteners (2) 12. When EV2 complete w/bolts, reinstall MLI tent 13. Ensure all Velcro flaps are covered, and fwd Velcro strap installed	
	<u>CLEANUP</u>	
	 Translate to crewlock and stow PM Jumper bag Translate to airlock Perform tool inventory 	

FS 16-149 EVA/116/FIN

INGRESS

IV	EV1 (FF)	EV2 (FF)
Perform WVS PWRDN		←
(PHOTO/TV, WVS CUE		
CARD)		1. Ingress airlock
		Connect right waist tether to UIA panel fwd D-ring, verify ST config
	Receive EV2 safety tether; stow on airlock aft D-ring, √reel unlocked	3. Disconnect from airlock safety tether, hand to EV1
	2. Transfer fish stringers #1 and #2 to EV2	4. Receive fish stringers #1 and #2 from EV1
	3. Connect right waist tether to D-ring extender on airlock internal D-ring, verify ST config	
	4. Disconnect from airlock safety tether, stow on airlock fw	vd .
	D-ring, √reel unlocked	
	5. Ingress airlock	
	6. Retrieve SCU, remove DCM cover	5. Retrieve SCU, remove DCM cover
	7. Connect SCU to DCM, √locked	6. Connect SCU to DCM, √locked
	8. DCM: water – OFF	7. DCM: water – OFF
	9. Hatch thermal cover – close, attach Velcro strap	
		CALITION
		CAUTION ntil EMU water – OFF for 2 min
	10. Verify hardware clear of hatch	
	11. Outer hatch – close and lock	
	12. Go to PRE REPRESS	8. Go to PRE REPRESS

FS 16-150 EVA/116/FIN

S1 PUMP MODULE R&R TASK DATA SHEET

Tools:

EV1	EV2
PGT w/6-in	PGT w/6-in
PM Jumper	Round TM w/58" proud socket
(1.5" vent tool)	Torque Wrench

Foot Restraints:

Task	WIF	APFR Setting
PM R&R	SSRMS	12, PP, F,6

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Release/Install Torque (ft-lbs)	Failure Torque (ft-lbs)	Turns	RPM
FGB-PM mounting bolts	GP1, GP2, GP3, GP4	7/16"	4	Release: 25.5 Install: 9.2		Release: 17-20 Install: 8-11 (w/FGB inplace)	30
PM Attach Bolts (truss)	Bolt 1, 2, 3,4	5/8"	4	Release: 25 (w/TM) Install: 6.3 (w/TM)		Release: 14-17 Install: 14-17	30
PM Attach Bolts (FSE)	Bolt 1, 2, 3,4	5/8"	4	Release: 24 (w/TM) Install: 37 - torq wren		Release: 14-17 Install: 14-17	30
P-Clamp Bolts	NA	7/16"	4	Release: 9.2 Install: 7.0		Release: 12-14 Install: 12-14	30

EVA Connectors:

Connector	From	То	Clamps	Size	Function
S1 P521		PM J1	1		
S1 P522		PM J2	1		
S1 P523		PM J3	1		
S1 P524		PM J4	1		
S1 P525		PM J5	1		
ESP2 M/W J5 (P11)		PM J5			
ESP2 M/W J4 (P10)		PM J4			
ESP2 M/W J1 (P12)		PM J1			

Notes:

- Check connectors for damage, emi band, FOD, bent pins, and cable bend radii
- 2. Original vent time of 00:25 for failed PM NH3 vent given by TCS community. New time of 00:08 minutes given by Boeing TCS

Cautions:

- 1. When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing
- 2. Avoid contact with FGB grapple pin and RMS target
- 3. Minimize loads inputted into PM MLI handholds. It is possible that handholds may tear off when used
- 4. GP2 must be the first bolt torqued during installation. Remaining bolts torqued in a star pattern
- 5. When operating QDs, assess sideloads and flexhose alignment prior to mating/demating and valve opening/closing
- 6. PM Installation bolts (for initial torque) must be installed in the following order: bolt 1 first, and then bolts 2-4 in any order (due to nut plate tolerances). There is no required order for bolt release, and no required order for torque multiplier operations (KSC)

Warnings:

1. N/A


Timeline Considerations:

1. The PM thermal clock begins when the PM MLI tent is removed on ESP2

Connector	From	То	Clamps	Size	Function
S1-F49	NA	M4	1 P, 1 TA	.5"	Connects the NH3 tank and NH3 supply to the inlet side of the PM (downstream of mixing valve) – venting QD
S1-F48	NA	М3	1 P, 1 TA	1.5"	Connects outlet of the PM to the EATCS system (iso valve)
S1-F45	NA	M2	1 P, 1 TA	1.5"	Connects radiator return NH3 to PM inlet
S1-F44	NA	M1	1 P, 1 TA	1.5"	Connects bypass return NH3 to PM inlet (doesn't go thru radiators)

FS 16-151 EVA/116/FIN

S1 PUMP MODULE R&R TASK DATA SHEET (Cont)



STBD

FS 16-152 EVA/116/FIN

NOTES

Assumptions:

- Start on 85' safety tethers at airlock
- MT @ WS 2; CETA carts coupled to port side of MT; CETA carts can be decoupled and moved as regd to allow EV1 good access to QD lines
- SSRMS on MBS PDGF 3
- Temp stow failed PM on SRMS
 - Keep crew separated from each other during failed PM venting ops to minimize contamination
- Plan to leave all cont tools in airlock
- Plan to remove 4 QD caps and 2 remaining electrical dust caps at ESP2 and leave them there for PM translation to S1
- EV1 FF/EV2 SSRMS
- EV1 on 85' safety tether
- Assumed 1st QD bag is outside and all cont tools we will need are in it
- For venting: the procedure is written assuming that IV can vent through the vent panel, and that no EVA venting of the NH3 from the failed PM is required. It also assumes we vent the PM jumper of Nitrogen using the vent panel and not the vent tool
- Need 2 crewmembers for all PM jumper operations, including N2 venting of jumper
- If EV crew vents N2 from spare PM on ESP2 (~12 min)
- The procedure is baselined to allow MCC to vent the N2 from the spare PM while it's in the truss. There is no additional EVA time needed for this. As soon as the PM gets installed into the truss, EV1 will mate and open valve on the .5: QD; no electricals are reqd for this since the valves are already configured to allow the N2 to vented through the ATA panel. No additional EVA time is needed

FS 16-153 EVA/116/FIN

SSRMS JOINT DRIVE

IV/RMS EV1/EV2 REFERENCE INITIAL POSITION VERIFICATION **IV NOTE** YAW WIR EVA JOINT Square scoop may be needed for body positioning at the 1. Translate to failed joint DRIVE worksite. If required, retrieve square scoop from crewlock DRIVE 2. Verify initial joint position using the WRIST-ROLL bag #1 in airlock. Install square scoop on failed joint micro JOINT following: fitting; attach BRT for body stabilization Black triangle on fixed side of failed joint Ambiguity sensor (90 degrees CW from EVA drive, toward front side of joint) JOINT IV: Record ambiguity sensor reading and joint angle: SCALE JOINT EVA DRIVE 1. Depress button and move EVA Drive **EVA Drive** handle to EVA Handle W/R Ambiguity 2. PGT[A1 2.5 ft-lb, CW2 or CCW2 (as JOINT (@ motor posn) Sensor DRIVE required), MTL 1.5]-6ext-7/16: Drive EVA Ambiguity bolt in +/- direction turns to desired Switch position 12:00 3. Verify joint angle using scale and ambiguity sensor 4. If possible, verify joint angle with IV; if **□**.3:00 necessary, fine position joint using PGT in manual ratchet mode Joint Scale and Black Triangle 5. Depress button and move EVA Drive Back Side of Joint handle to MOTOR MAINT. ANGLE **Ambiguity Switch**

Red Background, Joint Hard Stop Warning Zone (-270 to -280)

Red Background, Joint Hard Stop Warning Zone (-270 to -280)

Black Text on Yellow Background, 0 to 270)

Green Background, Maintenance Position, Not Applicable

JOINT SCALE

FS 16-154 EVA/116/FIN

SSRMS JOINT DRIVE TASK DATA SHEET

Tools:

EV1
PGT
7/16 (wobble) Socket-6 ext
BRT
Square Scoop

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Min Drive Torque (ft-lb)	Max Drive Torque (ft-lb)	Failure Torque (ft-lb)	RPM
EVA Drive		7/16	1				30

Foot Restraints: N/A

Other:

- 1. Gear ratio: 3.26 EVA Drive turns/1 degree of joint movement
- 2. CW input to the EVA drive will produce CCW motion of the joint
- 3. Staring from LEE, the order of joints is: roll, yaw, pitch
- 4. The signs of the logical (indicated on RWS) and physical (indicated on EVA scale) angles are reversed for the wrist roll joint (i.e. +73.2 logical = -73.2 physical)
- 5. Scale and Ambiguity Switch
 - □ Since the SSRMS joints can rotate more than 360 degrees, there is an ambiguity switch that tells the crewmember whether to use the positive or negative scale
 - ☐ The crew reads the scale using the black triangle on the fixed side of the joint. Located to the side of the black triangle (~ 90 degrees around the circumference of the joint) is the ambiguity switch. The switch has a pointer that indicates "+" or "-" to tell the crew which side of the scale to read. If the ambiguity switch points to "+" then the crew should read off the yellow scale (black text on yellow background). If the switch points to "-" then the crew should read off the black scale (yellow text on black background)
 - □ EVA Drive handle is on back side of joint (away from LEE), and scale triangle is across from it toward the LEE side

Cautions:

- 1. Avoid contact with ACU radiator surface silver Teflon film (white in color
- 2. CLA and CLPA radiator surface silver Teflon film (white in color)
- 3. VDU radiator surface silver Teflon film (white in color
- 4. JEU radiator surface Z93 paint


FS 16-155 EVA/116/FIN

MSS EXTENSION CABLE INSTALL (00:45)

		IV/S	SSRM	S		EV1 (FF)	EV2 (FF)
* Data S0 RF	comm: Page: (P1): E PCM X		nce RP	CM on Ta I:	ask * *	NOTE MSS Extension Cable is coiled into 5 wire tied loops, each 7 feet long; wire ties are captive ■ □ 1. Demate MT power cable connector □ P35 from MBS J35 (4B)	NOTE MSS Extension Cable is coiled into 5 wire tied loops, each 7 feet long; wire ties are captive 1. Retrieve MSS extension cable from bag 2. Release wire ties from P2 end of extension
√Clo	se Cm		J		MBS Connection	- OR - P37 from MBS J37 (3A) Temp stow MT power cable connector P35	cable bundle 3. Remove protective cap from P2
Worksite 2	Panel A107		Connector J2	in Truss Outside	(RPCM) J35 (4B)	(P37) on JO13 or JO19 MT dummy connector 3. Receive P2 connector from EV2	Transfer P2 connector to EV1
(S1, Bay 13)	A119	P246	J2	Outside	J37 (3A)	4. Inspect P2 and MBS J35 (J37) and mate5. Assist EV2 with cable routing and securing	Translate to passive UMA location closest to MT, releasing coils as reqd
(S1,	A112	P642 P645	J2 J2	Outside Outside	J35 (4B) J37 (3A)	<u>NOTE</u>	6. Remove protective cap from extension cable J2
Bay 5) 4	A294	P174	J2	Inside	J35 (4B)	Each cable is labeled both on the harness and	
(S0, Bay 1)	A143	P172	J2	Inside	J37 (3A)	opposite side of the feed-through bracket. Verify that the connector being demated	
5 (S0,	A292	P763	J2	Inside Inside	J35 (4B)	has a P label versus a J label	
Bay 4)	A249	P761 P645	J2 J2		J37 (3A)	Refer to Worksite UMA Location Chart for the	
6 (P1, Bay 6)	A118 A112	P645 P642	J2 J2	Outside Outside	J35 (4B) J37 (3A)	following steps: 6. Enter truss segment for access to UMA panel	7. Open shroud at UMA location (if required) 8. Transfer MSS extension cable J2 to EV1
7	A119	P246	J2	Inside	J35 (4B)	7. At UMA panel, demate P harness from J2	o. Transfer Moo extension capie 32 to EVT
(P1, Bay 14)	A107	P243	J2	Inside	J37 (3A)	8. Inspect P harness and MSS extension cable J2; mate9. Secure extension cable at worksite using wire ties, as reqd	

FS 16-156 EVA/116/FIN

MSS EXTENSION CABLE INSTALL TASK DATA SHEET



FS 16-157 EVA/116/FIN

MSS EXTENSION CABLE INSTALL TASK DATA SHEET (Cont)

Tools:

EV1 (RMS)	EV2 (FF)
NA	Wire Tie Caddy

EVA Fasteners:

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
None								

EVA Connectors:

From MBS	To MSS Ext. Cable	Truss Panel	Harness	From	To MSS Ext. Cable	Conn Size	Function
		A107		P243		33	RPCM S1-4B-E
		A112		P642		33	RPCM S1-4B-F
J35	P2	A143	W4122	P172	J2	33	RPCM S0 4B-A, Data
333	FZ	A249	W4122	P761	JZ	33	RPCM S0 4B-B, Data
		A112	W5195	P642		33	RPCM P1 4B-F, Data
		A107	W5198	P243		33	RPCM P1 4B-E, Data
		A119		P246		33	RPCM S1-3A-E
		A118		P645		33	RPCM S1-3A-F
J37	P2	A294	W4121	P174	J2	33	RPCM S0 3A-A, Data
337	FZ	A292	W4121	P763	JZ	33	RPCM S0 3A-B, Data
		A118	W5199	P645		33	RPCM P1 3A-F, Data
		A119	W5193	P246		33	RPCM P1 3A-E, Data

Foot Restraints:

Task	WIF	APFR Setting
None		

FS 16-158 EVA/116/FIN

PUMP MODULE MANUAL VENTING

IV	EV1 (FF)	
	1. Translate to stbd QD tool bag 2. Open lid 3. Remove 1.5" vent tool from bag, stow on MWS 4. Translate to VTE bag (aft) 5. Open VTE bag 6. Remove VTE and 1.0" vent tool from bag 7. Demate 1.0" vent tool from VTE 8. Perform visual check that 1.5" vent tool nozzle will protrude past VTE internal seals: □ Hold vent tool nozzle against VTE external alignment groove (vent tool hook should contact VTE connector) □ √Nozzle tip is past thin black alignment line 9. Install 1.5" vent tool nozzle into VTE connector via the following steps: □ Rotate lock lever to unlock (hard stop detent − very loose) □ Depress lever to hard stop (2-10 lbs) □ Insert vent tool nozzle into connector tube (vent tool hook will contact front of connector, go to hard stop) □ Release lever and rotate lock 10. Install 1.5" vent tool and VTE inside VTE bag, install internal straps 11. Close VTE bag lid 12. Stow 1.0" vent tool in stbd QD bag 13. Retrieve VTE bag from crewlock, attach to BRT VENT TOOL EXTENDER INSTALL 1. Translate to TBD PM worksite 2. Temp stow VTE bag 3. Vent M4 flexline (via TBD procedure) prior to EV crew demate and handling (based on new QD load limits) 4. Remove 1.5" vent tool and VTE from VTE bag 5. Perform the following steps to mate 1.5" vent tool to PM M3:	Possible HRs for VTE nozzle attachment: S1 zenith: 3235, 3236 S1 nadir: 3273 P1 zenith: TBD P1 nadir: TBD Assumptions 1. The VTE bag and PM jumper bag were installed on the airlock during EVA 2. If they have not been, the tools will be brought outside with the crew prior to the EVA 2. The 1.0" female NH3 vent tool was installed onto the VTE inside ISS prior to EVA 2 for 2 reasons: As a get-ahead for 10A nominal venting To prevent the VTE internal seals (2) from rigidizing to a smaller diameter interface in cold conditions that would prevent successful mating of a vent tool nozzle to the VTE connector (by having one already Installed, the nozzle keeps the seals in a more "open" position to readily accept another vent tool) 3. If manual venting is required, must decide best way to carry both VTE bag and PM Jumper bag to worksite

FS 16-159 EVA/116/FIN

PUMP MODULE MANUAL VENTING (Cont)

IV	EV1 (FF)	
	 A. Inspect male and female QDs for debris or damage B. √Button up C. √Release ring retracted (fwd white band not visible) D. Mate vent tool to PM M3 E. √Fwd white band visible (snapback, pull and gap√) 6. Restrain vent tool nozzle and VTE connector end to TBD HR using wire tie or vent tool integral hook 7. While tending VTE coil, translate to truss face 2 or face 6 HRs 8. Attach MUT EE to zenith or nadir truss HR; orient nozzle away from structure 	
	FAILED PM VENTING	
	1. Translate to PM	
 1A. √MCC GO for PM manual venting (just vents QD line) 1B. Ensure EV1 and EV2 clear of venting area 	 2. Perform the following steps to open valve on 1.5" vent tool to PM M3: A. Depress detent button and open valve (push bail fwd) (starts venting NH3, ~ 5 minutes to vent QD line) B. √Aft white band visible and detent button up 	
√MCC: Verify venting complete prior to closing valve and demating vent tool	 VENT TOOL REMOVAL 1. Translate to vent tool at PM M3 ✓ 2. Perform the following steps to close valve and demate vent tool from PM M3: A. Close valve (depress button and pull bail aft) B. Verify detent button up C. Verify fwd white line visible D. Demate vent tool from M3 (using release trigger) 	

FS 16-160 EVA/116/FIN

PUMP MODULE MANUAL VENTING (Cont)

IV	EV1 (FF)	
	 Tending VTE coil, translate to HR where MUT EE is attached; remove VTE nozzle from HR Translate to VTE Bag Stow VTE and 1.5" vent tool in VTE bag; black lines on VTE harness aid in alignment during re-coiling of cable, attach Velcro strap around coil 	
	CLEANUP	
	 After PM R&R complete, translate to airlock Stow VTE bag on zenith crewlock 	

FS 16-161 EVA/116/FIN

PUMP MODULE MANUAL VENTING TASK DATA SHEET

ASSUMPTIONS

- 1. PM failed in such a way that MCC cannot vent NH3 through ATA vent panel; EVA must vent
- 2. VTE required when EVA vents NH3
- 3. Assumes zenith HRs for venting; could use nadir HRs
- 4. Could use any 1.5" QDs to vent
- 5. Assumes NH3 venting done at truss wkst, not ESP2

VENTING NOTE

Although manual venting can occur from any 1.5" male QD, plan on only venting the QD portion with respect to M3. The isolation valve connect to M3 is normally going to be the only valve that we will be closing on-orbit (for heat exchanger freeze protection) and is therefore the most likely valve to be failed closed. The PM is also useless with this valve closed. The rest of the PM can still be vented through M4 and the ATA vent panel

If M3 valve fails, only the QD portion needs to be manually vented (tube to valve). No plan to ever close M4, should stay open and so should never fail closed on our flight. The manual venting should take place after the PM jumper is (installed all QDs disconnected)

FS 16-162 EVA/116/FIN

FAILED PUMP MODULE RETURN TO ICC

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
1. ROBO: TBD	SETUP 1. Translate to ESP2	SSRMS SETUP 1. Retrieve APFR from TBD, attach to BRT 2. Translate to ESP2 fwd/zenith 3. GCA SSRMS for APFR setup 4. Install WIF adapter (tether point facing same direction as LEE) into SSRMS 5. Relocate APFR from TBD to SSRMS, configure to: [12,PP,F,6] 6. Perform safety tether swap onto SSRMS safety tether; verify ST config 7. Temp stow airlock safety tether on VSSA FRAM
	2. Assist EV2 will PM MLI as reqd	HR (fwd) 8. Release velcro strap on PM fwd flap 9. Open forward flap on PM MLI tent, attach velcro flaps (2) 10. Install local waist tether onto APFR 11. Ingress SSRMS (head zenith)
2. ROBO: TBD	FGB REMOVAL AND TEMP STOW	FGB REMOVAL AND TEMP STOW 1. SSRMS mnvr to FGB bolt release position 2. Tether to FGB 3. PGT [B7, CCW2, 30.5]-6-Ext-7/16: Release FGB to Pump Module mounting bolts (4),
	Receive FGB from EV2, temp stow on BRT. Ensure FGB is tucked behind body and clear of snags	~ 8-11 turns (any order) 4. Remove FGB from Pump Module, transfer to EV1
3. √MCC ESP2 inhibits in place	FAILED PUMP MODULE REMOVAL FROM ESP2 ← □	FAILED PUMP MODULE REMOVAL FROM ESP2
	 Translate aft on ESP2 until body is port of MBSU Access PM primary FRAM bolt with body in between MBSU and PM with head facing forward PGT [A4, CCW2, 10.5]-6Ext-7/16: Release primary FRAM bolt 11 turns (hard stop) 	1. Tether to PM

FS 16-163 EVA/116/FIN

FAILED PUMP MODULE RETURN TO ICC (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	NOT FRAM has magnetic soft dock: 5 3 ½ lb at aft 2 corners	
	Assist EV2 with PM removal and clearances	2. Remove Pump Module from passive FRAM
	FGB INSTALL ONTO ATA	FAILED PUMP MODULE INSTALL ON ICC
4. ROBO: TBD	CAUTION Crew must be two feet from radiator beam when it's not locked	 SSRMS mnvr to ICC (EV2 on left side) Orient PM such that primary FRAM bolt faces Orbiter port
	 Translate to zenith S1 ATA (TBD) (S1 face 4, inboard) PGT [B7 (18.4 ft-lb), CCW2, 30.5]-6Ext-7/16: Disengage S1 ATA grapple bolts (4) 20 turns Soft dock FGB to ATA (RMS target closest to top of box) 	GP 4 (3rd) GP 2 (1 st)
	NOTE GP2 must be the first bolt torqued Remaining bolts are torqued in a star pattern	GP 1 (4th)
Record turns and torque for ATA grapple bolts:	4. PGT [A7 (9.2 ft-lb), CW2, 30.5]-6Ext-7/16: Engage S1 ATA grapple bolts (4), 10-11 turns in the following order: GP2, GP3, GP4, GP1	(2 nd) S1 ATA BOLT PATTERN
GP2: turnsft-lb GP3: turnsft-lb	5. Perform WVS survey	STAIABOLITATILIN
GP4: turnsft-lb GP1: turnsft-lb	FAILED PUMP MODULE INSTALL ON ICC	
	 Retrieve APFR from <u>TBD</u>, attach to BRT Translate to ICC via the following path to ensure safety tether is clear of SSRMS trajectory: Translate along Lab stbd/zen HRs to stbd ODS truss 	

FS 16-164 EVA/116/FIN

FAILED PUMP MODULE RETURN TO ICC (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	 □ Install poorman's fairlead around stbd ODS truss HR and under ODS light □ Translate to port ODS truss HR and perform safety tether swap onto spare safety tether, verify ST config □ Translate along Orbiter port sill to ICC 3. Install fairlead at port/fwd corner of ICC on sill HR 4. Install APFR into ICC bottom/aft/port WIF, configure to: [12,PP,H,9] 5. Ingress APFR 6. Assist EV2 and SSRMS operator with clearances 	3. GCA SSRMS in toward bottom of ICC
	NOT Be aware of tight clearances It is difficult to monitor aft/st	s between PM and ICC.
6. ROBO: TBD	Receive PM from EV2, bring close to body in port direction to provide clearance for EV2	 Transfer PM to EV1 SSRMS mnvr to ICC dropoff position (fwd edge) Egress SSRMS Translate to bottom of ICC through stbd side, install local fairlead if reqd
	 Install PM onto passive FRAM If reqd, egress APFR PGT [A4, CW2, 10.5]-6"-Ext-7/16: Drive primary FRAM bolt 11 turns (hard stop) Egress APFR Remove APFR from ICC WIF, attach to BRT Egress ICC 	 8. Inform EV1 when clear of passive FRAM interface 9. GCA PM clearances with coarse alignment cones and KYA 10. Egress ICC, go aft of PM and egress KYA via port side (must tend safety tether around PM)
	CLEANUP	SSRMS CLEANUP
	 Translate to port ODS truss; perform safety tether swap onto airlock safety tether, verify ST config Stow APFR in TBD WIF Perform tool inventory 	 Hold LEE HR SSRMS mnvr to ESP2 GCA SSRMS for egress Egress APFR

FS 16-165 EVA/116/FIN

FAILED PUMP MODULE RETURN TO ICC (Cont)

IV/SSRMS	EV1 (FF)	EV2 (SSRMS)
	4. Translate to airlock	 Perform safety tether swap onto airlock safety tether, verify ST config Retrieve spare safety tether from SSRMS Remove APFR, stow in <u>TBD</u> WIF Remove WIF adapter, stow on MWS Perform tool inventory Translate to airlock
	Assumptions/Questions: Need 2 APFRs for this, 1 for SSRMS, 1 for ICC Need to determine where APFRs come from Using SSRMS on Lab PDGF FGB must be removed from PM and stowed somewhere (S1 ATA?) (1 person comfortable with this?) This task will be done with connector re-do on same EVA Both crew begin EVA on 85' safety tethers	

FS 16-166 EVA/116/FIN

FAILED PUMP MODULE RETURN TO ICC TASK DATA SHEET

Tools:

EV1	EV2
• PGT with 7/16, 6-in	• PGT with 7/16, 6-in
• BRT	• BRT
• APFR	• APFR
	WIF adapter

EVA Fasteners:

Fastener Name	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns
FRAM	7/16	1	6.3	6.3	21	11
Primary Bolt					(both)	
ATA FGB GP	7/16	4		25.5	47.4	20
bolt release						17 min
ATA FGB GP	7/16	4	9.2		16.1	10-11
bolt install						

Notes:

- 1. Do not touch SRMS target or grapple pin shaft on FGB
- 2. FRAM has magnetic soft dock: 5 ½ lb at forward 2 corners and 3 ½ lb at aft 2 corners
- 3. GP2 must be the first bolt torqued. Remaining bolts are torqued in a star pattern
- 4. FGB FSE bolts must be backed out at least 20 turns to remove the FGB. Running torque will decrease at ~18 turns when the locking "poly patch" ends. The bolts are fully backed out at 33 turns, but torque should not be applied at this point to avoid breaking the castellated nut captive feature
- 5. Be aware of tight clearances bewtween PM and ICC. It is difficult to monitor aft/stbd corner of PM with KYA

Cautions:

1. Crew must be two feet from radiator beam when it's not locked

FS 16-167 EVA/116/FIN

This Page Intentionally Blank

FS 16-168 EVA/116/FIN

FLIGHT SPECIFIC EVA REFERENCE


12A.1 OVERVIEW		
12A.1 ISS OVERVIEW	FS ²	18-5
PAYLOAD BAY OVERVIEW		
MT/CETA CART LOCATIONS PER EVA		
12A.1 TRUSS WORKSITES		
12A.1 ICC OVERVIEW		
ICC WIF AND HANDRAIL LAYOUT – TOP		
ICC WIF AND HANDRAIL LAYOUT – BOTTOM		
ICC – FAILED PUMP MODULE RETURN CONFIG		
ESP2 HANDRAILS AND WIFs – ZENITH		
ESP2 HANDRAILS AND WIFS – NADIR		
EVA 1 OVERVIEW	го	10-14
P5 SAFETY TETHER SWAP OVERVIEW	EC /	10 15
P5 SAFETY TETHER SWAP OVERVIEWP5 PRE-INSTALL POSITION		
RTAS CORNER 2 CLEARANCES		
RTAS CORNER 2 CLOSEUP VIEW OF CLEARANCES – SSU & P5		
RTAS CORNERS 1&2 AND FINAL TORQUING		
RTAS CORNERS 3&4 AND FINAL TORQUING		
PVRGF OVERVIEW		
PVRGF REMOVAL WORKSITE – P5 WIF 11		
PVRGF STOWED ON KEEL		
CP3 OVERVIEW AND TRANSLATION PATH	FS 1	18-24
EVA 2 OVERVIEW		
S0 WORKSITES – EVA 2		
SAFETY TETHER SWAP LOCATION FOR P1 BAY 16 DDCU	FS 1	18-26
Z1 PP WORKSITES – EVA 2		
CETA CART RELOCATION - INITIAL POSN & SAFETY TETHER SWAP	FS 1	18-28
CETA CART RELOCATION		
CETA CART RELOCATION - FINAL POSN	FS ²	18-30
SSRMS FMS MLI INSTALL	FS ²	18-31
EVA 3 OVERVIEW		
S0 WORKSITES – EVA 3	FS ²	18-32
S1 BAY 15 DDCU WORKSITE AND TRANSLATION		
TRANSLATION PATH TO FACE 3 ACCESS FLAP FOR LAB 4A DDCU		
SECONDARY PWR	FS ²	18-34
SO PORT WEDGE FACE DDCU TRANSLATION PATH AND WORKSITE		
Z1 PP WORKSITES – EVA 3		
APFR INGRESS LOCATION FOR SMDP TRANSFER		
TRANSLATION PATH AND SAFETY TETHER SWAP TO PLB		
Z1-NODE 1 UMBILICALS WORKSITE OVERVIEW		
H-JUMPER WORKSITE		
P5/PVRGF	1 0	10-40
P5 ISOMETRIC VIEW	EQ.	18_//1
P5 HANDRAILS AND WIFs (PORT/FWD VIEW)	FS ·	18-42
P5 HANDRAILS AND WIFS (ZENITH/STBD VIEW)		
P5 HANDRAILS AND WIFS (NADIR/STBD VIEW)		
P5 HANDRAILS AND WIFs (FWD/PORT VIEW)		
P5 MRTAS – ACTIVE		
P5 EWIS LAYOUT		
RTAS HOUSING DIMENSIONS	FS ²	18-49
P4 MRTAS – PASSIVE	FS	18-50
P5 TO P4 MRTAS PRIMARY BOLT ENGAGED	FS ²	18-51
GAP CHECK TOOL		
P5-P4 CONNECTOR PANEL	FS ²	18-53
P5 CAPTURE LATCH ASSEMBLY (CLA)	FS '	18-54

ETVCG		
ETVCG - ASSEMBLED	FS	18-55
ETVCG MOUNTED ON STANCHION	FS	18-56
U.S. CONNECTIONS		
S0 FORWARD AVIONICS PANEL WORKSITE	FS	18-57
S0 WORKSITES - PANELS 163 AND 165, MBSU RECONFIG		
S0 – PANELS 163 AND 165		
S0 CH 1/4 AND 2/3 JUMPERS		
MBSU BYPASS JUMPER RECONFIG – CH 1/4		
MBSU BYPASS JUMPER RECONFIG - CH 2/3		
CID PHOTO		
S0/N1 PWR CABLE WORKSITE OVERVIEW		
SO PANEL A166 WORKSITE	F5	18-65
DDCU COLDPLATE CONNECTOR BOX – GENERIC		
S0 AFT TRAY		
Z1-LAB-S0 CONNECTIONS (PRE-12A.1 CONFIG)		
Z1-LAB-S0 CONNECTIONS (POST-12A.1 CONFIG)		
RAT'S NEST QD OVERVIEW		
RAT'S NEST CONNECTIONS – CHANNEL 2/3	FS	18-71
RAT'S NEST CONNECTIONS – CHANNEL 1/4	FS	18-72
PATCH PANELS 1 AND 2 – SPDA	FS	18-74
PATCH PANELS 5 AND 6 - DDCU	FS	18-75
P1 BAY 16 DDCU THERMAL COVER		
S1 DDCU THERMAL COVER		
CETA CART		10 70
CETA CART – TOP VIEW	FS	18-79
CETA SWINGARM AND WIF MARKINGS		
CETA SWINGARM AND WIL MARKINGS		
CETA CART COOPLERSCETA CART WHEEL BOGIES		
	F5	18-82
SSRMS FMS MLI		40.00
SSRMS FMS LOCATION		
SSRMS FMS MLI		
LATCHING END EFFECTOR (LEE)	FS	18-85
SMDP		
SMDP BUNDLE OVERVIEW		
SMDP TDK – LAUNCH CONFIG FOR BUNDLES 2 AND 3		
SMDP TDK – LANDING CONFIG FOR BUNDLES 2 AND 3	FS	18-88
SMDP TDK – LANDING CONFIG FOR BUNDLE 4	FS	18-89
TDK LANDING CONFIG - SIDE VIEW	FS	18-90
TDK BOLT OVERVIEW WITH LABELS	FS	18-91
TDK BOLTS - NOMINAL AND CONTINGENCY		
SMDP ADAPTER		
CHRISTMAS TREE		
CHRISTMAS TREE STOWAGE ON PMA3		
RUSSIAN PWR RECONFIG		10 00
S0/NODE 1 SWINGARM	EQ	18-06
Z1-NODE CONNECTIONS – PRE 12A.1		
Z1-NODE 1 CONNECTIONS – PRE 12A.1Z1-NODE 1 CONNECTIONS – POST 12A.1		
FGB/PMA1 H-JUMPER 2/3 CONFIG		
FGB/PMA1 CONFIG POST H-JUMPER REMOVAL		
ADJUSTABLE GRAPPLE BAR		
FHRC	FS	18-102
CONTINGENCIES		
P1 PUMP MODULE WORKSITE OVERVIEW		
P1 PM INSTALLED IN TRUSS		
S1 PUMP MODULE WORKSITE OVERVIEW	FS	18-105

PUMP MODULE AND FSE OVERVIEW	FS 18-106
LAPA AND REAR CONTINGENCY PINS	FS 18-107
PUMP MODULE WITH FIXED GRAPPLE BAR AND MLI	FS 18-108
FLUID QD BAIL LEVERS	FS 18-109
QD CAP TOOLS	FS 18-110
1.5-IN FLUID QD SPOOL POSITIONING DEVICE	FS 18-111
FLUID OD RELEASE TOOLS	FS 18-112
0.5-IN FLUID QD SPOOL POSITIONING DEVICE	FS 18-113
0.5-IN SPD BOOTIE EXTENSION	FS 18-113
QD VENT TOOLS	FS 18-114
VENT TOOL EXTENDER BAG	FS 18-115
VTE AND VTE BAG DETAILS	FS 18-116
PUMP MODULE NH3 JUMPER	FS 18-117
STATUS INDICATORS (MBSU, DDCU, BCDU)	FS 18-118
FAILED MBSU LOCATIONS	FS 18-119
CETA CART LOCATION FOR MBSU R&R	FS 18-120
SPARE MBSU STOWED ON CETA GRID E WITH PORT TFR	
SWINGARM DEPLOYED	FS 18-121
MBSU ORU	FS 18-122
MBSU AND COLDPLATE	FS 18-123
DDCU LOCATIONS	FS 18-124
DC-TO-DC CONVERTER UNIT – EXTERNAL	FS 18-125
SPARE DDCU S0-4B WORKSITE (S0 PORT WEDGE FACE) (EVA 3)	FS 18-126
FAILED DDCU S1-4B WORKSITE (S1 BAY 15) (EVA 3)	FS 18-127
FAILED DDCU S0-1A WORKSITE (S0 BAY 01) (EVA 3)	FS 18-128
SPARE DDCU S0-3B WORKSITE (S0 BAY 04) (EVA 2)	FS 18-129
FAILED DDCU S0-2B WORKSITE (S0 BAY 02) (EVA 2)	FS 18-130
FAILED DDCU P1-3A WORKSITE (P1 BAY 16) (EVA 2)	FS 18-131
P6 OVERVIEW FOR STBD BCDUs	FS 18-132
P4 2A BCDU WORKSITE OVERVIEW	FS 18-133
P4 4A BCDU WORKSITE OVERVIEW	FS 18-134
BCDU	FS 18-135
P6 2B STBD IEA (UPPER/NON-KEEL SIDE) ORU LABELS	FS 18-136
P6 4B PORT IEA (LOWER/KEEL SIDE) ORU LABELS	FS 18-137
P4 4A FWD IEA (ÙPPER/NON-KEEL SIDE) ORU LABELS	FS 18-138
P4 2A AFT IEA (LOWER/KEEL SIDE) ORU LABELS	FS 18-139
4B MANUAL RETRACT – P6 WIF 37	FS 18-140
SOLAR ARRAY LATCH/TENSION OVERRIDE – LEFT BLANKET BOX	FS 18-141
SOLAR ARRAY JETTISON OVERVIEW	FS 18-142
MAST CANISTER MDA	FS 18-143
SABB MDA	FS 18-144
SOLAR ARRAY BLANKET BOX (SABB)	FS 18-145
FRAM/FSE/ORU ASSEMBLY	FS 18-146
ACTIVE FRAM SOFT CAPTURE MECHANISM	FS 18-147
FRAM CONTINGENCY BOLTS – SAPA	FS 18-148
P5 SOFT CAPTURE ASSY MANUAL OVERRIDE	FS 18-149
SMDP ADAPTER FAILED MAGNETIC SOCKET	FS 18-151

This Page Intentionally Blank


12A.1 ISS OVERVIEW



FS 18-5 EVA/116/FIN


12A.1 OVERVIEW

PAYLOAD BAY OVERVIEW




FS 18-6 EVA/116/FIN

MT/CETA CART LOCATIONS PER EVA




FS 18-7 EVA/116/FIN

12A.1 TRUSS WORKSITES




FS 18-8 EVA/116/FIN

12A.1 ICC OVERVIEW




FS 18-9 EVA/116/FIN

ICC WIF AND HANDRAIL LAYOUT - TOP




EVA/116/FIN

ICC WIF AND HANDRAIL LAYOUT - BOTTOM




FS 18-11 EVA/116/FIN

ICC - FAILED PUMP MODULE RETURN CONFIG




FS 18-12 EVA/116/FIN




FS 18-13 EVA/116/FIN

AIRLOCK



FS 18-14 EVA/116/FIN


P5 SAFETY TETHER SWAP OVERVIEW



FS 18-15 EVA/116/FIN


EVA 1 OVERVIEW

P5 PRE-INSTALL POSITION




FS 18-16 EVA/116/FIN

RTAS CORNER 2 CLEARANCES




FS 18-17 EVA/116/FIN

RTAS CORNER 2 CLOSEUP VIEW OF CLEARANCES - SSU & P5




FS 18-18 EVA/116/FIN

RTAS CORNERS 1&2 AND FINAL TORQUING




FS 18-19 EVA/116/FIN

RTAS CORNERS 3&4 AND FINAL TORQUING




FS 18-20 EVA/116/FIN

PVRGF OVERVIEW




FS 18-21 EVA/116/FIN

PVRGF REMOVAL WORKSITE - P5 WIF 11




FS 18-22 EVA/116/FIN

PVRGF STOWED ON KEEL




FS 18-23 EVA/116/FIN

CP3 OVERVIEW AND TRANSLATION PATH




FS 18-24 EVA/116/FIN

S0 WORKSITES - EVA 2




FS 18-25 EVA/116/FIN


SAFETY TETHER SWAP LOCATION FOR P1 BAY 16 DDCU



FS 18-26 EVA/116/FIN


Z1 PP WORKSITES - EVA 2






FS 18-27 EVA/116/FIN

CETA CART RELOCATION - INITIAL POSN & SAFETY TETHER SWAP




FS 18-28 EVA/116/FIN

CETA CART RELOCATION




FS 18-29 EVA/116/FIN

CETA CART RELOCATION – FINAL POSN




FS 18-30 EVA/116/FIN

SSRMS FMS MLI INSTALL



FMS INSTALL OVERVIEW, VIEW 2




BASE LEE OVERVIEW

FS 18-31 EVA/116/FIN


EVA 3 OVERVIEW

SO WORKSITES – EVA 3




FS 18-32 EVA/116/FIN


S1 BAY 15 DDCU WORKSITE AND TRANSLATION



FS 18-33 EVA/116/FIN


TRANSLATION PATH TO FACE 3 ACCESS FLAP FOR LAB 4A DDCU SECONDARY PWR






FS 18-34 EVA/116/FIN


SO PORT WEDGE FACE DDCU TRANSLATION PATH AND WORKSITE






FS 18-35 EVA/116/FIN


Z1 PP WORKSITES - EVA 3






FS 18-36 EVA/116/FIN

APFR INGRESS LOCATION FOR SMDP TRANSFER




FS 18-37 EVA/116/FIN

TRANSLATION PATH AND SAFETY TETHER SWAP TO PLB




PATH FROM AIRLOCK TO ORBITER STBD SILL



TETHER SWAP AT PORT ODS HR & TRANSLATION TO ICC


FS 18-38 EVA/116/FIN

Z1-NODE 1 UMBILICALS WORKSITE OVERVIEW




FS 18-39 EVA/116/FIN

H-JUMPER WORKSITE



FS 18-40 EVA/116/FIN


P5 ISOMETRIC VIEW



FS 18-41 EVA/116/FIN


P5/PVRGF

P5 HANDRAILS AND WIFs (PORT/FWD VIEW)




FS 18-42 EVA/116/FIN

P5 HANDRAILS AND WIFs (ZENITH/STBD VIEW)




FS 18-43 EVA/116/FIN

P5 HANDRAILS AND WIFs (NADIR/STBD VIEW)




FS 18-44 EVA/116/FIN

P5 HANDRAILS AND WIFs (FWD/PORT VIEW)




FS 18-45 EVA/116/FIN

P5 MRTAS - ACTIVE




FS 18-46 EVA/116/FIN

P5 EWIS LAYOUT




FS 18-47 EVA/116/FIN

P5 EWIS LAYOUT (Cont)




FS 18-48 EVA/116/FIN

RTAS HOUSING DIMENSIONS





Α	Height of RTAS Housing	14.1 cm
В	Width of RTAS Housing	21.5 cm
С	Diameter of Coarse Alignment Cone	9.2 cm
D	Diameter of Launch Lock	6.4 cm
Е	Diameter of Cont Bolt Hole	3.0 cm
F	Distance between contingency bolt disks	2.9 cm
G	Diameter of contingency bolt disk	5.5 cm



FS 18-49 EVA/116/FIN


P4 MRTAS - PASSIVE






FS 18-50 EVA/116/FIN


P5 TO P4 MRTAS PRIMARY BOLT ENGAGED




FS 18-51 EVA/116/FIN

GAP CHECK TOOL












TOOL REMOVED



TOOL INSTALLED ON RTAS CONTINGENCY SPACER SLEEVE


FS 18-52 EVA/116/FIN

P5-P4 CONNECTOR PANEL




FS 18-53 EVA/116/FIN

P5 CAPTURE LATCH ASSEMBLY (CLA)



FS 18-54 EVA/116/FIN

ETVCG - ASSEMBLED




Pan/Tilt Lock in Locked Posn

FS 18-55 EVA/116/FIN


ETVCG

ETVCG MOUNTED ON STANCHION



FS 18-56 EVA/116/FIN


SO FORWARD AVIONICS PANEL WORKSITE



FS 18-57 EVA/116/FIN


U.S. CONNECT

SO WORKSITES – PANELS 163 AND 165, MBSU RECONFIG




FS 18-58 EVA/116/FIN

SO - PANELS 163 AND 165



PANEL A163 (EVA 3) PRE 12A.1




W4144 P338 mated to A165
J338

TA clamp


W4144 P340 mated to A165
J340

PANEL A165 (EVA 2) PRE 12A.1




FS 18-59 EVA/116/FIN

S0 CH 1/4 AND 2/3 JUMPERS




FS 18-60 EVA/116/FIN


MBSU BYPASS JUMPER RECONFIG - CH 1/4



FS 18-61 EVA/116/FIN

MBSU BYPASS JUMPER RECONFIG - CH 2/3







Post 12A.1 Config (CID 7)

FS 18-62 EVA/116/FIN

CID PHOTO




S0/N1 PWR CABLE WORKSITE OVERVIEW



NODE 1 JACKS (don't plug cable into Node on 12A.1)


FS 18-64 EVA/116/FIN

SO PANEL A166 WORKSITE




FS 18-65 EVA/116/FIN

DDCU COLDPLATE CONNECTOR BOX - GENERIC




FS 18-66 EVA/116/FIN

SO AFT TRAY




FS 18-67 EVA/116/FIN

Z1-LAB-S0 CONNECTIONS (PRE-12A.1 CONFIG)




FS 18-68 EVA/116/FIN

Z1-LAB-S0 CONNECTIONS (POST-12A.1 CONFIG)




* = Connected on 12A.1

RAT'S NEST QD OVERVIEW




FS 18-70 EVA/116/FIN

RAT'S NEST CONNECTIONS – CHANNEL 2/3




FS 18-71 EVA/116/FIN

RAT'S NEST CONNECTIONS – CHANNEL 1/4



FS 18-72 EVA/116/FIN


RAT'S NEST CONNECTIONS - CHANNEL 1/4 (Cont)



FS 18-73 EVA/116/FIN

PATCH PANELS 1 AND 2 - SPDA


(Z1 PORT)



FS 18-74 EVA/116/FIN


PATCH PANELS 5 AND 6 - DDCU


(Z1 STBD)



FS 18-75 EVA/116/FIN


PATCH PANELS 5 AND 6 – DDCU (Cont) (Z1 STBD)







FS 18-76 EVA/116/FIN

P1 BAY 16 DDCU THERMAL COVER








Ground Strap

PORT

STBD


FS 18-77 EVA/116/FIN

S1 DDCU THERMAL COVER




FS 18-78 EVA/116/FIN

CETA CART - TOP VIEW




FS 18-79 EVA/116/FIN

CETA SWINGARM AND WIF MARKINGS





CETA CART COUPLERS




FS 18-81 EVA/116/FIN


CETA CART WHEEL BOGIES










Nadir Port Shown, Stbd Opposite










FS 18-82 EVA/116/FIN


SSRMS FMS LOCATION




FS 18-83 EVA/116/FIN

SSRMS FMS MLI


SSRMS FMS MLI




FMS MLI STOWED CONFIG



FMS MLI – UNROLLED






FMS MLI INSTALLATION

FS 18-84 EVA/116/FIN


LATCHING END EFFECTOR (LEE)



FS 18-85 EVA/116/FIN


SMDP

SMDP BUNDLE OVERVIEW




FS 18-86 EVA/116/FIN

SMDP TDK - LAUNCH CONFIG FOR BUNDLES 2 AND 3




FS 18-87 EVA/116/FIN

SMDP TDK - LANDING CONFIG FOR BUNDLES 2 AND 3



FS 18-88 EVA/116/FIN


SMDP TDK - LANDING CONFIG FOR BUNDLE 4




TDK WITH 6 PANELS

FS 18-89 EVA/116/FIN

TDK LANDING CONFIG - SIDE VIEW






TDK LANDING CONFIG FOR 5 PANEL DESIGN


FS 18-90 EVA/116/FIN


TDK BOLT OVERVIEW WITH LABELS



FS 18-91 EVA/116/FIN

TDK BOLTS - NOMINAL AND CONTINGENCY






Nominal TDK Release Interface

Hinge Pin Contingency Release


FS 18-92 EVA/116/FIN

SMDP ADAPTER




FS 18-93 EVA/116/FIN

CHRISTMAS TREE



FS 18-94 EVA/116/FIN


CHRISTMAS TREE STOWAGE ON PMA3



FS 18-95 EVA/116/FIN


RUSSIAN PWR RECONFIG

S0/NODE 1 SWINGARM




FS 18-96 EVA/116/FIN

Z1-NODE CONNECTIONS - PRE 12A.1



FS 18-97 EVA/116/FIN


Z1-NODE 1 CONNECTIONS - POST 12A.1



(TRAY NOT DEPLOYED IN PICTURE)


FS 18-98 EVA/116/FIN

FGB/PMA1 H-JUMPER 2/3 CONFIG




FS 18-99 EVA/116/FIN

FGB/PMA1 CONFIG POST H-JUMPER REMOVAL



FS 18-100 EVA/116/FIN

ADJUSTABLE GRAPPLE BAR



FS 18-101 EVA/116/FIN

FHRC




VELCRO FLAPS FOR AGB ATTACH – CLOSED POSN



AGB INSTALL ON FHRC – DOUBLE PIN SIDE (MLI FLAPS ARE VELCROED OPEN)




FHRC ON ESP2 (DOUBLE PIN SIDE)



AGB INSTALL ON FHRC - FRONT VIEW

FS 18-102 EVA/116/FIN

P1 PUMP MODULE WORKSITE OVERVIEW




FS 18-103 EVA/116/FIN

CONTINGENCIES

P1 PM INSTALLED IN TRUSS

ZENITH



NADIR

FS 18-104 EVA/116/FIN


S1 PUMP MODULE WORKSITE OVERVIEW



FS 18-105 EVA/116/FIN

PUMP MODULE AND FSE OVERVIEW

PUMP MODULE ON LAPA (FRAM + LARGE ADAPTER PLATE) LAPA WITH FSE (PM REMOVED)




FS 18-106 EVA/116/FIN

LAPA AND REAR CONTINGENCY PINS


LAPA SHOWING EXTENDED CONTINGENCY PINS

FRAM EXTENDED REAR CONTINGENCY PIN




FS 18-107 EVA/116/FIN

PUMP MODULE WITH FIXED GRAPPLE BAR AND MLI




FS 18-108 EVA/116/FIN

FLUID QD BAIL LEVERS




FS 18-109 EVA/116/FIN


QD CAP TOOLS




1 INCH CAP TOOL



1/2 INCH CAP TOOL




CAP TOOL - PGT INTERFACE



1/4 INCH CAP TOOL


FS 18-110 EVA/116/FIN


1.5-IN FLUID QD SPOOL POSITIONING DEVICE




FS 18-111 EVA/116/FIN

FLUID QD RELEASE TOOLS












FS 18-112 EVA/116/FIN


0.5-IN FLUID QD SPOOL POSITIONING DEVICE






0.5-IN SPD BOOTIE EXTENSION






FS 18-113 EVA/116/FIN


QD VENT TOOLS



FS 18-114 EVA/116/FIN


VENT TOOL EXTENDER BAG






FS 18-115 EVA/116/FIN

VTE AND VTE BAG DETAILS



FS 18-116 EVA/116/FIN


PUMP MODULE NH3 JUMPER



FS 18-117 EVA/116/FIN

STATUS INDICATORS (MBSU, DDCU, BCDU)

H2 Status Indicator




Positional Criteria

(Adhered to in accordance with torque and turns specified in LSAR procedure).

Locked, Nominal: The lock/unlock slot should be centered in relation to the silver mark.




Locked, Tolerance: The lock/un lock slot can be left or right of nominal by a distance no greater than the width of the black stripe.



Unlocked, Nominal: The lock/un lock slot should be centered in relation to the silver mark.




Unlocked, Tolerance: The lock/un lock slot can be left or right of nominal by a distance no greater than the width of the black stripe.



LOG-1010-01


H1 Status Indicator




Positional Criteria

(Adhered to in accordance with torque and turns specified in LSAR procedure.)

Unlocked, Nominal: The unlock slot should be centered in relation to the silver mark.



Unlocked, Tolerance: The unlock slot can be left or right of nominal by a distance no greater than the width of the black stripe.



Locked, Nominal: The right edge of the lock slot should be flush with the right edge of the silver mark.




Locked, Tolerance: The lock slot can be left of nominal by a dis tance no greater than the width of the black stripe.



LOG-1009-01


FS 18-118 EVA/116/FIN

FAILED MBSU LOCATIONS




FS 18-119 EVA/116/FIN

CETA CART LOCATION FOR MBSU R&R




FS 18-120 EVA/116/FIN

SPARE MBSU STOWED ON CETA GRID E WITH PORT TFR SWINGARM DEPLOYED




FS 18-121 EVA/116/FIN


MBSU ORU



MBSU ORU




MBSU with Thermal Cover




MBSU with FRAM

FS 18-122 EVA/116/FIN

MBSU AND COLDPLATE





DDCU LOCATIONS



FS 18-124 EVA/116/FIN

DC-TO-DC CONVERTER UNIT - EXTERNAL






TOP VIEW BOTTOM VIEW


FS 18-125 EVA/116/FIN

SPARE DDCU S0-4B WORKSITE (S0 PORT WEDGE FACE) (EVA 3)



FS 18-126 EVA/116/FIN

FAILED DDCU S1-4B WORKSITE (S1 BAY 15) (EVA 3)




FS 18-127 EVA/116/FIN

FAILED DDCU S0-1A WORKSITE (S0 BAY 01) (EVA 3)




FS 18-128 EVA/116/FIN

SPARE DDCU S0-3B WORKSITE (S0 BAY 04) (EVA 2)




FS 18-129 EVA/116/FIN

FAILED DDCU S0-2B WORKSITE (S0 BAY 02) (EVA 2)




FS 18-130 EVA/116/FIN

FAILED DDCU P1-3A WORKSITE (P1 BAY 16) (EVA 2)




FS 18-131 EVA/116/FIN

P6 OVERVIEW FOR STBD BCDUs




FS 18-132 EVA/116/FIN

P4 2A BCDU WORKSITE OVERVIEW




FS 18-133 EVA/116/FIN


P4 4A BCDU WORKSITE OVERVIEW



FS 18-134 EVA/116/FIN

BCDU






TOP VIEW BOTTOM VIEW


FS 18-135 EVA/116/FIN

P6 2B STBD IEA (UPPER/NON-KEEL SIDE) ORU LABELS




FS 18-136 EVA/116/FIN

P6 4B PORT IEA (LOWER/KEEL SIDE) ORU LABELS




FS 18-137 EVA/116/FIN

P4 4A FWD IEA (UPPER/NON-KEEL SIDE) ORU LABELS




FS 18-138 EVA/116/FIN

P4 2A AFT IEA (LOWER/KEEL SIDE) ORU LABELS




FS 18-139 EVA/116/FIN

4B MANUAL RETRACT - P6 WIF 37




FS 18-140 EVA/116/FIN

SOLAR ARRAY LATCH/TENSION OVERRIDE – LEFT BLANKET BOX




FS 18-141 EVA/116/FIN


SOLAR ARRAY JETTISON OVERVIEW



JETTISON POSITIONS FOR EV1 and EV2








SSU REMOVAL POSITION

FS 18-142 EVA/116/FIN

MAST CANISTER MDA






FS 18-143


EVA/116/FIN


SABB MDA



FS 18-144 EVA/116/FIN

SOLAR ARRAY BLANKET BOX (SABB)






SABB MDA


FS 18-145 EVA/116/FIN

FRAM/FSE/ORU ASSEMBLY



FS 18-146 EVA/116/FIN


ACTIVE FRAM SOFT CAPTURE MECHANISM




SIDE VIEW


FS 18-147 EVA/116/FIN


FRAM CONTINGENCY BOLTS - SAPA





FWD CONTINGENCY BOLT (2)







AFT CONTINGENCY BOLT (2)

FS 18-148 EVA/116/FIN


P5 SOFT CAPTURE ASSY MANUAL OVERRIDE




MRTAS CORNER 1



MRTAS CORNER 2




MRTAS CORNER 3



MRTAS CORNER 4

FS 18-149 EVA/116/FIN


P5 SOFT CAPTURE ASSY MANUAL OVERRIDE (Cont)



FS 18-150 EVA/116/FIN

SMDP ADAPTER FAILED MAGNETIC SOCKET







FS 18-151 EVA/116/FIN

This Page Intentionally Blank

FS 18-152 EVA/116/FIN



EVA CHECKLIST 116