# **EVA Checklist**

# STS-117 Flight Supplement

# Mission Operations Directorate EVA, Robotics, and Crew Systems Operations Division

Final February 26, 2007

#### NOTE

This supplement is to be integrated into the generic edition to provide a complete document for the specific flight. Some pages in the generic edition may be replaced with supplemental pages identified as 'TEMP'. These generic pages, if any, must be retained for use on future flights.

National Aeronautics and Space Administration

Lyndon B. Johnson Space Center Houston, Texas



#### MISSION OPERATIONS DIRECTORATE

#### EVA CHECKLIST STS-117 FLIGHT SUPPLEMENT

FINAL February 26, 2007

PREPARED BY:

bulon C. Scoville Book Manager

APPROVED BY:

Tricia K. Mack

Lead, EVA Systems Group

Randall S. McDaniel

Lead, EVA Task Group

Angela R. Prince

Chief, EVA and Crew Systems Operations Branch

This document is under the configuration control of the Crew Procedures Control Board (CPCB). All proposed changes must be submitted via FDF Workflow Crew Procedure Change Request (CR) to DO3/FDF Manager.

Additional distribution of this book, for official use only, may be requested in writing to DO3/PMO Administrator. The request must include justification and requester's name, organization, position, and phone number. Contractor requests are made through the NASA or DOD organization supported. Deletions, reduction in quantity, or change of address may be submitted to DO3/FDF Management Office, 281-244-1184.

		Incorporates the	e following:	
482#:	EVA FS-0008	EVA FS-0017	EVA FS-0025	EVA FS-0033
	EVA FS-0009	EVA FS-0018	EVA FS-0026	EVA FS-0034
	EVA FS-0010	EVA FS-0019	EVA FS-0027	EVA FS-0035
	EVA FS-0011	EVA FS-0020	EVA FS-0028	EVA FS-0036
	EVA FS-0012	EVA FS-0021	EVA FS-0029	EVA FS-0037
	EVA FS-0013	EVA FS-0022	EVA FS-0030	EVA FS-0038
	EVA FS-0014	EVA FS-0023	EVA FS-0031A	EVA FS-0039
	EVA FS-0015	EVA FS-0024	EVA FS-0032	EVA FS-0040
	EVA FS-0016			

# AREAS OF TECHNICAL RESPONSIBILITY

Book Manager DX35/Z. Scoville 281-483-2701

FS ii EVA/117/FIN

# EVA CHECKLIST STS-117 FLIGHT SUPPLEMENT

# LIST OF EFFECTIVE PAGES

	FINAL	02/26/07	
Sign Off*	117/FIN	3-8	generic
FS ii*	117/FIN	3-9	generic
iii*	generic	CC 3-10	generic
iv*	generic	CC 3-11	generic
FS v*	117/FIN	3-12	generic
FS vi*	117/FIN	4-1	generic
FS vii*	117/FIN	4-2	generic
FS viii*	117/FIN	4-3	generic
FS ix	117/FIN	4-4	generic
FS x	117/FIN	4-5	generic
FS xi	117/FIN	4-6	generic
FS xii	117/FIN	4-7	generic
FS xiii	117/FIN	4-8	generic
FS xiv	117/FIN	4-9	generic
FS xv	117/FIN	4-10	generic
FS xvi	117/FIN	4-11	generic
1-1	generic	4-12	generic
1-2	generic	5-1	generic
1-3	generic	5-2	generic
1-4	generic	5-3	generic
1-5	generic	5-4	generic
1-6	generic	A6-1	generic
1-7	generic	CC A6-2	generic
1-8	generic	6-3	generic
1-9	generic	CC 6-4	generic
1-10	generic	FS 7-1	117/FIN
TEMP FS 2-1	Ĭ17/FIN	FS 7-2	117/FIN
TEMP FS 2-2	ALL/FIN	FS 7-3	117/FIN
2-3	generic	FS 7-4	117/FIN
2-4	generic	FS 7-5	117/FIN
TEMP FS 2-5	117/FIN	FS 7-6	117/FIN
TEMP FS 2-6	ALL/FIN	FS 7-7	117/FIN
FS 2-7	117/FIN	FS 7-8	117/FIN
FS 2-8	117/FIN	FS 7-9	117/FIN
FS 2-9	117/FIN	FS 7-10	117/FIN
FS 2-10	117/FIN	FS 7-11	117/FIN
FS 2-11	117/FIN	FS 7-12	117/FIN
FS 2-12	117/FIN	FS 7-13	117/FIN
FS 2-13	117/FIN	FS 7-14	117/FIN
FS 2-14	117/FIN	FS 7-15	117/FIN
FS 2-15	117/FIN	FS 7-16	117/FIN
FS 2-16	117/FIN	FS 7-17	117/FIN
FS CC 2-17	117/FIN	FS 7-18	117/FIN
FS CC 2-18	117/FIN	FS 7-19	117/FIN
3-1	generic	FS 7-20	117/FIN
3-2	generic	FS 7-21	117/FIN
3-3	generic	FS 7-22	117/FIN
3-4	generic	FS 7-23	117/FIN
3-5	generic	FS 7-24	117/FIN
3-6	generic	FS 7-25	117/FIN
3-7	generic	FS 7-26	117/FIN

<sup>\* –</sup> Omit from flight book

50 <b>7</b> 0 <b>7</b>	4.47/5151	-0 - o4	
FS 7-27	117/FIN	FS 7-81	117/FIN
FS 7-28	117/FIN	FS 7-82	117/FIN
FS 7-29	117/FIN	FS 7-83	117/FIN
FS 7-30	117/FIN	FS 7-84	117/FIN
FS 7-31	117/FIN	FS 7-85	117/FIN
FS 7-32	117/FIN	FS 7-86	
FS 7-33	117/FIN		117/FIN
FS 7-34	117/FIN	FS 7-87	117/FIN
FS CC 7-35	117/FIN	FS 7-88	117/FIN
		FS 7-89	117/FIN
FS CC 7-36	117/FIN	FS 7-90	117/FIN
FS 7-37	117/FIN	FS 7-91	117/FIN
FS 7-38	117/FIN	FS 7-92	117/FIN
FS 7-39	117/FIN	FS 7-93	117/FIN
FS 7-40	117/FIN		
FS 7-41	117/FIN	FS 7-94	117/FIN
FS 7-42	117/FIN	FS 7-95	117/FIN
FS 7-43	117/FIN	FS 7-96	117/FIN
FS 7-44	117/FIN	FS 7-97	117/FIN
		FS 7-98	117/FIN
FS 7-45	117/FIN	FS 7-99	117/FIN
FS 7-46	117/FIN	FS 7-100	117/FIN
FS 7-47	117/FIN	FS 7-101	
FS 7-48	117/FIN		117/FIN
FS 7-49	117/FIN	FS 7-102	117/FIN
FS 7-50	117/FIN	FS 7-103	117/FIN
FS 7-51	117/FIN	FS 7-104	117/FIN
FS 7-52	117/FIN	FS 7-105	117/FIN
		FS 7-106	117/FIN
FS 7-53	117/FIN	FS 7-107	117/FIN
FS 7-54	117/FIN	FS 7-108	117/FIN
FS 7-55	117/FIN	FS 7-109	117/FIN
FS 7-56	117/FIN		
FS 7-57	117/FIN	FS 7-110	117/FIN
FS 7-58	117/FIN	TEMP FS 8-1	117/FIN
FS 7-59	117/FIN	TEMP FS 8-2	117/FIN
FS 7-60	117/FIN	8-3	generic
FS 7-61	117/FIN 117/FIN	8-4	generic
		8-5	generic
FS 7-62	117/FIN	8-6	generic
FS 7-63	117/FIN	FS 8-7	117/FIN
FS 7-64	117/FIN		
FS 7-65	117/FIN	FS 8-8	117/FIN
FS 7-66	117/FIN	FS 8-9	117/FIN
FS 7-67	117/FIN	FS 8-10	117/FIN
FS 7-68	117/FIN	9-1	generic
		9-2	generic
FS 7-69	117/FIN	9-3	generic
FS 7-70	117/FIN	9-4	generic
FS 7-71	117/FIN	9-5	•
FS 7-72	117/FIN		generic
FS 7-73	117/FIN	9-6	generic
FS 7-74	117/FIN	TEMP FS 10-1	117/FIN
FS 7-75	117/FIN	TEMP FS 10-2	ALL/FIN
FS 7-76	117/FIN	10-3	generic
		10-4	generic
FS 7-77	117/FIN	10-4a	generic
FS 7-78	117/FIN	10-4b	generic
FS 7-79	117/FIN	10-5	generic
FS 7-80	117/FIN		•
		10-6	generic

10-7	generic	14-7	generic
10-8	generic	14-8	generic
10-9	generic	14-9	generic
10-10	generic	14-10	generic
10-11	generic	14-11	generic
10-12	•	14-12	•
	generic		generic
FS CC 10-13	117/FIN	14-13	generic
FS CC 10-14	117/FIN	14-14	generic
FS 10-15	117/FIN	14-15	generic
FS 10-16	117/FIN	14-16	generic
11-1	generic	14-17	generic
11-2	generic	14-18	generic
11-3	generic	14-19	generic
11-4	generic	14-20	generic
12-i	generic	14-21	generic
12-ii	generic	14-22	generic
TEMP FS 12-1	117/FIN	15-1	generic
TEMP FS 12-2	ALL/FIN	15-2	generic
12-3	generic	15-3	generic
12-4	generic	15-4	generic
12-5	generic	15-5	generic
12-6	generic	15-6	generic
12-7	generic	15-7	generic
12-8	generic	15-8	generic
12-9	generic	15-9	generic
12-10	generic	15-10	generic
12-11	generic	15-11	generic
12-12	generic	15-12	generic
12-13	generic	15-13	generic
12-14	generic	15-14	generic
12-15	generic	16-i	generic
12-16	generic	16-ii	generic
12-17	generic	TEMP FS 16-1	117/FIN
12-18	generic	TEMP FS 16-2	117/FIN
12-19	generic	FS 16-3	117/FIN
12-20	generic	FS 16-4	117/FIN
12-21	generic	FS 16-5	117/FIN
12-22	generic	FS 16-6	117/FIN
12-23	generic	FS 16-7	117/FIN
12-24	•	FS 16-8	117/FIN
12-25	generic generic	FS 16-9	117/FIN
	•		
12-26	generic	FS 16-10	117/FIN
FS 12-27	117/FIN	FS 16-11	117/FIN
FS 12-28	117/FIN	FS 16-12	117/FIN
FS 12-29	117/FIN	FS 16-13	117/FIN
FS 12-30	117/FIN	FS 16-14	117/FIN
FS 13-1	117/FIN	FS 16-15	117/FIN
FS 13-2	117/FIN	FS 16-16	117/FIN
14-1	generic	FS 16-17	117/FIN
14-2	generic	FS 16-18	117/FIN
14-3	generic	FS 16-19	117/FIN
14-4	generic	FS 16-20	117/FIN
14-5	generic	FS 16-21	117/FIN
14-6	generic	FS 16-22	117/FIN

FS 16-23	117/FIN	FS 16-77	
FS 16-24	117/FIN	FS 16-78	117/FIN
FS 16-25	117/FIN	FS 16-79 FS 16-80 FS 16-81	117/FIN
		FS 16-80	117/FIN
FS 16-26	117/FIN	TO 10-00	117/11IN
FS 16-27	117/FIN	FS 10-01	117/FIN
FS 16-28	117/FIN	FS 16-82	
FS 16-29	117/FIN	FS 16-83	117/FIN
		FS 16-84	
FS 16-30	117/FIN		
FS 16-31	117/FIN	FS 16-85	
FS 16-32	117/FIN	FS 16-86	117/FIN
FS 16-33	117/FIN	FS 16-87	117/FIN
		FS 16-88	117/FIN
FS 16-34	117/FIN	17-1	
FS 16-35	117/FIN		9
FS 16-36	117/FIN	17-2	0
FS 16-37	117/FIN	FS 18-1	117/FIN
		FS 18-2	117/FIN
FS 16-38	117/FIN	FS 18-3	
FS 16-39	117/FIN	FS 18-4	
FS 16-40	117/FIN		
FS 16-41	117/FIN	FS 18-5	
		FS 18-6	117/FIN
FS 16-42	117/FIN	FS 18-7	117/FIN
FS 16-43	117/FIN	FS 18-8	
FS 16-44	117/FIN	FS 18-9	
FS 16-45	117/FIN		
		FS 18-10	
FS 16-46	117/FIN	FS 18-11	
FS 16-47	117/FIN	FS 18-12	
FS 16-48	117/FIN	FS 18-13	117/FIN
FS 16-49	117/FIN	FS 18-14	117/FIN
FS 16-50	117/FIN	FS 18-15	117/FIN
FS 16-51	117/FIN	FS 18-16	117/FIN
		FS 18-17	117/FIN
FS 16-52	117/FIN	FS 18-18	117/FIN
FS 16-53	117/FIN		
FS 16-54	117/FIN	FS 18-19	
FS 16-55	117/FIN	FS 18-20	
FS 16-56	117/FIN	FS 18-21	
		FS 18-22	117/FIN
FS 16-57	117/FIN	FS 18-23	117/FIN
FS 16-58	117/FIN	FS 18-24	117/FIN
FS 16-59	117/FIN		
FS 16-60	117/FIN	19-i	generic
FS 16-61	117/FIN	19-ii	generic
		19-1	generic
FS 16-62	117/FIN	19-2	generic
FS 16-63	117/FIN	19-3	generic
FS 16-64	117/FIN	19-4	generic
FS 16-65	117/FIN	19-5	generic
	117/FIN		
FS 16-66		19-6	generic
FS 16-67	117/FIN	19-7	generic
FS 16-68	117/FIN	19-8	generic
FS 16-69	117/FIN	19-9	generic
FS 16-70	117/FIN	19-10	•
FS 16-71	117/FIN		generic
FS 16-72	117/FIN	19-11	generic
		19-12	generic
FS 16-73	117/FIN	20-1*	generic
FS 16-74	117/FIN	20-2*	generic
FS 16-75	117/FIN		3
FS 16-76	117/FIN		

<sup>\* –</sup> Omit from flight book

# **EVA CUE CARDS**

<u>Title</u>	Ref. Page	Card No.	
EMU SWAP CUE CARD (Front)	FS CC 2-17	EVA-7a/117/O/A	I
LTA RESTRAINT STRAP CUE CARD (Back)	FS CC 2-18	EVA-7b/117/O/A	
SAFER CHECKOUT RESULTS (Front)	CC 3-10	generic	
SAFER STATUS TROUBLESHOOTING (Back)	CC 3-11	generic	
DEPRESS/REPRESS			
Nominal Configuration (Front)	CC A6-2	generic	
FAILED LEAK CHECK			
(Back of DEPRESS/REPRESS)	CC 6-4	generic	
SARJ PREP CUE CARD (Front)		EVA-6a/117/O/B	ĺ
(Back)	FS CC 7-36	EVA-6b/117/O/B	
STS-117 CONSUMABLES TRACKING			
CUE CARD			
STS-117 BATTERY RECHARGE PLAN	FS CC 10-14	EVA-5b/117/O/B	

FS ix EVA/117/FIN

This Page Intentionally Blank

<u>CONTENTS</u>			<u>PAGE</u>
10.2 PSI CABIN			1-1
MASK PREBREATHE INITIATE		••	1-2
PREP FOR 10.2 PSI CABIN			1-3
CABIN DEPRESS TO 10.2 PSI		••	1-4
10.2 PSIA DEPRESS CHART			1-5
10.2 PSI CABIN CONFIG			1-6
MASK PREBREATHE TERMINATE			1-6
10.2 PSI MAINTENANCE			1-7
CABIN REPRESS TO 14.7 PSI			1-8
14.7 PSI CABIN CONFIG			_
AIRLOCK CONFIG			
AIRLOCK PREP			
EMU SWAP			
BOOSTER FAN DEACTIVATION/REMOVAL			
BOOSTER FAN INSTALLATION/ACTIVATION			
EMU REMOVAL			
EMU INSTALLATION			
EMU CHECKOUT PREP			
LTA RESTRAINT STRAP REMOVAL			
LTA RESTRAINT STRAP INSTALLATION			
EVA PREP FOR TRANSFER TO ISS			
POST-DOCKING EVA TRANSFER/RECONFIG			
FR/SW EMU RECONFIGURATION			
POST EVA RECONFIGURATION AND TRANSFER			
EMU SWAP CUE CARD			
LTA RESTRAINT STRAP CUE CARD	FS	CC	2-18
CHECKOUTS			3-1
EMU CHECKOUT			3-1
EMU POWERUP AND COMM CHECK			3-2
PRIMARY REGULATOR/FAN/PUMP CHECK			3-4
SOP CHECK			3- <del>4</del> 3-5
BATTERY CHARGE CHECK INIT			3-6
BATTERY CHARGE CHECK TERM			3-6
EMU SWAP DURING CHECKOUT			3-7
POST EMU C/O RECONFIG			3- <i>7</i>
SAFER CHECKOUT			_
SELF TEST SEQUENCE			
SAFER CHECKOUT RESULTS			
SAFER STATUS TROUBLESHOOTING			
REBA POWERED HARDWARE CHECKOUT			
REDAT OWERED HARDWARE CHECKOOT		••	J-12
EVA PREP			4-1
MIDDECK PREP			4-2
EVA PREP			4-3
PREP FOR DONNING			4-3
EMU DONNING			4-5
EMU CHECK			4-7
EMU PURGE			4-7
EMU PREBREATHE			4-8
SAFER DONNING			4-8
EVA COMM CONFIG			4-10
EVA COMM DECONFIG			4-10
APPROVED NON-FMU HARDWARE MATRIX			4-11

FS xi

EMU STATUSEMU STATUS		
DEPRESS/REPRESS		A6-1
DEPRESS/REPRESS (NOM A/L)		
FAILED LEAK CHECK		
FAILED LEAK CHECK (5 PSI)	С	C 6-4
FAILED LEAK CHECK (14.7/10.2 PSI)		
·		
TIMELINES	F	S 7-1
EVA 1	<b>-</b>	0 7 2
EVA 1 SUMMARY TIMELINE		
PRE EVA 1 TOOL CONFIG		S 7-4
EVA 4 INJURIT DAD (HC)		S 7-5
EVA 1 INHIBIT PAD (HC)		S 7-6
NOTES, CAUTIONS, AND WARNINGS (HC)	Fi	S 7-7 S 7-9
EVA 1 EGRESS/SETUPS1-S3 UTILITY TRAY CONNECT	F	
		S 7-10 S 7-11
SABB RESTRAINT RELEASES4 IEA KEEL PIN ROTATE/TA CLAMP RELEASE/	Г	5 7-11
		C 7 40
S5 RTAS SOFTDOCK ROTATE		S 7-12
PVR RADIATOR CINCHES/WINCHES		S 7-13
SAW BETA GIMBAL RESTRAINT RELEASE		S 7-14
FWD/AFT (1A/3A) SABB UNSTOW		S 7-15
AJIS STRUT RIGIDIZATION		S 7-16
SARJ DLA 2 DEPLOY		S 7-17
SARJ LAUNCH LOCK REMOVAL		S 7-18
EVA 1 CLEANUP/INGRESS		S 7-19
POST EVA 1 TOOL CONFIG		
EVA 1 TASK DATA		S 7-21
SARJ PREP CUE CARD	FS C	C 7-35
EVA 2	_	0 7 07
EVA 2 SUMMARY TIMELINE		S 7-37
PRE EVA 2 TOOL CONFIG		S 7-38
EVA 8 NUMBER DAD (HC)		S 7-39
EVA 2 INHIBIT PAD (HC)	Fi	S 7-40
NOTES, CAUTIONS, AND WARNINGS (HC)	F:	S 7-41
EVA 2 EGRESS/SETUP FOR SOLAR ARRAY		
2B SOLAR ARRAY RETRACT		S 7-44
DEPLOY SARJ BRACES		S 7-46
SARJ DLA 1 INSTALL		S 7-47
SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL		S 7-48
MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE		S 7-49
EVA 2 CLEANUP/INGRESS		S 7-50
POST EVA 2 TOOL CONFIG		S 7-51
EVA 2 TASK DATA	F	S 7-52
EVA 3	_	0 7 00
EVA 3 SUMMARY TIMELINE		S 7-63
PRE EVA 3 TOOL CONFIG		S 7-64
EVA 3 INHIBIT PAD (HC)		S 7-65
NOTES, CAUTIONS, AND WARNINGS (HC)		S 7-67
EVA 3 EGRESS/SETUP2B SOLAR ARRAY RETRACT		S 7-69
		S 7-70
S3 KEEL PIN/DRAG LINK STOW		S 7-72
MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE		
H2O/H2 VENT VALVE CHANGEOUT		S 7-75
LAB EWIS ANTENNA INSTALLATION	⊢;	S /-/6

FS xii

NODE/SM LAN CABLE ROUTING	FS 7-	77
SASA GIMBAL LOCKS	FS 7-	78
GPS ANTENNA #4 REMOVAL		
CP7 ETVCG STANCHION INSTALLATION	FS 7-8	80
S3 LOWER OUTBOARD PAS DEPLOY		
EVA 3 CLEANUP/INGRESS		
POST EVA 3 TOOL CONFIG		
EVA 3 TASK DATA		
TOOLS AND STOWAGE TEM	P FS 8-	1
PGT CHECKOUT		
PGSC-PGT CONNECTION (A31P AND 760XD)	8-4	4
PROGRAM PGT SETTINGS	8-	5
DOWNLOAD/ERASE EVENT LOG	8-	5
PGT CONTINGENCIES	8-6	6
TOOLBOX STOWAGE		
TOOLBOX PANEL AND SLOT LABELS	FS 8-8	8
Z1 TOOLBOX INTERNAL LAYOUT		
AIRLOCK TOOLBOX INTERNAL LAYOUT		
		10
POST EVA	9-	1
POST EVA	9-2	2
SUIT DOFFING	9-2	2
SAFER DOFFING		2
EMU WATER RECHARGE	9-3	3
SAFER STOW		
SUIT DRYING/SEAL WIPE		
OXYGEN RECHARGE VERIFICATION	9-4	
WATER FILL VERIFICATION		
EMU POWERDOWN/OVERNIGHT STOW		
EMU MAINT/RECHARGE TEMP		
WATER RECHARGE TEMP	FS 10-2	2
EMU POWERUP TEMP	FS 10-2	2
WATER FILL TEMP	FS 10-2	2
WATER FILL VERIFICATION TEMP	FS 10-2	2
EMU LIOH CHANGEOUT	10-	4
MIDDECK EMU BATTERY RECHARGE (STAND-ALONE)	10-	4a
MIDDECK EMU BATTERY RECHARGE/LIOH REPLACEMENT		
INITIATE		
TERMINATE		
IN-SUIT EMU BATTERY RECHARGE/CHARGE VERIFICATION		
INITIATE		
TERMINATE		
EMU POWERDOWN	_	
HELMET LIGHT/PGT BATTERY RECHARGE		
INITIATE		
TERMINATE	_	-
REBA BATTERY INSTALLATION		
EMU BATTERY REMOVAL/INSTALL		
HELMET LIGHT BULB CHANGEOUT		
REBA BATTERY RECHARGE		
INITIATE		
TERMINATE	10-	
CIETALIONE CONTRA C	00 10	4 ^
STS-117 CONSUMABLES TRACKING CUE CARD FS STS-117 BATTERY RECHARGE PLAN FS		

POST EVA ENTRY PREP		11-1
POST EVA ENTRY PREP		
SAFER ENTRY STOW		
POST ISS EVA ENTRY PREP		
SAFER ENTRY STOW		
OFF-NOMINAL PROCEDURES		
EMU CONTINGENCY PROCS		
DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART)		
VACUUM H2O RECHARGE (MANNED)		
LIOH REPLACEMENT (MANNED)		12-3
BATTERY REPLACEMENT (MANNED)		12-4
WATER DUMP		12-6
SCU SWAP (UNMANNED)		12-7
SCU SWAP (MANNED)		
EMU COLD RESTART (MANNED)		12-7
12.1 STS EVA DECONTAMINATION		12-8
CONTAMINATION TEST		
SAFER BATTERY CHANGEOUT		
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (IN-SUIT)		
BTA PREP		
BTA TREATMENT		
		12-19
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (POST		40.04
SUIT DOFFING)		
BTA PREP		
BTA TREATMENT		
EMU RESIZE		
STS-117 NOMINAL EMU SIZING		
STS-117/13A EMU CONTINGENCY RESIZE MATRIX	FS	12-29
TPS REPAIR		
TPS REPAIR	FS	13-1
TPS REPAIRORBITER CONTINGENCY EVA	FS	13-1 14-1
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE	FS	13-1 14-1 14-2
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE  RMS/PRLA CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE  RMS/PRLA CONTINGENCY EVA  96 BOLT PRE-EVA TOOL CONFIG	FS	13-1 14-1 14-2 14-3 14-13
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE  RMS/PRLA CONTINGENCY EVA  96 BOLT PRE-EVA TOOL CONFIG  96 BOLT EVA TIMELINE	FS	13-1 14-1 14-2 14-3 14-13 14-14
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE  RMS/PRLA CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21
TPS REPAIR  ORBITER CONTINGENCY EVA  PAYLOAD BAY EVA NOMENCLATURE  RMS/PRLA CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 15-2 15-2 15-2 15-2 15-3 15-3 15-3 15-3 15-3
TPS REPAIR  ORBITER CONTINGENCY EVA PAYLOAD BAY EVA NOMENCLATURE RMS/PRLA CONTINGENCY EVA 96 BOLT PRE-EVA TOOL CONFIG 96 BOLT EVA TIMELINE CAPTURE LATCH MANUAL RELEASE (ODS/PMA) 96 BOLT EVA LAYOUT PLBD LATCH TOOL PLACEMENT WITH DUAL LATCH GANG FAILU  EVA CUFF CHECKLIST (CIL) NORMAL EVA STATUS DCM CONFIGURATION EMU MALFUNCTION INDEX DECOMPRESSION SICKNESS (DCS) DECOMPRESSION SICKNESS (DCS) (CONT) ABORT EVA TERMINATE EVA SUIT P EMERG	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4 15-4
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 14-22 15-1 15-2 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4 15-4 15-4
TPS REPAIR  ORBITER CONTINGENCY EVA	FS	13-1 14-1 14-2 14-3 14-13 14-14 14-19 14-21 15-1 15-2 15-2 15-3 15-3 15-3 15-3 15-4 15-4 15-4 15-5

FS xiv

O2 USE HIGH		15-5
SUBLM PRESS		15-6
H2O GP LOW		15-6
RESRV H2O ON		15-6
H2O WP HIGH		
NO VENT FLOW		
CO2 HIGH OR MONITOR CO2		
CO2 SNSR BAD		
COMM FAILURE		
AIR FLOW CONTAMINATION		
LOSS OF COOLING		
RLF V FAIL		15-8
MISC MSGS 1		
MISC MSGS (CONT)/TIME LF		
AIRLOCK LATCH DISCONNECT		
AIRLOCK INGRESS		15-9
FOLLOWING PAGES NOT IN EV CUFF		
RADIATOR ACTUATOR DISCONNECT		15-9
PLBD DRIVE CUT		
DOOR DRIVE RESTRAINT		15-10
DOOR DRIVE DISCONNECT		
WINCH OPERATIONS		
WINCH OPERATIONS (CONT)		
3-PT TOOL INSTALLATION		15-11
CL LATCH TOOL		
RMS JOINT ALIGN		
MPM STOW/DEPLOY		
RMS TIEDOWN		
RMS FLIGHT RELEASABLE GRAPPLE FIXTURE RELEASE		
PRLA OPEN/CLOSE		
PRLA OPEN/CLOSE (CONT)		
KU ANTENNA STOW		
KU ANTENNA STOW (CONT)		
AIRLOCK EGRESS		15-13
FLIGHT SPECIFIC REFERENCE		16-i
UNSCHEDULED/CONTINGENCY EVA TASKS TEM		
13A WORKAROUNDS CRIBSHEET TEN		
S1-S3 CAPTURE LATCH OVERRIDE		16-13
S1-S3 MBA BOLT OVERRIDE		16-19
S1-S3 SSAS CONTINGENCY BOLT INSTALL		16-23
MANUAL OVERRIDE TO UNLATCH/LATCH (TENSION) SABB	. FS	16-25
MANUAL RELEASE OF SABB RESTRAINT PINS	. FS	16-27
MANUAL OVERRIDE TO EXTEND/RETRACT MAST	. FS	16-30
SABB SPOOL RE-TENSION	. FS	16-33
EVA ASSISTED DEPLOYMENT OF S4 SAW	. FS	16-39
SSRMS JOINT DRIVE		16-42
MANUAL SAW JETTISON	_	16-47
BDCU BACKOUT	_	16-53
REMOVE AND REPLACE DCSU		16-56
REMOVE AND REPLACE PVCU LOWER		16-61
MDM REMOVE AND REPLACE		16-64
CANADIAN REMOTE POWER CONTROL MODULE (CRPCM)		10-0-
REMOVE/REPLACE	EC	16-68

FS xv

EVA/117/FIN

MBSU REMOVE/REPLACE		
REMOVE AND REPLACE PFCS	FS	16-79
GENERIC EVA REFERENCE		17-1
FLIGHT SPECIFIC EVA REFERENCE		
TRUSS SSAS COMPONENTS AT READY-TO-LATCH (RTL) POSITION		18-3
BGA PRIMARY POWER CABLE CLAMPS	_	18-4
RELEASE BETA GIMBAL LAUNCH RESTRAINTS		18-5
FOUR BAR IN LOCKED POSITION		18-6
SABB UNSTOW		18-7
4-BAR STOWED AND DEPLOYED CONFIGURATIONS		18-10
MAST CANISTER MDA		18-11
SARJ DLA EVA BOLT CONFIG		18-12
P4 UPPER ORU AND CABLE BOX NUMBERS	_	18-13
P4 LOWER ORU AND CABLE BOX NUMBERS		18-14
P6 UPPER ORU AND CABLE BOX NUMBERS	FS	18-15
P6 LOWER ORU AND CABLE BOX NUMBERS		18-16
PRD USE FOR 4-BAR DEPLOY		18-17
ESP-2 HANDRAILS AND WIFs – ZENITH		18-18
ESP-2 HANDRAILS AND WIFs – NADIR		
CETA CART – TOP VIEW	FS	18-20
CETA SWINGARM AND WIF MARKINGS		
CETA CART COUPLERS	FS	18-22
STATUS INDICATORS (MBSU, DDCU, BCDU)	FS	18-23
EVA EMERGENCY		10_i
EMERGENCY PROCEDURES		
EMERGENCY AIRLOCK REPRESS		
EMERGENCY AIRLOCK REPRESS		
POST EMERGENCY AIRLOCK REPRESS		
SAFER RESCUE		
SAFER RESCUE		
DAP/EVA RESCUE/RETRIEVE		
EVA ORBITER CONFIG		
EVA RESCUE/RETRIEVE		
19.1 DCS TREATMENT		
CHE CARD CONFICURATION		20.4

# AIRLOCK CONFIG

# **AIRLOCK CONFIG**

AIRLOCK PREP	TEMP FS 2-2
EMU SWAP	2-3
BOOSTER FAN DEACTIVATION/REMOVAL	2-4
BOOSTER FAN INSTALLATION/ACTIVATION	2-4
EMU REMOVAL	
EMU INSTALLATION	2-4
EMU CHECKOUT PREP	TEMP FS 2-5
LTA RESTRAINT STRAP REMOVAL	
LTA RESTRAINT STRAP INSTALLATION	TEMP FS 2-6
EVA PREP FOR TRANSFER TO ISS	
POST-DOCKING EVA TRANSFER/RECONFIG	FS 2-10
FR/SW EMU RECONFIGURATION	FS 2-11
POST EVA RECONFIGURATION AND TRANSFER	FS 2-13
EMU SWAP CUE CARD	FS CC 2-17
I TA RESTRAINT STRAP CHE CARD	FS CC 2-18

#### AIRLOCK PREP (50 min)

Retrieve or unstow following equipment:

MF28G 3/8-in breaker bar, 4-in ext w/3/8-in drive

IFM Tool Kit 1/2-in socket w/3/8-in drive

Vol H EMU Equipment Bag – attach to middeck wall

Helmet Lights EVA Bag

Contamination Detection Kit (location flight specific)

FDF Locker Cuff Checklists (2) – stow in EMU Equipment Bag

DEPRESS/REPRESS Cue Card

1. √Inner hatch Equal vIv (two) – OFF

AW18A

2. LTG FLOOD (four) - ON

3. Remove from airlock, as reqd:

Airlock Stowage Bag

Airlock Floor Pallet using 3/8-in breaker bar, 4-in ext w/3/8-in drive, and

1/2-in socket w/3/8-in drive

4. Stow Vol H Bags in Vol H

5. Transfer to airlock:

EVA Bag – install on airlock wall

**DEPRESS/REPRESS** Cue Card

**Helmet Lights** 

Contamination Detection Kit – install on airlock wall

6. Install IVA foot restraint, as regd

7. Unbuckle SCU straps, Velcro SCU to wall

8. Install EMU lights on helmets (EMU 1,EMU 2)

9. Disconnect helmets from Airlock EMUs, temp stow

10. Remove comm caps from LTA Restraint Bags and connect to electrical harnesses

11. Install helmets (not regd if proceeding directly to EMU Checkout)

12. Remove LTA Restraint Bags

13. Disconnect waist rings; remove and stow any equipment stowed in HUT/LTA

14. Stow LTA Restraint Bags on AAPs

15. √Thermal cover clear of waist ring

16. Waist ring – engage posn

17. Connect LTA to HUT, lock

18. Remove 20-g Crash Bag from middeck EMU, as regd

#### AW18A

- 1. LTG FLOOD (four) ON
- 2. Remove Airlock Stowage Bag from airlock (as reqd)
- 3. Unbuckle SCU straps, Velcro SCU to wall
- 4. Disconnect helmets from airlock EMUs, temp stow
- 5. √DIDB restraint bags installed
- Remove comm caps, s/n 1189 (RY) and s/n 1197 (OL) from LTA restraint bag kangaroo pouches and connect to electrical harnesses (RY backup comm cap s/n 1185 will get stowed in RY ECOK)
- 7. Remove LTA restraint bags
- 8. Disconnect waist rings; remove ECOKs, LCVGs
- 9. Stow RY backup comm cap (s/n 1185) in RY ECOK (LCVGs will be used for EMU Checkout)
- 10. Retrieve mesh bag labeled "EVA SYSTEMS TRANSFER BAG" from RY ECOK; temp stow ECOKs

#### Vol H

11. Unstow:

EMU Servicing Kit (s/n 5004) – (tagged for transfer to ISS) EMU Equipment Bag

- 12. Stow EMU Servicing Kit (s/n 5004) and EMU Equipment Bag Crew Compartments in EVA SYSTEMS TRANSFER BAG
- 13. Stow LTA restraint bags on AAPs
- 14. √Thermal cover clear of waist ring
- 15. Waist ring engage posn
- 16. Connect LTA to HUT, lock

#### LTA RESTRAINT STRAP REMOVAL (15 min)

#### NOTE

May be performed on EMU 1 and 2 simultaneously. Perform steps as reqd for current EMU config


- 1. As reqd, remove comm cap from LTA Restraint Bag; temp stow
- 2. Remove EMU from AAP
- 3. Disconnect all restraint attachments from SAFER mount brackets (two)
- 4. Loosen cinch strap mechanism, remove SAFER mount brackets
- 5. Remove strap from PLSS
- 6. Stow strap in LTA Restraint Bag Pouch with D-rings (three) connected
- 7. Engage EMU in AAP
- 8. Stow LTA Restraint Bag/strap

#### LTA RESTRAINT STRAP INSTALLATION (15 min)

#### **NOTE**

May be performed on EMU 1 and 2 simultaneously. Perform steps as reqd for current EMU config. Procedure written to install in Launch/Landing config shown below

- 1. Unstow LTA Restraint Bag/strap
- 2. Remove EMU from AAP
- 3. Install SAFER mount brackets (two)
- 4. Install elastic band of strap around SOP
- 5. Tighten cinch strap mechanism
- 6. Attach strap French hooks (two) to SAFER mount brackets
- 7. Engage EMU in AAP
- 8. Stow LTA, suit arms inside LTA Restraint Bag
- 9. Connect upper spring hooks (two) over suit shoulders to upper AAP attachment rings (two)
- 10. Connect lower spring hooks (two) around suit arms to SAFER mount brackets (two)
- 11. Tighten all LTA bag straps with bag as high as possible on EMU



French hooks should be attached to SAFER mount brackets for launch and landing

EVA/ALL/FIN

	ı
	ı
	ı

EMU PACK-UP (45 min)

BOTH EMUs 1. √PWR – SCU

DCM 2. √DCM PURGE vlv – op (up)

3. √WATER – OFF, switch guard installed

4. √O2 ACT – OFF

5. √Helmet sun visors down, cover installed

6. Retrieve EVA SYSTEMS TRANSFER BAG (was temp stowed earlier)

7. Configure/verify items stowed in the table below

EMU 3010 (L)(RY)  ☐ Helmet s/n 1072 (with cover)  ☐ Valsalva  ☐ Wrist Mirror (2)  ☐ CCA (s/n 1189)  ☐ RY1 Gloves (s/n 6073)  ☐ EMU Battery (s/n 2077)  ☐ LiOH Cartridge (s/n 2028)  ☐ LTA (RY)  ☐ LTA Restraint Strap and Bag	EMU 3004 (L) (OL)  ☐ Helmet s/n 1068 (with cover) ☐ Valsalva ☐ Wrist Mirror (2) ☐ CCA (s/n 1197) ☐ OL1 Gloves (s/n 6138) ☐ EMU Battery (s/n 2038) ☐ LiOH Cartridge (s/n 2030) ☐ LTA (OL) ☐ LTA Restraint Strap and Bag
EMU Crew Option Kit (RY)  □ ECOK Mesh Bag □ LCVG w/biomed (RY1) (s/n 3182) □ RY EVA #1 Ziplock Bag □ 2 MAGs □ TCUs (top, bottom) □ Thermal Socks □ Sock Liners □ Comfort Gloves □ Wristlets □ Glasses Retention Device □ Croakie □ 2 Ziplock Bags □ Mole Skin □ Mosite □ RY EVA #3 Ziplock Bag (same as RY EVA #1 plus crew patch) □ RY Contingency Ziplock Bag □ 3 MAGs □ Sock Liners □ 2 Ziplock Bags □ Moleskin □ Mosite □ Back-up CCA (comm cap) s/n 1185	EMU Crew Option Kit (OL)  □ ECOK Mesh Bag □ LCVG w/biomed (OL1) (s/n 3206) □ OL EVA #1 Ziplock Bag □ 2 MAGs □ TCUs (top, bottom) □ Thermal Socks □ Comfort Gloves □ Wristlets □ 2 Ziplock Bags □ OL EVA #3 Ziplock Bag (same as OL EVA #1 plus crew patch) □ OL Contingency Ziplock Bag □ 3 MAGs □ 2 Ziplock Bags

# EVA PREP FOR TRANSFER TO ISS (90 min) (Cont)

EMU Crew Option Kit (FR)	EMU Crew Option Kit (SW)
☐ ECOK Mesh Bag	☐ ECOK Mesh Bag
☐ FR EVA #2 Ziplock Bag	☐ SW EVA #2 Ziplock Bag
□ 2 MAGs	□ 2 MAGs
☐ TCUs (top, bottom)	☐ TCUs (top, bottom)
□ Comfort Gloves, Thick	☐ Comfort Gloves, Thick
☐ Comfort Gloves, Thin ☐ Wristlets ☐ Sock Liners ☐ Modified Croakie ☐ 2 Ziplock Bags ☐ Moleskin ☐ Mosite ☐ EV-3 Crew ID stripes ☐ Mission patch and flag ☐ FR EVA #4 Ziplock Bag (same as FR EVA #2, no stripes, no flag)	☐ Comfort Gloves, Thin ☐ Wristlets ☐ Tube Socks ☐ Glasses Retension Device ☐ 2 Ziplock Bags ☐ EV-4 Crew ID stripes ☐ Mission patch and flag ☐ SW EVA #4 Ziplock Bag (same as SW EVA #2, no stripes, no flag) ☐ SW Spares Bag ☐ Crew Prefs Bag
☐ FR Spares Bag	

- Stow LTA, suit arms inside LTA Restraint Bag
   Connect upper spring hooks (two) over suit shoulders to upper AAP attachment rings (two)
   Connect lower spring hooks (two) around suit arms to SAFER mount brackets (two)
   Tighten all LTA bag straps with bag as high as possible on EMU
   Gather items and pack EVA Systems Transfer Bag per table below

2. Gather Remo and pack EVA Cyclems Transfer Bag per table below		
EVA SYSTEMS TRANSFER BAG  Vol H – Previously gathered  □ EMU Servicing Kit (S/N 5004, For Xfer to ISS)  □ EMU Equipment Bag Crew Compartments		
External Airlock Floor Bag  □ 8 DIDBs  □ Small Shuttle Trash Bag (2) (s/n 1003, 1010)  □ 5/8 (rigid) Socket-7.8 ext (s/n 1009)  □ Spare 85-ft safety tether (s/n 1001)		
Drug Subpack (MF28H)  ☐ Aspirin  Middeck Locker (MA16G)  ☐ CSA-O2 Monitor (2) (s/n 1056, 1059)		
FDF/SODF Shared Locker (MF57K)  □ Ziplock bag labeled "EVA Procedures/Cue Cards"  Verify contents:  □ STS-117 Consumables Tracking Cue Card (1 of 1)  □ STS-117 EMU Swap Cue Card (1 of 1)  □ STS EVA Checklist (1 of 3)  □ ISS EVA Systems Checklists (2 of 2)  □ Ziplock bag labeled "ISS EVA Cuff Checklists"  □ STS-117 ISS EVA Cuff Checklists (4 of 4)		
Crew Personal Notes ☐ Crew personal items to be in airlock for campout		
WCS  ☐ Towels ☐ Hygiene Items		

FS 2-8 EVA/117/FIN

# EVA PREP FOR TRANSFER TO ISS (90 min) (Cont)

13. Verify contents of External Airlock Floor Bag per table below

EXTERNAL AIRLOCK FLOOR BAG			
☐ 3 LiOH Cartridges (CCC) (s/n 2015, 2017, 2031)			
☐ FR EMU Crew Options Kit (ECOK)			
☐ FR1 LCVG w/biomed			
☐ FR1 CCA (s/n 1065)			
☐ FR1 prime gloves			
☐ SW EMU Crew Options Kit (ECOK)			
☐ SW1 LCVG w/biomed (s/n 3154)			
☐ SW1 CCA (s/n 1023)			
☐ SW1 prime gloves			
☐ EMU Lower Arms – SW back-up (s/n 319/320)			
☐ EMU Batteries (s/n 2039, 2040)			
☐ Compound Cutters/Needle Nose Pliers Caddy (w/Kapton Tape) (s/n 101)			
☐ Velcro/Tape Caddy (s/n 1007)			
☐ Wire Tie Caddy (s/n 1001)			
☐ Loop Pin Puller Caddy (w/Kapton Tape) (s/n 101)			
☐ EVA Punch Tool (s/n 1001)			
☐ SLR Torque Multiplier (s/n xxxx) – transfer here from MF710			

14. Report to MCC-H when complete with EVA Prep for Transfer to ISS

FS 2-9 EVA/117/FIN

# POST-DOCKING EVA TRANSFER/RECONFIG (60 min)

#### **NOTE**

This procedure assumes that transfer items were reconfigured per EVA PREP FOR TRANSFER TO ISS procedure

# EMU/TOOL TRANSFER TO ISS (15 min)

1. Transfer following EMU equipment to ISS per table:

Item	Destination	Transfer Status
STS-117 EVA Hardware		
EMU 3010 (RY)	E-Lk aft EDDA	
EMU 3004 (OL)	E-Lk fwd EDDA	
EVA Systems Transfer Bag	E-Lk	
External Airlock Floor Bag	E-Lk	

CAUTION

Do NOT install METOX in the Airlock CO2

Removal Box at this point in the timeline

2. Report transfer status to MCC-H

EVA Sys Transfer Bag	3.	Unstow the following items and position in E-Lk for Campout:  ☐ STS-117 Consumables Tracking Cue Card  ☐ STS-117 ISS EVA Checklist  ☐ CSA-O2 Monitors (2)
M02 Dog		☐ Crew Preference and Hygiene Items
M02 Bag		□ 2.0 CTB s/n 1060 (Regenerated Metox)
∃-Lk	4.	Locate the EV1/3 and EV2/4 bags and verify each bag contains the items in the list below
EV1/3 Bag,		☐ Helmet Light Batteries (4)
EV2/4 Bag		☐ PGT Battery (1) – loose in bag or with PGTs
		□ REBA Battery (1)
		☐ Old ISS EMU Servicing Kit (in bag or attached to E-Lk wall)

5. Perform EVA 1 Tool Config as time permits

FS 2-10 EVA/117/FIN

#### EMU 3018 RECONFIG FOR FORRESTER (15 min)

#### NOTE

Reconfig can be performed as late as FD5. Steps 1-14 and steps 15-28 can be performed in parallel

- 1. Install EMU (s/n 3018, M, FR) in EDDA, as regd to assist with config
- 2. Attach FR1 gloves, lock
- 3. Install ISS EVA Cuff Checklist, √wrist mirrors installed
- 4. Install STS-117 mission patch, EV3 (broken) ID stripes, USA flag
- 5. Verify cam configurations per EMU NOMINAL SIZING (STS-117/13A) (EMU CONT PROCS)
- 6. Rotate EDDA open, as regd
- 7. Unzip PLSS thermal cover and Velcro to top
- 8. Verify METOX canister installed per <u>STS-117 CONSUMABLES TRACKING</u> <u>CUE CARD</u>
- 9. Install EMU battery from External Airlock Floor Bag per <u>STS-117</u> CONSUMABLES TRACKING CUE CARD
- 10. √REBA installed per STS-117 CONSUMABLES TRACKING CUE CARD
- 11. Verify REBA connected to power harness with pull test
- 12. √All latches locked, zip thermal cover closed
- 13. Install/replace valsalva (as regd)
- 14. Reconfig ISS EMU Equipment Bag crew compartment (1 of 2) with items from FR ECOK:

Comfort Gloves	☐ FR1 CCA
Wristlets	

#### EMU 3006 RECONFIG FOR SWANSON (15 min)

- 15. Install EMU (s/n 3006, L, SW) in EDDA, as reqd to assist with config
- 16. Attach SW1 gloves, lock
- 17. Install ISS EVA Cuff Checklist, √wrist mirrors installed
- 18. Install STS-117 mission patch, EV4 (bp) ID stripes, USA flag
- 19. Verify cam configurations per EMU NOMINAL SIZING (STS-117/13A) (EMU CONT PROCS)
- 20. Rotate EDDA open, as regd
- 21. Unzip PLSS thermal cover and Velcro to top
- 22. Verify METOX canister installed per <u>STS-117 CONSUMABLES TRACKING</u> CUE CARD
- 23. Install EMU battery from External Airlock Floor Bag per <u>STS-117</u> CONSUMABLES TRACKING CUE CARD
- 24. √REBA installed per STS-117 CONSUMABLES TRACKING CUE CARD
- 25. Verify REBA connected to power harness with a pull test
- 26. √All latches locked, zip thermal cover closed
- 27. Install/replace valsalva (as regd)
- 28. Reconfig ISS EMU Equipment Bag crew compartment (1 of 2) with items from SW ECOK:

Comfort Gloves	□ SW1	CCA
Wristlets		

#### FR/SW EMU RECONFIGURATION (40 min) (Cont)

#### FR/SW HEATED GLOVE CHECKOUT (10 min)

#### **NOTE**

The heated glove checkout can be performed serially or in parallel for both EMU 3018 and 3006

EMU 3018, 29. √REBA sw (1 per EMU) – OFF (toward left arm of suit)

EMU 3006 30. √Upper arm connections mated

- 31. √Glove heater sw (one per glove) OFF
- 32. Connect lower arm pwr harness to gloves

#### **NOTE**

To avoid excessive battery consumption and heat buildup, deactivate heaters once heat detected at fingertips

- 33. REBA sw (1 per EMU) ON, pull tab toward right arm of suit
- 34. Glove heater sw (one per glove) ON When heat detected on all outside fingertips:
  - 35. Glove heater sw (one per glove) OFF
  - 36. REBA sw (1 per EMU) OFF, pull tab toward left arm of suit
  - 37. Disconnect lower arm pwr harness from gloves
  - 38. Stow lower arm and glove pwr harness connectors under TMG
  - 39. As comm permits, report completion of EMU reconfig to MCC-H

#### ı

#### EMU RECONFIGURATION FOR TRANSFER

1. Unstow EMU batteries s/n 2031 and s/n 2036 from EMU Temp Stow Bag Node 2. Unzip thermal cover for EMUs 3010 (RY), 3004 (OL) **PLSS** 3. √Expended LiOH (s/n 2015, 2017) installed 4. √sw POWER – SCU DCM EMU 3010 5. Remove used EMU batteries (s/n 2077, 2038) from EMUs 3010 and 3004; stow in 0.5 CTB labeled EMU Batteries in M-02 bag (s/n 1038) EMU 3004 6. Install EMU battery s/n 2031 in EMU 3010, and EMU battery s/n 2036 in EMU 3004 7. Engage latch 8. √sw (pulltab) REBA – OFF 9. Disconnect EMU Power Harness (P1) from REBA (J1) 10. Remove REBAs from EMUs 3010 and 3004 11. Install REBA J1 fabric cover 12. Stow REBAs in M-02 bag (s/n 1038) PLSS 13. Close thermal cover zipper on EMUs 3010 and 3004 14. Remove helmet lights and EMU TV from EMUs 3010 and 3004; temp stow 15. Remove Cuff Checklists, stow in EVA Systems Transfer Bag 16. √No tools or tethers installed on EMU 3010 or EMU 3004 17. Remove LTA Restraint Straps and Restraint Bags from RY and OL ECOKs 18. On EMUs 3010 and 3004, remove helmet, disconnect CCA from electrical harness, connect helmet to HUT, lock, install helmet cover 19. Remove CCA (comm cap) from RY ECOK 20. Retrieve OL back-up CCA (s/n 1177) EMU Temp Stow Bag Node 21. Stow prime and backup RY CCAs in RY LTA Restraint Bag kangaroo pouch, and prime and backup OL CCAs in OL LTA Restraint Bag kangaroo pouch (can be performed after LTA Restraint Bag installation if desired) 22. Verify RY and OL ECOKs contain, at most, items listed in Table 1 (some items may be in clothes hamper)

EMU Crew Options Kit (RY)	EMU Crew Options Kit (OL)
☐ ECOK Mesh Bag	☐ ECOK Mesh Bag
☐ LCVG w/biomed (RY1) (s/n 3182)	☐ LCVG w/biomed (OL1) (s/n 3206)
☐ RY EVA #1 Ziplock Bag	☐ OL EVA #1 Ziplock Bag
☐ Glasses Retention Device	☐ 2 Ziplock Bags
☐ 2 Ziplock Bags	☐ OL EVA #3 Ziplock Bag (same as
☐ RY EVA #3 Ziplock Bag (same as	OL EVA #1)
RY EVA #1)	□ OL Contingency Ziplock Bag
☐ RY Contingency Ziplock Bag	□ 3 MAGs
☐ 3 MAGs	☐ 2 Ziplock Bags
☐ Sock Liners	☐ EV Crew ID tags
☐ 2 Ziplock Bags	
☐ Moleskin	
☐ Mosite	
☐ EV Crew ID tags	

Table 1. RY and OL ECOK Contents

- 23. On EMUs 3010 and 3004, disconnect LTAs
- 24. Stow RY ECOK in EMU 3010 and OL ECOK in EMU 3004

# POST EVA RECONFIGURATION AND TRANSFER (120 min) (Cont)

25. Connect LTAs to HUTs, and verify final configuration of both EMUs per lists below:

EMU 3010 (L) FINAL RETURN CONFIG	EMU 3004 (L) FINAL RETURN CONFIG		
□ EMU 3010 – L	□ EMU 3004 – L		
☐ EMU Battery 2031	☐ EMU Battery 2036		
☐ LiOH s/n 2015	☐ LiOH s/n 2017		
☐ Gloves (RY1)	☐ Gloves (OL1)		
☐ Mesh Bag (ECOK) (RY)	☐ Mesh Bag (ECOK) (OL)		
□ LCVG (RY1)	□ LCVG (OL1)		
□ LTA (RY)	☐ LTA (OL)		
☐ Patches, Stripes, Flag ☐ Wrist Mirrors (2)	☐ Patches, Stripes, Flag ☐ Wrist Mirrors (2)		
☐ Helmet (S/N 1072)	☐ Helmet (S/N 1068)		
☐ Helmet cover installed	☐ Helmet cover installed		
□ O2 ACT – OFF	□ O2 ACT – OFF		
□ PWR – SCU	□ PWR – SCU		
☐ DCM Purge vlv – Op (up)	☐ DCM Purge vlv – Op (up)		
□ WATER – OFF	☐ WATER – OFF		
☐ WATER Switch Guard installed	☐ WATER Switch Guard installed		
□ No Tethers/Tools	□ <u>No</u> Tethers/Tools		
□ No EMU TV, Helmet Lights or REBA	□ No EMU TV, Helmet Lights or REBA		
<ul> <li>Install LTA Restraint Strap and Restraint Bag on EMUs 3010 and EMU 3004.         Reference LTA Restraint Strap Installation (<u>LTA RESTRAINT STRAP CUE CARD</u>) for diagrams as needed</li> <li>Remove EMUs from EDDAs and temp stow EMU 3010 and EMU 3004 in Nod (will be transferred to shuttle middeck at the end of this procedure)</li> </ul>			
FR AND SW EMU CONFIG FOR UNDOCK			
EMU 3006,			
EMU 3018			
28. Install EMUs 3006 and 3018 in			
	oth EMU 3006 and 3018; stow in External		
Airlock Floor Bag for return to ☐ EMU Gloves	Shuttle:		
☐ CCA (comm cap)			
☐ Mission Patch, Flag, EV	Crew Identifier Stripes		
<u>—</u>	om EMU 3006 and EMU 3018; stow in		
EVA Systems Transfer Bag			
31. Remove boots from EMU 3018	· /·		
(s/n 118/119); re-attach boots,	, lock		
32. Connect rings together, lock	to mouse from FMII Town Otom Down to		
	ve pouch from EMU Temp Stow Bag; stow rings Shuttle External Airlock Floor Bag		

# POST EVA RECONFIGURATION AND TRANSFER (120 min) (Cont)

# EMU SYSTEMS TRANSFER BAG RECONFIGURATION FOR TRANSFER

34. Swap or transfer following hardware per Table 2 below:

ITEM	ITEM	CURRENT LOCATION	DESTINATION	STATUS
1	1 pr EMU Lower Arms (s/n 319/320)	External A/L Floor Bag	EMU Soft Goods M-02 bag (s/n 1010)	
2a	EMU Servicing Kit (s/n 5004, Xfer to ISS)	EVA Systems Transfer Bag	EVA Prep and Ops M-02 bag (s/n 1038)	
2b	EMU Servicing Kit (s/n 5002)	E-Lk Wall or EVA Prep and Ops M-02 bag (s/n 1038)	EVA Systems Transfer Bag	
3a	Velcro/Tape Caddy (s/n 1007)	External A/L Floor Bag	Crewlock Staging Bag	
3b	Velcro/Tape Caddy (s/n 1019)	Crewlock Staging Bag	External Airlock Floor Bag	
4	5/8 (rigid) Socket – 7.8-in ext (s/n 1009)	Crewlock Bag #1	Leave in Crewlock Bag #1 for ISS unstow	
5	EVA Punch Tool (s/n 1001)	External A/L Floor Bag	Mesh Bag: IV Tools	
6	CSA-O2 (2) (s/n 1056, 1059)	E-Lk Wall	Leave on E-Lk Wall	

Table 2. EVA Systems Transfer Items

35. Configure/verify final contents of EVA Systems Transfer Bags per Table 3 below. Report any additional or missing hardware to MCC

EVA SYSTEMS TRANSFER BAG
☐ Aspirin (if any left over after EVAs)
☐ <u>STS-117 CONSUMABLES TRACKING CUE CARD</u>
☐ 1 STS-117 EVA Checklist
☐ 2 ISS EVA Systems Checklists (STS-117 copies)
☐ 4 STS-117 ISS Cuff Checklists
☐ 1 SYS-117 EMU Swap Cue Card
☐ STS EMU Equipment Bag Crew Compartments (2)
☐ EMU Servicing Kit (s/n 5002)
☐ Towels (brought over from WCS)
T     0   E     0   E     0   E     0   E

Table 3. EVA Systems Transfer Bag Final Configuration

# POST EVA RECONFIGURATION AND TRANSFER (120 min) (Cont)

36. Configure/verify final contents of External Airlock Floor Bag per Table 4 below. Report any additional or missing hardware to MCC

EXTERNAL AIRLOOK FLOOR RAG
EXTERNAL AIRLOCK FLOOR BAG
☐ 3 LiOH Cartridges (CCC) (s/n 2028, 2030, 2031)
□ FR ECOK
☐ FR1 LCVG w/biomed
☐ FR1 CCA (s/n 1169)
☐ FR1 prime gloves
□ SW ECOK
☐ SW1 LCVG w/biomed (s/n 3154)
☐ SW1 CCA (s/n 1168)
☐ SW1 prime gloves
☐ Small Shuttle Trash Bag (2) (s/n 1003, 1010)
☐ SLR Torque Multiplier (s/n xxxx)
☐ Compound Cutters/Needle Nose Pliers Caddy (w/Kapton Tape) (s/n 101)
☐ Loop Pin Puller (w/Kapton Tape) and caddy (s/n 101)
☐ Wire Tie Caddy (s/n 1001)
☐ Spare 85 ft safety tether (s/n 1001)
☐ EMU 0.5" leg sizing rings (sn 118/119) in protective pouch
☐ EMU Batteries (s/n 2059, 2060) – Returning ISS batteries via Transfer List
□ Velcro/Tape caddy (s/n 1019) – Returning ISS caddy
The state of the s

Table 4. External Airlock Floor Bag Return Configuration

#### **TRANSFER AND STOW**

37. Transfer the items in Table 5 to Shuttle

Item	Destination	Transfer Status
EMU 3010 (L) with ECOK	Temp stow Middeck	
EMU 3004 (L) with ECOK	Temp stow Middeck	
EVA Systems Transfer Bag	Temp stow Middeck	
EVA Laundry Bag	Temp stow Middeck	
External Airlock Floor Bag	External Airlock	

Table 5. Transfer to Shuttle

#### **EVA UNPACK AND STOW** (15 min)

38. Unpack and stow items from EVA Systems Transfer Bag per Table 6 below; report status to MCC when complete:

<b>Current Location</b>	Item	Final Stowage Location	Status
EVA Systems	Aspirin	Drug subpack (MF28H)	
Transfer Bag			
_	STS-117 Consumables Tracking	FDF/SODF Locker (MF57K)	
	Cue Card		
_	STS EVA Checklists (1)	FDF/SODF Locker (MF57K)	
_	ISS EVA Systems Checklists (2)	FDF/SODF Locker (MF57K)	
	STS-117 EMU Swap Cue Card	FDF/SODF Locker (MF57K)	
_	4 STS-117 ISS Cuff Checklists	FDF/SODF Locker (MF57K)	
_	Towels (as required)	Crew pref	
_	EMU Servicing Kit (s/n 5002)	Volume H Inboard	
_	EMU Equipment Bag Crew	Volume H Outboard	
	Compartments		
-	Empty Systems Transfer Bag	FR ECOK in Ext A/L FIr Bag	

Table 6. EVA Systems Transfer Bag Unpack and Stow

TOP

HOOK VELCRO

# **EMU SWAP CUE CARD**

Outgoing		
EMUs	□ □ √O2 ACT – OFF	
	□□□√WATER – OFF	
	□□□√PWR – SCU	
	Remove EMUs from EDDAs	
	Stow EMU Equipment Bag Crew Compartments in ECOKs	
	Stow EMUs and ECOKs in Node, bundle as reqd	
Incoming	☐ ☐ ☐ Install EMUs in EDDAs	
EMUs	□ □ □ Swap Helmet Lights/WVS assembly onto helmets	
	Remove helmet, verify CCA connected to electrical harness	
	☐ ☐ ☐ Install/replace valsalva (as reqd)	
	☐ ☐ √Cuff checklist, wrist mirrors installed	
	□ □ □ √O2 ACT – OFF	
	□□□√WATER – OFF	
	□□□√PWR – SCU	
	Stow ECOKs in E-Lk	
	☐☐☐☐ Configure EMU Equipment Bag Crew Compartments as reqd	
	EVA-7a/117/O/A	
_	$\dashv$	L
		4

# TOP Back of 'EMU SWAP CUE CARD'

HOOK VELCRO

# LTA RESTRAINT STRAP CUE CARD

Perform following on EMU 3010 and EMU 3004 to install LTA Restraint Strap and Stowage Bag. Reference LTA RESTRAINT STRAP INSTALLATION for diagrams as needed:

	LTA Restraint Bag attached to LTA Restraint Strap D-rings (three) Remove EMU from EDDA, as regd
	Connect LTA Restraint Strap SAFER mount brackets (two) to SAFER striker
П	plate on PLSS Install elastic band of LTA Restraint Strap around SOP
Ħ	Tighten cinch strap mechanism
Ш	Engage EMU in EDDA as reqd to restrain EMU (will be pulled off of EDDA for transfer at end of procedure)
	Stow LTA and suit arms inside LTA Stowage Bag Connect upper spring hooks (two) to SAFER mount brackets (two) such
Ш	that strap runs over shoulder
	Connect lower spring hooks (two) to SAFER mount brackets (two) Tighten all LTA Stowage Bag Straps with bag as high as possible on EMU
	EVA-7b/117/O/A

# **TIMELINES**

A 1		
	FS	7-3
PRE EVA 1 TOOL CONFIG	FS	7-4
	FS	7-5
	FS	7-6
	_	7-7
	_	7-9
		7-10
		7-10
S4 IEA KEEL PIN ROTATE/TA CLAMP RELEASE/	го	7-11
OF DIA COOFTDOOK DOTATE		7 40
S5 RTAS SOFTDOCK ROTATE		
PVR RADIATOR CINCHES/WINCHES	-	7-13
SAW BETA GIMBAL RESTRAINT RELEASE		7-14
		7-15
	_	7-16
	FS	7-17
	FS	7-18
EVA 1 CLEANUP/INGRESS	FS	7-19
	FS	7-20
EVA 1 TASK DATA	FS	7-21
SARJ PREP CUE CARD FS		
A 2	-	
EVA 2 SUMMARY TIMELINE	EQ	7-37
PRE EVA 2 TOOL CONFIG		7-38
FRE EVA 2 TOOL CONFIG		7-39
EVA BRIEFING CARD		
EVA 2 INHIBIT PAD	_	7-40
NOTES, CAUTIONS, AND WARNINGS	_	7-41
EVA 2 EGRESS/SETUP FOR SOLAR ARRAY	_	7-43
2B SOLAR ARRAY RETRACT	_	7-44
DEPLOY SARJ BRACES		7-46
SARJ DLA 1 INSTALL		7-47
	FS	7-48
	FS	7-49
EVA 2 CLEANUP/INGRESS	FS	7-50
	FS	7-51
EVA 2 TASK DATA	FS	7-52
A 3	. •	
	FS	7-63
PRE EVA 3 TOOL CONFIG		
EVA 3 INHIBIT PAD		
NOTES, CAUTIONS, AND WARNINGS		
EVA 3 EGRESS/SETUP	LO	7-09
2B SOLAR ARRAY RETRACT		
S3 KEEL PIN/DRAG LINK STOW		
MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE	FS	7-73
H2O/H2 VENT VALVE CHANGEOUT		
LAB EWIS ANTENNA INSTALLATION	FS	7-76
NODE/SM LAN CABLE ROUTING		
SASA GIMBAL LOCKS		
GPS ANTENNA #4 REMOVAL	FS	7-79
CP7 ETVCG STANCHION INSTALLATION	FS	7-80
S3 LOWER OUTBOARD PAS DEPLOY		
EVA 3 CLEANUP/INGRESS		
POST EVA 3 TOOL CONFIG		
EVA 3 TASK DATA		

This Page Intentionally Blank

# **EVA 1 SUMMARY TIMELINE**

TIME	IV	EV1	EV2	
HR : MIN		(RY)	(OL)	
00:00		POST DEPRESS (00:10)	POST DEPRESS (00:10)	00:00
		EGRESS/SETUP (00:15)	EGRESS/SETUP (00:35)	
-		Relocate CETA APFR to S3-04	Translation adaptation	
	MCC: Verify Nadir Tray Utilities Inhibited; IV – Go	S1 – S3 NADIR UTILITY TRAY CONNECT (00:30)	1	
	to connect Nadir Tray	<u> </u>	Relocate CETA APFR to S4-15	
-	•		AFT/FWD (3A/1A) SABB RESTRAINT RELEASE (02:00)	
	IV: Notify MCC, Nadir Tray complete	Notify IV: Nadir Tray connected		
01:00	MCC: Perform Nadir Tray Utilities powerup	APFR RECONFIG, ORU BAG CONFIG, AND MDM SHROUD (00:35) • Relocate APFR from S3-04 to S3-01		01:00
_		Config ORU Bag over AJIS interface		
	MCC: Verify MDM activated; IV – GO to remove	Keel Pin Nut Clamp Bolts		
	MCC: Verify Zenith Tray Utilities inhibited; IV – GO	On IV GO: MDM shroud Removal and Jettison		
	to connect Zenith Tray	S1 – S3 ZENITH UTILITY TRAY CONNECT (00:30)	Relocate APFR from S4-15 to S4-13	
-				-
02:00	IV: Notify MCC, Zenith Tray complete	Notify IV: Zenith Tray connected		02:00
02.00	MCC: Perform Zenith Tray Utilities powerup	APFR RECONFIG, KEEL PIN ROTATE (00:30)	-	02.00
_		• Relocate APFR from S3-01 to S4-04		-
		Rotate IEA Keel Pin		
		Release TA Clamps	Relocate APFR from S4-13 to S3-28	
		1A/3A SAW BETA GIMBAL RESTRAINT RELEASE (00:40)	• Release TA Clamps	_
-			PVR RADIATOR CINCHES/WINCHES (00:30)	
03:00				03:00
-		FWD (1A) SABB UNSTOW (00:20)	AFT (3A) SABB UNSTOW (00:20)	-
	MCC: Verify 1A/3A SSU/ECU Activated; IV – Go	• Engage TA clamps	• Engage TA clamps	
	to Remove/Jettison	SARJ DLA 2 INSTALL (01:00)	FWD/AFT (1A/3A) ECU/SSU MLI REMOVAL AND JETTISON (00:30)	=
_	MCC: Verify DLA 2 commanding; IV – GO to Deploy	• On IV GO: Install DLA 2	• On IV GO: Remove AFT (3A) SSU/ECU MLI	_
	DLA 2		Remove FWD (1A) SSU/ECÚ MLI	
04:00			AJIS STRUT RIGIDIZATION (1-4) (00:40)	04:00
-				-
	IV: Notify MCC DLA 2 Installed	Notify IV: DLA 2 installed		
	MCC: Command DLA 2 Engage	SARJ LAUNCH LOCKS (01:15)		
-	3 3	On IV GO: Verify DLA 2 teeth engaged then install DLA 2 cover	SARJ LAUNCH LOCKS (01:00)	7
			Assist EV1 with DLA 2 cover	
05:00				05:00
_				
	MCC: Verify PVR Ready for Deploy; IV – GO	Observe PVR deploy		
-				_
06:00		CLEANUP/INGRESS (00:40)	CLEANUP/INGRESS (00:40)	06:00
00:00				00.00
-				
				_
		PREREPRESS (00:05)	PREREPRESS (00:05)	

FS 7-3 EVA/117/FIN

#### EVA 1

#### **PRE EVA 1 TOOL CONFIG**

	EV1			AIRLOCK CONFIG	
	MWS			Staging Bag	
	BRT (L)			Fuse Tether	
	RET (eq-eq)			PGT	S/N
	Swing Arm (R)			PGT Battery	S/N
	RET (eg-eg)			Wire Tie Caddy	<u> </u>
	PGT [ <b>A1</b> 2.5ft-lb, <b>CAL</b> , MTL <b>30.5</b> ]	C/NI	-	RAD	S/N
$\vdash$	•	S/N	-		3/N
	7/16 (wobble) Socket-6 ext	0.41		Connector Cleaner Tool	INIL
-	PGT Battery	S/N		Probe	
	T-Bar			Prybar	
	RET (eq-eq)(2)			Connector Pin Straighte	ener
	RET (eq-eq) w/PIP pin (2)			Velcro/Tape Caddy	
	Wire Ties (2)			Fuse Tether	
	Small Shuttle Trash Bag			Locking Strut Aids (4)	
	Adj Equip Tether (2, R & L glove)			GP Caddy (2)	
	D-Ring Extender (2, R & L)			SSAS Contingency B	Rolts (4 ner caddy)
	85 ft Safety Tether (L D-ring to MWS)		-	ISS Torque Wrench Bag	
	Waist Tether (2, L D-ring and R ext)		_	ISS Torque Wrench (	
$\vdash$	, ,		-		,
-	SAFER			Spare 85-ft safety tethe	r
	WVS			IV Bag	
				Towels (2)	
	EV2			Contamination Detection k	Kit
	MWS			GP Caddy (2)	
	BRT (L)			Adjustable Thermal Mitt	tens (2)
	RET (eq-eq)			Socket Caddy (hatch cont)	) w/eq-eq RET
	Swing Arm (R)			1/2 Socket-8 ext	,
	RET (eg-eg)			7/16 (wobble) Socket-6	ext (spare)
	PGT [ <b>B7</b> 25.5 ft-lb, <b>CAL</b> , MTL <b>30.5</b> ]	S/N		DCM Plug (SAFER Hardm	` ' '
	PGT Battery	S/N		EVA Crewlock Bag	(2)
-	T-Bar	O/N	-	Vise Grips	
			_	RET (eq-eq) w/PIP pin	
	RET (eq-eq) (2)				/DDT Adamtan
-	RET (eq-eq) w/PIP pin (2)			3/8-in IVA Tool Stack w	•
	5/8 (rigid) Socket-7.8 ext				n wheel removed or taped)
	Wire Ties (2)			5/8 (rigid) Socket-7.8 ex	ct
	Small Shuttle Trash Bag			Round Torque Multiplier	
	Adj Equip Tethers (2, R & L glove)			Rd TM Socket – 5/8 prd	1
	D-ring Extender (2, R & L)			Socket Caddy	
	85-ft Safety Tether (R D-ring to EV1 exte	nder)		7/16 (wobble) Socket-6	ext
	Waist Tether (2, L D-ring and R ext)	ŕ		7/16 (rigid) Socket-9 ext	t
	SAFER			7/16 (rigid) Socket-2 ext	
	WVS			RET (eq-Lg) (outside of ba	
ш			$\vdash$	Medium ORU Bag with SLRI	0,
			$\vdash$	Fuse Tether (tethered to in	
			$\vdash$	,	iside bottom or bay)
			$\vdash$	RET (eq-eq)	
				Large Trash Bag	
				Digital camera w/L brac	ket
				Adj Equip Tether (eq-Lg) (	2 outside bottom of bag)
				RET (eq-lg) (outside of ba	- ·
				(- 4 -9) ( 30 01 00	<i>5,</i>

CETA 2
WIF 1 APFR [7,MM,E,1]
WIF 2 APFR [3,TT,F,12]

#### NOTE

Prior to use, perform the following hardware inspections:

- 1. RET cords for fraying
- No red line visible on safety and waist tether load Alleviation straps
- 3. Check BRT/Ballstack for loose screws and play
- 4. Inspect STS trash bags for deformation/damage

Shading indicates tools that came from STS

FS 7-4 EVA/117/FIN

# **EVA BRIEFING CARD**

EV1/3_	<del></del>	EV2/4	IV1	IV2
EVA Pr Depres Start pu PET 00	s to 10.2 irge	(GMT)/		
EVA Pr	Get-up p Exercise Equipme Suit dor SAFER Airlock of EV/IV co	plan – clothing a e protocol revievent lock activitied nning plan – spe , MWS, tools, C depress review omm protocol SSRMS initial po	w if required es – IV respon ecial requests L positions an	sibilities
EV Cre	Egress	tions – tether sv f tasks	vaps	
Genera	Get ahe Constra Caution RMS op	ure Review ead tasks ints – ground and s and warnings perations – com ency procedure	review m protocol/cle	arances
Emerge	Lost too	nm alfunctions		
Post E\		fing responsibili ′A plan	ties	

Lessons learned from previous EVAs and general motherhood

### **EVA 1 INHIBIT PAD**

### Orbiter

**TCS** 

1. √TCS POWER – OFF

**Ku-Band Antenna** 

MCC-H

L12

1. √KU-BAND Mask – active

2. √KU-BAND EVA Protect Box – active

RCS

If EV crew < 27 ft from FRCS:

1. √DAP: VERN, FREE, LO Z IV

O14,15,16 2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF

LOGIC (four) - OFF

MCC-H

3. √Above RCS config

IV 4. √RCS F – ITEM 1 EXEC (\*)

√JET DES F1U – ITEM 17 (\*)

F3U - ITEM 19 (\*)

F2U - ITEM 21 (\*)

#### Ground

#### **Ground Radar**

MCC-H 1. √TOPO console, ground radar restrictions in place for EVA

### **USOS**

#### **PCU**

MCC-H 1. √PCUs (two) operational in discharge mode and one of the following:

- A. CCS PCU EVA Hazard Control enabled
- B. No more than two arrays unshunted
- C. No more than two arrays pointed < 90 from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
  - A. No more than two arrays unshunted
  - B. No more than two arrays pointed < 90 from velocity vector

#### TRRJ DLA

MCC-H

1. Starboard radiator TRRJ parked at 0 degrees

# **RSOS**

#### **SM Antennas**

MCC-M IV

- 1. Global Timing Sys 1(400.1 MHz) [GTS] Deactivate
- 2. ARISS (HAM radio) Deactivate, or VHF (144-146 MHz) TX only

#### **FGB Antennas**

IV

1. ARISS (HAM radio) - Deactivate, or VHF (144-146 MHz) TX only

FS 7-6 EVA/117/FIN

# **NOTES, CAUTIONS, AND WARNINGS**

#### **NOTES**

- 1. Bolt install: report torque and turns
- 2. Bolt release: report torque and turns if different from published range
- EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD
- Toolbox doors must be closed with one latch per door when EV crew not in immediate vicinity

#### **CAUTION**

#### Flight Specific

- A. Electrical Cables:
  - 1. Avoid bend radius < 10 times cable diameter
- B. Fiber optic cables:
  - Avoid bend radius < 10 times cable diameter</li>
     Avoid pulling on cable during mate/demate
- C. SABB Restraints:
- 1. Unfasten jack bolt #6 last
- D. Prior to releasing SAW BGA Restraints:
  - 1. SABB Restraints Released (2 per wing)
  - Primary Power cable TA clamps released (3 per wing)
  - 3. APFR relocated from SABB Restraint location
  - 4. IEA Keel Pin rotated prior to forward wing BGA Restraint release
- E. SABB Unstow:
  - 1. Deploy rate of SABB must not exceed 6 degrees/sec (15 sec for full deploy)
- Four-bar linkage must be deployed and locked and SABBs rotated into deploy position before Mast Canister Tip Fitting restraints can be disengaged
- F. SARJ Prep:
  - 1. During removal of inboard MLI cover fasteners:
    - Limit turn count to minimum required for fastener release
  - b. Minimize side loading bolt head
  - c. Maintain axial force on fastener to compress spring during rotation
  - During re-installation of MLI covers, do not re-install swing bolts on MLI covers
  - Avoid impacting the race ring with the DLA when the DLA is unconstrained
  - DLA must be held against the outer side of the SARJ race ring during follower arm deploy to avoid interference with structure
- G. Radiators:
  - Avoid contact with radiator bellows and thermal outer coating
- H. Translation Path/Tether routing
  - 1. Avoid contact with S1/P1 Radiator Beam
  - During ingress route and fairleed safety tether forward of camera/light stanchions and trunnions

#### **CAUTION** (Cont)

#### **ISS Generic Constraints**

- I. Avoid inadvertent contact with:
  - Grapple fixture shafts (dry lube)
  - 2. PIP pins
  - 3. EVA Crane [PMA 1]
  - 4. TCS Reflectors [PMA 2, PMA 3]
  - 5. APAS hardware [PMA 2, PMA 3]
  - 6. CETA Lights (Z-93 paint) [Lab, S1, Node 1]
  - 7. Deployed MISSEs
  - 8. Passive UMAs
  - MBS VDU, MCU, CRPCMs and Cameras (tape radiative surface, silver Teflon)
  - 10. Deployed TUS cable
  - 11. S0 aft face radiator
  - 12. GPS Antennas (S13 paint) [S0]
  - 13. UHF Antennas [Lab, P1]
  - 14. ETCS Radiators [S1, P1]
  - 15. SASA RF Group [Z1, S1, P6]
  - 16. Heat pipe radiators [Z1]
  - 17. PCU cathode and HCA ports [Z1]
  - 18. Ku-Band Antenna (SGANT) dish [Z1]
  - 19. CMG cover/shells [Z1]
  - 20. SSRMS Cameras
- 21. Lab window shutter
- J. For Structural Reasons:
  - Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
  - Avoid performing shaking motions (sinusoidal functions) more than four cycles
  - If any of these occur, wait 2-5 min to allow structural response to dissipate

#### K. Other:

- ITT Cannon connector: On demated connectors, do not rotate collar or manipulate cable/connector using collar or connector tool
- 2. WIS Antennas: do not use as handholds [Node 1, P6, Z1, P4, S4]
- Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners can contaminate EMU [P6, P4, S4]
- MLI handholds are not rated for crewmember translation loads
- CBM petal covers may not be used as handholds unless both launch restraint pins are engaged
- 6. Do not close hatch until EMU water OFF for 2 min

FS 7-7 EVA/117/FIN

# NOTES, CAUTIONS, AND WARNINGS (Cont)

#### WARNING

#### Flight Specific

- A. Electrical connectors:
  - NZGL connector linkage. Use caution when mating/locking
  - Power must be turned off to electrical connectors prior to mating/demating to preclude arcing/sparking
  - Sharp edge mating surfaces of EVA connectors. Avoid side loads during mating
- B. Release SABB restraints
  - Sharp edge avoid contact with exposed threads on jack bolt #6 after clam shell released
  - 2. Sharp edge blanket box skirt
- C. Release SAW beta gimbal restraints:
  - Entire area behind IEA bulkhead, beta gimbal/solar array wing must be clear prior to fastener disengagement
  - 2. Verify beta gimbal/solar array motion has stopped before exiting worksite
  - Sharp edge exposed threads on keel pin fastener
- D. Unstow SABB:
  - Pinch point pivot fitting and lockout arm during SABB rotation
  - Sharp edge exposed bolts in rib cavities on mast canister
- E. SARJ Prep
  - Sharp edge spring loaded captive EVA fasteners (SARJ MLI cover bolts); ends of springs may protrude

#### **ISS Generic Constraints**

- F. Avoid inadvertent contact with:
  - 1. Grapple fixture targets and target pins
  - SSU, ECU, beta gimbal platform, mast canister, SAW blanket boxes unless the beta gimbal is locked and the motor is turned off
  - 3. Stay 2 ft from S1/P1 radiator beam rotational envelope when beam is free to rotate
  - 4. Stay 5 ft from moving MT on face 1
  - 5. Stav inboard of SARJ when active
- G. Handrails
  - Handrails previously used for MISSE attachment may not be used as a safety tether point [A/L endcone 564 and 566, A/L Tank 2 nad/fwd and port/fwd. P6 5389]

#### WARNING (Cont)

#### ISS Generic Constraints (Cont)

- H. Pinch
  - 1. ITT Cannon Connector rotating housing
  - 2. EV side of IV Hatch during Hatch operation (also snag hazard) [A/L]
  - 3. LAB window shutter and CBM petal cover linkages during operation
- I. RF radiation exposure
  - 1. Stay 3 ft from S-Band (SASA) high gain antenna when powered [S1, P6]
  - 2. Stay 1.3 ft from S-Band (SASA) low gain antenna when powered [S1, P6]
  - 3. Stay 1 ft from UHF antenna when powered [Lab, P1, PLB]
- J. Sharp Edges:
  - 1. Inner edges of WIF sockets
  - 2. Back side of MMOD shield fasteners
  - 3. PMA umbilical launch restraints exposed threads
  - Adjustable Fuse Tether buckles stowed in Node Bag
  - 5. Nickel coated braided copper ground straps may have frayed wires [P6, P4, S4]
  - 6. Z1 handrail 6061 by the Ku-Band boom launch restraint [Z1]
  - 7. Solar Array
    - a. SABB (skirts, swing bolts)
    - b. Solar cells
    - c. Springs along tension bar
    - d. Panel hinges
    - e. Guide cable burrs or frays
    - f. Mast Canister roller guides
    - g. Braided cables
    - h. Fastener exposed threads
    - i. Exposed bolts in rib cavities on mast canister
  - Keep hands away from SSRMS LEE opening, and snares
  - Exposed fasteners on back of Z1 U-jumper male QD panel, if nutplate cap missing
- K. Thermal:
  - EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
  - 2. PMA handrails may be hot. Handling may need to be limited
  - Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on

#### WARNING (Cont)

### ISS Generic Constraints (Cont)

- K. Thermal (Cont)
  - 4. Uncovered trunnion pins may be hot
  - 5. SSRMS/MBS operating Cameras and lights may radiate large amounts of heat
  - 6. Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
  - Stay 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor
  - Stay 0.5 ft away from PMA and MMOD shields > 325 degF
  - 9. Do not touch EMU protective visor if temp has been < -134 for > 15 min
  - 10.No EMU TMG contact of PMAs and MMOD shields when temp > 320 degF
  - 11.No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF

FS 7-8 EVA/117/FIN

# EVA 1 EGRESS/SETUP (00:35)

IV	EV1	EV2
Initial Condition: PLB Camera C pointed at Airlock	Initial Condition: Waist Tether (L + R) D-ring to MWS EV2 85-ft tether to (L) extender EV1 85-ft tether on (R) D-ring to MWS EGRESS	Initial Condition: Waist Tether (L) to A/L D-ring, (R) to MWS, 85-ft tether on (R) D-ring to EV1 (L) extender  EGRESS
1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max	<ol> <li>Open A/L thermal cover</li> <li>Egress airlock</li> <li>√SAFER man isol vlv – open (down)</li> <li>√SAFER HCM – closed (down)</li> <li>Receive/temp stow Crewlock Bag</li> <li>Receive Medium ORU Bag from EV2; stow on BRT</li> <li>Translate to S1 HR 3214 (stanchion/trunnion at 3282, 3234)</li> <li>Attach EV1 85-ft safety tether to S1 HR 3214</li> <li>Verify locking hooks – Locked</li> <li>Attach EV2 85-ft safety tether to S1 HR 3221</li> <li>Verify locking hooks – Locked</li> <li>Give EV2 GO for translation</li> </ol>	<ol> <li>Transfer Crewlock Bag to EV1 (RET stays on bag)</li> <li>Transfer Medium ORU Bag to EV1 (RET stays in A/L)</li> <li>Egress airlock</li> <li>√SAFER man isol vlv – open (down)</li> <li>√SAFER HCM – closed (down)</li> <li>Retrieve Crewlock Bag; stow on BRT</li> <li>On EV1 GO, disconnect waist tether</li> <li>Close A/L thermal cover</li> </ol>
	SETUP  13. Translate to S3; temp stow ORU bag on S3 HR 3063  14. Configure/relocate APFR: CETA WIF 2 to S3-04  [6,TT,F,12]	9. Translate to CETA cart 10. Stow Crewlock Bag on APFR 11. Configure/relocate APFR: CETA WIF 1 to S4-15 [9,MM,E,1] 12. Stow Crewlock Bag on S4 HR 2245 13. Retrieve Rd TM

FS 7-9 EVA/117/FIN

# S1-S3 UTILITY TRAY CONNECT (01:35)

	IV	EV1		
МСС-Н	Verify DEACTIVATING DDCU P13A AND VERIFY MBSU & RBI CONFIGS step 3 complete (SODF: ASSY OPS: ACT & C/O: S3 ACTIVATION)      Give EV1 GO for Nadir Tray connections	NADIR UTILITY TRAY CONNECT  1. Ingress APFR 2. Open S1 Nadir Utility Tray shroud to access connector panel A51 3. Open all TA clamps except P17  4. On IV GO, demate from panel A51 and mate to panel A88 Nadir Tray Utilities as follows and transfer caps:		
	3. Inform MCC – S3 Nadir Tray Utilities complete ← GMT (:)	Demate P17 (leave in TA clamp) P16 to J16 (fiber optic) P15 to J15 P14 to J14 P17 to J17 P18 ro J17 P19 ro J17 P19 ro J17 P19 ro J13 P19 to J19		
		7. Relocate S3-04 APFR: S3-01 [6,TT,F,12] 8. PGT[A1 2.5 ft-lb, CW2 30 RPM, MTL 30.5]-6 ext 7/16: Tighten nadir and zenith nut clamp bolts (2) ~6 turns  MEDIUM ORU BAG CONFIGURATION 9. Transfer Medium ORU Bag from temp stow to face 1 S3 HRs 3062,3063 and S4 HRs 2213 2215 with adj tethers 10. Attach free end of fuse tether to S4 HR 2215		
	4. Verify MCC GO for S3 MDM shroud removal	MDM SHROUD REMOVAL		
	GMT/:::	11. On IV GO, remove S3 MDM shroud; jettison retrograde; report speed/direction     12. √MCC-H for time remaining until GO for zenith utility tray; reference Block A		
MCC-H	<ol> <li>Verify DEACTIVATING DDCU S14B AND VERIFY MBSU &amp; RBI CONFIGS step 11 complete (SODF: ASSY OPS: ACT &amp; C/O: S3 ACTIVATION)</li> </ol>	ZENITH UTILITY TRAY CONNECT (PREDICT 30 MIN FROM NADIR UTILITIES)  13. Ingress APFR  14. Open S1 Zenith Utility Tray shroud to access connector panel A50  15. Open all TA clamps except P5		
	6. Give EV1 GO for Zenith Tray connections	► 16. On IV GO, demate from panel A50 and mate to panel A89 Zenith Tray Utilities as follows and transfer caps		
	7. Inform MCC – S3 Zenith Tray Utilities complete ◆	Demate P5 (leave in TA clamp) P6 to J6 (fiber optic) P5 to J5 P4 to J4 P3 to J3 P2 to J2 P1 to J1 P1 to J1 P3 to J1 Char  17. If possible, close S1 TA clamps 18. Reattach S1 Utility Tray shroud 19. Configure/relocate APFR from S3-01 to S4-04 [6, PP, L, 1] for DLA 2		


FS 7-10 EVA/117/FIN

# SABB RESTRAINT RELEASE (02:00)

IV	EV2
	RELEASE AFT INBOARD RESTRAINTS
	<ol> <li>Ingress APFR: S4-15 [9,MM,E,1]</li> <li>PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]Rd TM-5/8 prd: √Anti-backlash Neutral: Break torque on Inboard SABB fasteners (2) ~5 turns</li> <li>PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-7.8ext 5/8: Release Inboard SABB fasteners (2) ~12 turns</li> <li>Open clam shell; remove 7.8ext 5/8 from PGT</li> <li>Egress APFR and reconfigure: S4-15 [2,MM,E,12]</li> </ol>
	RELEASE AFT OUTBOARD RESTRAINTS  CAUTION Unfasten jack bolt #6 last
	<ul> <li>6. Connect RET to S4 HR 2229 and SABB Restraint</li> <li>7. Ingress APFR: S4-15 [2,MM,E,12]</li> <li>8. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]Rd-TM-5/8 prd: √Anti-backlash Neutral: Break torque on Outboard SABB fasteners (6) ~5 turns</li> <li>9. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-7.8ext 5/8: Release Outboard SABB fasteners (6) ~12 turns</li> <li>10. Temp stow SABB Restraint</li> <li>11. Stow 7.8 ext-5/8 socket in trash bag</li> <li>12. Egress APFR</li> <li>13. Stow SABB Restraint on APFR</li> <li>14. Retrieve APFR</li> <li>15. Stow SABB Restraint on fuse tether</li> <li>16. Relocate APFR: S4-13 [9,NN,E,1]</li> </ul>
	RELEASE FORWARD INBOARD RESTRAINTS  17. Ingress APFR: S4-13 [9,NN,E,1]  18. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]Rd TM-5/8 prd: √Anti-backlash Neutral: Break torque on Inboard SABB fasteners (2) ~5 turns  19. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-7.8ext 5/8: Release Inboard SABB fasteners (2) ~12 turns  20. Open clam shell; remove 7.8 ext 5/8 from PGT  21. Egress APFR and reconfigure: S4-13 [2,NN,E,11]
	RELEASE FORWARD OUTBOARD RESTRAINTS  CAUTION Unfasten jack bolt #6 last
	22. Connect RET to S4 HR 2236 and SABB Restraint 23. Ingress APFR: S4-13 [2,NN,E,11] 24. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]Rd-TM-5/8 prd: √Anti-backlash Neutral: Break torque on Outboard SABB fasteners (6) ~5 turns 25. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-7.8ext 5/8: Release Outboard SABB fasteners (6) ~12 turns 26. Temp stow SABB Restraint 27. Stow 7.8 ext 5/8 socket in trash bag 28. Egress APFR
	29. Stow SABB Restraint on fuse tether 30. Relocate APFR S4-13 to S3-28 [2, PP, F, 12] (for DLA 1); Translation path: S4 zenith/aft, cross to S3 to relocate APFR, retrace to go back to S4 31. Transfer TM to Crewlock Bag; retrieve 7/16-in 6-in ext, stow 5/8 socket 32. Coordinate with MCC/IV for GO to release TA clamps, Remove ECU/SSU covers or PVR cinches/winches

FS 7-11 EVA/117/FIN

# S4 IEA KEEL PIN ROTATE/TA CLAMP RELEASE/S5 RTAS SOFTDOCK ROTATE (00:30)



# PVR RADIATOR CINCHES/WINCHES (00:30)

IV	EV2
Verify ISS in CMG control/thrusters inhibited	UNCINCH/UNWINCH RADIATOR  1. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-6ext 7/16: Release PVR Cinch bolts H11-H16 (6) ~8-14 turns (Push to engage bolts); stow cables in cinch clips    H12 (1st or 2nd)   H11 (1st or 2nd)   H15   H13   H16   H14  2. Remove winch bar PIP pin from winch clevis 3. Remove winch bar from array panel, reinstall PIP pin in winch clevis    H33   H34
2. Verify MCC GO for SSU/ECU MLI removal  AFT SSU GMT	4. If not previously performed, release aft wing Primary Power cable TA clamps (3) 5. On IV GO: release SSU/ECU ground PIP pin and remove thermal covers (2 each); jettison retrograde; report speed/direction 6. If not previously performed, release fwd wing Primary Power cable TA clamps (3) 7. If not previously performed, release fwd wing Primary Power cable TA clamps (3)

FS 7-13 EVA/117/FIN

# SAW BETA GIMBAL RESTRAINT RELEASE (00:40)

IV	EV1
	WARNING Stored energy and collision hazard. EV crew must remain clear of IEA bulkhead, Beta Gimbal/Solar Array Wing during Beta Gimbal Restraint disengagement Verify that Beta Gimbal/Solar Array motion has stopped before exiting worksite
	CAUTION  The following must be complete prior to release of BGA Restraints:  1. SABB Restraints Released (2 per wing)  2. Primary Power cable TA clamps released (3 per wing)  3. APFR relocated from SABB Restraint location  4. IEA Keel Pin rotated prior to forward wing BGA Restraint release
	RELEASE AFT WING (3A) BETA GIMBAL RESTRAINTS  1. Retrieve ratchet wrench with 7.8 ext 5/8 from Crewlock Bag 2. Remove PIP pins from BGA launch restraint assemblies (2) 3. Verify EV2 is clear of stored energy hazard 4. BRT to HR 2235 5. Ratchet wrench -7.8 ext 5/8: Release AFT Wing Beta Gimbal restraints (2) ~10 turns 6. Re-insert anti-rotation PIP pins (2) into BGA launch restraint assemblies 7. Verify 4-Bar linkages have been fully deployed and locked (minimum of 3 of 4 locks)
	RELEASE FWD WING (1A) BETA GIMBAL RESTRAINTS  8. Remove PIP pins from BGA launch restraint assemblies (2) 9. Verify EV2 is clear of stored energy hazard and SABB restraint/keel rotation complete 10. BRT to HR 2207 11. Ratchet wrench -7.8 ext 5/8: Release FWD Wing Beta Gimbal restraints (2) ~10 turns 12. Re-insert anti-rotation PIP pins (2) into BGA launch restraint assemblies 13. Verify 4-Bar linkages have been fully deployed and locked (minimum of 3 of 4 locks)

FS 7-14 EVA/117/FIN

# FWD/AFT (1A/3A) SABB UNSTOW (00:20/SABB)

IV	EV1/EV2
TA (fwd)  Left BB Right BB Left BB Right BB  PIP Pin  Lock sleeve  Mast Tip 1  Mast Tip 2  Mast Tip 3	WARNING Pinch Point – Stay clear of pivot fitting and lockout arm during SABB rotation  UNSTOW FWD/AFT WING (1A/3A) SABBs  1. Translate to top of Mast Canister 2. Remove PIP pin from Lockout arm 3. Rotate blanket box to deploy position (15 sec minimum) 4. Verify pivot arm is locked with locking sleeve over joint 5. Install PIP pin through the Lockout arm 6. Repeat steps 2-5 for other blanket box 7. PGT[A7 9.2 ft-lb, CCW2 30 RPM, MTL 30.5]-6ext 7/16: Release Mast Tip fasteners (3) ~14 turns 8. Verify Mast Tip fasteners are released 9. □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □


FS 7-15 EVA/117/FIN

# AJIS STRUT RIGIDIZATION (00:10 PER STRUT – 00:40 TOTAL)

IV	EV1/EV2
	Rigidize AJIS struts using the procedure below for each     AJIS strut (no specific order required)
	□ AJIS strut fwd zenith (#3) (HR 3064)
	☐ AJIS strut aft zenith (#4) (HR 2203)
	☐ AJIS strut aft nadir (#1) (HR 2211)
	☐ AJIS strut fwd nadir (#2) (HR 2212)
	RIGIDIZE STRUT
	<ol> <li>Open thermal bootie</li> <li>Release Velcro strap</li> <li>Tether to Strut Launch Restraint</li> <li>Remove PIP pin</li> <li>Remove Hitch pin</li> <li>Remove and stow Strut Launch Restraint</li> <li>Verify anti-rotation tabs on cones and ground wire attach point are pointing "out" of cups and are visible</li> <li>Position fastener into mating bulkhead bracket</li> <li>PGT[B2 16.0 ft-lb, CW3 60 RPM, MTL 30.5]-6ext 7/16: Engage fastener ~39 turns to torque</li> <li>Re-install thermal bootie  10 Restraint in Large Trash Bag</li> </ol>

FS 7-16 EVA/117/FIN

# SARJ DLA 2 DEPLOY (01:00)



FS 7-17 EVA/117/FIN

# SARJ LAUNCH LOCK REMOVAL (01:15)

IV	EV1	EV2		
	A. Remove the following Launch Locks and swing bolts:	A. Remove the following Launch Locks:		
	☐ Cover 4, Face 2, Launch Lock 10	☐ Cover 18, Face 5, Launch Lock 5, if APFR required: S3-30 [9,PP,G,12]		
	☐ Cover 3, Face 1/2, swing bolt (1)	□ Cover 19, Face 6, Launch Lock 6, if APFR required: S3-30 [9,PP,F,12]		
	☐ Cover 2, Face 1, Launch Lock 9	Release the following swing bolts (# per cover):		
	□ Cover 1, Face 1, Launch Lock 8	□ Cover 17 (2) □ Cover 10 (3)		
	☐ Cover 22, Face 1/6, swing bolt (1)	□ Cover 16 (2) □ Cover 9 (2)		
	☐ Cover 21, Face 6, Launch Lock 7	□ Cover 15 (3) □ Cover 8 (2)		
		□ Cover 14 (1) □ Cover 7 (2)		
		□ Cover 13 (3) □ Cover 6 (2)		
		□ Cover 12 (3) □ Cover 5 (4)		
		□ Cover 11 (1)		
	PGT[A1 2.5 ft-lb, CCW3 60 RPM, MTL 30.5]-6ext 7/16: Release swing bolts (1 to 4) ~10-11 turns  2. Verify fasteners swing open  REMOVE SARJ LAUNCH LOCKS  CAUTION  The following precautions should be observed to prevent loss of inboard MLI cover fasteners during removal:  • Limit turn count to minimum required for fastener release  Minimizers side leading both board.			
	<ul> <li>Minimize side loading bolt head</li> <li>Maintain axial force on fastener to compress spring during rotation</li> </ul> 3. PGT[A6 8.3 ft-lb, CCW3 60 RPM, MTL 30.5]-6ext 7/16: Release inboard MLI cover fasteners (4-6) =9 turns (add single turns incrementally as required for release) 4. Remove MLI cover and temp stow 5. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]-6ext 7/16: Release SARJ Launch Lock fasteners (4) ~13-15 turns 6. Remove launch lock and stow 7. Re-position MLI cover 8. PGT[A1 2.5 ft-lb, CW2 30 RPM, MTL 30.5]-6ext 7/16: Engage inboard MLI cover fasteners (4-6) ~9 turns			

FS 7-18 EVA/117/FIN

# EVA 1 CLEANUP/INGRESS (00:40)

	IV	EV1	EV2
1	Perform WVS PWRDN (PHOTO/TV, <u>WVS CUE CARD</u> )	CLEANUP  1. If 4 or more Launch Locks removed, retrieve Med ORU Bag; stow on BRT 2. Retrieve digital camera 3. Perform tool inventory 4. Translate to Airlock	CLEANUP  1. If not already performed, retrieve Crewlock Bag; stow on S3 HR 3049 2. Perform tool inventory 3. Translate to Airlock
		INGRESS  5. Transfer Med ORU Bag to EV2 6. Attach Waist Tether (R) to A/L D-ring; verify locked 7. Stow Safety Tether on external A/L handrail (√reel unlocked) 8. Ingress A/L 9. Remove SCU from stowage pouch Remove DCM cover Connect SCU to DCM, check locked 10. Water − OFF 11. Close thermal cover, attach Velcro strap  CAUTION Do not close hatch until EMU water off for 2 min  12. Verify no hardware blocking hatch 13. EV Hatch Handle − Preclose 14. EV Hatch − close and lock 15. Go to PRE-REPRESS Cue Card	INGRESS  4. Open A/L Thermal Cover 5. Ingress A/L 6. Waist tether swap (end with R on UIA D-ring); verify locked 7. Stow Safety Tether on external Airlock handrail (√reel unlocked) 8. Receive Med ORU Bag; stow in Airlock 9. Remove SCU from stowage pouch Remove DCM cover Connect SCU to DCM, check locked 10. Water − OFF

FS 7-19 EVA/117/FIN

# **POST EVA 1 TOOL CONFIG**

 EV 1	AIRLOCK CONFIG	S1 TRUSS
MWS	Staging Bag	Safety Tether – S1 – HR 3214 (cable tray) strung to airlock
BRT (L)	Fuse Tether	Safety Tether – S1 – HR 3221 (nadir edge) strung to airlock
RET (eq-eq)	PGT	
Swing Arm (R)	PGT Battery	
RET (eq-eq)	Wire Tie Caddy	S3 TRUSS
PGT	RAD	APFR WIF S3-28 [2,PP,F,12]
PGT Battery	Connector Cleaner Tools Kit	EVA Crewlock Bag – S3 – HR 3049
7/16 (wobble) Socket-6 ext	Probe	Vise Grips
T-Bar	Prybar	Socket Caddy
RET (eq-eq) (2)	Connector Pin Straightener	5/8 (rigid) socket-7.8 ext
RET (eq-eq) w/PIP pin (2)	Velcro/Tape Caddy	7/16 (rigid) Socket-2 ext
Wire Ties (2)	Fuse Tether	7/16 (rigid) Socket-9 ext
Small Shuttle Trash Bag	Locking Strut Aids (4)	RET (eq-eq) w/PIP pin
Adj Equip Tether (2, R & L glove)	GP Caddy (2)	3/8-in IVA Tool Stack w/DPT Adapter
D-Ring Extender (2, R & L)	SSAS Contingency Bolts (4 per caddy)	ISS Ratchet Wrench
Waist Tether (2, L D-ring and R extender)	ISS Torque Wrench Bag	5/8 (rigid) socket-7.8 ext
SAFER	ISS Torque Wrench (preset to 34 ft-lb)	RET (eq-eq)
WVS	Spare 85-ft safety tether	Round Torque Multiplier
		Rd TM Socket – 5/8 prd
	IV Bag	RET (eq-lg) (outside of bag)
 EV 2	Towels (2)	
MWS	Contamination Detection Kit	S4 TRUSS
BRT (L)	GP Caddy (2)	APFR WIF S4-04 [6,PP,L,1]
Ret (eq-eq)	Adjustable Thermal Mittens (2)	
Swing Arm (R)	Socket Caddy (hatch cont) w/eq-eq RET	
RET (eq-eq)	1/2 Socket-8 ext	Shading indicates trash items
PGT	7/16 (wobble) Socket-6 ext (spare)	
PGT Battery	DCM Plug (SAFER Hardmount) (2)	
7/16 (wobble) Socket-6 ext		
T-Bar	Medium ORU Bag with SLRI 6	
RET (eq-eq)(2)	Fuse Tether	
RET (eq-eq) w/PIP pin (2)	RET (eq-lg)	
Wire Tie (2)	SABB Restraints (2)	
Small Shuttle Trash Bag	Large Trash Bag	
Adj Equip Tether (2, R & L glove)	AJIS Launch Restraint Locks (4)	
D-ring Extender (2, R & L)	Digital camera	
Waist Tether (2, R on D-ring & L on extender)	SARJ Launch Locks (up to 6)	
SAFER	Adj Equip Tether (eq-lg) (2 outside bag)	
WVS	RET (eq-lg) (outside of bag)	
	<del></del>	

FS 7-20 EVA/117/FIN **EVA 1 TASK DATA** 

FS 7-21 EVA/117/FIN

# S1-S3 UTILITY TRAY CONNECT - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:30/utility tray + 0:35 commanding
Two EV Crew	NA	NA

#### Tools:

EV1	EV2
BRT	NA
APFR	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
NA								

#### **EVA Connectors:**

Harness -	From: panel/	To: panel/	Clamps (#)	Conn	Function
Connector	connector	connector		Size	
W5002 (EO) - P11	A51/J31	A88/J11	1	37	Primary Power 3A
W5004 (EO) - P12	A51/J32	A88/J12	1	37	Primary Power 3B
W5104 (EO) - P13	A51/J33	A88/J13	1	25	Secondary Power 2B
W5102 (EO) - P14	A51/J34	A88/J14	1	33	Secondary Power 3A
W5210 (RF) - P15	A51/J1	A88/J15	1	25	Data/1553 B
W5402 (FO) – P16	A51/J36	A88/J16	1	15	High Rate Data Link (PAS-1/4)
W5304 (ML) – P17	A51/J37	A88/J17	1	25	INSTM (Strain Gage/ Accelerometer)
W5001 (EO) - P1	A50/J21	A89/J1	1	37	Primary Power 1A
W5003 (EO) - P2	A50/J22	A89/J2	1	37	Primary Power 1B
W5101 (EO) – P3	A50/J23	A89/J3	1	25	Secondary Power 1A
W5103 (EO) - P4	A50/J24	A89/J4	2	33	Secondary Power 4B
W5209 (RF) – P5	A50/J1	A89/J5	1	25	Data/1553 A
W5401 (FO) – P6	A50/J26	A89/J6	1	15	Video/Sync-3, High Rate Data Link (PAS-2/3)

#### **Foot Restraints:**

Task	WIF	APFR Setting
Mate S1 to S3 Nadir Tray Umbilicals	S3-04	[6,TT,F,12]
Mate S1 to S3 Fluid Line	S3-04	[6,TT,F,12]
Mate S1 to S3 Zenith Tray Umbilicals	S3-01	[6,TT,F,12]

#### Note:

- 1. Internal S1 TA clamps (3) were released during 9A
- 2. No shroud exists on the S3 side utility tray
- P11/J11 and P12/J12 connector mating may require excessive cable manipulation due to excess cable length on W5001, W5002, W5003, and W5004. (Ref: S1 to S3 OOCT Crew squak)
- 4. Connectors can be mated in any order to optimize EVA sequence

#### Cautions:


- Power should be restored as quickly as possible after the power umbilicals have been connected
- Fiber optic cable harnesses P6 and P16 shall be firmly supported during installation to prevent damage due to excessive bending, kinking, tension, torsional loading or other excessive strain. Avoid bend radii of less than 10 times the diameter of the wire harness

#### Warnings:


 Power must be turned off to connectors P1-P6 and P11-P17 while being mated/demated to preclude arcing/sparking

FS 7-22 EVA/117/FIN

# S1-S3 UTILITY TRAY CONNECT - TASK DATA (Cont)




S1-S3 Nadir Tray Utilities (Face 6) – before mating to S3



S1-S3 Nadir Tray Utilities (Face 6) – after mating to S3


FS 7-23 EVA/117/FIN

# S1-S3 UTILITY TRAY CONNECT – TASK DATA (Cont)



S1-S3 Zenith Tray Utilities (Face 2) – before mating to S3

P5/J1



S1-S3 Zenith Tray Utilities (Face 2) – after mating to S3 (mockup)

FS 7-24 EVA/117/FIN

# SABB RESTRAINT RELEASE - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	02:00
Two EV Crew	NA	01:00

#### Tools:

10013.	<del>-</del>
EV1	EV2
NA	PGT
	Rd TM with 5/8
	5/8 (rigid) Socket-7.8 ext
	APFR

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Inboard SABB Launch Restraint	NA	5/8	2	98	119	389	<mark>13</mark>	30
Outboard SABB Launch Restraint	1-6	5/8	6	97	118	390	<mark>13</mark>	30

### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting
Release aft inboard SABB Launch Restraint	S4-15	[9,MM,E,1]
Release aft outboard SABB Launch Restraint	S4-15	[2,MM,E,12]
Release forward inboard SABB Launch Restraint	S4-13	[9,NN,E,1]
Release forward outboard SABB Launch Restraint	S4-13	[2,NN,E,11]

# Notes:

Reach to Outboard SABB restraint fasteners 5 and 6 may require partial egress of APFR


# Cautions:

1. Unfasten Jack bolt #6 (nearest the tether point) last. Fasteners #1-5 can be released in any order


# Warnings: None

FS 7-25 EVA/117/FIN


# SABB RESTRAINT RELEASE - TASK DATA (Cont)




SABB Inboard Launch Restraint



SABB Outboard and Inboard Restraints (left to right in view)



SABB Outboard Launch Restraint



SABB Outboard Launch Restraint

FS 7-26 EVA/117/FIN

# S4 IEA KEEL PIN ROTATE - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:30
Two EV Crew	NA	N/A

#### Tools:

EV1	EV2
PGT (prime)	NA
7/16 wobble socket-6 ext	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
IEA Keel Pin Restraint Bolt	NA	7/16	1	4 gnd	38	168 removal 44 install	43	60

#### **EVA Connectors:**

Har	ness	From	То	Clamps (#)	Conn Size	Function
NA						

#### **Foot Restraints:**

Task	WIF	APFR Setting
Rotate IEA Keel Pin	S4-28	12,QQ,G,12 (3A 4-bar
		must be deployed)

#### Notes:


none

#### Cautions:

none

Warnings:

1. Sharp edge. The Keel fastener has exposed bolt threads when removed from the Keel body



Beta Gimbal Restraints and IEA Keel Pin



Keel Pin Rotated

EVA/117/FIN FS 7-27

# **PVR RADIATOR CINCHES/WINCHES - TASK DATA**

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	N/A	0:30
Two EV Crew	N/A	0:15

#### Tools:

EV2
PGT
BRT
7/16 wobble socket-6 ext

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Cinch	H11-H16	7/16	6	22.9 (H11-H12) 33.8 (H13-H16)	15.8 (H11-H12) 24.6 (H13-H16)	39.7	8-14	30



**PVR FQDC** 

#### Notes:

- 1. Incidental contact with silver radiator surface is acceptable
- Winch release is performed after cinches so that winch bar tension is relieved for PIP pin removal

#### Cautions:

#### None


#### Warnings:

1. Moving hardware hazard. Radiators are free to move after winches released


#### Constraints:


1. APFR ingress/egress cannot happen concurrently with radiator deploy

### **PVR EVA Interfaces**



PVR





FQDC Shroud

FQDC

H5,6,9,8 = FQDC Shroud Fasteners H7 = FQDC Shroud Alignment Pin H10 = Winch Drive H11- H16 = Cinches H17 = Grounding Strap H18 - H19 = FQDC Drive bolts H20 - H21 = Carrier Slider bolts H22 - H23 = Carrier to PVR Attach H24 - H25 = Carrier to IEA Attach H26 - H27 = Center Bolts

H26 - H27 = Center Bolts H28 - H31 = Corner Bolts

H32 = Manual Deploy/Retract H33-H34 = Winch PIP pins

FS 7-28 EVA/117/FIN

# SAW BETA GIMBAL RESTRAINT RELEASE - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:40
Two EV Crew	NA	N/A

#### Tools:

EV1	EV2
Ratchet wrench	NA
5/8 (rigid) Socket-7.8 ext	
BRT	
Rd TM with 5/8 prd (backup)	
PGT (backup)	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Beta Gimbal Launch Restraint Bolts	NA	5/8	2	60 gnd	60 @ 70F, 118 @200F	496	10-12	60

#### **FVA Connectors:**

EVA COMICCIONS.										
Harness	From	То	Clamps (#)	Conn Size	Function					
NA										

#### **Foot Restraints:**

Task	WIF	APFR Setting
Release Aft Beta Gimbal Restraints	S4-16	1,PP,L,12
Release Forward Wing Beta Gimbal Restraints	S4-14	12,PP,K,12

### Notes:

1. Do not release the third clamp from the BMRRM. This is a sliding clamp which the Primary power cable is intended to slide through

#### Cautions:

The following must be complete prior to release of BGA Restraints:

- 1. SABB Restraints Released (2 per wing)
- Primary Power cable TA clamps released (3 per wing)
   APFR relocated from SABB Restraint location
- IEA Keel Pin rotated prior to forward wing BGA Restraint release

#### Warnings:

- 1. Entire area behind the IEA bulkhead, Beta Gimbal/Solar Array wing, must be clear prior to fastener disengagement
- 2. Verify that Beta Gimbal/Solar Array wing motion has stopped before exiting worksite



Beta Gimbal Restraints (Aft Wing)



Primary Power Cable TA Clamps (Aft Wing)

FS 7-29 EVA/117/FIN

# FWD/AFT (1A/3A) SABB UNSTOW - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:45
Two EV Crew	NA	0:20

#### Tools:

100.01	
EV1	EV2
PGT	
7/16 (wobble) Socket-6 ext	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Mast Canister Tip Fitting	Yes	7/16	3	7	8	12.8	14	30

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### Foot Restraints:

Task	WIF	APFR Setting
NA		

Note:

1. Mast Tip Fasteners will pop-up when disengaged

#### Cautions:

- 1. Deploy SABB no faster than 6 degrees/second (15 seconds minimum for complete
- 2. 4-bar linkage must be deployed and SABBs rotated into the deployed position before Mast Canister Tip Fitting restraints can be disengaged

### Warnings:

1. Pinch point hazard – Stay clear of pivot fitting and lockout arm during SABB rotation

FS 7-30 EVA/117/FIN

# AJIS STRUT RIGIDIZATION - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:40
Two EV Crew	NA	NA

#### Tools:

EV1	EV2
NA	PGT
	7/16 (wobble) Socket-6 ext
	Large Trash Bag

#### **EVA Fasteners:**

				_				_
Fastener Name	Label	Head Size	Qt y	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
AJIS Strut Fastener	Yes	7/16	4	7-22 on orbit	N/A	22.1	39	60

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting
AJIS Strut #1 worksite	S4-11	[9,QQ,F,12]
AJIS Strut #2 worksite	S4-03	[7,PP,G,12]
AJIS Strut #3 worksite	S4-02	[5,PP,E,12]
AJIS Strut #4 worksite	S4-10	[3,QQ,F,12]

### Notes:

- Per 12A analysis, Struts 1 and 4 are predicted to not engage the cone fasteners if they are not installed prior to SARJ Launch Lock and Launch restraint removal due to structural deflection
- 2. There are (4) AJIS on-orbit struts between S4 and S3. The struts may be rigidized in any order
- The strut numbers correspond to the label numbers located on the S4 bulkhead adjacent to the strut clevis

#### Cautions:


None

#### Warnings:

None

FS 7-31 EVA/117/FIN

# AJIS STRUT RIGIDIZATION - TASK DATA (Cont)



AJIS Strut with SARJ Bulkhead in Background (thermal bootie not shown)



AJIS Strut with Strut Launch Restraint (thermal bootie removed)



AJIS Strut Cone Fastener (engaged, but not fastened)

FS 7-32 EVA/117/FIN

### SARJ DLA INSTALL - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	NA

#### Tools:

EV1	EV2			
PGT	NA			
6 Ext 7/16				
APFR				
RET				
Adj. Equipment Tether				

#### **EVA Fasteners:**

EVA Fasteriers.									
Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM	
MLI Cover Swing Bolts	NA	7/16	4 per cover	2.3-3.0	2.8	5.5	8-12	60	
MLI Cover Inboard Fasteners	NA	7/16	4 per cover	3.1-3.6 gnd 0.8-3.8 on- orbit	3.4	13.7	7-9	60 rmv 30 inst	
DLA 1A and 2A Lock bolts	Yes	7/16	2 per	3.3-6.3	6.7	42.2	6	30	
DLA 1C and 2C Draw Bolts	Yes	7/16	2 per	4.8 initial 19.4 final	0.8	38.9	38	30	
DLA 4A, 4B, and 4C Launch Restraint Bolts	Yes	7/16	3 per	24-26	25	50-A&B 75-C	10-A&B 8-C	30	
DLA 1B and 2B Follower arm rotation Bolts	Yes	7/16	2 per	NA	NA	10.6	5/8	10	

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting
Cover 5 DLA 1 Face 2	S3-28	[2,PP,F,12]
Cover 20 DLA 2 Face 6	S4-04	[6,PP,L,1]

#### Notes:

- If any spring clamp assembly fails to snap completely out of the way, a gentle nudge may be required
- The bolts nearest the tether loop must be released prior to tethering to the shroud to avoid interference between the tether hook and PGT
- The outboard SARJ race ring side MLI cover bolts (spring clamp bolts) should be released prior to the inboard MLI cover bolts
- Cabling on outboard side of SARJ may interfere with DLA cover re-installation. Cover should be installed outboard side first, then inboard side
- To re-install the DLA cover, all bolts should be started before any are driven fully

#### Cautions:

- During re-installation of MLI covers, do not re-install spring clamp assemblies on the outboard SARJ race ring side (outboard fasteners). This will preclude SARJ rotation
- Any single failure of bolts/spring clamp assemblies will prevent SARJ activation
- Avoid impacting the race ring with the DLA when the DLA is unconstrained
- During follower arm rotation (90 deg turn) when the DLA is still
  unconstrained, interference with structure may occur. The DLA must be
  held against the outer side of the SARJ race ring for the follower arm to
  rotate fully clearing obstruction


#### Warnings:

None

FS 7-33 EVA/117/FIN

# SARJ DLA INSTALL – TASK DATA (Cont)








DLA


FS 7-34 EVA/117/FIN



FS CC 7-35 EVA/117/FIN

### TOP Back of 'SARJ PREP CUE CARD'





EVA-6b/117/O/B

(reduced copy)

FS CC 7-36 EVA/117/FIN

# **EVA 2 SUMMARY TIMELINE**

TIME	IV	EV3	EV4	
HR : MIN 00:00		(FR) POST DEPRESS (00:05)	(SW) POST DEPRESS (00:05)	00:00
		EGRESS/SETUP (00:40)	EGRESS/SETUP (00:40)	7
-				-
		<u>2B RETRACT</u> (00:45)	2B RETRACT (00:45)	
1		2B RETRACT (00:45)	2B RETRACT (00:45)	-
01:00				01:00
				_
				_
_	· Verify MCC GO for DLA 2 Install	SARJ BRACE DEPLOY (2) (00:30)	SARJ BRACE DEPLOY (2) (00:30)	
	· Verily MIGG GO for DEA 2 Install			-
		CARLEI A INOTALL (04 00)	CARLLAUNCILL COMMANDE PETRANT REMOVAL (00.00)	
02:00		SARJ DLA INSTALL (01:00)	SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL (03:30) Remove Launch Locks (Covers 15, 8, 9, 10, 12, 13)	02:00
-				-
-	Perform DLA 2 engagement			-
03:00	T GHOITI DE LE GIIGAGGIIGHE	SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL (03:00)	1	03:00
		Remove Launch Locks (Covers 17, 16, 6, 7)		
-				-
				_
04-00				04:00
04:00				04:00
-				-
1				
05:00		· Remove Launch Restraints	· Remove Launch Restraints	05:00
-	Lock DLA	· MT/CETA Path clearing tasks as time permits	· MT/CETA Path clearing tasks as time permits	-
	LUCK DLA			-
00.00		CLEANUP/INGRESS (00:30)	CLEANUP/INGRESS (00:30)	00.00
06:00				06:00
-				
		PREREPRESS (00:05)	PREREPRESS (00:05)	-
		11.13.11.11.11.100 (00.00)	113E13E13E00 (00.00)	1

FS 7-37 EVA/117/FIN

# **PRE EVA 2 TOOL CONFIG**

	EV 3	AIRLOCK CONFIG	S1 TRUSS		
	MWS	Staging Bag	Safety Tether – S1 - HR 3214 (cable tray) strung to airlock		
	BRT (L)	Fuse Tether	Safety Tether– S1 - HR 3221 (nadir edge) strung to airlock		
	RET (eq-eq)	PGT S/N	Carety Founds of Thir OZZT (madii odgo) strang to amount		
-	Swing Arm (R)	PGT Battery S/N			
-	RET (eq-eq)	Wire Tie Caddy	S3 TRUSS		
	T-Bar	RAD S/N	APFR WIF S3-28 [2,PP,F,12]		
		Connector Cleaner Tool Kit	Crewlock EVA Bag – S3 - HR 3049		
-	RET (eq-eq)	Probe			
-	RET (eq-eq) w/PIP pin		Vise Grips		
-	Adj Equip Tether (2)	Prybar Connector Din Straightoner	Socket Caddy		
	Wire Tie (2)	Connector Pin Straightener	5/8 (rigid) Socket-7.8 ext		
-	Small Shuttle Trash Bag	Velcro/Tape Caddy	7/16 (rigid) Socket-2 ext		
-	D-ring Extender (2, R & L D-ring)	SLR Torque Multiplier	7/16 (rigid) Socket-9 ext		
-	Waist Tether (L D-ring)	IV Bag	RET (eq-eq) w/PIP pin		
	SAFER	Towels (2)	3/8-in IVA Tool Stack w/DPT Adapter		
	WVS	Contamination Detection Kit	ISS ratchet wrench		
		GP Caddy (2)	5/8 (rigid) Socket-7.8 ext		
	EV 4	Adjustable Thermal Mittens (2)	Round Torque Multiplier		
	MWS	Socket Caddy (hatch cont) w/ eq-eq RET	Rd TM Socket – 5/8 prd		
	BRT (L)	1/2 Socket-8 ext	RET (eq-lg) (outside of bag)		
	RET (eq-eq)	7/16 (wobble) Socket-6 ext (spare)			
	Wire Tie	DCM Plug (SAFER Hardmount) (2)			
	Swing Arm (R)	Fuse Tether	S4 TRUSS		
	RET (eq-eq)	PGT [A2 3.8ft-lb, CAL, MTL 30.5] S/N	APFR WIF S4-04 [6,PP,L,1]		
	PGT [ <b>A2</b> 3.8ft-lb, <b>CAL</b> , MTL <b>30.5</b> ] S/N	PGT Battery S/N			
	PGT Battery S/N	7/16 (wobble) Socket-6 ext			
	7/16 (wobble) Socket-6 ext	WIF Adapter w/PIP pin			
	T-Bar	Cheater Bar (w/ Tape)			
	RET (eq-eq)	1.5" Bail Drive Lever (taped to Cheater Bar)			
	RET (eq-eq) w/PIP Pin	Crewlock Bag			
	Adj Equip Tether	EVA Temporary Rail Stop (ETRS) S/N	NOTE		
	Wire Tie (2)	RET (eq-eq)(2)	Prior to use, perform the following		
	Small Shuttle Trash Bag	RET (eq-lg) (outside of bag)	hardware inspections:		
	D-ring Extender (2, R & L D-ring)	Crewlock Bag (2B Tools)	RET cords for fraying		
-	85 ft Safety Tether	Digital Camera	No red line visible on safety and waist tether load		
-	Waist Tether (L D-ring)	Digital Camera L bracket	Alleviation straps		
	SAFER	Compound Cutter/Needle Nose Pliers Caddy (w/ Tape)	Check BRT/Ballstack for loose screws and play		
	WVS	Loop Pin PullerCaddy (w/ Tape)	Check Kapton Tape on solar array tools for		
		TPS Scraper (w/ Kapton Tape)	damage		
		BRS Pin Contingency Tool (w/ Kapton Tape)	Inspect STS trash bags for deformation/damage		
	<del> </del>	RET (eq-lg) (outside of bag)	o. mopest of a tradit bags for deformation/daillage		
		Medium ORU Bag with SLRI 10	Shading indicates tools coming from STS		
		RET (eq-eq) (2)	Bold indicates tools required for Solar Array tasks		
	<u> </u>	Adj Equip Tether	Bolu iliulcates tools required for Solar Array (45%)		
	<del> </del>	<b>-</b>			
	<u> </u>	Large Trash Bag (empty)			
	<u> </u>	Adj Equip Tethers (2 eq-lg) (outside of bag)			
	L_	RET (eq-lg) (outside of bag)			

FS 7-38 EVA/117/FIN

# **EVA BRIEFING CARD**

EV1/3_		EV2/4		IV1		IV2
EVA Pro Depress Start pu PET 00	s to 10.2 ırge	(GMT)			:	
EVA Pr	Get-up Exercise Equipm Suit dor SAFER Airlock EV/IV c	plan – clothine protocol reent lock actioning plan – , MWS, tools depress revioum protocolsSRMS initia	vitie spe s, Cl ew ol	v if requi s – IV re cial requ L positio	ired espor uests	nsibilities
EV Crev	Egress	tions – tethe f tasks		/aps		
Genera	Get ahe Constra Caution RMS op	ure Review ead tasks iints – groun s and warnir perations – c ency proced	ngs omr	review n protoc		
Emerge	Lost too	mm alfunctions				
Post EV		fing respons ⁄A plan	ibili	ties		

Lessons learned from previous EVAs and general motherhood

#### **EVA 2 INHIBIT PAD**

### Orbiter

TCS

L12 1. √TCS POWER – OFF

**Ku-Band Antenna** 

MCC-H 1. √KU-BAND Mask – active

2. √KU-BAND EVA Protect Box – active

RCS

If EV crew < 27 ft from FRCS:

IV 1. √DAP: VERN, FREE, LO Z

O14,15,16 2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF

LOGIC (four) - OFF

3. √Above RCS config MCC-H

4. √RCS F – ITEM 1 EXEC (\*) IV

 $\sqrt{\text{JET DES F1U}}$  – ITEM 17 (\*)

F3U – ITEM 19 (\*)

F2U – ITEM 21 (\*)

# Ground

### **Ground Radar**

MCC-H 1. √TOPO console, ground radar restrictions in place for EVA

### **USOS**

#### **PCU**

MCC-H 1. √PCUs (two) operational in discharge mode and one of the following:

- A. CCS PCU EVA Hazard Control enabled
- B. No more than two arrays unshunted
- C. No more than two arrays pointed < 90 from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
  - A. No more than two arrays unshunted
  - B. No more than two arrays pointed < 90 from velocity vector

## **TRRJ DLA**

MCC-H

1. Starboard radiator TRRJ parked at 0 degrees

### **INHIBITS IF SOLAR ARRAY TASKS PERFORMED** S-BAND (SASA) Antennas

MCC-H

1. S1 SASA – Powered down

BGA

- 2. 2B BGA angle = 227.8125
- 3. 2B Motor State OFF
- 4. Latch 2 Pin Status Latched
- 5. 2B SSU Shunted

# **RSOS**

#### **SM Antennas**

1. Global Timing Sys 1(400.1 MHz) [GTS] – Deactivate MCC-M

2. ARISS (HAM radio) - Deactivate, or IV

VHF (144-146 MHz)TX only

#### **FGB Antennas**

IV 1. ARISS (HAM radio) - Deactivate, or

VHF (144-146 MHz)TX only

FS 7-40 EVA/117/FIN

# **NOTES, CAUTIONS, AND WARNINGS**

#### NOTES

- 1. Bolt install: report torque and turns
- 2. Bolt release: report torque and turns if different from published range
- EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD
- Toolbox doors must be closed with one latch per door when EV crew not in immediate vicinity

#### CAUTION

## Flight Specific

- A. SARJ Prep:
  - 1. During removal of inboard MLI cover fasteners:
    - Limit turn count to minimum required for fastener release
    - b. Minimize side loading bolt head
    - c. Maintain axial force on fastener to compress spring during rotation
  - During re-installation of MLI covers, do not re-install swing bolts on MLI covers
  - Avoid impacting the race ring with the DLA when the DLA is unconstrained
  - DLA must be held against the outer side of the SARJ race ring during follower arm deploy to avoid interference with structure
- B. Translation Path/Tether routing
  - 1. Avoid contact with S1/P1 Radiator Beam
  - During ingress route and fairleed safety tether forward of camera/light stanchions and trunions
  - 3. During translation to 2B retract activities, fairlead safety tether along P6 to clear SSRMS path

#### **ISS Generic Constraints**

- C. Electrical Cables:
  - 1. Avoid bend radius < 10 times cable diameter
- D. Fiber optic cables:
  - 1. Avoid bend radius < 10 times cable diameter
  - 2. Avoid pulling on harness during mate/demate
- E. For Structural Reasons:
  - Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
  - Avoid performing shaking motions (sinusoidal functions) more than four cycles
  - If any of these occur, wait 2-5 min to allow structural response to dissipate

#### F. Other:

- ITT Cannon connector: On demated connectors, do not rotate collar or manipulate cable/connector using collar or connector tool
- 2. WIS Antennas: do not use as handholds [Node 1, P6, Z1, P4, S4]
- 3. Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners can contaminate EMU [P6, P4, S4]
- MLI handholds are not rated for crewmember translation loads
- 5. CBM petal covers may not be used as handholds unless both launch restraint pins are engaged
- 6. Do not close hatch until EMU water OFF for 2 min

### CAUTION (Cont)

#### **ISS Generic Constraints**

- G. Avoid inadvertent contact with:
  - Grapple fixture shafts (dry lube)
  - 2. PIP pins
  - 3. EVA Crane [PMA 1]
  - 4. TCS Reflectors [PMA 2, PMA 3]
  - 5. APAS hardware [PMA 2, PMA 3]
  - 6. CETA Lights (Z-93 paint) [Lab, S1, Node 1]
  - Deployed MISSEs
  - 8. Passive UMAs
  - MBS VDU, MCU, CRPCMs and Cameras (tape radiative surface, silver Teflon)
  - 10. Deployed TUS cable
  - 11. S0 aft face radiator
  - 12. GPS Antennas (S13 paint) [S0]
  - 13. UHF Antennas [Lab, P1]
  - 14. ETCS Radiators [S1, P1]
  - EETCS/PV Radiator bellows and panels [P6, P4, S4, S6]
  - 16. SASA RF Group [Z1, S1, P6]
  - 17. Heat pipe radiators [Z1]
  - 18. PCU cathode and HCA ports [Z1]
  - 19. Ku-Band Antenna (SGANT) dish [Z1]
  - 20. CMG cover/shells [Z1]
  - 21. SSRMS Cameras
  - 22. Lab window shutter

FS 7-41 EVA/117/FIN

# NOTES, CAUTIONS, AND WARNINGS (Cont)

### WARNING

## Flight Specific

#### A. Solar Array

- Sharp edges:
  - a. SABB (skirt, swing bolts)
  - b. Solar cells
  - c. Springs along tension bar
  - d. Panel hinges
  - e. Guide cable burrs or frays
  - f. Mast Canister roller guides
  - g. Braided cables
  - h. Fastener exposed threads
  - i. Exposed bolts in rib cavities on mast canister
  - j. Keep hands away from SSRMS LEE opening, and snares
- 2. RF radiation exposure:
  - a. Stay 3 ft from S-Band (SASA) high gain antenna when powered [S1, P6]
  - b. Stay 1.3 ft from S-Band (SASA) low gain antenna when powered [S1, P6]
- 3. Avoid inadvertant contact with:
  - SSU, ECU, beta gimbal platform, mast canister, SAW blanket boxes unless the beta gimbal is locked and the motor is turned off
- 4. Pinch:
  - a. Lower SABB exposed reels and pulleys (guide wire and tensioning mechanisims)
  - b. Solar array mast during retraction
- Other
  - EV crew will ony contact energized surfaces with approved tools that have been insulated with Kapton tape to prevent molten metal and shock
  - b. Solar array to be manipulated will be shunted prior to EV crew entering worksite

#### B. SARJ Prep

 Sharp edge - spring loaded captive EVA fasteners (SARJ MLI cover bolts); ends of springs may protrude

### WARNING (Cont)

#### **ISS Generic Constraints**

- C. Avoid inadvertent contact with:
  - 1. Grapple fixture targets and target pins
  - 3. Stay 2 ft from S1/P1 radiator beam rotational envelope when beam is free to rotate
  - 4. Stay 5 ft from moving MT on face 1
  - 5. Stay inboard of SARJ when active
  - Power must be turned off to electrical connectors prior to mating/demating to preclude arcing/sparking

#### D. Handrails

 Handrails previously used for MISSE attachment may not be used as a safety tether point [A/L endcone 564 & 566, A/L Tank 2 nad/fwd & port/fwd, P6 5389]

#### E. Pinch

- 1. ITT Cannon Connector rotating housing
- 2. EV side of IV Hatch during Hatch operation (also snag hazard) [A/L]
- 3. LAB window shutter and CBM petal cover linkages during operation
- 4. NZGL connector linkage. Use caution when mating/locking
- F. RF radiation exposure
  - Stay 1 ft from UHF antenna when powered [Lab, P1, PLB]

#### G. Sharp Edges:

- 1. Inner edges of WIF sockets
- Back side of MMOD shield fasteners
- PMA umbilical launch restraints exposed threads
- 4. Adjustable Fuse Tether buckles stowed in Node
- Nickel coated braided copper ground straps may have fraved wires[P6, P4, S4]
- 6. Z1 handrail 6061 by the Ku-Band boom launch restraint [Z1]
- Exposed fasteners on back of Z1 U-jumper male QD panel, if nutplate cap missing
- Sharp edge mating surfaces of EVA connectors. Avoid side loads during mating.

## WARNING (Cont)

## ISS Generic Constraints (Cont)

#### H. Thermal:

- EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
- PMA handrails may be hot. Handling may need to be limited
- Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on
- 4. Uncovered trunnion pins may be hot
- SSRMS/MBS operating Cameras and lights may radiate large amounts of heat
- Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
- Stay 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor up
- Stay 0.5 ft away from PMA and MMOD shields > 325 degF
- 9. Do not touch EMU protective visor if temp has been < -134 for > 15 min
- No EMU TMG contact of PMAs and MMOD shields when temp > 320 degF
- 11. No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF

FS 7-42 EVA/117/FIN

# EVA 2 EGRESS/SETUP FOR SOLAR ARRAY (00:40)

IV/SSRMS	EV3	EV4
SSRMS at 2B SAW EVA Setup location	Initial Condition: Waist Tether (L) to A/L D-ring  EGRESS	Initial Condition: Waist Tether (L) to UIA D-ring, 85 ft safety tether to D-Ring Extender (R) EGRESS
WVS Software:     Select page – RF camera     Sel 'Advanced Controls'     S-Band Level (two) – Max	<ol> <li>Open A/L thermal cover</li> <li>Egress airlock</li> <li>Attach airlock 55 ft Safety Tether to D-ring extender (L); verify Locked</li> <li>√SAFER man isol vlv – open (down)</li> <li>√SAFER HCM – closed (down)</li> <li>Receive tools from EV4</li> <li>Receive/temp stow Crewlock Bag</li> <li>Connect EV4 safety tether to external airlock D-ring; verify locked</li> <li>Retrieve airlock 55 ft safety tether; stow on MWS</li> <li>Give EV4 GO for egress</li> </ol>	<ol> <li>Transfer Cheater Bar and WIF Adapter to EV3</li> <li>Transfer 2B Tools Crewlock Bag to EV3</li> <li>Transfer safety tether (cable end) to EV3</li> <li>On EV 3 GO, Egress A/L</li> <li>√SAFER man isol vlv – open (down)</li> <li>√SAFER HCM – closed (down)</li> <li>Close A/L thermal cover</li> <li>Retrieve Crewlock Bag</li> </ol>
SSRMS translate to 2B array	SETUP  11. Retrieve APFR from Z1-11; fairlead safety tether on Z1-6024  12. Translate to P6 HR 5327  13. GCA SSRMS for APFR install  14. Install WIF Adapter, tether point towards end effector  15. Install APFR in WIF adapter [12,PP,F,6]  16. Tether swap to SSRMS; verify locked  17. Stow airlock safety tether on P6-5327  18. Ingress APFR  19. Give SSRMS GO for translation to 2B array	SETUP  9. Translate to P6 HR 5307 via P6 aft/stbd (to avoid SASA KOZ); Fairlead safety tether at P6-5309  10. Temp stow Crewlock Bag and PGT on P6 HR 5307  11. Retrieve digital camera  WARNING SASA Keepout Zone 0.9 meters. Avoid translation forward of 2B four bar linkage  12. Translate to 2B mast canister

FS 7-43 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT (00:45)

Sharp edge/pinch point/shock hazard: Avoid EMU co  1. Lower SABB exposed reels and pulleys (gr  2. SABB skirt  3. Swing bolts  4. Springs on tension bar  5. Panel hinges  6. Guide wire frays  7. Braided cables  8. Fastener exposed threads  9. Exposed bolts in rib cavities on mast canis	contact with the following:
1. Verify glove gauntlets cover wrist disconnects 2. Determine SAW problem and perform corresponding SAW WORKAROUND 3. As body position allows inspect the following:  • Y-guides (4 per SABB should not be visible) • Center and outboard guide wire not rubbing against power Cable near pulley • Foam pads in SABB base 4. Prior to retract, GCA SSRMS and EMU 3 ft away from array plane 5. Give IV GO for retract 6. Monitor array retract; call ABORT if problem seen 7. Repeat steps 1 thru 6 until EVA PET = 1:15 or on MCC GO 7. R  2B CLEANUP 8. Give SSRMS GO for translation to APFR egress location 9. Egress APFR 10. Tether swap to airlock safety tether; verify locked 11. Relocate APFR from SSRMS to P6-11 [4,PP,F,6] 12. Retrieve WIF adapter 13. Translate to Airlock, retrieve fairlead 14. When EV4 waist tether locked, transfer EV4 safety tether to EV4 15. Transfer WIF Adapter and Cheater Bar to EV4 16. Receive PGT from EV4 17. Tether swap to S1 safety tether; verify locked 18. Stow both 55ft safety tether; verify locked 19. Receive Medium ORU Bag; stow on BRT 20. Transfer S1 safety tether to EV4 21. Receive/temp stow Crewlock Bag 19. Tiles 20. Transfer S1 safety tether to EV4 21. Receive/temp stow Crewlock Bag	

FS 7-44 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT (00:45) (Cont)

#### SAW WORKAROUND

#### Over-center Hinge Reset:

- A. GCA SSRMS to affected location on panel
- B. Use cheater bar to press metal panel hinge into normal configuration; avoid contact with guide wire

### Uneven Panel Distribution (causes stuck grommets during retract):

- C. GCA SSRMS to lower blanket box near center quide wire on affected solar array
- D. Use TPS scraper or cheater bar to evenly distribute panel folds along array (fluff); avoid contact with guide wire; GCA SSRMS along center guide wire as required

#### **Stuck Grommet:**

### **NOTE**

Provided a fray is not causing the grommet fault, panel fluffing near center guide wire will likely clear problems at all three guide wires

#### If guide wire fray NOT suspected:

- E. If backward folding panel still a potential, free specific grommet; do not fluff
- F. If backward folding panel not a concern, GCA SSRMS to affected panel near center guide wire
- G. Use TPS scraper or cheater bar to evenly distribute panel folds (fluff); avoid contact with guide wire
- H. If no joy; perform steps as is guide wire fray suspected

## If guide wire fray is suspected:

- I. GCA SSRMS to affected grommet
- J. Use TPS scraper or cheater bar to free grommet; repeat as necessary for lower panel grommets as guide wire fray retracts

#### Guide Wire Slack Due to Reel/Pulley Jam:

#### CAUTION

Guide wire can jump out of pulley track, attempt cable manipulation from inside blanket box first. If guide wire must be handled from outside of blanket box, avoid pulling guide wire to side of pulley plane

- K. Verify all grommets on affected guide wire are loose
- L. GCA SSRMS to lower blanket box near affected guide wire
- M. Use needle nose pliers to pull cable out of reel; allow cable to retract

#### Out of Plane Panels:

- N. Perform steps for stuck grommet
- O. If no joy; GCA SSRMS to goal posts of affected blanket
- P. Use gloved hand to realign STE loops between goal posts; avoid contact with FCC

#### Y-Guide Reset

- Q. Verify SABB is unlatched (low tension)
- R. Use BRS Pin Tool on short skirt stiffener to lift tension bar; TPS scraper can be used assist with tension bar manipulation
- S: Lower tension bar on to Y-guide


FS 7-45 EVA/117/FIN

# DEPLOY SARJ BRACES (00:30)

IV	EV3	EV4	
	SETUP  1. Translate to S1 (stanchion/trunion at 3282, 3234); verify safety tether anchor hooks locked 2. Temp stow Med ORU bag on S3 HR 3065 3. Translate to SARJ Brace (face 6) 4. Execute DEPLOY SARJ BRACE steps  □ SARJ Brace Face 6 (HR 3061) □ SARJ Brace Face 2 (HR 3052)	SETUP  1. Stow Crewlock Bag on S3 HR 3050; stage digital camera for use 2. Stow Medium ORU Bag on Face 4 with adj tethers to S3 HR 3065, 3066, lid straps to S4 HRs 2209, 2210 3. Stage Large Trash Bag with Adj tether on S3 HR 3057 4. Stage RET nearby for temp stowing launch locks 5. Translate to S3, SARJ Brace (face 3) 6. Execute DEPLOY SARJ BRACE steps  □ SARJ Brace Face 3 (HR 3055) □ SARJ Brace Face 5 (HR 3058)	
Installation Data SARJ Brace 2: TorqueTurns Installation Data SARJ Brace 3: TorqueTurns Installation Data SARJ Brace 5: TorqueTurns Installation Data SARJ Brace 6: TorqueTurns	DEPLOY SARJ BRACE  7. PGT[B6 24.0 ft-lb, CCW2 30 Release brace launch rest  8. Rotate brace away from diag  9. Re-insert launch restraint bol  10. Rotate brace and insert the d the SARJ bulkhead cup feat  11. PGT[B2 16.0 ft-lb, CW3 60 R Engage brace cone fasten	onal beam t into diagonal beam fitting ~1 turn louble cone assembly into ture  RPM, MTL 30.5]-6ext 7/16:	

FS 7-46 EVA/117/FIN

# SARJ DLA 1 INSTALL (01:00 PER DLA)



# SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL (03:30)

IV	EV3	EV4	
1. Prior to removal of last launch restraint/lock, verify DLA 1&2 in ENGAGE steps 7 & 8 complete (SODF: ASSY OPS: SARJ INITIAL ACTIVATION AND CHECKOUT)  WARNING Remain inboard of SARJ and limit motion until 1 DLA in LOCK  2. When Launch Restraint 2 removed: Inform MCC – all launch restraints removed  3. Notify EV crew when DLA locked	A. The following covers are nominally completed on EVA 1  Cover 1, 2, 3, 4, 11, 14, 18, 19, 20, 21, 22  B. Remove the following Launch Locks:  Cover 17, Face 5, Launch Lock 4 (BRT - 3059)  Cover 16, Face 5, Launch Lock 3 (BRT - 3058)  C. Reconfigure and ingress APFR: S3-28 [2,QQ,D,11]  Cover 6, Face 2, Launch Lock 11 (BRT - 3053)  D. Reconfigure and ingress APFR: S3-28 [2,QQ,C,9]  Cover 7, Face 3, Launch Lock 12 (BRT - 3054)  E. Retrieve ratchet wrench and configure 7/16 (rigid) 9 ext  F. Perform step 9 to break torque on Launch Restraints: 2, 1B, 6B, 5  G. Transfer ratchet wrench to EV4 or stow in Crewlock Bag  H. Remove the following Launch Restraints:  Launch Restraint 5 (BRT - 3068 - alternate 3060)  Launch Restraint 1B  On IV GO: Launch Restraint 2 (stow in Crewlock Bag on HR 3050) (BRT - 3054)  RELEASE SWING BOLTS  1. PGT[A1 2.5 ft-lb, CCW3 60 RPM, MTL 30.5]-6ext 7/16: 2. Verify fasteners swing open	A. Verify swing bolts released on covers 3, 11, 14, 22  B. Remove the following Launch Locks:  Cover 15, Face 5, Launch Lock 2 (BRT - 3067)  Cover 9, Face 3, Launch Lock 14 (BRT - 3054)  Cover 10, Face 3, Launch Lock 15 (BRT - 3055)  Cover 12, Face 4, Launch Lock 16 (BRT - 3065)  Cover 13, Face 4, Launch Lock 16 (BRT - 3066)  C. Retrieve ratchet wrench and configure 7/16 (rigid) 9 ext  D. Perform step 9 to break torque on Launch Restraints:  4B, 3B  E. Stow ratchet wrench in Crewlock Bag  F. Remove the following Launch Restraints:  Launch Restraint 4B  Launch Restraint 3B  G. Stow Large Trash Bag in Medium ORU Bag  H. Perform Medium ORU Bag tool inventory  I. If Get-Aheads to be performed, temp stow Medium ORU Bag on S3 HR 3049 (face 4); else stow on BRT	
	<ul> <li>Minimize side loading bolt h</li> <li>Maintain axial force on faste</li> </ul>	ead ener to compress spring during rotation	
	incrementally as required for release) 4. Remove MLI cover and temp stow 5. <b>PGT[B7</b> 25.5 ft-lb, <b>CCW3</b> 60 RPM, MTL <b>30.5]-6ext 7</b> / 6. Remove launch lock and stow 7. Re-position MLI cover	6: Release inboard MLI cover fasteners (4-6) =9 turns (add single turns  16: Release SARJ Launch Lock fasteners (4) ~13-15 turns  Engage inboard MLI cover fasteners (4-6) ~9 turns to torque	
Perform tool inventory	BREAK TORQUE AND REMOVE SARJ LAUNCH RESTRAI  9. Ratchet wrench: 7/16 (rigid) 9 ext: Break torque on 1  10. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/  11. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/  Release jack bolt (1) up to 3 turns  12. PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/  13. Remove clamshell from "mushroom-shaped" fitting; std	retaining bolts (2) (55 ft-lb) (16: Release retaining bolts (2) =9 turns (716: if launch restraint not loosened on "mushroom-shaped" fittings: (16: Release retaining bolts (2) ~9 turns	

FS 7-48 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE (01:00)

IV	EV3,4
Installation Data ETRS: Torque Turns Installation Data ETRS: Torque Turns	1. Coordinate with MCC-H/IV for GO to stow Drag Link/Keel Pin or the following tasks (note step 7 required prior to Keel Pin stow)  ETRS INSTALL  2. Retrieve Crewlock Bag with digital camera and ETRS 3. Install ETRS on nadir SARJ Rail Fitting  4. PGT[A3 4.8 ft-lb, CW2 30 RPM, MTL 30.5]-6ext 7/16: Tighten ETRS fasteners (2) ~4-6 turns
	5. Remove PIP pins (2) from S3 tether shuttle stop; stow In trash bag 6. Push tether shuttle stop inboard and rotate 90 degrees into stowage detents  APFR RELOCATES
Verify with MCC DLA Locked and give EV — Crew GO for translation outboard of SARJ	7. APFR S3-28 to S3-05 [6,PP,L,10] for Drag Link/Keel Pin 8. APFR: S4-04 to S4-19 (aft/nadir) [6,TT,J,11] (13a.1 get ahead)  REMOVE S3 SVS TARGET  CAUTION  The following precautions should be observed to prevent loss of SVS target fasteners during removal:  Limit turn count to minimum required for fastener release  Minimize side loading bolt head  Minital in said force on fastener to compress spring during rotation  9. PGT[A3 4.6 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/16: Release SVS target fasteners (4) (~12 turns)  10. Retrieve SVS target  IEA MMOD SHIELD BOLT RELEASE (GET AHEAD)  11. On IV GO, translate to IEA MMOD shield bolts, =1 turn  Release IEA MMOD Shield bolts, =1 turn  Fwd inboard (#1) (HR 2219)  Refuses IEA MMOD Shield and (#2) (HR 2227)  Aft outboard #3 (HR 2228)  Aft inboard (#4) (HR 2203)

FS 7-49 EVA/117/FIN

# EVA 2 CLEANUP/INGRESS (00:30)

	EV3	EV4
1. Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)	CLEANUP  1. Retrieve Crewlock Bag from S3 HR 3050 2. If Keel Pin Nut Clamp Bolts tight, retrieve Crewlock Bag from S3 HR 3049 3. Perform tool inventory 4. Translate to Airlock  INGRESS  5. Hand in Crewlock Bags 6. Stow EV4 safety tether on A/L circular handrail 7. Attach waist tether (L) to A/L D-ring; verify locked 8. Stow safety tether on A/L circular handrail  9. Ingress A/L 10. Remove SCU from stowage pouch Remove DCM cover Connect SCU to DCM, check locked 11. Water – OFF 12. Close thermal cover, attach Velcro strap  CAUTION Do not close hatch until EMU water off for 2 min  13. Verify no hardware blocking hatch 14. EV Hatch Handle – Preclose 15. EV Hatch – close and lock 16. Go to PRE-REPRESS Cue Card	CLEANUP  1. Retrieve Face 4 Medium ORU Bag 2. Perform tool inventory 3. Translate to Airlock  INGRESS  4. Open A/L thermal cover 5. Stow Medium ORU Bag in A/L 6. Ingress airlock 7. Attach waist tether (L) to UIA; verify locked 8. Retrieve Crewlock Bags from EV3 9. Release safety tether; hand to EV3 10. Remove SCU from stowage pouch Remove DCM cover Connect SCU to DCM, check locked 11. Water – OFF 12. Give EV3 GO for Ingress
	13. Verify no hardware blocking hatch 14. EV Hatch Handle – Preclose 15. EV Hatch – close and lock	

FS 7-50 EVA/117/FIN

# **POST EVA 2 TOOL CONFIG**

	EV 3	AIRLOCK CONFIG
	MWS	Staging Bag
	BRT (L)	Fish Stringer
	RET (eq-eq)	PGT
	SVS Target	PGT Battery
	Swing Arm (R)	Wire Tie Caddy
	RET (eq-eq)	RAD
	PGT	Connector Cleaner Tool Kit
	PGT Battery	Probe
	7/16 (wobble) Socket-6 ext	Prybar
	T-Bar	Connector Pin Straightener
	RET (eg-eg)	Velcro/Tape Caddy
-	,	SLR Torque Multiplier
	RET (eq-eq) w/PIP pin Adj Equip Tether (2)	·
-	• • • • • • • • • • • • • • • • • • • •	IV Bag Towels (2)
	Wire Tie (2) Small Shuttle Trash Bag	Contamination Detection Kit
	- J	
	D-ring Extender (2, R & L D-ring)	GP Caddy (2)
-	Waist Tether (L D-ring)	Adjustable Thermal Mittens (2)
-	SAFER	Socket Caddy (hatch cont) w/ eq-eq RET
	WVS	1/2 Socket-8 ext
	EV.4	7/16 (wobble) Socket-6 ext (spare)
	EV 4	DCM Plug (SAFER Hardmount) (2)
-	MWS	Fuse Tether
	BRT (L)	85 ft Safety Tether
	RET (eq-eq)	WIF Adapter w/PIP pin
	Wire Tie	Cheater Bar (w/ Tape)
	Swing Arm (R)	1.5" Bail Drive Lever (taped to Cheater Bar)
	RET (eq-eq)	Crewlock Bag
	PGT	Digital Camera
	PGT Battery	Digital Camera L Bracket
	7/16 (wobble) Socket-6 ext T-Bar	Launch Restraint
		RET (eq-eq)(2) RET (eq-lg) (lg hook to aft UIA HR)
-	RET (eq-eq)	( 1 0) (0
	RET (eq-eq) w/PIP Pin	Medium ORU Bag with SLRI 10
-	Wire Tie (2)	Launch Locks (10 total)
	Adj Equip Tether	RET (eq-eq) (2)
-	Small Shuttle Trash Bag	Adj Equip Tether
	D-ring Extender (2, R & L D-ring)	Large Trash Bag
	Waist Tether (L D-ring)	Launch Restraints (5)
	SAFER WVS	RET (eq-Lg)(outside of bag)
	VVVO	Adj Equip Tethers (2 eq-lg) (outside of bag)
		Crewlock Bag (2B Tools)
		Cutters/Needle Nose Pliers Caddy (w/ Tape)

Loop Pin Puller Caddy (w/ Tape)

BRS Pin Contingency Tool (w/ Tape)
RET (eq-Lg)(outside of bag)

TPS Scraper (w/ Tape)

S1 TRUSS Safety Tether – S1-HR 3214 (cable tray) strung to airlock Safety Tether – S1-HR 3221 (nadir edge) strung to airlock
S3 TRUSS  APFR WIF S3-05 [6,PP,L,10]  Crewlock EVA Bag  Vise Grips  Socket Caddy  5/8 (rigid) Socket-7.8 ext  5/8 (rigid) Socket-7.8 ext  7/16 (rigid) Socket-2 ext  RET (eq-eq) w/PIP pin  3/8-in IVA Tool Stack w/DPT Adapter  ISS ratchet wrench  7/16 (wobble) Socket-9 ext  Round Torque Multiplier  Rd TM Socket – 5/8 prd  RET (eq-Lg)(outside of bag)
S4 TRUSS APFR S4-19 (6,TT,J,11) (13A.1 prep)
Shading indicates trash items

FS 7-51 EVA/117/FIN

**EVA 2 TASK DATA** 

FS 7-52 EVA/117/FIN

# **DEPLOY SARJ BRACES - TASK DATA**

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	0:30

#### Tools:

EV3	EV4
PGT	PGT
7/16 (wobble) Socket-6 ext	7/16 (wobble) Socket-6 ext

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Brace cone fastener	No	7/16	4	NA	NA	22.1	37-39	60
Brace launch restraint fastener	No	7/16	4	12.1-15 gnd	16.9	32.3	10-11 release ~1 install	30

### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### Foot Restraints:

Task	WIF	APFR Setting
SARJ Brace Face 2, 3, 5, 6	NA	NA

#### Note:

- SARJ Braces lay longitudinally against the diagonal beam in a launch/stowed position ready for deployment. The SARJ brace is attached at one end to the diagonal beam with a rod and bearing allowing rotation and restrained at the opposite end. Brace restraint bolt is attached to diagonal beam via lanyard
- 2. Deployment of SARJ Braces is required prior to mating S5 to S4

#### Cautions:


 1 DLA must be in lock OR power must be off to RJMCs with both DLA pinion gears engaged to prevent freewheeling movement OR a minimum of one launch lock in place on the SARJ during this procedure

## Warnings:

None

FS 7-53 EVA/117/FIN

# **DEPLOY SARJ BRACES – TASK DATA** (Cont)



SARJ Brace (Launch position)



SARJ Brace Launch Restraint bolt (re-inserted into housing after brace release)



SARJ Brace Cup Cone placed in on-orbit position

FS 7-54 EVA/117/FIN

# SARJ DLA INSTALL - TASK DATA

#### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	NA

#### Tools:

EV3	EV4
PGT	NA
6 Ext 7/16	
APFR	
RET	
Adj. Equipment Tether	

#### **EVA Fasteners:**

ZVA Fasteriers.								
Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
MLI Cover Swing Bolts	NA	7/16	4 per cover	2.3-3.0	2.8	5.5	8-12	60
MLI Cover Inboard Fasteners	NA	7/16	4 per cover	3.1-3.6 gnd 0.8-3.8 on orbit	3.4	13.7	7-9	60 rmv 30 inst
DLA 1A and 2A Lock bolts	Yes	7/16	2 per	3.3 – 6.3	6.7	42.2	6	30
DLA 1C and 2C Draw Bolts	Yes	7/16	2 per	4.8 initial 19.4 final	0.8	38.9	38	30
DLA 4A, 4B, and 4C Launch Restraint Bolts	Yes	7/16	3 per	24-26	25	50 - A&B 75 - C	10-A&B 8-C	30
DLA 1B and 2B Follower arm rotation Bolts	Yes	7/16	2 per	NA	NA	10.6	5/8	10

#### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### Foot Restraints:

Task	WIF	APFR Setting
Cover 5 DLA 1 Face 2	S3-28	[2,PP,F,12]
Cover 20 DLA 2 Face 6	S4-04	[6,PP,L,1]

#### Notes:

- If any spring clamp assembly fails to snap completely out of the way, a gentle nudge may be required
- The bolts nearest the tether loop must be released prior to tethering to the shroud to avoid interference between the tether hook and PGT
- The outboard SARJ race ring side MLI cover bolts (spring clamp bolts) should be released prior to the inboard MLI cover bolts
- Cabling on the outboard side of the SARJ may interfere with DLA cover re-installation. The cover should be installed outboard side first, then inboard side
- To re-install the DLA cover, all bolts should be started before any are driven fully

#### Cautions:

- During re-installation of MLI covers, do not re-install spring clamp assemblies on the outboard SARJ race ring side (outboard fasteners). This will preclude SARJ rotation
- Any single failure of bolts/spring clamp assemblies will prevent SARJ activation
- Avoid impacting the race the ring with the DLA when the DLA is unconstrained
- During follower arm rotation (90 deg turn) when the DLA is still
  unconstrained, interference with structure may occur. The DLA must be
  held against the outer side of the SARJ race ring for the follower arm to
  rotate fully clearing obstruction

#### Warnings:


None

FS 7-55 EVA/117/FIN

# SARJ DLA INSTALL – TASK DATA (Cont)







FS 7-56 EVA/117/FIN

# SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL - TASK DATA

## **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	0:20/LL, 0:15/LR

## Tools:

EV3	EV4
PGT	PGT
6 Ext 7/16	6 Ext 7/16
APFR (backup)	APFR (backup)
Medium ORU transfer bag w/SLRI	Medium ORU transfer bag w/SLRI
Large Trash Bag	Ratchet wrench w/9 Ext rigid
If SLR Torque Multiplier rea d - no socke	et ext needed

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
MLI Cover Swing Bolts	NA	7/16	1-4 per cover	2.3-3.0	2.8	5.5	8-12	60
MLI Cover Inboard Fasteners	NA	7/16	4-6 per cover	3.1-3.6 gnd, 2.5 on orbit	3.4	13.7	7-9	60 rmv 30 inst
SARJ Launch Lock Fasteners	NA	7/16	4 per lock	22.1-23.7	32.6	148.5	13-15	60
SARJ Launch Restraint Fastener	NA	7/16	2 per	52.1-56.3	55.4	165.2	17	60
SARJ Launch Restraint Jack Screw	NA	7/16	1 per	3.9-12.5	12.0	139.3	3, 9 max	60

#### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

### Foot Restraints:

Foot Restraints:		•	
Task	WIF	APFR w/ PGT	APFR w/ Torque Mult
Cover 1 Launch Lock (#8 ) Face 1	S3-31	7,RR,F,11	
Cover 2 Launch Lock (#9 ) Face 1	S3-31	7,RR,F,11	
Launch Restraint 1 B	S4-05	10,PP,H,12	10,PP,J,2
Cover 3 Face 1 – 2	S4-05	10,PP,F,1	
Cover 4 Launch Lock (#10 ) Face 2	S4-05	10,QQ,H,1	
Cover 5 DLA 1 Face 2	S3-28	2,PP,F,12	
Cover 6 Launch Lock (#11 ) Face 2	S3-28	2,QQ,D,11	
Launch Restraint 2	S3-29	9,QQ,E,11	9,QQ,E,12
Cover 7 Launch Lock (#12 ) Face 3	S3-29	9,QQ,E,12	
Cover 8 Launch Lock (#13 ) Face 3	S3-29	10,TT,F,12	
Cover 9 Launch Lock (#14 ) Face 3	S3-29	10,TT,F,12	
Cover 10 Launch Lock (#15 ) Face 3	S3-36	12,PP,A,1	
Launch Restraint 3 B	S4-06	3,SS,G,3	2,NN,F,12
Cover 11 Face 3 – 4	S3-36	12,PP,A,1	
Cover 12 Launch Lock (#16 ) Face 4	NA	NA	
Cover 13 Launch Lock (#1 ) Face 4	NA	NA	
Launch Restraint 4 B	S3-35	6,QQ,B,1	6,QQ,A,12
Cover 14 Face 4 – 5	S3-35	6,QQ,B,1	
Cover 15 Launch Lock (#2 ) Face 5	S3-34	1,TT,F,12	
Cover 16 Launch Lock (#3 ) Face 5	S3-34	10,PP,B,1	
Cover 17 Launch Lock (#4 ) Face 5	S3-30	9,PP,H,12	
Cover 18 Launch Lock (#5 ) Face 5	S3-30	9,PP,G,12	
Launch Restraint 5	S3-30	9,PP,F,12	9,PP,E,11
Cover 19 Launch Lock (#6 ) Face 6	S3-30	9,PP,F,12	
Cover 20 DLA 2 Face 6	S3-27	10,00,F,12	
Cover 21 Launch Lock (#7 ) Face 6	S3-31	5,QQ,E,1	
Launch Restraint 6 B	S3-31	5,QQ,E,1	5,00,E,1
Cover 22 Face 1 – 6	S3-31	5,QQ,E,1	

FS 7-57 EVA/117/FIN

# SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL - TASK DATA (Cont)

#### Notes:

- If any spring clamp assembly fails to snap completely out of the way, a gentle nudge may be required
- There is no hardware constraint to the order of launch lock or launch restraint removal however to
  ensure that the launch restraint break away torque is below certified limits of EVA tools, it is
  recommended that the trunion longeron SLRs (#2 or #5) are removed last
- 3. All launch locks must be removed prior to any launch restraints. Ref flight rule C2-55
- The bolts nearest the tether loop must be released prior to tethering to the shroud to avoid interference between the tether hook and PGT
- 5. The outboard swing bolts on the MLI covers should be released prior to the inboard cover bolts
- 6. When releasing the last SARJ launch lock, the two outboard bolts should be released prior to the inboard launch lock captive bolts
- 7. The SARJ Launch Restraint (SLR) comes off in three attached pieces via lanyards. The SLR consists of two clam shell halves retained by two (2) captive EVA bolts on the outer edges, with a central EVA jackscrew and a EVA tether loop on the upper half of the clamshell assembly
- 8. The IVA Tool Stack consists of the following: 1/4-in to 3/8-in female adapter, 1/4-in drive 4-in ext, 1/4-in drive universal joint, 1/4-in drive 3/8-in shallow-well socket, drop proof tether adapter


#### Cautions:

- During re-installation of MLI covers, do not re-install swing bolts on the outboard SARJ race ring side (outboard bolts). This will preclude SARJ rotation
- When using the jackscrew to release the launch restraint, do not exceed 9 turns. Half "moonshaped" nuts on jackscrew may become detached if turned more than 9 times
- 3. Any single failure of bolts/latch assemblies will prevent SARJ activation
- 4. During removal of inboard MLI cover fasteners:
  - Limit turn count to minimum required for fastener release
  - Minimize side loading bolt head
  - Maintain axial force on fastener to compress spring during rotation

#### Warnings:

- Prior to the removal of the last launch structure (launch lock or launch restraint), power must be off to the RJMCs and both deployed DLA pinion gears must be engaged to prevent free rotation of the SARJ
- After removal of the last launch lock or launch restraint, crewmembers cannot translate outboard of SARJ until one DLA is in LOCK





SARJ Launch Locks - Face 1

FS 7-58 EVA/117/FIN

# SARJ LAUNCH LOCK/LAUNCH RESTRAINT REMOVAL - TASK DATA (Cont)



SARJ Launch Restraints – Face 1



SARJ Rail Alignment Pin

FS 7-59 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	0:30

#### Tools:

EV1	EV2
PGT	PGT
7/16 (wobble) Socket-6 ext	7/16 (wobble) Socket-6 ext
	EVA Temp Rail Stop

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
MMOD Shield Bolt	Yes	7/16	4	37.5 gnd	42.2	93.5	1	10
SVS Target bolts	No	7/16	4	3.3-4.2	3.8	7.5	11.5	60
ETRS Bolts	No	7/16	2	4.2-6.6	NA	12.8	4-6	30

### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

## Foot Restraints:

Task	WIF	APFR Setting
Forward Inboard (#1)	S4-06	[7,WW,F,1]
Forward Outboard (#2)	S4-14	[6,WW,F12]
Aft Outboard Bolt (#3)	S4-13	[6,WW,F12]
Aft Inboard Bolt (#4)	S4-05	[7,WW,F,1]

### Note:

1. Requirement for releasing torque on IEA MMOD Shield Bolts is within 1 year of launch

#### Cautions:

- ETRS bolts are not captive. Bolts may be lost if released more than 15 turns
   During removal of SVS fasteners:
- - Limit turn count to minimum required for fastener release
  - Minimize side loading bolt head
  - Maintain axial force on fastener to compress spring during rotation

## Warnings:


None



IEA MMOD Shield Bolt

FS 7-60 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE – TASK DATA (Cont)



Tether Shuttle Stop – launch configuration



P3 Tether Shuttle Stop (stowed)



EVA Temporary Rail Stop (ETRS)



S3 SVS Target

FS 7-61 EVA/117/FIN

This Page Intentionally Blank

FS 7-62 EVA/117/FIN

# **EVA 3 SUMMARY TIMELINE**

TIME HR : MIN	IV	EV1 (RY)	EV2 (OL)	
00:00		POST DEPRESS (00:05)	POST DEPRESS (00:05)	00:00
		EGRESS/SETUP (00:40)	EGRESS/SETUP (00:40)	-
_				-
		2B RETRACT	2B RETRACT	_
01:00				01:00
_				
02:00				02:00
02.00				02.00
-				
_				
-				
03:00				03:00
-				-
-				-
-	THE FOLLOWING TASKS CAN BE PERFORMED			-
04:00	AFTER 2B RETRACT IF TIME PERMITS, OR ON EVA 4:			04:00
-	<ul> <li>S3 DRAG LINK/KEEL PIN STOW (01:00)</li> <li>S3/S4 CLOSEOUT (up to 01:00)</li> </ul>			-
	<ul> <li>H2O/H2 VENT VALVE R&amp;R (01:30)</li> </ul>			
	<ul><li>LAB EWIS ANTENNA INSTALL (01:30)</li><li>NODE/SM LAN CABLE ROUTING (01:00)</li></ul>			-
05:00	<ul><li>SASA GIMBAL LOCKS (0:30)</li><li>GPS ANTENNA 4 REMOVAL (0:40)</li></ul>			05:00
	<ul> <li>ETVCG STANCHION INSTALL (0:45)</li> <li>S3 PAS DEPLOY (01:00 + translation)</li> </ul>			-
_	,,			
06:00		CLEANUP/INGRESS (00:35)	CLEANUP/INGRESS (00:35)	06:00
00.00				00.00
		PREREPRESS (00:05)	PREREPRESS (00:05)	

FS 7-63 EVA/117/FIN

# EVA 3

# **PRE EVA 3 TOOL CONFIG**

	F1/ 4		AIRLOOK CONFIG		AIDLOCK (Comt)
	EV 1		AIRLOCK CONFIG		AIRLOCK (Cont)
-	MWS		Staging Bag	-	Crewlock Bag (Solar Array Tools)
	BRT (L)		Fuse Tether		BRS Pin Contingency Tool (w/Tape)
	RET (eq-eq)		PGT S/N		Loop Pin Puller (w/Tape)
	Swing Arm (R)		PGT Battery S/N		TPS Scraper (w/Tape)
	RET (eq-eq)		Wire Tie Caddy		Compound Cutter/Needle Nose Pliers Caddy
	T-Bar		RAD S/N		(w/Tape)
	RET (eq-eq) (2)		Connector Cleaner Tool Kit		EVA Scissors (w/Tape)
	WIF Adapter w/PIP pin		Probe		Digital Camera
	RET (eq-eq) w/PIP pin		Prybar		Digital Camera L bracket
	Wire Ties (2)		Connector Pin Straightener		Small ORU Bag (GPS)
	Small Shuttle Trash Bag		Velcro/Tape Caddy		RET (eg-eg)
	Adj Equip Tethers (2, L & R gloves)		IV Bag		GPS Connector Caps (2 – long wire tied together)
	D-Ring Extender (2, R & L)		Towels (2)		RET (eq-lg) (outside of bag)
	Waist Tether (2, L D-ring and R ext)		Contamination Detection Kit		S3 TRUSS
	SAFER		GP Caddy (2)		Crewlock EVA Bag – S3 – HR 3049
	WVS		Adjustable Thermal Mittens (2)		Vise Grips
	_ *****		Socket Caddy (hatch cont) w/eg-eg RET		Socket Caddy
	EV 2		1/2 Socket-8 ext		5/8 (rigid) Socket-7.8 ext
	MWS		7/16 (wobble) Socket-6 ext (spare)	-	5/8 (rigid) Socket-7.8 ext
	BRT (L)		DCM Plug (SAFER Hardmount) (2)		7/16 (rigid) Socket-2 ext
-	1 1			-	
	Wire Ties (3)		Fuse Tether		RET (eq-eq) w/PIP pin
-	RET (eq-eq)		SLR Torque Multiplier (if SLRs still to be removed)		3/8-in IVA Tool Stack w/DPT Adapter
	Swing Arm (R)		NODE/LAN cable		ISS ratchet wrench
	RET (eq-eq)		PGT [B1 12 ft-lb, CAL, MTL 30.5] S/N		7/16 (rigid) Socket-9 ext
	PGT [A1 2.5 ft-lb, CAL, MTL 30.5] S/N		PGT Battery S/N		Round Torque Multiplier
	PGT Battery S/N		7/16 (wobble) Socket-6 ext		Rd TM Socket – 5/8 prd
	7/16 (wobble) Socket-6 ext		Cheater Bar (w/Kapton Tape)		RET (eq-Lg) (outside of bag)
	T-Bar		1.5" Bail Drive Lever (taped to Cheater Bar)		External APFRs
	RET (eq-eq) (3)		Crewlock Bag (Vent Tools)		S4-19 (13A.1 prep)
	RET (eq-eq) w/pip-pin		Gamah Removal Tool		S3-05
	Wire Ties (2)		Gamah Installation Tool		P6-4B
	Small ISS Trash Bag		Ratchet Wrench w/palm wheel		P6-11
	Adj Equip Tethers (2, L & R gloves)		7/16 rigid Socket-2 ext		S0-07
	D-ring Extender (2, R & L)		H2 Vent Assembly w/sock		IAPFR Z1-3
	85-ft Safety Tether		RET (eq-eq) (3)		IAPFR Z1-1
	Waist Tether (2, L D-ring and R ext)		MMOD T-Handle Tool (2)		55-ft Safety Tether (2) – Airlock External
	SAFER		RET (eq-lg) (outside of bag)		85-ft Safety Tether – HR 3214 strung to airlock
	WVS		EWIS ORU Bag (Medium)		85-ft Safety Tether – HR 3221 strung to airlock
	_		Fuse Tether		<u>NOTE</u>
			EWIS Cable		Prior to use, perform the following hardware inspections:
			OIH 297		RET cords for fraying
			OIH 298		2. No red line visible on safety and waist tether load
			Small ISS Trash Bag		Alleviation straps
			RET (eq-eq) (2) (outside of bag)		3. Check BRT/Ballstack for loose screws and play
	'	1	( 1 - 4) ( ) (		Check Kapton Tape on solar array tools for
					damage
					<ol><li>Inspect STS trash bags for deformation/damage</li></ol>
					-

FS 7-64 EVA/117/FIN

## **EVA 3 INHIBIT PAD**

## Orbiter

TCS

L12 1. √TCS POWER – OFF

**Ku-Band Antenna** 

MCC-H

1. √KU-BAND Mask – active

2. √KU-BAND EVA Protect Box – active

RCS

If EV crew < 27 ft from FRCS:

IV 1. √DAP: VERN, FREE, LO Z

O14,15,16 2. √RJDF F1, F2, F3, F4 MANF DRIVER (four) – OFF

LOGIC (four) - OFF

MCC-H

IV

3. √Above RCS config

4. √RCS F – ITEM 1 EXEC (\*)

 $\sqrt{\text{JET DES F1U}} - \text{ITEM 17 (*)}$ 

F3U - ITEM 19 (\*)

F2U - ITEM 21 (\*)

S-Band Antennas (during Lab endcone tasks)

Possible loss of comm when forced LL FWD antenna

IV If EV crew < 1.6 ft from S-Band antenna:

A1R 1. S-BAND FM ANT – XMIT LOWER/RCVR UPPER

2. √MCC, lower antenna selected

If no comm, or on MCC call:

C3 3. S-BAND PM ANT - LL FWD

When EVA crewmember at least 1.6 ft away from all S-Band

upper antennas:

4. S-BAND PM ANT - GPC C3

# Ground

## **Ground Radar**

MCC-H 1. √TOPO console, ground radar restrictions in place for EVA

## **USOS**

## **PCU**

MCC-H 1. √PCUs (two) operational in discharge mode and one of the following:

- A. CCS PCU EVA Hazard Control enabled
- B. No more than two arrays unshunted
- C. No more than two arrays pointed < 90 from velocity vector

OR

- 2. One or no PCUs operational in discharge mode and one of the following:
  - A. No more than two arrays unshunted
  - B. No more than two arrays pointed < 90 from velocity

### **LAB Window**

IV

If EV crew < 10 ft from window, close window shutter

## **INHIBITS IF SOLAR ARRAY TASKS PERFORMED** S-BAND (SASA) Antennas

MCC-H

1. S1 SASA – Powered down

BGA

- 2. 2B BGA angle = 227.8125
- 3. 2B Motor State OFF
- 4. Latch 2 Pin Status Latched
- 5. 2B SSU shunted

### TRRJ DLA

MCC-H

1. Starboard radiator TRRJ parked at 0 degrees

#### SARJ

MCC-H

If EV crew working within 2 ft or outboard of SARJ:

- 1. √DLA (1) LOCKED
- 2. All motor setpoints set to zero
- 3. All motors deselected

OR

Both DLAs – LOCKED

FS 7-65 EVA/117/FIN

# **EVA 3 INHIBIT PAD (Cont)**

# **RSOS**

IV

# **SM Antennas**

MCC-M 1. Global Timing Sys 1(400.1 MHz) [GTS] – Deactivate

ARISS (HAM radio) – Deactivate or VHF (144-146 MHz)
 TX only

### **FGB Antennas**

IV 1. ARISS (HAM radio) – Deactivate or VHF (144-146 MHz)

TX only

MCC-M 2. √FGB KURS P [KYPC P] – Deactivated

# Soyuz Antenna

MCC-M 1. √Soyuz KURS A [KYPC A] – Deactivated

## **FGB Thrusters**

MCC-M

- 1. √FGB MCS unpowered
- 2. √All FGB Attitude Control Thruster Valves (80) closed
- 3. √FGB Attitude Control Manifold Valves closed КШК1, КШК2, КШК4, КШК5, КШК9, ОКО3, ОКГ3, ОКО6, ОКГ6, ОКО7, ОКГ 7, ОКО8, ОКГ8

# **Soyuz Thrusters**

MCC-M

- 1. √Soyuz manifolds (4) closed ЭКО1, ЭКО2, ЭКГ1, ЭКГ2
- 2. √Soyuz MCS unpowered
- 3. √Soyuz Attitude Control Thruster Valves (52) closed
- 4. √Soyuz Main Engine Valves closed (K1, K2, K3, K4, K5, K6)

FS 7-66 EVA/117/FIN

# **NOTES, CAUTIONS, AND WARNINGS**

## EVA 3

### **NOTES**

- 1. Bolt install: report torque and turns
- Bolt release: report torque and turns if different from published range
- EVA connectors: after disconnection and prior to connection; verify pin and EMI band integrity; verify connector free of FOD
- 4. Inspect QDs for damage prior to mating
- Toolbox doors must be closed with one latch per door when EV crew not in immediate vicinity

## **CAUTION**

#### Flight Specific

- A. Translation Path/Tether routing
  - 1. Avoid contact with S1/P1 Radiator Beam
  - 2. During translation to 2B retract activities, fairlead safety tether along P6 to clear SSRMS path

#### ISS Generic Constraints

- B. Electrical Cables:
  - 1. Avoid bend radius < 10 times cable diameter
- C. Fiber optic cables:
  - 1. Avoid bend radius < 10 times cable diameter
  - 2. Avoid pulling on harness during mate/demate
- D. Fluid line flex hoses and QDs
  - Avoid bend radii < 5 in for hoses with diameter</li>
     1 in on LAB, S0, S1, P1, and 10-in for hoses with diameter < 1-in on all other elements</li>
  - Avoid bend radii < 14 in for hoses with a diameter ≥ 1 in</li>
  - Additional care should be taken to not exceed bend radii when applying loads at the flexible hose to rigid tube stub interfaces
  - Ensure fluid QD booties are fully closed prior to leaving worksite; wire tie if reqd
- E. For Structural Reasons:
  - Avoid vigorous body motions, quick grabs and kickoffs against tether restraints
  - 2. Avoid performing shaking motions (sinusoidal functions) more than four cycles
  - If any of these occur, wait 2-5 min to allow structural response to dissipate

#### F. Other

- ITT Cannon connector: On demated connectors, do not rotate collar or manipulate cable/connector using collar or connector tool
- 2. WIS Antennas: do not use as handholds [Node 1, P6, Z1, P4, S4]
- 3. Lubricant from Ku-Band SGANT gimbals [Z1], CMGs [Z1], and RTAS Ground Strap fasteners can contaminate EMU [P6, P4, S4]
- 4. MLI handholds are not rated for crewmember translation loads
- CBM petal covers may not be used as handholds unless both launch restraint pins are engaged
- 6. Do not close hatch until EMU water OFF for 2 min

## CAUTION (Cont)

#### **ISS Generic Constraints**

- G. Avoid inadvertent contact with:
  - 1. Grapple fixture shafts (dry lube)
  - 2. PIP pins
  - 3. EVA Crane [PMA 1]
  - 4. TCS Reflectors [PMA 2, PMA 3]
  - 5. APAS hardware [PMA 2, PMA 3]
  - 6. CETA Lights (Z-93 paint) [Lab, S1, Node 1]
  - 7. Deployed MISSEs
  - 8. Passive UMAs
  - 9. MBS VDU, MCU, CRPCMs and Cameras (tape radiative surface, silver Teflon)
  - 10. Deployed TUS cable
  - 11. S0 aft face radiator
  - 12. GPS Antennas (S13 paint) [S0]
  - 13. UHF Antennas [Lab, P1]
  - 14. ETCS Radiators [S1, P1]
  - 15. EETCS/PV Radiator bellows and panels [P6, P4, S4, S6]
  - 16. SASA RF Group [Z1, S1, P6]
  - 17. Heat pipe radiators [Z1]
  - 18. PCU cathode and HCA ports [Z1]
  - 19. Ku-Band Antenna (SGANT) dish [Z1]
  - 20. CMG cover/shells [Z1]
  - 21. SSRMS Cameras
  - 22. Open CBM petal covers and Lab window shutter

FS 7-67 EVA/117/FIN

# NOTES, CAUTIONS, AND WARNINGS (Cont)

#### WARNING

#### Flight Specific

- A. Solar Array
  - Sharp edges:
    - a. SABB (skirt, swing bolts)
    - b. Solar cells
    - c. Springs along tension bar
    - d. Panel hinges
    - e. Guide cable burrs or frays
    - f. Mast Canister roller quides
    - g. Braided cables
    - h. Fastener exposed threads
    - i. Exposed bolts in rib cavities on mast canister
    - j. Keep hands away from SSRMS LEE opening, and snares
  - 2. RF radiation exposure:
    - a. Stay 3 ft from S-Band (SASA) high gain antenna when powered [S1, P6]
    - b. Stay 1.3 ft from S-Band (SASA) low gain antenna when powered [S1, P6]
  - Avoid inadvertant contact with:
    - a. SSU, ECU, beta gimbal platform, mast canister, SAW blanket boxes unless the beta gimbal is locked and the motor is turned off
  - 4. Pinch:
    - a. Lower SABB exposed reels and pulleys (guide wire and tensioning mechanisims)
    - b. Solar array mast during retraction
  - 5. Other:
    - EV crew will only contact energized surfaces with approved tools that have been insulated with Kapton tape to prevent molten metal and shock
    - Solar array to be manipulated will be shunted prior to EV crew entering worksite
- B. QDs
  - If QD is in FID when valve is opened (bail fwd), QD will leak and fluid line may whip
- 2. 2. Do not rotate if in mated/valve open config

### WARNING (Cont)

#### ISS Generic Constraints

- C. Avoid inadvertent contact with:
  - 1. Grapple fixture targets and target pins
  - 2. Stay 2 ft from S1/P1 radiator beam rotational envelope when beam is free to rotate
  - 3. Stay 5 ft from moving MT on face 1
  - 4. Stay inboard of SARJ when active
  - Power must be turned off to electrical connectors prior to mating/demating to preclude arcing/sparking
- D. Handrails
  - Handrails previously used for MISSE attachment may not be used as a safety tether point [A/L endcone 564 & 566, A/L Tank 2 nad/fwd & port/fwd, P6 5389]
- E. Pinch
  - 1. ITT Cannon Connector rotating housing
  - 2. EV side of IV Hatch during Hatch operation (also snag hazard) [A/L]
  - 3. LAB window shutter and CBM petal cover linkages during operation
  - NZGL connector linkage. Use caution when mating/locking
- F. RF radiation exposure
  - 1. Stay 1 ft from UHF antenna when powered [Lab, P1, PLB]
- G. Sharp Edges:
  - Inner edges of WIF sockets
  - 2. Back side of MMOD shield fasteners
  - 3. PMA umbilical launch restraints exposed threads
  - Adjustable Fuse Tether buckles stowed in Node Bag
  - 5. Nickel coated braided copper ground straps may have frayed wires [P6, P4, S4]
  - 6. Z1 handrail 6061 by the Ku-Band boom launch restraint [Z1]
  - 7. Exposed fasteners on back of Z1 U-jumper male QD panel, if nutplate cap missing
  - 8. Sharp edge mating surfaces of EVA connectors. Avoid side loads during mating
  - Spring loaded captive EVA fasteners (e.g., SARJ MLI cover bolts); the end of the spring may protrude

## WARNING (Cont)

#### ISS Generic Constraints (Cont)

- H. Thermal:
  - EVA connectors with booties may become hot if left uncovered. Handling may need to be limited
  - PMA handrails may be hot. Handling may need to be limited
  - Turn off glove heaters when comfortable temp reached to prevent bladder damage. Do not pull fingers out of gloves when heaters are on
  - 4. Uncovered trunnion pins may be hot
  - SSRMS/MBS operating Cameras and lights may radiate large amounts of heat
  - 6. Stay 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
  - Stay 1 ft away for no more than 15 min from PMAs and MMOD shields > 300 degF if EMU sun visor up
  - Stay 0.5 ft away from PMA and MMOD shields > 325 degF
  - 9. Do not touch EMU protective visor if temp has been < -134 for >15 min
  - No EMU TMG contact of PMAs and MMOD shields when temp > 320 degF
  - 11. No EMU boot contact with foot restraint when temp < -120 degF or > 200 degF

FS 7-68 EVA/117/FIN

# EVA 3 EGRESS/SETUP (00:40)

IV/SSRMS	EV1	EV2
SSRMS at 2B SAW EVA Setup location  1. WVS Software: Select page – RF camera Sel 'Advanced Controls' S-Band Level (two) – Max	Initial Condition: Waist Tether (L) to A/L D-ring  EGRESS  1. Open A/L thermal cover 2. Egress airlock 3. Attach airlock 55-ft Safety Tether to D-ring extender (L); verify locked 4. √SAFER man isol vIv – open (down) 5. √SAFER HCM – closed (down) 6. Retrieve airlock 55-ft safety tether; stow on MWS 7. Receive cheater bar from EV2 8. Receive/temp stow Crewlock Bag 9. Connect EV2 safety tether to external airlock D-ring; verify locked 10. Give EV2 GO for egress	Initial Condition: Waist Tether (L) to UIA D-ring, 85-ft safety tether to D-Ring Extender (R)  EGRESS   1. Transfer cheater bar to EV1 2. Transfer 2B Tools Crewlock Bag to EV1 (RET stays on bag) 3. Transfer safety tether (cable end) to EV1 4. Egress A/L 5. √SAFER man isol vlv – open (down) 6. √SAFER HCM – closed (down) 7. Close A/L thermal cover 8. Retrieve Crewlock Bag
SSRMS translate to 2B     Array	SETUP  11. Translate to P6-11; fairlead safety tether on Z1-6024  12. GCA SSRMS for APFR install  13. Install WIF Adapter, tether point towards end effector  14. Relocate APFR from P6-11 to WIF adapter [12,PP,F,6]  15. Tether swap to SSRMS; verify locked  16. Ingress APFR  17. Give SSRMS GO for translation to 2B array	SETUP  9. Translate to P6 HR 5307 via P6 aft/stbd (to avoid SASA KOZ); Fairlead safety tether at P6-5309  10. Temp stow Crewlock Bag on P6 HR 5307  11. Temp stow PGT, retrieve digital camera  WARNING SASA Keepout Zone 0.9 meters. Avoid translation forward of 2B four bar linkage  12. Translate to 2B mast canister

FS 7-69 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT (02:00 to 05:00)

IV/SSRMS	EV1	EV2
	Sharp edge/pinch point/shock hazard: Av	d pulleys (guide wire and tensioning mechanisms)  mast canister
	<ol> <li>Verify glove gauntlets cover wrist disconnects</li> <li>Determine SAW problem and perform corresponding SAW WORKAROUND</li> <li>If not performed on EVA 2 inspect the following:         <ul> <li>Y-guides (4 per SABB should not be visible)</li> <li>Center, outboard guide wire not rubbing against power cable</li> <li>Foam pads in SABB base</li> </ul> </li> <li>Prior to retract, GCA SSRMS and EMU 3 ft away from array plane</li> </ol>	Verify glove gauntlets cover wrist disconnects     Assist EV1 with clearance and tool management     As reach with tool permits free grommets on inboard guide wire  4. Prior to retract, translate below Mast Canister separation plane
	5. Give IV GO for retract 6. Monitor array retract; call ABORT if problem seen 7. Repeat steps 1 thru 6 until mast retracted to one b 8. Perform SABB/SAW survey to verify the following:  □ Blanket fully contained within blanket box  □ Outboard STE loops neatly stacked within goal  □ Upper blanket box cover guide pins/alignment t  □ Guide wires (3 per SABB) retracted with no slad 9. Give IV GO for final bay retraction 10. Verify guide wires remain tight and grommets are in 11. If latching to be performed, verify latches aligned a	posts abs aligned with goal posts ck not caught between panels
SSRMS to APFR egress location	2B CLEANUP  12. Give SSRMS GO for translation to APFR egress location 13. Egress APFR 14. Tether swap to airlock safety tether; verify locked 15. Retrieve APFR/ WIF adapter 16. Relocate APFR to Z1-11 [2,TT,H,11]; retrieve fairlead 17. Translate to Airlock 18. Transfer WIF Adapter, cheater bar to EV2 19. Tether swap to S1 safety tether; verify locked 20. Stow both 55 ft safety tethers on airlock external D-ring; verify hooks locked, reels unlocked 21. Receive PGT from EV2	2B CLEANUP  12. Retrieve Crewlock Bag and PGT from P6 HR 5307  13. Translate to Airlock; retrieve fairlead  14. Coordinate with MCC/IV for GO to attempt SASA bolts  15. Tether swap to S1 safety tether; verify locked  16. Stow spare 85 ft safety tether on fuse tether  17. Stow 2B Tools Crewlock Bag in Airlock  18. Retrieve digital camera from 2B Tools Crewlock Bag  19. Receive/stow WIF Adapter, Cheater Bar on fuse tether  20. Transfer PGT to EV1  21. Close thermal cover

FS 7-70 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT (02:00 to 05:00) (Cont)

IV/SSRMS	EV1	EV2			
	SAW WORKAROUND  Over-center Hinge Reset:  A. GCA SSRMS to affected location on panel  B. Use cheater bar to press metal panel hinge into normal configuration; avoid contact with guide wire  Uneven Panel Distribution (causes stuck grommets during retract):  C. GCA SSRMS to lower blanket box near center guide wire on affected solar array  D. Use TPS scraper or cheater bar to evenly distribute panel folds along array (fluff); avoid contact with guide wire; GCA SSRMS along center guide wire as required				
	Stuck Grommet:  NOTE  Provided a fray is not causing the grommet fault, panel fluffing near center guide wire will likely clear problems at all three guide wires				
	If guide wire fray NOT suspected:     E. GCA SSRMS to affected panel near center guide wire     F. Use TPS scraper or cheater bar to evenly distribute panel folds (fluff); avoid contact with guide wire     G. If no joy; perform steps as is guide wire fray suspected  If guide wire fray is suspected:     H. GCA SSRMS to affected grommet     I. Use TPS scraper or cheater bar to free grommet; repeat as necessary for lower panel grommets as guide wire fray retracts				
	Guide wire can jump out of pulle from inside blanket box first. If g	AUTION by track, attempt cable manipulation guide wire must be handled from lling guide wire to side of pulley plane			
	J. Verify all grommets on affected guide wire are loose K. GCA SSRMS to lower blanket box near affected guide wire L. Use needle nose pliers to pull cable out of reel; allow cable to retract				
	Out of Plane Panels or Guide Wire Slack After Retract:  M. Perform steps for stuck grommet  N. If no joy; GCA SSRMS to goal posts of affected blanket  O. Use gloved hand to realign STE loops between goal posts; avoid contact with FCC				
	Y-Guide Reset P. Verify SABB is unlatched (low tension) Q. Use BRS Pin Tool on short skirt stiffener to lift tension bar; TPS scraper can be used assist with tension bar manipulation R: Lower tension bar on to Y-guide				
	Leader Disconnected from Tension Bar S. If spring not connected to leader, inspect tension bar for spring condition T. If spring still connected to leader, use needle nose pliers to retain loose put. If spring needs to be cut from tension bar, use needle nose pliers to retain	piece and cut leader with EVA scissors; stow in trash			

FS 7-71 EVA/117/FIN

# S3 KEEL PIN/DRAG LINK STOW (01:00)

IV	EV1	EV2
SSRMS support – Position SSRMS at S3 Keel Pin, S3 Face 1 for camera viewing	REMOVE AND STOW DRAG LINK  1. Translate to S3 2. APFR: From S3-28 to S3-05 [6,PP,L,10] 3. Install RET between Drag Link and Keel Pin (zenith aft Standoff) 4. Ingress APFR S3-05 [6,PP,L,10] 5. PGT[B3 18.4 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Release outboard drag link fastener (~11 turns) 6. Remove drag link fastener, remove drag link from clevis, Reinstall fastener ~3 turns by hand  7. Position drag link through face 1 and insert into retention/spring bracket	TIGHTEN KEEL PIN NUT CLAMPS  1. Translate to S3; photo op then temp stow digital camera 2. Remove PIP pin from S3 MT stop; stow in trash bag 3. If not already performed, PGT[A1 2.5 ft-lb, CW2 30 RPM, MTL 30.5]  -6 ext 7/16: Tighten nadir and zenith nut clamp bolts (2) ~6 turns  Nadir Zenith  REMOVE AND STOW DRAG LINK  4. When outboard fastener reinstalled, tether to inboard fastener 5. PGT[B3 18.4 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Release inboard drag link fastener (~11 turns) 6. Remove inboard drag link fastener and stow in trash bag  7. Remove outboard drag link fastener; engage drag link clevis onto eye bracket 8. PGT[A5 7.0 ft-lb, CW2 30 RPM, MTL30.5]-6 ext 7/16: Tighten outboard drag link fastener ~11 turns
Face 1  Nadir  Keel Pin Launch and Stow Config (looking outboard)	<ol> <li>REMOVE AND STOW KEEL PIN</li> <li>PGT[B2 16.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16:         Release zenith clevis bolt (#1) ~22 turns</li> <li>Remove zenith clevis bolt (#1), rotate keel to clear clevis; reinstall zenith clevis bolt ~3 turns by hand</li> <li>Rotate keel to clear clevis</li> <li>Rotate keel pin 180 deg; keep keel captive nuts facing the bulkhead while keel pin points into face 1</li> <li>Position keel pin into the center retention ring in truss</li> <li>Align keel clevis bolts above stow fittings</li> <li>Secure clevis bolt (#2) with zenith soft dock retention fitting inside the truss</li> <li>Egress APFR</li> </ol>	<ol> <li>PGT[B2 16.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Release nadir clevis bolt (#2) ~22 turns (use RET to tension lanyard)</li> <li>PGT[A3 4.8 ft-lb, CW2 30 RPM, MTL 30.5]-6 ext 7/16: Engage nadir clevis bolt (#2) ~22 turns to torque</li> <li>Assist EV1 with keel beam handling</li> <li>Align keel clevis bolts above stow fittings</li> <li>Remove clevis bolt (#1), engage keel onto nadir eye bracket and reinstall clevis bolt</li> <li>PGT[A3 4.8 ft-lb, CW2 30 RPM, MTL 30.5]-6 ext 7/16: Engage clevis bolt (#1) ~22 turns</li> <li>Retrieve drag link tether</li> </ol>

FS 7-72 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE (01:00)

IV	EV1/EV2
	ROTATE S1 MT STOP  1. Translate to S1 MT stop (Face 1 S1/S3 interface) 2. Remove PIP pin from S1 bulkhead 3. Move MT stop away from notch in bulkhead (inboard) and rotate 180 deg to clear face 1 (MT stop will spring back to engage bulkhead notch) 4. Reinsert PIP pin into bulkhead; √PIP pin fully seated
	REMOVE S3 SVS TARGET (IF NOT ALREADY PERFORMED)  CAUTION  To prevent loss of SVS target fasteners limit turn count, minimize side loading on bolt head, maintain axial force
	5. PGT[A3 4.8 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/16: Release SVS target fasteners (4) (~12 turns)
	IEA MMOD SHIELD BOLT RELEASE (IF NOT ALREADY PERFORMED)  6. Retrieve digital camera  7. PGT[B7 25.5 ft-lbs, CCW1 10 RPM, MTL 30.5]-6ext 7/16: Release IEA MMOD Shield bolts (4) =1 turn  Aft outboard #3 (HR 2228)  Aft inboard (#4) (HR 2203)  Fwd inboard (#1) (HR 2219)  Fwd outboard (#2) (HR 2227)
DEMATE QD  1. √Fwd white band visible, button up 2. Demate QD  MATE QD	APFR RELOCATES  8. APFR: from S3-05 to S4-18 [8,OO,C,1] (13A.1 get-ahead)  9. If EVA 2 did not perform, APFR: S4-04 to S4-19 (aft/nadir) [6,TT,J,11] (13a.1 get-ahead)
3. Inspect QDs for FOD or damage 4. √Detent button up 5. √Fwd white band not visible 6. Assess side loads	CONNECT S1 TO S3 FLUID LINE (GET AHEAD)  10. Open TA clamp  11. For QDs F56 and QD F57, perform DEMATE QD steps in IV column  12. Close TA clamp
<ul> <li>7. Mate QD; √Fwd white band visible</li> <li>8. Perform snap back test (√Fwd white band visible)</li> <li>9. Perform pull test, and visual gap test</li> </ul>	<ul> <li>13. Remove QD cap from panel S1-A503-M3; stow in trash Bag</li> <li>14. For QD F57 to S1-A503-M3, perform MATE QD steps in IV column</li> <li>15. For QD F57, perform OPEN VALVE steps in IV column</li> <li>16. Reinstall thermal bootie</li> </ul>
OPEN QD VALVE  10. Press button, move bail fwd (open valve) 11. √Aft white band visible, button up 12. Verify detent button can be depressed	17. BRT to S3 HR 3010 18. Open thermal bootie; remove QD cap from panel S3-A501-M1; stow in trash bag 19. For QD F56 to S3-A501-M1, perform MATE QD steps in IV column 20. For QD F56, perform OPEN VALVE steps in IV column 21. Reinstall thermal bootie

FS 7-73 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE (01:00) (Cont)

IV	EV1	EV2
	S3/S4 CLEANUP	S3/S4 CLEANUP
		22. If EVA 2 did not complete, retrieve Crewlock Bag from S3 HR 3049; perform Crewlock Bag inventory
	22. Retrieve digital camera and SVS target if required	23. Translate to airlock
	23. Translate to S1 HR 3221	24. Connect waist tether to airlock D-ring; verify locked
	<ol> <li>On EV2 GO, attach EV2 Safety tether to D-ring extender; verify locked</li> </ol>	25. Give EV1 GO for safety tether swap
	25. Remove EV1 safety tether from S1 HR; stow on MWS	26. Stow Crewlock Bag in A/L
	26. Translate to Airlock	
	<ol> <li>Connect EV1 safety tether to external A/L D-ring; verify locked</li> </ol>	
	<ol> <li>Connect EV2 safety tether to external A/L D-Ring; verify locked</li> </ol>	
	29. Give EV2 GO to disconnect waist tether	27. On EV1 GO, disconnect wait tether
	30. Transfer SVS target to EV2	28. Stow SVS target on fuse tether

FS 7-74 EVA/117/FIN

# H2O/H2 VENT VALVE CHANGEOUT (01:30)

IV	EV1	EV2
Verify with MCC Lab vent inhibits in place     Verify Port Bulkhead Isolation Valve     Lab: ECLSS: H2O Vent: Effector Commands     Water Vent Effector Commands     'Port Isolation Valves'     'Inboard'      ✓Position – Close     RPCM LA1B B RPC 11 – Open, Close cmd inh	MMOD SHIELD REMOVAL  1. Retrieve Vent Tools Crewlock Bag from airlock 2. Translate to Lab fwd/zenith endcone panel C2-03 3. Stow Crewlock Bag on Lab HR 263 4. Assess SSPTS bag for interference during MMOD shield temp stowage 5. Install MMOD T-handle tool into C2-03 shield 6. Install RET from T-handle to Lab HR 0271 7. Release Dzus fasteners (3) 8. Temp stow shield using second RET to Lab HR 0280 9. Release outer/port MLI Dzus fastener 10. Peel back MLI; restrain with RET to HRs PMA2-0403 and Lab-0280	
2. Give EV crew GO for connector demates  If PGT used for vent nozzle fasteners use settings: PGT[A7 9.2 ft-lb, CCW2 30 RPM, MTL 30.5]	WATER VENT REMOVAL  11. Retrieve ratchet wrench and Gamah Removal Tool 12. On IV GO: demate P1 from J1 and P2 from J2 13. BRT to HR 0270 14. Install Gamah Removal Tool on water vent feedthrough; push tool cw and radially inward 15. Gamah Removal Tool – Engage 16. Ratchet wrench -2 ext 7/16: Break torque on gamah fitting (~1 turn) 17. Gamah Removal Tool – Release; stow in Crewlock bag 18. Ratchet wrench -2 ext 7/16: Release vent nozzle fasteners (2)(~9-14 turns)(failure torque 13.8 ft-lb) 19. Evaluate vent hose bending during nozzle removal from Lab 20. Loosen gamah fitting by hand (~3-4 turns) 21. Release TA clamps (1) for vent swap 22. Stow vent assembly in Crewlock bag	
Turns to Hand Tight Turns to Torque  Bolt Torque Turns Nadir Zenith  3. Inform MCC-H H2 vent installed and CLOSED	H2 VENT INSTALLATION  23. Close TA clamps to restrain H2 vent electrical connectors (2) 24. Position gamah fitting on feedthrough  25. Engage gamah nut threads finger tight (~3.5 turns); Note location of sharpie mark on nut 26. Position H2 vent nozzle at end ring bracket; start fasteners by hand (~2 turns) 27. Install Gamah Installation Tool on vent feedthrough; Push tool ccw and radially inward 28. Gamah Installation Tool – Engage 29. Ratchet wrench -2 ext 7/16: Torque gamah fitting; Verify ~0.25 addition turn on nut at torque 30. Inspect tube orientation 31. Gamah Installation Tool – Release; stow in Crewlock bag 32. Mate P1 to J1 and P2 to J2 33. PGT[A1 2.5 ft-lb, CW1 10 RPM, MTL 30.5]-6 ext 7/16: Torque vent nozzle fasteners (2)(~9-14 turns) 34. Verify H2 vent nozzle – CLOSED  MMOD SHIELD INSTALLATION 35. Install MLI; verify MLI is under MMOD fastener brackets 36. Engage MLI Dzus fastener 37. Install MMOD shield with tabs under inner flange 38. Engage Dzus fasteners (3)(engage center first) 39. Retrieve RETs and T-handle tools 40. Stow T-handle tools in Crewlock Bag 41. Translate to Airlock 42. Stow Crewlock Bag in Airlock	MMOD SHIELD INSTALLATION  1. Assist EV1 with shield install


FS 7-75 EVA/117/FIN

# LAB EWIS ANTENNA INSTALLATION (01:30)

IV	EV2
NOTE	FAT
Due to Big Loop Reconfigurations, if comm	<u>SETUP</u>
Is required between ISS IV and EV crew,	1. Retrieve EWIS ORU Bag (RETs stay on bag)
recommend using drag-thru BPSMU with shuttle	2. Retrieve MMOD T-Handle Tools (2) from Airlock Toolbox 2, slot 5 (zenith door)
ATU configured to A/G1	3. Translate to Lab fwd nadir/port endcone C2-01
	4. Stow EWIS ORU Bag with lid nadir on Lab HRs 205/207 and 266/262
IV 1. Notify MCC-H when ready for SSSR	INSTALL LAB EWIS ANTENNA OIH
(UHF) reconfiguration	5. Remove and temp stow SSPTS cable from OIH 276
MCC 2. Deactivate SSSR (UHF)	6. PGT[B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Break torque on OIH 276 fasteners (2) =1 turn only
IV 3. On MCC-H GO:	7. <b>PGT[A1</b> 2.5 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5] - 6 ext 7/16:</b> Release OIH 276 fasteners (2) ~7 turns
A1R AUD CTR SL A/G1 – ON	8. Push OIH release buttons; Temp stow OIH 276
	9. Install EWIS ANT 12 (OIH 0297) with antenna pointing nadir (push release button to deploy shoes)
NOTE: Big Loop comm is via hardline	10. <b>PGT[A2</b> 3.8 ft-lb, <b>CW2</b> 30 RPM, MTL <b>30.5] - 6 ext 7/16:</b> tighten EWIS OIH 0297 fasteners (2) (8 turns)
	11. Remove cap from EWIS ANT 12 J1; stow in trash bag on fuse tether
	12. Secure SSPTS cable to EWIS OIH 0297
	13. <b>PGT[B1</b> 12.0 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5] - 6 ext 7/16:</b> Break torque on OIH 278 fasteners (2) =1 turn only
	14. <b>PGT[A1</b> 2.5 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5] - 6 ext 7/16:</b> Release OIH 278 fasteners (2) ~7 turns
	15. Push OIH release buttons; Temp stow OIH 278
	16. Install EWIS ANT 11 (OIH 0298) with antenna pointing nadir (push release button to deploy shoes)
EWIS Handrails	17. <b>PGT[A2</b> 3.8 ft-lb, <b>CW2</b> 30 RPM, MTL <b>30.5] - 6 ext 7/16</b> : tighten EWIS OIH 0298 fasteners (2) (8 turns)
Bolt Torque Turns	18. Remove cap from EWIS ANT 11 J1; stow in trash bag on fuse tether
298 stbd	19. Stow OIH 278 and 276 in EWIS ORU Bag
298 port	ROUTE EWIS CABLE TO ANTENNAS  20. Retrieve EWIS cable P2; release wire ties as required
297 stbd	21. Remove cap from EWIS cable P2, stow in trash bag on fuse tether
297 port	22. Translate to EWIS ANT 12 with P2
	23. Mate EWIS cable P2 to ANT 12 With 2
	24. Route cable to ANT 11; wire tie as required
	25. Remove remaining caps (3) from EWIS cable; stow in trash bag on fuse tether
	MATE EWIS CABLE TO LAB
	26. Install MMOD T-handle tool into C2-01 shield
	27. Install RET from T-handle to Lab HR 0277
	28. Release C2-01 Dzus fasteners (3)
	29. Temp stow shield using second RET to HR 0282
	30. Release nadir MLI Dzus fastener to expose connector P16
	31. On MCC-H GO: Demate Lab P16 from J16
	32. Mate EWIS cable P16A to J16
	33. Mate EWIS cable J16A to P16
	34. Feed EWIS cable to MMOD shield exit point
	35. Reinstall MLI Dzus fastener
	36. With EV1 assistance: Install MMOD shield C2-01
	37. Engage Dzus fasteners (3)(engage center first)
W. FW.	38. Mate EWIS cable P1 to ANT 11 J1
When EWIS connector mates complete:	EWIS CLEANUP
IV 4. On MCC-H GO:	39. Retrieve EWIS ORU Bag
A1R AUD CTR SL A/G1 - OFF	40. Translate to Airlock
MCC 5. Activate SSSR (UHF)	41. Stow MMOD T-Handle tools on tool board; stow tool board in Airlock Toolbox 2, slot 5 (zenith door)
NOTE: Pig Loop comm is via LIHE	42. Close Toolbox door
NOTE: Big Loop comm is via UHF	43. Stow EWIS ORU Bag in Airlock


FS 7-76 EVA/117/FIN

### **NODE/SM LAN CABLE ROUTING (01:00)**



FS 7-77 EVA/117/FIN

## SASA GIMBAL LOCKS (00:30)



FS 7-78 EVA/117/FIN

# GPS ANTENNA #4 REMOVAL (00:40)

IV .	EV
1. Verify with MCC-H, ISS GPS Antenna #4 power inhibits in place  RPCM S02B_E RPC 8 – Open, Close Cmd Inh RPCM S01A_E RPC 7 – Open, Close Cmd Inh	CAUTION  Avoid inadvertent contact with GPS Antenna (S-13 paint)  1. Retrieve Small ORU Bag (GPS) from airlock 2. Close thermal cover 3. Translate to GPS Antenna 44 worksite (S0 lower-inboard) 4. Temp stow GPS Ant ORU bag on HR 3509 5. BRT to HR 3508 6. Remove MLI shroud from antenna 7. On IV GO, demate connectors (any order), temp stow as required:    P696 from J1   P699 from J2   Tether to failed GPS antenna 9. PGT[B7 25.5 fr.lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release bolts (4) in any order, ~10 turns; bolts will spring up when released 10. Remove GPS antenna in ORU Bag   NOTE     Connector caps are wire-tied together to prevent GPS antenna cables from being lost inside the truss 12. Retrieve electrical connector caps from GPS ORU Bag; install electrical connector caps on electrical connectors:   J1 dummy electrical cover to P696   J2 dummy electrical cover to P697 13. Reconfigure MLI shroud, as reqd (MLI should not be above original antenna plane) 14. Stow GPS Antenna ORU Bag on BRT

FS 7-79 EVA/117/FIN

# **CP7 ETVCG STANCHION INSTALLATION (00:45)**

IV	EV1	EV2
	ETVCG STANCHION RELEASE  1. Translate to stanchion carrier on ESP-2 2. Tether to nadir/aft stanchion race track tether point 3. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release launch restraint bolts (2) ~9 turns (bolts spring out, black line visible) 4. Slide stanchion out of stowage interfaces (towards dummy box) 5. Install scoop on dummy box (handle towards stanchion base) 6. BRT to scoop 7. Translate via face 1 to ETVCG worksite (P1 nadir/inboard, CP-7)	ETVCG STANCHION RELEASE  1. Retrieve round scoop from airlock 2. Translate to stanchion carrier on ESP-2  3. Transfer round scoop to EV1 4. Assist EV1 with stanchion configuration for translation 5. Translate to CP-7
Bolt Turns Torque VSSA Bolt	STANCHION INSTALL  8. Softdock stanchion to CP-7 (race track outboard)  NOTE  Do not allow socket to come off stanchion bolt head until complete  9. PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5] - 6 ext 7/16: Break torque on stanchion bolt, =1 turn only  10. PGT[B3 18.4 ft-lb, CW2 30 RPM, MTL 30.5] - 6 ext 7/16: Engage stanchion Bolt 9 turns until it drops out of launch position. Continue to push downward (6 lb push force reqd), engage stanchion bolt ~16 turns to torque  11. Retrieve small scoop	STANCHION INSTALL 6. Assist EV1 by holding stanchion perpendicular to CP-7

FS 7-80 EVA/117/FIN

# S3 LOWER OUTBOARD PAS DEPLOY (01:00 + TRANSLATION TIME)

IV	EV1	EV2
Verify starboard SARJ locked	1. Retrieve hammer from Airlock Toolbox 1 (stbd), slot 1 (nadir door) 2. Translate to deploy clevis on S3 Lower Outboard PAS 3. PGT [B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release deployed clevis bracket bolts (4) ~10 turns; temp stow bracket    CAUTION	<ol> <li>Retrieve large gap spanner from airlock</li> <li>Translate to nadir hinges on the S3 Lower Outboard PAS</li> <li>Remove hinge line ADPs (2), insert in stowage hole, √lock bracket engaged</li> <li>Attach large gap spanner to yoke, loop back on itself; stow free end on nadir longeron HR 3051</li> <li>PGT [B6 24.0 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release SARJ brace beam cone fastener =35 turns; do not exceed 37 turns</li> <li>Release brace launch restraint fastener ~1 turns</li> <li>Rotate brace to diagonal strut</li> <li>PGT [B2 16.0 ft-lb, CW2 30 RPM, MTL 30.5] - 6 ext 7/16: Attach SARJ brace to diagonal strut ~1 turn (or hand tighten)</li> <li>PGT [B6 24.0 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release SARJ diagonal strut cone fastener =35 turns; do not exceed 37 turns</li> </ol>
		UTION than ~7 deg out of rotation plane nd  10. Move diagonal strut; temp stow clear using RET to HR 3043 or 3044 11. Route gap spanner to yoke  12. Rotate yoke to detent (10 deg past vertical) 13. Release gap spanner from HR 3051 (leave on yoke); temp stow free end
Torque Turns  Diagonal Brace  SARJ Brace	<ul> <li>14. Release RET on diagonal brace strut; rotate to install</li> <li>15. PGT [B2 16.0 ft-lb, CW3 60 RPM, MTL 30.5] - 6 ext 7/16: Engage diagonal brace strut cone bolt ~38 turns</li> <li>16. Pull yoke gap spanner to unfold yoke</li> <li>17. Rotate PAS out of detent position</li> <li>18. Lower yoke into deployed clevis</li> <li>19. Release wire tie securing PIP pin and ADP to yoke</li> <li>20. Install yoke ADP; √lock bracket engaged</li> </ul>	<ul> <li>14. Assist EV1 with diagonal brace strut reposition</li> <li>15. PGT [B6 24.0 ft-lb, CCW2 30 RPM, MTL 30.5] - 6 ext 7/16: Release SARJ brace launch restraint bolt from diagonal strut ~1 turns (or by hand)</li> <li>16. Rotate brace away from diagonal strut</li> <li>17. Re-insert launch restraint bolt into diagonal beam fitting ~1 turn</li> <li>18. PGT [B2 16.0 ft-lb, CW3 60 RPM, MTL 30.5] - 6 ext 7/16: Engage</li> <li>SARJ brace cone fastener ~38 turns to torque</li> </ul>

FS 7-81 EVA/117/FIN

# S3 LOWER OUTBOARD PAS DEPLOY (01:00 + TRANSLATION TIME) (Cont)

IV	EV1	EV2
Perform RTL verification     Notify EV: RTL verification complete	<ul> <li>21. Install yoke PIP pin</li> <li>22. Translate to PAS UMA</li> <li>23. Tether to EVA OVERRIDE anti-rotation cap hitch PIP pin; remove</li> <li>24. Remove anti-rotation cap; stow in trash bag</li> <li>25. Stow hammer in airlock toolbox 1, slot 1</li> </ul>	<ul> <li>19. Translate to each guide vane (3) and perform the following: <ul> <li>A. Remove launch restraint PIP pins from guide vanes; stow in trash bag</li> <li>B. Inform IV/MCC-H: Ready for RTL checkout</li> <li>C. On IV GO: Depress and hold RTL for 15 seconds; then release</li> <li>D. On IV GO: Move to next guide vane</li> </ul> </li> <li>20. Release large gap spanner from yoke; stow in trash bag</li> <li>CAUTION <ul> <li>EBCS target contains finished surface which could be damaged if contacted by EV crew</li> </ul> </li> <li>21. Translate to EBCS target</li> <li>22. Verify EV2 clear of target</li> <li>23. Remove EBCS target cover; stow on backside of target assembly</li> </ul>

FS 7-82 EVA/117/FIN

# EVA 3 CLEANUP/INGRESS (00:35)

IV	EV1	EV2
1. Perform WVS PWRDN (PHOTO/TV, WVS CUE CARD)  2. Start 2-min timer	EV1  CLEANUP  1. Relocate APFR/ingress aid from S0 aft/stbd wedge face WIF 07 to Airlock-11 [6,PP,F,6] (13a.1 get-ahead) 2. Perform tool inventory  INGRESS  3. Attach Waist Tether (R) to EV2 Waist Tether; verify locked 4. Disconnect EV1 and EV2 Safety Tethers 5. Ingress airlock 6. Remove SCU from stowage pouch Remove DCM cover Attach SCU to DCM, check locked 7. Water – OFF 8. Close thermal cover; attach Velcro strap	EV2  CLEANUP  1. Translate to Airlock 2. Perform tool inventory  INGRESS  3. Open Airlock Thermal Cover 4. Ingress airlock 5. Attach Waist Tether (L) to A/L D-ring; verify locked 6. Transfer Waist Tether (R) to EV1 7. Remove SCU from stowage pouch Remove DCM cover Attach SCU to DCM, check locked 8. Water – OFF
	Do not close hatch until EMU water off for 2 min  9. Verify no hardware blocking hatch 10. EV Hatch handle – Preclose position 11. EV Hatch – close and lock 12. Go to PRE-REPRESS Cue Card	

FS 7-83 EVA/117/FIN

# **POST EVA 3 TOOL CONFIG**

EV1	AIRLOCK CONFIG	AIRLOCK CONFIG (Cont)
l mws	Staging Bag	Crewlock Bag (Solar Array Tools)
BRT (L)	Fuse Tether	BRS Pin Contingency Tool (w/Tape)
RET (eq-eq)	PGT	Loop Pin Puller (w/Tape)
Swing Arm (R)	PGT Battery	TPS Scraper (w/Tape)
RET (eg-eg)	Wire Tie Caddy	Compound Cutter/Needle Nose Pliers Caddy
PGT	RAD S/N	(w/Tape)
PGT Battery	Connector Cleaner Tool Kit	EVA Scissors (w/Tape)
7/16 (wobble) Socket-6 ext	Probe	Small ORU Bag (GPS)
T-Bar	Prybar	RET (eq-eq)
RET (eq-eq) (2)	Connector Pin Straightener	GPS Connector Caps (2 - long wire tied together)
RET (eq-eq) w/PIP pin	Velcro/Tape Caddy	RET (eq-lg) (outside of bag)
Wire Ties (2)	SLR Torque Multiplier (if SLRs still to be removed)	: (= : (eq :g) (eaterac e: 2ag)
Small Shuttle Trash Bag	IV Bag	Crewlock EVA Bag
Adj Equip Tethers (2, L & R gloves)	Towels (2)	Vise Grips
D-Ring Extender (2, R & L)	Contamination Detection Kit	Socket Caddy
Waist Tether (2, L D-ring and R ext)	GP Caddy (2)	5/8 (rigid) Socket-7.8 ext
SAFER	Adjustable Thermal Mittens (2)	5/8 (rigid) Socket-7.8 ext
WVS	Socket Caddy (hatch cont) w/eq-eq RET	7/16 (rigid) Socket-2 ext
 1	1/2 Socket-8 ext	RET (eq-eq) w/PIP pin
EV2	7/16 (wobble) Socket-6 ext (spare)	3/8-in IVA Tool Stack w/DPT Adapter
l mws	DCM Plug (SAFER Hardmount) (2)	ISS ratchet wrench
BRT (L)	Fuse Tether	7/16 (rigid) Socket-9 ext
Wire Ties (3)	NODE/LAN cable	Round Torque Multiplier
RET (eq-eq)	WIF Adapter w/PIP pin	Rd TM Socket – 5/8 prd
Swing Arm (R)	Cheater Bar (w/Kapton Tape)	RET (eq-Lg)(outside of bag)
RET (eq-eq)	1.5" Bail Drive Lever (taped to Cheater Bar)	EWIS ORU Bag (Medium)
PGT "	Digital Camera	Fuse Tether
PGT Battery	Digital Camera L bracket	EWIS Cable
7/16 (wobble) Socket-6 ext	85-ft Safety Tether	OIH 297(276)
T-Bar	(SVS Target)	OIH 298(278)
RET (eq-eq) (3)	(Node OIH 120)	Small ISS Trash Bag (with caps)
RET (eq-eq) w/PIP pin	Crewlock Bag (Vent Tools)	RET (eq-eq) (2) (outside of bag)
Wire Ties (2)	Gamah Removal Tool	 
Small ISS Trash Bag	Gamah Installation Tool	
Adj Equip Tethers (2, L & R gloves)	Ratchet Wrench w/palm wheel	
D-ring Extender (2, R & L)	7/16 rigid Socket-2 ext	
Waist Tether (2, L D-ring and R ext)	H2(H20) Vent Assembly w/sock	
SAFER	RET (eq-eq) (3)	External APFRs
WVS	MMOD T-Handle Tool (2)	S4-19 (13A.1 prep)
	RET (eq-lg) (outside of bag)	S3-05
		P6-4B
	Shading indicates items that may have been left outside	P6-11
	depending upon which task completed	A/L-11
	Bold indicates trash items	IAPER Z1-3
		IAPFR Z1-1

FS 7-84 EVA/117/FIN

**EVA 3 TASK DATA** 

FS 7-85 EVA/117/FIN

### 2B SOLAR ARRAY RETRACT - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	NA
Two EV Crew	As long as	NA
	it takes	

### Tools:

100101	•
EV1	EV2
WIF Adapter	Crewlock Bag
APFR	Digital Camera
Cheater Bar with 1.5" bail drive lever	BRT
Needle Nose Pliers	
Compound Cutters	
Loop Pin Puller	
TPS Scraper	
BRS Pin Tool	
EVA Scissors	

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
NA								

### **EVA Connectors:**

,,					
Harness	From	То	Clamps (#)	Conn Size	Function
NA					

### **Foot Restraints:**

Task	WIF	APFR Setting
SSRMS	WIF Adapter	[12,PP,F,6]

### Notes:


Provided a fray is not causing the grommet fault, panel fluffing near center guide wire will likely clear problems at all three guide wires

### Cautions:

 Guide wire can jump out of pulley track, attempt cable manipulation from inside blanket box first. If guide wire must be handled from outside of blanket box, avoid pulling guide wire to side of pulley plane


### Warnings:


- 1. SASA Keepout Zone 0.9 meters. Avoid translation forward of 2B four bar linkage
- 2. Sharp edge/pinch point/shock hazard: Avoid EMU contact with the following:
  - Lower SABB exposed reels and pulleys (guide wire and tensioning mechanisms)
  - SABB skirt
  - Swing bolts
  - Springs on tension bar
  - Panel hinges
  - · Guide wire frays
  - · Braided cables
  - Fastener exposed threads
  - · Exposed bolts in rib cavities on mast canister
  - Mast roller guides
  - FCC and Kapton part of solar array panels



FS 7-86 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT - TASK DATA (Cont)






STE Loops (FCC is inside BB)



FS 7-87 EVA/117/FIN

# 2B SOLAR ARRAY RETRACT – TASK DATA (Cont)



FS 7-88 EVA/117/FIN

### S3 KEEL PIN/DRAG LINK STOW - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	NA
Two EV Crew	NA	1:00

### Tools:

EV1	EV2
PGT	PGT
6 Ext 7/16 wobble	6 Ext 7/16 wobble
APFR	
RET	

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Keel Nut Clamp Bolt	No	7/16	2	0-4.8 on orbit	NA	4.8	6	30
Keel Pin Structural Bolt	1stows in nadir clevis 2 stows in zenith soft dock	7/16	2	10.8- 12.5 gnd 1.6-8.7 on orbit	12.8	22.2 remove 8.7 install	22	30
Drag Link Bolts	No	7/16	2	8-10 gnd 3-15.9 on orbit	11.7	32.3 remove 23.9 install	10.5	30

### **EVA Connectors:**

Harness	From: Panel/ Connector	To: Panel/ Connector	Clamps (#)	Conn Size	Function
NA	NA	NA	NA	NA	NA

### **Foot Restraints:**

Task	WIF	APFR Setting
Nadir keel bolt position	S3-31	[11,00,F,12]
Zenith keel bolt position (EV1 nominal)	S3-05	[6,PP,L,10]

### Notes:

### Cautions:

1. Verify PGT clockwise (CW) setting prior to tightening nut clamp assembly. Opposite direction beyond 6 rotations can unscrew EVA bolt threads from the barrel nut which would disable the nut assembly. This means the loss of MT operations outboard of the keel location unless vice grips can be used to restrain nut during bolt release


### Warnings:

FS 7-89 EVA/117/FIN


# S3 KEEL PIN/DRAG LINK STOW – TASK DATA (Cont)



S3 Keel Pin/Drag Link – Launch Configuration




S3 Keel Pin/Drag Link – Stowed Configuration



Keel Pin Attachment Fastener and Clamping Nut








FS 7-90 EVA/117/FIN

# S3 KEEL PIN/DRAG LINK STOW – TASK DATA (Cont)






Keel Pin Stowage Clevis



Keel Pin Stowage Ring



Drag Link Mouse Trap and Stow Clevis



S3 MT Stop – Launch Configuration

FS 7-91 EVA/117/FIN

### MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	2:00
Two EV Crew	NA	1:00

### Tools:

EV1	EV2
PGT	PGT
7/16 (wobble) Socket-6 ext	7/16 (wobble) Socket-6 ext
	EVA Temp Rail Stop

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
MMOD Shield Bolt	Yes	7/16	4	37.5 gnd	42.2	93.5	1	10
ETRS Bolts	No	7/16	2	2.5	NA	TDB	5	30

### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
S1/S3 FLUID (1/4 INCH) JUMPER L13 QD F57	S1-A503 / M2	S1-A503 / M3	1 for entire jumper	1/4 inch	Ammonia line
S1/S3 FLUID (1/4 INCH) JUMPER L13 QD F56	S1-A504 / M1	S3-A501 / M1	NA	1/4 inch	Ammonia line

### Foot Restraints:

Task	WIF	APFR Setting
Forward Inboard (#1)	S4-06	[7,WW,F,1]
Forward Outboard (#2)	S4-14	[6,WW,F12]
Aft Outboard Bolt (#3)	S4-13	[6,WW,F12]
Aft Inboard Bolt (#4)	S4-05	[7,WW,F,1]

### Note:

- 1. Requirement for releasing torque on IEA MMOD Shield Bolts is within 1 year of launch
- The S1 MT stop prevents the MT/CETA from moving past the S1/S3 interface plane when the S3 segment is not attached
- 3. The S1 MT stop can be rotated in any direction
- 4. Failure to fully reinstall S1 MT stop PIP pin can cause interference with MT translation

### Cautions:

S1-S3 1/4-in flexhose shall be firmly supported during installation to prevent damage due to excessive bending, kinking; tension, torsional loading or other excessive strain

### Warnings:

 The ammonia lines will be launched with 80 psia N2 pad pressure. Potential hazard to the EVA crew



**IEA MMOD Shield Bolt** 

FS 7-92 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE – TASK DATA (Cont)




Tether Shuttle Stop – launch configuration



P3 Tether Shuttle Stop (stowed)



P1 MT Stop PIP Pin Fully Inserted (showing clearance to MT envelope)




S1 MT Stop (deployed)

FS 7-93 EVA/117/FIN

# MT/CETA PATH/S4 MMOD SHIELD BOLT RELEASE – TASK DATA (Cont)



EVA Temporary Rail Stop (ETRS)



Ammonia Jumper Connection (S3-A501-M1)

FS 7-94 EVA/117/FIN

### H2O/H2 VENT VALVE CHANGEOUT - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	1:30
Two EV Crew	NA	1:20

### Toole

EV1
Ratchet Wrench w/palm wheel
2 Ext 7/16 rigid
Gamah Removal Tool
Gamah Installation Tool
MMOD T-Handle Tool (2)
RETs (3)
Crewlock Bag
PGT
6 Ext 7/16 wobble

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Gamah	No		1				3-4	
Vent Nozzle Fastener	No	7/16	2	7 gnd 0-4 orbit	8.4	13.8	9-14	10

### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
Water Vent P1	J1	NA	1		
Water Vent P2	J2	NA	1		
H2 Vent P1	NA	J1	1		
H2 Vent P2	NA	J2	1		

### **Foot Restraints:**

Task		WIF	APFR Setting
Gamah Removal Inst	allation	Lab-11	[6,RR,F,11]
Vent Nozzle Fastene	'S	Lab-11	[7,QQ,G,10]


- Notes:

  1. Gamah nut should rotate at least 90 degrees during final torque. Less rotation is indicative of the installation tool disengaging from feedthrough When gamah nut sharpie mark can be used to count rotations

### Cautions:

MMOD panel must be fully seated prior engaging Dzus fasteners to prevent splaying

### Warnings:



Lab Endcone with MMOD Shield C2-03 removed

FS 7-95 EVA/117/FIN

# H2O/H2 VENT VALVE CHANGEOUT – TASK DATA (Cont)



Water vent gamah fitting and electrical connectors



Vent nozzle bracket and MLI



Water vent nozzle fittings



Gamah Removal and Installation Tools

FS 7-96 EVA/117/FIN

### **EWIS ANTENNA INSTALLATION - TASK DATA**

**Estimated Task Duration:** 

	With RMS	Without RMS
One EV Crew	NA	NA
Two EV Crew	NA	1:30

### Tools:

EV1 (FF)	EV2 (FF)
	PGT
	MMOD Shield Tools (2)
	6 Ext 7/16
	BRT
	Wire Ties

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
OIH Fastener	None	7/16	2 per	1.5-5.5	5.5	21.3	9.5	30

### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
EWIS Cable P1	NA	ANT 11 J1	NA	21	
EWIS Cable P2	NA	ANT 12 J1	NA	21	
EWIS Cable P16A	NA	LAB J16	NA	25	
Lab P16	LAB J16	EWIS Cable J16A	NA	25	

### Foot Restraints:

Task	WIF	APFR Setting
N/A		

### Note:

1. If performed during EVA 3, entire task can be performed by EV2 alone with the exception of MMOD shield installation. If performed on EVA 4, task should be performed by both crewmembers

### Cautions:


- 1. EVA crewmember shall be rigidly restrained during handrail installation or removal of OIH via APFR or rigidized BRT
- 2. EVA crewmember shall not be rigidly restrained to OIH that is being installed or removed
- 3. Do not use WIS antennas as handholds

### Warnings:

- 1. Sharp edge back side of MMOD shield fasteners
- 2. Sharp edge PMA umbilical launch restraints exposed threads
- 3. Avoid inadvertent contact with grapple fixture targets and target pins
- 4. PMA handrails may be hot. Handling may need to be limited
- 5. Stay > 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun
- Stay > 0.5 ft away from PMAs and MMOD shields > 325 degF
   No EMU TMG contact with PMAs or MMOD shields when temp > 320 degF

FS 7-97 EVA/117/FIN

# EWIS ANTENNA INSTALLATION – TASK DATA (Cont)



FS 7-98 EVA/117/FIN

### NODE/SM LAN CABLE ROUTING - TASK DATA

### Tools:

EV1 (FF)	EV2 (FF)
PGT	PGT
MMOD shield T-Tools	Wire ties

Foot Restraints: None

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
OIH Fastener	None	7/16	2 per	1.5-5.5	5.5	21.3	9.5	30

### **EVA Connectors:**

Harness	From	То	Conn Size
W0939-P1		W0940-J1	
W0939-P211		Node-J211	
W0939-J2		Node-HR 141	
W0940-J1		W0939-P1	

Notes: N/A

### Cautions:

- 1. EVA crewmember shall be rigidly restrained during handrail installation or removal of OIH via APFR or rigidized BRT
- 2. EVA crewmember shall not be rigidly restrained to OIH that is being installed or removed
- 3. Node Dzus fasterners may be difficult to engage. Apply firm downward force on fastener to ensure engagement

### Warnings:


- 1. Sharp edge back side of MMOD shield fasteners
- 2. Sharp edge PMA umbilical launch restraints exposed threads
- Avoid inadvertent contact with grapple fixture targets and target pins
   PMA handrails may be hot. Handling may need to be limited
- Stay > 1 ft away from PMAs and MMOD shields > 270 degF if EMU sun visor up
   Stay > 0.5 ft away from PMAs and MMOD shields > 325 degF
   No EMU TMG contact with PMAs or MMOD shields when temp > 320 degF




Node Port FWD - NOD1/C02-02 (MMOD Shield and MLI Cover removed)

FS 7-99 EVA/117/FIN


# NODE/SM LAN CABLE ROUTING - TASK DATA (Cont)





FS 7-100 EVA/117/FIN

# NODE/SM LAN CABLE ROUTING - TASK DATA (Cont)



Port view of Node 1 Shield NOD1/C2-02 removed

FS 7-101 EVA/117/FIN

### SASA GIMBAL BOLT - TASK DATA

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	00:30
Two EV Crew	NA	NA

### Tools:

EV1	
BRT	
IAPFR (backup)	
PGT	
6 Ext 7/16 wobble	

### **Foot Restraints:**

Task	WIF	APFR Setting
Z1 Gimbal bolts	Z1 WIF 01	IAPFR [3,RR,H,12]

### **EVA Fasteners:**

Fastener Name	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Gimbal Fasteners	7/16	4	16.7 gnd 3.8 on-orbit	18.1	13.9 install 46.4 release (first turn) 6.7 release (at hardstop)	4.5	30

### EVA Connectors: None

### **Timeline Considerations:**

SASA Gimbal bolts can be considered during translation back from 2B solar array retract tasks. This should only be considered if it will not risk higher priority objectives

### Notes:

- Torque and turns per STS-115 12A EVA Checklist
   Gimbal bolts should be torqued in specified pattern so as to prevent misalignment of the gimbal locks during tightening and resulting in higher torques and possibly not reaching turn counts

### Cautions:


1. Avoid contact SASA antennas and coatings

### Warnings:

None

FS 7-102 EVA/117/FIN

# SASA GIMBAL BOLTS – TASK DATA (Cont)



FS 7-103 EVA/117/FIN

### **GPS ANTENNA #4 – TASK DATA**

### **Estimated Task Duration:**

	With RMS	Without RMS
One EV Crew	NA	00:40
Two EV Crew	NA	NA

### Tools:

EV1 (FF)
Electrical caps
Wire Tie (32")
PGT w/ 7/16" wobble 6-in ext
Small ORU Bag

### **EVA Fasteners:**

Fastener Name	Head Size	Qty	Removal Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
GPS Antenna #4 (Failed)	7/16	4	20.2	70.6	10	30

### **EVA Connectors:**

Harness	From	То	Function
W4503	J1 (failed)	J1 (new)	GPS Antenna #4: Ops-1 & Htr-1 power
W4502	J2 (failed)	J2 (new)	GPS Antenna #4: Ops 2 & Htr-2 power

### Notes:

- 1. Connector caps are wire-tied together to prevent GPS antenna cables from being lost inside the truss
- 2. Attach wire tie ends to connector caps so that there is at least 12" of wire separating the caps
- 3. Insure MLI is not above original antenna plane


### Cautions:

- 1. Minimize contact with GPS Antenna S-13 paint
- 2. Thermal clock data for GPS Antenna 4 (with and without ORU bag):
  - a. 30 min to place failed GPS antenna in the ORU bag + 5 hr transfer clock
  - b. 60 min to place failed GPS antenna in the ORU bag + 2 hr transfer clock
  - c. If ORU bag not used, there is a 60-min clock to transfer the GPS antenna

FS 7-104 EVA/117/FIN


# GPS ANTENNA #4 - TASK DATA (Cont)

**GPS Antenna Worksite** 










# GPS Antenna 4 MLI



FS 7-105 EVA/117/FIN

# **CP7 ETVCG STANCHION INSTALL – TASK DATA**

### **Estimated Task Duration:**

	Without SSRMS
Two EV Crew	00:45

### Tools:

EV1 (FF)	EV2 (FF)
7/16 (wobble) socket-6 ext Round Scoop	7/16 (wobble) socket-6 ext

### **EVA Fasteners:**

Fastener Name	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns
VSSA Launch Bolt	7/16	2	16.7	30.1	50.1	7-11.5
VSSA Stanchion Bolt	7/16	1	20.0	18.0	62.0	10, 16.5

### Mass and Dimensions:

Item	Mass (lb)	Dimensions (in)
ETVCG Stanchion	51.0	16.6x13.0x58.2

FS 7-106 EVA/117/FIN

### S3 LOWER OUTBOARD PAS DEPLOY - TASK DATA

### **Estimated Task Duration:**

	Without SSRMS
One EV Crew	na
Two EV Crew	01:00

### Tools:

EV1	EV2
PGT	PGT
7/16 socket 6-in ext	7/16 socket 2-in ext
hammer	Adjustable equipment tether (2)
	Gap spanner (2 short)

### **EVA Fasteners:**

Fastener Name	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns
SARJ Brace Launch Restraint Bolt	7/16	1	Finger tight	Per EVA 2	32.3	1-13.5
SARJ Brace cup/cone Bolt	7/16	1	7.1-22.1	Per EVA 2 (16.0)	Inst=22.1 Rel=14.0 hardstop 31.6 running	37
Diagonal cup/cone bolt	7/16	1	20.8-22.5 gnd 16.0 on orbit	22.7	Inst=22.1 Rel=14.0 hardstop 31.6 running	37
Stowage Clevis	7/16	4	22.5-27.5 gnd 16.0 on orbit	34.3	46.7 rel 44.5 inst	9-16.5
Deploy Clevis	7/16	4	22.5-27.5 gnd 30.5 on orbit	31.7	106.6 rel 44.7 inst	7-10.5

### Inhibits:

Inhibit	
Starboard SARJ Locked	

Foot Restraint	WIF	Settings
Remove/Install	S3 - 11	2,PP,G,12
Deployed/Stowed		
Clevis Brackets		

### Notes:

- Can release 3 of 4 bolts on either stowed or deployed clevis bracket to rotate out of the way, due to mechanism design
- UMA EVA Override anti-rotation cap must be removed prior to first use of UMA on UCCAS
- 3. EBCS target cover must be removed prior to cargo attachment to UCCAS. Protects target from MMOD and inadvertent contact. Remove as last activity
- RAD or torque wrench may be needed for re-install of deployed clevis bracket if the yoke is installed prior to final torque of bracket bolts. It will likely exceed RAD limits and need to be returned for refurbishment
- 5. The following tether/gap spanner configuration is used to manipulate the PAS into the deployed position: Adjustable short gap spanner short gap spanner Adjustable. Only short gap spanners are available on-orbit, and the adjustable tethers reduce hand fatigue by eliminating manipulation of French hooks

### Cautions:


- If yoke ADP and PIP pin do not release from towed clevis bracket with less than 10 lbf.
  The bracket fasteners must be loosened 4 turns on each bolt prior to releasing yoke
  ADP
- Do not lift diagonal brace greater than 7 degrees out of rotation plane when rotating to temp stowage location so as to not bend hinge end
- Do not close ADP lock bracket when ADP is not inserted in a stowage/clevis hole.
   The pin can fall apart
- 4. EBCS target has finished surface that is susceptible to damage by contact

### Warnings:

None


FS 7-107 EVA/117/FIN

# S3 LOWER OUTBOARD PAS DEPLOY - TASK DATA (Cont)




FS 7-108 EVA/117/FIN


# S3 LOWER OUTBOARD PAS DEPLOY - TASK DATA (Cont)




Active UMA EVA Override with Anti-Rotation Cap



**EBCS Target with Cover** 




Guide Vane and RTL lever



Deployed and Stowed Clevis Brackets (looking from zenith)

FS 7-109 EVA/117/FIN


# S3 LOWER OUTBOARD PAS DEPLOY - TASK DATA (Cont)



Diagonal and SARJ braces and cup-cones



Diagonal and SARJ braces Jack-Joint cup-cones



Adjustable Diameter Pin (ADP) and stowage hole (hinge side)

FS 7-110 EVA/117/FIN

# TOOLS AND STOWAGE

# **TOOLS AND STOWAGE**

PGT CHECKOUT8	3-3
PGSC-PGT CONNECTION (A31P AND 760XD)	3-4
PROGRAM PGT SETTINGS	3-5
DOWNLOAD/ERASE EVENT LOG8	3-5
PGT CONTINGENCIES	3-6
TOOLBOX STOWAGE FS 8	3-7
TOOLBOX PANEL AND SLOT LABELS FS 8	3-8
Z1 TOOLBOX INTERNAL LAYOUT FS 8	3-9
AIRLOCK TOOLBOX INTERNAL LAYOUT FS 8	3-10

# TOOLS AND STOWAGE

This Page Intentionally Blank


TOOLBOX STOWAGE

	Z1 PORT TOOLBOX	Z1 STBD TOOLBOX	A/L TOOLBOX 1 (STBD)	A/L TOOLBOX 2 (PORT)
SLOT#1	SQUARE TM BOARD SQ TORQUE MULTIPLIER 7/16" FLUSH SQ SOCKET 7/16" PROUD SQ SOCKET 7/16" RECESSED SQ SOCKET	SQUARE TM BOARD SQ TORQUE MULTIPLIER 7/16" FLUSH SQ SOCKET 7/16" PROUD SQ SOCKET 7/16" RECESSED SQ SOCKET	HAMMER BOARD HAMMER	CABLE CUTTER BOARD COMPOUND CUTTERS (SM) SCISSORS
SLOT # 2		QD BAIL TOOL BOARD BMRRM LATCH TOOL QD BAIL DRIVE TOOL (1")	PLIERS BOARD NEEDLE NOSE PLIERS	
SLOT #3	RATCHET BOARD 3/8" DRIVE RATCHET 7/16" X 12" WOBBLE SOCKET 7/16" X 2" RIGID SOCKET	RATCHET BOARD 3/8" DRIVE RATCHET 7/16" X 6" WOBBLE SOCKET		
SLOT # 4				
SLOT # 5	ROUND TM BOARD RND TORQUE MULTIPLIER 5/8" PROUD RND SOCKET 7/16" FLUSH RND SOCKET 7/16" PROUD RND SOCKET	ROUND TM BOARD 7/16" FLUSH RND SOCKET 7/16" PROUD RND SOCKET	ADJ WRENCH BOARD FORCEPS WRENCH, ADJ	T-HANDLE TOOL BOARD 1-3" T-TOOLS 2-8" T-TOOLS
SLOT#6	TRASH BAG BOARD LARGE TRASH BAG SMALL TRASH BAG	TRASH BAG BOARD	HYDRAZINE BRUSH BOARD HYDRAZINE BRUSH	
SLOT #7	SOCKET BOARD 5/32" BALL END ALLEN DR 1/2" X 8" WOBBLE SOCKET 5/16" X 7" RIGID SOCKET	SOCKET BOARD 5/32" BALL END ALLEN DR 1/2" X 8" WOBBLE SOCKET 5/16" X 7" RIGID SOCKET	PRD (Toolboard) PRD	PRD (Toolboard) PRD
PANEL #8	CHEATER BAR PANEL ADJ EQUIP TETHER	CHEATER BAR PANEL CHEATER BAR ADJ EQUIP TETHER	TOOL CADDY PANEL CADDY, ISS (BUNGEE)	
PANEL # 9	18" SOCKET PANEL 7/16" X 18" WOBBLE SOCKET	18" SOCKET PANEL	BOLT PULLER PANEL BOLT PULLER MECHANICAL FINGER	LARGE CUTTER PANEL
EXTERNAL	1 SQUARE SCOOP 1 ROUND SCOOP w/D-HANDLE D-HANDLE on port side of toolbox	1 SQUARE SCOOP  NOTE  D-Handle will not stow on the side of this toolbox due to an interference with the CMG MLI		

FS 8-7 EVA/117/FIN


#### **NOTE**

- A/L Toolbox: Slider feature located in center slot only (#3)
- CETA Toolbox: Slider feature located in all slots




FS 8-8 EVA/117/FIN

Z1 TOOLBOX INTERNAL LAYOUT



DOORS SHOWN REMOVED AND ROTATED 180° FROM CLOSED POSITION FOR CLARITY.



FS 8-10 EVA/117/FIN

# EMU MAINI RECHARGI

### **EMU MAINT/RECHARGE**

WATER RECHARGE	TEMP FS	10-2
EMU POWERUP	TEMP FS	10-2
WATER FILL	TEMP FS	10-2
WATER FILL VERIFICATION		10-2
EMU LIOH CHANGEOUT		10-4
MIDDECK EMU BATTERY RECHARGE (STAND-ALONE)		10-4a
MIDDECK EMU BATTERY RECHARGE/LIOH REPLACEMENT		10-5
INITIATE		10-5
TERMINATE		10-6
IN-SUIT EMU BATTERY RECHARGE/CHARGE VERIFICATION		10-7
INITIATE		10-7
TERMINATE		10-7
EMU POWERDOWN		10-7
HELMET LIGHT/PGT BATTERY RECHARGE		10-8
INITIATE		10-8
TERMINATE		10-9
REBA BATTERY INSTALLATION		10-9
EMU BATTERY REMOVAL/INSTALL		10-10
HELMET LIGHT BULB CHANGEOUT		10-11
REBA BATTERY RECHARGE		10-12
INITIATE		10-12
TERMINATE		10-12
STS-117 CONSUMABLES TRACKING CUE CARD	FS CC	10-13
STS-117 BATTERY RECHARGE PLAN	FS CC	10-14
STS-117 LOGISTICS OVERVIEW	F۹	10_15

IF EMU NOT ALREADY POWERED UP:

**EMU POWERUP** 

IBOTH DCM

- 1. Retrieve, position SCUs; remove DCM covers
- 2. Connect SCUs to DCM, √locked
- 3. PWR BATT

CAUTION

EMU must be on BATT pwr when airlock pwr supply is turned on

AW18H 4. PWR/BATT CHGR EMU 1,2 MODE (two) – PWR

BUS SEL (two) – MNA(MNB)

MD(flr)

5. √EMU O2 ISOL VLV – OP

AW82B

6. EV1,2 O2 vlv (two) – OP

DCM

7. PWR - SCU

**WATER FILL** 

MO13Q

8. √ARLK H2O S/O VLV – OPEN (tb-OP)

R11L

9. √SPLY H2O TKA OUTLET – CL (tb-CL)

SM 60 TABLE MAINT

CRT

10. Use TKB quantity:

PARAM ID - ITEM 1 + 0 6 2 0 4 2 0 EXEC

11. Log value before recharge

Recharge #	H2O TKB %
1	
2	
3	
4	
5	

AW82D 12. √EMU 1,2 H2O WASTE tb (two) – CL

SPLY (two) – OP (tb-OP)

13. √H2O TKB quantity decreasing

#### <u>NOTE</u>

Full charge requires ~15 min

#### WATER FILL VERIFICATION

DCM 14. √STATUS: H2O WP 8-15 psi and stable for ~30 sec (indicates charging complete)

SM 60 TABLE MAINT

CRT 15. Use TKB quantity:

PARAM ID - ITEM 1 + 0 6 2 0 4 2 0 EXEC

16. Log value after recharge

Recharge #	H2O TKB %
1	
2	
3	
4	
5	

Cont next page



#### STS-117 CONSUMABLES TRACKING CUE CARD

 EV 1 - Ry:
 EMU 3010
 EV 3 - Fr:
 EMU 3018
 SAFER Usage:
 s/n 1005
 and s/n 1006

 EV 2 - OI:
 EMU 3004
 EV 4 - Sw:
 EMU 3006
 ERCA Usage:
 s/n 16
 and s/n 18

				ERCA Usage. S/II TO and S/II TO			
	LiOH/Metox (s/n or barcode)	EMU Battery (s/n)	HL Battery (s/n)	REBA (s/n)	PGT Battery (s/n)	PWR (s/n)	
	Metox for Campout/10.2 s/n 0012, s/n 0013 EV1: s/n 2028 (LiOH) – launched EV2: s/n 2030 (LiOH) – launched	EV 1: s/n 2077 launched in suit EV 2: s/n 2038 launched in suit	EV 1: <u>1011, 1012</u> EV 2: <u>1013, 1014</u>	EV 1: <u>1003</u> EV 2: <u>1004</u>	EV 1: 5011 EV 2: 5012 (5015 in spare PGT in C-Lk Staging Bag)		
Post EVA 1 – FD 4	Regen <u>s/n 0012</u> , <u>s/n 0013</u>	No EMU Battery charging	Recharge EVA 1 Batts in BSA	Recharge EVA 1 Batts from BSA	Recharge EVA 1 Batts in BSA	Fill: PWR s/n <u>1025</u> Dump: CWC s/n <u>1059</u>	
FD5		EVA 1 EMU Batts (s/n <u>2077</u> , <u>2038</u> ) in BSA					
EVA 2 – FD 6	Metox for Campout/10.2 s/n 0007, s/n 0011 EV3: s/n 0015 (Mtx) EV4: s/n 0016 (Mtx)	EV 3: <u>s/n 2039</u> EV 4: <u>s/n 2040</u>	EV 3: <u>1015, 1017</u> EV 4: <u>1019, 1021</u>	EV 3: <u>1005</u> EV 4: <u>1011</u>	EV 3: <u>5013</u> EV 4: <u>5014</u> ( <u>5015</u> in spare PGT in C-Lk Staging Bag)		
Post EVA 2 – FD 6	Regen <u>s/n 0007</u> , <u>s/n 0011</u>	No EMU Battery charging	Recharge EVA 2 Batts in BSA	Recharge EVA 2 Batts from BSA	Recharge EVA 2 Batts in BSA	Fill: PWR s/n <u>1025</u> If req'd use <u>1023</u> Dump: CWC s/n <u>1059</u>	
FD 7		EVA 2 EMU Batts (s/n <u>2039</u> , <u>2040</u> ) in BSA					
EVA 3 – FD 8	Metox for Campout/10.2 <u>s/n 0017</u> , <u>s/n 0020</u> EV1: <u>s/n 2015</u> (LiOH) EV2: <u>s/n 2017</u> (LiOH)	EV 1: <u>s/n 2077</u> EV 2: <u>s/n 2038</u>	EV 1: <u>1011,1012</u> EV 2: <u>1013,1014</u>	EV 1: <u>1003</u> EV 2: <u>1004</u>	EV 1: <u>5011</u> EV 2: <u>5012</u> ( <u>5015</u> in spare PGT in C-Lk Staging Bag)		
Post EVA 3 – FD 8	Regen <u>s/n 0017</u> , <u>s/n 0020</u> Only if no back to back EVA4					Fill: PWR s/n <u>1023</u> Dump: CWC s/n <u>1059</u>	
EVA 4	Metox for Campout/10.2 s/n 0019 s/n 0021 EV3: s/n 0012 (Mtx) EV4: s/n 0013 (Mtx)	EV 3: <u>s/n 2039</u> EV 4: <u>s/n 2040</u>	EV 3: <u>1015</u> , <u>1017</u> EV 4: <u>1019</u> , <u>1021</u>	EV 3: <u>1005</u> EV 4: <u>1011</u>	EV 3: 5013 EV 4: 5014 (5015 in spare PGT in C-Lk Staging Bag)		
Post EVA 4	Regen <u>s/n 0019</u> , <u>s/n 0021</u>					Fill: PWR s/n <u>1013</u> Dump: CWC s/n <u>1059</u>	

EVA-5a/117/O/B


(reduced copy)

FS CC 10-13 EVA/117/FIN

# TOP Back of 'STS-117 CONSUMABLES TRACKING CUE CARD'




#### STS-117 BATTERY RECHARGE PLAN



(reduced copy)

FS CC 10-14 EVA/117/FIN

STS-117 LOGISTICS OVERVIEW



FS 10-15 EVA/117/FIN

This Page Intentionally Blank

FS 10-16 EVA/117/FIN

### **EMU CONTINGENCY PROCS**

DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART) TEMP F	S 12-2
VACUUM H2O RECHARGE (MANNED) TEMP F	S 12-2
LIOH REPLACEMENT (MANNED)	12-3
BATTERY REPLACEMENT (MANNED)	12-4
WATER DUMP	12-6
SCU SWAP (UNMANNED)	12-7
SCU SWAP (MANNED)	12-7
EMU COLD RESTART (MANNED)	12-7
12.1 STS EVA DECONTAMINATION	
CONTAMINATION TEST	12-15
SAFER BATTERY CHANGEOUT	12-18
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (IN-SUIT)	12-19
BTA PREP	
BTA TREATMENT	12-19
BENDS TREATMENT ADAPTER (BTA) INSTALLATION (POST	
SUIT DOFFING)	12-21
BTA PREP	12-21
BTA TREATMENT	12-21
EMU RESIZE	
STS-117 NOMINAL EMU SIZING F	S 12-27
STS-117/13A FMU CONTINGENCY RESIZE MATRIX	S 12-29

#### **DISPLAY LOSS DURING POWER TRANSFER (WARM RESTART)**

DCM If PWR – BATT and SCU connected:

AW18H 1. √PWR/BATT CHGR EMU 1(2) BUS SEL – OFF

DCM If PWR – SCU:

2. PWR - BATT

AW18H 3. PWR/BATT CHGR EMU 1(2) BUS SEL – OFF

#### WARNING

Fan will be off from steps 4 to 9 during which time CO2 buildup is a concern

#### NOTE

Affected EMU will be without comm after step 6. Steps 6 and 7 should be read together before step 6 is performed

DCM 4. FAN – OFF (expect FAN SW OFF msg, DISP – PRO)

IV 5. Inform affected EV crewmember of impending comm loss

DCM 6. PWR – SCU (7 sec)

7. PWR - BATT

When power restart complete:

8. √Display – O2 POS XX, expect FAN SW OFF msg, DISP – PRO

9. As reqd, FAN – ON

If display blank or locked up: 10. Contact MCC

If SCU power desired:

11. √SCU connected to DCM

AW18H 12. PWR/BATT CHGR EMU 1(2) MODE – PWR

BUS SEL – MNA(MNB)

13.  $\sqrt{\text{EMU INPUT 1(2) Volts}} = 18.0 - 20.0$ 

DCM 14. PWR – SCU

DCM 15. √Display – O2 POS XX

#### **VACUUM H2O RECHARGE (MANNED)**

#### WARNING

Procedure should be used only if performing a contingency EVA

EV 1. Perform AIRLOCK INGRESS, Cuff C/L, 30 (Close hatch, partially engage latches)

2. √Helmet purge vlv – cl, locked

DCM 3. √PURGE vlv – cl (dn)

4. √WATER – OFF

IV MO13Q 5. √ARLK H2O S/O VLV – OPEN (tb-OP)

MD(flr) 6. √EMU O2 ISOL VLV – OP

ML86B:C 7. √cb MNC EXT ARLK HTR LINE ZN 1,2 (two) – op

AW82B 8. √EV-1(EV-2) O2 vlv – OP

EV AW18H 9. PWR/BATT CHGR EMU 1(2) BUS SEL – MNA(MNB)

DCM 10. PWR – SCU (fwd), WARN TONE

IV R11L If SPLY H2O XOVR VLV closed (tb-CL or bp) (water transfer config):

11. SPLY H2O TKA OUTLET – CL (tb-CL)

If SPLY H2O XOVR VLV open (tb-OP) (nominal config):

L1 12. √RAD CNTLR OUT TEMP – NORM

13. √FLASH EVAP CNTLR PRI A,B (two) – OFF


ML31C 14. SPLY H2O TKD OUTLET – CL (tb-CL) R11L 15. SPLY H2O TKB OUTLET – CL (tb-CL)

√TKA OUTLET – CL (tb-CL)
TKC INLET – CL (tb-CL)
TKC OUTLET – OP (tb-OP)

TEMP FS 12-2 EV

EVA/ALL/FIN


#### **STS-117 NOMINAL EMU SIZING**



	Croakie/GRD	Fresnel Lens	Valsalva	LCVG/ BLVD	MAG	TCU Top	TCU Bottom	Comfort Gloves	Socks
Reilly	GRD, Croakie	None	Val (1) EMU Servicing Kit	s/n 3182 06/05	711	L	L	Lg, Thin (-06)	Polyliners (XL) Thermax Liners (L)
Olivas	None	None	MV (1) EMU Servicing Kit	s/n 3206 06/05	709	L	L	(RS) Tipless	Polyliner (L)

FS 12-27 EVA/117/FIN

### STS-117 NOMINAL EMU SIZING (Cont)



	Croakie	Fresnel Lens	Valsalva	LCVG/ BLVD	MAG	TCU Top	TCU Bottom	Comfort Gloves	Socks	
Forrester	Mod [L]	None	Val (1) EMU Servicing Kit	s/n 3174 05/05	709	М	S	Lg, Thick (-12) Lg, Thin (-06)	Thermax Liners (L)	
Swanson	GRD	None	MV (1) EMU Servicing Kit	s/n 3154 03/05	709	М	М	Lg, Thick (-12) Lg, Thin (-06)	Tube	

FS 12-28 EVA/117/FIN

FOR LOSS	EV1 – Reilly	EV2 – Olivas	EV3 – Forrester	EV4 – Swanson		
OF:						
Arm Cams Waist	(3010, Large)  1. Use SW Large HUT  2. Remove SW ring/arm/glove assys  3. Install RY arm/glove assys  4. √Red to Right  5. Remove SW LTA  6. Install RY LTA  7. Swap EMU PLSS identifier stripes  8. √Cams, √Locks  Upper-S Lower-S  (02 L-L)  1. Use ISS spare waist	(3004, Large)  1. Use SW Large HUT  2. Remove SW ring/arm/glove assys  3. Install OL arm/glove assys  4. √Red to Right  5. Remove SW LTA  6. Install OL LTA  7. Swap EMU PLSS identifier stripes  8. √Cams, √Locks  Upper- S Lower- L  (02 S-S)  1. Use ISS spare waist	(3018, Medium)  1. Use OL HUT, Large  2. Remove OL     arm/glove assys  3. Install FR arms/gloves     (no rings)  4. √Red to Right  5. Remove OL LTA  6. Install FR LTA  7. Swap EMU PLSS     identifier stripes  8. √Cams, √Locks  Upper- L Lower- L  (01 S-S)  1. Use spare waist brief	glove assys 4. √Red to right 5. Remove OL LTA 6. Install SW LTA 7. Swap EMU PLSS identifier stripes 8. √Cams, √Locks Upper-S Lower-L  (01 S-L)		
Brief Cams	<ol> <li>Use ISS spare waist brief s/n 024</li> <li>Adjust cams L-L</li> <li>Install RY prime legs/rings/boots assys</li> <li>Swap EMU identifier stripes</li> <li>√Cams, √Locks</li> <li>Upper- L Lower- L</li> </ol>	<ol> <li>Use ISS spare waist brief s/n 024</li> <li>Adjust cams S-S</li> <li>Install OL prime legs/rings/boots assys</li> <li>Swap EMU identifier stripes</li> <li>√Cams, √Locks</li> <li>Upper- S Lower- S</li> </ol>	<ol> <li>Use spare waist brief s/n 021</li> <li>Adjust cams S-S</li> <li>Install FR prime legs/rings/boots assys</li> <li>Swap EMU identifier stripes</li> <li>√Cams, √Locks</li> <li>Upper-S Lower-S</li> </ol>	<ol> <li>Use ISS spare waist brief s/n 021</li> <li>Adjust cams S-L</li> <li>Install SW prime legs/boots assys</li> <li>Swap EMU identifier stripes</li> <li>√Cams, √Locks</li> <li>Upper- S Lower- L</li> </ol>		
Gloves	Upper- L Lower- L (6RY)	(6SM)	Upper- S Lower- S (6MA)	Upper- S Lower- L (6PZ)		
Gioves	Use 6RY s/n 6081 backup (Middeck)	Use 6SM s/n 6242 backup (Middeck)	Use 6MA s/n 6136     backup (Middeck)     Use thin spectra     glove	1. Use 6PZ s/n 6206 backup (Middeck) 2. Use thin spectra glove		
LCVG	(06, 07-Therm Slipper)  1. Use backup LCVG labeled "BU" (Middeck)  2. Transfer biomed, dosimeter	(06, 07-Therm Slipper)  1. Use backup LCVG labeled "BU" (Middeck)  2. Transfer biomed, dosimeter	(05, 07-Therm Slipper)  1. Use KT prime LCVG S/N 3176 on ISS  2. Transfer biomed, dosimeter	(05, 07-Therm Slipper)  1. Use KT prime LCVG S/N 3176 on ISS  2. Transfer biomed, dosimeter		
CCA	(05/327)	(03/327)	(03/321)	(04/327)		
	Use RY B/U (Middeck)	Use s/n 1177 on ISS	Use FR B/U (Middeck)	Use S/N 1183 on ISS		
Lower Arm Segment	(05) 1. Use B/U 05 arms (Middeck) 2. √Red to Right 3. √Cams, √Locks	(05) 1. Use B/U 05 arms (Middeck) 2. √Red to Right 3. √Cams, √Locks	(01) 1. Use B/U 01 arms (Middeck) 2. √Red to Right 3. √Cams, √Locks	(02) 1. Use B/U 02 arms (Shuttle Ext AL Bag) 2. √Red to Right 3. √Cams, √Locks		
Cams	Upper- S Lower- S	Upper- S Lower- L	Upper- L Lower- L	Upper- S Lower- L		
Leg Segment	(03) 1. Use SW 03 leg segment 2. √Cams, √Locks	(03) 1. Use SW 03 leg segment 2. √Cams, √Locks	(03) 1. Use OL 03 leg segment 2. Adjust cams, √Locks	(03) 1. Use OL 03 leg segment 2. √Cams, √Locks		
Cams	Upper- S Lower- L	Upper- S Lower- L	Upper- L Lower- S	Upper- S Lower- L		
Boot	(02)	(02)	(02)	(02)		
Sizing Rings	Use SW 02 boot (s/n 213) (0.5" Thigh, 1.5" Leg) 1. Use LA 0.5" Thigh Ring, s/n 119 or 120 on ISS 2. Use TU 1.5" leg ring, s/n 141 or 142 on ISS	Use SW 02 boot (s/n 213) (1.5" Leg) 1. Use TU 1.5" leg ring, s/n 141 or 142	Use OL 02 boot (s/n 228) (0.5" arm, 0.5" Leg) 1. Use WL 0.5" arm ring, s/n 120 or 121 on ISS 2. Use BB 0.5" leg ring, s/n 122 or 123 on ISS	Use OL 02 boot (s/n 228) (0.5" arm) 1. Use WL 0.5" arm ring, s/n 120 or 121 on ISS		

This Page Intentionally Blank

TPS REPAIR I

The TPS Repair procedures listed below are not published in the hardcopy EVA Flight Supplement. These procedures will be uplinked realtime if they are required.

A PDF and a WORD version of the procedures can be found at: <a href="http://mod.jsc.nasa.gov/do3/FDF/FDFBooks/Status%20Sheets/index.html">http://mod.jsc.nasa.gov/do3/FDF/FDFBooks/Status%20Sheets/index.html</a>. Select the "As Flown" Status sheet for STS-117 and the link to the procedures can be found with the link to the EVA FS. The procedures can also be found on the FDF Books CD provided to the FAO console

BOOM TPS INSPECTION	
BOOM POINT INSPECTION SUMMARY TIMELINE	FS 13-3
BOOM POINT INSPECTION TOOL CONFIG	FS 13-4
BOOM POINT INSPECTION	
BOOM WLE MAPPING SUMMARY TIMELINE	
BOOM WLE MAPPING TOOL CONFIG	
BOOM WLE MAPPING	
EVA WLE MAPPING INSPECTION	FS 13-24
SAFER TPS INSPECTION	
SAFER TPS INSPECTION SUMMARY TIMELINE	FS 13-29
SAFER TPS INSPECTION TOOL CONFIG	FS 13-30
SAFER TPS INSPECTION	FS 13-31
BOOM CONTINGENCY	
BOOM FRGF SHAFT RELEASE	FS 13-37
BOOM FRGF SHAFT INSTALLATION	
BOOM EFGF SHAFT RELEASE	FS 13-40
BOOM MPM STOW/DEPLOY	FS 13-42
BOOM ASSISTED LATCHING	
TILE REPAIR	
EMU PREP FOR TPS REPAIR	FS 13-44
POST TPS REPAIR DOFFING	FS 13-45
EWA MATERIAL MIXING	FS 13-46
EWA REF DAT	FS 13-47
EWA TILE REPAIR - DOCKED/ORM SUMMARY TIMELINE	FS 13-48
EWA TILE REPAIR - DOCKED/ORM TOOL CONFIG	FS 13-49
EWA TILE REPAIR - DOCKED/ORM	FS 13-50
SSRMS GAP FILLER REMOVAL SUMMARY TIMELINE	FS 13-58
BOOM GAP FILLER REMOVAL SUMMARY TIMELINE	FS 13-59
GAP FILLER REMOVAL	FS 13-60
RCC REPAIR	
RCC CRACK REPAIR BAG ASSEMBLY	FS 13-65
TEMP SENSOR DISASSEMBLY POST-EVA	FS 13-68
RCC CRACK REPAIR BAG DISASSEMBLY POST-EVA	
TEMPERATURE PROBE ASSEMBLY	FS 13-71
CRM APPLICATOR ASSEMBLY	
CRM APPLICATOR NOZZLE INSTALLATION (DAY OF EVA)	FS 13-72
RCC CRACK REPAIR	FS 13-73
RCC PLUG TRANSFER BAG ASSEMBLY	FS 13-85
NOTES, CAUTIONS, WARNINGS	
EVA TPS INSPECTION/REPAIR INHIBIT PAD	FS 13-97
TPS REPAIR CAUTIONS AND WARNINGS	FS 13-100
TPS REPAIR NOTES	FS 13-101
BOOM OPERATIONAL WARNINGS	FS 13-102
BOOM OPERATIONAL NOTES	FS 13-103

TPS REF DATA	
PREFERRED EMU POSITIONING FOR TPS REPAIR	FS 13-104
EVA TPS REACH AND ACCESS	
POINT INSPECTION REACH AND ACCESS WHILE DOCKED	
WLE MAPPING INSPECTION WHILE DOCKED	FS 13-108
TILE LAYUP	
85-FOOT SAFETY TETHER	FS 13-110
PFR ATTACHMENT DEVICE (PAD)	FS 13-111
WIF EXTENDER	FS 13-112
EVA DIGITAL CAMERA	FS 13-113
EVA IR CAMERA	
OVERLAY TILE REPAIR SYSTEM (OTRS)	FS 13-117
OTRS MARKING TEMPLATE AND INSULATION BAGS	
AUGER HOUSING	FS 13-119
OTRS RELEASED CONFIGURATION	
ORU BAG INSERT FOR OTRS	FS 13-121
BOOM REF DATA	
RTF BOOM OVERVIEW	
BOOM TRANSITIONS WITH MLI	
BOOM BASE END AND MODIFIED EFGF	
BOOM BASE END EFGF ADAPTER PLATE	
EVA-ASSISTED EFGF CONNECTOR DEMATE	
BOOM BASE END SADDLE AND MPM	
BOOM MID SECTION AND MODIFIED FRGF	
BOOM MID SECTION FRGF ADAPTER PLATE	
BOOM TIP END AND SENSORS	
BOOM SENSOR DETAILS	
SENSOR PACKAGE 1 (SP1): LDRI/ITVC	
SENSOR PACKAGE 2 (SP2): LCS	FS 13-136
POSSIBLE PRD ROUTING FOR EVA ASSISTED LATCHING	
OF BOOM IN MPMS	
BOOM CONTINGENCIES	
GRAPPLE SHAFTS	
PDGF GRAPPLE SHAFT COVER	
	1 ( 40 4 40

### UNSCHEDULED/CONTINGENCY EVA TASKS

13A WORKAROUNDS CRIBSHEET	TEMP	FS	16-2
S1-S3 CAPTURE LATCH OVERRIDE			
S1-S3 MBA BOLT OVERRIDE		FS	16-19
S1-S3 SSAS CONTINGENCY BOLT INSTALL		FS	16-23
MANUAL OVERRIDE TO UNLATCH/LATCH (TENSION) SABB		FS	16-25
MANUAL RELEASE OF SABB RESTRAINT PINS		FS	16-27
MANUAL OVERRIDE TO EXTEND/RETRACT MAST		FS	16-30
SABB SPOOL RE-TENSION		FS	16-33
EVA ASSISTED DEPLOYMENT OF S4 SAW		FS	16-39
SSRMS JOINT DRIVE		FS	16-42
MANUAL SAW JETTISON		FS	16-47
BDCU BACKOUT		FS	16-53
REMOVE AND REPLACE DCSU		FS	16-56
REMOVE AND REPLACE PVCU LOWER		FS	16-61
MDM REMOVE AND REPLACE		FS	16-64
CANADIAN REMOTE POWER CONTROL MODULE (CRPCM)			
REMOVE/REPLACE		FS	16-68
MBSU REMOVE/REPLACE		FS	16-72
REMOVE AND REPLACE PECS		FS	16-79

### **13A WORKAROUNDS CRIBSHEET**

Procedure	Failure	Work-Around Steps		
I. GENERIC	TA Clamps			
	TA clamps fail to release	A. With handle up, press down on top of rounded clamp     B. With handle up, use tether hook to pry drawhook from capture pin		
	NZGL Connectors	diawnook iroin capture piir		
	2. Connector fails to release	A. Verify bail is in fully demated position (aft)		
	from softdock	B. Inspect connector/bail for FOD		
		C. Check alignment/side loads/interference		
		D. Wiggle/jiggle connector		
		E. On MCC GO: Use EVA hammer or		
		similar tool to gently tap bottom of		
		connector		
	3. Connector fails to softdock	A. Inspect:		
		• FOD		
		■ EMI band		
		Bend radius		
		<ul> <li>Soft dock springs</li> </ul>		
		<ul> <li>O-ring seal</li> </ul>		
		Connector keying features		
		B. Verify bail is in fully demated position (aft)		
		C. Check alignment/side loads/torsion		
	4. O	D. Wiggle/jiggle connector		
	4. Connector pin bent	A. Report bent pin location to MCC		
		B. Verify pin gauge with MCC; retrieve		
	5 Commenter FOD	connector pin straightener, straighten		
	5. Connector FOD	A. On MCC GO: obtain Connector Cleaner		
	C. Comporter FMI bond bont	Tool to remove FOD (A/L staging bag)		
	6. Connector EMI band bent	A. On MCC GO: obtain Needle Nose Pliers		
	7	or Forceps to remove band		
	7. Connector bail linkage	A. Pull (to demate) or push (to mate) on		
	failure	connector backshell to assist bail motion		
		B. On MCC GO: Tether hooks or Vise Grips		
		may be used for additional leverage on bail		
	8. Connector soft dock spring	A. On MCC GO: obtain Needle Nose Pliers,		
	bent	attempt to remove bent spring		
	9. Connector O-ring seal loose			
	Ů	B. On MCC GO: obtain Needle Nose Pliers		
		to remove seal		

Procedure	Failure	Work-Around Steps		
	MMOD Shield			
	10. MMOD shield Dzus fastener fails to release  WARNING  Do not touch back side of MMOD Shields or handle fastener fragments due to sharp edges  Fastener and shield/tool interface must be covered to avoid potential projectiles	C. D.	Retrieve Pry Bar (A/L staging bag) and emptied Med ORU Bag Release other MMOD shield fasteners Assess clearance between MMOD shield and tools If possible, rotate fasteners to position tangs off of tools Place Med ORU Bag over failed fastener Insert prybar under MMOD shield by failed fastener; pry shield away from structure until fastener is free	
	11. MMOD shield Dzus fastener fails to engage	C. D.	Verify center fastener is engaged first Check Dzus fastener aligned with bracket Verify fastener clocking correct per alignment mark Push firmly and rotate Engage other fasteners: 2 of 3 required	
	12. T-handle tool fails to engage shield			
	13. MLI grounding strap Dzus fails to release	A.	Cut ground wire near Dzus	
	APFR/IAPFR			
	14. APFR/IAPFR fails to install into WIF	А. В.	Verify APFR/IAPFR collar in install position Check for FOD in WIF or structural	
			interference Attempt APFR install in alternate clocking and/or WIF position If APFR does not install (APFR failure), use another APFR	
	15. Joint fails to actuate	B.	Verify no load is applied to joint For pitch joint, push knob in during rotation Increase force applied to free joint	
	16. Boot becomes stuck in APFR boot plate		Remove 7/16-in EVA bolts (3) on heel plate using EVA ratchet or <b>PGT: [B1</b> 12.0 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5]</b> , 5 turns	
	17. Boot becomes stuck in IAPFR boot plate	A.	Remove 7/16-in EVA bolts on heel plate (2 per boot) using EVA ratchet or <b>PGT</b> : <b>[B2</b> 16.0 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5]</b> , 4 turns	
	Safety Tether			
	18. 85-ft or 55-ft safety tether fails to tend		Verify safety tether reel is unlocked Pull out small amount of cable, allow reel to retract while holding cable slightly tensioned Tap side of reel housing during retract Use alternate safety tether	
	19. Crew hook fails on load alleviating side or red mark on load alleviating strap showing	A.	Use second Waist Tether to replace load alleviating strap; retrieve replacement safety tether	

FS 16-3

Procedure	Failure	Work-Around Steps		
	Torque Multiplier		·	
	20. Torque multiplier fails to release from fitting	В.	Verify torque multiplier anti-backlash in neutral, if not, PGT[RCW, MTL 30.5].  Apply cw torque and push anti-backlash button to neutral position.  PGT[A5 7.0 ft-lb, CCW2 30 RPM, MTL 30.5] - 5/32 Allen Drive: Release torque multiplier contingency release band pin 20 turns (do not exceed 28 turns).  When contingency band springs open, remove torque multiplier; return torque multiplier IVA	
	Scoops			
	21. Scoop will not release from fitting	A.	PGT[A2 3.8 ft-lb, CCW2 30 RPM, MTL 30.5] - 5/32 Ball-end Drive Assy: Remove screws (non-captive) 5 turns	
	Fluid QD Ops			
	Mating Ops			
	22. QD fails to mate		Check for debris, damage, or crystals; verify release ring is retracted Check alignment; verify no side loading present	
	23. Release ring snap back test	Α.		
	fails		Demate and remate QD	
	24. Gap check fails (visual or FID gauge)	_	Retract release ring, demate/remate QD	
	Valve Ops			
	25. Bail fails to actuate (to valve open)		Check for debris, damage, or crystals; depress button, attempt to actuate Retrieve and use QD bail drive lever tool	
	26. Detent button fails to pop up			
	after bail actuation (to valve open)		opening force to QD bail handle Contact MCC for use of QD bail drive	
	27. Detent button fails to depress	٨	lever tool to apply greater force	
	CAUTION  Handle may kick back when button is depressed and pressure is built up in spring cavity from a leaking primary seal		Push bail handle fwd (to open) to relieve load on button while depressing detent button  1. If button depresses, vent by pulling bail aft until release ring covers aft white band  2. Push bail fwd to valve open; check button depresses	
		C.	On MCC GO: Retrieve QD bail drive lever tool to push bail fwd  1. Repeat step B with the QD bail drive lever tool	
			Contact MCC to reduce NH3 temperature at affected QD, if possible On MCC GO: Install QD button depress tool (BDT)	
	28. Bail fails to actuate or detent	A.		
	button fails to pop up after	В.		
	actuation (to valve close)	C. D.	•	

Procedure	Failure	Work-Around Steps
	Demating Ops	
	29. Female QD fails to demate	Verify release ring is retracting fully while attempting to demate
		B. Verify line clamps are released
		C. Verify locking collar has been successfully
		rotated under detent button (for ½, ¾, 1 in
		QDs) – verifies button is all the way up
		D. For 1.5 in QD, verify trigger linkage is still
		attached to release ring; if not re-attach  E. Neutralize sideloads or manipulate flexhose
		to relieve mating forces on female QD  F. Apply greater retraction force to release
		ring and/or greater removal force to female
		QD while neutralizing sideloads
		G. Contact MCC for use of QD Release Tool
		(QRT) to apply greater force
	30. Bootie fails to remain	A. Install wire tie around bootie to keep QD
	securely closed	fully covered
	31. Fluid cap will not demate	A. For 1/4, 1/2, and 1 in:
	·	<ul> <li>Retrieve QD cap tool (QD Tool Bag – A/L)</li> </ul>
		<ul> <li>Reconfigure PGT [A4 6.3 ft-lb, CCW1 10</li> </ul>
		RPM, MTL <b>10.5]</b> ; install QD Cap Tool
		<ul> <li>Use cap tool to turn stuck cap a</li> </ul>
		maximum of 2 turns (cap vents at ~2
		turns). Finish removal of cap by hand
		(1 additional turn)
		B. If force too great for hand actuation or
		crystals visible around the QD (may have
		leaking male) re-install QD cap, notify MCC
	Leaks	IVICC
	32. Male QD leaks after cap	A. Re-install QD cap, notify MCC
	removed	Ne-install QD cap, notify Moo     Prepare for quick mate
	33. Female QD leaks during or	A. Return bail to closed position
	after bail actuation (to valve	B. Perform release ring pull-back to verify no FID
	open)	1. If FID is observed, demate/remate QD
		2. If no FID, neutralize sideloads, cycle
		bail to open position
	34. Mated QD leaks (valve open	
	position)	B. If leak continues, close valve (bail aft)
	35. Leaking QD – after SPD	A. Remove SPD, open valve, verify detent
	install	button up, aft white line visible
		<ol> <li>If leak stops, rotate locking collar to lock</li> </ol>
		B. Close valve, verify detent button up, fwd
		white line visible; rotate locking collar to lock
		C. If applicable, close valve of appropriate
		QD in flowpath, verify detent button up,
	36. After demate, female QD	

FS 16-5

Procedure	Failure	Work-Around Steps		
	37. After demate, male QD leaks	A.	Remate female QD to male and open valve (bail forward)  1. Depress button and use significant force to push bail forward, then release button  2. With QD in open position apply significant force to end of the female QD in back and forth, up and down directions  3. Attempt to close valve  4. Demate QDs, and inspect If applicable, close valve of appropriate QD in flowpath Install cap (exception: 3/4, 1.5 in)	
	38. Frozen ammonia present on female/male QD	A.	Leave QD exposed to vacuum; wait maximum of 5 min for sublimation (check periodically)  If ammonia still present after 5 min, continue with operation	
	SPDs 39. 1-in SPD spring-loaded capture point fails to install	A.	Manually pivot capture point into place	
	On-orbit Installed Handrails     OIH shoe will not engage in soft dock	A.	Verify button depressed (shoe extended)	
II. SSAS	41. Ready to Latch – fails to detect RTL	A.	If camera views not adequate, EVA crew will provide visual RTL if sensors are in question	
	42. Capture Latch Assembly failed closed		PGT[A7 9.2 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/16: Drive manual override up to 60 turns Leave latch closed	
III. SABB LAUNCH RESTRAINT	43. SABB launch restraint will not release	A.	PGT[RCCW, MTL 30.5] RD TM w/5/8" PRD: Apply manual torque to fastener 3/8" Drive Ratchet – RD TM w/5/8" PRD: Apply ccw manual torque to fastener	
IV. BETA GIMBAL LAUNCH RESTRAINT	44. Beta Gimbal launch restraint will not release	В.	PGT[B7 25.5 ft-lb, CCW3 60 RPM, MTL 30.5] RD TM w/5/8" PRD: Apply torque, report release torque to MCC PGT[RCCW, MTL 30.5] RD TM w/5/8" PRD: Apply manual torque to fastener 3/8" Drive Ratchet – RD TM w/5/8" PRD: Apply ccw manual torque to fastener	
V. 4-BAR LINKAGE	45. Four bar linkage does not deploy to the locked position		Push on 4-bar linkage until latches engage If required, install PRD between IEA and Beta Gimbal Assembly structure. Ratchet PRD to pull 4-bar into locked position	

Procedure	Failure	Work-Around Steps			
VI. IEA KEEL PIN	46. IEA Keel Pin fastener will not release	A. PGT[RCCW, MTL 30.5]-6 ext 7/16: Apply torque B. Ratchet wrench, 9 rigid ext 7/16: Apply torque C. Retrieve SQ TM w/ 7/16 PRD D. Ratchet wrench, SQ TM: Apply torque, 1 turn E. On MCC GO,  WARNING Sharp edge hazard, bolts have exposed threads  Remove keel pin nut plate: 1. PGT[B1 12 ft-lb, CCW1 10 RPM, MTL 30.5]-6 ext 7/16: Drive ~14 turns 2. Release non-captive fasteners (2) and stow in trash 3. Unfasten hex nut with adjustable wrench and stow in trash 4. Translate to inboard side of keel housing and remove keel pin fastener			
VII. SAW	47. SABB strut locking collar does not engage after SABB unstow	If jammed, use hammer to drive bolt out     A. Insert SABB PIP pin when the Pivot Locking Mechanism is in BOX UNSTOWED position. Apply manual force to engage locking collar     B. If locking sleeve is reset to the STOW position, cycle SABB to LAUNCH position and then back to the UNSTOWED position			
	48. Mast Tip Fittings will not release	<ul> <li>C. Install Locking Strut Aid</li> <li>A. On MCC GO, PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Apply torque, report release torque to MCC-H</li> <li>B. If free spinning nut plate: <ol> <li>Retrieve vise grips</li> <li>Attach vise grips to nut plate</li> <li>Turn bolt while restraining nut plate</li> </ol> </li> </ul>			
VIII. UTA CENTER BOLT	49. Loss of electrical connectivity between S3 and S4	A. Check position of UTA center bolt Sharpie			
IX. SARJ ACTIVATION	50. SARJ MLI Cover Spring Clamp Bolt will not release	A. If free spinning nut plate suspected:     1. Retrieve vise grips from Crewlock bag     2. Attach vise grips to bolt head     3. Turn bolt ccw while applying gentle pull force (do not fail bolt/retention clip)			

Procedure	Failure	Work-Around Steps
		B. <b>PGT[B7</b> 25.5 <b>ft-lb, CCW2</b> 30 RPM, MTL
		<b>30.5] -6 ext 7/16</b> : Drive bolt 1 turn only
		C. Remove spring clamp assembly and fail
		bolt/retention clip
		1. <b>PGT[A3</b> 4.8 ft-lb, <b>CCW2</b> 30 RPM, MTL
		<b>30.5]</b> Drop proof tether adapter, 3/8"
		drive IVA socket tool stack
		Release non-captive spring clamp 3/8"
		bolts/washers (x2 each) x9 turns, stow in
		trash bag
		Move cover away from worksite to keep
		FOD clear of SARJ
		4. Use vise grips to force spring clamp bolt
		out; potential FOD: bolt, spring,
		retaining clip, nut plate
		5. Stow spring clamp assy and FOD in
		trash bag
		6. Re-install MLI cover
	51. SARJ MLI Cover Inboard Bolt	
	will not release	30.5]-6 ext 7/16: Drive bolt 1 turn; report
		release torque to MCC-H
	52. SARJ MLI Cover Inboard	A. Engage other inboard bolts. (Minimum
	Bolt will not engage	number of bolts that must be re-installed
		is 2 of 4 or 3 of 6 per cover panel)
	53. SARJ Launch Lock will not	A. Release other 3 bolts. <b>PGT[RCCW</b> , MTL
	release	30.5]-6 ext 7/16: Apply manual torque to
		fastener
	54. SARJ Launch Restraint –	A. Retrieve SLR Torque Mutiplier from A/L
	retaining bolts will not	and cheater bar from Z1 stbd tool box.
	release	B. Install SLR Torque Multiplier on failed bolt
		C. <b>PGT[B7</b> 25.5 ft-lb, <b>CCW2</b> 30 RPM, MTL
		30.5] MTM: Apply torque
	55. SARJ Launch Restraint	A. <b>PGT[B7</b> 25.5 ft-lb, <b>CCW2</b> 30 RPM, MTL
	cannot be removed after	<b>30.5]-6 ext 7/16</b> : Drive jacking bolt
	retaining bolts released 18	maximum of 9 turns total
	turns	
	56. DLA Lock Bolts 1A, 2A will	A. <b>PGT[B7</b> 25.5 ft-lb, <b>CCW2</b> 30RPM, MTL
	not release	<b>30.5]-6 ext 7/16</b> : Report release torque to
		MCC-H
		B. <b>PGT[RCCW</b> , MTL <b>30.5]-6 ext 7/16</b> : Break
		torque in manual ratchet mode
		C. Drive associated DLA Draw Bolt (1C CW
		or 2C <b>CCW</b> ) 6 turns in clamp direction
		(moves follower arm enough to clear race
		ring structure during deploy), proceed with
		nominal procedure
	57. DLA Draw Bolt 1C will not	A. <b>BOLT 1A: PGT[A6</b> 8.3 ft-lb, <b>CCW2</b> 30
	release (unable to break	RPM, MTL <b>30.5]-6 ext 7/16</b> : Release 1
	initial torque)	turn; re-attempt 1C
		B. If NO JOY: <b>BOLT 1C: PGT[B7</b> 25.5 ft-lb,
		CW1 10 RPM, MTL 30.5]-6 ext 7/16:
		Report release torque to MCC-H
	58. DLA Draw Bolt 2C will not	A. BOLT 2A: PGT[A6 8.3 ft-lb, CCW2 30
	release (unable to break	RPM, MTL <b>30.5]-6 ext 7/16</b> : Release 1
	initial torque)	turn; re-attempt 2C
		B. If NO JOY: <b>BOLT 2C: PGT[B7</b> 25.5 ft-lb,
		CCW1 10 RPM, MTL 30.5]-6 ext 7/16:
		Report release torque to MCC-H

FS 16-8

Proce	edure	Failure	Work-Around Steps		
		59. DLA Launch Restraint Bolts 4A, 4B, 4C	В.	PGT[RCCW, MTL 30.5]-6 ext 7/16: Break torque in manual ratchet mode Ratchet Wrench-6 ext 7/16: Break torque	
IX. S	SARJ BRACE	60. Unable to release launch restraint bolt		<b>PGT[B7</b> 25.5 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5]-6 ext 7/16:</b> Drive bolt 1 turn, report release torque to MCC	
		61. Unable to re-engage launch restraint bolt	A.	Secure launch restraint bolt with wire tie	
		62. Unable to insert cones into cups	A.	Restow SARJ brace in launch config	
		63. Unable to break torque on brace cone fastener		PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]-6 ext 7/16: Drive fastener 1 turn, report release torque to MCC	
				PGT[RCW, MTL 30.5]- 6 ext 7/16: Break torque in manual ratchet mode Ratchet Wrench-6 ext 7/16: Break	
X. /	AJIS STRUTS	64. Unable to insert cones into cups	A.	torque  Restow AJIS Strut in launch config, installation of MLI strap not required	
		65. Unable to break torque on brace cone fastener	A.	PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]: Drive fastener 1 turn, report release torque to MCC	
XI. S	SVS TARGET	66. SVS target bolt will not release		PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Drive bolt 1 turn PGT[RCCW, MTL 30.5]-6 ext 7/16: Drive	
	REMOVE AND STOW DRAG LINK	67. Drag link fastener will not release  WARNING		Release other end then reattempt failed bolt PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Drive bolt 1 turn	
		Nutplate rivets may break; potential sharp edges/debris		PGT[RCCW, MTL 30.5]-6 ext 7/16: (failure 32.3 ft-lb) Drive bolt 1 turn On MCC GO, Ratchet Wrench-6 ext 7/16: break torque	
		68. Drag link fastener will not re- install		<b>PGT[A7</b> 9.2 ft-lb, <b>CW2</b> 30 RPM, MTL <b>30.5]</b> : Apply torque, report torque to MCC If only one bolt functional, orient drag link as required to use good bolt for clevis bracket	
			C.	If NO JOY using other bolt, wire tie or tether drag link in stowage position	
XIII.	REMOVE/ STOW KEEL	69. Nut retainer bolt is not sufficiently engaged	A.	PGT[A2 3.8 ft-lb, CW2 30 RPM, MTL 30.5] (failure 5.4 ft-lb): Apply torque, report	
	PIN	WARNING Bolt may shear at thread interface	В.	torque to MCC Use vise grips to retain nut during keel pin bolt release. Adjustable Wrench will not fit flats of nut	
		Potential sharp edges and debris			
		70. Keel pin bolt will not release	A. B.	Gently shake keel pin to relieve potential binding, reattempt bolt release <b>PGT[B7</b> 25.5 ft-lb, <b>CCW2</b> 30 RPM, MTL <b>30.5]</b> : Drive bolt 1 turn, report release torque to MCC	

Proce	edure	Failure	Work-Around Steps		
		71. Keel pin bolt is released from nut, but will not release from bracket	A.	Use bolt puller (A/L toolbox 1) to free bolt from bracket	
		72. Keel pin bolt will not reinstall	A.	Stow keel pin bolt in keel with wire tie/tethers as necessary	
XIV.	PV RADIATOR	73. Cinch bolt fails to release	A.	PGT[RCCW, MTL 30.5]-6 ext 7/16: Apply manual torque	
XV.	LAB VENT	74. H2 vent nozzle cannot be bent to fit through Lab end ring bracket	A. B. C.	Remove gamah nut by hand Install vent nozzle through Lab end ring bracket Install gamah nut on feedthrough; use caution to reduce side loads during thread engagement	
		75. Vent nozzle fasteners fail to release	A.	PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]: Drive bolt 1 turn. Warning: potential sharp edges if bolt fails	
				NOTE If bolt fails during release, H2 vent can be held in place through Lab end ring bracket by compression from hose	
		76. Vent nozzle fasteners cannot be reinstalled	А. В.	Verify vent nozzle aligned with key feature on inside of end ring bracket; attempt bolt engagement by hand Leave nozzle in end ring bracket without bolts	
XVI.	GPS	77. GPS bolts will not release	А. В.		
		78. Unable to release antenna from soft dock		Rotate antenna cw (~25 deg) pull on antenna bolt flanges Retrieve bolt puller (A/L toolbox 1). With antenna rotated cw (~25 deg), position bolt puller close to soft dock pin to pry antenna out	
XVII.	ETVCG	79. FSE launch restraint bolts fails to release	В.	PGT[RCCW, MTL 30.5]-6 ext 7/16: Reattempt restraint bolt release Ratchet Wrench-6 ext 7/16: Break torque On MCC GO: go to next stanchion and release	
		80. Stanchion fails to slide off of FSE	A.	Use EVA hammer to persuade stanchion	
		81. Stanchion bolt doesn't release from launch position or drop	A.	PGT[RCW, MTL 30.5]-6 ext 7/16: Break torque	
		82. Stanchion bolt does not fully engage		Release stanchion bolt, verify alignment and reattempt PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]-6 ext 7/16: Reattempt stanchion bolt engage Remove stanchion, inspect bolt and truss interface, report to MCC	

Procedure	Failure	Work-Around Steps		
	83. PGT socket comes off	Attempt to reen	gage bolt	
	stanchion bolt		from PGT; engage socket	
			olt, then put back on PGT	
			ench or torque wrench	
XVIII. UCCAS	84. SARJ Brace Launch Lock		-lb, CCW2 30 RPM, MTL	
AVIII. UCCAS				
	bolt fails to release	<b>30.5]</b> : Drive bo		
			TL <b>30.5]</b> : Apply manual	
		torque		
	85. SARJ Brace cup/cone bolt	PGT[B7 25.5 ft-	-lb, CCW2 30 RPM, MTL	
	fails to release	<b>30.5]</b> : Drive bo	lt 1 turn	
		PGT[RCCW, M	TL <b>30.5]:</b> Apply manual	
		torque		
	86. SARJ Diagonal cup/cone		-lb, CCW2 30 RPM, MTL	
	bolt fails to release	<b>30.5]</b> : Drive bo		
	boil fails to release			
		-	TL 30.5]: Apply manual	
		torque		
	87. Strut cone cannot be		rance between cup and	
	removed from cup interface	cone, if reqd, Po	<b>GT[A7</b> 9.2 ft-lb, <b>CCW2</b> 30	
		RPM, MTL <b>30.5</b>	i]-6 ext 7/16: Release bolt	
		to hardstop		
			vorked during VITT	
		deploys)	9	
		Retrieve hamm	er and tan brace	
	99 Doploy brooket helt feile to		TL <b>30.5]:</b> Apply manual	
	88. Deploy bracket bolt fails to		TE 30.5]. Apply manual	
	release	torque	1 . 400 (: 11	
			nch to 100 ft-lbs, attempt	
			Stop applying force if	
		torque wrench b		
	89. Yoke PIP pin will not release	PGT[B7 25.5 ft-	-lb, <b>CCW2</b> 30 RPM, MTL	
	with less than 10 lbf	30.5]-6 ext 7/16	5: Loosen stowage clevis	
		bracket bolts (4		
			er, strike PIP pin in	
		outward direction		
	90. ADP will not release with		lb, <b>CCW2</b> 30 RPM, MTL	
	less than 10 lbf		5: Loosen stowage clevis	
	less than 10 lbi			
		bracket bolts (4	,	
			open position, tap inward	
			with hammer. Reattempt	
		removal		
	91. Stowage bracket bolt fails to	PGT[RCCW, M	TL <b>30.5]</b> : Apply manual	
	release	torque		
		•	of PIP pin and ADP to	
		free yoke, then		
	92. Stowage bracket bolts will		vage bracket; bring inside	
	not fully torque		rago bracket, bring maide	
		at end of task	alayda halta arad saatta saat	
	93. Yoke will not engage deploy		clevis bolts and reattempt	
	clevis	to engage yoke		
			MTL <b>30.5]-6 ext 7/16</b> :	
			is bolts (4) ~4-6 turns	
		<ol><li>Reattempt yo</li></ol>	ke, ADP, and PIP pin	
		installation	•	
			ft-lb, CW2 30 RPM, MTL	
			/16: Engage clevis bolts (4)	
		to torque	10. Engage devis bolts (4)	
			ATI 20 51 6 04 7/40- April	
			TL 30.5]-6 ext 7/16: Apply	
		final torque to		
	Í	It access to clevi	s bolts is restrictive, retrieve	
			ch for steps A1-A4	

Procedure	Failure	Work-Around Steps
	94. PIP pin will not install	<ul> <li>A. Open handle of ADP, reattempt PIP pin installation</li> <li>B. Manipulate yoke to align PIP pin holes, reattempt PIP pin installation</li> <li>C. Remove ADP, loosen deploy clevis bolts ~4-6 turns, reattempt installation of ADP and PIP pin</li> </ul>
XIX. IEA MMOE SHIELD	95. Bolt fails to release	<ul> <li>A. PGT[RCCW, MTL 30.5]-6 ext 7/16:</li> <li>Break torque</li> <li>B. Ratchet Wrench-6 ext 7/16: Break torque</li> </ul>
XX. SASA	TBD	TBD

FS 16-12

EVA/117/FIN

### **S1-S3 CAPTURE LATCH OVERRIDE**

IV/SSRMS	EV1	EV2
CAPTURE LATCH MANUAL DRIVE FOR FAILED OPEN CLA	CAPTURE LATCH MANUAL DRIVE FOR FAILED OPEN CLA	
IV 1. First stage capture complete, GO to limp SSRMS MCC-H 2. Inhibit mechanism autosafing	PGT[A6 8.3 ft-lb, CW1 10RPM, MTL 30.5]-6 ext 7/16:     Drive manual override up to 42 turns to topological capture	
CAUTION  Verify and maintain good communication with EV crew during manual override drive		
If SSRMS safing occurs during EVA manual drive of CLA, IV must notify EV crew to stop driving the manual override immediately to prevent SSRMS damage		
IV 3. Give EV GO to continue latch closure	<ol> <li>On IV GO, rotate drive to hard stop (approx 85 turns, 127 total turns)</li> <li>PGT[A6 8.3 ft-lb, CCW2 30RPM, MTL 30.5]-6</li> </ol>	
NOTE  If less than 64 additional turns (105 total turns) before hard stop, capture latch closure not complete, go to CAPTURE LATCH OVERRIDE WITH PRDs	ext 7/16: Drive manual override 5 turns to final close position	
MCC-H 4. On EV GO, perform nominal MBA bolting	Give IV GO for nominal MBA bolting     If NO JOY closing capture latch, continue with     CAPTURE LATCH OVERRIDE WITH PRDs	
CAPTURE LATCH OVERRIDE WITH PRDs	CAPTURE LATCH OVERRIDE WITH PRDs	CAPTURE LATCH OVERRIDE WITH PRDs
CAUTION  If SSRMS safing occurs during PRD ratcheting, IV must notify crew to stop ratcheting immediately to prevent SSRMS damage	CAUTION  Do not exceed 200 lbf on EVA handrails while ratcheting with PRDs. When PRD actuating force increases sharply during bail throw, stop actuating	
Verify and maintain good communication with EV crew during PRD ratcheting	Install PRD on zenith longeron between handrails     S1-3212 (outboard standoff) and S3 – 3013 (inboard)	Install PRD between handrails S1-3200 (standoff by 5820) and S3 – 3000 (nadir CETA rail handrails) with
IV 1. First stage capture complete, GO to limp SSRMS	standoff) with fixed end on S1 handrail 2. Pull minimum 6 inches slack in strap. Ratchet PRD snug (14 full strokes reqd) 3. Verify SSAS coarse pin engages cone	fixed end on S1 handrail  2. Pull minimum 6 inches slack in strap. Ratchet PRD snug (14 full strokes reqd)  3. Verify SSAS coarse pin engages cone

FS 16-13 EVA/117/FIN

# S1-S3 CAPTURE LATCH OVERRIDE (Cont)

IV/SSRMS	EV1	EV2
2. Give EV GO to continue ratcheting PRDs	4. On IV GO, ratchet PRD until trusses fully seated (0.5 inch bulkhead clearance) or PRD actuating force increases sharply during PRD bail throw  5. Install contingency bolt 1B, DO NOT PRELOAD  6. PGT[A7 9.2ft-lb, CW2 30RPM, MTL 30.5]-7.8  ext 5/8: If required, use RAD: Drive contingency bolt 1B (zenith) until bolt head seated  7. DO NOT PRELOAD. Install and drive contingency bolt 2B (zenith CETA rail) until bolt head seated  CAUTION  Structural damage may occur if PRD tension is not released prior to preloading EVA contingency bolts	<ol> <li>On IV GO, ratchet PRD until trusses fully seated (0.5 inch bulkhead clearance) or PRD actuating force increases sharply during PRD bail throw</li> <li>Install contingency bolt 3B, DO NOT PRELOAD</li> <li>PGT[A7 9.2 ft-lb, CW2 30RPM, MTL 30.5]-7.8ext 5/8: If required, use RAD: Drive contingency bolt 3B (nadir CETA rail)) until bolt head seated</li> <li>DO NOT PRELOAD. Install and drive contingency bolt 4B (nadir) until bolt head seated</li> </ol>
Locking Cap Installation:  A. Position locking cap on bolt without engaging cap B. Rotate the cap ccw until the tab contacts structure C. Fully seat the cap onto the bolt If necessary to fully seat, rotate the locking cap cw up to 30 deg to align/engage the socket with the bolt head  IV 3. On EV GO, perform nominal MBA bolting	<ol> <li>Release PRD and temp stow</li> <li>PGT[B7 25.5 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Drive contingency bolt 18 to torque</li> <li>PGT[RCW MTL 30.5]-7.8 ext 5/8: Ratchet contingency bolt 18 to torque</li> <li>Install locking cap onto bolt head</li> <li>PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]-7.8 ext 5/8: Drive contingency bolt 2B to torque</li> <li>PGT[RCW MTL 30.5]-7.8 ext 5/8: Ratchet contingency bolt 2B to torque</li> <li>Install locking cap onto bolt head</li> <li>Give IV GO to perform nominal MBA bolting</li> </ol>	<ol> <li>Release PRD and temp stow</li> <li>PGT[B7 25.5 ft-lb, CW2 30RPM, MTL 30.5]-7.8         ext 5/8: If required, use RAD: Drive contingency bolt         3B to torque</li> <li>PGT[RCW MTL 30.5]-7.8 ext 5/8: Ratchet         contingency bolt 3B to torque</li> <li>Install locking cap onto bolt head</li> <li>PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]-7.8 ext         5/8: Drive contingency bolt 4B to torque</li> <li>PGT[RCW MTL 30.5]-7.8 ext 5/8: Ratchet         contingency bolt 4B to torque</li> <li>Install locking cap onto bolt head</li> <li>Give IV GO to perform nominal MBA bolting</li> </ol>
CONTINGENCY BOLT REMOVE  IV 1. When MBA bolting complete and as assembly time permits, perform CONTINGENCY BOLT REMOVE	CONTINGENCY BOLT REMOVE  1. Remove locking cap from 1B bolt head 2. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Drive contingency bolt 1B, remove and stow 3. Remove locking cap from 2B bolt head 4. Drive contingency bolt 2B, remove and stow	CONTINGENCY BOLT REMOVE  1. Remove locking cap from 3B bolt head 2. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Drive contingency bolt 3B, remove and stow 3. Remove locking cap from 4B bolt head 4. Drive contingency bolt 4B, remove and stow

FS 16-14 EVA/117/FIN

#### S1-S3 CAPTURE LATCH OVERRIDE - TASK DATA

#### Tools:

EV1	EV2
PGT	PGT
6 Ext 7/16	7.8 Ext 5/8
7.8 Ext 5/8	RAD
RAD	PRD
PRD	APFR (if required)
APFR (if required)	Contingency Bolts (2)
Contingency Bolts (2)	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Manual Capture Latch Override bolt	Capture Latch EVA Override	7/16	1	8.3	3.3	14.6	127	10
Contingency Bolt at Trunion Longeron	1A, 1B, 4A, 4B	5/8	4	47.9	NA	60.8	43	30
Contingency Bolt at Zenith MT rail	2A, 2B	5/8	2	47.9	NA	83.3	43	30
Contingency Bolt at Nadir MT rail	3A, 3B	5/8	2	55.8	NA	145.8	43	30

#### **FVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting
Aft-zenith position (MBA 1)	S1-31	(12,00,F,12)
Fwd-zenith position (MBA 2)	None	
Fwd-nadir position (MBA 3)	S3-05*	(11,00,F,12)*
Aft-nadir position (MBA 4)	S1-32	(12,00,F,12)

<sup>\*</sup>Only a viable option if all other three MBAs are already installed

Mass: NA

#### Notes:

- During the Capture Latch Override steps, the "B" bolts are used to avoid having to remove thermal covers. The "A" bolts are acceptable if the crewmember believes they have better access to them
- There is no APFR worksite for MBA corner 2 (zenith CETA rail corner)
- The APFR worksite for MBA corner 3 (nadir CETA rail corner) is only available if all other three MBAs are already installed

#### Cautions:


- IV and SSRMS operator must maintain good communication with EV crew for the duration of the capture latch override task. If SSRMS safing occurs during the task, IV must notify EV crew to stop driving the manual override or ratcheting the PRDs immediately to prevent SSRMS damage
- Do not exceed 200 lbf on EVA handrails while ratcheting with PRDs. When PRD actuating force increased sharply during bail throw, stop actuating
- Structural damage may occur if PRD tension is not released prior to preloading EVA contingency bolts

#### Warnings:


None

FS 16-15 EVA/117/FIN

### S1-S3 CAPTURE LATCH OVERRIDE – TASK DATA (Cont)



SSAS Contingency Bolt



SSAS Contingency Bolt Installed



P1 Capture Latch and Capture Latch Manual Drive




S1 Bay 15 – Internal view of CLA Mechanism

FS 16-16 EVA/117/FIN

### S1-S3 CAPTURE LATCH OVERRIDE – TASK DATA (Cont)

Hook PRD to S1 Handrail 3212 (outboard standoff)

Hook PRD to S3 Handrail 3013 (inboard standoff)




FS 16-17 EVA/117/FIN

# S1-S3 CAPTURE LATCH OVERRIDE – TASK DATA (Cont)

Hook PRD to S3 Handrail 3000

Hook PRD to S1 Handrail 3200 (standoff by 5820)



FS 16-18 EVA/117/FIN

# **S1-S3 MBA BOLT OVERRIDE**

IV/RMS	EV1	EV2
MBA locations which require MBA MOTOR FAILURE steps:	MBA MOTOR FAILURE	
IV 1. Verify with MCC that the MBA gear train is at or above minimum temperature	MBA 1 and 2 override bolts are driven cw. MBA 3 and 4 override bolts are driven ccw  CAUTION  To prevent excessive preload, EV and IV crewmember will need to coordinate driving MBA override bolt in order to stop PGT torque when bolt tight switch (BTS) indication received	
	For each failed MBA:  1. PGT[A6 8.3 ft-lb, CW3(CCW3) 60 RPM, MTL 30.5]-6 ext 7/16: Drive MBA override bolt approx 460 turns	
IV 2. Check for bolt tight switch "closed". If YES, bolting complete, stop PGT torque	<ol> <li>If NO bolt tight switch closing, continue with procedure</li> <li>Increase PGT torque incrementally starting with A7</li> <li>9.2 ft-lb up to B3 18.4 ft-lb, drive MBA override bolt to torque, have IV check for bolt tight switch "closed" after each torque setting</li> </ol>	MBA Override Bolt
	If NO bolt tight switch "closed" at 18.4 ft-lb, install x2     SSAS contingency bolts at this MBA location per     SSAS CONTINGENCY BOLT INSTALL	MBA 1 Zenith
MBA locations which require <u>DUAL BBC FAILURE</u> steps:	DUAL BBC FAILURE	MDA 2
Locking cap installation:	NOTE  MBA 1 and 2 override bolts are driven cw. MBA 3 and 4 override bolts are driven ccw	MBA 2 Aft Fwd
Position locking cap on bolt without engaging cap     Rotate the cap ccw until the tab contacts structure	For each failed MBA, perform the following steps (in order of MBA 3, 1, 2, 4):  1. Install one contingency bolt (either A or B location)	MBA 3
Fully seat the cap onto the bolt  If necessary to fully seat, rotate the locking cap cw up to 30 deg to align/engage the socket with the bolt head	<ol> <li>PGT[B7 25.5 ft-lb, CW2 30 RPM, MTL 30.5]-7.8 ext 5/8:         If required, use RAD: Drive contingency bolt to torque     </li> <li>PGT[RCW, MTL 30.5]-7.8 ext 5/8: Ratchet contingency bolt to torque</li> </ol>	MBA 4 Nadir
	4. Drive failed MBA override bolt approx 460 turns:  ☐ MBA 3 & 4: PGT[A7 9.2 ft-lb, CCW3 60 RPM, MTL 30.5]-6 ext 7/16  ☐ MBA 1 & 2: PGT[B1 12.0 ft-lb, CW3 60 RPM, MTL 30.5]-6 ext 7/16	

FS 16-19 EVA/117/FIN

# S1-S3 MBA BOLT OVERRIDE (Cont)

IV/RMS	EV1	EV2
Record final MBA torque and turns:         MBA 3 ft-lb turns         MBA 1 ft-lb turns         MBA 2 ft-lb turns         MBA 4 ft-lb turns	<ul> <li>5. PGT[RCCW, MTL 30.5]-7.8 ext 5/8: Ratchet contingency bolt to break torque</li> <li>6. PGT[B7 25.5 ft-lb, CCW2 30 RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Drive contingency bolt and remove bolt</li> </ul>	

FS 16-20 EVA/117/FIN

# S1-S3 MBA BOLT OVERRIDE - TASK DATA

#### Tools:

EV1	EV2
PGT	PGT
6 Ext 7/16	6 Ext 7/16
7.8 Ext 5/8	7.8 Ext 5/8
APFR (if required)	APFR (if required)

### **EVA Fasteners:**

Fastener Name	Label	Head	Qty	Install	Max Break	Failure	Turns	RPM
rastener Name	Labei	Size	Qiy	Torque (ft-lb)	Away Torque (ft-lb)	Torque (ft-lb)	Turns	RPIVI
S1 MBA 1 Override bolt	Motorized Bolt 1 EVA Override	7/16	1	12.0	<2	20.3 (Note 3)	460	60
S1 MBA 2 Override bolt	Motorized Bolt 2 EVA Override	7/16	1	12.0	<2	21.3 (Note 3)	460	60
S1 MBA 3 Override bolt	Motorized Bolt 3 EVA Override	7/16	1	9.2	<2	17.7 (Note 3)	460	60
S1 MBA 4 Override bolt	Motorized Bolt 4 EVA Override	7/16	1	9.2	<2	16.8 (Note 3)	460	60
Contingency Bolt at Trunnion Longeron	1A, 1B, 4A, 4B	5/8	4	47.9	NA	60.8	43	30
Contingency Bolt at Zenith MT Rail	2A, 2B	5/8	2	47.9	NA	83.3	43	30
Contingency Bolt at Nadir MT Rail	3A, 3B	5/8	2	55.8	NA	145.8	43	30

### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting
Aft-zenith position (MBA 1)	S1-31	(12,00,F,12)
Fwd-zenith position (MBA 2)	None	
Fwd-nadir position (MBA 3)	S3-05*	(11,00,F,12)*
Aft-nadir position (MBA 4)	S1-32	(12,00,F,12)

<sup>\*</sup>Only a viable option if all other three MBAs are already installed

Mass: NA

#### Notes:

- . For the S1 MBAs: MBA 1 and 2 override bolts are driven cw MBA 3 and 4 override bolts are driven ccw
- For a MBA motor failure, it is assumed that the bolt tight switches will provide an indication. If the max torque is reached without a bolt tight switch, the MBA can be declared failed. Consequently, the EVA crewmember will need to install two contingency bolts
- 3. For MBA motor failure, the failure torque for each MBA is 26.3 ft-lb (higher value because the sensor can measure torque better than the PGT can)
- 4. For the Dual BBC failure case, a contingency bolt is used to seat the cup/cone. The Dual BBC failure case is treated as a non-instrumented bolt and installation is defined by torque and use turns as a secondary indicator
- There is no APFR worksite for MBA corner 2 (zenith CETA rail corner)
- The APFR worksite for MBA corner 3 (nadir CETA rail corner) is only available if all other three MBAs are already installed

## Cautions:


 To prevent excessive preload, EV and IV crewmember will need to coordinate driving MBA override bolt in order to stop PGT torque when bolt tight switch (BTS) indication received (within 4 sec)

#### Warnings:


None


FS 16-21 EVA/117/FIN

# S1-S3 MBA BOLT OVERRIDE - TASK DATA (Cont)



# S1/S3 Trunnion Locations (Aft)





S1/S3 NADIR MT Rail Location (Fwd)

FS 16-22 EVA/117/FIN

# **S1-S3 SSAS CONTINGENCY BOLT INSTALL**

IV/RMS	EV
Locking cap installation:  1. Position locking cap on bolt without engaging cap 2. Rotate the cap ccw until the tab contacts structure 3. Fully seat the cap onto the bolt If necessary to fully seat, rotate the locking cap cw up to 30 deg to align/engage the socket with the bolt head  NOTE  To maintain required torque tolerances, the EVA torque wrench must be kept in its bag when not in use	SSAS CONTINGENCY BOLT INSTALLATION  ZENITH AND NADIR TRUNNION LONGERON LOCATIONS (MBA 1 AND 4)  1. PGT[B5 22.0 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Install contingency bolt A and drive bolt to torque  2. PGT[B7 25.5 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Install contingency bolt B and drive bolt to torque  3. Torque Wrench 34 ft-lb-7.8 ext 5/8: Drive contingency bolt A to torque  4. Torque Wrench 45 ft-lb-7.8 ext 5/8: Drive contingency bolt B to torque  5. Torque Wrench 45 ft-lb-7.8 ext 5/8: Drive contingency bolt B to torque  6. Install locking caps  ZENITH MT RAIL LOCATION (MBA 2)  1. PGT[B6 24.0 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Install contingency bolt 2A and drive bolt to torque  2. PGT[B7 25.5 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Install contingency bolt 2B and drive bolt to torque  4. Torque Wrench 48 ft-lb-7.8 ext 5/8: Drive contingency bolt 2B to torque  5. Install locking caps  NADIR MT RAIL LOCATION (MBA 3)  1. PGT[B7 25.5 ft-lb, CW2 30RPM, MTL 30.5]-7.8 ext 5/8: If required, use RAD: Install contingency bolt 3A and drive bolt to torque  2. Torque Wrench 48 ft-lb-7.8 ext 5/8: Drive contingency bolt 2A to torque  3. Torque Wrench 26 ft-lb-7.8 ext 5/8: Drive contingency bolt 3A to torque  4. Torque Wrench 26 ft-lb-7.8 ext 5/8: Drive contingency bolt 3B to torque  5. Torque Wrench 56 ft-lb-7.8 ext 5/8: Drive contingency bolt 3B to torque  6. Install locking caps

FS 16-23 EVA/117/FIN

# S1-S3 SSAS CONTINGENCY BOLT INSTALL - TASK DATA

## Tools:

EV1	EV2
PGT	NA
7.8 Ext 5/8	
RAD (if required)	
APFR (if required)	

## **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty		Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Contingency Bolt at Trunion Longeron	1A, 1B, 4A, 4B	5/8	4	47.9	NA	60.8	43	30
Contingency Bolt at Zenith MT rail	2A, 2B	5/8	2	47.9	NA	83.3	43	30
Contingency Bolt at Nadir MT rail	3A, 3B	5/8	2	55.8	NA	145.8	43	30

# **EVA Connectors:**

,		_	_		
Harness	From	То	Clamps (#)	Conn Size	Function
NA					

## **Foot Restraints:**

Task	WIF	APFR Setting
Aft-zenith position (MBA 1)	S1-31	(12,00,F,12)
Fwd-zenith position (MBA 2)	None	
Fwd-nadir position (MBA 3)	S3-05*	(11, OO,F,12)*
Aft-nadir position (MBA 4)	S1-32	(12,00,F,12)

<sup>\*</sup>Only a viable option if all other three MBAs are already installed

Mass: NA

# Notes:

- To maintain required torque tolerances, the EVA torque wrench must be kept in its bag when not in use
   There is no APFR worksite for MBA corner 2 (zenith CETA rail corner)
   The APFR worksite for MBA corner 3 (nadir CETA rail corner) is only available if all other three MBAs are already installed

# Cautions:

None

## Warnings:

None

FS 16-24 EVA/117/FIN

# MANUAL OVERRIDE TO UNLATCH/LATCH (TENSION) SABB

IV/RMS	EV
Identify Affected Power Channel XX =  IF UNLATCHING SABB  MCC-H	WARNING Sharp edge/pinch point/entrapment hazard – Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms Avoid contact with blanket box latches during manual override operation  CAUTION Maintain a constant push force (3-10 lb) on the MDA fastener anti-rotation collar during fastener rotation
IF TENSIONING SABB  MCC-H  1. Perform {3.193 SAW XX FAILURE TO LATCH (TENSION) SABB REMOTELY} SODF: EPS: MALFUNCTION: PRIMARY POWER)  THEN:  IV  2. If required (see Task Data notes) – Verify affected SABB positioned over the IEA and BGA latched PVM: EPS: BGA XX  BGA XX  'ECU XX'  Verify: Integ Cnt – Incrementing	<ol> <li>MANUAL OVERRIDE TO UNLATCH SABB</li> <li>On IV GO (see IV column, Unlatching SABB, step 2) – Enter worksite area</li> <li>If required – APFR, setup and ingress (see Task Data for WIF position, APFR settings, and BGA angle)</li> <li>Release PIP pin from back-up position lever</li> <li>Move override lever to MANUAL position</li> <li>Insert PIP pin into lock lever position</li> <li>PGT[A6 8.3 ft-lb, CCW2 30 RPM, MTL 30.5]-2 ext 7/16: Push to engage MDA drive fastener (3-10 lb), apply torque, 48 ± 1 turns until visual indication of latch position or hard stop</li> <li>Release PIP pin from override positioning lever</li> <li>Move override lever to AUTOMATIC position</li> <li>Insert PIP pin into lock lever position</li> <li>PGT[RCCW, MTL 30.5]-2 ext 7/16: Push to engage MDA drive fastener (3-10 lb), apply torque, ¼ turn to engage clutch pins</li> </ol>
'BGA XX'  Verify:  Actual Angle, deg = 270.000 (± 0.5) (Left SABB)  OR  Actual Angle, deg = 90.000 (± 0.5) (Right SABB)  Motor State — OFF  Latch 1 Pin Status – Latched  IV 3. GO for EV crew ingress at worksite  NOTE  Free Drift or CMG Control with Thrusters Disabled is required while SABB is being unlatched/latched. Applies only while mechanisms are in motion  MCC-H 4. Configure ISS/Orbiter attitude control to CMG Control with thrusters disabled  IV 5. When task complete, give MCC-H GO to resume nominal attitude control	<ol> <li>MANUAL OVERRIDE TO tensioning SABB</li> <li>On IV GO (see IV column, Tensioning SABB, step 3) – Enter worksite area</li> <li>If required – APFR, setup and ingress (see Task Data for WIF position, APFR settings, and BGA angle)</li> <li>Release PIP pin from back-up position lever</li> <li>Move override lever to MANUAL position</li> <li>Insert PIP pin into lock lever position</li> <li>PGT[A6 8.3 ft-lb, CW2 30 RPM, MTL 30.5]-2 ext 7/16: Push to engage MDA drive fastener (3-10 lb), apply torque, 48 ± 1 turns until visual indication of latch position or hard stop. The latches along the blanket box are visible and will move to the engaged position</li> <li>Release PIP pin from override positioning lever</li> <li>Move override lever to AUTOMATIC position</li> <li>Insert PIP pin into lock lever position</li> <li>PGT[RCW, MTL 30.5]-2 ext 7/16: Push to engage MDA drive fastener (3-10 lb), apply torque, ½ turn to engage clutch pins</li> </ol>

FS 16-25 EVA/117/FIN

# MANUAL OVERRIDE TO UNLATCH/LATCH (TENSION) SABB - TASK DATA

**Estimated Task Duration:** 

	With RMS	Without RMS
One EV Crew	NA	0:30
Two EV Crew	NA	NA

#### Tools:

EV1	EV2
PGT	NA
2 Ext 7/16	

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
SABB MDA Fastener	Yes	7/16	1 per	NA	7.5	12	48	30

## **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### **Foot Restraints:**

Task	WIF	APFR Setting	BGA Angle
IEA Non-keel side – Right SABB	P4/S4-26;	(12,FF,F,3)	90
	P6/S6-38		
IEA Non-keel side – Left SABB	P4/S4-26;	(12,FF,E,9)	270
	P6/S6-38		
IEA Keel side – Right SABB	P4/S4-25;	(12,FF,F,3)	90
_	P6/S6-37		
IEA Keel side – Left SABB	P4/S4-25;	(12,FF,E,9)	270
	P6/S6-37		

Mass: NA

## Notes:

- . It has been demonstrated in the NBL that the EVA crewmember can access the SABB Manual Override Fastener from a free floating position on the mast canister. If the EVA crew thinks they can actuate the SABB Manual Override Fastener from a free floating position on the mast canister, there is no need to position the BGA per IV step 2
- Free Drift or CMG Control with Thrusters Disabled is required while SABB is being unlatched/latched. Applies only while mechanisms are in motion

## Cautions:

- Equipment damage Maintain a constant push force (3-10 lb) on the MDA fastener anti-rotation collar during fastener rotation. Damage to the locking collar and/or the fastener could result if the collar is allowed to extend during fastener rotation
- Equipment damage Avoid contact with blanket box latches and mechanisms on underside of blanket box

## Warnings:

- Sharp edge/pinch point/entrapment hazard Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms
- Moving equipment. Avoid contact with blanket box latches during manual override operation



SABB MDA

FS 16-26 EVA/117/FIN

# MANUAL RELEASE OF SABB RESTRAINT PINS

IV	EV
<ol> <li>Position applicable BGA to angle per Task Data page</li> <li>Secure BGA</li> <li>Give EV crew GO to enter worksite</li> </ol>	WARNING Sharp edge/pinch point/entrapment hazard: Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms
	Collision hazard: BRS Pin will extend ~1 inch from bottom of box when fired. Keep EMU and tools out of this area
	CAUTION Actuation of BRS trigger with probe tool should not require excessive force. Application of excessive force may damage the BRS pin tool
	<ol> <li>Set up and ingress APFR (see Task Data page)</li> <li>Induce sharp rap(s) to side of BRS pin housing with the hammer to release</li> <li>If no joy, use the BRS pin release tool to actuate the trigger in the direction indicated by the arrow</li> </ol>

FS 16-27 EVA/117/FIN

# MANUAL RELEASE OF SABB RESTRAINT PINS - TASK DATA

**Estimated Task Duration:** 

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	NA

#### Tools:

EV1	EV2
APFR	N/A
Ingress aid	
BRS Pin Contingency Tool	
Hammer	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
N/A								

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

Foot Restraints, Right SABB setttings are in ():

IEA Side	Task	WIF	APFR Setting	BGA Angle
Non-Keel	Left (Right) SABB BRS Pin #1	S4-26, S6-38	12,FF,F,1 (6,FF,G,3)	284 (53)
	Left (Right) SABB BRS Pin #2	S4-26, S6-38	12,FF,F,9 (12,FF,G,3)	265 (78)
	Left (Right) SABB BRS Pin #3	S4-15, S6-27	10,FF,D,9 (9,FF,G,4)	281 (90)
	Left (Right) SABB BRS Pin #4	S4-15, S6-23	3,FF,F,8 (9,GG,G,3)	281 (90)
	Left (Right) SABB BRS Pin #5	S4-15, S6-27	3,FF,F,8 (3,GG,G,3)	281 (90)
	Left (Right) SABB BRS Pin #6	S4-11, S6-23	5,II,F,6 (7,FF,E,10)	281 (95)
	Left (Right) SABB BRS Pin #7	S4-11, S6-23	9,JJ,E,7 (7,KK,F,5)	281 (101)
Keel	Left (Right) SABB BRS Pin #1	S4-25, S6-37	12,FF,F,1 (6,FF,G,3)	284 (53)
	Left (Right) SABB BRS Pin #2	S4-25, S6-37	12,FF,F,9 (12,FF,G,3)	265 (78)
	Left (Right) SABB BRS Pin #3	S4-13, S6-25	10,FF,D,9 (9,FF,G,4)	281 (90)
	Left (Right) SABB BRS Pin #4	S4-13, S6-21	3,FF,F,8 (9,GG,G,3)	281 (90)
	Left (Right) SABB BRS Pin #5	S4-13, S6-27	3,FF,F,8 (3,GG,G,3)	281 (90)
	Left (Right) SABB BRS Pin #6	S4-09, S6-21	5,II,F,6 (7,FF,E,10)	281 (95)
	Left (Right) SABB BRS Pin #7	S4-09, S6-21	9,JJ,E,7 (7,KK,F,5)	281 (101)

#### Notes:

- 1. When the trigger is actuated, the slider will slide down and lock the trigger in the actuated position. If the slider has moved down, the BRS pin may be have not fired due to solar array panel side loads
- If trigger/slider is not in actuated position, trigger must be actuated manually with probe tool
- 3. Arrows (←) indicate direction of trigger actuation
- 4. All triggers are on the MDA side of BRS pin
- Pin 3 is a blind operation, and pins 4, 5 require bending metal for access
- Some APFR settings have a body position that is rather close to the lower blanket box; in these instances, the ingress aid may be used to control body positioning to avoid hitting the helmet against the SABB

## Cautions:


 Actuation of BRS trigger with probe tool should not require excessive force. Application of excessive force may damage the BRS pin tool


## Warnings:

- Sharp edge/pinch point/entrapment hazard: Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms
- Collision hazard: BRS Pin will extend ~1 inch from bottom of box when fired. Keep EMU and tools out of this area

FS 16-28 EVA/117/FIN

# MANUAL RELEASE OF SABB RESTRAINT PINS - TASK DATA (Cont)





POV is looking away from P6, toward end of mast canister

# MANUAL OVERRIDE TO EXTEND/RETRACT MAST

IV	EV
Identify Affected Power Channel XX =  MCC-H 1. Perform {3.191 SAW XX FAILURE TO EXTEND MAST REMOTELY} (SODF: EPS: MALFUNCTION: PRIMARY POWER)  OR	WARNING Sharp edge/pinch point/entrapment hazard – Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms Avoid contact with blanket box latches during manual override operation
Perform {3.192 SAW XX FAILURE TO RETRACT MAST REMOTELY} (SODF: EPS: MALFUNCTION: PRIMARY POWER)	MANUAL OVERRIDE TO EXTEND MAST  CAUTION  If excessive blanket panel "stiction" occurs during mast deployment, perform contingency incremental deployment
IV 2. Verify affected SABB positioned over the IEA and BGA latched PCS PVM: EPS: BGA XX  BGA XX  'ECU XX'  Verify: Integ Cnt – Incrementing  'BGA XX'  Verify: Actual Angle, deg = 180.000 (+/- 0.5) Motor State – OFF	<ol> <li>On IV GO (see IV column, step 3) – Enter worksite area</li> <li>Set up and ingress APFR (see Task Data page)</li> <li>Deploy MCHD PGT swing arm, install MCHD onto mast canister, zip nuts (4)</li> <li>PGT[A5 7.0 ft-lb, CW2 30RPM, MTL 30.5]-2 ext 7/16: Secure MCHD fasteners (4) to hardstop</li> <li>Ratchet -2 ext 7/16: Rotate Manual Override Actuator Shaft on left side of MDA 180 deg to disengage MDA, indicator – MANUAL</li> <li>Place PGT in MCHD PGT swing arm</li> </ol> CAUTION Crew must monitor the tension bar. Stop SAW deployment if the tension bar rises more than 1.5 inches from the sill. PGT[A4 6.3 ft-lb, CW3 60 RPM, MTL 30.5]-2 ext 7/16: drive MDA EVA override fastener until tension bar returns to 1.5 inches from the sill. When panels release and tension bar returns to the sill, deployment can continue
Latch 1 Pin Status – Latched  IV 3. GO FOR EV CREW INGRESS AT WORKSITE  NOTE  Free Drift or CMG Control with Thrusters Disabled is required while solar array is being deployed/retracted. Applies only while mechanisms are in motion	NOTE Insolation is not required for this task, unless needed for visual abort cues. As expected, the tension bar will rise 18 to 20 inches from the sill as the last half mast bay is deployed.  Extension complete when: Visual observation of the last mast bay visual indicators (black/white, cross hatched). Hard stop, sharp rise in tool torque
MCC-H 4. Configure ISS/Orbiter attitude control to CMG Control with thrusters disabled  MCC-H 5. On EV GO (see EV column, Extend Mast, step 7), place solar array blanket boxes in high tension, when complete, give EV GO to continue SAW deployment	<ol> <li>PGT[A7 9.2 ft-lb, CCW3 60 RPM, MTL 30.5]-2 ext 7/16: Drive MDA EVA override fastener until 1 mast bay is deployed (~ 78 turns), give MCC-H GO to place solar array blanket boxes in high tension</li> <li>On MCC-H GO (see IV column, step 5), PGT[A7 9.2 ft-lb, CCW3 60RPM, MTL 30.5]-2 ext 7/16: Drive MDA EVA override fastener 2382 turns (x1 PGT battery will actuate approx 1300 turns), PGT battery changeout expected</li> </ol>

FS 16-30 EVA/117/FIN

# MANUAL OVERRIDE TO EXTEND/RETRACT MAST (Cont)

IV	EV
MCC-H 6. On EV GO – resume nominal attitude control	<ol> <li>While holding the PGT – 2 ext 7/16 on the backup drive fastener, Ratchet – 2 ext 7/16 – rotate Manual Override Actuator Shaft 180 to disengage MDA, indicator – AUTOMATIC</li> <li>Give MCC-H GO to resume nominal attitude control</li> <li>Egress worksite, leave MCHD on mast canister</li> </ol>
	<ol> <li>MANUAL OVERRIDE TO RETRACT MAST</li> <li>On IV GO (see IV column, step 3) – Enter worksite area</li> <li>Set up and ingress APFR (see Task Data page)</li> <li>Deploy MCHD PGT swing arm, install MCHD onto mast canister, zip nuts (4)</li> <li>PGT[A5 7.0 ft-lb, CW2 30RPM, MTL 30.5]-2 ext 7/16: Secure MCHD fasteners (4) to hardstop</li> <li>Ratchet -2 ext 7/16: Rotate Manual Override Actuator Shaft on left side of MDA 180 deg to disengage MDA, indicator – MANUAL</li> <li>Place PGT in MCHD PGT swing arm</li> <li>PGT[A7 9.2 ft-lb, CW3 60 RPM, MTL 30.5]-2 ext 7/16: Drive MDA EVA override fastener 2460 turns (x1 PGT battery will actuate approx 1300 turns), PGT battery changeout expected</li> <li>While holding the PGT -2 ext 7/16 on the backup drive fastener, Ratchet -2 ext 7/16 – rotate Manual Override Actuator Shaft 180 to disengage MDA, indicator – AUTOMATIC</li> <li>Give MCC-H GO to resume nominal attitude control</li> <li>Egress worksite, leave MCHD on mast canister</li> </ol>

FS 16-31 EVA/117/FIN

# MANUAL OVERRIDE TO EXTEND/RETRACT MAST - TASK DATA

**Estimated Task Duration:** 

	With RMS	Without RMS	
One EV Crew	NA	2:00	
Two EV Crew	NA	NA	

#### Tools:

EV1	EV2
PGT with 2 Ext 7/16	NA
Ratchet wrench with 2 Ext 7/16	
MCHD	
APFR	

#### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
MCHD Fasteners	NA	7/16	4	7.0	8.1	11.0 (I) 12.2 (R)	Zip	10
Mast Canister Manual Override Actuator Shaft	Yes	7/16	2 per	NA	2.5	10	0.5	10
Mast Canister MDA Fastener	Yes	7/16	1 per	NA	9.0	19.3	2461	60

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

## **Foot Restraints:**

Task	WIF	APFR Setting
IEA Keel Side	P6/S6-37,	(12,FF,F,12)
	P4/S4-25	
IEA Non-keel side	P6/S6-38,	(12,FF,F,12)
	P4/S4-26	

Mass: NA

## Notes:

- Insolation is not requried for this task, unless needed for visual abort cues.
   As expected, the tension bar will rise 18 to 20 inches from the sill as the last half mast bay is deployed
- Extension complete when: Visual observation of the last mast bay visual indicators (black/white, cross hatched). Hard stop, sharp rise in tool torque
- The mast canister needs to be positioned such that the MDA faces the direction of the IEA. This will allow an EV crewmember to set up an APFR to access the MDA
- In order to release MCHD fasteners from zipnuts, inward force on each bolt must be minimized

### Cautions:

- Crew must monitor the tension bar. Stop SAW deployment if the tension bar rises more than 1.5 inches from the sill. Drive MDA EVA override fastener until tension bar returns to 1.5 inches from the sill. When panels release and tension bar returns to the sill, deployment can continue
- Equipment damage Avoid contact with blanket box latches and mechanisms on underside of blanket box
- If monitoring IVA notes excessive blanket panel "stiction", during mast deployment, abort deployment. Coordinate with IVA to perform contingency incremental deploy. Not applicable for retraction

#### Warnings:

- Sharp edge/pinch point/entrapment hazard Avoid contact with outboard underside of SABB due to exposed reels, guide-wire and tension mechanisms
- Moving equipment. Avoid contact with blanket box latches during manual override operation



Mast Canister MDA

FS 16-32 EVA/117/FIN

# **SABB SPOOL RE-TENSION**

IV/RMS	EV1	EV2		
Identify Affected Power Channel XX =  Which SABB needs re-tensioning  Which Tension Reel needs re-tensioning  IV	WARNING  Moving equipment hazard. Stay clear of SABB and capture latch mechanisms  Moving equipment hazard. Avoid contact with mast canister/beta gimbal during rotation of SAW  Sharp edges: Pulley shroud at machined edges Guide wire mechanism cover at machined edges Guide wire mechanism Guide wire pulley	Moving equipment hazard. Stay clear of SABB and capture latch mechanisms  Moving equipment hazard. Avoid contact with mast canister/beta gimbal during rotation of SAW  Sharp edges: Pulley shroud at machined edges Guide wire mechanism cover at machined edges Guide wire mechanism Guide wire pulley		
Wait approx 20 sec (~ 1 bay) cmd Mast – Abort  √MDA Voltage, V < 10 (± 2.8)  2. Unlatch affected SABB. If required: Perform {1.3.450 SAW XX SABB INITIAL UNLATCH} (SODF: EPS: ACTIVATION AND CHECKOUT: CHANNEL ACTIVATION), step 2 for LBB or step 3 for RBB (NOTE: BRS Pin visual checks can be ignored)  MCC-H  3. Position and safe SAW for Tension Reel Task. Perform {2.101 PVM BGA XX ENGAGE ANTIROTATION LATCH} (SODF: EPS: NOMINAL: PRIMARY POWER), using the following values:	Guide wire Top flange of blanket box Protrusions (4) on tension reel housing  TENSION REEL TASK SETUP  1. Translate to S3	Guide wire Top flange of blanket box Protrusions (4) on tension reel housing  TENSION REEL TASK SETUP  1. Translate to S3		
If Right SABB (Inboard Reel) BGA XX Cmded Angle = 80.000 deg BGA XX Latch Select = 1 If Right SABB (Outboard Reel) BGA XX Cmded Angle = 93.000 deg BGA XX Latch Select = If Left SABB (Inboard Reel) BGA XX Cmded Angle = 285.000 deg BGA XX Latch Select = 2 If Left SABB (Outboard Reel) BGA XX Cmded Angle = 283.000 deg BGA XX Cmded Angle = 283.000 deg BGA XX Latch Select = 1	Set up APFR (see Task Data page)     Ingress APFR	Set up APFR (see Task Data page)     Ingress APFR using EV 1 ingress aid or EV 1 for assistance		

FS 16-33 EVA/117/FIN

# SABB SPOOL RE-TENSION (Cont)

IV/RMS	EV1	EV2
IV 4. SSRMS: SSRMS RECONFIGURATION FOR EVA SUPPORT (SODF: ROBO PROCEDURE REFERENCE)  5. SRMS: SRMS RECONFIGURATION FOR EVA SUPPORT (FDF: PDRS PROCEDURE REFERENCE)  NOTE Free Drift or CMG Control with Thrusters Disabled is required while the EV crewmembers are handling the cable  MCC-H 6. Configure ISS/Orbiter attitude control to CMG control with thrusters disabled  IV 7. When task complete, give MCC-H GO to resume nominal attitude control	INSTALL CABLE ON OUTBOARD REEL  1. Assist EV2 with cable as required  NOTE  The reel will rotate a fraction of a turn without resistance. Some uneven tension and binding may be initially detected as internal mechanism seats. The 2.5 turn count begins when this minimal rotational resistance (approx 2-6 lb) is encountered. The tension reel housing will self tend back to initial position. Hand guidance is required to control rate  2. Rotate tension reel ccw by hand approx 2.5-2.75 turns to hard stop  NOTE  EV1 acts as the "clutch" on reel in case EV2 lets go. Tension reel housing will self tend back to initial position. Hand guidance is required to control rate of motion  3. Maintain reel and help tend cable during EV2 alignment lnspect final cable routing on tension reel groves, through pulley, and clear of blanket box fasteners  5. Take closeout photos  6. Egress APFR	INSTALL CABLE ON OUTBOARD REEL  Pull cable on bottom side of blanket box running between pulley and tension reel. There will be approx 2 ft of cable slack. The tension bar will be pulled into position against blanket box  1. Using the loop pin puller, pull slack on tension cable by pulling cable through pulley using light force (expect 5-10 lb pull force. If force is high, contact MCC)  2. Align cable through pulley  3. Maintain cable tension during reel rotation using loop pin puller  4. Feed cable onto reel using loop pin puller as reel rotates back cw under it's own spring power  5. Remove loop pin puller  6. Egress APFR
	1. Set up APFR (see Task Data page) 2. Ingress APFR 3. Repeat INSTALL CABLE ON OUTBOARD REEL for the SABB inboard reel 4. Give IV GO for solar array deploy	Set up APFR (see Task Data page)     Ingress APFR using EV1 ingress aid or EV1 for assistance     Repeat INSTALL CABLE ON OUTBOARD REEL for the SABB inboard reel

FS 16-34 EVA/117/FIN

# SABB SPOOL RE-TENSION (Cont)

IV/RMS	EV1	EV2
MCC-H 8. Return SAW/BGA to Deploy Position. If required: Perform {2.101 PVM BGA XX ENGAGE ANTIROTATION LATCH} (SODF: EPS: NOMINAL: PRIMARY POWER)  IV 9. Return to Nominal SAW Deploy Camera configuration (Truss Cameras, PLB Cameras, etc) 10. SSRMS: SSRMS RECONFIGURATION FOR SAW VIEWING (SODF: ROBO PROCEDURE REFERENCE) 11. SRMS: SRMS RECONFIGURATION FOR SAW VIEWING (FDF: PDRS PROCEDURE REFERENCE)  MCC-H 12. Re-Latch (Tension) Affected SABB If required: Perform {1.3.452 SAW XX DEPLOY} (SODF: EPS: ACTIVATION AND CHECKOUT: CHANNEL ACTIVATION) step 13 for LBB, or step 14 for RBB	IF REQUIRED:  TENSION REEL JAM CONTINGENCY  1. If no rotational resistance or no hard stop (free spinning), call MCC  2. If excessive force (> 6 lb) or mechanism jam is encountered, go to INSTALL CABLE ON INBOARD REEL  3. EV guide tension reel back into initial position  4. IV Cycle SABB Latches. Perform {4.118 SAW XX RETRACT} (SODF: EPS: CORRECTIVE: PRIMARY POWER) steps 12 (13) for Unlatch OR steps 18 (19) for Latch  5. EV attempt outboard tension reel rotation  6. If smooth reel rotation, go to INSTALL CABLE ON OUTBOARD REEL, EV2, step 1  7. If jam or resistance encountered, repeat steps 4 and 5  8. If no joy, call MCC	

FS 16-35 EVA/117/FIN

# SABB SPOOL RE-TENSION - TASK DATA

## **Estimated Task Duration:**

	With RMS	Without RMS		
One EV Crew	NA	NA		
Two EV Crew	NA	1:00		

#### Tools:

EV1	EV2
APFR	APFR
Ingress aid	Loop pin puller

### **EVA Fasteners:**

	Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
ſ	N/A								

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

## **Foot Restraints:**

Task	WIF	APFR Setting	BGA Angle
IEA Non-keel side – SABB Outboard Reel EV1 access	P4/S4-11, P6/S6-23	(12, HH, F, 6)	283, 93
IEA Non-keel side – SABB Outboard Reel EV2 access	P4/S4-15, P6/S6-27	(10, HH, G, 1)	283, 93
IEA Non-keel side – SABB Inboard Reel EV1 access	P4/S4-26, P6/S6-38	(1, FF, F, 2)	285, 80
IEA Non-keel side – SABB Inboard Reel EV2 access	P4/S4-19, P6/S6-31	(5, GG, F, 7)	285, 80
IEA Keel side – SABB Outboard Reel EV1 access	P4/S4-09, P6/S6-21	(12, HH, F, 6)	283, 93
IEA Keel side – SABB Outboard Reel EV2 access	P4/S4-13, P6/S6-25	(10, HH, G, 1)	283, 93
IEA Keel side – SABB Inboard Reel EV1 access	P4/S4-25, P6/S6-37	(1, FF, F, 2)	285, 80
IEA Keel side – SABB Inboard Reel EV2 access	P4/S4-17, P6/S6-29	(5, GG, F, 7)	285, 80

## Notes:

- 1. SABB Outboard Reel does not have a pulley shroud
- 2. Combination wrenches may be used if the tension reel fails to take up the tension cable slack

# Cautions:

- 1. Equipment damage Beware of close proximity to blanket box during ingress. Visually inspect cables prior to handling for fraying or jamming on structure or nearby cables
- 2. Do not allow uncontrolled CW rotation of tension reel
- 3. Do not manually wrap cable on reel housing

# Warnings:

1. Sharp edges:

Pulley shroud at machined edges

Guide wire mechanism cover at machined edges

Guide wire mechanism

Guide wire pulley


Guide wire

Top flange of blanket box

- Protrusions (4) on tension reel housing
  2. Moving equipment hazard. Stay clear of SABB and capture latch mechanisms
- 3. Moving equipment hazard. Avoid contact with mast canister/beta gimbal during rotation of SAW


FS 16-36 EVA/117/FIN

# SABB SPOOL RE-TENSION – TASK DATA (Cont)




FS 16-37 EVA/117/FIN

# SABB SPOOL RE-TENSION – TASK DATA (Cont)



SABB Tensioning Reel Outboard



SABB Tensioning Reel Inboard

FS 16-38 EVA/117/FIN

# **EVA ASSISTED DEPLOYMENT OF S4 SAW**

IV/RMS	EV		
1. Retract SAW mast to one bay  MCC-H 2. Position and safe SAW from rotation during EVA, Perform {2.101 PVM BGA XX ENGAGE ANTIROTATION LATCH} (SODF: EPS: NOMINAL: PRIMARY POWER), using the following values: BGA XX Cmded Angle = 0 deg BGA XX Latch Select = 1  IV 3. Verify affected SABB positioned over the IEA and	WARNING  Beta gimbal assembly must be LOCKED prior to the EVA crewmember entering the worksite and during the task  Due to potential electrical arcing hazard, the EVA crew must execute this task ONLY when the SSU is shunted, the mast is retracted to one bay, EVA crewmember helmet light is on spot only, and only during orbital eclipse  Due to potential electrical arcing hazard, avoid touching damage areas of FCC in order to avoid being exposed to SAW voltage  Sharp edge/pinch point/entrapment hazard – avoid contact with the mast, panels (other than the FCC strips), and blanket boxes		
PCS PVM: EPS: BGA XX  BGA XX  'ECU XX'  Verify:     Integ Cnt – Incrementing  'BGA XX'  Verify:     Actual Angle, deg = 0.000 (+/- 0.5)     Motor State – OFF     Latch 1 Pin Status – Latched  MCC-H 4. Give GO for EV crew to setup at worksite  5. Shunt SSU, inform EVA crew when complete	<ol> <li>On MCC GO – Enter worksite area</li> <li>Set up WIF Extender and APFR (see Task Data page)</li> <li>Upon eclipse, set helmet light to spot light, verify</li> <li>Ingress APFR</li> <li>Identify sticky panels</li> <li>Grasp FCC strip perpendicular to FCC fold and at least 1 inch from fold in FCC</li> <li>Peel sticky panels away from each other in the direction of the hinge opening, to the first panel stiffener</li> <li>Repeat steps 5 thru 7 until complete</li> <li>Egress worksite, notify MCC when clear of the mast canister</li> <li>Repeat steps 1 thru 9 for other SAW if required</li> </ol>		

FS 16-39 EVA/117/FIN

# EVA ASSISTED DEPLOYMENT OF S4 SAW – TASK DATA

**Estimated Task Duration:** 

	With RMS	Without RMS
One EV Crew	NA	2:30 (both SABBs)
Two EV Crew	NA	NA

#### Tools:

EV1	EV2 (If required)
EV1	EV2 (If required)
APFR	
WIF Extender	
APFR Ingress Aid (if required)	

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
NA								

#### **EVA Connectors**:

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

#### Foot Restraints:

Task	WIF	WIF Extender	APFR Setting
IEA Keel Side Right SABB	P6/S6-37,	12, G, 7	12, PP, F, 5
	P4/S4-25		
IEA Keel Side Left SABB	P6/S6-37,	2, G, 7	12, NN, F, 6
	P4/S4-25		
IEA Non-keel side Right SABB	P6/S6-38,	12, G, 7	12, PP, F, 5
	P4/S4-26		
IEA Non-keel side Left SABB	P6/S6-38,	2, G, 7	12, NN, F, 6
	P4/S4-26		

Mass: NA

#### Notes:

- The mast canister needs to be positioned in the launch position (beta gimbal angle = 0) in order for the EVA crewmember to access both SABBs if required. Other beta gimbal angles may allow the EVA crewmember to access a single SABB
- EVA crewmember does not need to separate the entire solar array panel. The intent is separate enough of the panel adhesion such that the tension of deployment will separate any additional adhesion

### Cautions:

- The solar array panels and blanket box should not be grasped due to load constraints. In particular, avoid contact with blanket box latches and mechanisms on underside of blanket box
- Avoid using the outboard SABB FCC to separate the panels. Inadvertent loads into the outboard portion of the blanket box could compromise the functionality of the SAW
- The FCC fold edge is the most likely area to be damaged. Crew should not handle the FCC within 1 inch of the fold in the FCC to prevent pinching the circuitry. Normal handling of FCC should not result in damage to FCC
- 4. Stop exerting loads into the foot restraint if the load alleviator trips. The EVA crewmember should be pay additional attention to loads exterted while in the APFR/WIF Extender. It will be easier to trip the load alleviator due to the crewmembers distance from structure

## Warnings:

- Beta gimbal assembly must be LOCKED prior to the EVA crewmember enter the worksite and during the EVA task
- Due to potential electrical arcing hazard, the EVA crew must execute this task ONLY when the SSU is shunted, the mast is retracted to one bay, during orbital elipse, and with only the EMU spot light on
- 3. Due to potential electrical arcing hazard, avoid touching damage areas of FCC in order to avoid being exposed to SAW voltage
- Sharp edge/pinch point/puncture/entrapment hazard Avoid contact with the mast, panels (other than the FCC strips), and blanket boxes. The following are specific sharp edges or puncture hazards:

SABB panel hinge pins

SABB skirts

SABB swing bolts

Potential panel broken cells

Electrical connector fastener exposed threads

Tension bar springs

Guide wire cables

Mast canister stiffner ring fasteners exposed threads

Mast canister roller guides

Mast canister braided cables

FS 16-40 EVA/117/FIN

# EVA ASSISTED DEPLOYMENT OF S4 SAW – TASK DATA (Cont)



IEA Non Keel side – EVA crew access to right SABB



IEA Non Keel side – EVA crew access to left SABB



Grasping the SAW panel FCC



Separating the SAW panel FCC

FS 16-41 EVA/117/FIN

# **SSRMS JOINT DRIVE**

# **CAUTION**


## Avoid contact with:

- 1. ACU radiator surface: silver Teflon film (white in color).
- 2. CLA and CLPA radiator surface: silver Teflon film (white in color).
- VDU radiator surface: silver Teflon film (white in color).
- 4. JEU radiator surface: Z93 paint.

# NOTE

- 1. Gear ratio: 3.26 EVA Drive turns/1 degree of joint movement.
- 2. CW input to the EVA drive will produce CCW motion of the joint.
- 3. Staring from LEE, the order of the joints: roll, yaw, pitch.
- 4. The signs of the logical (indicated on RWS or PCS) and physical (indicated on EVA scale) angles are reversed for the shoulder roll, shoulder yaw, and wrist roll joint (i.e., +73.2 logical = -73.2 physical) regardless of which end is base.
- 5. Scale and Ambiguity Switch
  - □ Since the SSRMS joints can be rotated more than 360 degrees, there is an ambiguity switch that tells the crewmember whether to use the positive or negative scale.
  - ☐ The crew reads the scale using the black triangle on the fixed side of the joint. Located to the side of the black triangle (~90 degrees around the circumference of the joint) is the ambiguity switch. The switch has a pointer that indicates "+" or "-" to tell the crew which side of the scale to read. If the ambiguity switch points to "+" then the crew should read off the yellow scale (black text on yellow background). If the switch points to "-" then the crew should read off the black scale (yellow text on black background).
  - □ EVA Drive handle is on back side of joint (away from LEE), and scale triangle is across from it towards the LEE side.

FS 16-42 EVA/117/FIN



Red Background, Joint Hard Stop Warning Zone (-270 to -280)

Black Text on Yellow Background (0 to 270)

Black Text on Yellow Background, Maintenance Position, Not Applicable

JOINT SCALE

FS 16-43 EVA/117/FIN

# Task Data:

Table 1. Tools

EV1 (FF)
PGT
7/16 (wobble) Socket-6 ext
BRT
Square Scoop

Table 2. EVA Fasteners

F	Fastener Name	Label	Head Size	Qty	Min Drive Torque (ft-lb)	Max Drive Torque (ft-lb)	Failure Torque (ft-lb)	RPM
EVA Dr	rive		7/16	1	1.25	2.5		30

Foot Restraints: N/A

FS 16-44 EVA/117/FIN




Figure 1.- Roll/Pitch Joint ORU.

FS 16-45 EVA/117/FIN




Figure 2.- YAW Joint ORU

FS 16-46 EVA/117/FIN

# **MANUAL SAW JETTISON**

## PRIOR TO EVA:

- 1. Unstow SSU cover and place in crewlock
- 2. If ECU removal is planned, stow Medium ORU bag in crewlock
- If ECU removal is planned, stow Medium ORU bag in crewlock
   Remove SSU shunt plug adapter J5A and J6A caps and tether to tether point on SSU shunt plug adapter
   Remove SSU shunt plug caps and mate SSU shunt plugs to SSU shunt plug adapter J5A and J6A (shunt plugs can go on either adapter receptacle)
   Remove caps from SSU shunt plug adapter ground service equipment connectors
   Stow SSU shunt plug adapter/shunt plugs, Cannon connector tool in EVA crewlock bag
   If available, stow size 37 Cannon connector plug cap in EVA crewlock bag; if not available, will need to retrieve one from Z1

IV/RMS	EV1	EV2
Identify Affected Power Channel XX = and opposite deck	WARNING  Voltage hazard exists at the connectors of the SSU. SSU must be safed before removal  Electrical Shock Hazard. SSU Shunt Plug installation/removal and SSU removal/installation must occur during eclipse. STEPS DENOTED BY AN "E" MUST OCCUR DURING ECLIPSE. Crew must wait the specified wait periods for voltage drops to safe levels before proceeding. EV crew will need to move away from exposed electrical receptacles during day pass Protrusion Hazard. SSU alignment post protrudes beyond mast canister. Maintain clearances between structure and crewmember during SSU removal  Collision Hazard. The solar array motion should be prevented by locking the BGA. This avoids a collision hazard with the EV crew if the EV crew is within 24 inches of the array rotational envelope	WARNING  Voltage hazard exists at the connectors of the SSU. SSU must be safed before removal  Electrical Shock Hazard. SSU Shunt Plug installation/removal and SSU removal/installation must occur during eclipse. STEPS DENOTED BY AN "E" MUST OCCUR DURING ECLIPSE. Crew must wait the specified wait periods for voltage drops to safe levels before proceeding. EV crew will need to move away from exposed electrical receptacles during day pass  Protrusion Hazard. SSU alignment post protrudes beyond mast canister. Maintain clearances between structure and crewmember during SSU removal  Collision Hazard. The solar array motion should be prevented by locking the BGA. This avoids a collision hazard with the EV crew if the EV crew is within 24 inches of the array rotational envelope
4. GO for EV ingress at SSU worksite  MCC-H  5. Verify power connector inhibits in place before SSU Removal PVM: EPS: DCSU XX  DCSU XX  'DCSU XX' sel RBI 1 Verify: Cmded Position – Op	EVA SETUP  1. If required, retrieve Sq TM with 7/16 Rec socket and square scoop from Z1 toolbox  2. If required, translate to Z1 forward face, demate Cannon connector cap from Z1 J259 or J260, stow in EVA crewlock bag  3. On MCC GO, translate to SSU worksite  4. Transfer tools and APFR with AIA to worksite  5. Set up APFR (see Task Data page)	EVA SETUP  1. Translate to Mast Canister/Aux bag (PMA1 stbd by Node bag)  2. Retrieve MCHD  3. On MCC GO, translate to worksite  4. Temp stow MCHD and SSU cover  5. Translate to BMRRM  6. Remove BMRRM thermal shroud (peels back)

FS 16-47 EVA/117/FIN

# MANUAL SAW JETTISON (Cont)

IV/RMS	EV1	EV2
Close Cmd – Inh Voltage: -4.2 – 4.2 Current: -7.5 – 7.5  PCS  PVM: EPS: SSU XX  SSU XX  'BCDU YY1' (YY= opposite channel on IEA) sel CP RBI  BCDU XX CP RBIs  'YY1 CP RBI' (YY= opposite channel on IEA) Verify: YY1 CP RBI Posn – Op  MCC-H  6. Turn off and off point video camera luminaries, rpcm open and closed inhibited  MCC-H  7. Give GO for BMRRM J1 demate and SSU shunt plug installation	SSU shunt plugs and adapter installed on mast canister with shroud open  E6. On MCC GO (2 min wait after transition from insolation to eclipse), remove mast canister ground test port caps (2) and place in EVA trash bag	<ul> <li>E7. On MCC GO, demate connector from BMRRM J1</li> <li>E8. Mate Cannon connector cap on BMRRM J1</li> <li>9. If reqd, reinstall BMRRM thermal shroud</li> </ul>
MCC-H 8. Give GO for SSU removal during 2nd ECLIPSE ONLY	E7. Position MLI shroud as shown above or folded against shunt plugs  E8. Install SSU shunt plug adapter with bails facing outward, not against mast canister  9. Reinstall MLI shroud  10. Ingress APFR  REMOVE FAILED SSU  1. Install Sq TM onto primary fastener, √anti-backlash neutral  E2. On MCC GO (5 min wait after transition from insolation to eclipse), PGT [A7 9.2 ft-lb, CCW2 30RPM, MTL 30.5]- Sq TM-7/16Rec: Drive PGT 5 turns  E3. Remove Sq TM  E4. Install Sq Scoop on SSU  E5. PGT [A7 9.2 ft-lb, CCW2 30RPM, MTL 30.5]-12-ext-7/16: Drive fastener 10 turns	REMOVE FAILED SSU

FS 16-48 EVA/117/FIN

# MANUAL SAW JETTISON (Cont)

IV/RMS	EV1	EV2
9. Position and safe SAW for ECU Removal (if required) and SAW jettison. Perform {2.101 PVM BGA XX ENGAGE ANTI-ROTATION LATCH} (SODF: EPS: NOMINAL: PRIMARY POWER) using the following values:  BGA XX Cmded Angle = 180 deg BGA XX Latch Select = 1  10. GO for EV ingress at ECU worksite  MCC-H 11. Remove ECU power PCS PVM: EPS:BGA XX BGA XX  sel RPCM YY A RPC 02 RPCM YY A RPC 02 cmd RPC Position – Open (Verify – Op) (Expect Caution Message: BGA XX Loss of Comm)	E6. √Status indicator – UNLOCK E7. Remove SSU and hand to EV2 8. Clear BGA rotation plane for BGA rotation and inform IV when clear  WARNING Moving equipment hazard: Avoid contact with	Receive SSU and stow on SSU cover     Clear BGA rotation plane for BGA rotation and inform IV when clear
MCC-H 12. GO for ECU removal and BMRRM cable demate	REMOVE ECU [if required]  1. Set up and ingress APFR [see Task Data page]  2. On MCC GO, PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-Sq TM w/7/16 REC: Release fastener 1 turn  3. Remove Sq TM  4. Install Square Scoop on ECU  5. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6 ext 7/16: Release fastener 10 ± 2 turns  6. √Status indicator – UNLOCK  7. Remove ECU and stow in ORU transfer bag	RELEASE BMRRM FASTENERS/CONNECTORS  1. If not done already, remove BMRRM thermal shroud and temp stow  2. PGT[B6 24.0 ft-lb, CCW2 30RPM, MTL 10.5]-6 ext 7/16: Release BMRRM center fastener 17 turns  3. On MCC GO, disconnect the following connectors from the BMRRM:  □ Demate connector from J3  □ Demate connector from J2

FS 16-49 EVA/117/FIN

# MANUAL SAW JETTISON (Cont)

IV/RMS	EV1	EV2
MCC-H 13. Give GO for MCHD installation	INSTALL MCHD  1. On MCC GO, set up and ingress APFR (see Task Data page)  2. Deploy MCHD appendages  3. Install MCHD on mast canister  4. PGT[A5 7.0 ft-lb, CW2 30RPM, MTL 30.5]-6 ext 7/16: Fasten MCHD corner attach fasteners (4) to hardstop	
MCC-H 14. Give GO for jettison	Using MCHD, move mast canister from beta gimbal at a velocity less than 1 ft/min. Move mast canister 2 ft from beta gimbal separation plane. Correct wing attitude as reqd to achieve stability     Release MCHD	MANUAL SAW JETTISON  1. On MCC GO, PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 10.5]- 6 ext 7/16: Release platform vice clamp fastener, 19 turns to hardstop  2. When complete, give EV1 GO for SAW motion  3. Call out separation distance until 2 ft separation achieved
	Monitor SAW separation     When SAW is clear, egress worksite	Monitor SAW separation

FS 16-50 EVA/117/FIN

# **MANUAL SAW JETTISON – TASK DATA**

## **Estimated Task Duration:**

	Without RMS
One EV Crew	NA
Two EV Crew	3:00

## Tools:

EV1	EV2
PGT	PGT
6 ext-7/16	6 ext-7/16
APFR/ingress aid	
Square TM with 7/16-in Recessed socket	
EVA crewlock bag	SSU cover
SSU shunt plug adapter	Mast Canister Handling Device
SSU shunt plugs (2)	
Size 33 Cannon conn plug cap	
Square scoop (2)	
Medium ORU bag (if reqd - for ECU)	

## **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
SSU fastener	NA	7/16	1	6.3	35.7	264 (R)	11 ± 2	30
ECU fastener	NA	7/16	1	6.3	30.5	290.3 (R)	11 ± 2	30
BMRRM Center Fastener	NA	7/16	1	NA	16.0	54.0	17	30
MCHD Fasteners	NA	7/16	4	7.0	8.1	11.0 (I)	ZIP	10
Vice Clamp	NA	7/16	1	NA	5.2	20.1	19	30

#### **EVA Connectors:**

ETA COMINCOLOIS.					
Harness	From	То	Clamps (#)	Conn Size	Function
W05 P23 J3		BMRRM J3		25	ECU feed; SSU Control pwr; 1553B
W06 P22 J2		BMRRM J2		25	ECU cross feed
•		BMRRM J1		37	Primary power

## Foot Restraints:

Task	WIF	APFR Setting	BGA Angle
Access to SSU (IEA non-keel side 4A/3A SAW)	P4/S4-23	4, PP, G, 9	270
Access to SSU (IEA keel side 2A/1A SAW)	P4/S4-24	4, PP, G, 9	270
Access to BMRRM (IEA non-keel side 4A/ 3ASAW)	P4/S4-28	9, NN, G, 3	Any
Access to BMRRM (IEA keel side 2A/1A SAW)	P4/S4-27	9, NN, G, 3	Any
Install MCHD and 4A/3A SAW jettison position (IEA non-keel side SAW)	P4/S4-26	6, FF, F, 6	180
Install MCHD and 2A/1A SAW jettison position (IEA keel side SAW)	P4/S4-25	6, FF, F, 6	180
Access to 4A/3A ECU	P4/S4-26	8, OO, A, 3	180
Access to 2A/1A ECU	P4/S4-25	8, OO, A, 3	180
Access to SSU (IEA non-keel side)	P6/S6-35	4, PP, G, 9	270
Access to SSU (IEA keel side)	P6/S6-33	4, PP, G, 9	270
Access to BMRRM (IEA non-keel side)	P6/S6-39	9, NN, G, 3	Any
Access to BMRRM (IEA keel side)	P6/S6-40	9, NN, G, 3	Any
Install MCHD and SAW jettison position (IEA non-keel side)	P6/S6-38	12, FF, F, 12	180
Install MCHD and SAW jettison position (IEA keel side)	P6/S6-37	12, FF, F, 12	180
Access to ECU (IEA non-keel side)	P6/S6-38	8, OO, A, 3	180
Access to ECU (IEA keel side)	P6/S6-37	8, OO, A, 3	180

ORU Mass: SSU – 186 lb ECU – 90 lb SAW – approx 2326 lb

FS 16-51 EVA/117/FIN

# MANUAL SAW JETTISON - TASK DATA (Cont)

# Notes:

. The MCHD has four deployable legs. Each leg has an EVA fastener which engages a zip nut on the mast canister hand rails. The MCHD also has a deployable PGT cradle assembly which is used to drive the mast canister MDA. The PGT cradle assembly is not required for the jettison procedure

## Cautions:


None

# Warnings:

- Electrical Shock Hazard: Install SSU shunt plug adapter/SSU shunt plugs and remove SSU during orbital eclipse. Procedure specifies wait time before installing SSU shunt plug adapter/SSU shunt plugs and removing SSU to allow voltages to drop to safe levels
- 2. Protrusion Hazard: SSU alignment post protrudes beyond mast canister. Maintain clearances between structure and crewmember during SSU changeout
- Voltage hazard may exist at connectors of the ECU and BMRRM. ECU and BMRRM must be safed before removal
- Collision Hazard: The solar array motion should be inhibited to prevent a collision hazard with the EV crew because the EV crew may be within 24 inches of the array rotational envelope
- Moving equipment hazard: Avoid contact with mast canister/beta gimbal during rotation of SAW
- Mass handling The crewmember will control the SAW mass with bent arms to avoid loading the EMU suit structure
- 7. Release mast canister with minimal tip-off rates



Mast Canister Handling Device (MCHD)



BMRRM connectors without BMRRM thermal cover

FS 16-52 EVA/117/FIN

# **BCDU BACKOUT**

MCC-H 1. Verify SAW rotation inhibits complete 2. Verify power inhibits complete (see Task Data page) 3. Record S/N of failed BCDU:  1. Translate to IEA worksite 2. Verify failed BCDU P/N and S/N to IV    CAUTION	IV	EV
	MCC-H 1. Verify SAW rotation inhibits complete 2. Verify power inhibits complete (see Task Data page) IV 3. Record S/N of failed BCDU:  H2  Jacking bolt, Scoop install	1. Translate to IEA worksite 2. If reqd, install and ingress APFR (see Task Data page) 3. Verify failed BCDU P/N and S/N to IV  CAUTION  Acme screws unfastened/fastened out of sequence could lead to jamming of BCDU  Avoid contacting BCDU mating surfaces (electrical connectors and cooling fins)  4. Install Sq TM onto H1 fitting, √anti-backlash neutral 5. PGT[B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM with 7/16 Rec: Drive PGT 5 turns (1 turn at bolt) on H1 6. Remove Sq TM and install on H2 fitting, √anti-backlash neutral 7. PGT[B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM with 7/16 Rec: Drive PGT 5 turns (1 turn at bolt) on H2 8. Remove Sq TM 9. PGT[B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Drive H1 minimum 5 turns 10. √Status indicator − UNLOCK 11. PGT[B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 ext 7/16: Drive H2, 5 turns

FS 16-53 EVA/117/FIN

# **BCDU BACKOUT - TASK DATA**

Estimated Task Duration:

	With RMS	Without RMS
One EV Crew	NA	0:45

### Tools:

EV	
PGT	APFR (if reqd)
6 Ext 7/16 Socket	WIF Extender (if reqd)
Sa TM with 7/16 Rec Socket	

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
H1	H1	7/16	1	4.8	31.7	190.3 (R)	5-6	30
(Secondary Bolt)						22.8 (I)		
H2	H2	7/16	1	4.8	33.5	188.4 (R)	16-17	30
(Primary Bolt)						27.8 (I)		

## Foot Restraints:

Foot Restraints:	I	1	1	1
Task	Fitting	WIF	WIF Extender	APFR Setting
Access to IEA BCDU 2B1 (1B1)	H1	P6/S6 - 26		12, QQ, K, 12
	H2	P6/S6 - 38		9, QQ, J, 12
Access to IEA BCDU 2B2 (1B2)	H1	P6/S6 – 18		10, QQ, G, 12
	H2	P6/S6 - 22		9, QQ, E, 12
Access to IEA BCDU 2B3 (1B3)	H1	P6/S6 - 22		5, QQ, L, 12
	H2	P6/S6 – 26		3, QQ, G, 12
Access to IEA BCDU 4B1 (3B1)	H1	P6/S6 - 25		12, QQ, B, 12
	H2	P6/S6 – 21		3, QQ, G, 12
Access to IEA BCDU 4B2 (3B2)	H1	P6/S6 – 17		2, QQ, E, 12
	H2	P6/S6 – 37		3, QQ, B, 12
Access to IEA BCDU 4B3 (3B3)	H1	P6/S6 - 21		7, QQ, A, 12
	H2	P6/S6 – 25		9, QQ, E, 12
Access to IEA BCDU 2A1 (1A1)	H1	P4/S4 - 09	9, A, 1	12, QQ, G, 12
	H2	P4/S4 - 09		3, QQ, G, 12
Access to IEA BCDU 2A2 (1A2)	H1	P4/S4 - 05		2, QQ, E, 12
	H2	P4/S4 - 25		3, QQ, B, 12
Access to IEA BCDU 2A3 (1A3)	H1	P4/S4 - 09		7, QQ, A, 12
	H2	P4/S4 - 13		9, QQ, E, 12
Access to IEA BCDU 4A1 (3A1)	H1	P4/S4 - 06		10, QQ, G, 12
	H2	P4/S4 - 26	11, A, 1	3, QQ, F, 12
Access to IEA BCDU 4A2 (3A2)	H1	P4/S4 - 10	3, A, 3	3, QQ, L, 12
	H2	P4/S4 - 10		9, QQ, E, 12
Access to IEA BCDU 4A3 (3A3)	H1	P4/S4 - 14	9, A, 3	9, QQ, A, 12
	H2	P4/S4 - 14		3, QQ, G, 12

**EVA Connectors: NA** 

# Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- Removing BCDU from coldplate causes H1 status indicator to move from UNLOCK to LOCK
- The BCDU backout procedure does not actually remove the ORU from the truss, it just backs the H2 bolt out enough to demate the blind-mate connectors
- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

## Cautions:

- Acme screws unfastened/fastened out of sequence could lead to jamming of BCDU. When unfastening Acme screws, H1 must be unfastened before H2
- Avoid contacting BCDU mating surfaces (electrical connectors and cooling fins)
- 3. Fins on bottom of MBSU and coldplate are no touch
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

## Warnings:

 Hazard voltage exist at the connectors of the BCDU. BCDU must be safed before removal


ORU Mass: 234 lbs

## MCC Inhibits:

BCDU	Inhibits	BCDU	Inhibits
2B1 (P6)	DCSU 2B RBI 2 Op, Cl Inh	2A1 (P4)	DCSU 2A RBI 2 Op, Cl Inh
	BCDU 4B1 CP RBI Op		BCDU 4A1 CP RBI Op
2B2 (P6)	DCSU 2B RBI 3 Op, Cl Inh	2A2 (P4)	DCSU 2A RBI 3 Op, CI Inh
	BCDU 4B2 CP RBI Op		BCDU 4A2 CP RBI Op
2B3 (P6)	DCSU 2B RBI 4 Op, Cl Inh	2A3 (P4)	DCSU 2A RBI 4 Op, Cl Inh
	BCDU 4B3 CP RBI Op		BCDU 4A3 CP RBI Op
4B1 (P6)	TBD	4A1 (P4)	DCSU 4A RBI 2 Op, Cl Inh
			BCDU 2A1 CP RBI Op
4B2 (P6)	TBD	4A2 (P4)	DCSU 4A RBI 3 Op, Cl Inh
			BCDU 2A2 CP RBI Op
4B3 (P6)	TBD	4A3 (P4)	DCSU 4A RBI 4 Op, Cl Inh
			BCDU 2A3 CP RBI Op
1B1 (S6)	TBD	1A1 (S4)	TBD
1B2 (S6)	TBD	1A2 (S4)	TBD
1B3 (S6)	TBD	1A3 (S4)	TBD
3B1 (S6)	TBD	3A1 (S4)	TBD
3B2 (S6)	TBD	3A2 (S4)	TBD
3B3 (S6)	TBD	3A3 (S4)	TBD

FS 16-54 EVA/117/FIN

## **BCDU BACKOUT – TASK DATA** (Cont)




Lock Status Indicator

Micro Square



H2 Primary Fastener

## Micro Square



Lock Status Indicator

H1 Secondary Fastener

FS 16-55 EVA/117/FIN

## **REMOVE AND REPLACE DCSU**

IV	EV1	EV2
MCC-H  1. Verify SAW rotation inhibits complete 2. Verify Inhibits for spare DCSU complete; give EV GO for DCSU removal	REMOVE SPARE DCSU FROM ESP1  1. Translate to ESP1 worksite  2. Ingress APFR 3. Remove thermal cover 4. Transfer thermal cover to EV2  CAUTION Acme screws unfastened/fastened out of sequence could lead to jamming of DCSU  5. Install Sq TM onto H1, √anti-backlash neutral 6. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H1 7. Remove Sq TM; Install on H2 fitting; √anti-backlash neutral 8. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H2 9. Remove Sq TM 10. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H1 minimum 5 turns 11. √Status indicator – UNLOCK 12. Install Square scoop on H2 13. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H2 minimum 16 turns 14. √Status indicator – UNLOCK 15. Remove DCSU from ESP1 FSE 16. Transfer spare DCSU to EV2	REMOVE SPARE DCSU FROM ESP1  1. Translate to ESP1 worksite 2. Set up WIF Extender and APFR (see Task Data sheet)  3. Receive thermal cover from EV1 4. Temp stow thermal cover at worksite  5. Receive spare DCSU from EV1 and stow on BRT  CAUTION  Avoid contacting DCSU mating surface (electrical connectors and cooling fins) with structure during translation with DCSU
IV 3. Record S/N of failed DCSU:  MCC-H 4. Verify electrical power inhibits complete. Give EV GO for DCSU removal	REMOVE FAILED DCSU  1. Translate to IEA worksite 2. Set up and ingress APFR (see Task Data sheet) 3. Verify failed DCSU P/N and S/N to IV 4. Install Sq TM onto H1, √anti-backlash neutral  5. On MCC GO, PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H1	REMOVE FAILED DCSU  1. Translate to IEA worksite with spare DCSU

FS 16-56 EVA/117/FIN

	IV	EV1	EV2
		<ol> <li>Remove Sq TM; Install on H2 fitting; √anti-backlash neutral</li> <li>PGT[[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-Sq TM-7/16: Drive PGT 5 turns (1 turn at bolt) on H2</li> <li>Remove Sq TM</li> <li>PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H1 minimum 5 turns</li> <li>√Status indicator – UNLOCK</li> <li>Install Square scoop on H2</li> <li>PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H2 minimum 16 turns</li> <li>√Status indicator – UNLOCK</li> <li>Remove failed DCSU</li> <li>Stow failed DCSU on BRT</li> </ol>	
IV	5. Record spare DCSU bolt data  Bolt Turns Torque  H1  H2	INSTALL SPARE DCSU  1. Receive spare DCSU from EV2 2. Install spare DCSU on IEA 3. √Status indicator on H1 and H2 are in UNLOCK 4. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H2, 16-17 turns 5. √Status indicator – LOCK 6. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H1, 5-6 turns 7. √Status indicator – LOCK 8. Remove Square scoop from H2 fitting 9. Egress and remove APFR 10. Give MCC-H GO to restore power to DCSU	INSTALL SPARE DCSU  1. Transfer spare DCSU to EV1
IV	6. Record failed DCSU bolt data  Bolt Turns Torque  H1  H2	STOW FAILED DCSU ON ESP1  1. Translate to ESP1 worksite  2. Transfer failed DCSU to EV2  3. Retrieve and transfer thermal cover to EV2	STOW FAILED DCSU ON ESP1  1. Translate to ESP1 worksite 2. Ingress APFR/WIF Extender 3. Receive failed DCSU from EV1 and install on ESP1 4. √Status indicator on H1 and H2 are in UNLOCK 5. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H2, 16-17 turns 6. √Status indicator – LOCK 7. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5]-6 ext-7/16: Drive H1, 5-6 turns 8. √Status indicator – LOCK 9. Remove Square scoop from H2 fitting 10. Receive thermal cover from EV1 11. Install thermal cover OCSU 12. Remove APFR and WIF Extender

FS 16-57 EVA/117/FIN

## **REMOVE AND REPLACE DCSU - TASK DATA**

#### **Estimated Task Duration:**

Two EV Crew	2:30

#### Tools:

EV1 (RMS)	EV2 (FF)
PGT	PGT
6ext 7/16	6ext 7/16
Square TM w/7/16 in Rec Socket	Square TM w/7/16 in Rec Socket
Square scoop	Square scoop
APFR	APFR
	WIF Extender
BRT	BRT

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Fastener	H1	7/16	1	4.8	31.7	190.3 (R) 22.8 (I)	5-6	30
Fastener	H2	7/16	1	4.8	33.5	188.4 (R) 27.8 (I)	16-17	30

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
P3/J3	ESP1	FRAM	3		FSE Heater Power

#### Foot Restraints:

Task	WIF	APFR Setting	WIF Extender					
P6 (S6) Non-keel side DCSU	P6-26 (S6-26)	12, PP, D, 12	N/A					
P6 (S6) Keel side DCSU	P6-28 (S6-28)	12, PP, D, 12	N/A					
P4 (S4) IEA Non-keel side DCSU	P4-14 (S4-14)	12, PP, D, 12	N/A					
P4 (S4) IEA Keel side DCSU	P4-16 (S4-16)	12, PP, D, 12	N/A					
Access to ESP1 DCSU (spare)	LAB 01-06	11, QQ, G, 12	6, B, 7					

#### **ORU Identification:**

Task	Part Number	Serial Number
Spare DCSU	R072610	X830114
Failed DCSU	TBD	TBD

ORU Mass: DCSU = 217 lb, FSE = 154 lb

### Notes:

- Thermal conditioning of the spare DCSU before installation may be required (Preliminary LSAR time of 18 minutes)
- DCSU will travel outward or inward as Acme screw H2 is unfastened or fastened
- 3. Lock SARJ when translating outboard of SARJ
- A crewman on the RMS could also be used for ORU transfer to and from the worksite. This might also change the order of the task
- If taking the FRAM with the DCSU, combined mass exceeds BRT capability
- DO NOT USE the P6 IEA ORU placards. The label information is incorrect. Reference P6 ORU label mapping in Section 18
- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin

### Cautions:


- Acme screws unfastened/fastened out of sequence could lead to jamming of DCSU during removal/installation. When unfastening Acme screws, H1 must be unfastened before H2. When fastening Acme screws, H2 must be fastened before H1
- Avoid contacting DCSU mating surface (electrical connectors and cooling fins) with structure during translation with DCSU
- Ensure ORU is maintained level and perpendicular to stanchion during installation. Failure to comply may damage H2 status indicator probe
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

### Warnings:


- Depending on worksite proximity to SAW rotation, MCC-H may need to inhibit SAW rotation to avoid collision with the EVA crewmembers
- Hazard voltage exists at the mating connectors to the failed DCSU. DCSU interface must be safed before removal
- If taking the FRAM with the DCSU, inhibit may be different. Connector must be released

FS 16-58 EVA/117/FIN

## REMOVE AND REPLACE DCSU – TASK DATA (Cont)




DCSU installed on P6 IEA



**H2 Status Indicator in Locked position** 

FS 16-59 EVA/117/FIN

# REMOVE AND REPLACE DCSU – TASK DATA (Cont)



FS 16-60 EVA/117/FIN

## **REMOVE AND REPLACE PVCU LOWER**

## PRIOR TO EVA:

- Remove connector cover plugs
   Record New PVCU S/N
   Stow in PVCU thermal cover

- 4. Attach Round scoop to PVCU micro conical fitting

IV/RMS	EV1	EV2
1. Verify IEA PVCU power and data inhibits complete. Give EV a GO for PVCU removal  2. Record failed PVCU S/N  3. Record bolt installation: final torque turns	REMOVE FAILED PVCU  1. Verify failed PVCU serial number    CAUTION	

EVA/117/FIN FS 16-61

## **REMOVE AND REPLACE PVCU LOWER - TASK DATA**

**Estimated Task Duration:** 

One EV Crew	1:00
Two EV Crew	N/A

#### Tools:

10013.	
EV1	EV2
PGT	
7/16 (wobble) Socket – 9 ext	
Round TM with 7/16 in flush	
Crewlock EVA Bag	
PVCU (spare) and thermal shroud	
Round Scoop (x2)	

## **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
PVCU Attachment bolt	N/A	7/16	1	4.8	33.5	188.4 (R) 27.6 (I)	16 to 17	30

### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
NA					

### Foot Restraints:

Task	WIF	APFR Setting
ORU Access IEA Keel Side	P6 - 29	9, OO, F, 12
ORU Access IEA Non-Keel Side	P6 - 30	3, OO, F, 12

ORU Mass: 42 lb

### **PVCU Reference Info:**

	Part Number	Serial Number
Spare PVCU	R071826-1	
PVCU on P6	R071826-1	
PVCU Cover	24700-10015-701	

## Notes:

- The keel side (also know as lower side) and non-keel side (also known as upper side) IEA PVCUs are not interchangeable due to dissimilar IEA structural interfaces
- P6 IEA ORU location decal is incorrect. Refer to reference section for the correct reference information

### Cautions:


 Tabs on the round TM interfere with the lock/unlock indicator next to the micro-conical in 4 out of the 6 possible attach positions. The interference could cause damage to the lock/unlock indicator during PVCU change out if the TM is not installed such that the torque multiplier tabs do not interfere with travel of the status indicator

## Warnings:

None

FS 16-62 EVA/117/FIN

# REMOVE AND REPLACE PVCU LOWER – TASK DATA (Cont)



IEA MDM (PVCU)



**IEA MDM (PVCU) with thermal cover** 

FS 16-63 EVA/117/FIN

## MDM REMOVE AND REPLACE (00:45)

OBJECTIVE: Generic procedure to replace a failed MDM ORU. Additional logistics and worksite specific information will be uplinked real time

## PRIOR TO EVA:

- Remove connector cover plugs
   Record spare MDM S/N \_\_\_\_\_
- 3. Attach round scoop to spare MDM
- 4. Install spare MDM onto cover (ISS EVA Task Checklist 1.220.125) or into ORU bag

IV	EV
MCC-H 1. Verify electrical power inhibits complete (see Task Data)	<ol> <li>Translate to MDM worksite</li> <li>Temp stow spare MDM</li> <li>Inspect failed MDM and 1553 cables which mate to back of MDM for possible damage</li> <li>Note – viewing may not be possible due to limited access</li> </ol>
IV 2. Record failed MDM EVA label number —————	REMOVE FAILED MDM  1. If reqd, remove thermal cover 2. Report failed MDM EVA label number 3. Attach tether to MDM
MCC-H 3. Give EV GO for MDM removal	<ul> <li>On MCC GO, perform MDM removal:</li> <li>4. PGT[A5 7.0 ft-lb, CCW2 30 RPM, MTL 10.5]-6 ext 7/16: Release secondary bolts (x2), expect ~16 turns for MDM sizes 4 &amp; 10 and ~7-14 turns for MDM size ESS</li> <li>5. PGT[A5 7.0 ft-lb, CCW2 30 RPM, MTL 10.5]-6 ext 7/16: Release primary jack bolt (x1), expect ~33 turns for MDM sizes 4 &amp; 10 and ~25-32 turns for MDM size ESS</li> <li>6. Install Round Scoop on MDM</li> <li>7. Slide failed MDM along guide rails to remove</li> <li>8. Inspect failed MDM Cho-Therm and blindmate connections, report condition to MCC-H</li> <li>9. Temp stow failed MDM</li> </ul>
IV 4. When MDM is removed from cover (ORU bag), record thermal clock start time:::	INSTALL SPARE MDM  1. Remove spare MDM from cover (ORU bag) 2. Inspect spare MDM Cho-Therm, truss coldplate, and blindmate connections for debris/damage 3. Align guide pins (x2) to bracket, slide spare MDM into soft-dock position  NOTE  To insure proper torque, verify PGT is straight on bolt and no side load is applied. Cycle PGT collar between each bolt, to reset turn count

EVA/117/FIN FS 16-64

# MDM REMOVE AND REPLACE (00:45) (Cont)

IV	EV
IV	EV
IV 5. Record MDM bolt data, Initial Torquing  Bolt Turns Torque (ft-lb)  Primary Jack Bolt  Secondary Bolt (Port)  Secondary Bolt (Stbd)  IV 6. Record MDM bolt data, Second Torquing  Bolt Turns Torque (ft-lb)	DRIVE MDM BOLTS: INITIAL TORQUING  NOTE  The three different MDM sizes have slightly different turn counts; please reference Task Data for the exact turn count range per MDM size  1. PGT[A4 6.3 ft-lb, CW2 30 RPM, MTL 10.5]-6 ext 7/16: Drive primary jack bolt (x1) to torque, minimum ~25 turns expected  2. If torque and/or minimum turns not achieved, contact MCC-H before driving secondary bolts  3. PGT[A4 6.3 ft-lb, CW2 30 RPM, MTL 10.5]-6 ext 7/16: Drive secondary bolts (x2) to torque, minimum ~7 turns expected  DRIVE MDM BOLTS: SECOND TORQUING
Primary Jack Bolt	<ol> <li>PGT[A4 6.3 ft-lb, CW2 30 RPM, MTL 10.5]-6 ext 7/16: Drive primary jack bolt (x1) to torque, for expected 25-32 total turn count</li> </ol>
Secondary Bolt (Port) Secondary Bolt (Stbd)	<ol> <li>PGT[A4 6.3 ft-lb, CW2 30 RPM, MTL 10.5]-6 ext 7/16: Drive secondary bolts (x2) to torque, for expected 7-14 total turn count</li> </ol>
7. Record MDM bolt data, Final Torquing	DRIVE CENTER BOLT: FINAL TORQUING
Bolt Turns Torque (ft-lb)  Primary Jack Bolt	<ol> <li>PGT[A4 6.3 ft-lb, CW2 30 RPM, MTL 10.5]-6 ext 7/16: Drive primary jack bolt (x1) to torque, for expected 25-32 total turn count</li> </ol>
<ul> <li>8. When ORU is installed, record thermal clock time:</li></ul>	<ol> <li>Remove Round Scoop</li> <li>Clean up worksite</li> <li>Give MCC-H GO for MDM power up</li> <li>□□ Perform WVS survey</li> <li>Stow failed MDM on cover (in ORU bag)</li> </ol>

FS 16-65 EVA/117/FIN

## MDM REMOVE AND REPLACE - TASK DATA

## Tools:

EV	
PGT	MDM Cover (if reqd)
6 Ext 7/16	ORU Bag (if reqd)
Round Scoop	3" Scraper (if reqd)

## **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Primary Jack Bolt (Center)	N/A	7/16	1	6.3	6.5	9.2 (I) 14.7 (R)	See table below	30
Secondary Bolts (Outer)	N/A	7/16	2	6.3	6.5	9.2 (I) 14.7 (R)	See table below	30

Fastener Name	MDM Size	Turns to Remove	Turns to Install
Primary Jack Bolt	ESS	24.5-31.5	24.5-31.5
(Center)	4	33	25.4-31.5
	10	33	25.5-31.5
Secondary Bolts	ESS	7-14	7-14
(Outer)	4	16	7.5-14
	10	16	7.5-14

## **ORU Identification:**

ORU	Part number	Serial Number	EVA Label Number
Spare MDM	8259065-910	98070105	MDM 16-1015
Failed MDM			

ORU	Height	Length	Width	Weight
EXT 1, EXT 2	10.5 inches	14.9 inches	16.4 inches	50.8 lbs

## **ORU Power Inhibits:**

ORU Power Inhibits:				
ORU (Size)	Location	Cover/Bag	Power Inhibits	
Ext-1 (ESS)	S0 Bay 1	MDM Cover	S01A_C RPC 01 (pwr)	
	(Zenith)		S02B_C RPC 02 (htr)	
Ext-2 (ESS)	S0 Bay 1	MDM Cover	S02B_C RPC 01 (pwr)	
	(Nadir)		S01A_C RPC 02 (htr)	
N1-1 (10)	PMA1	MDM Cover	N1RS1_A RPC 11 (pwr)	
	(Zenith)		N1RS1_A RPC 05, 06 (SDO)	
			N1RS2_C RPC 15 (htr)	
N1-2 (10)	PMA1	MDM Cover	N1RS2_C RPC 13 (pwr)	
	(Nadir)		N1RS2_C RPC 03, 04 (SDO)	
			N1RS1_C RPC 2 (htr)	
P1-1 (4)	P1 Bay 14	Small ORU	P11A_B RPC 05 (pwr)	
	(Zenith)	Bag	P13A_G RPC 16 (htr)	
P1-2 (10)	P1 Bay 14	MDM Cover	P12B_C RPC 16 (pwr)	
	(Nadir)		P12B_C RPC 1013 (SDO)	
			P14B_G RPC 16 (htr)	
PTR (4)	P1 Radiator	Small ORU	P12B_C RPC 03 (pwr)	
	Beam	Bag	P12B_C RPC 0406 (SDO)	
	Zenith		P14B_G RPC 11 (htr &	
			thermostat)	
S0-1 (10)	S0 Bay 0	MDM Cover	S01A_C RPC 16 (pwr)	
	(Zenith)		S01A_D RPC 0205 (SDO)	
			S03A_E RPC 05 (htr)	
S0-2 (10)	S0 Bay 0	MDM Cover	S02B_C RPC 16 (pwr)	
	(Nadir)		S02B_D RPC 0205 (SDO)	
S1-1 (10)	S1 Bay 13	MDM Cover	S11A_C RPC 16 (pwr)	
	(Zenith)		S11A_D RPC 1013 (SDO)	
			S13A_G RPC 16 (htr)	
S1-2 (4)	S0 Bay 0	Small ORU	S12B_B RPC 05 (pwr)	
	(Nadir)	Bag	S14B_G RPC 16 (SDO)	
STR (4)	S1 Radiator	Small ORU	S11A_C RPC 03 (pwr)	
	Beam Nadir	Bag	S11A_C RPC 0406 (SDO)	
			S13A_G RPC 11 (htr &	
			thermostat)	
P3-1 (TBD)	TBD	TBD	TBD	
P3-2 (TBD)	TBD	TBD	TBD	
S3-1 (TBD)	TBD	TBD	TBD	
S3-2 (TBD)	TBD	TBD	TBD	

FS 16-66 EVA/117/FIN

## MDM REMOVE AND REPLACE – TASK DATA (Cont)

# Notes:

- To insure proper torque, verify PGT is straight on bolt and no side load is applied. Cycle PGT collar between each bolt, to reset turn count
- 2. MDM EVA label number is located on the front of the MDM
- 3. Secondary bolts spring out upon release; primary bolt free spins
- Residual Cho-Therm material on truss coldplate may be removed using the 3" Scraper Tool, as regd

### Cautions:

- 1. Avoid contacting MDM Cho-Therm and electrical connector mating surfaces
- Equipment damage During MDM removal, ensure that the left and right captive fasteners are unfastened before loosing center jackscrew
- 3. The blind mate connectors are subject to damage as replacement unit is secured to structure. Ensure that the center jack bolt is tightened fully to properly engage blind mate connectors
- Center jack bolt must first be installed minimum turns, at torque setting, for proper installation of outer bolts

### Warnings:

1. Hazard voltage exists at the connectors of the MDM. MDM must be safed before removal



MDM Receptacle on P3



MDM Installed in Receptable

FS 16-67 EVA/117/FIN

## CANADIAN REMOTE POWER CONTROL MODULE (CRPCM) REMOVE/REPLACE

## **OBJECTIVE:**

Generic procedure to replace a failed CRPCM ORU. Additional logistic and worksite specific information as well as updated PGT settings, will be uplinked real time.

## PRIOR TO EVA

- 1. Unstow spare CRPCM.
- 2. Remove blind mate connector covers; stow in Airlock.
- 3. Verify part number of spare CRPCM and record serial number on Task Data Sheet. Report P/N and S/N of spare unit to **MCC-H**.

## **WARNING**

- 1. Due to touch temperatures, the EVA crew must avoid the volume extending 6" out from the front of the operating light on the MSS Camera/lights.
- 2. Hazard voltage exists at the connectors of the failed CRPCM. Failed CRPCM must be safed prior to removal.

## CAUTION

Minimize contact with silver Teflon (white surface) on CRPCM and surrounding ORUs to avoid hardware damage.

## NOTE

- 1. Although the bolt does not travel inside the CRPCM, the CRPCM itself is "jacked out" by the rotation of the bolt.
- 2. CRPCM softdocks are magnetic.

FS 16-68 EVA/117/FIN

# CANADIAN REMOTE POWER CONTROL MODULE (CRPCM) REMOVE/REPLACE (Cont)

IV	EV1	EV2
<ol> <li>On MCC-H GO for RPCM inhibit</li> <li>PCS P1(S0,S1,S3,P3,S4,P4): EPS: RPCM X</li> <li>RPCM X RPC 1</li> <li>Verify RPC Position – Op         √Close Cmd – Inh</li> <li>Give EV1 GO for CRPCM removal.</li> <li>Table 1. Required RPCM Inhibits</li> </ol>	REMOVE FAILED CRPCM  1. If required, setup and ingress APFR per Task Data Sheet.  2. Report failed CRPCM part number and serial number to IV.  3. Install square scoop on CRPCM.  4. Hold for IV GO.  5. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5]-6ext-7/16:	
MT/MBS Prime String Redundant Worksite CRPCM R&R CRPCM R&R  P1 worksite 7 P1-4B_E P1-3A_E	Release CRPCM tie-down bolt ~17 to 19 turns 6. Remove failed CRPCM.	
P1 worksite 6         P1-4B_F         P1-3A_F           S0 worksite 5         S0-4B_B         S0-3A_B	Slide out of RPCA. 7. Transfer failed CRPCM to EV2.	Receive failed CRPCM from EV1.  Temporarily stow.
S0 worksite 4         S0-4B_A         S0-3A_A           S1 worksite 3         S1-4B_F         S1-3A_F           S1 worksite 2         S1-4B_E         S1-3A_E	INSTALL SPARE CRPCM  8. Inspect RPCA and CRPCM interface for debris/damage.	Transfer replacement CRPCM to EV1.
S3 worksite 1 S3-4B_F S3-3A_F P3 worksite 8 P3-4B_F P3-3A_F	<ol> <li>Install replacement CRPCM into soft dock position.</li> <li>PGT[B1 12.0 ft-lb, CW2 30RPM, MTL</li> </ol>	
	30.5]-6ext-7/16:  Drive CRPCM tie-down bolt ~17 to 19 turns.  11. Remove square scoop from CRPCM.	

FS 16-69 EVA/117/FIN

## CANADIAN REMOTE POWER CONTROL MODULE (CRPCM) REMOVE/REPLACE - TASK DATA

Table 2. Estimated Task Duration

	With RMS	Without RMS
One EV Crew	NA	1:00
Two EV Crew	NA	1:00

Table 3. Tools

EV1 (FF)	EV2 (FF)
PGT	Square scoop
6ext-7/16	
Square scoop	

Table 4. EVA Fasteners

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Release Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
CRPCM tie-down bolt	N/A	7/16"	1	13.3	13.3	TBD	17 to 19	30

<sup>\*</sup> Data obtained from MBS operating procedures - Annex4: MBS EVA maintenance procedures.

**EVA Connectors: None** 

Table 5. Foot Restraints

Task	WIF	APFR Setting
CRPCM R&R	MBS-02	5,VV,B,12

ORU Mass: 19.4 lbs - 12.4" x 10.8" x 7.1"

Table 6. ORU Identification

	Part Number	Serial Number
Spare CRPCM	51800-0041-1	
Failed CRPCM	51800-0041-1	

<sup>\*</sup>ORU mass, dimensions, and identification obtained from UF-2 flight launch and return manifest.

FS 16-70 EVA/117/FIN

## CANADIAN REMOTE POWER CONTROL MODULE (CRPCM) REMOVE/REPLACE – TASK DATA (Cont)




Figure 3.- CRPCM Interface on MBS.

Figure 4.- Isometric View of CRPCM.

FS 16-71 EVA/117/FIN

## MBSU REMOVE/REPLACE

IV/SSRMS	EV1(SSRMS)	EV2 (FF)
IV 1. Verify with MCC S0 inhibits in place  - MBSU 4 RBI 7 OP (CL INH) - MBSU 4 RBI 6 OP (CL INH) - MBSU 4 RBI 14 OP (CL INH) IV 2. Verify with MCC ESP2 inhibits in place - RPCM N1RS2-B RPC10 (open and close inhibited) - RPCM S04B F RPC 12 (open and close inhibited) SSRMS 3. At TBD APFR install posn IV 4. Verify SSRMS in standby prior to APFR install  SSRMS 6. On EV GO – to APFR Ingress posn, as reqd SSRMS 6. On EV GO – to MBSU worksite IV 7. Record S/N of failed MBSU	S0 MBSU R&R SET-UP  1. Retrieve APFR from TBD location 2. Translate to SSRMS APFR install location 3. Install WIF adapter in SSRMS PFR socket, tether point toward EE 4. Install APFR (12,PP,F,6) in SSRMS WIF adapter (Toes away from EE)  — Pull test  — Verify APFR lock collar black on black 5. Safety tether swap to SSRMS, verify hook locked; attach A/L safety tether to nearby HR 6. GCA SSRMS for APFR ingress 7. Ingress SSRMS APFR 8. GCA SSRMS to MBSU worksite	SO MBSU R&R SET-UP  1. Translate to ESP2; attach BRT to ESP2 HR 8003 (aft face, stbd side)  2. Remove MLI from spare MBSU (hinge is FWD)  □ Release velcro tabs on front, side, and back corners of ORU base □ Release integral strap from underside of fwd flap □ Fold or roll cover toward back of MBSU, attach strap to Velcro mating swatch on back side of MLI □ Using side straps from front of MLI, secure rest of MLI as reqd  3. Translate up CETA Spur to S0 Face 1 4. Translate to failed MBSU  5. Verify failed MBSU P/N and S/N to IV  CAUTION  Minimize loads on H1 microfixture  6. Install Sq TM on H1 fitting; √anti-backlash neutral

FS 16-72 EVA/117/FIN

# MBSU REMOVE/REPLACE (Cont)

IV/SSRMS	EV1(SSRMS)	EV2 (FF)
Jacking bolt, Scoop install location H1	CAUTION  Acme screws unfastened/fastened out of sequence could lead to jamming of MBSU  On MCC GO:  1. PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H1  2. Remove Sq TM and install on H2 fitting; √anti-backlash neutral  3. PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H2  4. Transfer TM to EV2  5. PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 Ext 7/16: Drive H1 minimum 5 turns  6. √Status indicator - UNLOCK  7. Receive Sq Scoop from EV2; install on H2  8. PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 Ext 7/16: Drive H2 minimum 16 turns  9. √Status indicator — UNLOCK  10. Stow PGT  WARNING  Avoid contact with intermeshing fins of the MBSU and coldplate  11. Remove MBSU from coldplate (soft dock on H2 15-20 lbs)	1. Receive Sq TM from EV1; stow on MWS  2. Transfer Sq Scoop to EV1

FS 16-73 EVA/117/FIN

# MBSU REMOVE/REPLACE (Cont)

IV/SSRMS	EV1(SSRMS)	EV2 (FF)
SSRMS 8. On EV GO – to spare MBSU on ESP-2	<ol> <li>RETRIEVE SPARE MBSU/STOW FAILED MBSU</li> <li>GCA SSRMS to spare MBSU on ESP-2</li> <li>Temp stow failed MBSU on ESP-2 HR 8005 using MUT EE/Ballstack (fins facing away from structure)</li> <li>PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H1</li> <li>Remove Sq TM and install on H2 fitting; √antibacklash neutral</li> <li>PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-Sq TM-7/16Rec: Drive PGT 5 turns (1 turn at bolt) on H2</li> <li>Transfer Sq TM to EV2</li> <li>PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 Ext 7/16: Drive H1 minimum 5 turns</li> <li>√Status indicator – UNLOCK</li> <li>Retrieve Sq Scoop from MWS; install on H2</li> <li>PGT [B1 12.0 ft-lb, CCW2 30 RPM, MTL 30.5]-6 Ext 7/16: Drive H2 minimum 16 turns</li> <li>√Status indicator – UNLOCK</li> <li>Stow PGT</li> <li>Remove MBSU (soft dock on H2 15-20 lb); transfer to EV2</li> </ol>	<ol> <li>RETRIEVE SPARE MBSU/STOW FAILED MBSU</li> <li>Translate to ESP-2; assist with temp stow</li> <li>Install MUT EE/Ballstack on ESP-2 HR 8005</li> <li>Temp stow failed MBSU on ESP-2 HR 8005 using MUT EE/Ballstack (fins facing away from structure)</li> <li>Install Sq TM on Spare MBSU H1 fitting; √anti-backlash neutral</li> <li>Receive Sq TM from EV1; stow on MWS</li> </ol>
IV 9. Record failed MBSU	CAUTION  Ensure ORU is level during installation to prevent damage to H2 status indicator probe	6. Receive spare MBSU
installation turns and torque  Bolt Turns Torque  H2  H1	<ul> <li>14. Install failed MBSU (soft dock on H2 15-20 lb) on FRAM</li> <li>15. √Status indicator on H1and H2 are in UNLOCK</li> <li>16. PGT [B3 18.4 ft-lb, CW2 30 RPM, MTL 30.5]-6 Ext-7/16 Drive H2, 16-17 turns</li> <li>17. √H2 status indicator – LOCK</li> </ul>	

FS 16-74 EVA/117/FIN

# MBSU REMOVE/REPLACE (Cont)

IV/SSRMS	EV1(SSRMS)	EV2 (FF)
SSRMS 10. On EV GO – to MBSU worksite	<ul> <li>18. PGT [B3 18.4 ft-lb, CW2 30 RPM, MTL 30.5]-6 Ext-7/16 Drive H1, 5-6 turns</li> <li>19. √H1 status indicator – LOCK</li> <li>20. Remove Sq Scoop; stow on MWS</li> <li>21. Install thermal cover on failed unit</li> <li>22. Receive spare MBSU</li> <li>23. GCA SSRMS to MBSU worksite</li> <li>INSTALL SPARE MBSU</li> </ul>	7. Transfer spare MBSU to EV1  INSTALL SPARE MBSU
	Orient MBSU such that blind-mate connectors and H2 are oriented correctly      CAUTION      There is a TBD thermal dwell time between the MBSU & coldplate. Wait TBD time prior to driving bolt	<ol> <li>Translate to worksite</li> <li>Inspect guide rails and connectors for debris/damage</li> <li>Assist EV1 with MBSU install</li> </ol>
IV 11. Record spare MBSU installation turns and torque  Bolt Turns Torque H2 H1	<ol> <li>Install spare MBSU (soft dock on H2 15-20 lbs)</li> <li>√Status indicator on H1and H2 are in UNLOCK</li> <li>PGT [A3 4.8 ft-lb, CW2 30 RPM, MTL 30.5]-6 Ext-7/16 Drive H2, 16-17 turns</li> <li>√H2 status indicator – LOCK</li> <li>PGT [A3 4.8 ft-lb, CW2 30 RPM, MTL 30.5]-6 Ext-7/16 Drive H1, 5-6 turns</li> <li>√H1 status indicator – LOCK</li> <li>Give MCC-H GO to restore power to MBSU</li> </ol>	
SSRMS 12. On EV GO – to spare safety tether location	<ul> <li>CLEANUP</li> <li>1. GCA SSRMS to spare safety tether anchor point</li> <li>2. Egress APFR; tether swap back to A/L safety tether, verify hook locked</li> <li>3. Remove APFR; stow in TBD location</li> <li>4. Remove WIF Adapter; stow in small trash bag</li> </ul>	CLEANUP  1. Remove Sq scoop from MBSU

FS 16-75 EVA/117/FIN

## MBSU REMOVE/REPLACE - TASK DATA

## **Estimated Task Duration:**

	With SSRMS
One EV Crew	NA
Two EV Crew	3:00

### Tools:

EV1	EV2
Square scoop	EVA Crewlock bag (optional)
PGT – 6 Ext 7/16	Square Scoop
WIF Adapter	EVA Ratchet 3/8 drive – 6 Ext 7/16 (backup)
Safety Tether (SSRMS)	Sq TM 7/16 rec
APFR	MUT EE
	Ballstack

## **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
H1 (Secondary Bolt)	H1	7/16	1	4.8 (S0) 18.4 (FSE)	31.7	190.3 (R) 22.8 (I)	5-6	30
H2 (Primary Bolt)	H2	7/16	1	4.8 (S0) 18.4 (FSE)	33.5	188.4 (R) 27.8 (I)	16-17	30

#### **Foot Restraints:**

Task	WIF	Swing Arm Setting	APFR Setting
MBSU	SSRMS	N/A	12, PP, F, 6
MBSU 4A4B (CETA at Bay 02)	3	13, 12, GG	9, TT, F, 12
MBSU 1A1B (CETA at Bay 00)	3	13, 12, GG	9, TT, F, 12
MBSU 3A3B (CETA at Bay 00)	2	15, 12, GG	3, TT, F, 12
MBSU 2A2B (CETA at Bay 02)	2	15, 12, GG	3, TT, F, 12

## **ORU Data:**

ORU	Part Number	Serial Number	Mass	Dimensions
MBSU 1A1B	R072591-41	X700385	236 lb	40" x 28" x 12"
MBSU 2A2B	R072591-41	X700386	236 lb	40" x 28" x 12"
MBSU 1A1B	R072591-41	C250636	236 lb	40" x 28" x 12"
MBSU 3AB	R072591-41	C250637	236 lb	40" x 28" x 12"
Spare MBSU	R072591-41	X652064	236 lb	40" x 28" x 12"
Spare MBSU	R072591-41	TBD	236 lb	40" x 28" x 12"

### Notes:

- 1. H1 is secondary bolt, H2 is primary bolt
- NO ACTION is required when Acme screw torque and appropriate number of turns has been met and the status indicator is not at the LOCKED position. Report anomaly
- 3. Removing MBSU from coldplate causes H1 status indicator to move from UNI OCK to LOCK
- There is no hard stop when releasing H1 and H2 bolts; upon release, they will free spin
- 5. Primary stanchion (H2) has ~15-20 lb soft dock force to overcome during MBSU removal and installation from/to FSE & coldplate
- 6. H1 and H2 status indicators are not identical, see drawing below

## Cautions:


- Acme screws unfastened/fastened out of sequence could lead to jamming of MBSU during removal. When unfastening Acme screws, H1 must be unfastened before H2. When fastening Acme screws, H2 must be fastened before H1
- Ensure ORU is maintained level and perpendicular to the tiedown stanchions during installation. Failure to comply may damage H2 status indicator probe
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads
- 4. There is a TBD thermal dwell time between the MBSU and coldplate. Wait TBD time, prior to driving bolts

### Warnings:

- Hazard voltage exists at the connectors of the MBSU. MBSU must be safed before removal
- 2. Avoid contact with intermeshing fins of the MBSU and coldplate due to sharp edge concerns


FS 16-76 EVA/117/FIN

# MBSU REMOVE/REPLACE – TASK DATA (Cont)



FS 16-77 EVA/117/FIN

## MBSU REMOVE/REPLACE - TASK DATA (Cont)





Spare MBSU w/MLI attached to FRAM on ESP2



MBSU at worksite

FS 16-78 EVA/117/FIN

## **REMOVE AND REPLACE PFCS**

IV	EV1	EV2
MCC-H  1. Verify SAW rotation inhibits complete 2. Verify inhibits for spare PFCS complete; give EV GO for PFCS removal	REMOVE SPARE PFCS  1. Translate to P6 worksite  2. Ingress APFR 3. Remove thermal cover 4. Transfer thermal cover to EV2  Demate FQDC H1 5. On MCC GO, PGT[B1 12.0 ft-lb, CCW1 10RPM, MTL 30.5]  - 6 ext 7/16: Break torque and drive QD H1 10 turns  CAUTION  The torque necessary for the initial, break-free rotation of the QD drive point is greater than the maximum torque allowed when the drive point reaches internal mechanical stops. The PGT must not operate the drive point into the mechanical stops at the initial torque. Mechanical stops will be reached at 18 turns  6. PGT[A4 6.3 ft-lb, CCW2 30RPM, MTL 30.5] − 6 ext 7/16: Drive QD H1 to hard stop, ~8 turns  7. √Status indicator − DEMATE  Retract Acme screw and latch key from passive half  8. PGT[A4 6.3 ft-lb, CW2 30RPM, MTL 30.5] − 6 ext 7/16: Drive QD H1 to hard stop, ~18 turns  9. √Status indicator remains at − DEMATE  Demate FQDC H2  10. PGT[B1 12.0 ft-lb, CCW1 10RPM, MTL 30.5] − 6 ext 7/16: Break torque and drive QD H2 10 turns  11. PGT[A4 6.3 ft-lb, CCW2 30RPM, MTL 30.5] − 6 ext 7/16: Drive QD H2 to hard stop, ~8 turns  12. √Status indicator − DEMATE  Retract Acme screw and latch key from passive half  13. PGT[A4 6.3 ft-lb, CW2 30RPM, MTL 30.5] − 6 ext 7/16: Drive QD H2 to hard stop, ~8 turns  14. √Status indicator remains at − DEMATE  Retract Acme screw and latch key from passive half  15. Install Sq TM onto H3, √anti-backlash neutral	REMOVE SPARE PFCS  1. Translate to P6 worksite 2. Set up WIF Extender and APFR (see Task Data page)  3. Receive thermal cover from EV1 4. Temp stow thermal cover at worksite

FS 16-79 EVA/117/FIN

IV	EV1	EV2
	<ul> <li>16. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – Sq TM with 7/16 Rec: Drive PGT 5 turns (1 turn at bolt) on H3</li> <li>17. Remove Sq TM and install on H4, √anti-backlash neutral</li> <li>18. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – Sq TM with 7/16 Rec: Drive PGT 5 turns (1 turn at bolt) on H4</li> <li>19. Remove Sq TM</li> <li>20. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H3 minimum 5 turns</li> <li>21. √Status indicator – UNLOCK</li> <li>22. Install Square scoop on H4</li> <li>23. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H4 minimum 17 turns</li> <li>24. √Status indicator – UNLOCK</li> <li>25. Remove Spare PFCS</li> <li>26. Transfer spare PFCS to EV2</li> <li>27. Retrieve APFR</li> </ul>	5. Receive spare PFCS from EV1 and stow on BRT  CAUTION Avoid contacting PFCS mating surface (electrical and fluid connectors) with structure during translation with PFCS  REMOVE FAILED PFCS  1. Translate to IEA worksite with spare PFCS
IV 3. Record S/N of failed PFCS:	REMOVE FAILED PFCS  1. Translate to Failed PFCS worksite 2. Set up and ingress APFR (see Task Data sheet) 3. Verify failed PFCS P/N and S/N to IV	
	Demate FQDC H1  4. On MCC GO, PGT[B1 12.0 ft-lb, CCW1 10RPM, MTL 30.5]  - 6 ext 7/16: Break torque and drive QD H1 10 turns  5. PGT[A4 6.3 ft-lb, CCW2 30RPM, MTL 30.5] - 6 ext 7/16:  Drive QD H1 to hard stop, ~8 turns  6. √Status indicator – DEMATE	
	Retract Acme screw and latch key from passive half 7. PGT[A4 6.3 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive QD H1 to hard stop, ~18 turns 8. √Status indicator remains at – DEMATE  Demate FQDC H2 9. PGT[B1 12.0 ft-lb, CCW1 10RPM, MTL 30.5] – 6 ext 7/16:	
	Break torque and drive QD H2 10 turns  10. <b>PGT[A4</b> 6.3 ft-lb, <b>CCW2</b> 30RPM, MTL <b>30.5] – 6 ext 7/16:</b> Drive QD H2 to hard stop, ~8 turns  11. √Status indicator – DEMATE	

FS 16-80 EVA/117/FIN

IV	EV1	EV2
MCC-H 4. Verify Inhibits for failed PFCS complete; give EV GO for PFCS removal	Retract Acme screw and latch key from passive half  12. PGT[A4 6.3 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16:     Drive QD H2 to hardstop, ~18 turns  13. √Status indicator remains at – DEMATE  Release Structural Fasteners  14. Install Sq TM onto H3, √anti-backlash neutral  15. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – Sq TM with 7/16 Rec: Drive PGT 5 turns (1 turn at bolt) on H3  16. Remove Sq TM and install on H4, √anti-backlash neutral  17. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – Sq TM 7/16  Rec: Drive PGT 5 turns (1 turn at bolt) on H4  18. Remove Sq TM  19. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H3 minimum 5 turns  20. √Status indicator – UNLOCK  21. PGT[B7 25.5 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H4 minimum 17 turns  22. √Status indicator – UNLOCK  23. On MCC GO, remove failed PFCS  24. Stow failed PFCS on BRT  INSTALL SPARE PFCS  1. Receive spare PFCS from EV2 and install on IEA  2. √Status indicator on H3 and H4 are in UNLOCK  CAUTION  Attempting to mate QDs H1 and H2 before Acme screw H4 is fastened could lead to jamming of PFCS and breakage of QDs. Acme screw H4 must be fastened before QDs H1 and H2 are mated  3. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H4, 16-17 turns  4. √Status indicator – LOCK  5. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H3, 5-6 turns  6. √Status indicator – LOCK  7. Remove Square Scoop from H4 fitting  Engage Acme screw and latch key to passive half  8. PGT[B1 12.0 ft-lb, CCW230RPM, MTL 30.5] – 6 ext 7/16: Drive QD H2 to hardstop, ~18 turns	2. Install Square Scoop on H4  INSTALL SPARE PFCS 1. Transfer spare PFCS to EV1

FS 16-81 EVA/117/FIN

IV	EV1	EV2
IV 5. Record spare PFCS bolt data  Bolt Turns Torque  H1  H2 H3 H4  IV 6. Record failed PFCS bolt data  Bolt Turns Torque  H1 H2 H3 H4  H4	Mate FQDC H2 9. PGT[B1 12.0 ft-lb, CW2 30RPM, MTL 30.5] - 6 ext 7/16: Drive QD H2 to hardstop, ~18 turns 10. √Status indicator - MATE  Engage Acme screw and latch key to passive half 11. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] - 6 ext 7/16: Drive QD H1 to hardstop, ~18 turns  Mate FQDC H1 12. PGT[B1 12.0 ft-lb, CW2 30RPM, MTL 30.5] - 6 ext 7/16: Drive QD H1 to hardstop, ~18 turns 13. √Status indicator - MATE 14. Egress and remove APFR 15. Give MCC-H GO to restore power to PFCS  INSTALL FAILED PFCS 1. Translate to P6 worksite 2. Transfer failed PFCS to EV2	INSTALL FAILED PFCS  1. Translate to P6 worksite 2. Ingress APFR/WIF Extender 3. Receive failed PFCS from EV1 and install on ESP1 4. √Status indicator on H3 and H4 are in UNLOCK 5. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H4, 16-17 turns 6. √Status indicator – LOCK 7. PGT[A3 4.8 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive H3, 5-6 turns 8. √Status indicator – LOCK 9. Remove Square Scoop from H4 fitting  Engage Acme screw and latch key to passive half 10. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive QD H2 to hardstop, ~18 turns  Mate FQDC H2 11. PGT[B1 12.0 ft-lb, CW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive QD H2 to hardstop, ~18 turns 12. √Status indicator – MATE  Engage Acme screw and latch key to passive half 13. PGT[B1 12.0 ft-lb, CCW2 30RPM, MTL 30.5] – 6 ext 7/16: Drive QD H1 to hardstop, ~18 turns

FS 16-82 EVA/117/FIN

IV	EV1	EV2
	Retrieve and transfer thermal cover to EV2	15. √Status indicator – MATE 16. Receive thermal cover from EV1 17. Install thermal cover 18. Remove APFR and WIF Extender

FS 16-83 EVA/117/FIN

## **REMOVE AND REPLACE PFCS - TASK DATA**

### **Estimated Task Duration:**

Two EV Crew 3:00

#### Tools:

EV1	EV2
PGT	PGT
7/16" x 6" ext	7/16" x 6" ext
Square Torque Multiplier w/7/16" Recessed socket	Square Scoop
Square Scoop	APFR
APFR	WIF extender
BRT	BRT

### **EVA Fasteners:**

Fastener Name	Label	Head Size	Qty	Install Torque (ft-lb)	Max Break Away Torque (ft-lb)	Failure Torque (ft-lb)	Turns	RPM
Fluid QD	H1	7/16"	1	12.0	7.5	33.3 (R) 27.1 (I)	18	30
Fluid QD	H2	7/16"	1	12.0	7.5	33.3 (R) 27.1 (I)	18	30
Fastener	НЗ	7/16"	1	4.8	31.7	190.3 (R) 22.8 (I)	5-6	30
Fastener	H4	7/16	1	4.8	33.5	188.4 (R) 27.8(I)	16-17	30

#### **EVA Connectors:**

Harness	From	То	Clamps (#)	Conn Size	Function
P5 (ESP1)	ESP DF	PFCS J7	None	15	FSE Heater Power

#### **Foot Restraints:**

Task	WIF	APFR Setting	WIF Extender Setting
P6 IEA PFCS (Non-Keel side, 2B)	P6-19	12,QQ,A,12	N/A
P6 IEA PFCS (Keel side, 4B)	P6-20	12,QQ,L,12	N/A
S4 IEA PFCS (Non-Keel side)	S4-7	12,QQ,A,12	N/A
S4 IEA PFCS (Keel side)	S4-8	12,QQ,L,12	N/A
Spare PFCS on ESP1	LAB-01-06	8, MM, F, 12	7, B, 6
Other PFCS Locations	TBD	TBD	N/A

#### **ORU Identification:**

Task	Part Number	Serial Number
Spare PFCS	RE-2814-06	0008
P6 PFCS	RE-2814-05	Port-00004, Stbd-00002
Other PFCS Locations TBD	TBD	TBD

ORU Mass: PFCS=255 lb, FSE=103 lb

#### Notes:

- 1. Thermal conditioning of the spare PFCS before installation may be required
- PFCS will travel outward or inward as Acme screw H4 is unfastened or fastened
- 3. Lock SARJ when translating outboard of SARJ
- 4. A crewman on the RMS could also be used for ORU transfer to and from the worksite. This might also change the order of the task
- 5. If taking the FRAM with the PFCS, combined mass exceeds BRT capability
- 6. DO NOT USE the P6 IEA ORU placards. The label information is incorrect. Reference P6 ORU label mapping in Section 18
- 7. There is no hard stop when releasing H3 and H4 bolts; upon release, they will free spin

#### Cautions:


- Acme screws unfastened/fastened out of sequence could lead to jamming of PFCS during removal. When unfastening Acme screws, H3 must be unfastened before H4. When fastening Acme screws, H4 must be fastened before H3
- Attempting to mate QDs H1 and H2 before Acme screw H4 is fastened could lead to jamming of PFCS and breakage of QDs. Acme screw H4 must be fastened before QDs H1 and H2 are mated
- Avoid contacting PFCS mating surface (electrical and fluid connectors) with structure during translation with PFCS
- Ensure ORU is maintained level and perpendicular to stanchion during installation. Failure to comply may damage H4 status indicator probe
- Minimize force applied to H1 microfixture. It is not rated to withstand excessive loads

### Warnings:


- Voltage Hazard exists at the connectors of the failed PFCS. Failed PFCS must be safed before removal
- 2. Depending on worksite proximity to SAW rotation, MCC-H may need to inhibit SAW rotation to avoid collision with the EVA crewmembers
- 3. If taking the FRAM with the PFCS, inhibit may be different. Connector must be released

FS 16-84 EVA/117/FIN

# REMOVE AND REPLACE PFCS – TASK DATA (Cont)




PFCS installed on P6 IEA (Port)




FS 16-85 EVA/117/FIN

# REMOVE AND REPLACE PFCS – TASK DATA (Cont)



FS 16-86 EVA/117/FIN



**PFCS Thermal Cover** 

**PFCS Mating Surfaces** 

FS 16-87 EVA/117/FIN

This Page Intentionally Blank

FS 16-88 EVA/117/FIN


# FLIGHT SPECIFIC EVA REFERENCE

TRUSS SSAS COMPONENTS AT READY-TO-LATCH (RTL) POSITION	FS	18-3
BGA PRIMARY POWER CABLE CLAMPS	FS	18-4
RELEASE BETA GIMBAL LAUNCH RESTRAINTS	FS	18-5
FOUR BAR IN LOCKED POSITION	FS	18-6
SABB UNSTOW	FS	18-7
4-BAR STOWED AND DEPLOYED CONFIGURATIONS	FS	18-10
MAST CANISTER MDA	FS	18-11
SARJ DLA EVA BOLT CONFIG	FS	18-12
P4 UPPER ORU AND CABLE BOX NUMBERS	FS	18-13
P4 LOWER ORU AND CABLE BOX NUMBERS	FS	18-14
P6 UPPER ORU AND CABLE BOX NUMBERS	FS	18-15
P6 LOWER ORU AND CABLE BOX NUMBERS	FS	18-16
PRD USE FOR 4-BAR DEPLOY	FS	18-17
ESP-2 HANDRAILS AND WIFs – ZENITH	FS	18-18
ESP-2 HANDRAILS AND WIFs – NADIR	FS	18-19
CETA CART – TOP VIEW	FS	18-20
CETA SWINGARM AND WIF MARKINGS	FS	18-21
CETA CART COUPLERS	FS	18-22
STATUS INDICATORS (MBSU_DDCU_BCDU)	FS	18-23

This Page Intentionally Blank

# TRUSS SSAS COMPONENTS AT READY-TO-LATCH (RTL) POSITION

Fwd truss face SSAS RTL components (other SSAS RTL components at zenith and nadir edges of truss)




RTL Sensor

Course Alignment Cone


FS 18-3 EVA/117/FIN

#### **BGA PRIMARY POWER CABLE CLAMPS**




FS 18-4 EVA/117/FIN

#### **RELEASE BETA GIMBAL LAUNCH RESTRAINTS**




FS 18-5 EVA/117/FIN

# **FOUR BAR IN LOCKED POSITION**




FS 18-6 EVA/117/FIN

## **SABB UNSTOW**




FS 18-7 EVA/117/FIN


# SABB UNSTOW (Cont)



FS 18-8 EVA/117/FIN

# **SABB UNSTOW** (Cont)






SOLAR ARRAY LOCKING ARMS

FS 18-9 EVA/117/FIN

## **4-BAR STOWED AND DEPLOYED CONFIGURATIONS**




Stowed (Launch Configuration)

Deployed (On-Orbit Configuration)


FS 18-10 EVA/117/FIN

# **MAST CANISTER MDA**






#### SARJ DLA EVA BOLT CONFIG




FS 18-12 EVA/117/FIN

#### P4 UPPER ORU AND CABLE BOX NUMBERS




FS 18-13 EVA/117/FIN

#### P4 LOWER ORU AND CABLE BOX NUMBERS




FS 18-14 EVA/117/FIN

#### P6 UPPER ORU AND CABLE BOX NUMBERS




FS 18-15 EVA/117/FIN

#### P6 LOWER ORU AND CABLE BOX NUMBERS




FS 18-16 EVA/117/FIN

# PRD USE FOR 4-BAR DEPLOY



FS 18-17 EVA/117/FIN

#### **ESP-2 HANDRAILS AND WIFs - ZENITH**




FS 18-18 EVA/117/FIN

# **AIRLOCK** 8000 8031 8024 8025 **BCDU** 8007 (not currently installed) 回 STBD **FHRC** 8022 - 8008 **UTA** SHOSS-ED (not currently installed) 8009 **FWD FRGF** (removed on 114)


FS 18-19 EVA/117/FIN

#### **CETA CART - TOP VIEW**




FS 18-20 EVA/117/FIN

#### **CETA SWINGARM AND WIF MARKINGS**




FS 18-21 EVA/117/FIN

#### **CETA CART COUPLERS**



FS 18-22 EVA/117/FIN

# STATUS INDICATORS (MBSU, DDCU, BCDU)



FS 18-23 EVA/117/FIN

This Page Intentionally Blank



# EVA CHECKLIST

STS 117