

Orbit Operations Checklist


**Mission Operations Directorate
Operations Division**

**Generic, Rev H
January 17, 2002**

NOTE
For STS-109 and subsequent flights

National Aeronautics and
Space Administration

**Lyndon B. Johnson Space Center
Houston, Texas**



JSC-48035

MISSION OPERATIONS DIRECTORATE

ORBIT OPERATIONS CHECKLIST

GENERIC, REVISION H
January 17, 2002

PREPARED BY:

Harold L. Scott
Book Manager

APPROVED BY:

Deborah J. Jackson
Manager,
Shuttle Procedures
Management (USA)

John W. Bearley
FDF Subsystem
Manager (NASA)

This document is under the configuration control of the Crew Procedures Control Board (CPCB). All proposed changes must be submitted on JSC Form 482 to DO3/FDF Manager.

Additional distribution of this book for official use must be requested in writing to DO3/FDF Manager. The request must include justification and requester's name, organization, position, and phone number. Contractor requests are made through the NASA or DOD organization supported. Deletions, reduction in quantity, or change of address may be submitted to DO3/FDF Management Office, 281-244-1184.

ORB OPS/ALL/GEN H

Incorporates the following:	
482#:	ORB OPS-1895 MULTI-1568
	ORB OPS-1896
	ORB OPS-1928
	ORB OPS-1934
	ORB OPS-1935A
	ORB OPS-1936
	ORB OPS-1944
	ORB OPS-1945

AREAS OF TECHNICAL RESPONSIBILITY

Book Manager	DO3/H. Scott	281-483-0670
Alt. Book Manager	DO3/T. Grosko	281-483-3727

ORBIT OPERATIONS CHECKLIST

LIST OF EFFECTIVE PAGES

GENERIC 10/30/87
REV H 01/17/02

Sign Off	*	ALL/GEN H	2-15	ALL/GEN H
ii	*	ALL/GEN H	2-16	ALL/GEN H
iii	*	ALL/GEN H	2-17	ALL/GEN H
iv	*	ALL/GEN H	2-18	ALL/GEN H
v	*	ALL/GEN H	2-19	ALL/GEN H
vi	*	ALL/GEN H	2-20	ALL/GEN H
vii	*	ALL/GEN H	2-21	ALL/GEN H
viii	*	ALL/GEN H	2-22	ALL/GEN H
ix	*	ALL/GEN H	A3-1	ALL/GEN H
x	*	ALL/GEN H	A3-2	MEDS/GEN H
xi		ALL/GEN H	A3-3	MEDS/GEN H
xii		ALL/GEN H	A3-4	MEDS/GEN H
xiii		ALL/GEN H	B3-1	ALL/GEN H
xiv		ALL/GEN H	B3-2	NOM/GEN H
xv		ALL/GEN H	B3-3	NOM/GEN H
xvi		ALL/GEN H	B3-4	NOM/GEN H
1-1		ALL/GEN H	3-5	ALL/GEN H
1-2		ALL/GEN H	3-6	ALL/GEN H
1-3		ALL/GEN H	3-7	ALL/GEN H
1-4		ALL/GEN H	3-8	ALL/GEN H
2-1		ALL/GEN H	A3-9	MEDS/GEN H
2-2		ALL/GEN H	A3-10	ALL/GEN H
2-3		ALL/GEN H	B3-9	NOM/GEN H
2-4		ALL/GEN H	B3-10	ALL/GEN H
2-5		ALL/GEN H	3-11	ALL/GEN H
2-6		ALL/GEN H	3-12	ALL/GEN H
2-7		ALL/GEN H	3-13	ALL/GEN H
2-8		ALL/GEN H	3-14	ALL/GEN H
2-9		ALL/GEN H	3-15	ALL/GEN H
2-10		ALL/GEN H	3-16	ALL/GEN H
A2-11		MEDS/GEN H	3-17	ALL/GEN H
A2-12		ALL/GEN H	3-18	ALL/GEN H
B2-11		NOM/GEN H	3-19	ALL/GEN H
B2-12		ALL/GEN H	3-20	ALL/GEN H
2-13		ALL/GEN H	3-21	ALL/GEN H
2-14		ALL/GEN H	3-22	ALL/GEN H

* – Omit from flight book

3-23	ALL/GEN H	5-25	☒ ALL/GEN H
3-24	ALL/GEN H	5-26	ALL/GEN H
3-25	ALL/GEN H	5-27	ALL/GEN H
3-26	ALL/GEN H	5-28	ALL/GEN H
3-27	ALL/GEN H	5-29	ALL/GEN H
3-28	ALL/GEN H	5-30	☒ ALL/GEN H
3-29	ALL/GEN H	5-31	ALL/GEN H
3-30	ALL/GEN H	5-32	ALL/GEN H
4-1	ALL/GEN H	5-33	ALL/GEN H
4-2	ALL/GEN H	5-34	ALL/GEN H
4-3	ALL/GEN H	5-35	ALL/GEN H
4-4	ALL/GEN H	5-36	ALL/GEN H
4-5	ALL/GEN H	5-37	☒ ALL/GEN H
4-6	ALL/GEN H	5-38	ALL/GEN H
4-7	ALL/GEN H	5-39	☒ ALL/GEN H
4-8	ALL/GEN H	5-40	ALL/GEN H
4-9	ALL/GEN H	5-41	ALL/GEN H
4-10	ALL/GEN H	5-42	ALL/GEN H
5-1	ALL/GEN H	6-1	ALL/GEN H
5-2	ALL/GEN H	6-2	ALL/GEN H
5-3	ALL/GEN H	6-3	ALL/GEN H
5-4	ALL/GEN H	6-4	ALL/GEN H
5-5	ALL/GEN H	6-5	ALL/GEN H
5-6	ALL/GEN H	6-6	ALL/GEN H
5-7	ALL/GEN H	6-7	ALL/GEN H
5-8	ALL/GEN H	6-8	ALL/GEN H
A5-9	MEDS/GEN H	6-9	ALL/GEN H
A5-10	MEDS/GEN H	6-10	ALL/GEN H
B5-9	NOM/GEN H	6-11	ALL/GEN H
B5-10	NOM/GEN H	6-12	ALL/GEN H
5-11	ALL/GEN H	6-13	ALL/GEN H
5-12	ALL/GEN H	6-14	ALL/GEN H
5-13	ALL/GEN H	7-1	ALL/GEN H
5-14	ALL/GEN H	7-2	ALL/GEN H
5-15	ALL/GEN H	7-3	ALL/GEN H
5-16	ALL/GEN H	7-4	ALL/GEN H
5-17	ALL/GEN H	7-5	ALL/GEN H
5-18	ALL/GEN H	7-6	ALL/GEN H
5-19	ALL/GEN H	7-7	ALL/GEN H
5-20	ALL/GEN H	7-8	ALL/GEN H
5-21	ALL/GEN H	7-9	ALL/GEN H
5-22	ALL/GEN H	7-10	ALL/GEN H
5-23	ALL/GEN H	7-11	ALL/GEN H
5-24	ALL/GEN H	7-12	ALL/GEN H

☒ – Prelift-off information required

A7-13	MEDS/GEN H	7-36	ALL/GEN H
A7-14	MEDS/GEN H	A7-37	MEDS/GEN H
A7-15	MEDS/GEN H	A7-38	MEDS/GEN H
A7-16	MEDS/GEN H	A7-39	MEDS/GEN H
A7-17	ALL/GEN H	A7-40	MEDS/GEN H
A7-18	ALL/GEN H	B7-37	NOM/GEN H
A7-19	MEDS/GEN H	B7-38	NOM/GEN H
A7-20	MEDS/GEN H	B7-39	NOM/GEN H
A7-21	MEDS/GEN H	B7-40	NOM/GEN H
A7-22	ALL/GEN H	8-1	ALL/GEN H
A7-23	MEDS/GEN H	8-2	ALL/GEN H
A7-24	MEDS/GEN H	9-1	ALL/GEN H
A7-25	ALL/GEN H	9-2	ALL/GEN H
A7-26	ALL/GEN H	9-3	ALL/GEN H
A7-27	ALL/GEN H	9-4	ALL/GEN H
A7-28	MEDS/GEN H	9-5 (3 pgs)	† ALL/GEN H
A7-29	MEDS/GEN H	9-6 (3 pgs)	† ALL/GEN H
A7-30	MEDS/GEN H	10-1	ALL/GEN H
A7-31	ALL/GEN H	10-2	ALL/GEN H
A7-32	MEDS/GEN H	10-3	ALL/GEN H
B7-13	NOM/GEN H	10-4	ALL/GEN H
B7-14	NOM/GEN H	10-5	ALL/GEN H
B7-15	ALL/GEN H	10-6	ALL/GEN H
B7-16	NOM/GEN H	10-7	ALL/GEN H
B7-17	ALL/GEN H	10-8	ALL/GEN H
B7-18	ALL/GEN H	10-9	ALL/GEN H
B7-19	NOM/GEN H	10-10	ALL/GEN H
B7-20	NOM/GEN H	10-11	ALL/GEN H
B7-21	NOM/GEN H	10-12	ALL/GEN H
B7-22	ALL/GEN H	10-13	ALL/GEN H
B7-23	NOM/GEN H	10-14	ALL/GEN H
B7-24	ALL/GEN H	10-15	ALL/GEN H
B7-25	ALL/GEN H	10-16	ALL/GEN H
B7-26	ALL/GEN H	10-17	ALL/GEN H
B7-27	ALL/GEN H	10-18	ALL/GEN H
B7-28	ALL/GEN H	10-19	ALL/GEN H
B7-29	NOM/GEN H	10-20	ALL/GEN H
B7-30	NOM/GEN H	10-21 (4 pgs) ...	† ALL/GEN H
B7-31	NOM/GEN H	10-22 (4 pgs) ...	† ALL/GEN H
B7-32	NOM/GEN H	11-1	ALL/GEN H
7-33	ALL/GEN H	11-2	ALL/GEN H
7-34	ALL/GEN H	11-3	ALL/GEN H
7-35	ALL/GEN H	11-4	ALL/GEN H

† – Extra pages in crew copy only

12-1	ALL/GEN H	12-45	ALL/GEN H
12-2	ALL/GEN H	12-46	<input checked="" type="checkbox"/> ALL/GEN H
12-3	ALL/GEN H	12-47	ALL/GEN H
12-4	ALL/GEN H	12-48	ALL/GEN H
12-5	ALL/GEN H	12-49	ALL/GEN H
12-6	ALL/GEN H	12-50	ALL/GEN H
12-7	ALL/GEN H	12-51	ALL/GEN H
12-8	ALL/GEN H	12-52	ALL/GEN H
12-9	ALL/GEN H	12-53	ALL/GEN H
12-10	ALL/GEN H	12-54	ALL/GEN H
12-11	ALL/GEN H	12-55	ALL/GEN H
12-12	<input checked="" type="checkbox"/> ALL/GEN H	12-56	ALL/GEN H
12-13	ALL/GEN H	12-57	ALL/GEN H
12-14	ALL/GEN H	12-58	ALL/GEN H
12-15	ALL/GEN H	12-59	ALL/GEN H
12-16	ALL/GEN H	12-60	ALL/GEN H
12-17	ALL/GEN H	12-61	ALL/GEN H
12-18	ALL/GEN H	12-62	ALL/GEN H
12-19	ALL/GEN H	12-63	ALL/GEN H
12-20	ALL/GEN H	12-64	ALL/GEN H
12-21	ALL/GEN H	12-65	ALL/GEN H
12-22	ALL/GEN H	12-66	ALL/GEN H
12-23	ALL/GEN H	12-67	ALL/GEN H
12-24	ALL/GEN H	12-68	ALL/GEN H
12-25	ALL/GEN H	12-69	ALL/GEN H
12-26	ALL/GEN H	12-70	ALL/GEN H
12-27	ALL/GEN H	12-71	ALL/GEN H
12-28	ALL/GEN H	12-72	ALL/GEN H
12-29	ALL/GEN H	12-73	ALL/GEN H
12-30	ALL/GEN H	12-74	ALL/GEN H
12-31	ALL/GEN H	12-75	ALL/GEN H
12-32	ALL/GEN H	12-76	ALL/GEN H
12-33	ALL/GEN H	12-77	ALL/GEN H
12-34	ALL/GEN H	12-78	ALL/GEN H
12-35	ALL/GEN H	13-1	ALL/GEN H
12-36	ALL/GEN H	13-2	<input checked="" type="checkbox"/> ALL/GEN H
12-37	ALL/GEN H	13-3	ALL/GEN H
12-38	ALL/GEN H	13-4	<input checked="" type="checkbox"/> ALL/GEN H
12-39	ALL/GEN H	13-5	<input checked="" type="checkbox"/> ALL/GEN H
12-40	ALL/GEN H	13-6	<input checked="" type="checkbox"/> ALL/GEN H
12-41	ALL/GEN H	13-7	<input checked="" type="checkbox"/> ALL/GEN H
12-42	ALL/GEN H	13-8	<input checked="" type="checkbox"/> ALL/GEN H
12-43	ALL/GEN H	13-9	ALL/GEN H
12-44	ALL/GEN H	13-10	<input checked="" type="checkbox"/> ALL/GEN H

– Prelift-off information required

13-11	ALL/GEN H	CC 15-30	* ALL/GEN H
13-12	<input checked="" type="checkbox"/> ALL/GEN H	CC 15-31	* ALL/GEN H
13-13	ALL/GEN H	CC 15-32	* ALL/GEN H
13-14	ALL/GEN H	CC 15-33	* ALL/GEN H
13-15	ALL/GEN H	CC 15-34	* ALL/GEN H
13-16	ALL/GEN H	CC 15-35	* ALL/GEN H
13-17	ALL/GEN H	CC 15-36	* ALL/GEN H
13-18	ALL/GEN H	CC 15-37	* ALL/GEN H
14-1	ALL/GEN H	CC 15-38	* ALL/GEN H
14-2	ALL/GEN H	CC 15-39	* ALL/GEN H
14-3	ALL/GEN H	CC 15-40	* ALL/GEN H
14-4	ALL/GEN H	CC 15-41	* ALL/GEN H
15-1	* ALL/GEN H	CC 15-42	* ALL/GEN H
CC 15-2	* ALL/GEN H		
CC A15-3	* ALL/GEN H		
CC A15-4	* MEDS/GEN H		
CC B15-3	* ALL/GEN H		
CC B15-4	* NOM/GEN H		
CC 15-5	* ALL/GEN H		
CC 15-6	* ALL/GEN H		
CC 15-7	* ALL/GEN H		
CC 15-8	* ALL/GEN H		
CC 15-9	* ALL/GEN H		
CC 15-10	* ALL/GEN H		
CC 15-11	* ALL/GEN H		
CC 15-12	* ALL/GEN H		
CC 15-13	* ALL/GEN H		
CC 15-14	* ALL/GEN H		
CC 15-15	* ALL/GEN H		
CC 15-16	* ALL/GEN H		
CC 15-17	* ALL/GEN H		
CC 15-18	* ALL/GEN H		
CC 15-19	* ALL/GEN H		
CC 15-20	* ALL/GEN H		
CC 15-21	* ALL/GEN H		
CC 15-22	* ALL/GEN H		
CC 15-23	* ALL/GEN H		
CC 15-24	* ALL/GEN H		
CC 15-25	* ALL/GEN H		
CC 15-26	* ALL/GEN H		
CC 15-27	* ALL/GEN H		
CC 15-28	* ALL/GEN H		
CC 15-29	* ALL/GEN H		

– Prelift-off information required
 * – Omit from flight book

This Page Intentionally Blank

ORBIT OPS CUE CARDS

<u>Title</u>	<u>Ref. Page</u>	<u>Card No.</u>
WCCS COMM Plan		
(Front)	CC 15-2	ORB OPS-1a/O/A
(Back)	CC A15-3	ORB OPS-1b/O/A
Orbit Spec (R11)	CC A15-4	ORB OPS-2a/MEDS/O/F
(Back)	CC B15-3	ORB OPS-1b/O/A
Orbit Spec (R11)	CC B15-4	ORB OPS-35a/NOM/O/A
Primary C/W Parameter		
Matrix (Back of Orbit		
Spec (R11)).....	CC 15-5	ORB OPS-2b/O/B
KU Antenna Overlay		
(B&W Monitor)	CC 15-6	ORB OPS-3a/O/B
(Color Monitor)	CC 15-7	ORB OPS-4a/O/A
Urine Collection		
(w/o UMS) (Front)	CC 15-8	ORB OPS-5a/O/G
CONT Waste Collection –		
UCD/Apollo Bag (Back of		
Urine Collection		
(w/o UMS))	CC 15-9	ORB OPS-5b/O/F
Urine Collection (w/UMS)		
(Front)	CC 15-10	ORB OPS-6a/O/H
UMS CONT Waste		
Collection – UCD/		
Apollo Bag (Back of		
Urine Collection		
(w/UMS))	CC 15-11	ORB OPS-6b/O/G
EDO WCS Urine/Feces		
Collection		
(Front)	CC 15-12	ORB OPS-7a/O/C
(Back)	CC 15-13	ORB OPS-7b/O/C
EDO WCS Manual		
Compaction		
(Front)	CC 15-14	ORB OPS-8a/O/A
(Back)	CC 15-15	ORB OPS-8b/O/A
Photo Grid Overlay	CC 15-16	ORB OPS-9a/O/A

ORBIT OPS CUE CARDS

<u>Title</u>	<u>Ref. Page</u>	<u>Card No.</u>
Dual Shift Orbiter CO2		
Absorber Replacement		
(Front)	CC 15-17	ORB OPS-11a/NON-RCRS/A
(Back)	CC 15-18	ORB OPS-11b/NON-RCRS/A
(Front)	CC 15-19	ORB OPS-12a/NON-RCRS/A
(Back)	CC 15-20	ORB OPS-12b/NON-RCRS/A
(Front)	CC 15-21	ORB OPS-13a/NON-RCRS/A
(Back)	CC 15-22	ORB OPS-13b/NON-RCRS/A
(Front)	CC 15-23	ORB OPS-14a/NON-RCRS/A
(Back)	CC 15-24	ORB OPS-14b/NON-RCRS/A
(Front)	CC 15-25	ORB OPS-15a/NON-RCRS/A
(Back)	CC 15-26	ORB OPS-15b/NON-RCRS/A
(Front)	CC 15-27	ORB OPS-16a/NON-RCRS/A
(Back)	CC 15-28	ORB OPS-16b/NON-RCRS/A
(Front)	CC 15-29	ORB OPS-17a/NON-RCRS/A
(Back)	CC 15-30	ORB OPS-17b/NON-RCRS/A
(Front)	CC 15-31	ORB OPS-18a/NON-RCRS/A
(Back)	CC 15-32	ORB OPS-18b/NON-RCRS/A
Single Shift Orbiter CO2		
Absorber Replacement		
(Front)	CC 15-33	ORB OPS-19a/NON-RCRS/A
(Back)	CC 15-34	ORB OPS-19b/NON-RCRS/A
(Front)	CC 15-35	ORB OPS-20a/NON-RCRS/A
(Back)	CC 15-36	ORB OPS-20b/NON-RCRS/A
(Front)	CC 15-37	ORB OPS-21a/NON-RCRS/A
(Back)	CC 15-38	ORB OPS-21b/NON-RCRS/A
(Front)	CC 15-39	ORB OPS-22a/NON-RCRS/A
(Back)	CC 15-40	ORB OPS-22b/NON-RCRS/A
Urine Pretreat		
Changeout		
(Front)	CC 15-41	ORB OPS-23a/O/C
(Back)	CC 15-42	ORB OPS-23b/O/C

x

ORB OPS/ALL/GEN H

<u>CONTENTS</u>	<u>PAGE</u>
<u>APU/HYDRAULICS</u>	1-1
APU HEATER RECONFIG	1-2
HYD ISOL VALVE REPOSITIONING	1-3
MANUAL CIRC PUMP 2 OPS	1-4
3 OPS	1-4
<u>COMM/INST</u>	2-1
KU-BD ANT DEPLOY	2-2
ACTIVATION	2-3
ANT STOW (CIL)	2-5
MANUAL ACQUISITION (COMM)	2-7
ANT JETTISON	2-8
PRE-SLEEP AUD CONFIG	2-11
POST-SLEEP AUD CONFIG	2-13
STD VLHS/HIU CONFIG (NO SPEAKER)	2-14
S-BD/KU-BD PNL CONFIG	2-15
HANDHELD MIC/SPEAKER CONFIG	2-16
WCCS CONFIG	2-17
ICOM RECORDER OPS	2-18
LANDING-1 COMM C/O	2-19
COMM STRING 1 C/O	
(PART A: COMMAND TO STRING 1)	2-21
COMM STRING 1 C/O	
(PART B: RETURN TO STRING 2)	2-22
<u>CREW SYSTEMS</u>	3-1
PRE-SLEEP ACTIVITY	
(RCS Config, step 13-CIL)	3-2
POST-SLEEP ACTIVITY	3-7
OCAC SETUP	3-11
STOWAGE	3-12
MAL	3-13
LiOH VOLUME INFLIGHT RECONFIG	3-14
TISSUE EQUIVALENT PROPORTIONAL	
COUNTER (TEPC)	3-16
TEPC DISPLAY LOGSHEET	3-22
CYCLE ERGOMETER OPS	3-23
<u>DPS</u>	4-1
G2 SET CONTRACTION	4-2
EXPANSION	4-4
TO G8 TRANSITION	4-6
G8 TO G2 TRANSITION	4-7

SM CHECKPOINT INITIATE	4-9
<u>ECLS</u>	5-1
SUPPLY/WASTE WATER DUMP	5-2
SUPPLY WATER DUMP USING FES	5-9
CABIN TEMP CONTROL	5-10
CO2 RMVL SYS CNTLR CONFIG:	
ACT 1/DEACT 2 (ACT 2/DEACT 1)	5-11
RAD BYPASS/FES C/O	5-12
MODIFIED RAD BYP/FES C/O AND TOPPING	
CORE FLUSH	5-13
RAD DEPLOY	5-15
STOW	5-17
PCS 1(2) CONFIG	5-19
TOPPING FES DEACTIVATION	5-20
FES STARTUP	5-21
SMOKE DETN CKT TEST	5-22
SHUTTLE/ISS H2O CONTAINER FILL	5-25
CWC OVERBOARD DUMP	5-32
CABIN TEMP CONTROLLER	
RECONFIG – 2(1)	5-35
SHUTTLE CONDENSATE COLLECTION	5-36
PWR OVERBOARD DUMP	5-37
EMU WATER RECHARGE BAG FILL	5-40
<u>EPS</u>	6-1
LAMP TEST	6-2
HEATER RECONFIG – CONFIG B(CONFIG A)	6-5
FUEL CELL PURGE – AUTO, SM 2(4)	
– MANUAL	6-6
VI PERFORMANCE PLOT	6-7
CRYO O2 TK HTR SNSR CK	6-8
EDO PALLET CRYO O2 TK HTR SNSR CK ..	6-9
ACTIVATION	6-11
DEACT	6-12
<u>GNC</u>	6-13
IMU ALIGN – S TRK, GNC 201,202,301	7-1
ALIGNMENT – IMU/IMU	7-2
S TRK SELF-TEST, GNC 201,202,301	7-4
IMU STAR OF OPPORTUNITY ALIGN	7-5
COAS CALIBRATION, GNC 201	7-6
HUD CALIBRATION, GNC 201	7-7
BORESIGHT DESIGNATION	7-9
FCS CHECKOUT	7-12
	7-13

AFT CONTROLLER C/O	7-33
OMICRON SPECIFICATION	7-35
ELEVON PARK, GNC 201	7-36
GPS PWRUP	7-37
PWRDN	7-38
SELF-TEST, GNC 201,202,301,801	7-39
<u>MPS</u>	8-1
MPS VACUUM INERT	8-2
<u>OMS</u>	9-1
ON-ORBIT OMS BURN	9-2
<u>RCS</u>	10-1
RCS HOT FIRE TEST	10-2
GG FREE DRIFT	10-6
PRCS PTC	10-8
VRCS PTC	10-9
ON-ORBIT +X RCS BURN, MM202	10-10
-X RCS BURN, MM202	10-13
MULTI-AXIS RCS BURN, MM202	10-15
LOSS OF VERNIERS	10-18
RECOVERY OF VERNIERS	10-19
RCS REGULATOR RECONFIG	10-20
<u>SEP MANEUVER</u>	11-1
SEP MANEUVER	11-2
<u>PGSC</u>	12-1
PGSC ACT	12-3
OCA, PROSHARE, AND PCMMU EXPANSION CARDS	12-8
PGSC HARD DISK LATE UPDATE	12-9
OCA SETUP	12-11
CABLE DIAGRAM	12-16
DOWNLINK VIA GROUND CMD	12-17
DIRECTORY STRUCTURE	12-18
FILENAMES	12-19
KU-BAND (KFX) MANUAL DOWNLINK	12-20
S-BAND MODEM (MFX) ACTIVATION	12-21
VIDEO CONFERENCING	12-23
PROSHARE CHALKBOARD	12-25
APPLICATION SHARING	12-26

REMOTE PAN/TILT/ZOOM CONTROL OF GROUND CAMERA (KCA CAMERA CNTL)	12-27
OCA LOOPBACK TEST	12-28
CABLE DIAGRAM – LOOPBACK	12-29
PGSC NETWORK	12-30
NETWORK SETUP DIAGRAM	12-35
PCMCIA CARD REMOVAL	12-36
WINDECOM OPS	12-37
SETTING TIMES AND STATE VECTOR	12-42
WORLD MAP INITIALIZATION	12-44
COLOR PRINTER UNSTOW AND ASSEMBLE	12-46
WARMUP AND SELF-TEST	12-49
STOW	12-50
CHECK COLOR PRINTER SETTINGS	12-51
COLOR PRINTER PAPER JAM	12-51
INK CARTRIDGE CHANGEOUT	12-52
CLEANING PRINTER HEADS	12-54
PRINTER HEAD ALIGNMENT	12-55
EXECUTE PACKAGE PRINTING	12-56
PILOT WITH RHC	12-57
RHC SETUP DIAGRAM	12-61
WITHOUT RHC	12-62
UPDATING SpOC APPLICATIONS USING	
OCA DATA DISKETTE (ODD)	12-64
PCANYWHERE ACT/DEACT	12-65
PGSC HARD DISK SWAP	12-66
SWAP ON EXPANSION UNIT	12-67
DEACT	12-68
WINDOWS KEYBOARD REF	12-69
WORLD MAP KEYBOARD REF	12-73
GRAFTRAK KEYBOARD REF	12-74
STARS KEYBOARD REF	12-75
POC STATE VECTOR PADS	12-77
RELOAD STS PGSC	12-78

<u>COMPOUND SPECIFIC ANALYZER – COMBUSTION PRODUCTS (CSA-CP)</u>	13-1
COMPOUND SPECIFIC ANALYZER – COMBUSTION PRODUCTS CHECKOUT AND ZERO CALIBRATION OPS	13-2
PASSIVE SAMPLING WITH DATA LOGGING ..	13-5
ACTIVE SAMPLING WITH PUMP AND DATA LOGGING	13-7
CSA-CP BATTERY CHANGEOUT	13-9

SAMPLING PUMP BATTERY CHANGEOUT ..	13-11
ZERO CALIBRATION	13-12
DATA LOGGER ACTIVATION/DEACTIVATION ..	13-15
ALARM DISABLE/ENABLE	13-16
DATA RECORDING TABLE	13-17
<u>SHUTTLE AUDIO DOSIMETER</u>	14-1
ACTIVATION	14-2
SOUND LEVEL METER (SLM) MODE	14-2
Lavg/Leq MODE	14-3
DEACTIVATION	14-4
<u>CUE CARD CONFIGURATION</u>	15-1

This Page Intentionally Blank

APU/HYDRAULICS

APU HEATER RECONFIG	1-2
HYD ISOL VALVE REPOSITIONING	1-3
MANUAL CIRC PUMP 2 OPS	1-4
3 OPS	1-4

**APU/
HYD**

**APU/
HYD**

APU HEATER RECONFIG

A12

APU HTR GAS GEN/FUEL PUMP (three) – B AUTO
LUBE OIL LINE (three) – B AUTO
TK/FU LINE/H2O SYS 1B,2B,3B – AUTO
1A,2A,3A – OFF

1-2

ORB OPS/ALL/GEN H

HYD ISOL VALVE REPOSITIONING

SM 87 HYD THERMAL

NOTE

LG EXTEND ISOL VLV should
not be opened on orbit

CAUTION

If CIRC PUMP P (HYD PRESS)
< 100 psia 30 sec after pump on,
CIRC PUMP – OFF

If Spacelab and HYD System 2:

- R1 MN BUS TIE A – ON
 B – OFF
- R2 HYD CIRC PUMP 2 – ON
 Wait 10 sec
- R4 HYD BRAKE ISOL VLV 2 – OP(CL)
 Hold 5 sec, \sqrt{tb} – OP(CL)
- R2 HYD CIRC PUMP 2 – GPC
- R1 MN BUS TIE B – ON
 A – OFF

- R2 HYD CIRC PUMP X – ON
 Wait 10 sec
- R4 HYD BRAKE ISOL VLV X – OP(CL)
 Hold 5 sec, \sqrt{tb} – OP(CL)
 or
 HYD MPS/TVC ISOL VLV X – OP(CL)
 Hold 5 sec, \sqrt{tb} – OP(CL)
- R2 HYD CIRC PUMP X – GPC

MANUAL CIRC PUMP 2 OPS

R1	MN BUS TIE A – ON B – OFF
R2	HYD CIRC PUMP 2 – ON Wait 30 min
R1	MN BUS TIE B – ON A – OFF

MANUAL CIRC PUMP 3 OPS

R1	MN BUS TIE B – ON A – OFF
R2	HYD CIRC PUMP 3 – ON Wait 30 min – GPC
R1	MN BUS TIE A – ON B – OFF

COMM/INST

KU-BD ANT DEPLOY	2-2
ACTIVATION	2-3
ANT STOW (CIL)	2-5
MANUAL ACQUISITION (COMM)	2-7
ANT JETTISON	2-8
PRE-SLEEP AUD CONFIG	2-11
POST-SLEEP AUD CONFIG	2-13
STD VLHS/HIU CONFIG (NO SPEAKER)	2-14
S-BD/KU-BD PNL CONFIG	2-15
HANDHELD MIC/SPEAKER CONFIG	2-16
WCCS CONFIG	2-17
ICOM RECORDER OPS	2-18
LANDING-1 COMM C/O	2-19
COMM STRING 1 C/O (PART A: COMMAND TO STRING 1)	2-21
COMM STRING 1 C/O (PART B: RETURN TO STRING 2)	2-22

COMM/
INST

**COMM
INST**

KU-BD ANT DEPLOY

A1U ✓KU PWR – OFF
 CNTL – PNL
R13L ✓ANT DIRECT STO – OFF

PL BAY MECH PWR SYS 1,2 (two) – ON
KU ANT – DPY

- * If tb not DPY after 46 sec, *
- * KU ANT – GND *
- * Perform MAL, MECH, 9.3a *

When KU ANT tb – DPY (~23 to 46 sec),
KU ANT – GND

PL BAY MECH PWR SYS 1,2 (two) – OFF

KU-BD ACTIVATION

R15:C cb MNB KU ELEC – cl
 ✓ANT HTR – cl
 ✓CABLE HTR – op
 MNC KU SIG PROC – cl

A1U ✓SIG STRENGTH sel – KU
 ✓SLEW RATE – SLOW
 ✓KU SCAN WARN tb – bp
 ✓TRACK tb – bp
 ✓SEARCH tb – bp
 ✓sel – MAN SLEW
 ✓RADAR OUTPUT – HI
 ✓SIG PROC HDR – TV
 ✓LDR – OPS RCDR
 MODE – RDR PASSIVE
 PWR – ON
 ✓CNTL – PNL

CRT **SM ANTENNA**
I/O RESET KU – ITEM 8 EXEC (*)

NOTE

System warmup takes ~4 min

A2 DIGI-DIS SEL – EL/AZ
✓R/EL ind: +000.0
✓R/AZM ind: +000.0

DIGI-DIS SEL – R/R

CRT When warmup complete,
 SELF TEST – ITEM 7 EXEC (*)

A1U When SELF TEST complete (~3 min):
 ✓KU SCAN WARN tb – gray
 ✓TRACK tb – gray
 ✓SEARCH tb – gray

A2 ✓R/EL ind: +888.8
If R/EL ind: +333.3, ✓MCC

Cont next page

CRT SELF TEST – ITEM 7 EXEC (no *)

A1U KU MODE – COMM
 KU – GPC DESIG
 KU CNTL – CMD

KU-BD ANT STOW

R13L ✓PL BAY MECH PWR SYS 1,2 (two) – OFF
 ✓KU CNTL – CMD
A1U KU PWR – ON
 MODE – RDR PASSIVE
 CNTL – PNL
 sel – MAN SLEW
A2 ✓DIGI-DIS SEL – EL/AZ
A1U SLEW RATE – as reqd

 SLEW ELEV – as reqd:
A2 R/EL ind: –27.0 ($\pm 1^\circ$)

A1U SLEW AZM – as reqd:
A2 R/AZM ind: –123.0 ($\pm 1^\circ$)

LOCK GIMBALS

NOTE

KU ANT sw must remain in STOW until
STOW DEPLOYED ASSEMBLY complete

DAP: VERN(FREE)

R13L KU ANT – STOW

A2 ✓R/EL ind: –29.0 ($\pm 1^\circ$)
 ✓R/AZM ind: –125.0 ($\pm 1^\circ$)

00:00 Start Event Timer
A2 Monitor KU ANT gimbal angles for 50 sec
(gimbal lock test), then:

 * If KU ANT gimbal movement occurs *
 * within 50 sec, and/or if gimbal *
 * angles incorrect after 50 sec, *
 * perform MAL, MECH, 9.3c *

DAP: as reqd

Cont next page

STOW DEPLOYED ASSEMBLY

R13L PL BAY MECH PWR SYS 1,2 (two) – ON
✓ KU ANT tb – STO (~23 to 46 sec)

* If tb not STO after 46 sec, *
* perform MAL, MECH, 9.3b *

A1U KU PWR – OFF (Expect 'BCE BYP KU')
R15:C cb MNB KU ELEC – op
 MNC KU SIG PROC – op

R13L PL BAY MECH PWR SYS 1,2 (two) – OFF
KU ANT – GND

OCA If not in D/O Prep,
 go to OCA S-BAND MODEM (MFX)
 ACTIVATION (PGSC)

KU-BD MANUAL ACQUISITION (COMM)

1. SETUP

A2	✓DIGI-DIS SEL	- EL/AZ
A1U	KU sel	- AUTO TRACK
	✓PWR	- ON
	MODE	- COMM
	✓SIG PROC HDR	- TV
	✓LDR	- OPS RCDR
	CNTL	- PNL
	✓SIG STRENGTH sel	- KU
	SLEW RATE	- as reqd
	✓KU SCAN WARN tb	- bp
	✓TRACK tb	- bp
	✓SEARCH tb	- bp

2. ANTENNA STEERING

NOTE

ANT will not LOCK/TRACK
when slewing in FAST RATE

SM ANTENNA

A1U,CRT,
A2 Use SLEW AZM and SLEW ELEV sw as reqd to
position antenna, until ANT EL,AZ angles on pnl
A2 are within 5° of ANT EL,AZ CMD angles on
CRT

A1U KU SEARCH - SEARCH
 ✓tb - gray
When SIG STRENGTH > 1.0 and
KU TRACK tb - gray (< 3 min),
✓KU SCAN WARN tb - bp
✓SEARCH tb - bp

- * If no track in 3 min, *
- * repeat step 2 once *
- * If still no track, ✓MCC *

KU CNTL - CMD

KU-BD ANT JETTISON

NOTE

Jettison between sunrise
and noon if possible

AUTO MNVR TO -XLV

GNC UNIV PTG

- ✓START TIME at least 15 min prior to sunrise
- ✓TGT ID: +2
- BODY VECT: +2
- OM: +0
- START TRK – ITEM 19 EXEC (CUR – *)
- A6U DAP: A/AUTO/VERN

CONFIGURE KU FOR JETTISON

- A1U ✓KU PWR – OFF
- R15 CNTL – PNL
- cb MNB KU ELEC – op
- ANT HTR – op
- CABLE HTR – op
- MNC KU SIG PROC – op
- A14 ✓ANT ARM – SAFE
- ✓JETT – SAFE
- MA73C:A MCA LOGIC MNC MID 2 – OFF
- :B MNB MID 4 – OFF
- ML86B:D cb MNA PYRO JETT SYS A KU ANT – cl
- MNC PYRO JETT SYS B KU ANT – cl

CONFIGURE CCTVs TO MONITOR JETTISON

Perform ACTIVATION (Cue Cards, TV, 8mm VTR)

- CCTV MON 1 – A
- 2 – B
- Point CCTVs as reqd
- Put new tape in VTR
- A7U ✓Lighting – as reqd

Cont next page

A6U FLT CNTLR PWR – ON

✓ In jettison att
DAP TRANS: PULSE/PULSE/PULSE

If VERN jets avail:
| DAP: A1/INRTL/VERN
If VERN jets not avail:
| DAP: B1/INRTL/PRI

Wait until rates damped, then:
DAP: A1/FREE/PRI
✓ SENSE – as reqd
VTR – PLAY/RCD/RUN

NOTE

After JETT, initiate opening rate ASAP. Minimize other THC/RHC inputs

A14 PYRO KU ANT ARM – ARM

Wait 1 sec, then:
PYRO KU ANT JETT – JETT

INITIAL SEP MNVR (IMMEDIATELY AFTER JETT)
DAP: A/INRTL/PRI

THC: +Z, 12 pulses (~1 fps)
(-X sense: THC dn)
(-Z sense: THC out)

SECOND SEP BURN (JETT +2:00 MIN)
SENSE – as reqd

THC: +Z, 12 pulses (~1 fps)
(-X sense: THC dn)
(-Z sense: THC out)

Cont next page

Maintain visual contact with KU ANT in OVHD window using RHC
When KU ANT no longer visible, then:

R12L CLEANUP
VTR pb – STOP

GNC UNIV PTG
✓TGT ID: +2
BODY VECT: +3
✓OM: +0
START TRK - ITEM 19 EXEC (CUR - *)

DAP: A1/AUTO/VERN
FLT CNTLR PWR - OFF

A7U ✓Lighting – as reqd

A14 PYRO KU ANT JETT - SAFE
ARM - SAFE

ML86B:D cb MNA PYRO JETT SYS A KU ANT – op
 MNC PYRO JETT SYS B KU ANT – op
MA73C:A MCA LOGIC MNC MID 2 – ON
 :B MNB MID 4 – ON

PRE-SLEEP AUD CONFIG

✓XX AUD PWR	– AUD
A/G 2	– T/R
All other LOOPS	– OFF
XX AUD XMIT/ICOM MODE	– PTT/PTT

O6 ✓UHF MODE SEL – OFF

FLIGHT DECK/MIDDECK AUD CONFIG

Perform STD HANDHELD MIC/SPEAKER
CONFIG, 2–16, then:

MO42F **SPKR BOX CHECKOUT**
MIDDECK SPKR AUD PWR – AUD
Set off alert tone and adjust Bypass Tone volume
as reqd
IDP/CRT PWR – OFF,ON

MIDDECK SPKR AUD PWR – OFF
Perform comm check with GND using flt deck
handheld mic
MIDDECK SPKR AUD PWR – AUD/TONE

A13 OS AUD SPKR PWR – OFF
Perform comm check with GND using middeck
handheld mic
OS AUD SPKR PWR – SPKR

NOTE

If during sleep period, SM ALERT
annunciated with no fault msg, MCC has
no cmd capability. ✓MCC. If no joy, go
to COMM LOST (ORB PKT, COMM)

MEDS

A2-11 ORB OPS/MEDS/GEN H

This Page Intentionally Blank

A2-12

ORB OPS/ALL/GEN H

PRE-SLEEP AUD CONFIG

✓XX AUD PWR	– AUD
A/G 2	– T/R
All other LOOPS	– OFF
XX AUD XMIT/ICOM MODE	– PTT/PTT

O6 ✓UHF MODE SEL – OFF

FLIGHT DECK/MIDDECK AUD CONFIG

Perform STD HANDHELD MIC/SPEAKER
CONFIG, 2–16, then:

MO42F **SPKR BOX CHECKOUT**
MIDDECK SPKR AUD PWR – AUD
Set off alert tone and adjust Bypass Tone volume
as reqd
CRT PWR – STBY,ON

MIDDECK SPKR AUD PWR – OFF
Perform comm check with GND using flt deck
handheld mic
MIDDECK SPKR AUD PWR – AUD/TONE

A13 OS AUD SPKR PWR – OFF
Perform comm check with GND using middeck
handheld mic
OS AUD SPKR PWR – SPKR

NOTE

If during sleep period, SM ALERT
annunciated with no fault msg, MCC has
no cmd capability. ✓MCC. If no joy, go
to COMM LOST (ORB PKT, COMM)

NOM

B2-11 ORB OPS/NOM/GEN H

This Page Intentionally Blank

B2-12

ORB OPS/ALL/GEN H

POST-SLEEP AUD CONFIG

If handheld mic/speaker operation:

Perform STD HANDHELD MIC/SPEAKER
CONFIG, 2-16

If VLHS/HIU operation:

Perform STD VLHS/HIU CONFIG
(NO SPEAKER)

If WCCS operation:

NOTE

More than one crewmember per
WCCS channel will cause
intermittent loss of comm. Turn
unused WCCS leg units OFF

Perform STD VLHS/HIU CONFIG
(NO SPEAKER)

STD VLHS/HIU CONFIG (NO SPEAKER)

XX	XX AUD PWR	- AUD/TONE
	A/G 1	- T/R, tw - 2
	A/G 2	- RCV, tw - 2
	A/A	- RCV, tw - 2
	ICOM A,B (two)	- T/R, tw - 2
	XMIT/ICOM MODE	- PTT/PTT
XX	CCU PWR	- ON
A13	OS AUD SPKR PWR	- OFF
	MSTR SPKR VOL	- MIN
MO42F	MIDDECK AUD TONES	- ACCU/BYP
	SPKR PWR	- OFF
	MSTR SPKR VOL	- MIN

NOTE

Unused audio loops either RCV or OFF.
Unused VLHS comm systems either
disconnected or CCU PWR – OFF and
HIU VOL – 0

STD S-BD/KU-BD PNL CONFIG

If configuring for TDRS KU-BD:

Prior to configuring A1L/C3:

If KU in radar:

✓KU PWR – ON

Perform KU OPS, step 4 (Cue Card,
RNDZ), then:

KU CNTL – PNL,CMD

NOTE

KU-BD may take up to 3 min to
complete search and acquire TDRS

If KU TRACK tb – bp

Perform KU-BD MANUAL
ACQUISITION, 2–7, then:

		IF STDN(SGLS)	IF TDRS	IF TDRS
		S-BD	S-BD	KU-BD
A1L	NSP DATA RATE XMIT	– HI	HI	HI
	RCV	– HI	HI	HI
	UPLK DATA	– S-BD	S-BD	KU
	CODING XMIT	– OFF	ON	ON
	RCV	– OFF	ON	OFF
	S-BD PM MODE	– STDN LO (SGLS)	TDRS DATA	—
C3	S-BD PM CNTL	– PNL, CMD	PNL, CMD	PNL, CMD

NOTE

If S-BD mode TDRS or STDN HI,
xmit may be delayed 3 min for PA
warmup. Receive not affected

STD HANDHELD MIC/SPEAKER CONFIG

NOTE

For PRE-SLEEP AUD CONFIG,
MS(OS*) A/G 2, and MIDDECK
SPKR AUD A/G 2 switches should
remain off. '*' indicates OV102

FLIGHT DECK CONFIG

R10(A13*)	MS(OS*) AUD PWR	- AUD/TONE
	A/G 1	- T/R, tw - 2
	2	- RCV, tw - 2
	A/A	- RCV, tw - 2
	ICOM A,B (two)	- RCV, tw - 2
	XMIT/ICOM MODE	- PTT/PTT
A13	OS AUD SPKR PWR	- SPKR
	MSTR SPKR VOL sel	- 8
A11	MS(OS*) COMM CCU PWR	- ON
	All WCCS leg units	- off

MIDDECK CONFIG

MO42F	MIDDECK SPKR AUD	
	A/G 1	- T/R, tw - 2
	2	- RCV, tw - 2
	A/A	- RCV, tw - 2
	ICOM A,B (two)	- RCV, tw - 2
	XMIT/ICOM MODE	- PTT/PTT
	SPKR PWR	- SPKR
	MSTR SPKR VOL sel	- 8
MO39M	MIDDECK COMM CCU PWR	- ON
	All WCCS leg units	- off

STD WCCS CONFIG

ACTIVATION

Unstow and assemble WCCS leg units

XX	XX AUD PWR	- AUD/TONE
	A/G 1	- T/R, tw - 5
	A/G 2	- RCV, tw - 2
	A/A	- RCV, tw - 5
	ICOM A	- T/R, tw - 5
	B	- OFF, tw - 5
	XX AUD XMIT/ICOM MODE	- PTT/PTT
A13	OS AUD SPKR PWR	- OFF
	MSTR SPKR VOL sel	- MIN
MO42F	MIDDECK AUD SPKR PWR	- OFF
	MSTR SPKR VOL	- MIN
XX	XX CCU PWR	- OFF
	Connect AIU cables to CCU outlets	
	XX CCU PWR	- ON
AIU	MODE SEL	- as reqd
	Green pwr lt	- ON
CRU	CHNL	- Designated chnl (see Cue Card, <u>WCCS COMM PLAN</u>)
	VOLUME	- as reqd

NOTE

If WCCS used in config with Spkr Units, adjust spkr volume as reqd to prevent squeals

DEACTIVATION

AIU	MODE SEL	- OFF
	Green pwr lt	- OFF
CRU	VOLUME	- OFF
XX	XX CCU PWR	- OFF
	Disconnect AIU cables from CCU outlets	
	Disassemble, stow WCCS leg units	

ICOM RECORDER OPS

1. RECORD (Entry Config)
 - A11
 - CCU PWR – OFF
 - ✓MHA Connected to CCU
 - Connect to MHA at A11
 - ICOM RCDR CABLE
 - Plug P3/RCDR into Rcdr MIC Port
 - Plug P2/RCDR Headphone into Rcdr Headphones port
 - Plug mic into cable MIC connector
 - Tape all connections to Rcdr
 - A11 RCDR
 - CCU PWR – ON
 - Install tape
 - MIC ATT sw – 0 dB
 - SPEED TUNE – OFF
 - HEADPHONE VOLUME – 0 (taped)
 - DOLBY NR – OFF
 - TAPE – NORM
 - PEAK/BATT – BATT
 - MIC PWR – 120
 - MIC
 - ✓LED flash for good BATT
 - ATU RCDR
 - Desired Audio Loop(s) – T/R
 - PAUSE and RECORD – depress, ✓no motion
 - ✓BATT LED
 - PEAK/BATT – PEAK
 - REC LEVEL – 4
 - PAUSE – release, ✓tape motion
 - When complete – STOP, Mic – OFF
 - To test setup – PLAYBACK
2. PLAYBACK
 - RCDR
 - ✓Tape rewound
 - ATU
 - HEADPHONE VOL – 7
 - XMIT/ICOM MODE – PTT/VOX
 - VOX SENS – MAX
 - ICOM A(B)
 - PLAY – depress
 - RCDR
 - ✓Tape motion, voice quality
 - When complete, STOP – depress

Cont next page

LANDING-1 COMM C/O

NOTE

Performed to verify good CMD/TLM/voice/video and UHF with entry sites. MCC config COMM system to STDN and back to TDRS via SPC. East and west coast sites checked on different revs. Expect A/G, UHF voice calls for each site. MCC will ✓good TLM, CMD, voice, video, and UHF. Expect poor S-BD COMM during H/Os and if site problem. TDRS COMM available with C3 S-BD PM PNL/CMD. Perform step 1 prior to AOS of site

NOTE

Once good link established at site, MCC will call crew on A/Gs, then A/A. Crew responds on all loops for each comm check performed. Once MCC finished comm checks, complete remaining steps

Cont next page

O6 3. NORMAL UHF CONFIG
 ✓UHF SQUELCH – ON
 MODE – OFF

ATUxx AUD A/A – RCV

F8U 4. VIDEO RECONFIG
F3 R HUD MODE – NORM
V10 PWR – OFF
O19 PWR – OFF
 TV PWR – OFF

H/O TIMES (supplied by MCC at crew request)

WEST COAST TDRS → STDN ____/____:____:____
EAST COAST STDN → TDRS ____/____:____:____
 TDRS → STDN ____/____:____:____
 SITE → SITE (STDN) ____/____:____:____
 STDN → TDRS ____/____:____:____

COMM STRING 1 C/O (PART A: COMMAND TO STRING 1)

1. VERIFY PANEL A1L CONFIG
A1L ✓S-BD PM ANT SW ELEC – 1
 ✓PRE AMP – 1
 ✓PWR AMPL STBY – 1
 ✓OPER – 1
 ✓AMP MODE – TDRS DATA
 ✓XPNDR – 1
✓NSP DATA RATE (two) – HI
 ✓UPLK DATA – S-BD
 ✓CODING (two) – ON
 ✓PWR – 1

2. RECONFIG COMM STRINGS
✓MCC ready for reconfig

C3 S-BD PM CONTROL – PNL,CMD

Perform comm check with MCC-H

NOTE

S-Band, NSP now configured to String 1.
Alternate sw callouts used on all malfunction procedures. This config maintained for approx 24 hr

3. RECONFIG PANEL A1L
A1L S-BD PM ANT SW ELEC – 2
 PRE AMP – 2
 PWR AMPL STBY – 2
 OPER – 2
 XPNDR – 2
 NSP PWR – 2

COMM STRING 1 C/O (PART B: RETURN TO STRING 2)

1. VERIFY PANEL A1L CONFIG
A1L ✓S-BD PM ANT SW ELEC – 2
 ✓PRE AMP – 2
 ✓PWR AMPL STBY – 2
 ✓OPER – 2
 ✓AMP MODE – TDRS DATA
 ✓XPNDR – 2
✓NSP DATA RATE (two) – HI
 ✓UPLINK DATA – S-BD
 ✓CODING (two) – ON
 ✓PWR – 2
 2. RECONFIG COMM STRINGS
✓MCC ready for reconfig
- C3 S-BD PM CONTROL – PNL,CMD

Perform comm check with MCC-H
- NOTE
S-Band, NSP now configured to String 2.
Nominal sw callouts should be used on
all malfunction procedures
3. RECONFIG PANEL A1L
A1L S-BD PM ANT SW ELEC – 1
 PRE AMP – 1
 PWR AMPL STBY – 1
 OPER – 1
 XPNDR – 1
 NSP PWR – 1

CREW SYSTEMS

PRE-SLEEP ACTIVITY	
(RCS Config, step 13-CIL)	3-2
POST-SLEEP ACTIVITY	3-7
OCAC SETUP	3-11
STOWAGE	3-12
MAL	3-13
LiOH VOLUME INFLIGHT RECONFIG	3-14
TISSUE EQUIVALENT PROPORTIONAL COUNTER (TEPC)	3-16
TEPC DISPLAY LOGSHEET	3-22
CYCLE ERGOMETER OPS	3-23

TABLES

3-I TEPC NORMAL OPS DISPLAY KEY	3-17
---	------

CREW
SYS

FIGURES

3-1 TEPC location (middeck avionics bay 3A)	3-18
3-2 Ergometer	3-24
3-3 Ergometer middeck launch/landing config (ergo assy)	3-27
3-4 Alternate exercise bungee attachments – front view (facing stbd)	3-29
3-5 Alternate exercise bungee attachments – side view (facing stbd)	3-30

MEDS

A3-1

ORB OPS/ALL/GEN H

**CREW
SYS**

PRE-SLEEP ACTIVITY

FLIGHT DECK ACTIVITY LIST

1. If reqd, SUPPLY WATER DUMP (ECLS) (✓MCC)
R1(A11) CRYO HEATER/MANF VLV config per MCC

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. If FD1 and PPO2 < 3.20:
MO69M ✓LEH O2 8 vlv – CL
Insert O2 Bleed Orifice Assembly into
LEH O2 8 QD
LEH O2 8 vlv – OP
C7 ✓SPLY 1,2 vlv – OP

3. SM CHECKPOINT INITIATE (DPS)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

4. CRT TIMER FOR WAKE UP

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. ALERT TONE DURATION

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

- L1 6. CAB TEMP – adj rotary as desired (suggest
5 o'clock posn)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

A3-2 ORB OPS/MEDS/GEN H

MEDS

MO10W 7. If 14.7 CAB REG INLET SYS 1(2) VLV – OP
(PCS active):

L2 Expect possible 'S66 CAB N2 FLO 1(2)'
 O2/N2 CNTLR VLV SYS 1(2) – OP

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

NOTE

Do not perform following step until PRE-SLEEP
AUD CONFIG (COMM/INST) complete; see
MIDDECK ACTIVITY LIST, step 9, 3–6

8. PWRDN:

R11 ✓IDP/CRT4 PWR – ON
 IDP/CRT4 MAJ FUNC – SM
✓IDP4 assigned to SM GPC

CRT4 **SM ANTENNA**
All AFT MDUs PWR – OFF
IDP/CRT4 PWR sw – OFF

C2 ✓IDP/CRT1 PWR sw – ON
✓IDP/CRT2 PWR sw – ON
IDP/CRT2 MAJ FUNC – GNC
✓IDP2 assigned to GNC GPC

CRT2 **GNC UNIV PTG**
All FWD MDUs except CRT 1,
MDU PWR – OFF
IDP/CRT2 PWR sw – OFF

Perform ERR LOG resets:

GNC 0 GPC MEMORY

ITEM 48 EXEC

SM 0 GPC MEMORY

ITEM 48 EXEC

C3 BFC CRT SEL – 1 + 2
 DISP – ON
MDU CRT1 PWR – OFF

Cont next page

MEDS

A3–3 ORB OPS/MEDS/GEN H

C2

IDP/CRT1 PWR sw – OFF

✓PWR OFF:

TV MON

CAMERAS

PWR CONTR UNIT

PWR

VTR

PLB LIGHTS

DDUs

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

9. WINDOW SHADES/FILTERS

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

10. LIGHTING

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

O14:F, 11. Pri RJDF DRIVER,LOGIC (eight) – OFF

O15:F,

O16:F

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

O14:F, 12. Pri RJDA DRIVER,LOGIC (eight) – OFF

O15:F,

RJDA 1A L2/R2 MANF DRIVER – ON

O16:F

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

MIDDECK ACTIVITY LIST

1. FOOD PREP/POST

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

2. CO₂ ABSORBER REPLACEMENT (Cue Card)

1 2 3 4 5 6 7 8 9 10

11 12 13 14 15 16

Cont next page

MEDS

A3–4 ORB OPS/MEDS/GEN H

CREW SYSTEMS

PRE-SLEEP ACTIVITY	
(RCS Config, step 13-CIL)	3-2
POST-SLEEP ACTIVITY	3-7
OCAC SETUP	3-11
STOWAGE	3-12
MAL	3-13
LiOH VOLUME INFLIGHT RECONFIG	3-14
TISSUE EQUIVALENT PROPORTIONAL COUNTER (TEPC)	3-16
TEPC DISPLAY LOGSHEET	3-22
CYCLE ERGOMETER OPS	3-23

TABLES

3-I TEPC NORMAL OPS DISPLAY KEY	3-17
---	------

CREW
SYS

FIGURES

3-1 TEPC location (middeck avionics bay 3A)	3-18
3-2 Ergometer	3-24
3-3 Ergometer middeck launch/landing config (ergo assy)	3-27
3-4 Alternate exercise bungee attachments – front view (facing stbd)	3-29
3-5 Alternate exercise bungee attachments – side view (facing stbd)	3-30

NOM

B3-1

ORB OPS/ALL/GEN H

**CREW
SYS**

PRE-SLEEP ACTIVITY

FLIGHT DECK ACTIVITY LIST

1. If reqd, SUPPLY WATER DUMP (ECLS) (√MCC)
R1(A11) CRYO HEATER/MANF VLV config per MCC

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. If FD1 and PPO2 < 3.20:
MO69M √LEH O2 8 vlv – CL
Insert O2 Bleed Orifice Assembly into
LEH O2 8 QD
LEH O2 8 vlv – OP
C7 √SPLY 1,2 vlv – OP

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

3. SM CHECKPOINT INITIATE (DPS)
CRT 4. CRT MAJ FUNC – one SM, one GNC

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. CRT TIMER FOR WAKE UP
L1 6. ALERT TONE DURATION

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

- L1 7. CAB TEMP – adj rotary as desired (suggest
5 o'clock posn)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

NOM

B3-2

ORB OPS/NOM/GEN H

MO10W 8. If 14.7 CAB REG INLET SYS 1(2) VLV – OP
(PCS active):

L2 Expect possible 'S66 CAB N2 FLO 1(2)'
 O2/N2 CNTLR VLV SYS 1(2) – OP

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

NOTE

Do not perform following step until PRE-SLEEP
AUD CONFIG (COMM/INST) complete; see
MIDDECK ACTIVITY LIST, step 9, 3–6

9. PWRDN:

CRT4

✓PWR – ON
MAJ FUNC – SM
✓CRT4 assigned to SM GPC

SM ANTENNA

PWR – OFF

CRT2

✓PWR – ON
MAJ FUNC – GNC
✓CRT2 assigned to GNC GPC

GNC UNIV PTG

PWR – OFF

Perform ERR LOG reset:

CRT1

GNC 0 GPC MEMORY

ITEM 48 EXEC

SM 0 GPC MEMORY

ITEM 48 EXEC

C3

BFC CRT SEL – 1+2

DISP – ON

Cont next page

NOM

B3–3

ORB OPS/NOM/GEN H

CRT1

PWR – STBY
✓PWR OFF:
 TV MON
 CAMERAS
 PWR CONTR UNIT
 PWR
 VTR
 PLB LIGHTS
 DDUs (one ON, if reqd)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

10. WINDOW SHADES/FILTERS

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

11. LIGHTING

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

O14:F, 12. Pri RJDF DRIVER,LOGIC (eight) – OFF

O15:F,

O16:F

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

O14:F, 13. Pri RJDA DRIVER,LOGIC (eight) – OFF

O15:F,

O16:F

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

MIDDECK ACTIVITY LIST

1. FOOD PREP/POST

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. CO2 ABSORBER REPLACEMENT (Cue Card)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

NOM

B3-4

ORB OPS/NOM/GEN H

| | | |

3. HOUSEKEEPING

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

4. WCS CLEANING (Cue Card, URINE
COLLECTION)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. SET UP EQUIPMENT FOR NEXT DAY'S
ACTIVITIES

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

6. ✓PWR OFF:
TV PWR

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

7. MISSION NOTES

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

8. TYPE PERSONAL MESSAGES, if desired

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

9. PRE-SLEEP AUD CONFIG (COMM/INST)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

10. LIGHTING

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

POST-SLEEP ACTIVITY

MIDDECK ACTIVITY LIST

1. LIGHTING (minimize if in GROUP B(C) PWRDN)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. CO2 ABSORBER REPLACEMENT (Cue Card)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

3. MESSAGE REVIEW

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

4. POST-SLEEP AUD CONFIG (COMM/INST)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. If FD2 and Bleed Orifice not installed:

MO69M ✓LEH O2 8 vlv – CL
Insert O2 Bleed Orifice Assembly into
LEH O2 8 QD
LEH O2 8 vlv – OP
C7 ✓SPLY 1,2 vlv – OP

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

6. FOOD PREP/POST

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

7. HOUSEKEEPING

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

8. WCS OHS REPLACEMENT
 - a. If FD2, perform URINE PRETREAT SETUP (Cue Card, URINE PRETREAT CHANGEOUT)
 - b. URINE PRETREAT CHANGEOUT (Cue Card)
1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16
9. If Entry day, perform URINE PRETREAT ENTRY PREP (Cue Card, URINE PRETREAT CHANGEOUT) (if flown)

Cont next page

FLIGHT DECK ACTIVITY LIST

1. LIGHTING (minimize if in GROUP B(C) PWRDN)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. WINDOW SHADES/FILTERS

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

3. IDPs/MDUs – ON as desired (use only one IDP with three MDUs max if in GROUP B(C) PWRDN)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

C3 4. BFC CRT DISP – OFF

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. ALERT TONE DURATION

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

L1 6. CAB TEMP – adj rotary as reqd

If Entry day:

CAB TEMP – full COOL

Wait 20 min

CAB TEMP CNTLR – OFF

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

MO10W 7. If 14.7 CAB REG INLET SYS 1(2) vlv – OP (PCS active):

L2 O2/N2 CNTLR VLV SYS 1(2) – AUTO

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

MEDS

A3–9 ORB OPS/MEDS/GEN H

8. If planned, perform I'CNCT: L(R) OMS to RCS
(ORB PKT, RCS), then:

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

9. If not GROUP B(C) PWRDN:

O14:F,
O15:F,
O16:F Pri RJDF DRIVER,LOGIC (eight) – ON

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

10. If not GROUP B(C) PWRDN:

O14:F,
O15:F,
O16:F Pri RJDA DRIVER,LOGIC (eight) – ON

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

11. If reqd, SUPPLY WATER DUMP (ECLS) (✓MCC)
R1(A11) CRYO HEATER/MANF VLV config per MCC

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

MEDS

A3–10

ORB OPS/ALL/GEN H

FLIGHT DECK ACTIVITY LIST

1. LIGHTING (minimize if in GROUP B(C) PWRDN)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

2. WINDOW SHADES/FILTERS

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

3. CRTs (three) – ON (use only one CRT if in GROUP B(C) PWRDN)

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

C3 4. BFC CRT DISP – OFF

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

5. ALERT TONE DURATION

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

L1 6. CAB TEMP – adj rotary as reqd

If Entry day:

CAB TEMP – full COOL

Wait 20 min

CAB TEMP CNTLR – OFF

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

MO10W 7. If 14.7 CAB REG INLET SYS 1(2) vlv – OP (PCS active):

L2 O2/N2 CNTLR VLV SYS 1(2) – AUTO

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

Cont next page

NOM

B3-9

ORB OPS/NOM/GEN H

8. If planned, perform I'CNCT: L(R) OMS to RCS
(ORB PKT, RCS), then:

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

9. If not GROUP B(C) PWRDN:

O14:F,
O15:F,
O16:F Pri RJDF DRIVER,LOGIC (eight) – ON
1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

10. If not GROUP B(C) PWRDN:

O14:F,
O15:F,
O16:F Pri RJDA DRIVER,LOGIC (eight) – ON
1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

11. R1(A11) If reqd, SUPPLY WATER DUMP (ECLS) (√MCC)
CRYO HEATER/MANF VLV config per MCC

1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16

NOM

B3-10

ORB OPS/ALL/GEN H

OCAC SETUP

- OCAC
1. ✓OCAC PWR – OFF
Attach DC Pwr cable to OCAC
 2. Loosen fabric shroud via Velcro attach points
 3. Loosen knurled collar on port arm until arm can
be rotated down and locked
Fully extend arm by rotating collar
 4. Depress handles on stbd arm
Rotate arm down until locked
 5. Center OCAC in stbd interdeck accessway
 6. Place port arm pad in upper groove
 7. While depressing stbd arm handles, pivot
OCAC into position, then release handles

NOTE

Port arm may need adjustment
to accommodate OCAC fit

8. ✓OCAC fit secure
9. Secure fabric shroud to surrounding accessway
10. ✓DC UTIL PWR – OFF
Attach DC Pwr cable to predetermined orbiter
DC UTIL PWR outlet
DC UTIL PWR – ON
11. Remove filter cover
OCAC PWR – ON
Adjust CFM to 300 cfm (or desired level)

OCAC STOWAGE

- OCAC
1. ✓Filter for debris. If reqd, clean using Gray Tape or vacuum
Place filter cover over filter
 2. OCAC PWR – OFF
✓RPM – 0
 3. DC UTIL PWR – OFF
Disconnect DC Pwr cable from orbiter/OCAC
 4. Pivot stbd/port arms into stowed position via pivot release buttons
Adjust arms to fit within OCAC
 5. Secure fabric shroud to OCAC
 6. Stow OCAC


OCAC MAL

ERROR INDICATOR	PROBLEM RESOLUTION
CHECK FILTER (LED illuminated)	Filter not properly attached to OCAC; reattach filter
CHECK BREAKER (LED illuminated)	✓cb sw – off ✓MCC
MOTOR OVERHEAT (LED illuminated)	✓OCAC PWR – OFF ✓Filter clean (If reqd, clean filter, allow motor to cool down before turning) OCAC PWR – ON ✓Motor not restricted (If reqd, remove object, allow motor to cool down before turning OCAC PWR – ON)
LED on top of OCAC (not illuminated)	✓DC UTIL PWR – ON ✓OCAC PWR – ON ✓cb sw – on Ensure proper cable connection

LiOH VOLUME INFLIGHT RECONFIG

1. Open LiOH Door
2. Unfasten wing fasteners (two) on beam assembly
Remove beam
3. Unfasten strap from buckle
4. Remove clothing bags (seven)
5. Unfold trash bag liner and position in container, matching bottom Velcro on liner with Velcro on preinstalled Nomex bag (verify vent opening positioned aft of beam)
6. Place collar on trash bag liner under beam assembly and align with wing fasteners (four) on beam assembly. Hand tighten
7. Mate vent line from orbiter to collar assembly (ensure proper connection by gently pulling on hose)
8. Reinstall beam
9. Place hand inside liner and mate Velcro on outside of liner to Velcro on Nomex bag
Spread bag out while mating Velcro

Cont next page



TISSUE EQUIVALENT PROPORTIONAL COUNTER (TEPC)

A. POWER ON

NOTE

PDB (P1) needs to be connected
after launch

- | | |
|-------------------|--|
| MO52J
TEPC | 1. ✓DC UTIL PWR MNA – ON |
| Avionic
Bay 3A | 2. POWER sw 1 – ON |
| | 3. Verify green LED – ON
If not, perform Malfunction step C1 |
| | 4. After 1 min, verify display backlit and startup
displays cycling
If not, perform Malfunction step C3
If no joy, notify MCC |

NOTE

During instrument startup routine,
TEPC cycles through 12 startup
displays (initializations). After
8 min, TEPC startup complete

5. Record initialization MET

____/____:____:____

NOTE

When startup complete, TEPC cycles
through four operational displays.
See table 3-I for displays

When time permits:

6. ✓TEPC Window Display
If display not cycling, (e.g., if time not
incrementing), perform Malfunction
step C4

If dose not incrementing,
perform Malfunction step C5

7. Notify MCC of MET

Cont next page

TABLE 3-I.— TEPC NORMAL OPERATIONAL DISPLAY KEY

Verification of normal operation:

Cyclic displays of operating parameters from the Window Display are shown below. Each left-hand box represents the layout of each display. The right-hand boxes are the noun names of the indicated values for the corresponding Window Display. Dose rate should change with each screen. Elapsed time (m) will change with each min

NOTE

Units for Dose Rate may be pGy/h, nGy/h, μ Gy/h, or mGy/h. Units for Total Dose may be pGy, nGy, μ Gy, or mGy. 1 Gy = 100 rad
 pGy – picogray
 nGy – nanogram
 μ Gy – microgray
 mGy – milligray

::00 Display 1	hh:mm:ss _____.____ μ G _____m_____ μ G/h	→	Time Elapsed Time	Total Dose Dose Rate
::15 Display 2	hh:mm:ss _____.____ μ G DD.MM.YY _____ μ G/h	→	Date	Time Total Dose Dose Rate
::30 Display 3	hh:mm:ss _____.____ μ G ____% ____E _____ μ G/h	→	Memory Errors	Time Total Dose Dose Rate
::45 Display 4	hh:mm:ss _____.____ μ G > _____ _____ μ G/h	→	Flags	Time Total Dose Dose Rate

Cont next page

TEPC B. POWERDOWN
 1. PWR sw 1 – OFF

NOTE

Following step 2 will terminate power
to other loads on that utility outlet

MO52J 2. DC UTIL PWR MNA – OFF

3. Record TEPC deactivation MET

____ / ____ : ____ : ____




Figure 3-1.– TEPC location (middeck avionics bay 3A).

Cont next page

C. MALFUNCTION

1. Green LED not ON (no display)

TEPC POWER sw 1 – OFF

MO52J DC UTIL PWR MNA – OFF

✓ External connections properly mated per
Plug-In-Plan

MO52J DC UTIL PWR MNA – ON

TEPC POWER sw 1 – ON

✓ Green LED – ON
If green LED ON, go to POWER ON step A3
If no green LED:
✓ MCC regarding fuse replacement and
perform Malfunction step C2

2. Fuse Replacement

TEPC POWER sw 1 – OFF

MO52J DC UTIL PWR MNA – OFF

TEPC sw Box ✓ Fuse (F1/F2)

If necessary:

Top of TEPC Replace with spare fuse
Stow blown fuse in spare fuse holder

NOTE

There are two spare fuses available, one
on top of TEPC pouch and one in TEPC
switchbox. Fuse on top of pouch is easier
to access so it should be tried first

MO52J DC UTIL PWR MNA – ON

TEPC POWER sw 1 – ON

✓ Green LED – ON
If green LED, perform POWER ON step A4
If no green LED, notify MCC

3. Green LED – ON but no display after 60 sec

TEPC POWER sw 1 – OFF

Cont next page

- MO52J DC UTIL PWR MNA – OFF
- ✓ Internal connections properly mated:
 - Unfasten straps and unzip TEPC case
 - Check three internal connections
 - Zip up TEPC case and fasten straps
- DC UTIL PWR MNA – ON
- TEPC POWER sw 1 – ON
- Go to POWER ON step A4
- TEPC 4. Display ON but not cycling (or no time updates)
- POWER sw 1 – OFF
- Wait 30 sec
- POWER sw 1 – ON
- NOTE
- During instrument startup routine,
TEPC cycles through 12 startup
displays (initializations). After
8 min, TEPC startup complete
- ✓ For proper display:
 If proper display, go to POWER ON step A4
 If no joy, notify MCC
5. Display ON but no dose rate or incrementing dose
- TEPC POWER sw 1 – OFF
- MO52J DC UTIL PWR MNA – OFF
- Unfasten straps and unzip TEPC case
- ✓ Detector cable connection to spectrometer
 - Zip up TEPC case and fasten straps
- MO52J DC UTIL PWR MNA – ON
- TEPC POWER sw 1 – ON

Cont next page

NOTE

During instrument startup routine,
TEPC cycles through 12 startup
displays (initializations). After
8 min, TEPC startup complete

✓ For proper display:

- If proper display, go to POWER ON step A4
- If no joy, notify MCC

D. CALL DOWN DATA

NOTE

This procedure only reqd at direction
of MCC

1. Record data per MCC instruction. Note appropriate scientific units on dose and dose rate. Refer to TEPC DISPLAY LOGSHEET, 3-22
2. Call down recorded data to MCC

NOTE

TEPC operational sequence consists of continuous cycling through four operational displays. See table 3-I for displays

Cont next page

TEPC DISPLAY LOGSHEET

NOTE

Report units as well as values

CYCLE ERGOMETER OPS

ERGOMETER SETUP

1. Remove Ergometer Assy from middeck floor, transport Ergometer to desired exercise location

2. Unstow:

Ergo Assy	Ergometer Accessories (Ergo Acc) Bag
Ergo Acc	Bio Bag
Bag	Sound Mounts (4)
Bio Bag	Adjustable Quick Disconnects (AQDs) Spacers (4)

NOTE

102 only – spacers
not used on flight deck

3. Attach AQDs (four) to seat floor studs. Install sound mounts and spacers on ADQs

Disassemble Ergo Assy:

4. Remove seat stem pip pin, seat stem foot, restraining belt, temp stow
5. Remove seat assy, temp stow
6. Remove Ergometer pip pins (four), ergometer assy straps (four); release Ergometer from frame; temp stow
7. Mount both frame sections loosely to AQDs on seat floor studs (fig 3–2) using Knurled Kbs (four)
8. Install seat assy on seat stem; insert seat stem foot into stem
Move seat assy pip pin (one) from green to yellow position, secure with seat stem pip pin, slide blocks together, secure with Velcro
9. ✓Ergometer ON/OFF – OFF

Cont next page

NOTE

Following steps will interrupt power
to other loads on that utility outlet

MO30F 10. ✓DC UTIL PWR – OFF

11. Connect prerouted Ergometer Pwr cable to Ergometer Pwr Jack
Connect Ergometer Display Panel cable to Ergometer Display Jack; temp stow




Figure 3–2.– Ergometer.

Bio Bag 12. Unstow: Threaded fasteners (four)

NOTE

Ergometer ON/OFF, MANUAL/REMOTE switches should face subject

Cont next page

13. ✓Ergometer for proper orientation
Mount Ergometer to frame assy with Threaded Fasteners (four)
Tighten with Wrench
Hand-tighten Knurled Kbs to secure Ergometer frame assy to Middeck floor
Tighten seat stem foot against orbiter floor

14. Unstow:
Ergo Acc Ergometer Pedals
Bag Ergometer Cranks

15. Install pedals on cranks using Wrench from Ergo Acc Bag, attach cranks with pedals to Ergometer, tighten with Wrench (fig 3-2)

NOTE
Install RED on RIGHT,
BLUE on LEFT

MO30F 16. DC UTIL PWR – ON

As reqd, if exercise session follows immediately,
perform muscle stretch:

17. Hold each stretch 1 min
18. While stretching, relax involved muscle

19. Adjust seat assy for subject comfort

20. Mount Ergometer
Secure shoes into pedals
Secure body with restraining belt

21. Ergometer ON/OFF – ON

22. Perform exercise

23. Ergometer ON/OFF – OFF

Cont next page

RECONFIG/STOW

NOTE

Following steps will interrupt power
to other loads on that utility outlet

- MO30F 1. DC UTIL PWR – OFF
2. Disconnect prerouted Ergometer Pwr cable,
secure
3. If other loads on utility outlet (verify per
Plug-In Plan)
DC UTIL PWR – ON
- Ergo Acc Bag 4. Detach Ergometer Display Panel cable,
Ergometer pedals, cranks, stow
- Bio Bag 5. Remove Threaded Fasteners, stow
6. Remove Ergometer from frame, temp stow
7. Remove seat stem pip pin, seat stem foot;
temp stow
8. Remove seat assy, reconfigure for
launch/landing (pip pin moves from yellow
to green hole)
9. Unscrew Knurled Kbs (four)
10. Release both frame sections from AQDs on seat
studs; remove spacers (four), AQDs with
Knurled Kbs/sound mounts (four), stow
11. Slide frame half, without seat stem, onto stem in
launch/landing config (fig 3–3)
12. Unstow: Ergo Assy Straps (two pair), slide onto
frame
13. Unstow: Pip pins

Cont next page

14. Attach Ergometer horizontally to frame with pip pins (fig 3-3)
 - ✓ Arrow on decal, seat stem face same direction
 15. Slide seat assy onto seat stem, reinstall seat stem foot, secure with seat stem pip pin
 16. Tighten Knurled Kbs (two) on seat assy
 17. Secure restraining belt around seat assy, seat stem
 18. Mount frame to launch/landing position in middeck using frame/AQDs (four), with seat stem facing forward (fig 3-3)
- Ergo Acc Bag
19. Unstow: Ergo Assy Straps
Using Ergo Assy Straps attach Ergo Acc Bag to Ergometer (fig 3-3)
 20. Pull straps tight; secure loose ends




Figure 3-3.– Ergometer middeck launch/landing config (ergo assy).

Cont next page

CYCLE ERGOMETER MANUAL OPS

- Ergo Acc 1. Unstow: Manual Control Kb Bag
2. Screw Manual Control Kb into bushing on Ergometer (fig 3-2)
- NOTE
- To increase workload, turn Manual Control Kb cw. To decrease workload, turn Manual Control Kb ccw
- If workload/pedal speed desired, pwr available:
3. ✓ Ergometer ON/OFF – ON
Set desired pedal speed, workload on display panel
Perform exercise
Adjust Manual Control Kb until ONLY center LED on workload illuminated; repeat for any change in workload
- If workload/pedal speed feedback not desired or pwr not available:
4. Perform exercise, adjusting Manual Control Kb cw or ccw as desired

ALTERNATE ERGOMETER EXERCISE

- Ergo Acc 1. Unstow: Bungee Cords (Bio Bag) Bag
2. Connect two sets of four Bungee Cords in series
3. Stand topside of Ergometer with feet approx shoulder width apart
4. Attach Bungees to opposite corners of Ergometer frame crossing Bungees over shoulders (figs 3-4, 3-5)
5. Adjust Bungee length for comfort

Cont next page

NOTE
Use towels, socks for shoulder
padding if desired

6. Perform exercise
7. Stow: Bungee Cords (Bio Bag)




Figure 3-4.— Alternate exercise bungee attachments – front view (facing stbd).

Cont next page

Middeck fwd




Figure 3-5.—Alternate exercise bungee attachments — side view (facing stbd).

DPS

G2 SET CONTRACTION	4-2
EXPANSION	4-4
TO G8 TRANSITION	4-6
G8 TO G2 TRANSITION	4-7
SM CHECKPOINT INITIATE	4-9

DPS

G2 SET CONTRACTION

NOTE

Do not perform any keyboard item entries or sw throws 10 sec before and after moding PASS GPCs to RUN or making OPS transition requests

1. If RNDZ NAV enabled:

NOTE

The following steps do not take PASS redundant set through OPS 0

- a. Remove GPC From Redundant Set
Perform step 2 without modifying GPC target set, then:

O6 GPC MODE – STBY (tb-bp)
 – RUN (tb-RUN)

C3(A6U) DAP: as reqd

- b. Create G2FD GPC
Perform step 4 if GPC not currently reqd
- c. Clear Software Fail Votes
Go to step 6 >>

2. CONTRACT G2 GPC SET

If MM202: GNC, OPS 201 PRO

GNC 0 GPC MEMORY

CONFIG –

ITEM 1 +2 EXEC

Assign MC 2 per table

✓ DOWNLIST GPC,
ITEM 44 +1 EXEC

C3(A6U) DAP: FREE
 VERN (ALT)

CRT GNC, OPS 201 PRO

If:	Single G2	Dual G2
CONFIG GPC	2 10000	2 12000
STR	1 2 3 4	1 1 1 2
PL	1/2 0	0 0
CRT	1 2 3 4	1 1 0 2
L	1 2	0 0
MM	1 2	1 2

Cont next page

- C3(A6U) 3. Pause ~30 sec (DAP settling), then
DAP: as reqd
- CRTX 4. **FREEZE DRY GPC 2(3) (G2FD)**
MAJ FUNC – PL
GPC/CRT2(3)/X EXEC
X: PL GPC MEMORY
CONFIG – ITEM 45 +2 EXEC
GPC – ITEM 46 +2(3) EXEC
STORE – ITEM 47 EXEC
Store complete when MC = 02 (~30 sec)
✓All IDPs [CRTs] deassigned from FD GPC
- O6 GPC MODE 2(3) – STBY (tb–bp)
– HALT (tb–bp)
– STBY (tb–RUN)
– HALT (tb–bp)
5. **CONFIG CLEANUP**
GNC 22 S TRK/COAS CNTL
S TRK –Y,–Z: STAR TRK – ITEM 3,4 EXEC (*)
GNC 21 IMU ALIGN
RESUME
6. **CLEAR SOFTWARE FAIL VOTES**
On MCC GO:
GNC 0 GPC MEMORY
ITEM 48 EXEC
SM 0 GPC MEMORY
ITEM 48 EXEC

G2 SET EXPANSION

NOTE

Do not perform any keyboard item entries or sw throws 10 sec before and after moding PASS GPCs to RUN or making OPS transition requests

1. If RNDZ NAV enabled:
C3(A6U) DAP: LVLH

GNC UNIV PTG

 CNCL – ITEM 21 EXEC
2. CONFIG G2FD GPC(s) FOR SET EXPANSION
 ✓AV BAY 2(3) FAN A(B) – ON
 O6 ✓GPC MODE 2(3) – HALT
 ✓OUTPUT 2(3) – NORM
 ✓PWR 2(3) – ON
 MODE 2 – STBY(tb-RUN)
 – RUN (OUTPUT tb-gray)
- If triple G2 reqd:
 MODE 3 – STBY (tb-RUN)
 – RUN (OUTPUT tb-gray)
3. CONFIG FOR SET EXPANSION
 If MM202: GNC, OPS 201 PRO

GNC 0 GPC MEMORY

 CONFIG –
 ITEM 1 +2 EXEC
 Assign MC 2 per table →

If:	Dual G2	Triple G2
CONFIG GPC	2	2
STR 1	1	1
2	2	2
3	1	3
4	2	3
PL 1/2	0	0
CRT 1	1	1
2	2	2
3	0	0
4	2	3
L 1	0	0
2	0	0
MM 1	1	1
2	2	2
4. OPS MODE RECALL
 C3(A6U) DAP: FREE
 CRT GNC, OPS 201 PRO
 Pause ~30 sec
 (DAP settling), then
 C3(A6U) DAP: as reqd

Cont next page

5. CONFIG CLEANUP
[GNC 22 S TRK/COAS CNTL]
S TRK -Y, -Z: STAR TRK – ITEM 3,4 EXEC (*)
[GNC 21 IMU ALIGN]
RESUME
6. If resuming RNDZ NAV TRACKING:
Go to RNDZ NAV RECOVERY (RNDZ,
CONTINGENCY OPS)

G2 TO G8 TRANSITION

NOTE

Do not perform any keyboard item entries or sw throws 10 sec before and after moding PASS GPCs to RUN or making OPS transition requests

1. If RNDZ NAV enabled:
C3(A6U) DAP: LVLH
GNC UNIV PTG
CNCL – ITEM 21 EXEC
2. CONFIGURE TFL FOR G8 TRANSITION
If Elevon Park: TFL change not reqd
If FCS Checkout:
SM 62 PCMMU/PL COMM
Perform LOAD PCMMU FORMAT
(ORB OPS FS, COMM/INST)
FORMAT ID: 103/161
3. CONFIGURE FOR G8 OPS TRANSITION
O8 √MLS (three) – ON
O14,O15, √cb ADTA (four) – cl
O16:E
O14,O15:F √MMU (two) – ON
CRT If MM202: GNC, OPS 201 PRO
GNC 0 GPC MEMORY
4. OPS TRANSITION
C3(A6U) DAP: FREE
CRT GNC, OPS 801 PRO
Modify MC8 per table →

If:	Single G2	Dual G2	Triple G2
CONFIG GPC	8 10000	8 12000	8 12300
STR 1	1	1	1
2	1	2	2
3	1	1	3
4	1	2	3
PL 1/2	0	0	0
CRT 1	1	1	1
2	1	2	2
3	0	0	0
4	1	2	3
L 1	0	0	0
2	0	0	0
MM 1	1	1	1
2	1	2	2
5. If PWRDN config:
O15:F MMU2 – OFF

G8 TO G2 TRANSITION

NOTE

Do not perform any keyboard item entries or sw throws 10 sec before and after moding PASS GPCs to RUN or making OPS transition requests

1. **SM 62 PCMMU/PL COMM**
If reqd, perform LOAD PCMMU FORMAT (ORB OPS FS, COMM/INST)

O14,
O15:F

2. **CONFIGURE FOR G2 OPS TRANSITION**

✓MMU (two) – ON

GNC 0 GPC MEMORY

CONFIG – ITEM 1 +2 EXEC Modify MC2 per table	If:	Single G8			Dual G8			Triple G8		
		CONFIG GPC	2 10000	2 12000	2 12300	1	2	3		
STR	1	1		1		1		1		
	2		1		2		2			
	3		1		1		1	3		
	4		1		2		2	3		
PL	1/2	0		0		0		0		
CRT	1	1		1		1		1		
	2		1		2		2			
	3		0		0		0	0		
	4		1		2		2	3		
L	1	0		0		0		0		
	2		0		0		0	0		
MM	1	1		1		1		1		
	2		1		2		2	2		

3. **OPS TRANSITION**

C3(A6U)
CRT

C3(A6U)

DAP: FREE
GNC, OPS 201 PRO
Pause ~30 sec
(DAP settling), then
DAP: as reqd

4. **CONFIG CLEANUP**

GNC 22 S TRK/COAS CNTL

S TRK –Y, –Z: STAR TRK – ITEM 3,4 EXEC (*)

GNC 21 IMU ALIGN

RESUME

O15:F

MMU 2 – OFF (if PWRDN config reqd)

If not currently performing FCS Checkout, then:

O8

✓MLS (three) – OFF

O14,O15,
O16:E

✓cb ADTA (four) – op

Cont next page

5. If resuming RNDZ NAV TRACKING:
Go to RNDZ NAV RECOVERY (RNDZ,
CONTINGENCY OPS)

SM CHECKPOINT INITIATE

O15:F 1. ✓MMU 2 – ON

NOTE

If MMU powered off (Group B or Group C PWRDN), unit can take up to 34 sec to initialize before ready to support MMU ops

- CRT 2. SELECT MMU 2(1) FOR CKPT
[SM 1 DPS UTILITY]
MMU 2(1) ASSIGN – ITEM 4(3) EXEC (*)
- ✓MMU STATUS 2(1):
When 'RDY' (up to ~30 sec), continue
[SM 60 TABLE MAINT]
✓SM COM BUFF – 'RDY'
CHECKPT INITIATE – ITEM 18 EXEC
✓Time updated
✓STATUS – 'GOOD'
3. Repeat step 2 for MMU 1
4. After completion of SM CKPTs:
[SM 1 DPS UTILITY]
✓CKPT RETRV ENA – ITEM 12 EXEC (*)
5. If in Group B or C PWRDN:
MMU 2 – OFF

O15:F

This Page Intentionally Blank

ECLS

SUPPLY/WASTE WATER DUMP	5-2
SUPPLY WATER DUMP USING FES	5-9
CABIN TEMP CONTROL	5-10
CO2 RMVL SYS CNTLR CONFIG:	
ACT 1/DEACT 2 (ACT 2/DEACT 1)	5-11
RAD BYPASS/FES C/O	5-12
MODIFIED RAD BYP/FES C/O AND TOPPING	
CORE FLUSH	5-13
RAD DEPLOY	5-15
STOW	5-17
PCS 1(2) CONFIG	5-19
TOPPING FES DEACTIVATION	5-20
STARTUP	5-21
SMOKE DETN CKT TEST	5-22
SHUTTLE/ISS H2O CONTAINER FILL	5-25
CWC OVERBOARD DUMP	5-32
CABIN TEMP CONTROLLER	
RECONFIG – 2(1)	5-35
SHUTTLE CONDENSATE COLLECTION	5-36
PWR OVERBOARD DUMP	5-37
EMU WATER RECHARGE BAG FILL	5-40

ECLS

FIGURES

5-1	Initial purge setup; tee/hose coming from GIRA	5-26
5-2	CWC or EDV fill setup	5-27
5-3	Quantity measuring strap and CWC details ..	5-28
5-4	CWC sample setup	5-29

ECLS

SUPPLY/WASTE WATER DUMP

For SPLY H₂O Dump, perform steps in sections A,B,D,F,H,K.

For WST H₂O Dump, perform steps in sections B,E,G,I,K.

For simo SPLY/WST H₂O Dump, perform all steps

NOTE

If PASS SM avail, monitor temps and QTY; otherwise, dump only when MCC avail to monitor.

Dump in current SPLY H₂O tank config (panels R11L, ML31C), unless directed otherwise by MCC.

If no comm: Dump H₂O tanks to provide 100% total ullage in any single or combination of TKs A,B,C,D. 100% ullage reqd for FC-produced water for 12 hr.

QTY of approx 200% among TKs A,B,C,D reqd for deorbit/entry FES usage.

If part of TKA and all of TKB to be dumped:

Set TKB QTY LL to -10 to preclude nuisance alarm

Do not reset LL or dump TKA QTY less than 80

A. SUPPLY/SIMO DUMP PREP

For SPLY H₂O or simo SPLY/WST H₂O DUMP, unstow and install SPLY H₂O Dumpline Purge Device into CONT H₂O X-TIE POT QD (Lower QD with blue Velcro and "POTABLE" label)

NOTE

Have towel ready for possible release of water when mating/demating any connections

Cont next page

B. PRE-DUMP FDA

If comm, MCC will TMBU nozzle temp, tank qty limits, and provide dump duration as reqd

If no comm, change limits via table A for SPLY H2O Dump, table B for WST H2O Dump, or both for simo SPLY/WST H2O Dump

TABLE A

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
SUPPLY H2O QTY A	0620410	*	
	B	0620420	*
	C	0620548	*
	D	0620544	*
NOZ T A	0620440	90	250
	B	0620439	90

*Limits TMBU'd on orbit to provide leak and overfill detection

TABLE B

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H2O QTY 1	0620540	*	99
	NOZ T A	50	250
	B	50	250

*Limits TMBU'd on orbit to provide leak and overfill detection

Cont next page

- MO10W C. SIMO DUMP H2O TK N2 REG CONFIG
 If performing simo SPLY/WST H2O Dump:
 H2O TK N2 REG INLET SYS 1,SYS 2 vlv
 (two) – OP
- CRT D. SUPPLY H2O DUMP NOZZLE HTR ACTIVATION
SM 66 ENVIRONMENT
 1. ✓SUPPLY H2O DMP LN T ≥ 65
- ML86B:A * If DMP LN T < 65, enable 2nd heater: *
 * cb MNB(MNA) H2O LINE HTR *
 * B(A) – cl *
- R11L 2. ✓SPLY H2O DUMP ISOL VLV – OP (tb–OP)
 3. SPLY H2O DUMP VLV ENA/NOZ HTR –
 ON
 4. ✓SPLY H2O DUMP VLV – CL (tb–CL)
- CRT E. WASTE H2O DUMP NOZZLE HTR ACTIVATION
SM 66 ENVIRONMENT
 1. ✓WASTE H2O DMP LN T > 50
- ML86B:A * If WASTE H2O DMP LN T ≤ 50, *
 * enable 2nd heater: *
 * cb MNB(MNA) H2O LINE HTR *
 * B(A) – cl *
- ML31C 2. ✓WASTE H2O DUMP ISOL VLV – OP
 (tb–OP)
 3. WASTE H2O DUMP VLV ENA/NOZ HTR –
 ON
 4. ✓WASTE H2O DUMP VLV – CL (tb–CL)

Cont next page

F. SUPPLY H₂O DUMP INITIATION

SM 66 ENVIRONMENT

CAUTION

Tile debonding may occur if nozzle temps exceed 350 degF

- CRT 1. When SUPPLY H₂O NOZ T A,B (two) exceed 100 (~5 min warmup time), continue

- R11L 2. SPLY H₂O DUMP VLV – OP (tb–OP)

- CRT 3. ✓ SUPPLY H₂O QTY A(B,C,D) decr (~1 to 2% per min)

If 'S66 SPLY H₂O TEMP', SUPPLY H₂O NOZ T A,B (two) < 90, terminate dump immediately per step H (SUPPLY H₂O DUMP TERMINATION), 5–6

NOTE

If dump terminated for SUPPLY H₂O NOZ T < 90, ✓ MCC about dumping supply water thru FES, thru waste water nozzle, or into CWC to make ullage for fuel cell product water

G. WASTE H₂O DUMP INITIATION

SM 66 ENVIRONMENT

CAUTION

Tile debonding may occur if nozzle temps exceed 350 degF

- CRT 1. When 'S66 WASTE H₂O TEMP' msg, WASTE H₂O NOZ T A,B (two) exceed 250 (~10 min warmup time), continue

CAUTION

Dumping WASTE H₂O TK1 QTY below 5% can cause bellows damage

Cont next page

- ML31C 2. ✓WASTE H2O TK1 VLV – OP (tb–OP)
 3. DUMP VLV – OP (tb–OP)
 CRT 4. WASTE H2O QTY 1 – decr (~1 to 2%
 per min)
 5. ✓WASTE H2O NOZ T A,B (two) – not incr
- If 'S66 WASTE H2O TEMP' msg, WASTE
 H2O NOZ T A(B) '↓' then:
 ML31C 6. WASTE H2O DUMP VLV – CL
 (tb–CL)
 7. When 'S66 WASTE H2O TEMP' msg,
 WASTE H2O NOZ T A,B (two) exceed
 250 (~8 min reheat time), continue
 8. WASTE H2O DUMP VLV – OP
 (tb–OP)
- H. SUPPLY H2O DUMP TERMINATION
- R11L 1. SPLY H2O DUMP ISOL VLV – CL (tb–CL)
 CRT 2. ✓SUPPLY H2O QTY A(B,C,D) not decr
- R11L * If SUPPLY H2O QTY A(B,C,D) decr, *
 * cycle SPLY H2O DUMP ISOL VLV *
 * If not successful, *
 * SPLY H2O DUMP VLV – CL (tb–CL) *
- CRT 3. When 'S66 SPLY H2O TEMP' msg,
 SUPPLY H2O NOZ T A,B (two) exceed
 250 (~10–12 min bakeout time), continue
- R11L 4. SPLY H2O DUMP VLV – CL (tb–CL), wait
 60 sec
 5. SPLY H2O DUMP VLV – OP (tb–OP), wait
 60 sec
 6. SPLY H2O DUMP VLV – CL (tb–CL)
 7. SPLY H2O DUMP ISOL VLV – OP
 (tb–OP)
 8. SPLY H2O DUMP VLV ENA/NOZ
 HTR – OFF
 9. ✓SPLY H2O DUMP VLV tb – bp

Cont next page

- CRT 10. ✓SUPPLY H₂O NOZ T A,B (two) – not incr
- ML86B:A * If SPLY H₂O NOZ T A,B (two) incr: *
 * cb MNC SPLY H₂O DUMP *
 * VLV/NOZ HTR – op *
- WCS 11. Remove, stow SPLY H₂O Dumpline Purge
Outboard Device from CONT H₂O X-TIE POT QD
Wall
- ML31C I. WASTE H₂O DUMP TERMINATION
CRT 1. WASTE H₂O DUMP VLV – CL (tb-CL)
 ✓QTY 1 not decr
- ML31C * If WASTE H₂O QTY 1 decr: *
 * Cycle WASTE H₂O DUMP VLV *
 * If not successful, *
 * WASTE H₂O DUMP ISOL VLV – *
 * CL (tb-CL) *
- CRT 3. When 'S66 WASTE H₂O TEMP' msg,
 WASTE H₂O NOZ T A,B (two) exceed
 250 (~8 min bakeout time), continue
- ML31C 4. WASTE H₂O DUMP VLV ENA/NOZ HTR –
 OFF
 5. ✓WASTE H₂O DUMP VLV tb – bp
- * If WASTE H₂O NOZ T A,B (two) incr: *
 * cb MNA WASTE H₂O DUMP *
 * VLV/NOZ HTR – op *
- J. SIMO DUMP H₂O TK N2 REG RECONFIG
If simo SPLY/WASTE H₂O DUMP performed,
execute following after both dumps complete:

- MO10W If Cab P < 14.7 psia or PCS1 active:
 1. H₂O TK N2 REG INLET SYS 2
 vlv – CL
 If PCS2 active:
 2. H₂O TK N2 REG INLET SYS 1
 vlv – CL

Cont next page

K. POST-DUMP FDA CLEANUP
If comm, MCC will reset SM limits via TMBU

If no comm, reset SM limits via table C for
SPLY H2O DUMP, table D for WST H2O
Dump, or both for simo SPLY/WST H2O
Dump

TABLE C

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
SUPPLY H2O NOZ T A	0620440	-82	250
	B 0620439	-82	250

TABLE D

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H2O NOZ T A	0620520	-82	250
	B 0620519	-82	250

NOTE

If WASTE H2O and SUPPLY QTY limits
were reset to annunciate end of dump,
leave limits at annunciation value

SUPPLY WATER DUMP USING FES

NOTE

If PASS SM avail, monitor tank QTY;
otherwise, monitor dump time provided
by MCC

Approx 8%/hr net supply water used by this
method

1. DUMP INITIATION

- L1 FLASH EVAP CNTLR PRI A,B,SEC (three) – OFF
RAD CNTLR OUT TEMP – HI
O1 When FREON EVAP OUT TEMP > 50 degF,
L1 FLASH EVAP CNTLR PRI A(B) – ON
After 1 min, ✓FREON EVAP OUT TEMP
~39 degF

2. DUMP TERMINATION

- L1 RAD CNTLR OUT TEMP – NORM
FLASH EVAP CNTLR PRI A(B) – OFF
If FES reqd, wait 1 min, then:
O1 When FREON EVAP OUT TEMP < 40 degF,
L1 FLASH EVAP CNTLR PRI A(B) – ON

MEDS

A5-9 ORB OPS/MEDS/GEN H

CABIN TEMP CONTROL**SM 88 APU/ENVIRON THERM**

CREW ACTION	Δ TEMP degF EXPECTED
✓MCC	
Implement ECLS SSR-6 CABIN EQUIP PWRDN-----	
✓H2O LOOP 2(1) ICH FLOW 950 -----	{ 1 to 9 degF 8 degF
(L1) FLOW PROP VLV LOOP 2 – ICH ----- (✓MCC for payload impact)	{ 1 degF
FLOW PROP VLV LOOP 1 – ICH ----- (✓MCC for payload impact)	{ 4 degF
(MD44F) CAB TEMP CNTLR vlv – FULL COOL --	{ 6 degF
– 2/3 COOL -----	{ 4 degF
– 1/3 COOL -----	{ 4 degF
– FULL HEAT --	{ 4 degF
(L1) FLOW PROP VLV LOOP 1 – PL ----- 2 – PL -----	{ 1 degF
H2O LOOP 2 BYP MAN – DECR until H2O LOOP 2 ICH FLOW MAX-----	{ 8 degF
H2O PUMP LOOP 1 – ON, B ----- H2O LOOP 1,2 BYP MAN – DECR until H2O LOOP 1,2 ICH FLOW MAX	{ 5 degF
FLASH EVAP CNTLR PRI A,B – OFF SEC – OFF	
✓MCC	

MEDS

A5-10 ORB OPS/MEDS/GEN H

SUPPLY WATER DUMP USING FES

NOTE

If PASS SM avail, monitor tank QTY;
otherwise, monitor dump time provided
by MCC

Approx 8%/hr net supply water used by this
method

1. DUMP INITIATION

- L1 FLASH EVAP CNTLR PRI A,B,SEC (three) – OFF
RAD CNTLR OUT TEMP – HI
O1 When FREON EVAP OUT TEMP > 50 degF,
L1 FLASH EVAP CNTLR PRI A(B) – ON
After 1 min, ✓FREON EVAP OUT TEMP
~39 degF

2. DUMP TERMINATION

- L1 RAD CNTLR OUT TEMP – NORM
FLASH EVAP CNTLR PRI A(B) – OFF
If FES reqd, wait 1 min, then:
O1 When FREON EVAP OUT TEMP < 40 degF,
L1 FLASH EVAP CNTLR PRI A(B) – ON

NOM

B5-9 ORB OPS/NOM/GEN H

CABIN TEMP CONTROL

SM 88 APU/ENVIRON THERM

	CREW ACTION	Δ TEMP degF EXPECTED
	✓MCC	
	Implement ECLS SSR-6 CABIN EQUIP PWRDN-----	
	✓H2O LOOP 2(1) ICH FLOW 950 -----	1 to 9 degF
(L1)	FLOW PROP VLV LOOP 2 – ICH ----- (✓MCC for payload impact)	8 degF
	FLOW PROP VLV LOOP 1 – ICH ----- (✓MCC for payload impact)	1 degF
	(MD44F) CAB TEMP CNTLR vlv – FULL COOL -- – 2/3 COOL ----- – 1/3 COOL ----- – FULL HEAT --	4 degF
(L1)	FLOW PROP VLV LOOP 1 – PL ----- 2 – PL -----	6 degF
	H2O LOOP 2 BYP MAN – DECR until H2O LOOP 2 ICH FLOW MAX-----	4 degF
(C2)	Pwr up one or two CRTs as reqd ----- H2O PUMP LOOP 1 – ON, B ----- H2O LOOP 1,2 BYP MAN – DECR until H2O LOOP 1,2 ICH FLOW MAX	1 degF
	FLASH EVAP CNTLR PRI A,B – OFF SEC – OFF	8 degF
	✓MCC	5 degF

NOM

B5-10

ORB OPS/NOM/GEN H

**CO2 RMVL SYS CNTLR CONFIG:
ACT 1/DEACT 2 (ACT 2/DEACT 1)**

ML86B:E ✓cb MNA,C CO2 SYS 1,2 CNTLR (two) – cl

MO51F CNTLR 2(1) MODE – STBY (hold 3 sec)
Wait 6 sec

✓CNTLR 2(1) OPER lt – off
✓FAIL lt – on
MNC(MNA) – OFF
✓CNTLR 2(1) FAIL lt – off
AC3(AC1) – OFF (hold 3 sec)
cb AC3(AC1) (three) – op
AC1(AC3) (three) – cl
AC1(AC3) – ON (hold 3 sec)
MNA(MNC) – ON
CNTLR 1(2) MODE – OPER (hold 3 sec)
Wait 6 sec

✓CNTLR 1(2) OPER lt – on
✓COM INSTR – ON

CHARCOAL CANISTER REPLACEMENT

Perform if CO2 RMVL SYS CNTLR CONFIG
accomplished as part of midflight reconfig:

- a. Remove and replace charcoal canister, if manifested
- b. Reseal used charcoal canister with wrapper and Gray Tape, stow

MD54G

RAD BYPASS/FES C/O

NOTE

Procedure bypasses radiators and performs checkout of Secondary (Topper and Hi-Load) and PRI B (Full Up) FES controllers. Expect 'S88 EVAP OUT T 1(2)' msgs

1. ✓DAP: A/AUTO/ALT(PRI)
- R11L 2. ✓SPLY H2O XOVR VLV – OP (tb-OP)
- L1 3. FLASH EVAP CNTLR PRI A – OFF
 B – OFF
 SEC (two) – A SPLY,ON
 ✓HI LOAD DUCT HTR – B
 EVAP – ENA
- O1 4. RAD BYP VLV MODE (two) – MAN
 MAN SEL (two) – BYP
 (tb-BYP ~3 sec)
 RAD CNTLR LOOP (two) – OFF
 After 2.5 min, ✓FREON EVAP
 OUT TEMP ind: 62 deg ± 2 degF
- L1 5. HI LOAD EVAP – OFF
 After 2.5 min, ✓FREON EVAP
- O1 6. HI LOAD EVAP – ENA
- O1 7. FLASH EVAP CNTLR SEC (two) – A SPLY,OFF
 PRI B – ON
 After 2.5 min, ✓FREON EVAP
 OUT TEMP ind: 39 deg ± 1 degF
- L1 8. ✓FLOW PROP VLV LOOP 1,2 (two) tb – ICH
9. RAD CNTLR OUT TEMP – NORM

MODIFIED RAD BYP/FES C/O AND TOPPING CORE FLUSH

NOTE

Following procedure should be used if icing is suspect cause of FES shutdown. Use on MCC call. Expect 'S88 EVAP OUT T 1(2)' msgs

- R11L 1. ✓DAP: A/AUTO/ALT(PRI)

L1 2. ✓SPLY H2O XOV R VLV – OP (tb–OP)

L1 3. FLASH EVAP CNTLR PRI A – OFF
B – OFF
SEC (two) – A SPLY, ON
✓HI LOAD DUCT HTR sel – B
EVAP – ENA
TOP EVAP HTR DUCT sel – A/B

L1 4. RAD BYP VLV MODE (two) – MAN
MAN SEL (two) – BYP
(tb–BYP ~3 sec)
RAD CNTLR LOOP (two) – OFF
After 2.5 min, ✓FREON EVAP
OUT TEMP ind: 62 deg ± 2 degF

O1

L1 5. FLASH EVAP CNTLR SEC – OFF
HI LOAD EVAP – OFF
Wait 2 min

L1 6. FLASH EVAP CNTLR SEC – ON
Wait 30 sec
FLASH EVAP CNTLR SEC – OFF
Wait 30 sec

L1 7. Repeat step 6 two additional times (three total),
then:
FLASH EVAP CNTLR SEC – ON

Cont next page

8. Proceed on MCC call (if no comm, wait minimum 7 min, then proceed when EVAP OUTs stable at 62 and TOP FWD(AFT) DUCT temps > 120 degF)
 - * While waiting, if TOP FWD(AFT) *
 - * DUCT < 40, proceed to step 9 *
 - * Flush not successful *
9. FLASH EVAP CNTLR SEC – OFF
HI LOAD EVAP – ENA
If successful flush:
 - FLASH EVAP CNTLR PRI B – ONIf not successful flush:
 - FLASH EVAP CNTLR SEC – ON
10. ✓FLOW PROP VLV LOOP 1,2 tb (two) – ICH
11. RAD CNTLR OUT TEMP – NORM

RAD DEPLOY

NOTE

If RMS uncradled, ✓MCC for priority of RAD deploy/RMS ops. If MCC not avail and RADs must be deployed immediately, continue ops. Expect PORT RAD, LAT 7–12, STBD LAT 1–6 to operate single motor

WARNING

To preclude inadvertent MPM cycling:
cb MCA PWR AC2 3Φ MID 2
AC3 3Φ MID 4
must remain open if RMS uncradled

1. CONFIG CBS

MA73C:
C,D

DESIRED ACTION	cb CONFIG
Deploy PORT RAD	cb MCA PWR AC1 3Φ MID 3 – op AC2 3Φ MID 2 – op AC3 3Φ MID 2 – op
Deploy STBD RAD	cb MCA PWR AC1 3Φ MID 1 – op AC2 3Φ MID 4 – op AC3 3Φ MID 4 – op

2. UNLATCH PANELS

R13L

- ✓RAD LAT CNTL SYS A,B (two) – OFF
- ✓CNTL SYS A,B (two) – OFF
- ✓RAD,LAT PORT,STBD tb (four) match current RAD config

PL BAY MECH PWR SYS 1,2 (two) – ON

RAD LAT CNTL SYS A,B (two) – REL
(✓Deploying RAD LAT tb(s)–bp, ~30 sec REL)
RAD LAT CNTL SYS A,B (two) – OFF

Cont next page

- * If deploying RAD LAT tb not REL in *
- * 30 sec: *
- * RAD LAT CNTL SYS A,B (two) – OFF *
- * Perform MAL, MECH, 9.2a *

3. DEPLOY PANELS

RAD CNTL SYS A,B (two) – DPY
 (√Deploying RAD tb(s)–bp, ~50 sec DPY)

RAD CNTL SYS A,B (two) – OFF

- * If deploying RAD tb(s) not bp after 10 sec *
- * and no motion, or *
- * If RAD panel(s) in transit and no motion, or *
- * If deploying RAD tb not DPY within *
- * 50 sec: *
- * RAD CNTL SYS A,B (two) – OFF *
- * Perform MAL, MECH, 9.2b *

PL BAY MECH PWR SYS 1,2 (two) – OFF

4. RECONFIG CBS

If cbs were opened for single RAD deploy,
 config cbs:
 MA73C:
 C,D

COMPLETED ACTION	cb CONFIG
PORT RAD Deployed	cb MCA PWR AC1 3Φ MID 3 – cl AC2 3Φ MID 2 – cl (unless RMS uncradled) AC3 3Φ MID 2 – cl
STBD RAD Deployed	cb MCA PWR AC1 3Φ MID 1 – cl AC2 3Φ MID 4 – cl AC3 3Φ MID 4 – cl (unless RMS uncradled)

RAD STOW

NOTE

If RMS uncradled, PORT RAD, LAT 7–12, and STBD LAT 1–6 will operate single motor (cbs are pulled to safe MPMs)

WARNING

To preclude inadvertent MPM cycling:
cb MCA PWR AC2 3Φ MID 2
AC3 3Φ MID 4
must remain open if RMS uncradled

1. CONFIG CBS

MA73C:
C,D
If stowing single RAD and opposite RAD deployed, config cbs:

DESIRED ACTION	cb CONFIG
Stow PORT RAD	cb MCA PWR AC1 3Φ MID 3 – op AC2 3Φ MID 2 – op AC3 3Φ MID 2 – op
Stow STBD RAD	cb MCA PWR AC1 3Φ MID 1 – op AC2 3Φ MID 4 – op AC3 3Φ MID 4 – op

2. STOW PANELS

R13L
✓RAD LAT CNTL SYS A,B (two) – OFF
✓CNTL SYS A,B (two) – OFF
✓RAD,LAT PORT,STBD tb (four) match current RAD config

PL BAY MECH PWR SYS 1,2 (two) – ON

RAD CNTL SYS A,B (two) – STO
(✓Stowing RAD tb(s)–bp, ~50 sec STO)
RAD CNTL SYS A,B (two) – OFF

Cont next page

- * If stowing RAD tb(s) not bp after 10 sec *
- * and no motion, or *
- * If RAD panel(s) in transit and no motion, *
- * or *
- * If stowing RAD tb not STO within 100 sec *
- * and no motion: *
- * RAD CNTL SYS A,B (two) – OFF *
- * Perform MAL, MECH, 9.2b *

3. LATCH PANELS

RAD LAT CNTL SYS A,B (two) – LAT
 (√ Stowing RAD LAT tb(s)–bp, ~30 sec, LAT)
 RAD LAT CNTL SYS A,B (two) – OFF

- * If stowing RAD LAT tb not LAT in *
- * 60 sec: *
- * RAD LAT CNTL SYS A,B (two) – *
- * OFF *
- * Perform MAL, MECH, 9.2a *

PL BAY MECH PWR SYS 1,2 (two) – OFF

4. RECONFIG cbs

MA73C:
 C,D
 If cbs were pulled for single RAD stow, config
 cbs:

COMPLETED ACTION	cb CONFIG
PORT RAD stowed	cb MCA PWR AC1 3Φ MID 3 – cl AC2 3Φ MID 2 – cl (unless RMS uncradled) AC3 3Φ MID 2 – cl
STBD RAD stowed	cb MCA PWR AC1 3Φ MID 1 – cl AC2 3Φ MID 4 – cl AC3 3Φ MID 4 – cl (unless RMS uncradled)

PCS 1(2) CONFIG

If FD1:

S66 ENVIRONMENT

CRT,O1 Report cabin pressure (two) to MCC

Expect possible 'S66 CAB O2(N2) FLO 1(2)' msg

MO10W 14.7 CAB REG INLET SYS 1(2) vlv – OP
2(1) vlv – CL

O2 REG INLET SYS 1(2) vlv – OP
2(1) vlv – CL

H2O TK N2 REG INLET SYS 1(2) vlv – OP
2(1) vlv – CL

✓ISOL SYS 1,2 vlv (two) – OP

✓PPO2 CNTLR SYS 1,2 (two) – NORM

✓N2 XOVER vlv – CL

✓PL O2 SYS 1,2 vlv – CL

✓N2 SYS 1,2 vlv – CL

If no internal Airlock:

Middeck Floor ✓EMU O2 ISOL VLV – CL

L2 ✓O2 SYS 1,2 SPLY (two) – ctr (tb–OP)
✓XOVR SYS 1,2 (two) – OP
✓N2 SYS 1,2 SPLY (two) – ctr (tb–OP)
✓REG INLET (two) – ctr (tb–OP)
O2/N2 CNTLR VLV SYS 1(2) – AUTO
✓2(1) – CL

O1 ✓O2/N2 FLOW sel – SYS 1(2) O2
✓PPO2 sel – SNSR A(B)

VENT SAFING

O14:D ✓cb MNA CAB VENT – op
✓VENT ISOL – op

TOPPING FES DEACTIVATION

L1 FLASH EVAP CNTLR PRI A,B – OFF
 SEC – OFF
Wait 30 min

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
EVAP TEMP TOPPING AFT	0631802	-10	
FWD	0631801	-10	
L DUCT	0631800	-10	
NOZ	0631878	-10	
R DUCT	0631810	-10	
NOZ	0631879	-10	

TOP EVAP HTR DUCT – OFF
NOZ L,R – OFF

TOPPING FES STARTUP

1. HEATER ACTIVATION
L1 ✓TOP EVAP HTR DUCT – A(B,C)
 ✓NOZ L,R – A(B) AUTO


* If htrs were off, wait 90 min *

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
EVAP TEMP TOPPING AFT	0631802	100	
FWD	0631801	100	
L DUCT	0631800	50	
NOZ	0631878	40	
R DUCT	0631810	50	
NOZ	0631879	40	

2. FES STARTUP

- CRT SM 79 SM SYS SUMM 2
L1 If FREON EVAP OUT TEMP > 41 and ≤ 47 degF:
 RAD CNTLR OUT TEMP – HI
CRT When FREON EVAP OUT TEMP > 50 degF,
L1 RAD CNTLR OUT TEMP – NORM, then
 immediately:
 FLASH EVAP CNTLR PRI A(B) – ON
CRT If FREON EVAP OUT TEMP ≤ 41 or > 47 degF:
L1 FLASH EVAP CNTLR PRI A(B) – ON

SMOKE DETN CKT TEST



NOTE

If any SMOKE DETN It fails to illum (except PAYLOAD), open and close associated cb (pnl O14/O15/O16) and repeat test. For PART 2 TESTS only, allow 60 sec to take SMOKE DETN CKT TEST – OFF

CKT TEST A PART 1

- L1 SMOKE DETN CKT TEST – A
 - ✓ FIRE SUPPR AV BAY pb (three) – Its on
Wait at least 5 sec (no more than 10 sec)
SMOKE DETN CKT TEST – OFF
 - ✓ FIRE SUPPR AV BAY pb (three) – Its off
 - ✓ SMOKE DETN A Its (five) – on
 - ✓ Siren – on
- F2 ✓ MSTR ALARM It – on
 pb – off
- L1 SMOKE DETN SNSR – RESET
 - ✓ Above lights and siren – off

Cont next page

CKT TEST A PART 2

SMOKE DETN CKT TEST – A
✓ FIRE SUPPR AV BAY pb (three) – Its on

In 15–25 sec:

- ✓ SMOKE DETN A Its (five) – on
- ✓ Siren – on

F2

✓ MSTR ALARM It – on

MSTR ALARM pb – off

L1

SMOKE DETN CKT TEST – OFF

SNSR – RESET

- ✓ Above lights and siren – off

CKT TEST B PART 1

SMOKE DETN CKT TEST – B
✓ FIRE SUPPR AV BAY pb (three) – Its on

Wait at least 5 sec (no more than 10 sec)

SMOKE DETN CKT TEST – OFF

- ✓ FIRE SUPPR AV BAY pb (three) – Its off
- ✓ SMOKE DETN B Its (four) – on (PL It off)

- ✓ Siren – on

F2

- ✓ MSTR ALARM It – on
- pb – off

L1

SMOKE DETN SNSR – RESET

- ✓ Above lights and siren – off

CKT TEST B PART 2

SMOKE DETN CKT TEST – B

- ✓ FIRE SUPPR AV BAY pb (three) – Its on

In 15–25 sec:

- ✓ SMOKE DETN B Its (four) – on (PL It off)
- ✓ Siren – on

F2

- ✓ MSTR ALARM It – on

MSTR ALARM pb – off

L1

SMOKE DETN CKT TEST – OFF

SNSR – RESET

- ✓ Above lights and siren – off

Cont next page

CRT

SM SYS SUMM 1

Verify:

SMOKE	1/A	2/B
CABIN	-.5 to +.5	
L/R FD	-.5 to +.5	-.5 to +.5
AV BAY 1	-.5 to +.5	-.5 to +.5
2	-.5 to +.5	-.5 to +.5
3	-.5 to +.5	-.5 to +.5

If limits exceeded, ✓MCC

SHUTTLE/ISS H2O CONTAINER FILL

NOTE

For CWC or RSA EDV Tank fill. Assumes galley iodine removal hardware (LIRS or GIRA) already installed. Refer to flight-specific iodine removal procedures for galley iodine removal config. To minimize contamination possibility, avoid touching any internal parts of QDs or connections

EQUIPMENT PREPARATION

Unstow from designated stowage when needed:

Towel(s), CWCs, Sample/Purge Kit (contains Sample Bags (mylar), Purge Bags (clear), Needle Adapter, Sampling Adapter), mineral and silver biocide syringe kits. Retrieve “-2” adapter (EDV QD Adapter) if filling EDVs

TEE/HOSE ASSEMBLY PURGE (Perform ONLY if GIRA installed. See fig 5-1)

NOTE

TEE/HOSE ASSEMBLY PURGE reqd only if prior to first fill or three or more days since last fill

- ML90N
1. Retrieve Needle Adapter from Sample/Purge kit. Attach to injection port on tee at end of CWC Hose coming from tee of previously installed ACTEX
 2. Remove cap on Needle Adapter and attach Purge Bag. Open valve on injection port and fill bag to capacity (about 12 ounces). Close valve when capacity reached
 3. Disconnect bag from Needle Adapter. Stow Bag in Ziploc and place in crew-designated location (empty fresh food locker suggested). Replace cap on Needle Adapter and temp stow adapter until further use

Cont next page




Figure 5–1.– Initial purge setup; tee/hose coming from GIRA.

CWC FILL (see fig 5–2)

NOTE

Potable water is water to which both silver biocide and minerals are added. Technical water is water to which only silver biocide is added

Do not squeeze CWC while filling. This may result in water backflow into connecting equipment and galley. Do not detach or move quantity measurement strap (if flown)

4. Retrieve desired number of CWCs. Report condition to MCC–H

NOTE

For Potable CWCs, ALWAYS add minerals first

CWC will begin filling as soon as it is connected to free end of ACTEX or tee/hose assembly

- ML90N 5. Attach CWC to free end of ACTEX (if LIRS installed) or tee/hose assembly (if GIRA installed)

Cont next page

6. Remove cap from syringe. At injection port nearest to CWC, remove cap and install syringe. Open valve on injection port and inject solution. Slowly withdraw syringe plunger fully, filling syringe with water, then reinject. Close valve on injection port when final injection complete
7. Remove syringe and stow in empty syringe location




Figure 5–2.– CWC or EDV fill setup.

FILL TERMINATION

8. If quantity indicator flown:
If NO COMM, terminate fill if quantity indicator shows yellow/white transition (see fig 5–3)
If COMM, terminate fill on MCC call or when quantity indicator shows yellow/white transition, whichever occurs first
9. To terminate fill, disconnect CWC from ACTEX (if LIRS) or tee/hose assembly (if GIRA). Flow to CWC will stop when this action performed

Cont next page

10. If no samples reqd, fill out CWC label and temp stow CWC until transferred to ISS. If samples reqd, fill out CWC label, then go to CWC SAMPLING PROCEDURE and/or CARTRIDGE ASSEMBLY SAMPLING PROCEDURE
11. Report barcode and serial number (located on CWC label) to MCC-H




Figure 5–3.– Quantity measuring strap and CWC details.

Cont next page

CWC SAMPLING PROCEDURE (if reqd. See fig 5-4)

NOTE

If filling Technical CWCs, use ONLY sampling hardware with green valve handle. Sampling hardware with blue handle is for Potable CWCs only

12. Retrieve Sample/Purge kit and obtain Sampling Adapter. Connect Luer-lock end to Sample Bag. Connect QD end of Sampling Adapter to CWC. Ensure manual valve set to open posn. Fill bag (estimate visually) by squeezing CWC. When complete, close manual valve and remove Sample Bag. Fill out Sample Bag label, stow in Ziploc Bag, and place in crew-designated sample stowage location
13. Disconnect Sampling Adapter from CWC and stow in Sample/Purge kit. Temp stow CWC until transferred to ISS




Figure 5-4.– CWC sample setup.

Cont next page

ACTEX CARTRIDGE SAMPLING PROCEDURE
(if reqd)

- ML90N 14. At injection port on ACTEX cartridge, remove cap, connect Needle Adapter
15. Connect clear Purge Bag to Needle Adapter. Open valve on injection port and fill bag to ~4 oz (estimate visually)
16. When complete, close valve on injection port and remove bag. Fill out label. Stow Sample Bag in Ziploc Bag and place in crew-designated sample stowage location
17. Remove and temp stow Needle Adapter. Replace cap on injection port

EDV TANK FILL PROCEDURE (see fig 5-2)

NOTE

Procedure assumes TEE/HOSE ASSEMBLY PURGE has already been completed

1. Retrieve desired number of EDV tanks (usually preassembled with lids), fill indicator, “-2” adapter, EDV tank hose (US-PB or US/RSA-B)
- ML90N 2. Install “-2” adapter to free end of ACTEX (if LIRS) or Tee/Hose assembly (if GIRA)
3. Attach free end of “-2” adapter to EDV tank hose, and free end of hose to EDV tank hose fitting (remove cap if present)

Cont next page

NOTE

EDV will begin filling as soon as it is connected to “–2” adapter

4. On EDV tank lid, remove plug from fitting designated “Supply Pressure” (ПОДАЧА ДАБЛЕНИЯ). Remove plug from opposite fitting and install fill indicator in that fitting (Note: This fitting will not have filter screen)

NOTE

For Potable EDVs, ALWAYS add minerals first

5. Remove cap from syringe. At injection port nearest to EDV, remove cap and install syringe. Open valve on injection port and INJECT ONLY 1/2 OF SYRINGE. When complete, remove syringe and replace syringe cap. Stow syringe in location from which it came
6. Retrieve empty syringe from syringe kit and remove cap. Verify syringe plunger fully depressed. At injection port nearest to EDV, install empty syringe. Slowly withdraw syringe plunger fully, filling syringe with water, then reinject. Repeat once. After last reinjection, remove empty syringe and replace cap on syringe and injection port
7. On MCC-H call, check that EDV fill indicator shows red band. If red band shows, disconnect EDV from tank hose
8. Remove fill indicator from fitting and replace plug. Install other plug on “Supply Pressure” (ПОДАЧА ДАБЛЕНИЯ) fitting. Reinstall cap on tank hose fitting on lid (if cap present). Label EDV as reqd using spare labels from kit, then temp stow EDV until transferred to ISS

CWC OVERBOARD DUMP

NOTE

Use for dump of CWC(s) containing waste or supply water, or shuttle/ISS condensate. If CWC hose contains waste or shuttle/ISS condensate, use "CWC hose" instead of Y-Y hose.

If PASS SM avail, monitor waste dumpline and nozzle temps; otherwise, dump only when MCC available to monitor. Have towels ready to absorb any liquid released when mating or demating QDs

1. DUMP PREP

- BOB CHCK Obtain CWCs to be dumped
Unstow Waste Water Dump (WWD) filter
Unstow Y-Y (CWC) hose
- ML31C WASTE H2O DUMP ISOL VLV – CL (tb-CL)
- WCS OUTBD WALL Connect female end of WWD filter to Cont H2O X-tie Waste QD (upper QD with yellow Velcro and "WASTE" label)
Connect Y-Y (CWC) hose to male end of WWD filter
Connect free end of Y-Y (CWC) hose to CWC
Change limits via table or request MCC TMBU:

SM 60 SM TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H2O NOZ T A	0620520	50	250
	B	50	250

On MCC GO, proceed to step 2

Cont next page

2. HEATER ACTIVATION

SM 66 ENVIRONMENT

✓WASTE H2O DMP LN T > 50

- * If WASTE H2O DMP LN T ≤ 50, *
 - * enable 2nd htr: *
 - ML86B:A * cb MNB(MNA) H2O LINE *
 - * HTR B(A) – cl *
- ML31C WASTE H2O DUMP VLV ENA/NOZ HTR – ON
 - ✓VLV – CL (tb-CL)
 - ✓ISOL VLV – CL (tb-CL)

3. DUMP INITIATION

- CRT When WASTE H2O NOZ T A,B (two) > 250
(8–10 min),
ML31C WASTE H2O DUMP VLV – OP (tb-OP)
CRT ✓WASTE H2O NOZ T A,B (two) – not incr
If 'S66 WASTE H2O TEMP', WASTE H2O
NOZ T A(B) '↓':
 - * WASTE H2O DUMP VLV – CL (tb-CL) *
 - * When WASTE H2O NOZ T A,B (two) *
 - * > 250 (~8 min), *
 - * WASTE H2O DUMP VLV – OP *
 - * (tb-OP) *

NOTE

Periodically monitor CWC and hose. Ensure
no hose kinks or signs of CWC collapse

4. DUMP TERMINATION

Terminate on MCC call, or if no comm, upon any
signs of CWC collapse

- ML31C WASTE H2O DUMP VLV – CL (tb-CL)
Disconnect CWC from Y-Y (CWC) hose, and
temp stow empty CWC

If dumping multiple CWCs sequentially:
Connect next CWC to Y-Y (CWC) hose
Repeat step 3

Cont next page

CRT When WASTE H₂O NOZ T A,B (two) > 250 (~8 min),
 ML31C WASTE H₂O DUMP VLV ENA/NOZ HTR – OFF
 ✓WASTE H₂O DUMP VLV tb – bp
 * If WASTE H₂O NOZ T A,B (two) incr: *
 ML86B:A * cb MNA WASTE H₂O DUMP *
 * VLV/NOZ HTR – op *

5. POST-DUMP RECONFIG

WCS Disconnect WWD filter from Cont H₂O X-tie
 OUTBD Waste QD and Y-Y (CWC) hose from filter
 WALL

ML31C WASTE H₂O DUMP ISOL VLV – OP (tb-OP)
 Stow empty CWC(s)
 If additional CWC dump(s) to be performed:
 Temp stow WWD filter (place filter in Ziploc Bag) and Y-Y (CWC) hose

CHCK If final CWC dump:
 BOB Stow Y-Y (CWC) hose
 Stow WWD filter (place filter in Ziploc Bag)

6. POST-DUMP FDA CLEANUP

Change limits via table or request MCC TMBU:

SM 60 SM TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H ₂ O NOZ T A	0620520	-82	250
B	0620519	-82	250

CABIN TEMP CONTROLLER RECONFIG – 2(1)

L1 CAB TEMP sel – WARM
Wait 10 sec, then:
MD44F CAB TEMP CNTLR – OFF
L1 Pin CAB TEMP CNTL act link – SEC(PRI) ACT
 CAB TEMP CNTLR – 2(1)
 sel – as reqd

SHUTTLE CONDENSATE COLLECTION

SETUP

1. Unstow:
 - Y/Y Hose
 - Contingency Water Container (CWC),
report barcode and serial number to MCC
 - Towel
 - Gray Tape
2. Attach CWC to Y/Y Hose
3. Label CWC with Gray Tape marked
“CONDENSATE, DO NOT TRANSFER TO ISS”
- ML86B:B 4. cb MNB WASTE H2O TK1 DRAIN – cl

NOTE

Catch any water droplets with towel. Waste Tank Drain config (step 6) should be performed ASAP after attaching Y/Y Hose to Condensate QD to prevent possible backflow of waste tank contents into condensate CWC

MIDDECK

- FLR 5. Attach Y/Y Hose to Condensate QD
- ML31C 6. WASTE H2O TK1 DRAIN VLV – CL (tb-CL)
- ML86B:B 7. cb MNB WASTE H2O TK1 DRAIN – op
8. Position, secure all hardware
9. Mark start MET on CWC label
10. Notify MCC, CONDENSATE FILL initiated
11. ✓CWC fill progress every 24 hr

TEARDOWN

- ML86B:B 1. cb MNB WASTE H2O TK1 DRAIN – cl
- ML31C 2. WASTE H2O TK1 DRAIN VLV – OP (tb-OP)
- ML86B:B 3. cb MNB WASTE H2O TK1 DRAIN – op

NOTE

Catch any water droplets with towel

4. Remove, stow all hardware

PWR OVERBOARD DUMP

NOTE

If PASS SM avail, monitor waste dump line and nozzle temps, otherwise dump only when MCC available to monitor.
Have towels ready to absorb any liquid released when mating or demating QDs

1. DUMP PREP

- BOB

ML31C WASTE H₂O DUMP ISOL VLV – CL (tb-CL)
WCS Connect female end of WWD filter to Cont H₂O
OUTBD X-tie Waste QD (upper QD with yellow Velcro
WALL and “WASTE” label)
 Connect yellow end of R-Y QD adapter to free
 end of WWD filter
 Connect B-B hose to free end of R-Y QD
 adapter
 Connect free end of B-B hose to PWR

2. Change limits via table, or request MCC TMBU:

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H ₂ O NOZ T A	0620520	50	250
B	0620519	50	250

Proceed to step 3

3. HEATER ACTIVATION

SM 66 ENVIRONMENT

✓WASTE H₂O DMP LN T > 50

Cont next page

ML86B:A * If WASTE H₂O DMP LN T ≤ 50, *
 * enable second heater: *
 * cb MNB(MNA) H₂O LINE HTR B(A) – cl *

ML31C WASTE H₂O DUMP VLV ENA/NOZ HTR – ON
 ✓VLV – CL (tb-CL)
 ✓ISOL VLV – CL (tb-CL)

4. DUMP INITIATION

CRT When WASTE H₂O NOZ T A,B (two) > 250
(8–10 min),

ML31C WASTE H₂O DUMP VLV – OP (tb-OP)
CRT ✓NOZ T A,B (two) – not incr

If dumping multiple PWRs sequentially:

ML31C When PWR empty,
 WASTE H₂O DUMP VLV – CL (tb-CL)
 Disconnect empty PWR and temp stow
 Connect next PWR

CRT When WASTE H₂O NOZ T A,B (two) > 150,
ML31C WASTE H₂O DUMP VLV – OP (tb-OP)

If 'S66 WASTE H₂O TEMP', WASTE H₂O NOZ
T A,(B) '↓':

ML31C * WASTE H₂O DUMP VLV – CL (tb-CL) *
CRT * When WASTE H₂O NOZ T A,B (two) > 250 *
 * (~8 min), *
ML31C * WASTE H₂O DUMP VLV – OP (tb-OP) *

NOTE

Periodically monitor PWR and B-B
hose. Ensure no hose kinks or signs
of PWR collapse

5. DUMP TERMINATION

CRT Upon any sign of PWR collapse, or when
WASTE H₂O NOZ T A,B (two) > 250:

ML31C WASTE H₂O DUMP VLV – CL (tb-CL)
 Disconnect PWR from B-B hose and temp stow

Cont next page

CRT When WASTE H2O NOZ T A,B (two) > 250 (~8 min),
 ML31C WASTE H2O DUMP VLV ENA/NOZ
 HTR – OFF
 ✓WASTE H2O DUMP VLV tb – bp

CRT * If WASTE H2O NOZ T A,B (two) still incr: *
 ML86B:A * cb MNA WASTE H2O DUMP *
 * VLV/NOZ HTR – op *

6. POST-DUMP RECONFIG

WCS Disconnect WWD filter from Cont H2O X-tie
 OUTBD Waste QD, R-Y QD adapter from filter, and
 WALL B-B hose from adapter
 ML31C WASTE H2O DUMP ISOL VLV – OP (tb-OP)

Stow empty PWR(s)
 If additional PWR dump(s) to be performed later:
 Temp stow WWD filter, B-B hose, and R-Y QD adapter (place equipment in Ziploc Bags)

If final PWR dump of flight:

 BOB Stow B-B hose (place in Ziploc Bag)
 Stow R-Y QD adapter (place in Ziploc Bag)
 Stow WWD filter (place in Ziploc Bag)

7. POST-DUMP FDA CLEANUP

Change limits via table, or request MCC TMBU:

SM 60 TABLE MAINT

PARAMETER NAME	PARA ID	SM ALERT	
		LOW	HIGH
WASTE H2O NOZ T A	0620520	-82	250
B	0620519	-82	250

EMU WATER RECHARGE BAG FILL

- E-Lk 1. Unstow EMU Water Recharge Bag(s) (Payload Water Reservoir) from E-Lk floor bin, as reqd

CAUTION
Do not use water bags containing orange cards. These bags not certified for EMU use

2. Transfer bag(s) to orbiter galley

WATER FILL (ON MCC-H CALL)

NOTE

Do not perform Galley Ops or CWC fills while filling EMU Water Recharge Bags

If SPLY H2O XOVF VLV – CL (tb-CL) (water transfer config):

- R11L 3. SPLY H2O TKA OUTLET → CL (tb-CL)
SM 60 TABLE MAINT

4. Use TKA quantity:
PARAM ID – ITEM 1 +0 6 2 0 4 1 0 EXEC
5. Log bag serial number/barcode and TKA % value before recharge. Report bag serial number/barcode to MCC-H

Bag Serial Number/Barcode	H2O TKA %

CAUTION
Do not overfill EMU Water Recharge Bag as damage to bag may occur

Cont next page

NOTE

Full charge = 12% change in TKA
quantity and requires ~ 30 min

- Galley
6. MV2 vlv → Max AMB
 7. EMU Water Recharge Bag QD →|← Orbiter Galley Aux Port
 8. Set timer for 30 min
Attach timer to Velcro square on EMU Water Recharge Bag
 9. ✓H2O TKA quantity decreasing

VERIFYING WATER FILL

After approx 30 min:

SM 60 TABLE MAINT

10. Use TKA quantity:
PARAM ID – ITEM 1 +0 6 2 0 4 1 0 EXEC
11. Log bag serial number/barcode and TKA % value after recharge

Bag Serial Number/Barcode	H2O TKA %

NOTE

Full charge = 12% change in TKA quantity

To terminate fill:

12. EMU Water Recharge Bag →|← Orbiter Galley Aux Port
13. Temp stow EMU Water Recharge Bag for transfer to ISS

Cont next page

14. Repeat steps 4–13 for remaining bag(s)

After last bag filled:

Galley 15. MV2 vlv → as reqd

If SPLY H2O XOVR VLV – CL (tb–CL) (water transfer config):

16. SPLY H2O TKA OUTLET → OP (tb–OP)

17. Record fill date and quantity for bag(s) on white card. Report bag(s) serial number, fill date, and quantity of bags to MCC–H as comm permits

18. Transfer bag(s) to ISS


E–Lk 19. Stow bag(s) in floor bins

EPS

LAMP TEST	6-2
HEATER RECONFIG – CONFIG B(CONFIG A) ..	6-5
FUEL CELL PURGE – AUTO, SM 2(4)	6-6
– MANUAL	6-7
VI PERFORMANCE PLOT	6-8
CRYO O2 TK HTR SNSR CK	6-9
EDO PALLET CRYO O2 TK HTR SNSR CK	6-11
ACTIVATION	6-12
DEACT	6-13

EPS

LAMP TEST



C/W PANEL

EPS

O2 PRESS	H2 PRESS	FUEL CELL REAC (R)	FUEL CELL STACK TEMP	FUEL CELL PUMP
CABIN ATM (R)	O2 HEATER TEMP	MAIN BUS (R) UNDERVOLT	AC VOLTAGE	AC OVERLOAD
FREON LOOP	AV BAY/CABIN AIR	IMU	FWD RCS (R)	RCS JET
H2O LOOP	RGA/ACCEL	AIR DATA (R)	LEFT RCS (R)	RIGHT RCS (R)
— (R)	LEFT RHC (R)	RIGHT/AFT RHC (R)	LEFT OMS (R)	RIGHT OMS (R)
PAYOUT WARNING (R)	GPC	FCS (R) SATURATION	OMS KIT	OMS TVC (R)
PAYOUT CAUTION	PRIMARY C/W	FCS CHANNEL	MPS (R)	—
BACKUP C/W ALARM (R)	APU TEMP	APU OVERSPEED	APU UNDERSPEED	HYD PRESS

(34V73A7A2)

Cont next page

FORWARD STATION

O6/O8	ANNUN LAMP TEST – L, hold	
	✓78 lights – illuminated:	
O1	CAM Its	(25)
F2	MSTR ALARM	(1)
	Aerodynamic controls	(7)
	DRAG CHUTE	(2)
F3	NWS FAIL	(1)
	DRAG CHUTE	(1)
L1	FIRE SUPPR AV BAY	(3)
	SMOKE DETN	(10)
F6	LDG GEAR	(2)
	ABORT	(1)
	RCS CMD	(3)
	RANGE SAFE ARM	(1)
F7	SM ALERT	(1)
	C/W panel – partial	(20)

O6/O8	ANNUN LAMP TEST – R, hold	
	✓61 lights – illuminated:	
F4	MSTR ALARM	(1)
	Aerodynamic controls	(7)
	DRAG CHUTE	(1)
F3	ANTISKID FAIL	(1)
	DRAG CHUTE	(2)
F8	LDG GEAR	(2)
F7	MN ENG STAT	(3)
	C/W panel – partial	(20)
C3	DAP PANEL	(24)

MIDDECK (Verified by second crewmember)

O6/O8	ANNUN LAMP TEST – L, hold	
MO29J	✓MIC KEY light – illuminated	
O6/O8	ANNUN LAMP TEST – R, hold	
	✓5 lights – illuminated:	
MO52J	MSTR ALARM light	(1)
MO51F	RCRS CNTLR 1	(2)
	RCRS CNTLR 2	(2)

Cont next page

A6U AFT STATION
 ANNUN LAMP TEST – L, hold
 ✓25 lights – illuminated:
 DAP PANEL (24)
 MIC KEY (1)

A6U ANNUN LAMP TEST – R, hold
 ✓28 lights – illuminated:
A7U MSTR ALARM (1)
 VID IN (13)
 OUT (8)
 CAMR CMD ALC (3)
 GAMMA (3)

R13U C/W STATUS
 C/W LAMP TEST – L, hold
 ✓STATUS lights – illuminated (60)
 C/W LAMP TEST – R, hold
 ✓STATUS lights – illuminated (60)

HEATER RECONFIG – CONFIG B(CONFIG A)

L2 FLASH EVAP FDLN HTR A,B SPLY (two) – 2(1)

A12	HYD HTR RUD SPD BK A	- OFF(AUTO)
	B	- AUTO(OFF)
	BDY FLP A	- OFF(AUTO)
	B	- AUTO(OFF)
	ELEV A	- OFF(AUTO)
	B	- AUTO(OFF)
	AFT FUS A	- OFF(AUTO)
	B	- AUTO(OFF)

Perform APU HEATER RECONFIG (APU/HYD),
then:

A14 RCS/OMS HTR FWD RCS – B AUTO(A AUTO)
L POD – A OFF(A AUTO)
– B AUTO(B OFF)
R POD – A OFF(A AUTO)
– B AUTO(B OFF)

RCS/OMS HTR
 OMS CRSFD LINES – OFF(A AUTO)
 – B AUTO(OFF)

R11U FC H2O LINE HTR – B AUTO(A AUTO)
RELIEF HTR – B AUTO(A AUTO)

ML86B:A cb MNA H2O LINE HTR A - op(cl)
MNB H2O LINE HTR B - cl(op)

If no internal A/L:

ML86B:C cb MNA EXT ARLK HTR
LINE ZN 1,2 (two) — op(cl)
STRUC Z1/2/3 — op(cl)

cb MNB EXT ARLK HTR
LINE ZN 1,2 (two) – cl(op)
STRUC Z1/2/3 – cl(op)

If docked:

cb MNA EXT ARLK HTR
VEST Z1/2/3 = op(cl)

cb MNB EXT ARLK HTR
VEST Z1/2/3 - cl(op)

Cont next page

If both RMS htrs active >>

A8L PORT RMS HTR A – OFF(AUTO)
 B – AUTO(OFF)

FUEL CELL PURGE – AUTO, SM 2(4)

CAUTION

Do not purge FC if:
FC AMPS > 350
FC is shut down
Do not init auto purge within:
1 hr of any SM OPS transition or
3 hr of deorbit burn

R11U FC PURGE VLV (three) – GPC
 HTR – GPC
 GPC PURGE SEQ – START
 (After tb-gray, hold 3 sec)

* If any flow '↑' alarm, *
* (aff) FC PURGE VLV – CL *

FUEL CELL PURGE – MANUAL

R11U 1. TURN ON PURGE HEATERS
 FC PURGE HTR – ON

CRT

SM 69 FUEL CELLS
✓PURGE LN O ₂ T > 69
✓H ₂ T ₁ > 79
✓T ₂ > 40

2. MANUAL PURGE SEQUENCE

NOTE
Fuel cells must be purged separately

CAUTION
Do not purge FC if:
FC AMPS > 350
FC is shut down
Within 3 hr of deorbit burn

CRT FC 1(2,3) FLOW O₂ – note
 H₂ – note

R11U FC PURGE VLV 1(2,3) – OP

CRT ✓FC 1(2,3) FLOW O₂ – incr ~3.3 (max)
 ✓H₂ – incr ~0.6 (max)

R11U * If any flow '↑' alarm, *
 * (aff) FC PURGE VLV – CL *


Wait 2 min
FC PURGE VLV 1(2,3) – GPC

CRT ✓FC 1(2,3) FLOW O₂ – decr ~3.3 (max)
 ✓H₂ – decr ~0.6 (max)

Repeat step 2 for FCs 2 and 3
Wait at least 30 min, then continue

R11U 3. TURN OFF PURGE HEATERS
 FC PURGE HTR – GPC

FUEL CELL VI PERFORMANCE PLOT



NOTE

Record FC performance.
Select a curve for each
FC. A drop of 0.5 volts
below a selected curve
during subsequent
check indicates a
degraded FC

0 = FC1
X = FC2
Δ = FC3

CRYO O2 TK HTR SNSR CK

NOTE

Expect 'S68 O2 HTR TRP' msg
when htr sensor taken to test

SM 68 CRYO SYSTEM

- R1 1. Note O2 TK1 HTR sw posns
 O2 TK1 HTRS A,B (two) – ON, pause 5 sec, then:
 – TEST (1 sec)
- CRT 2. ✓HTR CUR SNSR 1A,1B,2A,2B (four) – '↓'
 * If HTR CUR SNSR 1A(1B)/2A(2B) not '↓': *
 * O2 TK1 HTRS A(B) – OFF, then: *
 * If HTRS A(B) was in AUTO: *
 * O2 TK1 HTRS B(A) – AUTO *
 * Go to step 4 *
- R1 3. O2 TK1 HTRS A,B (two) – previous posn
4. O2 TK1 – RESET
5. Repeat steps 1–4 for following:
 O2 TK2 HTRS
 TK3 HTRS
- A11 O2 TK4 HTRS (if OV103/104/105 and
 4th tk flown)
- A15 O2 TK5 HTRS (if OV103/104/105 and
 5th tk flown)
- If OV102 TK4/TK5 flown:
- A11 6. Note O2 TK4/5 HTR sw posns
 CRYO TK4/5 HTR O2 TK4,TK5 (two) – ON,
 pause 5 sec, then:
 CRYO TK4/5 HTR O2 TK4/5 – TEST (1 sec)

Cont next page

CRT 7. ✓HTR CUR SNSR TK4 1A,1B,2A,2B
(four) – ‘↓’

A11 * If HTR CUR SNSR 1A(1B)/2A(2B) *
* not ‘↓’: *
* CRYO TK4/5 HTR O2 TK4(TK5) – *
* OFF, then: *
* If TK4(TK5) was in AUTO: *
* O2 TK5(TK4) HTR – AUTO *
* Go to step 9 *

8. CRYO TK4/5 HTR O2 TK4,TK5 (two) –
previous posn

9. CRYO TK4/5 HTR O2 TK4/5 – RESET

EDO PALLET CRYO O2 TK HTR SNSR CK

NOTE

Expect 'S168 O2 HTR TRP' msg
when htr sensor taken to TEST

SM 168 CRYO PALLET

- A15 1. Note O2 TK6 HTR sw posns
 O2 TK6 HTRS A,B (two) – ON, pause 5 sec, then:
 – TEST (1 sec)
- CRT 2. ✓HTR CUR SNSR 1A,1B,2A,2B (four) – '↓'
 * If HTR CUR SNSR 1A(1B)/2A(2B) not '↓': *
 * O2 TK6 HTRS A(B) – OFF, then: *
 * If HTRS A(B) was in AUTO: *
 * O2 TK6 HTRS B(A) – AUTO *
 * Go to step 4 *
- A15 3. O2 TK6 HTRS A,B (two) – previous posn
4. O2 TK6 – RESET
5. Repeat steps 1–4 for following:
 O2 TK7 HTRS
 TK8 HTRS
 TK9 HTRS

EDO PALLET ACTIVATION

A15:H	cb PALLET MNA,MNB TK6 O2 SNSR 1,2 (two) – cl :I TK7 O2 SNSR 1,2 (two) – cl :J TK8 O2 SNSR 1,2 (two) – cl :K TK9 O2 SNSR 1,2 (two) – cl
A15:B	cb PPCA CONT PWR 1 (1/3 if OV105) ESS 1BC – cl cb PPCA CONT PWR 2 (2/4 if OV105) ESS 2CA – cl
A15:C	PALLET PWR PPCA-1 (PPCA-1/3 if OV105) MNA – ON (tb-ON) PALLET PWR PPCA-2 (PPCA-2/4 if OV105) MNB – ON (tb-ON) PALLET HTRS A – AUTO

EDO PALLET DEACT

A15:C PALLET HTRS A,B (two) – OFF
:D–G ✓PALLET O2,H2 TK6,TK7,TK8,TK9 HTRS A,B
(sixteen) – OFF

A15:C PALLET PWR PPCA-1 (PPCA-1/3 if OV105)
MNA – OFF (tb-OFF)
PALLET PWR PPCA-2 (PPCA-2/4 if OV105)
MNB – OFF (tb-OFF)

A15:B cb PPCA CONT PWR 1 (1/3 if OV105)
ESS 1BC – op
cb PPCA CONT PWR 2 (2/4 if OV105)
ESS 2CA – op

A15:H cb PALLET MNA,MNB TK6 O2 SNSR 1,2 (two) – op
:I op
:J op
:K op

This Page Intentionally Blank

GNC

IMU ALIGN – S TRK, GNC 201,202,301	7–2
ALIGNMENT – IMU/IMU	7–4
S TRK SELF–TEST, GNC 201,202,301	7–5
IMU STAR OF OPPORTUNITY ALIGN	7–6
COAS CALIBRATION, GNC 201	7–7
HUD CALIBRATION, GNC 201	7–9
BORESIGHT DESIGNATION	7–12
FCS CHECKOUT	7–13
AFT CONTROLLER C/O	7–33
OMICRON SPECIFICATION	7–35
ELEVON PARK, GNC 201	7–36
GPS PWRUP	7–37
PWRDN	7–38
SELF–TEST, GNC 201,202,301,801	7–39

GNC

IMU ALIGN – S TRK, GNC 201,202,301

1. COLLECT STAR DATA

✓ In attitude

GNC 22 S TRK/COAS CNTL

S TABLE CLR – ITEM 20 EXEC

✓ STAR TRK – ITEM 3,4 (*)

✓ S TRK –Y,-Z: STATUS – (no BITE)
SHUTTER – OP

- * If SHUTTER – CL: *
- * ✓ Attitude,MET correct *
- * Visually verify no bright object in FOV *
- * After data collected and before changing *
- * attitude, return shutter to AUTO *
- * To open shutter: *
- * MAN OP – ITEM 15(16) EXEC (*) *
- * To return shutter to AUTO: *
- * MAN OP – ITEM 15(16) EXEC (no *) *

2. VERIFY STAR DATA

✓ S TABLE: TRK ID 1,2 correct #s

ANG ERR 1 ≤ .08

SEL, ITEM 17,18 – (*)

Wait ~1 min for new IMU ΔANGs

- * If no data after 3 min or bad data: *
- * Repeat step 1 *
- * ✓ Attitude,stars,MET correct *
- * ✓ S TRK –Y,-Z: TRK ID: correct #s *
- * ΔANG: < 1.0 *
- * If still no data or bad data: *
- * Perform S TRK SELF-TEST, then: *
- * If both STATUS – ST FAIL: *
- * | Inform MCC before proceeding *
- * If both STATUS – ST PASS: *
- * | Repeat step 1 at new att, stars *
- * If one STATUS – ST PASS: *
- * Perform single tracker steps *

GNC

Cont next page

- * Single tracker procedure *
- * ✓TERM/IDLE, ITEM 9(10) – (*) *
- * Good S TRK, STAR TRK – *
- * ITEM 3(4) EXEC (*) *
- * S TABLE CLR – ITEM 20 EXEC *
- * ✓S TABLE: TRK ID 1 correct # *
- * Good S TRK, TERM/IDLE – ITEM *
- * 9(10) EXEC (*) *
- * Mnvr to 2nd attitude, star *
- * Good S TRK, STAR TRK – ITEM *
- * 3(4) EXEC (*) *
- * Repeat step 2 with good S TRK only *

3. CHECK IMU ΔANGs

GNC 21 IMU ALIGN

- CRT
- IMU 1,2,3: STAT – blank
 - ✓STAR ALIGN, ITEM 13 – (*)
 - ✓ANG 1,2,3: $\Delta X, \Delta Y, \Delta Z \leq 0.50$
 - If no comm, record ΔANGs

- * If ANG $\Delta X, \Delta Y, \Delta Z > 0.50$ for two or *
- * more IMUs, repeat steps 1,2,3 *

CAUTION

If ANG $\Delta X, \Delta Y, \Delta Z$ still > 0.50 for two or more IMUs, DO NOT TORQUE PLATFORMS EXCEPT UNDER MCC INSTRUCTIONS

4. ALIGN IMUs

- ALIGN IMU 1(2,3) – ITEM 10(11,12) EXEC (*)
- EXEC – ITEM 16 EXEC (*)
- ✓EXEC, ITEM 16 – (no *)
- If not deorbit align >>

5. D/O ALIGN VERIFICATION

- When D/O align complete, mnvr to VERIF ATT (FLIGHT PLAN, Detailed Timeline), perform steps 1,2 using verif stars
- ✓IMU 1,2,3 ANG $\Delta X, \Delta Y, \Delta Z < 0.1$

- * If ANG $\Delta X, \Delta Y, \Delta Z \geq 0.1$, ✓MCC *
- * If no comm, repeat steps 1–5 *

IMU ALIGNMENT – IMU/IMU

NOTE

Procedure must be accomplished
in GNC OPS 2 or 3

GNC 21 IMU ALIGN
IMU/IMU – ITEM 14 + EXEC

1 2 3
 ΔX ()_____._____()_____._____()_____._____
 ΔY ()_____._____()_____._____()_____._____
 ΔZ ()_____._____()_____._____()_____._____
ALIGN IMU 1(2,3) – ITEM 10(11,12) EXEC (*)
EXEC – ITEM 16 EXEC (*),
Rcd MET ____ / ____ : ____
____ / ____ : ____
____ / ____ : ____

NOTE

Align will require 3–6 min

Report IMU align results

VERIFY GOOD IMU/IMU ALIGNMENT

- ✓ EXEC, ITEM 16 – (no *)
- ✓ IMU/IMU – ITEM 14 +(SAME REF IMU) EXEC
- ✓ IMU 1,2,3 ANG $\Delta X, \Delta Y, \Delta Z < 0.13$

* If ANG $\Delta X, \Delta Y, \Delta Z \geq 0.13$, report to MCC *

If in GNC OPS 2 or MM 301,
STAR ALIGN – ITEM 13 EXEC (*)

S TRK SELF-TEST, GNC 201,202,301

Mnvr to avoid bright objects in both BOSSs

CRT GNC 22 S TRK/COAS CNTL
✓S TRK -Y,-Z: STATUS – (no BITE)
 SHUTTER – OP

* If SHUTTER – CL: *
* ITEM 15(16) – EXEC (*) *
* ITEM 15(16) – EXEC (no *) *

SELF-TEST – ITEM 1,2 EXEC (*)
✓S TRK -Y,-Z: SHUTTER – CL
 S PRES – (*)
 STATUS – BITE (mom)
 SHUTTER – OP
 STATUS – ST PASS

* If STATUS – ST FAIL, repeat *
* SELF-TEST *
* If still FAIL, use only if directed *
* by MCC *

STAR TRK – ITEM 3,4 EXEC (*)

IMU STAR OF OPPORTUNITY ALIGN

1. VERIFY STAR DATA

✓S TABLE: TRK ID 1,2,3 for correct #s
ANG ERR 1,2,3: ≤ 0.08 for correct #s
SEL, ITEM 17,18,19 – (*) for correct #s

2. CHECK IMU ΔANGs

GNC 21 IMU ALIGN

IMU 1,2,3: STAT – blank
✓STAR ALIGN, ITEM 13 – (*)
✓ANG 1,2,3: $\Delta X, \Delta Y, \Delta Z \leq 0.50$

CAUTION

If ANG $\Delta X, \Delta Y, \Delta Z > 0.50$ for any IMU,
DO NOT TORQUE PLATFORMS
EXCEPT UNDER MCC INSTRUCTIONS

3. ALIGN IMUs

ALIGN IMU 1(2,3) – ITEM 10(11,12) EXEC (*)
EXEC – ITEM 16 EXEC (*)
✓EXEC, ITEM 16 – (no*)

COAS CALIBRATION, GNC 201

1. COAS CALIBRATION PREP

O1(O19) COAS
COAS ✓Barrel Index – FW(OW)
✓DAP: A/AUTO/VERN

If –Z COAS CAL,SENSE: –Z

Change DAP A,B to A1,B5

GNC 22 S TRK/COAS CNTL

COAS: REQD ID – ITEM 21 +_ EXEC
POS +X(-Z) – ITEM 26(27) EXEC (*)
CAL MODE – ITEM 24 EXEC (*)

O14:E, ✓cb DDU L(AFT) (two) – cl
O15:E,
O16:E

GNC 25 RM ORBIT

SW RM INH – ITEM 16 EXEC (*)
FLT CNTLR PWR – ON
SW RM INH – ITEM 16 EXEC (no *)

GNC 22 S TRK/COAS CNTL

F7/F8 (A6U)

2. MARK ON STAR

DAP: A1/INRTL(FREE)/VERN (for COARSE CNTL)

Mnvr to locate star

DAP: B5/INRTL(FREE)/VERN (for FINE CNTL)
B5/FREE/PRI (loss of VERNs)

F6 (A6U)

Mnvr to center star in COAS:

ATT REF pb – push

NOTE

Take minimum three verif marks
to ensure Δ BIAS consistency

DAP: A1/AUTO/VERN

Cont next page

- CRT
3. **CALIBRATE COAS**
 Rcd CAL +X(-Z) ΔBIAS: ____.
 UPDATE – ITEM 28(29) EXEC, Rcd
 MET ____ / ____ ____ : ____
 ✓ΔBIAS goes to zero
 4. **VERIFICATION**
 DAP: A1/INRTL(FREE)/VERN (for COARSE CNTL)
 Mnvr to locate star
 DAP: B5/INRTL(FREE)/VERN (for FINE CNTL)
 B5/FREE/PRI (loss of VERNs)
- F6
(A6U)
- Mnvr to center star in COAS:
 ATT REF pb – push
- NOTE**
 Take minimum three verif marks
 to ensure ΔBIAS consistency
- ✓ΔBIAS < 0.12
- * If majority of ΔBIASs > 0.12, repeat *
 - * steps 3 and 4. If ΔBIAS still > 0.12, *
 - * ✓MCC *
- O1(O19)
F7/F8
(A6U)
5. **CLEAN UP**
 COAS: DES – ITEM 25 EXEC (*)
 COAS – OFF
 FLT CNTLR PWR – OFF
- O14,O15,
O16:E
- cb DDU L(AFT) (two) – as reqd
- ✓Data transcribed into FLIGHT PLAN
- CRT
- If S TRK(S) to be left in auto star-select mode:
 S TRK(S) –Y(-Z) – ITEM 3(4) EXEC (*)
- Reconfig to FLIGHT PLAN DAP

HUD CALIBRATION, GNC 201

1. HUD PREP

Remove L(R) HUD Cover

F3 L(R) HUD PWR – ON
F6U(F8U) MODE – TEST

Wait ~15 sec for final symbology of test mode display (see HUD BORESIGHT DESIGNATION, 7–12)

✓Final test mode display symbology

* If final test mode symbology not in *
* agreement with diagram, notify MCC *

L(R) HUD BRT – MAN NIGHT
MAN BRT – as reqd

C3 ✓DAP: A/AUTO/VERN
Change DAP A,B to A1,B5

CRT

GNC 22 S TRK/COAS CNTL

COAS: REQD ID – ITEM 21 + ____ EXEC
POS +X – ITEM 26 EXEC (*)
CAL MODE – ITEM 24 EXEC (*)

O14,O15,
O16:E ✓ cb DDU L(R) (two) – cl

F7/F8

GNC 25 RM ORBIT

SW RM INH – ITEM 16 EXEC (*)
FLT CNTLR PWR – ON
SW RM INH – ITEM 16 EXEC (no *)

GNC 22 S TRK/COAS CNTL

2. MARK ON STAR

DAP: A1/INRTL(FREE)/VERN (for COARSE CNTL)

Mnvr to locate star

DAP: B5/INRTL(FREE)/VERN (for FINE CNTL)
B5/FREE/PRI (loss of VERNs)

Cont next page

7–9 ORB OPS/ALL/GEN H

Mnvr to center star in HUD boresight:
(‘P’ in ‘COMPLETE’, see HUD BORESIGHT
DESIGNATION, 7–12)
F6/F8 ATT REF pb – push

Note Δ BIAS value

NOTE
Take minimum three marks to
ensure Δ BIAS consistency

If Δ BIAS < 0.12° for at least three marks, go to
step 5

DAP: A1/AUTO/VERN

- CRT
3. CALIBRATE HUD
Rcd CAL +X Δ BIAS: ____ . ____ —
UPDATE – ITEM 28 EXEC,
Rcd MET ____ / ____ : ____
✓ Δ BIAS goes to zero
 4. VERIFICATION
DAP: A1/INRTL(FREE)/VERN (for COARSE CNTL)

Mnvr to locate star

DAP: B5/INRTL(FREE)/VERN (for FINE CNTL)
B5/FREE/PRI (loss of VERNS)

F6/F8 Mnvr to center star in HUD boresight:
 ATT REF pb – push

NOTE
Take minimum three marks to
ensure Δ BIAS consistency

✓ Δ BIAS < 0.12°

* If majority of Δ BIAS > 0.12, repeat *
* steps 3 and 4. If Δ BIAS still > 0.12, *
* ✓MCC *

Cont next page

7-10 ORB OPS/ALL/GEN H

5. CLEAN UP
F6U/F8U COAS: DES – ITEM 25 EXEC (*)
F3 HUD MODE – NORM
F7/F8 HUD PWR – OFF
FLT CNTLR PWR – OFF

O14,O15, cb DDU L(R) (two) – as reqd
O16:E


✓Data transcribed into FLIGHT PLAN

CRT If S TRK(s) to be left in auto star-select mode:
S TRK(s) –Y(–Z) – ITEM 3(4) EXEC (*)


Install L(R) HUD Cover

Reconfig to FLIGHT PLAN DAP

HUD BORESIGHT DESIGNATION



Final symbology of HUD test mode display



HUD boresight designation

FCS CHECKOUT

DISPLAY/DPS CONFIG

O14, RGA (four) – ON
O15, cb MNA,B,C ADTA (four) – cl
O16 MNA,B ACCEL 1,2 (two) – cl
 DDU L (two) – cl
 MNB,C DDU R (two) – cl
If APU will be used:
| ASA (four) – ON
If circ pump will be used:
✓ASA (four) – OFF
ACCEL 3,4 (two) – ON
BRAKES (three) – ON
O15 ✓cb GPS 2 PRE AMPL UPPER – cl
 LOWER – cl
A13 ✓GPS PRE AMPL UC – ON
 ✓LC – ON

✓GPS PWR – ON
L2 ANTISKID – ON
O17 ATVC (four) – ON
O7 TACAN MODE (three) – GPC

O8 RADAR ALTM (two) – ON
 MLS (three) – ON

F3 TRIM PNL (two) – ON
 HUD PWR (two) – ON

C3 ✓FCS CH (four) – AUTO

✓DAP: A1/AUTO/VERN

Perform G2 TO G8 TRANSITION (DPS), then:

If using circ pump for part 1:
FCS CH 2,3 – OFF
ASA (four) – ON
Go to step 7b, 7–18

Cont next page

MEDS

A7–13 ORB OPS/MEDS/GEN H

ON-ORBIT FCS CHECKOUT, PART 1

NOTE

Only one APU will be used for FCS C/O.
If APU does not start or MCC advises
abbreviated actuator check, circ pump
will be used. Selection of APU or circ
pump will be made real time by MCC

If APU shuts down, 'S86 APU GBX T', 'S86 APU
TEMP', 'S86 APU GBX P', APU shifts to HI
speed (✓CRT), **APU OVERSPEED** or
APU UNDERSPEED, then go to step 6,
APU SHUTDOWN

NOTE

Any previously failed actuator channel
should be bypassed via ITEM 21 on
FCS/DED DIS C/O display prior to APU
start

Cont next page

MEDS

A7-14 ORB OPS/MEDS/GEN H

- C2
1. FCS C/O PREP
Set EVENT TIMER to 00:00, count UP
 2. APU PRESTART

1: GNC, FCS/DED DIS C/O	2: SM 86 APU/HYD
-------------------------	------------------
- CRT2
- ✓APU, HYD, WB status no '↑' or '↓'
(except HYD B/U)
- If SYS 1:
- R4
- ✓LG EXTEND ISOL VLV tb – CL
- R2
- ✓HYD BRAKE ISOL VLV X tb – CL
HYD CIRC PUMP (three) – OFF
- BLR N2 SPLX X – ON
✓PWR (three) – ON
✓CNTLR/HTR (three) – B
✓APU AUTO SHUTDN (three) – ENA
 CNTLR PWR X – ON
HYD MN PUMP PRESS X – LO
✓APU SPEED SEL (three) – NORM
 ✓OPER (three) – OFF
 ✓FUEL TK VLV (three) – CL
✓cb APU FU TK VLV ENA (six) – cl

Inform MCC: READY FOR APU START

Wait for MCC GO

Cont next page

MEDS

A7-15 ORB OPS/MEDS/GEN H

- R2 3. APU START
 APU FUEL TK VLV X – OP
 ✓APU/HYD RDY X tb – gray

* If tb – bp, ✓MCC *

- 00:00 Start EVENT TIMER
 R2 APU OPER X – START/RUN
 HYD/APU ✓HYD PRESS ind X – LOW green
 R2 ✓APU/HYD RDY X tb – bp

* If APU did not start, go to step 6 *

- HYD MN PUMP PRESS X – NORM
 HYD/APU ✓HYD PRESS ind X – HI green

SM 87 HYD THERMAL

- ✓SW VLV ELEV (four) per table
 ✓RUD/SPDBK per table

If HYD SYS 1	If HYD SYS 2	If HYD SYS 3
1(*)	2(*)	3(*)
1(*)	2(*)	3(*)

4. CRT1 AEROSURFACE DRIVE
 SURF DR START – ITEM 10 EXEC (*)
 Verify all surfaces cycling for 30 sec

NOTE

POS '↓' may be indicated
 until HYD SYS is warm

- * If FCS CH failure ('↓' port status), *
- * reset affected FCS CH: *
- * FCS CH – ORIDE, then *
- * – AUTO *

- After 30 sec of aerosurface drive,
 SURF DR STOP – ITEM 11 EXEC (*)
 ✓Surfaces not moving

Cont next page

MEDS

A7-16 ORB OPS/MEDS/GEN H

5. SECONDARY ACTUATOR CHECK (APU)

NOTE

If a port does not bypass during check, bypass affected port after APU shutdn:

SEC ACT BYPASS – ITEM 21 +X X EXEC

If affected port still does not bypass:

SEC ACT RESET – ITEM 22 +X X EXEC

CRT1 a. ✓POS STIM ENA, ITEM 20 – (*)

C3 b. ✓FCS CH 1,2,3,4 – AUTO

CRT1 c. SEC ACT CK, CH 1 – ITEM 15 EXEC (*)

d. ✓All CH 1 ports bypass ('↓')
STOP – ITEM 19 EXEC (*)

C3 e. FCS CH 1 – ORIDE

CRT1 ✓All CH 1 ports reset (no '↓')
C3 FCS CH 1 – AUTO

f. Repeat steps c thru e for CH 2,3,4

CRT1 g. NEG STIM – ITEM 20 EXEC (no *)

h. Repeat steps b thru f

6. APU SHUTDOWN

On MCC GO for APU SHUTDN:

R2 BLR PWR (three) – OFF
 APU OPER X – OFF
 FUEL TK VLV X – CL
 ✓Shutdn (hyd press)
 CNTLR PWR X – OFF
 BLR N2 SPLY X – OFF
 HYD CIRC PUMP (three) – GPC

Proceed to part 2

Cont next page

MEDS

A7-17

ORB OPS/ALL/GEN H

7. CIRC PUMP ACTIVATION

1: GNC, FCS/DED DIS C/O	2: SM 86 APU/HYD
-------------------------	------------------

NOTE

OPS 2/8 trans must be performed with
ASAs off to avoid AERO DRIVE fault
msgs during actuator checks

- a. Perform G8 to G2 TRANSITION (DPS),
then:

O14,O15,
O16:F ASA (four) – OFF

C3 Perform G2 to G8 TRANSITION (DPS), then:
✓FCS CH 1,4 – AUTO
2,3 – OFF

R4 ASA (four) – ON

R2 ✓HYD BRAKE ISOL VLV X tb – CL

R2 ✓HYD CIRC PUMP (three) – OFF

- b. HYD CIRC PUMP X – ON

8. ABBREVIATED SECONDARY ACTUATOR
CHECK (circ pump)

NOTE

If an elevon does not move to
commanded posn, bypass affected
port after check of all channels:

SEC ACT BYPASS – ITEM
21 +X X EXEC

CRT1 a. ✓POS STIM ENA, ITEM 20 – (*)

C3 b. ✓FCS CH 1,4 – AUTO
✓2,3 – OFF

CRT2 c. GNC 42 SWITCH/SURF
✓All elevons move to U7.5° ± 0.8°

CRT1 d. SEC ACT CK, CH1 – ITEM 15 EXEC (*)
Wait 5 sec

Cont next page

MEDS

A7-18

ORB OPS/ALL/GEN H

- C3 CRT2
- e. Turn off FCS CH not being checked:
 FCS CH (three) – OFF
 ✓ All elevons move to $U1.5^\circ \pm 0.8^\circ$
- * If any elevon drives past 0° , turn on *
 - * all FCS CHs to stop movement *
 - * FCS CH (four) – AUTO *
 - * Expect AERO DRIVE msg. Continue *
 - * procedure and report to MCC *
- CRT1
- f. STOP – ITEM 19 EXEC (*)
 ✓ All elevons move to $U7.5^\circ \pm 0.8^\circ$
- C3
- g. Config FCS CHs for check of next CH:
 (Config switches in sequence shown)
- | NEXT CH | FCS CH SWITCHES | | | |
|---------|-----------------|-----|------|------|
| | 4 | 1 | 2 | 3 |
| 2 | AUTO | OFF | AUTO | OFF |
| 3 | AUTO | OFF | OFF | AUTO |
| 4 | AUTO | OFF | OFF | AUTO |
- h. Repeat steps d thru g for CHs 2,3,4
- R2
9. HYDRAULIC SYSTEM RECONFIG
 HYD CIRC PUMP (three) – GPC
10. FCS CH RECONFIG
- C3
- a. Perform G8 to G2 TRANSITION (DPS),
 then:
 FCS CH 1,2,3 – AUTO
 ✓4 – AUTO
- b. Perform G2 to G8 TRANSITION (DPS),
 then:
 Continue with part 2

Cont next page

MEDS

A7-19 ORB OPS/MEDS/GEN H

ON-ORBIT FCS CHECKOUT, PART 2

1. Sensor Test – MLS,TAC,RA,AA

NOTE

During MLS/TAC/RA/AA test, deselect LRU for failure indicated:

MLS,TAC,RA,AA – ‘↑’ or ‘↓’
or AA – BIAS/NUL limits exceeded
Record values of failures defined

Record values of failures defined

2: GNC 40 SENSOR TEST

CRT2 ✓ DES: (no *)
 ✓ STAT: blank
 ✓ RNG,AZ,EL: no M

CONFIG FOR FREE DRIFT

F6 ADI RATE – LO
DAP: A1/INRTL/VERN
✓R,P,Y rates $0 \pm .1^\circ/\text{sec}$, then:
DAP: FREE

AA Bias/Null Shift Test

MLS,TAC,RA,AA Test

START – ITEM 13 EXEC (*)

NOTE

* blanks when test complete; ✓No ↑ or ↓. See Limit Values Table, 7-21

Cont next page

MEDS

A7-20 ORB OPS/MEDS/GEN H

LIMIT VALUES TABLE

	RNG	AZ	EL
MLS	15.0 to 15.4	+,-2.9 to +,-3.1 (+ for 3 sec, then -)	5.9 to 6.1
TAC	0 to 0.5	177.5 to 182.5 <u>NOTE</u> Values from 182.1 to 182.5 will be displayed as 2.1 to 2.5	
RA	ALT		
	900 to 1100		
AA		Y	Z
		+14.40 to 17.80	+57.70 to 71.10

O7 STOP – ITEM 14 EXEC (*)
TACAN MODE (three) – OFF

2. Sensor Test – RGA, ADTA

NOTE

During RGA, ADTA test, deselect LRU for failure indicated:

RGA – bias null limits exceeded,
'↑' or '↓', or SMRD

ADTA – any '↑' or '↓', except temp ('T')

If RGA does not respond to HIGH or LOW TEST or displays 'SMRD' indication in STAT column:

✓MCC, confirm that payload config can support PRCS firings

Null vehicle rates

Maneuver at 0.5°/sec about appropriate axis;
monitor RGA data

If RGA responds, self-test circuitry
or SMRD circuitry failed

If no RGA response, deselect sensor

Cont next page

MEDS

A7-21 ORB OPS/MEDS/GEN H

CRT2

2: GNC 41 RGA/ADTA/RCS

- ✓DES: (no *)
- ✓STAT: blank
- ✓PS,P_αC,P_αU,P_αL,T – no M

Config For Free Drift

- ✓DAP: A1/INRTL/VERN
- ✓R,P,Y rates $0 \pm 0.1^\circ/\text{sec}$, then:
DAP: FREE

RGA Bias/Null Shift Test

- ✓R,P,Y within limits: R -.4 to +.4
P/Y -.2 to +.2
- Refer to Limit Values Table, 7-23

High Test

- TEST HI – ITEM 9 EXEC (*)
(after 10 sec, no *)
- ✓No ' \uparrow ' or ' \downarrow ',
If ADTA BITE, ✓MCC (if LOS, proceed with test)

TEST STOP – ITEM 11 EXEC (*)

Low Test

- TEST LOW – ITEM 10 EXEC (*) (after 10 sec,
no *)
- ✓No ' \uparrow ' or ' \downarrow ',
If ADTA BITE, ✓MCC (if LOS, proceed with test)

TEST STOP – ITEM 11 EXEC (*)
DAP: A1/AUTO/VERN

Cont next page

A7-22

ORB OPS/ALL/GEN H

MEDS

LIMIT VALUES TABLE

<u>HIGH TEST LIMITS</u>				
<u>RGA</u>				
R +18.8 to +21.2	P +9.4 to +10.6	Y +9.4 to +10.6		
<u>ADTA</u>				
PS .813 to .815	P _α C 5.473 to 5.477	P _α U 2.740 to 2.744	P _α L 1.708 to 1.712	T 173.56 to 173.60
<u>LOW TEST LIMITS</u>				
<u>RGA</u>				
R -18.8 to -21.2	P -9.4 to -10.6	Y -9.4 to -10.6		
<u>ADTA</u>				
PS 24.887 to 24.889	P _α C 29.527 to 29.531	P _α U 21.708 to 21.712	P _α L 14.713 to 14.717	T 18.50 to 18.54

3. Sensor Test – GPS

NOTE

After GPS S/TEST, deselect LRU for failure indicated by '↓'. GPS self-test takes about 2 min to complete. 'BIT' in STAT field on SPEC 55 indicates hardware feedback and clears when test complete

2: GNC 55 GPS STATUS

- ✓NAV – ITEM 18 (*)
- If 'RPF' in STAT field, ✓MCC (if LOS, proceed with test)
- S/TEST – ITEM (12) EXEC (*)
- ✓'BIT' in STAT field after ~6 sec,
Wait for 'BIT' to clear after ~2 min
- ✓S/TEST ↑; if '↓' deselect GPS
- NAV – ITEM 18 EXEC (*)
- ✓MODE – INS

Cont next page

MEDS

A7-23 ORB OPS/MEDS/GEN H

4. FCS MODE/CH SWITCH TEST

NOTE

During tests, FCS CH:

Fail op or fail cl – deselect failed contacts
FCS CH OVERRIDE function of a CH with
failed contacts may be made operable if at
least one good contact available.

Proceed: ✓MCC when possible

FCS MODE:

Fail op – 2 op or 1 op/1 cl contacts preclude
use of sw
Fail cl – 1st failure, deselect failed contact
2nd failure L(R), deselect all L(R)
contacts

ENTRY MODE:

Fail op or cl – 1st, 2nd failure, deselect
contact
3rd failure, when in OPS 3,
GNC 51 OVERRIDE
AUTO SEL – ITEM 42
EXEC (*)

2: GNC 43 CONTROLLERS

Deselect L THC:

CRT2 THC L DES – ITEMS 1,2,3 EXEC (*)

Cont next page

MEDS

A7-24 ORB OPS/MEDS/GEN H

2: GNC 42 SWITCH/SURF

CRT2

NOTE

During following tests, verify '*' appears except as noted. If '*' remains after releasing pb, contact failed closed

F6/F8

FLT CNTLR PWR (two) – ON

C3

FCS CH (four) – ORIDE (wait 5 sec)
– AUTO (no *)

F2/F4

PITCH pb – AUTO

– CSS

ROLL/YAW pb – AUTO

– CSS

SPDBK/THROT pb – AUTO

BODY FLAP pb – AUTO

L2/C3

SBTC TAKEOVER pb – push

5. SURF TEST

Notify MCC if any single surf feedback exceeds average of other three feedbacks by greater than:

Elevons ($\Delta 1.3^\circ$)

Rudder ($\Delta 1.2^\circ$)

SPD BK ($\Delta 2.2\%$)

BDY FLP ($\Delta 3\%$)

2: GNC 44 SWITCHES

During following sw test, verify '*' appears

L2

ENTRY MODE – LO GAIN

– NO Y JET

– AUTO (no *)

Cont next page

MEDS

A7-25

ORB OPS/ALL/GEN H

6. NWS CHECK

2: GNC 45 NWS CHECK

CRT2

NOTE

During following tests, verify position
transducer values A,B,C remain ~0.00°

✓Position A,B,C: 0.00° ± 0.75°

L2

a. NWS1
NWS – 1

CRT2

✓NWS1 SYS SEL (*)
✓HYD PRESS HIGH (no *)
✓CURRENT: 1.00 ma to 3.15 ma

F3

ENABLE – ITEM 1 EXEC (*)
✓NWS1 ENABLE A,B (*)
✓NWS FAIL lt – on (illuminated)

CRT2

RIGHT TURN – ITEM 2 EXEC (*)
✓NWS1 CURRENT: 3.75 ma to 6.25 ma

LEFT TURN – ITEM 3 EXEC (*)
✓NWS1 CURRENT: -4.25 ma to -1.75 ma
STOP – ITEM 4 EXEC (*)
✓NWS1 CURRENT: 1.00 ma to 3.15 ma

L2

b. NWS2
NWS – 2

CRT2

✓NWS2 SYS SEL (*)
✓HYD PRESS HIGH (no *)
✓CURRENT: 1.00 ma to 3.15 ma

F3

ENABLE – ITEM 1 EXEC (*)
✓NWS2 ENABLE A,B (*)
✓NWS FAIL lt – on (illuminated)

CRT2

RIGHT TURN – ITEM 2 EXEC (*)
✓NWS2 CURRENT: 3.75 ma to 6.25 ma

Cont next page

A7-26

ORB OPS/ALL/GEN H

MEDS

LEFT TURN – ITEM 3 EXEC (*)
✓NWS2 CURRENT: -4.25 ma to -1.75 ma
STOP – ITEM 4 EXEC (*)
✓NWS2 CURRENT: 1.00 ma to 3.15 ma

L2

NWS – OFF

7. CONTROLLER AND SWITCH TEST

NOTE

During cntlr/sw test,
THC: One TX(TY,TZ) failed CLOSED –
reselect all contacts (failed
contact last)
One TX(TY,TZ) failed OPEN –
reselect good contacts only
Multi +TX,-TX,+TY,-TY,+TZ,-TZ
failures – reselect good
contacts only

SPDBK L(R): Deselect failed xdcrs
After 2nd L(R) failure,
use other side

RUD PED L(R): One failure – deselect
failed xdcr
Multi L(R) failures –
deselect all L(R) xdcrs

RHC L(R): One xdcr failure – reselect
good xdcrs only
Multi L(R) failures – reselect
good xdcrs L(R) and F7(F8)
FLT CNTLR PWR – OFF

BDY FLP L(R): Fail close, deselect all
L(R) contacts

RHC or PNL TRIM L(R): If contact failed, deselect
failed contact row

Cont next page

A7-27

ORB OPS/ALL/GEN H

MEDS

2: GNC 43 CONTROLLERS

F5
CRT2

- a. THC
L THC – deflect in each axis
✓ THC: '+' and '-'
Reselect THC contacts:
THC L – ITEM 1,2,3 EXEC (no *)
- b. L SBTC
L SBTC – full aft; ✓ > 95%
– full fwd; ✓ < 15%
- c. Rudder/Brake
RUD PED – full L; ✓ > 87% and ch Δ < 9%
– full R; ✓ > 80% and ch Δ < 9%
– null; between L 14% and R 4%
BK PED – depress to verify unrestricted
movement (~20 to 25°)
- d. L Body Flap Switch
BDY FLP – UP, DN
✓ BDY FLP UP, DN – '*'

e. L RHC
Deselect L RHC:
RHC L DES – ITEM 23,24,25 EXEC (*)
L RHC – deflect to hardstop in each axis
✓ RHC L: R,P – > 92%
Y – > 88%

Reselect RHC CHs:
RHC L DES – ITEM 23,24,25
EXEC (no *)
- f. L RHC Trim Switch
L RHC Trim – deflect sw in each axis
✓ RHC TRIM L: R – R/L
P – U/D

Cont next page

MEDS

A7-28 ORB OPS/MEDS/GEN H


- L2 g. L Panel Trim Switches
 ROLL TRIM – R, then L
 PITCH TRIM – UP, then DN
 YAW TRIM – R, then L
- CRT2 ✓PNL TRIM L: R,Y – R/L
 P – U/D
- F3 TRIM RHC/PNL – ENA
 (wait 5 sec; no crew insight)
 TRIM RHC/PNL – INH
- h. Repeat steps b and d thru g for R cntlrs/sw:
 RHC R DES – ITEM 26,27,28
8. MEDS CHECKOUT
MDU Checkout
F6/F7 Power ON all forward MDUs (9) and IDPs (3)
F8/C2 Verify appropriate display appears (expect big 'X'
 for any DPS Display whose IDP is deassigned)
- Flight Critical/IDP Interface Checkout
F6/F8 On CDR 1, CDR 2, and PLT 1 MDUs:
 Ensure on primary ports
 Sel FLT INST: ORBIT: ADI displays
 Verify no OFF FLAGS in the following
 configurations:
 On CDR 1 and CDR 2, ✓FC BUS 4,1,2,3
 On PLT 1, ✓FC BUS 1,2,3,4
- F6/F7 Reconfig MDUs as desired (use only one IDP
F8/C2 with three MDUs max if in GROUP B(C) PWRDN)
9. HUD CHECK
✓HUD BRT (two) – as reqd
 MODE (two) – TEST
✓Brightness
✓Format 'COMPLETE' msg
 HUD MODE (two) – NORM
- CRT1 DED DIS FWD – ITEM 1 EXEC (*)
 LOW – ITEM 4 EXEC (*)
✓HUD using HUD low value test diagram
- F6/F8 ✓Readouts for L(R) DATA BUS 1,2(3,4)
- CRT1 DED DIS OFF – ITEM 6 EXEC (*)

Cont next page

MEDS

A7-29 ORB OPS/MEDS/GEN H

HUD LOW VALUE TEST
NOTE
No HUD high value test exists



Cont next page

A7-30 MEDS

ORB OPS/MEDS/GEN H

10. MODE LAMP TEST

Test Start

CRT1 MODE LT ON – ITEM 7 EXEC (*)

F2/F4 ✓PITCH AUTO,CSS It (two) – on
✓ROLL/YAW AUTO,CSS It (two) – on
✓SPDBK/THROT AUTO,MAN It (two) – on
✓BDY FLP AUTO,MAN It (two) – on

Test Terminate

CRT1 MODE LT OFF – ITEM 8 EXEC (*)

F6/F8 FLT CNTLR PWR (two) – OFF

Display/DPS Reconfig

Perform G8 TO G2 TRANSITION (DPS), then:

F3 TRIM PNL (two) – OFF

HUD PWR (two) – OFF

C3 FCS CH (four) – AUTO

O8 MLS (three) – OFF
RADAR ALTM (two) – OFF

O14, RGA (four) – OFF

O15, cb MNA,B,C ADTA (four) – op

O16 MNA,B ACCEL 1,2 (two) – op

DDU L (two) – as reqd

MNB,C DDU R (two) – op

ASA (four) – OFF

ACCEL 3,4 (two) – OFF

L2 BRAKES (three) – OFF

ANTISKID – OFF

O17 ATVC (four) – OFF

MEDS

A7-31

ORB OPS/ALL/GEN H

This Page Intentionally Blank

MEDS

A7-32 ORB OPS/MEDS/GEN H

FCS CHECKOUT

DISPLAY/DPS CONFIG

O14, RGA (four) – ON
O15, cb MNA,B,C ADTA (four) – cl
O16 MNA,B ACCEL 1,2 (two) – cl
 ✓DDU L (two) – cl
 MNB,C DDU R (two) – cl
If APU will be used:
| ASA (four) – ON
If circ pump will be used:
✓ASA (four) – OFF
ACCEL 3,4 (two) – ON
BRAKES (three) – ON

✓cb MNA GPS PRE AMPL UC – op
 ✓LC – cl
✓MNC GPS PRE AMPL UC – cl
 ✓LC – op

L2 ANTISKID – ON
O17 ATVC (four) – ON

O7 TACAN MODE (three) – GPC

O8 RADAR ALTM (two) – ON
 MLS (three) – ON

F6 INST PWR – FLT
F8 INST PWR – ON
F3 TRIM PNL (two) – ON
 HUD PWR (two) – ON
F6/F8 HSIs: ✓Off flag – not visible

F8 ADI: ✓Error needles and Rate pointers – visible
C3 ✓FCS CH (four) – AUTO

✓DAP: A1/AUTO/VERN

Cont next page

NOM

B7-13 ORB OPS/NOM/GEN H

A13

✓GPS PWR – ON
✓ENCRYPT – NORMAL
✓PRE AMPL UC – MNC
✓LC – MNA

Perform G2 TO G8 TRANSITION (DPS), then:

If using circ pump for part 1:

FCS CH 2,3 – OFF
ASA (four) – ON
Go to step 7b, 7-18

ON-ORBIT FCS CHECKOUT, PART 1

NOTE

Only one APU will be used for FCS C/O.
If APU does not start or MCC advises
abbreviated actuator check, circ pump
will be used. Selection of APU or circ
pump will be made real time by MCC

If APU shuts down, 'S86 APU GBX T', 'S86 APU
TEMP', 'S86 APU GBX P', APU shifts to HI
speed (✓CRT), APU OVERSPEED or
APU UNDERSPEED, then go to step 6,
APU SHUTDOWN, 7-17

NOTE

Any previously failed actuator channel
should be bypassed via ITEM 21 on
FCS/DED DIS C/O display prior to APU
start

Cont next page

B7-14

ORB OPS/NOM/GEN H

NOM

- C2
1. FCS C/O PREP
Set EVENT TIMER to 00:00, count UP
 2. APU PRESTART

1: GNC, FCS/DED DIS C/O	2: SM 86 APU/HYD
-------------------------	------------------
- CRT2
- ✓APU, HYD, WB status no '↑' or '↓'
(except HYD B/U)
- If SYS 1:
- R4
- ✓LG EXTEND ISOL VLV tb – CL
- R2
- ✓HYD BRAKE ISOL VLV X tb – CL
HYD CIRC PUMP (three) – OFF
- BLR N2 SPLX X – ON
✓PWR (three) – ON
✓CNTLR/HTR (three) – B
✓APU AUTO SHUTDN (three) – ENA
 CNTLR PWR X – ON
HYD MN PUMP PRESS X – LO
✓APU SPEED SEL (three) – NORM
 ✓OPER (three) – OFF
 ✓FUEL TK VLV (three) – CL
✓cb APU FU TK VLV ENA (six) – cl

Inform MCC: READY FOR APU START

Wait for MCC GO

Cont next page

B7-15

ORB OPS/ALL/GEN H

NOM

- R2 3. APU START
 APU FUEL TK VLV X – OP
 ✓APU/HYD RDY X tb – gray

* If tb – bp, ✓MCC *

- 00:00 Start EVENT TIMER
 R2 APU OPER X – START/RUN
 F8 ✓HYD PRESS ind X – LOW green
 R2 ✓APU/HYD RDY X tb – bp

* If APU did not start, go to step 6 *

- F8 HYD MN PUMP PRESS X – NORM
 ✓HYD PRESS ind X – HI green

SM 87 HYD THERMAL

- ✓SW VLV ELEV (four) per table
 ✓RUD/SPDBK per table

If HYD SYS 1	If HYD SYS 2	If HYD SYS 3
1(*)	2(*)	3(*)
1(*)	2(*)	3(*)

4. AEROSURFACE DRIVE
 CRT1 SURF DR START – ITEM 10 EXEC (*)
 Verify all surfaces cycling for 30 sec

NOTE

POS '↓' may be indicated
 until HYD SYS is warm

- * If FCS CH failure ('↓' port status), *
- * reset affected FCS CH: *
- * FCS CH – ORIDE, then *
- * – AUTO *

After 30 sec of aerosurface drive,
 SURF DR STOP – ITEM 11 EXEC (*)
 ✓Surfaces not moving

Cont next page

NOM

B7-16 ORB OPS/NOM/GEN H

5. SECONDARY ACTUATOR CHECK (APU)

NOTE

If a port does not bypass during check, bypass affected port after APU shutdn:

SEC ACT BYPASS – ITEM 21 +X X EXEC

If affected port still does not bypass:

SEC ACT RESET – ITEM 22 +X X EXEC

CRT1 a. ✓POS STIM ENA, ITEM 20 – (*)

C3 b. ✓FCS CH 1,2,3,4 – AUTO

CRT1 c. SEC ACT CK, CH 1 – ITEM 15 EXEC (*)

d. ✓All CH 1 ports bypass ('↓')
STOP – ITEM 19 EXEC (*)

C3 e. FCS CH 1 – ORIDE

CRT1 ✓All CH 1 ports reset (no '↓')
C3 FCS CH 1 – AUTO

f. Repeat steps c thru e for CH 2,3,4

CRT1 g. NEG STIM – ITEM 20 EXEC (no *)

h. Repeat steps b thru f

6. APU SHUTDOWN

On MCC GO for APU SHUTDN:

R2 BLR PWR (three) – OFF
 APU OPER X – OFF
 FUEL TK VLV X – CL
 ✓Shutdn (hyd press)
 CNTLR PWR X – OFF
 BLR N2 SPLY X – OFF
 HYD CIRC PUMP (three) – GPC

Proceed to part 2

Cont next page

NOM

B7-17

ORB OPS/ALL/GEN H

7. CIRC PUMP ACTIVATION

1: GNC, FCS/DED DIS C/O	2: SM 86 APU/HYD
-------------------------	------------------

NOTE

OPS 2/8 trans must be performed with
ASAs off to avoid AERO DRIVE fault
msgs during actuator checks

- a. Perform G8 to G2 TRANSITION (DPS),
then:

O14,O15,
O16:F ASA (four) – OFF

C3 Perform G2 to G8 TRANSITION (DPS), then:
✓FCS CH 1,4 – AUTO
2,3 – OFF

R4 ASA (four) – ON

R2 ✓HYD BRAKE ISOL VLV X tb – CL

R2 ✓HYD CIRC PUMP (three) – OFF

- b. HYD CIRC PUMP X – ON

8. ABBREVIATED SECONDARY ACTUATOR
CHECK (circ pump)

NOTE

If an elevon does not move to
commanded posn, bypass affected
port after check of all channels:

SEC ACT BYPASS – ITEM
21 +X X EXEC

CRT1 a. ✓POS STIM ENA, ITEM 20 – (*)

C3 b. ✓FCS CH 1,4 – AUTO
✓2,3 – OFF

CRT2 c. GNC 42 SWITCH/SURF
✓All elevons move to U7.5° ± 0.8°

CRT1 d. SEC ACT CK, CH1 – ITEM 15 EXEC (*)
Wait 5 sec

Cont next page

NOM

B7-18 ORB OPS/ALL/GEN H

- C3 CRT2
- e. Turn off FCS CH not being checked:
FCS CH (three) – OFF
✓ All elevons move to $U1.5^\circ \pm 0.8^\circ$
 - * If any elevon drives past 0° , turn on *
 - * all FCS CHs to stop movement *
 - * FCS CH (four) – AUTO *
 - * Expect AERO DRIVE msg. Continue *
 - * procedure and report to MCC *

- CRT1
- f. STOP – ITEM 19 EXEC (*)
✓ All elevons move to $U7.5^\circ \pm 0.8^\circ$

- C3
- g. Config FCS CHs for check of next CH:
(Config switches in sequence shown)

NEXT CH	FCS CH SWITCHES			
	4	1	2	3
2	AUTO	OFF	AUTO	OFF
3	AUTO	OFF	OFF	AUTO
4	AUTO	OFF	OFF	AUTO

h. Repeat steps d thru g for CHs 2,3,4

- R2
- 9. **HYDRAULIC SYSTEM RECONFIG**
HYD CIRC PUMP (three) – GPC
 - 10. **FCS CH RECONFIG**
 - a. Perform G8 to G2 TRANSITION (DPS),
then:
FCS CH 1,2,3 – AUTO
✓ 4 – AUTO
 - b. Perform G2 to G8 TRANSITION (DPS),
then:
Continue with part 2

Cont next page

B7-19 ORB OPS/NOM/GEN H

NOM

ON-ORBIT FCS CHECKOUT, PART 2

1. Sensor Test – MLS,TAC,RA,AA

NOTE

During MLS/TAC/RA/AA test, deselect LRU for failure indicated:
MLS,TAC,RA,AA – ↑ or ↓
or AA – BIAS/NUL limits exceeded
Record values of values defined

2: GNC 40 SENSOR TEST

CRT2 ✓ DES: (no *)
 ✓ STAT: blank
 ✓ RNG,AZ,EL: no M

CONFIG FOR FREE DRIFT

F6 ADI RATE – LO
DAP: A1/INRTL/VERN
✓R,P,Y rates $0 \pm 0.1^\circ/\text{sec}$, then:
DAP: FREE

AA Bias/Null Shift Test

MLS,TAC,RA,AA Test

START – ITEM 13 EXEC (*)

NOTE

* blanks when test complete; ✓No ↑ or ↓. See Limit Values Table, 7-21

Cont next page

B7-20

NOM

ORB OPS/NOM/GEN H

LIMIT VALUES TABLE

	RNG	AZ	EL
MLS	15.0 to 15.4	+,-2.9 to +,-3.1 (+ for 3 sec, then -)	5.9 to 6.1
TAC	0 to 0.5	177.5 to 182.5 <u>NOTE</u> Values from 182.1 to 182.5 will be displayed as 2.1 to 2.5	
RA	ALT		
	900 to 1100		
AA		Y	Z
		+14.40 to 17.80	+57.70 to 71.10

07 STOP – ITEM 14 EXEC (*)
TACAN MODE (three) – OFF

2. Sensor Test – RGA, ADTA

NOTE

During RGA, ADTA test, deselect LRU for failure indicated:

RGA – bias null limits exceeded,

‘↑’ or ‘↓’, or SMRD

ADTA – any ‘↑’ or ‘↓’, except temp (‘T’)

If RGA does not respond to HIGH or LOW TEST or displays 'SMRD' indication in STAT column:

- ✓ MCC, confirm that payload config can support PRCS firings
 - Null vehicle rates
 - Maneuver at $0.5^\circ/\text{sec}$ about appropriate axis; monitor RGA data
 - If RGA responds, self-test circuitry or SMRD circuitry failed
 - If no RGA response, deselect sensor

Cont next page

NOM

B7-21 ORB OPS/NOM/GEN H

CRT2

2: GNC 41 RGA/ADTA/RCS

- ✓DES: (no *)
- ✓STAT: blank
- ✓PS,P_αC,P_αU,P_αL,T – no M

Config For Free Drift

- ✓DAP: A1/INRTL/VERN
- ✓R,P,Y rates $0 \pm 0.1^\circ/\text{sec}$, then:
DAP: FREE

RGA Bias/Null Shift Test

- ✓R,P,Y within limits: R -0.4 to $+ -0.4$
P/Y -0.2 to $+ -0.2$
- Refer to Limit Values Table, 7-23

High Test

- TEST HI – ITEM 9 EXEC (*)
(after 10 sec, no *)
- ✓No ' \uparrow ' or ' \downarrow ',
If ADTA BITE, ✓MCC (if LOS, proceed with test)

TEST STOP – ITEM 11 EXEC (*)

Low Test

- TEST LOW – ITEM 10 EXEC (*) (after 10 sec,
no *)
- ✓No ' \uparrow ' or ' \downarrow ',
If ADTA BITE, ✓MCC (if LOS, proceed with test)

TEST STOP – ITEM 11 EXEC (*)
DAP: A1/AUTO/VERN

Cont next page

B7-22

ORB OPS/ALL/GEN H

NOM

LIMIT VALUES TABLE

<u>HIGH TEST LIMITS</u>				
<u>RGA</u>				
R +18.8 to +21.2	P +9.4 to +10.6	Y +9.4 to +10.6		
<u>ADTA</u>				
PS .813 to .815	P _α C 5.473 to 5.477	P _α U 2.740 to 2.744	P _α L 1.708 to 1.712	T 173.56 to 173.60
<u>LOW TEST LIMITS</u>				
<u>RGA</u>				
R -18.8 to -21.2	P -9.4 to -10.6	Y -9.4 to -10.6		
<u>ADTA</u>				
PS 24.887 to 24.889	P _α C 29.527 to 29.531	P _α U 21.708 to 21.712	P _α L 14.713 to 14.717	T 18.50 to 18.54

Cont next page

NOM

B7-23 ORB OPS/NOM/GEN H

3. SENSOR TEST – GPS

NOTE

After GPS S/TEST, deselect LRU for failure indicated by '↓'. GPS self-test takes about 2 min to complete. 'BIT' in STAT field on SPEC 55 indicates hardware feedback and clears when test complete

2: GNC 55 GPS STATUS

- ✓NAV – ITEM 18 (*)
If 'RPF' in STAT field, ✓MCC (if LOS, proceed with test)
- S/TEST – ITEM 12 EXEC (*)
- ✓'BIT' in STAT field after ~6 sec
Wait for 'BIT' to clear after ~2 min
- ✓S/TEST '↑'; if '↓' deselect GPS
NAV – ITEM 18 EXEC (*)
- ✓MODE – INS

4. FCS MODE/CH SWITCH TEST

NOTE

During tests, FCS CH:

Fail op or fail cl – deselect failed contacts
FCS CH OVERRIDE function of a CH with failed contacts may be made operable if at least one good contact available.
Proceed: ✓MCC when possible

FCS MODE:

- Fail op – 2 op or 1 op/1 cl contacts preclude use of sw
- Fail cl – 1st failure, deselect failed contact
2nd failure L(R), deselect all L(R) contacts

Cont next page

B7-24

ORB OPS/ALL/GEN H

NOM

ENTRY MODE:

Fail op or cl – 1st, 2nd failure, deselect contact
3rd failure, when in OPS 3,
GNC 51 OVERRIDE
AUTO SEL – ITEM 42
EXEC (*)

2: GNC 43 CONTROLLERS

Deselect L THC:

CRT2 THC L DES – ITEMS 1,2,3 EXEC (*)

2: GNC 42 SWITCH/SURF

CRT2

NOTE

During following tests, verify '*' appears except as noted. If '*' remains after releasing pb, contact failed closed

F7/F8

FLT CNTLR PWR (two) – ON
C3 FCS CH (four) – ORIDE (wait 5 sec)
 – AUTO (no *)

F2/F4

PITCH pb – AUTO
 – CSS
ROLL/YAW pb – AUTO
 – CSS

L2/C3

SPDBK/THROT pb – AUTO
BODY FLAP pb – AUTO
SBTC TAKEOVER pb – push

5. SURF TEST

Notify MCC if any single surf feedback exceeds average of other three feedbacks by greater than:

Elevons ($\Delta 1.3^\circ$)
Rudder ($\Delta 1.2^\circ$)
SPD BK ($\Delta 2.2\%$)
BDY FLP ($\Delta 3\%$)

Cont next page

B7-25

NOM

ORB OPS/ALL/GEN H

2: GNC 44 SWITCHES

During following sw test, verify '*' appears

- L2 ENTRY MODE – LO GAIN
 – NO Y JET
 – AUTO (no *)

6. **NWS CHECK**

2: GNC 45 NWS CHECK

- CRT2 NOTE
 During following tests, verify position
 transducer values A,B,C remain ~0.00°
 ✓Position A,B,C: 0.00° ± 0.75°

- L2 a. NWS1
 NWS – 1

- CRT2 ✓NWS1 SYS SEL (*)
 ✓HYD PRESS HIGH (no *)
 ✓CURRENT: 1.00 ma to 3.15 ma

- F3 ✓ENABLE – ITEM 1 EXEC (*)
 ✓NWS1 ENABLE A,B (*)
 ✓NWS FAIL lt – on (illuminated)

- CRT2 RIGHT TURN – ITEM 2 EXEC (*)
 ✓NWS1 CURRENT: 3.75 ma to 6.25 ma

- LEFT TURN – ITEM 3 EXEC (*)
 ✓NWS1 CURRENT: -4.25 ma to -1.75 ma
 STOP – ITEM 4 EXEC (*)
 ✓NWS1 CURRENT: 1.00 ma to 3.15 ma

- L2 b. NWS2
 NWS – 2

- CRT2 ✓NWS2 SYS SEL (*)
 ✓HYD PRESS HIGH (no *)
 ✓CURRENT: 1.00 ma to 3.15 ma

Cont next page

B7-26

ORB OPS/ALL/GEN H

NOM

F3 ENABLE – ITEM 1 EXEC (*)
 ✓NWS2 ENABLE A,B (*)
 ✓NWS FAIL lt – on (illuminated)

CRT2 RIGHT TURN – ITEM 2 EXEC (*)
 ✓NWS2 CURRENT: 3.75 ma to 6.25 ma

 LEFT TURN – ITEM 3 EXEC (*)
 ✓NWS2 CURRENT: -4.25 ma to -1.75 ma
 STOP – ITEM 4 EXEC (*)
 ✓NWS2 CURRENT: 1.00 ma to 3.15 ma

L2 NWS – OFF

7. CONTROLLER AND SWITCH TEST

NOTE

During cntlr/sw test,
THC: One TX(TY,TZ) failed CLOSED –
reselect all contacts (failed
contact last)
One TX(TY,TZ) failed OPEN –
reselect good contacts only
Multi +TX,-TX,+TY,-TY,+TZ,-TZ
failures – reselect good
contacts only

SPDBK L(R): Deselect failed xdcrs
After 2nd L(R) failure,
use other side

RUD PED L(R): One failure – deselect
failed xdcr
Multi L(R) failures –
deselect all L(R) xdcrs

RHC L(R): One xdcr failure – reselect
good xdcrs only
Multi L(R) failures – reselect
good xdcrs L(R) and F7(F8)
FLT CNTLR PWR – OFF

Cont next page

NOM

B7-27 ORB OPS/ALL/GEN H

BDY FLP L(R): Fail close, deselect all L(R) contacts

RHC or PNL TRIM L(R): If contact failed, deselect failed contact row

2: GNC 43 CONTROLLERS

F5
CRT2

- a. THC
L THC – deflect in each axis
✓ THC: '+' and '-'
Reselect THC contacts:
THC L – ITEM 1,2,3 EXEC (no *)
- b. L SBTC
L SBTC – full aft; ✓ > 95%
– full fwd; ✓ < 15%
- c. Rudder/Brake
RUD PED – full L; ✓ > 87% and ch Δ < 9%
– full R; ✓ > 80% and ch Δ < 9%
– null; between L 14% and R 4%
BK PED – depress to verify unrestricted movement (~20 to 25°)
- d. L Body Flap Switch
BDY FLP – UP, DN
✓ BDY FLP UP, DN – ‘*’
- e. L RHC
Deselect L RHC:
RHC L DES – ITEM 23,24,25 EXEC (*)
L RHC – deflect to hardstop in each axis
✓ RHC L: R,P – > 92%
Y – > 88%

Reselect RHC CHs:
RHC L DES – ITEM 23,24,25 EXEC (no *)

L2
CRT2

Cont next page

B7-28

ORB OPS/ALL/GEN H

NOM

- f. L RHC Trim Switch
 L RHC Trim – deflect sw in each axis
 ✓RHC TRIM L: R – R/L
 P – U/D

- L2 g. L Panel Trim Switches
 ROLL TRIM – R, then L
 PITCH TRIM – UP, then DN
 YAW TRIM – R, then L
 ✓PNL TRIM L: R,Y – R/L
 P – U/D

- F3 TRIM RHC/PNL – ENA
 (wait 5 sec; no crew insight)
 TRIM RHC/PNL – INH

- h. Repeat steps b and d thru g for R cntlrs/sw:
 RHC R DES – ITEM 26,27,28

8. DEDICATED DISPLAY/HUD CHECK
 ✓HUD BRT (two) – as reqd
 MODE (two) – TEST
 ✓Brightness
 ✓Format 'COMPLETE' msg
 HUD MODE (two) – NORM

- CRT1 DED DIS FWD – ITEM 1 EXEC (*)
 LOW – ITEM 4 EXEC (*)

✓HUD using HUD low value test diagram

- F6/F8 ✓Readouts for DATA BUS 1,2,3,4

- CRT1 DED DIS HIGH – ITEM 3 EXEC (*)

- F6/F8 ✓Readouts for DATA BUS 1,2,3,4 and record
 deltas

* For ADI failure, consult MCC *
 * for possible replacement *

Cont next page

NOM

B7-29 ORB OPS/NOM/GEN H

Dedicated Display Input Checkout Values			
	<u>Parameter</u>	<u>Low Value</u>	<u>High Value</u>
F6/F8 ADI:	R,P,Y ATT	20°	— 300° —
	R,Y RATE	2 ticks L	— 3 ticks R —
	P RATE	2 ticks D	— 3 ticks U —
	R,Y ATT ERR	2 ticks L	— 3 ticks R —
	P ATT ERR	2 ticks D	— 3 ticks U —
	AMI: ALPHA	+2°	— +30° —
	ACCEL	+20 fps ²	— +30 fps ² —
	M/VEL	20,000 fps	— Mach 3 —
	EAS	20 kts	— 300 kts —
	AVVI: ALT ACCEL	-2 fps ²	— +3 fps ² —
HSI:	ALT RATE	-200 fps	— +300 fps —
	ALT	200 ft	— +300K ft —
	RDR ALT	200 ft	— +3000 ft —
	SEL COURSE	200°	— 30° —
	HEADING	20°	— 300° —
	PRI BEAR	20°	— 30° —
	SEC BEAR	200°	— 300° —
	PRI,SEC MILES	200 nmi	— 3000 nmi —
	CDI	1 tick L	— 1 tick R —
	GSI	1 tick D	— 1 tick U —
F7 SPI:	ELEV	U20°	— U30° —
	BDY FLP	20%	— 30% —
	RUD	20° L	— 3° R —
	AILERON	2° L	— 3° R —
	SPD BK	20%	— 30% —
	SPD BK CMD	20%	— 30% —


Cont next page

B7-30

ORB OPS/NOM/GEN H

NOM

HUD LOW VALUE TEST
NOTE
No HUD high value test exists



- CRT1 9. FLAG TEST
DED DIS FLAG – ITEM 5 EXEC (*)

FLAG TEST		
Verify flags visible:		
AMI	4	
AVVI	4	
HSI	MILES	2
	CDI	1
	BRG	1
GSI	1	(pointer stowed)
ADI	6 (rate/err needle stowed)	
SPI	1	

- Test Terminate
DED DIS OFF – ITEM 6 EXEC (*)

Cont next page

B7-31

ORB OPS/NOM/GEN H

NOM

10. MODE LAMP TEST

Test Start

CRT1 MODE LT ON – ITEM 7 EXEC (*)

F2/F4 ✓PITCH AUTO,CSS lt (two) – on
✓ROLL/YAW AUTO,CSS lt (two) – on
✓SPDBK/THROT AUTO,MAN lt (two) – on
✓BDY FLP AUTO,MAN lt (two) – on

Test Terminate

CRT1 MODE LT OFF – ITEM 8 EXEC (*)

F7/F8 FLT CNTLR PWR (two) – OFF

Display/DPS Reconfig

Perform G8 TO G2 TRANSITION (DPS), then:

F3 TRIM PNL (two) – OFF

HUD PWR (two) – OFF

F6,F8 INST PWR (two) – OFF

C3 FCS CH (four) – AUTO

O8 MLS (three) – OFF

RADAR ALTM (two) – OFF

O14, RGA (four) – OFF

O15, cb MNA,B,C ADTA (four) – op

O16 MNA,B ACCEL 1,2 (two) – op

DDU L (two) – as reqd

MNB,C DDU R (two) – op

ASA (four) – OFF

ACCEL 3,4 (two) – OFF

L2 BRAKES (three) – OFF

ANTISKID – OFF

O17 ATVC (four) – OFF

NOM

B7-32 ORB OPS/NOM/GEN H

AFT CONTROLLER C/O

1. POWER UP

GNC 25 RM ORBIT

Deselect A THC:

THC A DES – ITEM 4,5,6 EXEC (*)

O14:E ✓cb MNA DDU AFT – cl
O16:E ✓MNC DDU AFT – cl
A6U FLT CNTLR PWR – ON

2. AFT THC

A THC – deflect in each axis

✓THC: '+' and '-'

AFT CONTROLLER C/O						
THC	PUSH	PULL	LEFT	RIGHT	UP	DOWN
DISP	+X	-X	+Z	-Z	-Y	+Y

- * During THC test, *
- * One TX(TY,TZ) failed CLOSED – *
- * reselect all contacts (failed contact last) *
- * One TX(TY,TZ) failed OPEN – reselect *
- * good contacts only *
- * Multi +TX,-TX,+TY,-TY,+TZ,-TZ *
- * failures – reselect good contacts only *

Reselect A THC contacts:

THC A DES – ITEM 4,5,6 EXEC (no *)

Cont next page

3. AFT RHC

Deselect A RHC:

CRT

RHC A DES – ITEM 13,14,15 EXEC (*)

A RHC – deflect to hardstop in each axis

✓RHC A: R,P > 92%

Y > 88%

* During RHC test,

* One xdcr failure – reselect good xdcrs *

* only *

* Multi RHC failures – reselect good *

* xdcr, A6U FLT CNTLR PWR – OFF *

Reselect RHC CHs:

RHC A DES – ITEM 13,14,15 EXEC (no *)

4. RECONFIG TO NOMINAL

A6U

FLT CNTLR PWR – OFF

O14:E,

AFT DDU PWR – as reqd

O16:E

OMICRON SPECIFICATION

1. DETERMINE REFERENCE ATTITUDE

Designated body axis pointed toward target (P).
Y body axis in same plane as negative angular
momentum vector ($-h$) and P

2. DETERMINE DESIRED ATTITUDE

Rotate cw around P (right-hand rule) to desired
attitude

Omicron = angle of rotation around P from
reference attitude to desired attitude

NOTE

If P = $\pm Y$ body axis, use $-Z$
body axis for reference attitude

ELEVON PARK, GNC 201

1. Perform G2 to G8 TRANSITION (DPS)
- O16:F 2. ASA 4 – ON
3. Perform G8 TO G2 TRANSITION (DPS)
- R2 4. HYD CIRC PUMP 1 – ON

NOTE

Elevons will be positioned
within 3 min

On MCC GO,
HYD CIRC PUMP 1 – GPC

GPS PWRUP

1. CHECK GPS ANTENNA PRE-AMP CONFIG

O15:C GPS 2 PRE AMPL UPPER – cl
O15:D LOWER – cl
A13 (A12
if OV102) PRE AMPL UC – ON
 LC – ON

2. PWR UP GPS RECEIVER

* If GPS just PWRD off, wait *
* at least 30 sec *

A13 (A12
if OV102) GPS PWR – ON
 ✓ENCRYPT – NORMAL
Wait at least 30 sec
GNC I/O RESET

3. INITIALIZE GPS RECEIVER

GNC 55 GPS STATUS

- ✓NAV – ITEM 18 (*)
- INIT – ITEM 15 EXEC (*)
- ✓MODE – INIT
- NAV – ITEM 18 EXEC (*)
- ✓MODE – INS

MEDS

A7-37 ORB OPS/MEDS/GEN H

GPS PWRDN

1. CHECK GPS RECEIVER MODE
SPEC 55 GPS STATUS
✓NAV – ITEM 18 (*)
2. PWR OFF GPS RECEIVER
A13 (A12
if OV102)
GPS PWR – OFF
3. PWR OFF GPS ANTENNA PRE-AMPS
A13 (A12
if OV102)
All except OV102
GPS 2 PRE AMPL UC – op
O15:C
O15:D
LC – op

MEDS

A7-38 ORB OPS/MEDS/GEN H

GPS SELF-TEST, GNC 201,202,301,801

1. CHECK GPS ANTENNA PRE-AMP CONFIG (if reqd)

O15:C ✓GPS 2 PRE AMPL UPPER – cl
O15:D LOWER – cl

A13 ✓PRE AMPL UC – ON
 LC – ON
 ✓ENCRYPT – NORMAL

2. PWR UP GPS RECEIVER (if reqd)

* If GPS just PWRD off, wait *
* at least 30 sec *

GPS PWR – ON
Wait at least 30 sec
GNC I/O RESET

3. INITIALIZE GPS RECEIVER (if reqd)

GNC 55 GPS STATUS

✓NAV – ITEM 18 (*)
INIT – ITEM 15 EXEC (*)
✓MODE – INIT
Wait 5 sec
NAV – ITEM 18 EXEC (*)
✓MODE – INS

4. GPS SELF-TEST

2: GNC 55 GPS STATUS

✓NAV – ITEM 18 (*)
If “RPF” in STAT field, ✓MCC (If LOS,
proceed with test)
S/TEST – ITEM 12 EXEC
✓“BIT” in STAT field after ~6 sec
Wait for “BIT” to clear after ~2 min
✓S/TEST ‘↑’; if ‘↓’ deselect GPS
NAV – ITEM 18 EXEC (*)

✓MODE – INS

Cont next page

MEDS

A7-39 ORB OPS/MEDS/GEN H

- A13 5. PWR OFF GPS RECEIVER (if reqd)
 GPS PWR – OFF
6. PWR OFF GPS ANTENNA PRE-AMPS (if reqd)
 GPS PRE AMPL UC – OFF
 LC – OFF
- O15:C 2 PRE AMPL UPPER – op
O15:D LOWER – op

MEDS

A7-40 ORB OPS/MEDS/GEN H

GPS PWRUP

1. CHECK GPS ANTENNA PRE-AMP CONFIG

O14:D ✓cb MNA GPS PRE AMPL UC – op
 LC – cl
O16:D MNC GPS PRE AMPL UC – cl
 ✓LC – op
A13 GPS PRE AMPL UC – MNC
 LC – MNA

2. PWR UP GPS RECEIVER

* If GPS just PWRD off, wait *
* at least 30 sec *

GPS PWR – ON
✓ENCRYPT – NORMAL
Wait at least 30 sec
GNC I/O RESET

3. INITIALIZE GPS RECEIVER

GNC 55 GPS STATUS
✓NAV – ITEM 18 (*)
INIT – ITEM 15 EXEC (*)
✓MODE – INIT
NAV – ITEM 18 EXEC (*)
✓MODE – INS

NOM

B7-37 ORB OPS/NOM/GEN H

GPS PWRDN

1. CHECK GPS RECEIVER MODE
SPEC 55 GPS STATUS
✓NAV – ITEM 18 (*)
2. PWR OFF GPS RECEIVER
A13 GPS PWR – OFF
3. PWR OFF GPS ANTENNA PRE-AMPS
GPS PRE AMPL UC – OFF
LC – OFF
O14:D ✓cb MNA GPS PRE AMPL UC – op
LC – op
O16:D ✓MNC GPS PRE AMPL UC – op
LC – op

NOM

B7-38 ORB OPS/NOM/GEN H

GPS SELF-TEST, GNC 201,202,301,801

1. CHECK GPS ANTENNA PRE-AMP CONFIG (if reqd)

O14:D ✓cb MNA GPS PRE AMPL UC – op
 LC – cl
O16:D MNC GPS PRE AMPL UC – cl
 ✓LC – op

A13 GPS PRE AMPL UC – MNC
 LC – MNA
 ✓ENCRYPT – NORMAL

2. PWR UP GPS RECEIVER (if reqd)

- * If GPS just PWRD off, wait *
- * at least 30 sec *

GPS PWR – ON
Wait at least 30 sec
GNC I/O RESET

3. INITIALIZE GPS RECEIVER (if reqd)

GNC 55 GPS STATUS

- ✓NAV – ITEM 18 (*)
- INIT – ITEM 15 EXEC (*)
- ✓MODE – INIT
- Wait 5 sec
- NAV – ITEM 18 EXEC (*)
- ✓MODE – INS

4. GPS SELF-TEST

2: GNC 55 GPS STATUS

- ✓NAV – ITEM 18 (*)
- If “RPF” in STAT field, ✓MCC (If LOS,
proceed with test)
- S/TEST – ITEM 12 EXEC
- ✓“BIT” in STAT field after ~6 sec
- Wait for “BIT” to clear after ~2 min
- ✓S/TEST ‘↑’; if ‘↓’ deselect GPS
- NAV – ITEM 18 EXEC (*)
- ✓MODE – INS

NOM

B7-39 ORB OPS/NOM/GEN H

- A13 5. PWR OFF GPS RECEIVER (if reqd)
 GPS PWR – OFF
6. PWR OFF GPS ANTENNA PRE-AMPS (if reqd)
 GPS PRE AMPL UC – OFF
 – OFF
- O14:D ✓cb MNA GPS PRE AMPL UC – op
 LC – op
- O16:D MNC GPS PRE AMPL UC – op
 ✓LC – op

NOM

B7-40 ORB OPS/NOM/GEN H

MPS

MPS VACUUM INERT 8-2

MPS

8-1

ORB OPS/ALL/GEN H

MPS VACUUM INERT

MPS

ACTIVATION

R2 1. MPS PNEU He ISOL – OP

R4 2. MPS FILL/DRAIN LH2 OUTBD – CL
Wait 15 sec

 3. MPS FILL/DRAIN LH2 OUTBD – OP

TERMINATION

NOTE

After 1 min or on MCC call

4. MPS FILL/DRAIN LH2 OUTBD – CL
Wait 15 sec

5. MPS FILL/DRAIN LH2 OUTBD – GND

R2 6. PNEU He ISOL – GPC

OMS

ON-ORBIT OMS BURN 9-2

OMS

9-1 ORB OPS/ALL/GEN H

ON-ORBIT OMS BURN

OMS

- C2
Wedge
1. **OMS BURN PREP**
Install OMS-2/ORBIT_OMS_BURNS
Cue Cards (two) and ORBIT BURN MONITOR Cue Cards (two) (F6,F8)

GNC 55 GPS STATUS
✓GPS TO NAV – INH (*)

CRT

If OPS 2:

- 1: GNC 20 DAP CONFIG
✓DAP Config A1,B1
1: GNC UNIV PTG
CNCL – ITEM 21 EXEC
GNC, OPS 202 PRO
1: GNC ORBIT MNVR EXEC
2: GNC SYS SUMM 2

If OPS 3:

- GNC, OPS 302 PRO
1: GNC DEORB MNVR EXEC
3: BFS, GNC SYS SUMM 2

F7

- ✓OMS PRESS He TK L(R) > 640 psia
✓N2 TK L(R) > 564 psia

WARNING
If OMS PRESS not within limits,
do not execute on-orbit burn

O14:F,
O15:F,
O16:F

- ✓Pri RJD LOGIC,DRIVER (sixteen) – ON

O14:E,
O15:E,
O16:E

- ✓cb DDU (six) – cl

Cont next page

2. LOAD TGT DATA
 Load TGT DATA per Burn Pad
 LOAD – ITEM 22 EXEC
 TIMER – ITEM 23 EXEC
 ✓BURN DATA per Burn Pad
 C3 DAP: If OPS 2, B/AUTO/VERN
 If OPS 3, AUTO
 CRT1 MNVR – ITEM 27 EXEC (*)
- TIG-4 3. PERFORM OMS BURN
 If xfeed Burn:
 ✓L(R) OMS TK ISOL (two) – OP (tb-OP)
 ✓R(L) OMS TK ISOL (two) – CL (tb-CL)
 ✓L,R OMS XFEED B (two) – OP (tb-OP)
- If straight feed:
 ✓L,R OMS TK ISOL (four) – OP (tb-OP)
- F7/F8 FLT CNTLR PWR (two) – ON
 Perform OMS-2/ORBIT OMS BURNS
 (Cue Card), then:
4. OMS POST BURN RECONFIGURATION
 CRT1 Perform OMS TVC GMBL CK as reqd
 * If down arrow(s) or M(s), *
 * select good GMBL *
- F7/F8 FLT CNTLR PWR (two) – OFF
 O14:E, cb DDU (six) – as reqd
 O15:E,
 O16:E
- O8 L,R OMS He PRESS/VAP ISOL (four) – CL

Cont next page

If feeding ICNCT:
✓L(R) OMS XFEED A – CL (tb-CL)
 B – OP (tb-OP)
✓R(L) OMS XFEED (two) – CL (tb-CL)

Otherwise:
L, R OMS XFEED (four) – CL (tb-CL)
TK ISOL (four) – OP (tb-OP)

CRT


• - - - - -
• IF OPS 2
• DAP: B/INRTL/VERN
• GNC, OPS 201 PRO (✓DAP)
• - - - - -

5. RECONFIG FOR GROUP B(C)

If Group B(C) Pwrnd:
O14:F, Pri RJD LOGIC,DRIVER (sixteen) – OFF
O15:F, RJDA 1A L2/R2 MANF DRIVER – ON
O16:F

ORB OPS/ALL/GEN H

9-5



ORBITAL MANEUVER PAD FOR _____

BURN ATT	
R 24	
P 25	
Y 26	

ΔV_{TOT}			
TGO	:		
VGO X	()		
VGO Y	()		
VGO Z	()		
HA			HP
TGT		()	

NOTES

OMS GMBL CK:

	PRE	POST-BURN
L PRI		
L SEC		
R PRI		
R SEC		

RCS I'CNCT:

	L OMS	RCS
	R OMS	RCS
	NONE	

DOWN MODE OPTIONS:

	2 OMS	1 OMS	RCS
	2 OMS	1 OMS	
	1 OMS	RCS	
	NONE		

OMS HE REG TEST:
L,R OMS HE P/VAP ISOL

	GPC	OP	CL
A			
B			

-X RCS BURNS:


	BURN ATT	LVLH ATT
P 15		
Y 16		
OM 17		

ORBIT BURN MONITOR:

GPC		()
	CRIT BURN	
	NON-CRIT BURN	

ORB OPS/ALL/GEN H

9-6



ORBITAL MANEUVER PAD FOR _____

BURN ATT	
R 24	
P 25	
Y 26	

ΔV_{TOT}				
TGO	:			
VGO X	()			
VGO Y	()			
VGO Z	()			

HA	HP
TGT	()

NOTES

OMS GMBL CK:	PRE	POST-BURN
L PRI		
L SEC		
R PRI		
R SEC		

RCS I'CNCT:	L OMS	RCS
	R OMS	RCS
	NONE	

DOWN MODE OPTIONS:	2 OMS	1 OMS	RCS
	2 OMS	1 OMS	
	1 OMS	RCS	
	NONE		

OMS HE REG TEST: L,R OMS HE P/VAP ISOL	-X RCS BURNS:		
	BURN ATT	LVLH ATT	
	P 15	R	
	Y 16	P	
	OM 17	Y	

GPC	OP	CL
A		
B		

ORBIT BURN MONITOR:	GPC	()
CRIT BURN		
NON-CRIT BURN		

RCS

RCS HOT FIRE TEST	10-2
GG FREE DRIFT	10-6
PRCS PTC	10-8
VRCs PTC	10-9
ON-ORBIT +X RCS BURN, MM202	10-10
-X RCS BURN, MM202	10-13
MULTI-AXIS RCS BURN, MM202	10-15
LOSS OF VERNIERS	10-18
RECOVERY OF VERNIERS	10-19
RCS REGULATOR RECONFIG	10-20

RCS

RCS HOT FIRE TEST

NOTE

If RMS not cradled, verify RMS not in jet impingement zone (✓MCC if desired)

1. CONFIGURE FOR JET TEST

DAP: A1/INRTL/VERN

2. PERFORM RCS JET TEST

Wait 3 sec between pulses

Monitor CRT for JET FAIL msgs

Monitor ADI rates to verify jet on or jet fail

RCS

NOTE

If failed RCS JET detected, wait
30 sec before next pulse,
deselect any failed RCS JET not
auto deselected, complete TEST,
then go to MAL, RCS, 10.1a
(MAL, RCS)

O14, Pri RJD LOGIC,DRIVER (sixteen) – ON
O15, ✓cb MNA,B DDU L (two) – cl

O16

DAP TRANS: PULSE/PULSE/PULSE
DAP: A/FREE/PRI

F6

ADI RATE – LO

F7/F8

FLT CNTLR PWR – ON

GNC 23 RCS

CRT RCS FWD – ITEM 1 EXEC (*)

MANF VLVS STAT OVRD

✓1 OP – ITEM 40

✓2 OP – ITEM 41

3 CL – ITEM 42 EXEC

4 CL – ITEM 43 EXEC

JET DES F2U – ITEM 21 EXEC (*)

Cont next page

RCS L – ITEM 2 EXEC (*)
MANF VLVS STAT OVRD

✓1 OP – ITEM 40
2 CL – ITEM 41 EXEC
3 CL – ITEM 42 EXEC
4 CL – ITEM 43 EXEC
RCS R – ITEM 3 EXEC (*)
MANF VLVS STAT OVRD

✓1 OP – ITEM 40
2 CL – ITEM 41 EXEC
3 CL – ITEM 42 EXEC
4 CL – ITEM 43 EXEC

Perform following pulse sequence twice:

F5 THC: +X, 1 PULSE (fires jets R1A,L1A)
 -X, 1 PULSE (fires jets F1F,F2F)
 +Z, 1 PULSE (fires jets F1U,R1U,L1U)
F6 +Y, 1 PULSE (fires jets F1L,L1L)
 -Y, 1 PULSE (fires jets F2R,R1R)

CRT ✓RCS R, ITEM 3 – (*)
 MANF VLVS STAT OVRD
 1 CL – ITEM 40 EXEC
 2 OP – ITEM 41 EXEC
 ✓3 CL – ITEM 42
 ✓4 CL – ITEM 43

RCS L – ITEM 2 EXEC (*)
MANF VLVS STAT OVRD
1 CL – ITEM 40 EXEC
2 OP – ITEM 41 EXEC
✓3 CL – ITEM 42
✓4 CL – ITEM 43

RCS F – ITEM 1 EXEC (*)
JET DES F1U – ITEM 17 EXEC (*)
 F2U – ITEM 21 EXEC (no *)

Perform following pulse sequence twice:

THC: +Z, 1 PULSE (fires jets F2U,L2U,R2U)
 -Z, 1 PULSE (fires jets F1D,F2D,L2D,R2D)
 +Y, 1 PULSE (fires jets F1L,L2L)
 -Y, 1 PULSE (fires jets F2R,R2R)

Cont next page

✓RCS F, ITEM 1 – (*)
JET DES F1U – ITEM 17 EXEC (no *)
MANF VLVS STAT OVRD
1 CL – ITEM 40 EXEC
2 CL – ITEM 41 EXEC
3 OP – ITEM 42 EXEC
4 OP – ITEM 43 EXEC

CRT RCS L – ITEM 2 EXEC (*)
MANF VLVS STAT OVRD
✓1 CL – ITEM 40
2 CL – ITEM 41 EXEC
3 OP – ITEM 42 EXEC
✓4 CL – ITEM 43

RCS R – ITEM 3 EXEC (*)
MANF VLVS STAT OVRD
✓1 CL – ITEM 40
2 CL – ITEM 41 EXEC
3 OP – ITEM 42 EXEC
✓4 CL – ITEM 43

Perform following pulse sequence twice:
THC: +X, 1 PULSE (fires jets L3A,R3A)
–X, 1 PULSE (fires jet F3F)
–Z, 1 PULSE (fires jets F3D,F4D,L3D,R3D)
+Y, 1 PULSE (fires jets F3L,L3L)
–Y, 1 PULSE (fires jets F4R,R3R)

✓RCS R, ITEM 3 – (*)
MANF VLVS STAT OVRD
✓1 CL – ITEM 40
✓2 CL – ITEM 41
3 CL – ITEM 42 EXEC
4 OP – ITEM 43 EXEC

RCS L – ITEM 2 EXEC (*)
MANF VLVS STAT OVRD
✓1 CL – ITEM 40
✓2 CL – ITEM 41
3 CL – ITEM 42 EXEC
4 OP – ITEM 43 EXEC

Cont next page

Perform following pulse sequence twice:

THC: +Z, 1 PULSE (fires jets F3U,L4U,R4U)
-Z, 1 PULSE (fires jets F3D,F4D,L4D,R4D)
+Y, 1 PULSE (fires jets F3L,L4L)
-Y, 1 PULSE (fires jets F4R,R4R)

F7/F8 DAP: A/INRTL/VERN
 FLT CNTLR PWR – OFF

CRT 3. RECONFIGURE JET SELECT
 ✓RCS L, ITEM 2 – (*)

MANF VLVS STAT OVRD
1 OP – ITEM 40 EXEC
2 OP – ITEM 41 EXEC
3 OP – ITEM 42 EXEC
✓4 OP – ITEM 43

RCS R – ITEM 3 EXEC (*)
MANF VLVS STAT OVRD
1 OP – ITEM 40 EXEC
2 OP – ITEM 41 EXEC
3 OP – ITEM 42 EXEC
✓4 OP – ITEM 43

RCS F – ITEM 1 EXEC (*)
MANF VLVS STAT OVRD
1 OP – ITEM 40 EXEC
2 OP – ITEM 41 EXEC
✓3 OP – ITEM 42
✓4 OP – ITEM 43

R15:C 4. CONFIG FOR VERN MANIFOLD VLV TEST
 cb MNC MANF ISOL L5,R5,F5 ENA (three) – op
 5. PERFORM TEST

NOTE

If any vernier manifold closes, ignore DAP RECONFIG message, reopen affected manifold, complete TEST, and notify MCC

O7,O8 L,R,F RCS MANF ISOL 5 (three) – CL (tb-OP)
R15:C 6. CLEANUP
O14,O15,
O16 cb MNC MANF ISOL L5,R5,F5 ENA (three) – cl
 Pri RJD LOGIC,DRIVER (sixteen) – as reqd
 ✓cb MNA,B DDU L (two) – as reqd
 Reconfig to FLIGHT PLAN DAP

GG FREE DRIFT

1. AUTO MNVR TO ATTITUDE

Change DAP A,B to A3,B3

DAP: B3/AUTO/VERN(ALT)

GNC UNIV PTG

✓TGT ID, ITEM 8 – 2

BODY VECT – ITEM 14 +5 EXEC

Load Body Vector P,Y,OM (per table, 10–7)

TRK – ITEM 19 EXEC (CUR – *)

✓ERR TOT, ITEM 23 – (*)

2. ESTABLISH FREE DRIFT

F6,F8

✓Att mnvr complete

ADI ATT – LVLH

L1

FLASH EVAP CNTLR PRI A,B (two) – OFF

✓SEC – OFF

✓HI LOAD DUCT HTR – OFF

If VERN jets avail:

DAP: A3/AUTO/VERN

Wait 3 min

DAP: FREE

If VERN jets not avail:

DAP: A3/AUTO/ALT

Wait 30 sec

When $-0.01 < \text{Roll Rate} < 0.01$, then:

DAP: FREE

Rcd MET ____/____ ____:____:____

NOTE

If FREON EVAP OUT TEMP > 60 , execute
PRIORITY PWRDN GROUP A and
subsequent (ORB PKT, PRIOR PWRDN) to
maintain FREON EVAP OUT TEMP ≤ 55

Cont next page

3. VEHICLE RECOVERY AND FES RESTART
 DAP: A3/FREE/VERN(ALT)
 If VERN jets avail:
 ✓All RJD LOGIC,DRIVER (seventeen) – ON
 O14:F,
 O15:F,
 O16:F
- If VERN jets not avail:
 ✓Pri RJD LOGIC,DRIVER (sixteen) – ON
- F6,F8 ADI ATT – as reqd
 Reconfig to FLIGHT PLAN DAP
 DAP: INRTL
 If FES reqd:
- | | | | | | | | | |
|---------|--|--|--|--|--|--|--|--|
| CRT(O1) | SM 88 APU/ENVIRON THERM | | | | | | | |
| L1 | If FREON EVAP OUT TEMP > 41 and ≤ 47 degF:
RAD CNTLR OUT TEMP – HI | | | | | | | |
| CRT(O1) | When FREON EVAP OUT TEMP > 50 degF,
RAD CNTLR OUT TEMP – NORM,
then immediately: | | | | | | | |
| L1 | FLASH EVAP CNTLR PRI A(B) – ON | | | | | | | |
| CRT(O1) | If FREON EVAP OUT TEMP ≤ 41 or > 47 degF:
FLASH EVAP CNTLR PRI A(B) – ON | | | | | | | |
| L1 | | | | | | | | |

GRAVITY GRADIENT BODY VECTORS

		ATT ID	EXEC DATA			BODY RATES (± 0.002)		
			P	Y	OM	R	P	Y
+	PLBD NORTH SOUTH	A B	357.51 357.51	0.97 359.23	249.18 110.91	0.002 -0.002	0.024 0.024	-0.062 0.062
-	PLBD NORTH SOUTH	C D	177.51 177.51	0.77 359.03	69.09 290.82	0.002 -0.002	-0.024 -0.024	-0.062 0.062

PRCS PTC

1. MNVR TO PTC ATTITUDE

NOTE

If crew sleep, use tail-only control for all DAPs

DAP: A1/AUTO/ALT

GNC UNIV PTG

CRT

TGT ID – ITEM 8 +4 EXEC
BODY VECT – ITEM 14 +5 EXEC
P – ITEM 15 +2 7 0 EXEC
Y – ITEM 16 +0 EXEC
OM – ITEM 17 +2 7 0 EXEC
TRK – ITEM 19 EXEC (CUR – *)

2. INITIATE PTC ROTATION

GNC 20 DAP CONFIG

Change DAP A to A2

GNC UNIV PTG

BODY VECT – ITEM 14 +1 EXEC
ROT – ITEM 20 EXEC (CUR – *)

3. TERMINATE PTC ROTATION

GNC UNIV PTG

CNCL – ITEM 21 EXEC
Reconfig to FLIGHT PLAN DAP

VRCS PTC

1. MNVR TO PTC ATTITUDE

DAP: A1/AUTO/VERN

GNC UNIV PTG

CRT TGT ID – ITEM 8 +4 EXEC
BODY VECT – ITEM 14 +5 EXEC
P – ITEM 15 +2 7 0 EXEC
Y – ITEM 16 +0 EXEC
OM – ITEM 17 +2 7 0 EXEC
TRK – ITEM 19 EXEC (CUR – *)

2. INITIATE PTC ROTATION

When in attitude:

GNC UNIV PTG

BODY VECT – ITEM 14 +1 EXEC
ROT – ITEM 20 EXEC (CUR – *)

When rates have stabilized (~60 sec):

G20 DAP CONFIG

Change DAP A to A2

3. TERMINATE PTC ROTATION

G20 DAP CONFIG

Change DAP A to A1

When rates have stabilized (~60 sec):

GNC UNIV PTG

CNCL – ITEM 21 EXEC

When rates have damped:

Reconfig to FLIGHT PLAN DAP

ON-ORBIT +X RCS BURN, MM202

O14:F, ✓Pri RJD LOGIC,DRIVER (sixteen) – ON
O15:F,
O16:F

O14:E, ✓cb DDU (six) – cl
O15:E,
O16:E

GNC 55 GPS STATUS
✓GPS TO NAV – INH (*)

1. AFT RCS/OMS SYSTEM CHECK

If I'CNCT: L(R) OMS to RCS

F7 ✓OMS PRESS He TK L,R > 1500 psia
O3 ✓L,R OXID,FUEL > 234 psia

C3 DAP: FREE

O7 AFT L,R RCS

TK ISOL (six) – CL (tb-CL)
XFEED (four) – OP (tb-OP)

O8 L(R) OMS
He PRESS/VAP ISOL A(B) – OP

L,R OMS

✓He PRESS/VAP ISOL B(A)
(two) – CL

✓TK ISOL A,B (four) – OP (tb-OP)
✓XFEED A (two) – CL (tb-CL)

L(R) OMS XFEED B – OP (tb-OP)

DAP: as reqd

C3 CRT

GNC 23 RCS

OMS PRESS ENA,L(R) OMS –
ITEM 5(6) EXEC

If no I'CNCT:

O3 ✓RCS PRESS L,R OXID,FUEL > 190 psia
✓He > 456 psia

O7 AFT L,R RCS

✓He PRESS A(B) (two) – GPC
(tb-OP)

✓He PRESS B(A) (two) – CL (tb-CL)
✓TK ISOL (six) – OP (tb-OP)

✓XFEED (four) – CL (tb-CL)

Cont next page

2. LOAD TGT DATA AND MNVR TO BURN ATT
 C3 DAP: B1/AUTO/VERN(PRI)

GNC UNIV PTG

CNCL – ITEM 21 EXEC
 GNC, OPS 202 PRO

1: GNC ORBIT MNVR EXEC

2: GNC SYS SUMM

Enter or verify TGT DATA per
 ORB MNVR PAD
 LOAD – ITEM 22 EXEC
 TIMER – ITEM 23 EXEC
 ✓BURN DATA per PAD
 MNVR – ITEM 27 EXEC (*)

3. BURN EXEC
 TIG–3:00 F6(F8) ADI ERR/RATE – MED
 ATT – INRTL
 ✓ADI ATT, then:
 ATT – REF
 REF pb – push

F7(F8)	FLT CNTLR PWR – ON
--------	--------------------

C3 DAP TRANS: NORM/PULSE/PULSE

TIG–0:30 DAP: B1/INRTL/PRI

TIG THC Trim VGOs < 0.2 fps critical burn
 < 2.0 fps noncritical burns

Cont next page

10-11 ORB OPS/ALL/GEN H

4. POST BURN RECONFIG

F7(F8) FLT CNTLR PWR – OFF
CRT GNC, OPS 201 PRO
C3 DAP TRANS: PULSE/PULSE/PULSE
 DAP: as reqd

O14:E, cb DDU (six) – as reqd
O15:E,
O16:E

• If I'CNCT RETURN

C3 DAP: FREE

• GNC 23 RCS

CRT OMS PRESS ENA,OFF – ITEM 7 EXEC
O8 L,R OMS XFEED (four) – CL (tb-CL)
 He PRESS/VAP ISOL A – CL
O7 AFT L,R RCS
 ✓He PRESS A(B) (two) – GPC (tb-OP)
 B(A) (two) – CL (tb-CL)
 XFEED (four) – CL (tb-CL)
 TK ISOL (six) – OP (tb-OP)

C3 DAP: as reqd

5. RECONFIG FOR GROUP B(C)

If Group B(C) Pwrdn:

O14:F, PriRJD LOGIC,DRIVER (sixteen) – OFF
O15:F, RJDA 1A L2/R2 MANF DRIVER – ON
O16:F

ON-ORBIT -X RCS BURN, MM202

O14:F, ✓Pri RJD LOGIC,DRIVER (sixteen) – ON
O15:F,
O16:F

O14:E, ✓cb DDU (six) – cl
O15:E,
O16:E

GNC 55 GPS STATUS
✓GPS TO NAV – INH (*)

1. FWD RCS SYSTEM CHECK

O3 ✓RCS PRESS FWD OXID,FUEL > 190 psia
 ✓He > 456 psia
O8 ✓FWD RCS He PRESS A(B) – GPC (tb-OP)
 ✓B(A) – CL (tb-CL)

2. MNVR TO BURN ATT AND LOAD TGT DATA

C3 DAP: B1/AUTO/VERN(PRI)

GNC UNIV PTG

Perform Auto Mnvr to Burn Att,
TGT ID – ITEM 8 +2 EXEC
BODY VECTOR – ITEM 14 +5 EXEC

	Posigrade Heads Up	Retrograde Heads Up	Burn Att from MNVR PAD
P – ITEM 15	+276.0	+280.0	_____
Y – ITEM 16	+0.0	+0.0	_____
OM – ITEM 17	+180.0	+0.0	_____

Init TRK – ITEM 19 EXEC (CUR – *)

GNC, OPS 202 PRO

1: GNC ORBIT MNVR EXEC

2: GNC SYS SUMM

Enter or verify TGT DATA per
ORB MNVR PAD

LOAD – ITEM 22 EXEC

TIMER – ITEM 23 EXEC

✓BURN DATA per PAD

Cont next page

NOTE

Ignore computed attitude,
perform burn in current attitude

3. BURN EXEC

TIG-3:00

ADI ERR/RATE – MED
ATT – LVLH
✓ADI ATT

	Posigrade <u>Heads Up</u>	Retrograde <u>Heads Up</u>	Burn Att from <u>MNVR PAD</u>
R	+180.0	+0.0	_____
P	+186.0	+350.0	_____
Y	+0.0	+0.0	_____

FLT CNTLR PWR – ON

DAP TRANS: NORM/PULSE/PULSE

TIG-0:30>

DAP: B1/INRTL/PRI
ADI ATT – REF
REF pb – push

TIG

THC: Trim VGOs < 0.2 fps critical burns,
< 2.0 fps noncritical burns

4. POST BURN RECONFIG

FLT CNTLR PWR – OFF
GNC, OPS 201 PRO
DAP TRANS: PULSE/PULSE/PULSE
DAP: as reqd

O14:E,
O15:E,
O16:E

cb DDU (six) – as reqd

5. RECONFIG FOR GROUP B(C)

If Group B(C) Pwrdn:

O14:F,
O15:F,
O16:F

Pri RJD LOGIC,DRIVER(sixteen) – OFF
RJDA 1A L2/R2 MANF DRIVER – ON

ON-ORBIT MULTI-AXIS RCS BURN, MM202

O14:F, ✓Pri RJD LOGIC,DRIVER (sixteen) – ON
O15:F,
O16:F

O14:E, ✓cb DDU (six) – cl
O15:E,
O16:E

GNC 55 GPS STATUS
✓GPS TO NAV – INH (*)

1. AFT RCS/OMS SYSTEM CHECK

If I'CNCT: L(R) OMS to RCS

F7 ✓OMS PRESS He TK L,R > 1500 psia
O3 ✓L,R OXID,FUEL > 234 psia

C3 DAP: FREE

O7 AFT L,R RCS

TK ISOL (six) – CL (tb-CL)
XFEED (four) – OP (tb-OP)

O8 L(R) OMS

He PRESS/VAP ISOL A(B) – OP

L,R OMS

✓He PRESS/VAP ISOL B(A)
(two) – CL

✓TK ISOL A,B (four) – OP (tb-OP)

✓XFEED A (two) – CL (tb-CL)

L(R) OMS XFEED B – OP (tb-OP)

DAP: as reqd

C3 CRT

GNC 23 RCS

OMS PRESS ENA,L(R) OMS –

ITEM 5(6) EXEC

If no I'CNCT:

O3 ✓RCS PRESS L,R OXID,FUEL > 190 psia
✓He > 456 psia

O7 AFT L,R RCS

✓He PRESS A(B) (two) – GPC
(tb-OP)

✓He PRESS B(A) (two) – CL (tb-CL)

✓TK ISOL (six) – OP (tb-OP)

✓XFEED (four) – CL (tb-CL)

Cont next page

10-15 ORB OPS/ALL/GEN H

- O3 2. FWD RCS SYSTEM CHECK
 ✓RCS PRESS FWD OXID,FUEL > 190 psia
 ✓He > 456 psia

O8 ✓FWD RCS He PRESS A(B) – GPC (tb-OP)
 ✓B(A) – CL (tb-CL)

C3 3. EXECUTE MULTI-AXIS BURN
 DAP: B1/AUTO/VERN(PRI)
 GNC, OPS 202 PRO

1: GNC ORBIT MNVR EXEC
2: GNC SYS SUMM

 Enter or verify TGT DATA per
 ORB MNVR PAD
 LOAD – ITEM 22 EXEC
 TIMER – ITEM 23 EXEC
 ✓BURN DATA per PAD

NOTE

Ignore computed attitude,
perform burn in current attitude

TIG-3:00 FLT CNTLR PWR – ON
 DAP TRANS: as reqd

TIG-0:30 If Inertial hold burn:
 DAP: B1/INRTL/PRI
If LVLH track burn:
 DAP: B1/LVLH/PRI

TIG If VGO Z neg:
 | Z,X,Y THC sequence
 If VGO Z not neg:
 X,Y,Z THC sequence

THC: Trim VGOs < 0.2 fps critical burns,
< 2.0 fps noncritical burns

Cont next page

10–16 ORB OPS/ALL/GEN H

4. **POST BURN RECONFIG**
FLT CNTLR PWR – OFF
GNC, OPS 201 PRO
DAP: VERN
DAP: A/AUTO

O14:E, cb DDU (six) – as reqd
O15:E,
O16:E

C3 **If I'CNCT RETURN**
 DAP: FREE

CRT GNC 23 RCS
O8 OMS PRESS ENA,OFF – ITEM 7 EXEC
 L,R OMS XFEED (four) – CL (tb-CL)
 He PRESS/VAP ISOL A – CL

O7 AFT L,R RCS
 ✓He PRESS A(B) (two) – GPC (tb-OP)
 ✓B(A) (two) – CL (tb-CL)
 XFEED (four) – CL (tb-CL)
 TK ISOL (six) – OP (tb-OP)

C3 DAP: as reqd

5. **RECONFIG FOR GROUP B(C)**

If Group B(C) Pwrdn:

O14:F, Pri RJD LOGIC,DRIVER(sixteen) – OFF
O15:F, RJDA 1A L2/R2 MANF DRIVER – ON
O16:F

LOSS OF VERNIERS

NOTE

DAPs called out in this procedure should only be used if flight-specific loss of VERN DAPs not specified in flight-specific checklists (Deploy, RNDZ, PDRS, EVA). Use Tail-only for crew sleep; Nose and Tail for all other times

1. CONFIG DAP

✓DAP: FREE

If Tail-only control desired:

| Change DAP A,B to A6,B2

If Nose and Tail control desired:

Change DAP A,B to A5,B3

2. ESTABLISH CONTROL

O14:F,
O15:F,
O16:F
O16:F

✓Pri RJD LOGIC,DRIVER (sixteen) – ON

✓RJD L5/F5/R5 DRIVER – OFF

DAP: A/FREE/ALT
A/AUTO/ALT

RECOVERY OF VERNIERS

DAP: FREE

- O16:F
1. CONFIG DAP
Reconfig to FLIGHT PLAN DAP
 2. CONFIG FOR VERNIER (PRIMARY) CONTROL
RJD L5/F5/R5 DRIVER – ON
Wait 5 sec
DAP: A/AUTO/VERN(PRI)

RCS REGULATOR RECONFIG

O7/O8 He PRESS A (three) – OP (tb–OP)
 B (three) – OP (tb–OP)
 A (three) – CL (tb–CL)
 B (three) – GPC (tb–OP)

10–20 ORB OPS/ALL/GEN H

10-21 ORB OPS/ALL/GEN H

OMS BOTH	1	<table border="1"><tr><td></td></tr></table>										
L	2	<table border="1"><tr><td></td></tr></table>										
R	3	<table border="1"><tr><td></td></tr></table>										
RCS SEL	4	<table border="1"><tr><td></td></tr></table>										
TV ROLL	5	<table border="1"><tr><td></td><td></td><td></td></tr></table>										
TRIM LOAD		+X -X MULTI-AXIS										
P	6	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
LY	7	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
RY	8	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
WT	9	<table border="1"><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr></table>										
TIG	10	<table border="1"><tr><td></td><td></td><td>/</td><td></td><td>:</td><td></td><td>:</td><td></td><td></td><td></td></tr></table>			/		:		:			
		/		:		:						
TGT PEG 7												
ΔVX	19	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												
ΔVY	20	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												
ΔVZ	21	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												

ORBITAL MANEUVER PAD FOR _____

BURN ATT					
R	24	<table border="1"><tr><td></td><td></td></tr></table>			
P	25	<table border="1"><tr><td></td><td></td><td></td></tr></table>			
Y	26	<table border="1"><tr><td></td><td></td><td></td></tr></table>			

ΔVTOT	<table border="1"><tr><td></td><td></td><td></td></tr></table>						
TGO	<table border="1"><tr><td>:</td><td></td><td></td></tr></table>	:					
:							
VGO X	<table border="1"><tr><td>()</td><td></td><td></td><td></td></tr></table>	()					
()							
VGO Y	<table border="1"><tr><td>()</td><td></td><td></td><td></td></tr></table>	()					
()							
VGO Z	<table border="1"><tr><td>()</td><td></td><td></td><td></td></tr></table>	()					
()							
HA							
HP							
TGT	<table border="1"><tr><td></td><td></td><td></td><td>()</td><td></td><td></td></tr></table>				()		
			()				

NOTES

OMS GMBL CK:

	PRE	POST-BURN		
L PRI	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	
L SEC	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	
R PRI	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	
R SEC	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	

RCS I'CNCT:

<table border="1"><tr><td></td></tr></table>		L OMS	RCS
<table border="1"><tr><td></td></tr></table>		R OMS	RCS
<table border="1"><tr><td></td></tr></table>		NONE	

DOWN MODE OPTIONS:

<table border="1"><tr><td></td></tr></table>		2 OMS	1 OMS	RCS
<table border="1"><tr><td></td></tr></table>		2 OMS	1 OMS	
<table border="1"><tr><td></td></tr></table>		1 OMS	RCS	
<table border="1"><tr><td></td></tr></table>		NONE		

OMS HE REG TEST:
L,R OMS HE P/VAP ISOL

	GPC	OP	CL			
A	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	
B	<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>		<table border="1"><tr><td></td></tr></table>	

-X RCS BURNS:

	BURN ATT	LVLH ATT			
P	15	<table border="1"><tr><td></td><td></td></tr></table>			
Y	16	<table border="1"><tr><td></td><td></td><td></td></tr></table>			
OM	17	<table border="1"><tr><td></td><td></td><td></td></tr></table>			

10-22 ORB OPS/ALL/GEN H

OMS BOTH	1	<table border="1"><tr><td></td></tr></table>										
L	2	<table border="1"><tr><td></td></tr></table>										
R	3	<table border="1"><tr><td></td></tr></table>										
RCS SEL	4	<table border="1"><tr><td></td></tr></table>										
TV ROLL	5	<table border="1"><tr><td></td><td></td><td></td></tr></table>										
TRIM LOAD		+X -X MULTI-AXIS										
P	6	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
LY	7	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
RY	8	<table border="1"><tr><td>()</td><td></td><td></td></tr></table>	()									
()												
WT	9	<table border="1"><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr></table>										
TIG	10	<table border="1"><tr><td></td><td></td><td>/</td><td></td><td>:</td><td></td><td>:</td><td></td><td></td><td></td></tr></table>			/		:		:			
		/		:		:						
TGT PEG 7												
ΔVX	19	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												
ΔVY	20	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												
ΔVZ	21	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td><td></td></tr></table>	()									
()												

ORBITAL MANEUVER PAD FOR _____

BURN ATT	ΔVTOT	<table border="1"><tr><td></td><td></td><td></td><td></td></tr></table>							
R 24	TGO	<table border="1"><tr><td></td><td></td><td>:</td></tr></table>			:				
		:							
P 25	VGO X	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td></tr></table>	()						
()									
Y 26	VGO Y	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td></tr></table>	()						
()									
	VGO Z	<table border="1"><tr><td>()</td><td></td><td></td><td></td><td></td></tr></table>	()						
()									
	HA								
	HP								
	TGT	<table border="1"><tr><td></td><td></td><td></td><td>()</td><td></td><td></td><td></td></tr></table>				()			
			()						

NOTES

OMS GMBL CK:	RCS I'CNCT:	DOWN MODE OPTIONS:			
L PRI	PRE	<table border="1"><tr><td></td></tr></table>			
L SEC	POST-BURN	<table border="1"><tr><td></td></tr></table>			
R PRI		<table border="1"><tr><td>L OMS</td><td>RCS</td></tr></table>	L OMS	RCS	
L OMS	RCS				
R SEC		<table border="1"><tr><td>R OMS</td><td>RCS</td></tr></table>	R OMS	RCS	
R OMS	RCS				
		<table border="1"><tr><td>NONE</td></tr></table>	NONE		
NONE					
OMS HE REG TEST: L,R OMS HE P/VAP ISOL	-X RCS BURNS:				
A	BURN ATT	<table border="1"><tr><td></td></tr></table>			
B	LVLH ATT	<table border="1"><tr><td></td></tr></table>			
GPC OP CL	P 15	<table border="1"><tr><td></td><td></td><td></td></tr></table>			
	Y 16	<table border="1"><tr><td></td><td></td><td></td></tr></table>			
	OM 17	<table border="1"><tr><td></td><td></td><td></td></tr></table>			
		<table border="1"><tr><td>R</td><td></td></tr></table>	R		
R					
		<table border="1"><tr><td>P</td><td></td></tr></table>	P		
P					
		<table border="1"><tr><td>Y</td><td></td></tr></table>	Y		
Y					

SEP MANEUVER

SEP MANEUVER 11-2

SEP
MNVR

11-1 ORB OPS/ALL/GEN H

**SEP
MNVR**

SEP MANEUVER

- A6U 1. SET UP AFT STATION
 ✓SENSE -Z
 DAP: A1/INRTL/PRI
 DAP TRANS: as reqd
 GNC 25 RM ORBIT
 SW RM INH – ITEM 16 EXEC (*)
 FLT CNTLR PWR – ON
 SW RM INH – ITEM 16 EXEC (no *)
2. OBTAIN VISUAL CONTACT THRU OVHD WINDOW
 DAP ROT: as reqd
 RHC: as reqd

 When adequate visual contact obtained,
 DAP ROT: DISC/DISC/DISC
3. NULL CLOSING RATE
 THC: +Z (out)
 As reqd to null closing rate
- A1U 4. PERFORM RR ACQ (if desired)
 KU MODE – RDR PASSIVE
 RADAR OUTPUT – LO
 sel – AUTO TRK
 CNTL – PNL

 Slew antenna to target

 KU SEARCH – SEARCH (tb-gray)

 If no lock-on within 1 min,
 repeat SEARCH as convenient

Cont next page

A6U

5. OBTAI~1 FPS OPENING RATE
DAP TRANS: NORM/NORM/NORM

- * If Norm Z sep desired: *
- * DAP: no LO Z *
- * THC: +Z (out) for 3 sec *
- * If LO Z sep desired (MCC call): *
- * DAP: LO Z *
- * THC: +Z (out) for 25 sec *

CRT

6. PERFORM OUT-OF-PLANE MANEUVER

GNC UNIV PTG

CNCL – ITEM 21 EXEC

GNC, OPS 202 PRO

GNC ORBIT MNVR EXEC

RCS SEL – ITEM 4 EXEC (*)

- * If time critical, *
- * Set TIG to current time + 2.00 *
- * If not time critical, *
- * Set TIG to current time +22.00 *

TGT PEG 7 ΔV_x – ITEM 19 +0 EXEC

ΔV_y – ITEM 20 +2 EXEC

ΔV_z – ITEM 21 +0 EXEC

LOAD – ITEM 22 EXEC

TIMER – ITEM 23 EXEC

\checkmark VGO Z \geq 0; if VGO Z < 0

- * TGT PEG 7 ΔV_y – ITEM 20 -2 EXEC *
- * LOAD – ITEM 22 EXEC *
- * TIMER – ITEM 23 EXEC *
- * \checkmark VGO Z \geq 0 *

Do NOT MNVR to BURN ATT

A6U

\checkmark DAP: no LO Z
At TIG, deflect THC to null VGOs

Cont next page

7. PERFORM FINAL SEP
[GNC ORBIT MNVR EXEC]
CRT ✓RCS SEL – ITEM 4 (*)

If ΔVY (block 6) +2:
| TV ROLL – ITEM 5 +2 7 0 EXEC
If ΔVY (block 6) -2:
| TV ROLL – ITEM 5 +0 9 0 EXEC

Set TIG to TIG from step 6 +15:00
TGT PEG 7 ΔVx – ITEM 19 +3 EXEC
 ΔVy – ITEM 20 +0 EXEC
 ΔVz – ITEM 21 +0 EXEC

LOAD – ITEM 22 EXEC
TIMER – ITEM 23 EXEC
DAP: B1/AUTO/PRI

At TIG–8:00, MNVR – ITEM 27 EXEC (*)

A6U At TIG, deflect THC to null VGOs
FLT CNTLR PWR – OFF

8. MNVR TO MINIMUM DRAG ATTITUDE
(-ZLV/-XVV)
A6U DAP: A/AUTO/VERN

CRT GNC, OPS 201 PRO
[GNC UNIV PTG]
✓TGT ID: 2
BODY VECT: 3
OM: 0
START TRK – ITEM 19 EXEC (CUR – *)

PGSC

PGSC ACT	12-3
OCA, PROSHARE, AND PCMMU EXPANSION	
CARDS	12-8
PGSC HARD DISK LATE UPDATE	12-9
OCA SETUP	12-11
CABLE DIAGRAM	12-16
DLINK VIA GROUND CMD	12-17
DIRECTORY STRUCTURE	12-18
FILENAMES	12-19
KU-BAND (KFX) MANUAL DLINK	12-20
S-BAND MODEM (MFX) ACTIVATION	12-21
VIDEO CONFERENCING	12-23
PROSHARE CHALKBOARD	12-25
APPLICATION SHARING	12-26
REMOTE PAN/TILT/ZOOM CONTROL OF GROUND	
CAMERA (KCA CAMERA CNTL)	12-27
OCA LOOPBACK TEST	12-28
CABLE DIAGRAM – LOOPBACK	12-29
PGSC NETWORK	12-30
NETWORK SETUP DIAGRAM	12-35
PCMCIA CARD REMOVAL	12-36
WINDECOM OPS	12-37
SETTING TIMES AND STATE VECTOR	12-42
WORLD MAP INITIALIZATION	12-44
COLOR PRINTER UNSTOW AND ASSEMBLE ..	12-46
WARMUP AND SELF-TEST ..	12-49
STOW	12-50
CHECK COLOR PRINTER SETTINGS	12-51
COLOR PRINTER PAPER JAM	12-51
INK CARTRIDGE CHANGEOUT	12-52
CLEANING PRINTER HEADS	12-54
PRINTER HEAD ALIGNMENT	12-55
EXECUTE PACKAGE PRINTING	12-56
PILOT WITH RHC	12-57
RHC SETUP DIAGRAM	12-61
WITHOUT RHC	12-62
UPDATING SpOC APPLICATIONS USING	
OCA DATA DISKETTE (ODD)	12-64
PCANYWHERE ACT/DEACT	12-65
PGSC HARD DISK SWAP	12-66
SWAP ON EXPANSION UNIT	12-67
DEACT	12-68

PGSC

WINDOWS KEYBOARD REF	12-69
WORLD MAP KEYBOARD REF	12-73
GRAFTRAK KEYBOARD REF	12-74
STARS KEYBOARD REF	12-75
POC STATE VECTOR PADS	12-77
RELOAD STS PGSC	12-78

FIGURES

12-1 Side view of printer and trays, ready for assembly	12-47
12-2 Printer (top view/back view), PGSC (parallel port)	12-48

PGSC

PGSC ACT

- A. **PGSC WITH EXPANSION UNIT**
 1. If activating OCA Router PGSC, go to OCA SETUP, 12-11
 2. Unstow:
PGSC with Expansion Unit
AC PWR cable

If PGSC to be networked:
PCMCIA Ethernet card, adapter assemblies
Ethernet cables
Network T-connectors
Network terminators (two)
Network barrel connectors (if reqd)
 - If WinDecom to be run:
PCMMU data cable (if not prerouted)
RS-232 Y data cable (if reqd)
RS-422 Y data cable (if reqd)
RS-422 PCMCIA cards, adapter boxes (if reqd)
 3. See UTILITY OUTLET PLUG-IN PLAN
ORBIT CONFIGURATION (REF DATA FS,
UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use

F1
(MO13Q,
A15,
MO52J,
ML85E)

4. ✓AC UTIL PWR – OFF

NOTE

If needed, reference PGSC pictorials on 12-7 and 12-8 to identify PGSC ports, connectors

5. Connect PGSC AC PWR cable from AC Util Pwr outlet to Expansion Unit Pwr port

Cont next page

6. ✓ PGSC Expansion Unit fan/louver not obstructed
 7. If multiple PGSCs to be powered from same AC Util Pwr outlet, repeat steps 2 thru 6 for each PGSC to be powered from same outlet
 8. AC UTIL PWR – ON
 9. If reqd, perform PGSC HARD DISK LATE UPDATE, 12–9, then:
 10. ✓ Windows shut down
- PGSC 11. Repeat steps 1 thru 10 for each PGSC to be networked
- PGSC 12. If PGSC to be networked, go to PGSC NETWORK – A. Initial Setup, 12–30 >>
- PGSC 13. PGSC pwr – on
14. Sel appropriate Expansion Unit config at Startup Menu, then press [ENTER]
15. Go to appropriate application setup procedure (e.g., WINDECOM OPS, 12–37, and/or WORLD MAP INITIALIZATION, 12–44), as needed >>
- B. PGSC WITHOUT EXPANSION UNIT
1. Unstow:
 - PGSC
 - DC PWR SPLY
 - DC PWR cable
 - DC PWR SPLY cable
- If PGSC to be networked:
- PCMCIA Ethernet card, adapter assemblies
 - Ethernet cables
 - Network T-connectors
 - Network terminators (two)
 - Network barrel connectors (if reqd)

Cont next page

- PWR SPLY
2. ✓ DC PWR SPLY PWR sw1 – OFF
 3. See UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate DC Util Pwr outlet/sw to use

- F1
(MO13Q,
A11,A15,
MO30F,
MO52J,
ML85E,
O19,L12)
4. ✓ DC UTIL PWR – OFF

NOTE


If needed, reference PGSC pictorials on 12–7 and 12–8 to identify PGSC ports, connectors

5. Connect PGSC DC PWR cable from DC Util Pwr outlet to DC Pwr Sply outlet (J1)
Connect DC PWR SPLY cable from DC Pwr Sply outlet (J2) to PGSC pwr port
6. ✓ PGSC fan/louver (at center rear of PGSC) not obstructed
7. If multiple PGSCs to be powered from same DC Util Pwr outlet, repeat steps 2 thru 6 for each PGSC to be powered from same outlet
8. DC UTIL PWR – ON
9. DC PWR SPLY PWR sw1 – ON (lt on)
10. If reqd, perform PGSC HARD DISK LATE UPDATE, 12–9, then:
11. ✓ Windows shut down
12. Repeat steps 1 thru 11 for each PGSC to be networked


Cont next page

12–5 ORB OPS/ALL/GEN H

- 
- 13. If PGSC to be networked, perform PGSC NETWORK – A. Initial Setup, 12-30
 - PGSC 14. PGSC pwr – on
 - 15. Go to appropriate application setup procedure (e.g., WORLD MAP INITIALIZATION, 12-44), as needed




PGSC without Expansion Unit




PGSC with Expansion Unit


OCA, PROSHARE, AND PCMMU EXPANSION CARDS



OCA EXPANSION CARD



PROSHARE EXPANSION CARD



PCMMU EXPANSION CARD

480351207 PNL 3

PGSC HARD DISK LATE UPDATE

- If late update reqd on STS PGSC portion of OCA Router PGSC hard disk:
- PGSC
- If running Windows NT (OCA Router s/w):
 - 1. Press [CNTL]/[ALT]/[DEL]
Sel 'Shut Down' at 'Logon Information' dialog box
Sel 'OK'
When prompted:
 PGSC pwr – off
 - If running Windows 98:
 - 2. Go to step 5
 - 3. PGSC pwr – on
Within 15 sec, click on 'STS PGSC' at 'Boot Magic' boot-up menu
Sel 'Docked (OCA Card)' config at Startup Menu, then press [ENTER]
 - 4. ✓PGSC pwr – on

CAUTION
If PCMCIA card is inserted in PCMCIA card slot for extended period of time, PCMCIA card may become hot

5. Insert PCMCIA card containing late PGSC updates

Cont next page

6. ✓‘PCMCIA card’ icon appears in system tray

- * If ‘PCMCIA card’ icon does not appear in *
- * system tray: *
- * ✓PCMCIA card properly inserted with *
- * correct side up (bottom release button *
- * extends outward and can be folded in) *
- |
- * If no joy, eject PCMCIA card and *
- * reinsert *
- * If still no joy: *
- * Shut down Windows *
- * Eject PCMCIA card *
- * Power up in Windows 98 *
- * Repeat steps 5 and 6 *

7. Double-click ‘Shuttle Apps’>‘Late PGSC Update’

8. If referred to this procedure from OCA SETUP or
PGSC ACT, follow instructions on PGSC monitor
but shut down Windows (versus restart) >>

9. Follow instructions on PGSC monitor

OCA SETUP

1. Unstow:
OCA Router PGSC with Expansion Unit
ProShare PGSC with Expansion Unit
AC Pwr cables (if not prerouted)
OCA I/F cable (if not prerouted)
PGSC Modem cable (if MFX ops reqd)
PCMCIA Ethernet card, adapter assemblies
Ethernet cables
Network T-connectors
Network terminators (2)
Network barrel connectors (if reqd)

NOTE

At a minimum, network equipment should be configured for OCA Router and ProShare PGSCs.

Network must always be properly terminated when connected to powered PGSCs

If adding OCA Router PGSC to existing network, perform the following for each PGSC on network:

PGSC

2. If time permits for PGSC shutdown and bootup process:
Shut down Windows
Go to step 6
If time not available, proceed with step 6
3. Click on 'PCMCIA card' icon in system tray
Click on popup window displaying 'Stop NAME_OF_NETWORK_CARD', wait for prompt
4. Press [ENTER] at network card dialog box displaying 'You may safely remove this device'
5. Remove PCMCIA Ethernet card from PCMCIA card slot
6. Repeat steps 2 thru 5 for each PGSC on network

Cont next page

OCA ROUTER PGSC SETUP

7. Config network equipment for OCA Router PGSC, ProShare PGSC, and Color Printer (if reqd) per:
 NETWORK SETUP DIAGRAM, 12–35
 PGSC Usage Chart (if available) or UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR)
8. Config switches for Ku-Band file xfer:
 ✓MCC for:
 Ku-band rate _____
 Pnl location of:
 PDIP Pwr cb
 KuBand Rate sw
 cb PDIP PWR 2 KU BAND RLY – cl
 Ku BAND RATE – LO(HI)

9. Config PGSC Modem cable (if MFX ops reqd) and OCA I/F cable per OCA CABLE DIAGRAM, 12–16
10. See UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use
11. ✓AC UTIL PWR – OFF
12. Connect AC PWR cable between AC Util Pwr outlet and OCA Router PGSC per:
 PGSC Usage Chart (if available) or UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR)

NOTE

Following two steps will prevent unnecessary pwrndn of AC Util Pwr outlet

13. If OCA Router and ProShare PGSCs powered from same AC Util Pwr outlet, connect AC PWR cable to ProShare PGSC

Cont next page

14. If reqd, perform COLOR PRINTER UNSTOW
AND ASSEMBLE, 12-46, then:
15. AC UTIL PWR – ON

OCA

Router

PGSC

16. If reqd, perform PGSC HARD DISK LATE
UPDATE, 12-9, then:
17. ✓Windows shut down

18. Insert PCMCIA Ethernet card into PCMCIA card
slot

NOTE

After powering on OCA Router PGSC,
allow approx 2 min for completion of
bootup process

19. PGSC pwr – on

20. Press [CTRL]/[ALT]/[DEL] to logon to Windows NT
✓Password field blank on 'Logon Information'
dialog box
Sel 'OK'
Wait approx 10 sec for logon sequence to
complete

21. Verify data rate:
Double-click 'OCA Control Panel Applet' icon
on desktop

* If error msg displayed: *
* Acknowledge msg *
* PGSC pwr – off *
* Eject,reinsert PCMCIA card *
* Repeat steps 19 thru 21 *
* If no joy: *
* PGSC pwr – off *
* Replace PCMCIA card,adapter *
* Repeat steps 19 thru 21 *

Cont next page

12-13 ORB OPS/ALL/GEN H

- ✓‘Local OCA Card–1’ display on desktop
- In ‘OCA–FLIGHT VC–2D’ section of ‘Local OCA Card–1’ display:
 - ✓SEND – 2(4)M
 - * If send rate out of config: *
 - * Sel ‘Control’>‘Transmit Rate’>‘2(4) *
 - * Mbps OCA internal clock (Shuttle *
 - * Ku Channel 2(3))’ *

PROSHARE PGSC SETUP

22. If ProShare PGSC already connected to AC PWR cable per step 13 of OCA SETUP, go to step 27
23. See UTILITY OUTLET PLUG–IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use
24. ✓AC UTIL PWR – OFF
25. Connect AC PWR cable between AC Util Pwr outlet and ProShare PGSC per:
PGSC Usage Chart (if available) or UTILITY OUTLET PLUG–IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR)
26. AC UTIL PWR – ON

ProShare

- PGSC
27. If reqd, perform PGSC HARD DISK LATE UPDATE, 12–9, then:
 28. ✓Windows shut down
 29. Insert PCMCIA Ethernet card into PCMCIA card slot
 30. If PGSC powered off:
PGSC pwr – on
If reqd, sel appropriate Expansion Unit config at Startup Menu, then press [ENTER]


Cont next page

31. Press [ENTER] for any of the following:
 - 'Enter Network Password' dialog box (if displayed)
 - 'Restoring Network Connections' dialog boxes
 - 'Windows Networking' dialog boxes (if displayed)
32. Repeat steps 29 thru 31 for each PGSC to be added to network
33. If reqd, perform COLOR PRINTER WARMUP AND SELF-TEST, 12-49, then:
34. Verify network connectivity using PingMaster:
 - Double-click 'Shuttle Apps'>'Network Config'>'PingMaster'
 - ✓ 'Status' column of 'Network Primary' and 'Network Nodes' sections for networked PGSCs
 - If status is 'Good Response' for networked PGSCs, press [CTRL]/[x] to exit PingMaster (if desired)
 - * If status is not 'Good Response', verify *
 - * proper network cable and card *
 - * connections, then recheck status in *
 - * PingMaster *

ProShare

- PGSC
35. Double-click 'Shuttle Apps'>'KFX'
Arrange 'KFX' window as desired
 36. Retrieve OCA Data Diskette from FDF
Insert diskette in floppy drive of ProShare PGSC

12-16 ORB OPS/ALL/GEN H



480351205, PNL 1

OCA DOWNLINK VIA GROUND CMD

1. MOVE FILE(S) TO DOWNLINK DIRECTORIES

NOTE

Files downlinked via ground cmd
unless MCC instructs otherwise

See OCA DIRECTORY STRUCTURE, 12–18

See OCA FILENAMES, 12–19, for file naming
convention

PGSC Copy(Move) desired files to
 c:\oca-down\dcs(payloads)
 Notify MCC when complete

2. MONITOR KFX DOWNLINK (if desired)

When link established:

From 'KFX' window:

- ✓ REMOTE KFX – green
- ✓ Uplink arrow ('↑' next to send rate) – green
- ✓ Dnlink arrow ('↓' next to send rate) – green

✓ KFX application activated

✓ File Transfer Status dialog (displayed during file
xfer)

3. MONITOR MFX DOWNLINK (if desired)

If MFX application not activated:

Perform OCA S-BAND MODEM (MFX)
ACTIVATION, 12–21, then:

If minimized:

- ✓ Icon Title displaying File Name, Send/Receive
Status

NOTE

For detailed file xfer information, following
steps must be completed prior to file xfer
initiation

Sel 'File' on menu bar of MFX application

✓ Show Status During File Xfers – (✓)

✓ Z MODEM(1K-X MODEM) display appears

✓ Displaying File Name, Send/Receive Status

OCA DIRECTORY STRUCTURE

```
C:\  
  |__ OCA-DOWN  
  |    |__ DCS  
  |    |__ PAYLOADS *  
  |__ OCA-UP  
  |    |__ MAIL  
  |    |__ MESSAGES  
  |    |__ OTHER  
  |    |__ PAYLOADS  
  |    |__ SPOC **  
  |    |__ WEB  
  |__ OCA--SW (ground use only)
```

* PAYLOADS Directory: Directory may contain flight-specific subdirectory

** SpOC Directory: Directory will contain latest SpOC updates. To create SpOC update disk, copy all files in c:\oca-up\spoc\uplink to a:\uplink

OCA FILENAMES

<u>UPLINKED FILES</u>	<u>LOCATION</u>
SpOC updates:	a:\uplink\ (c:\oca-up\spoc\)
Ops notes:	c:\oca-up\other\opsxxxxx.doc
Graphics files:	c:\oca-up\other\othrxxxx.bmp
Uplinked personal mail*:	c:\oca-up\mail\
Uplinked Payload files:	c:\oca-up\payloads\
<u>DLINKED FILES</u>	<u>LOCATION</u>
Personal mail, other*:	c:\oca-down\mail\
Payload files:	c:\oca-down\payloads\
<u>STD FILENAMES</u>	
filename.doc	WORD documents only
filename.txt	ASCII text file (NOTEPAD or WORD)
filename.bmp	Graphics file (Paint)
filename.pcx	Graphics file (Paint)
famcdr01.doc*	family mail: CDR → family on FD01
cdrfam02.doc*	family mail: family → CDR on FD02
fltcdr02.doc*	message: CDR → FLT Director on FD02

*Outlook OST files are nominally used for personal mail. If Outlook is not working properly, the above file locations and nomenclature will be used

NOTE

Do not downlink medical data. Downlink directories will be cleared of all files at end of each OCA session.
To retain archive copy of downlink msgs, save in personal directory

OCA KU-BAND (KFX) MANUAL DOWNLINK

- PGSC 1. CONFIGURE S/W FOR FILE DOWNLINK
If reqd, enlarge 'KFX' window

From 'KFX' window:
✓ REMOTE KFX – green
✓ Uplink arrow ('↑' next to send rate) – green
✓ Dnlink arrow ('↓' next to send rate) – green
2. SELECT FILE(S) TO DOWNLINK
Use WINDOWS EXPLORER to sel files/directories to transfer
Drag files over KFX window
Rel mouse button
✓ 'KFX File Transfer Preview' display appears with selected file(s) listed
3. ADD ADDITIONAL FILE FOR DOWNLINK (if reqd)
✓ 'KFX File Transfer Preview' display active
Sel 'add to list' button (button with documents, '+' symbols)
✓ 'Select Files for Transfer' display appears
Sel desired file from file listbox
Sel 'Select' button
Repeat for each additional file as reqd
Sel 'Done' button
4. REMOVE FILE FROM DOWNLINK (if reqd)
✓ 'KFX File Transfer Preview' display active
Sel desired file(s) in listbox
Sel 'delete' button (button with 'X')
5. START FILE DOWNLINK
- NOTE
- User may halt transfer while in progress by sel 'Abort' button
- ✓ 'KFX File Transfer Preview' display active
Sel 'downlink' button (button with '↓')
✓ 'File Transfer Status' display appears
✓ Displaying xfer status
- * If error displayed, repeat step 5 *

OCA S-BAND MODEM (MFX) ACTIVATION

1. ESTABLISH LINK

On MCC GO:

A15	PS COMM CCU PWR	– OFF
L9	PS AUD PWR	– AUD
	A/G 1	– OFF
	A/G 2	– T/R
	A/A	– OFF
	ICOM (two)	– OFF
	VOL A/G 2 tw	– 0
	XMIT/ICOM MODE	– PTT/PTT

CAUTION

Loss of A/A (UHF) will occur if OCA PGSC Modem cable connected to COMM OUTLET and A/A in T/R on ATU

O9	R AUD A/G 2	– OFF
O5	L AUD A/G 2	– OFF
R10	MS AUD A/G 2	– OFF
A13(OV102)	OS AUD A/G 2	– OFF
MO42F	MIDDECK SPKR AUD A/G 2	– OFF

A15 ✓PGSC Modem cable connected to PS COMM outlet

2. ACTIVATE FILE XFER S/W

OCA If PGSC not running Windows 98:
Router Restart (or pwr on) PGSC
PGSC Within 15 sec, click on 'STS PGSC' at 'Boot Magic' bootup menu
 Sel 'Docked (OCA Card)' config at Startup Menu, then press [ENTER]

Double-click 'Shuttle Apps'>'OCA ProShare'> 'MFX'

- ✓'MFX' display appears
- ✓WINDOW – OFFLINE
- Arrange 'MFX' window as reqd

Cont next page

- MFX PGSC
3. VERIFY PRINTER SETTINGS
- Click 'Start'>'Settings'>'Printers'
In "Printers" window, right-click "NETWORK EPSON1" printer
On popup menu:
 Verify "Set as Default" checked
 Verify "Use Printer Offline" NOT checked
Close "Printers" window

VIDEO CONFERENCING

1. Unstow:
Headset
Minicam
ProShare Video/Pwr cable
VLHS to VTS I/F cable
2. ✓OCA SETUP, 12–11, complete
3. Config cables per P/TV04 VIDEO
CONFERENCING (PHOTO/TV FS, SCENES)

ProShare
PGSC
4. Double-click 'Shuttle Apps'>'ProShare Video'

5. ✓Video active in 'Local' window
6. Adjust Thinkpad display tilt angle, camera posn,
iris, focus so oper's face centered in 'Local'
video window
7. ✓Picture quality and position
 - * If picture quality poor:
 - * From 'Local' video window:
 - * Sel 'Adjusts video' button ('slide bar' icon)
 - * Adjust picture quality as reqd
 - * Sel 'Close' button
 - * If 'Save camera control settings?' appears, sel 'Yes' button
 - *
 - * From 'Local' video window:
 - * ✓'Zooms in' button (mag glass) in out position
 - 8. TO RECEIVE CALL
Notify MCC when ready to receive video conference call, wait for MCC to initiate

Cont next page

| | | | |

9. TO INITIATE CALL

Notify MCC when ready to place video conference call, wait for MCC confirmation
Sel 'Dial List' button
Sel 'MCC, PC'
Sel 'Dial' button

NOTE

Title of remote video window changes to designate caller when video conference established

10. CONDUCT VIDEO CONFERENCE

NOTE

Video conference performance may be affected if other applications are active

- ✓ Remote video window active, audio active
Sel 'Split' button on handset
Move remote video window directly beneath camera
Adjust audio volume using slide bar under remote video window
- ✓ Headset/speaker Toggle button configured for headset audio (button not depressed)

11. TERMINATE VIDEO CONFERENCE

NOTE

When video conference completed, either side can terminate call. If MCC has disconnect, 'Hang Up' button will change to 'Dial'

From ProShare Video handset:

- Sel 'Hang Up' button
- Sel System Menu (upper left corner)
- Sel 'Exit' ([ALT]/[SHIFT]/[F4])

PROSHARE CHALKBOARD

1. If not already completed, perform VIDEO CONFERENCING, steps 1 thru 8(9), 12–23, then:
 2. **TO RECEIVE CHALKBOARD SESSION**
Notify MCC when ready to receive chalkboard session, wait for MCC to initiate
- PGSC From ProShare Video handset, sel 'Split' button
If 'Local' video remains on screen, minimize 'Local' video window
3. **TO INITIATE CHALKBOARD SESSION**
Notify MCC when ready to initiate chalkboard session, wait for MCC confirmation
- From ProShare Video handset, sel 'Share Document' button
Sel 'Yes' at 'Do you want to share notebook?' dialog box
Minimize all unused windows
4. **TERMINATING CHALKBOARD SESSION**

NOTE

When chalkboard session completed,
either side can terminate session

From ProShare Personal Conferencing menu bar:
Sel 'Conference'
Sel 'UnShare Notebook' menu

If MCC has terminated session, sel 'OK' in 'The other participant closed the notebook'

From ProShare Personal Conferencing menu bar:
Sel 'File'
Sel 'Exit'

NOTE

Operator will be prompted to save chalkboard session in 'xxxx.mtg' file

APPLICATION SHARING

- PGSC
1. Launch desired application
 2. Perform PROSHARE CHALKBOARD, steps 1 and 2(3), 12–25, then:
 3. From ProShare Personal Conferencing menu bar:
Sel 'Application'
Sel 'Share Application View..'
 4. From 'Share Application View' dialog box:
Sel desired application
Sel 'OK'
 5. Perform application edits with MCC when application is shared

NOTE

Mouse operation, shared between MCC and flight operator, must be coordinated using conference audio

6. **TERMINATING APPLICATION SHARING**
Either side can terminate application sharing by exiting application

REMOTE PAN/TILT/ZOOM CONTROL OF GROUND CAMERA (KCA CAMERA CNTL)

NOTE

PAN/TILT control only available if ground workstation involved in video conference has PAN/TILT and ground PAN/TILT camera running

1. Perform VIDEO CONFERENCING, steps 1 thru 8(9), 12–23, then:

- ProShare2. Double-click 'Shuttle Apps'>'OCA–ProShare'>
PGSC 'ProShare Pan–Tilt'
3. Sel 'Help' in KCA Camera Control menu bar for instructions
 4. When camera control ops complete, close KCA camera control application

OCA LOOPBACK TEST

NOTE

Perform procedure on OCA Router
PGSC running in Windows NT

1. **LOGON TO WINDOWS NT**
OCA Router
PGSC Press [CTRL]/[ALT]/[DEL] to logon to Windows NT
 Sel 'OK' on 'Logon Information' dialog box
 Wait approx 10 sec for logon sequence to complete
 Double-click 'OCA Control Panel Applet' icon on desktop
 ✓'Local OCA Card-1' display on desktop
2. **INITIATE INTERNAL LOOPBACK TEST**
From 'Local OCA Card-1' display:
 Sel 'OCA Self Tests' on menu bar
 Sel 'Internal Loopback'


 ✓'Local OCA Card-1' display:
 Successful Test – Animated signal moving inside PC icon
 Unsuccessful Test – 'Frowny face' displayed inside PC icon
 Inform MCC of results
3. **TERMINATE INTERNAL LOOPBACK TEST**
From 'Local OCA Card-1' display:
 Sel 'OCA Self Tests' on menu bar
 Sel 'Stop Loopback Testing'
4. **INITIATE EXTERNAL LOOPBACK TEST**
Disconnect OCA I/F cable from PDIP panel
Connect PDIP end of OCA I/F cable to loopback port on PGSC end of cable
See OCA CABLE DIAGRAM – LOOPBACK, 12–28, for cable config

From 'Local OCA Card-1' display:
 Sel 'OCA Self Tests' on menu bar
 Sel 'External Loopback #1'

Cont next page

- ✓ 'Local OCA Card-1' display:
 - Successful Test – Animated signal moving outside PC icon
 - Unsuccessful Test – 'Frowny face' displayed inside PC icon
 - Inform MCC of results
5. **TERMINATE EXTERNAL LOOPBACK TEST**
- From 'Local OCA Card-1' display:
- Sel 'OCA Self Tests' on menu bar
 - Sel 'Stop Loopback Testing'

OCA CABLE DIAGRAM – LOOPBACK



PGSC NETWORK

A. INITIAL SETUP

NOTE

Procedure assumes PGSC ACT,
12–3, performed for each PGSC
to be networked

1. If setting up network for OCA Router PGSC,
go to OCA SETUP 12–11

NOTE

Use red color-coded terminators and
T-connectors for PGSC network

2. Unstow:
 - PCMCIA Ethernet card, adapter assemblies
 - Ethernet cables
 - Network T-connectors
 - Network terminators (2)
 - Network barrel connectors (if reqd)
3. Configure network equipment per:
 - NETWORK SETUP DIAGRAM, 12–35
 - PGSC Usage Chart (if available) or
 - UTILITY OUTLET PLUG-IN PLAN
 - ORBIT CONFIGURATION (REF DATA FS, UTIL PWR)

✓ Network properly terminated

NOTE

If another resource (e.g., ESC) requires use of a specific PCMCIA card slot, use PCMCIA card slot which would avoid network card reconfiguration

- | | |
|------|--|
| PGSC | <ol style="list-style-type: none">4. Insert PCMCIA Ethernet card into any PCMCIA card slot of unpowered PGSCs5. PGSC pwr – on |
|------|--|

Cont next page

6. If Expansion Unit attached:
Sel appropriate Expansion Unit config at
Startup Menu, then press [ENTER]

7. If PGSC locks up during bootup or during
network ops:

- * ✓PCMCIA Ethernet cards are properly *
- * inserted into PCMCIA card slots *
- * ✓Adapters are properly mated to *
- * network T-connectors *
- * ✓Network cables and terminators are *
- * properly mated to T-connectors *

8. ✓‘PCMCIA card’ icon appears in system tray

- * If ‘PCMCIA card’ icon does not appear in *
- * system tray: *
- * ✓PCMCIA Ethernet card is properly *
- * inserted with correct side up (bottom *)
- * release button will extend outward *
- * and can be folded in) *
- * If no joy, eject PCMCIA Ethernet card *
- * and reinsert *
- * If still no joy, shut down Windows, *
- * repeat steps 5 thru 8 *

NOTE

Windows will attempt to connect to all
mapped drives

9. Press [ENTER] for any of the following:
Network password prompt (if displayed)
'Restoring Network Connections' dialog
boxes
'Windows Networking' dialog boxes
(if displayed)

10. Repeat steps 4 thru 9 for each PGSC to be
networked

Cont next page

12-31 ORB OPS/ALL/GEN H

11. Verify network connectivity using PingMaster:
Double-click 'Shuttle Apps'>'Network Config'>'PingMaster'
✓ 'Status' column of 'Network Primary' and 'Network Nodes' sections for networked PGSCs
If status is 'Good Response' for networked PGSCs, press [CTRL]/[x] to exit PingMaster (if desired)
 - * If status is not 'Good Response', *
 - * verify proper network cable and *
 - * card connections then recheck *
 - * status in PingMaster *
12. For each networked PGSC, go to appropriate application setup procedure (e.g., WINDECOM OPS, 12-37 and/or WORLD MAP INITIALIZATION, 12-44) as needed >>

B. RECONFIG

NOTE

Procedure assumes PGSC ACT, 12-3, performed for each PGSC to be added to network.

Use red color-coded terminators and T-connectors for PGSC network

- | | |
|------|--|
| PGSC | <ol style="list-style-type: none">1. If reqd, unstow additional network cables, cards, adapters, terminators, T-connectors2. If OCA Router PGSC on network and running Windows NT:
Press [CTRL]/[ALT]/[DEL] to logon to Windows NT
Sel 'Shut Down' at 'Logon Information' dialog box
Sel 'OK' |
|------|--|

Cont next page

When prompted:
PGSC pwr – off

3. If time permits for shutdown and bootup process of non-OCA Router PGSCs on network:
Shut down Windows
Go to step 7
If time not available, proceed with step 4
4. Click on 'PCMCIA card' icon in system tray
Click on popup window displaying 'Stop NAME_OF_NETWORK_CARD', wait for prompt
5. Press [ENTER] at network card dialog box displaying 'You may safely remove this device'
6. Remove PCMCIA Ethernet card from PCMCIA card slot
7. Repeat steps 3 thru 6 for each PGSC on network

NOTE

Network must always be properly terminated when connected to powered PGSCs

8. Reconfigure network cables, cards, adapters, terminators, T-connectors per:
NETWORK SETUP DIAGRAM, 12-35
PGSC Usage Chart (if available) or
UTILITY OUTLET PLUG-IN PLAN
ORBIT CONFIGURATION (REF DATA FS, UTIL PWR)
✓ Network properly terminated
9. Insert PCMCIA Ethernet cards into PCMCIA card slots of all PGSCs to be networked
10. If PGSC powered off:
PGSC pwr – on
If reqd, sel appropriate Expansion Unit config at Startup Menu, then press [ENTER]


Cont next page

12-33 ORB OPS/ALL/GEN H

- | | | |
11. Perform PGSC NETWORK – A. Initial Setup, 12–30, steps 8 thru 12
- PGSC C. TEARDOWN
1. Single-click ‘PCMCIA Card’ icon in system tray
 2. Click on popup window displaying ‘Stop *NAME_OF_NETWORK_CARD*’, wait for prompt
 3. Press [ENTER] at dialog box displaying ‘You may safely remove this device’
 4. Depress release button to eject PCMCIA card from PCMCIA card slot
 5. Remove PCMCIA card
 6. Disconnect network cables from network T-connectors
 7. Disconnect network T-connectors from network adapters
 8. Stow network equipment
- PGSC D. PGSC NAMING
1. ✓MCC for new PGSC name
 2. Double-click ‘Shuttle Apps’>‘Network Config’>‘Rename PGSC’
 3. Sel ‘Yes’ to run ‘Unique Client Config’ program
 4. At ‘Network Client Config’ dialog box, sel appropriate computer name assigned by MCC
 5. Sel ‘Update’ button
 6. Sel ‘OK’ at ‘Verification’ and ‘Update’ dialog boxes
 7. Sel ‘Yes’ to restart PGSC

| | | |

NETWORK SETUP DIAGRAM



ORB OPS/ALL/GEN H

PCMCIA CARD REMOVAL

- PGSC 1. If RS-422 PCMCIA card:
- Shut down Windows
 - ✓ Power off completed
 - Go to step 5
2. Single-click 'PCMCIA Card' icon in system tray
3. Click on popup window displaying 'Stop *NAME_OF_CARD*', wait for prompt
4. Press [ENTER] at dialog box displaying 'You may safely remove this device'

CAUTION
If PCMCIA hard disk drive is inserted in
PCMCIA card slot for extended period
of time, PCMCIA card may be hot

5. Depress release button to eject PCMCIA card from PCMCIA card slot
6. Remove PCMCIA card

WINDECOM OPS

A. ACT

1. Unstow data cables, cards, adapters:
PCMMU data cable (if not prerouted)
RS-232 Y data cable (if reqd)
RS-422 Y data cable (if reqd)
RS-422 PCMCIA cards, adapter boxes
(if reqd)
2. ✓OI PCMMU PWR – 1(2)
If using pnl O5 to receive PCMMU feed,
| verify jumper plug connected to PCMMU
| 1(2) outlet
If using pnl MO30F to receive PCMMU feed,
disconnect jumper plug from PCMMU 1(2)
outlet
3. Connect PCMMU data cable from PCMMU
1(2)outlet to PGSC PCMMU expansion
card port
4. If sending WinDecom data via serial
connection(s):
See UTILITY OUTLET PLUG-IN PLAN
ORBIT CONFIGURATION (REF DATA
FS, UTIL PWR) or PGSC Usage Chart
(if available) for appropriate data
cable/card connections from
WinDecom PGSC to end user PGSC(s)
5. If sending WinDecom data via network:
See UTILITY OUTLET PLUG-IN PLAN
ORBIT CONFIGURATION (REF DATA
FS, UTIL PWR) or PGSC Usage Chart
(if available) for appropriate network
cable connections from WinDecom
PGSC to end user PGSC(s)
If not already done so, perform PGSC
NETWORK, 12-30

Cont next page

6. Double-click 'Shuttle Apps'>'Windecom'> appropriate WinDecom application
After approx 30 sec, verify 'Tlm Pkt–Net' and 'Tlm Pkt–Com' displays appear
- End user PGSC 7. ✓S/W application(s) on end user PGSC(s) receiving WinDecom data
- * If S/W application(s) on end user *
 - * PGSC(s) not receiving WinDecom *
 - * data, go to WINDECOM OPS – *
 - * C. Troubleshooting, 12–38 * > >
- Win Decom PGSC B. DEACT
1. Double-click 'Shuttle Apps'>'Windecom'> 'WinDecom Shutdown'
Sel 'OK' to shut down telemetry system >>
- C. TROUBLESHOOTING
- NOTE
The following individual steps may fix the problem. Exit procedure as needed
- PCSC If dynamic data not displayed on WinDecom 'Tlm Pkt – Net' and/or 'Tlm Pkt – Com' displays:
1. ✓PGSC PCMMU card receiving data from orbiter PCMMU stream:
From WinDecom 'Tlm Pkt–Net' and/or 'Tlm Pkt–Com' displays, sel 'Packets' tab and verify 'send at' GMT times are dynamic

If no joy, verify PCMMU data cable properly connected at orbiter PCMMU port and PGSC Expansion Unit PCMMU port, repeat WINDECOM OPS – C. TROUBLESHOOTING, 12–38, step 1
- ✓End user PGSC(s) receiving WinDecom data

Cont next page

12–38 ORB OPS/ALL/GEN H

2. Repeat WINDECOM OPS – A. ACT, 12–37, step 2
 3. Disconnect PCMMU cable at both ends, connect backup PCMMU cable between orbiter PCMMU port and PGSC Expansion Unit PCMMU port
 4. Replace WinDecom PGSC with backup PGSC with PCMMU Expansion Unit
- If end user PGSC(s) not receiving WinDecom data:
5. ✓ Data being sent out from network and/or com ports on WinDecom PGSC:
From WinDecom ‘Tlm Pkt–Net’ and/or ‘Tlm Pkt–Com’ displays, sel ‘Ports’ tab and verify ‘Bytes’ indicator is dynamic
 6. ✓ Network, RS–232 Y, and/or RS–422 Y data cables properly connected on WinDecom and end user PGSC(s)
If applicable, verify RS–422 PCMCIA card(s) properly inserted and RS–422 adapters properly connected
 7. If sending WinDecom data via network, check network status using PingMaster:
Double-click ‘Shuttle Apps’>‘Network Config’>‘PingMaster’ on any networked PGSC
✓‘Status’ column of ‘Network Nodes’ section for WinDecom PGSC and end user PGSC(s)
If status is ‘Good Response’ for networked PGSCs, press [CTRL]/[x] to exit PingMaster (if desired)
If status is not ‘Good Response’:
✓ Proper network cable and card connections, then recheck status in PingMaster
Double-click ‘Telemetry Server’ icon (i.e., red stop sign or yellow circle) in system tray of each end user PGSC not receiving data
Sel ‘File’ on menu bar, then sel ‘Reset Server’

Cont next page

8. If end user application supports Telemetry Server and PGSC set up to receive serial data, verify port and baud rate selections:
 - Double-click 'Telemetry Server' icon (i.e., red stop sign or yellow circle) in system tray of each end user PGSC not receiving data
 - Sel 'Source' on menu bar of Telemetry Server
 - ✓ 'Serial' selected ("✓")
 - Sel 'Port' on menu bar
 - ✓ Com port selected ("✓") same as com port receiving WinDecom data
 - ✓ Correct baud rate selected for com port:
 - Open 'Packet & TFL Info' table (from 'Shuttle Apps'>'WinDecom' of any PGSC)
 - ✓ Footnotes of table to determine proper baud rate for each com port, then minimize file
 - Sel 'Baud' on menu bar of Telemetry Server
 - ✓ Baud rate selected (✓) matches rate shown in footnote of table for particular com port
9. ✓ Current TFL and WinDecom data output config can support end user application(s):
 - Open 'Packet & TFL Info' table (from 'Shuttle Apps'>'WinDecom' of any PGSC)
 - Reference table to verify current loaded TFL supports particular end user application(s)
 - ✓ 'Output' column of table for packet output from WinDecom (com ports and network), compare info to cabling on WinDecom PGSC

Cont next page

10. If end user application supports Telemetry Server, from 'Help' on menu bar of Telemetry Server of each end user PGSC not receiving data:
Sel 'Trouble–shooting' for more troubleshooting info

SETTING TIMES AND STATE VECTOR

- PGSC
1. Double-click 'Shuttle Apps'>'Time Utilities'>
'Time-Vector Server'
 2. Sel 'Update' on menu bar
Sel 'Time Values'
 3. If PGSC configured to receive WinDecom data:
At bottom of 'Update Time Values' dialog box,
verify 'Auto Synch PGSC with PCMMU'
checked ("") on
✓'Receiving PCMMU data' is displayed
 - * If 'Not receiving PCMMU data' *
 - * displayed: *
 - * Sel 'Exit' to close dialog box *
 - * Perform WINDECOM OPS – C. *
 - * Troubleshooting, 12–38, then: *
 - * Repeat steps 2–3 *Sel 'Exit' to close dialog box
 - Sel 'Update' on menu bar
Sel 'State Vector'
At bottom of 'Update State Vector' dialog box,
verify 'PCMMU feed' checked ("") on
✓'Receiving vector PCMMU data' is displayed
Sel 'Exit' to close dialog box
Minimize 'Time/State Vector Server'
application
 4. If PGSC not configured to receive WinDecom data:
Set GMT, MET, and/or launch values as reqd
Sel 'Apply'
Sel 'Exit' to close 'Update Time Values' dialog
box
Sel 'Update' on menu bar
Sel 'State Vector'

Cont next page

PGSC

GNC 34 ORBIT TGT

Update state vector info using data from SPEC
34 display
Sel 'Apply'
Sel 'Exit' to close 'Update State Vector' dialog
box
Sel 'File' on menu bar
Sel 'Exit'

WORLD MAP INITIALIZATION

- PGSC
1. Double-click 'Shuttle Apps'>'World Map'
 2. If 'World Map Initialization' dialog box displays "ERROR: vector > 4 days...":
 - Sel 'OK'
 - Go to step 4If 'World Map Initialization' dialog box displays "For best results, update GMT and State Vector...", sel 'OK'
 3. Proceed to initialization sequence by selecting 'NO' at 'World Map Initialization' dialog box
 4. At 'Update Time Values' dialog box, verify correct GMT of launch
 5. If PGSC configured to receive WinDecom data:
 6. At bottom of 'Update Time Values' dialog box, verify 'Auto Synch PGSC with PCMMU' checked ("√") on
 - ✓ 'Receiving PCMMU data' is displayed
 - * If 'Not receiving PCMMU data' is displayed:
 - * Sel 'Exit' to close dialog box
 - * Sel 'Exit' to close 'Update Orbiter State Vector' dialog box
 - * Perform WINDECOM OPS – C. Troubleshooting, 12–38
 - * then:
 - * Sel 'File' from WorldMap menu bar
 - * Sel 'Update'
 - * Sel 'Time Values'
 - * ✓ 'Receiving PCMMU data' is displayed in dialog box
 - * Sel 'Exit'
 - * Sel 'File' from menu bar
 - * Sel 'Update'
 - * Sel 'State Vector'
 - * Go to step 8

Cont next page

7. Sel 'Exit' to close dialog box
 8. At bottom of 'Update Orbiter State Vector' dialog box, verify 'PCMMU Feed' checked ("✓") on
 - ✓ 'Receiving vector PCMMU data' displayedSel 'Exit'
 9. If PGSC not configured to receive WinDecom data:
 - At 'Update Time Values' dialog box, verify current GMT displayed
 - Update GMT, if reqd
 - ✓ 'Auto Synch PGSC with PCMMU' not checked (no "✓")
 - Sel 'Apply'
 - Sel 'Exit'
- GNC 34 ORBIT TGT
- PGSC At 'Update Orbiter State Vector' dialog box, update state vector info using data from SPEC 34 display
- ✓ 'PCMMU Feed' not checked (no "✓")
- Sel 'Apply'
- Sel 'Exit'

COLOR PRINTER UNSTOW AND ASSEMBLE

NOTE

Power off Printer when not in use

1. UNSTOW

Printer

AC Pwr Cable (if reqd)

Printer Data Cable (one of the following):

6-ft parallel data cable

25-ft parallel data cable

25-ft network data cable and T-connector

Printer paper

Printer Paper Feeder Tray

Paper Output Tray

2. ASSEMBLE PRINTER

Printer

Align arrows on Paper Feeder Tray and back of
Printer

Insert white tabs on Paper Feeder Tray (near
arrows) into black outlined slots on Printer
(see fig 12-1)

Slide tray downward

Attach Paper Feeder Tray to Printer (secure via
thumbscrews)

Attach Paper Output Tray to Printer (secure via
thumbscrews)

3. See UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use

4. ✓AC UTIL PWR – OFF

Printer

✓AC PWR cable connected to AC Util Pwr panel

Connect AC PWR cable to Printer Power Port
(see fig 12-2)

NOTE

Network must always be properly terminated
when connected to powered PGSCs

Cont next page

If Printer to be set up as Network Printer:
Connect network cable, T-connector to
Printer Network Port (see fig 12-2)
Connect other end of network cable to
T-connector of networked PGSC
If Printer to be set up as Local Printer:
Connect parallel cable between Printer
Parallel Port and ProShare PGSC Parallel
Port (see fig 12-2)

Insert 8.5" x 11" paper into Paper Feeder Tray
(~50 sheets)

Attach Printer to wall of desired area (example:
AFD or Airlock ditch) using Velcro

If OCA Router not configured, perform OCA
SETUP, 12-11






Figure 12-1.– Side view of printer and trays, ready for assembly.

PRINTER Top View (Inside Cover)



PRINTER Back View



PGSC with Expansion Unit




Figure 12–2.– Printer (top view/back view), PGSC (parallel port).

COLOR PRINTER WARMUP AND SELF-TEST

WARMUP

1. See UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use
2. AC UTIL PWR – ON
- PGSC 3. ✓OCA Router PGSC pwr – on
✓ProShare PGSC pwr – on
- Printer 4. Printer pwr – on (see fig 12–2)
✓Flashing green pwr light (~5 min)
5. ✓Printer ready
Ready when pwr light is steady green

SELF-TEST

NOTE

After successful test print, terminate SELF-TEST by powering printer OFF

- Printer 1. Printer pwr – off
2. Press and hold Load/Eject button, then press power button
Hold Load/Eject button for 3 sec after depressing power button, then release
3. Observe printing of one black text page and one color text page
4. ✓Print quality
Look for missing sections in Nozzle Check section
5. If print quality not acceptable, go to CLEANING PRINTER HEADS, 12–54
6. If paper jam, go to COLOR PRINTER PAPER JAM, 12–51
7. If printer quality acceptable, Printer pwr – off (to terminate SELF-TEST)
8. Notify MCC: Status of SELF-TEST results

COLOR PRINTER STOW

- Printer
1. Printer pwr – off (press power button once)
✓ Printer lt – off
Wait for unit to stop moving. Printer head should be at right side and locked into place
 2. See **UTILITY OUTLET PLUG-IN PLAN ORBIT CONFIGURATION** (REF DATA FS, UTIL PWR) or PGSC Usage Chart (if available) for appropriate AC Util Pwr outlet/sw to use
- AC UTIL PWR – OFF
3. Disconnect AC PWR cable from AC Util Pwr outlet, if reqd
 4. Remove paper from Paper Feeder Tray and stow it
 5. Remove Paper Feeder Tray from Printer (disconnect via thumbscrews)
 6. Remove Paper Output Tray from Printer (disconnect via thumbscrews)
 7. Disconnect AC PWR cable from Printer
 8. If Printer set up as Network Printer:
| Disconnect network cable, T-connector from Printer Network Port (see fig 12-2)
If Printer set up as Local Printer:
| Disconnect parallel cable between Printer Parallel Port and ProShare PGSC Parallel Port (see fig 12-2)
 9. Stow:
Printer
AC PWR cable (if reqd)
Printer Data cable(s)
Printer paper
Printer Paper Feeder Tray
Paper Output Tray

CHECK COLOR PRINTER SETTINGS

NOTE

Perform following procedure to verify Printer settings on PGSC from which printing is being executed (i.e., settings are not on Printer)

- PGSC
1. Sel 'Start' from Windows taskbar
 2. Sel 'Settings'
 3. Sel 'Printers'
 4. Right-click appropriate printer icon:
Parallel: Local Color Printer
Network: Network Color Printer
 5. Verify 'Set as default' selected (✓)
 6. Sel 'Properties'
 7. Sel 'Main' tab
 8. Verify 'Automatic' selected (●)
 9. Sel 'OK' to exit

COLOR PRINTER PAPER JAM

- Printer
1. Printer pwr – off (press power button once)
 2. ✓Printer lt – off
 3. ✓Paper Feeder Tray clear of obstruction
✓Paper Output Tray clear of obstruction
 4. Raise Printer cover (see fig 12–1)
✓Inside of Printer clear from obstruction
 5. If paper jam cleared, perform COLOR PRINTER WARMUP AND SELF–TEST, 12–49, then:
 6. If paper jam continues, **notify MCC**
 7. If reqd, go to COLOR PRINTER STOW, 12–50

INK CARTRIDGE CHANGEOUT

NOTE

Perform if color(black) ink cartridge light illuminated. Changeout of color and black cartridges takes approx 5 min.

If color(black) ink cartridge light flashing, ink is low.

If color(black) ink cartridge light is solid, ink is out

- Printer 1. ✓Printer ready (notice steady green pwr light)
 2. Raise Printer cover (see fig 12-1)

NOTE

Printer will reset if step 4 not performed within 1 min after step 3. If reset experienced, repeat step 3

3. Press and hold “color(black) ink cartridge advance button” (~3 sec) and release. Color(black) ink cartridge will move and become accessible

<p style="text-align: center;">CAUTION Do NOT squeeze ink cartridges</p>
--

4. Lift tab on purple cover
Remove color(black) ink cartridge

5. Cover opening on used cartridge with Gray Tape
Stow old cartridge in Ziploc Bag
Place Ziploc in printer locker

6. Unstow new cartridge from sealed pack
Remove small yellow plastic tab on top (Do not remove white tab; reference instructions on cartridge)

Cont next page

- Printer
7. Insert new cartridge (arrow should be pointing toward back of printer)
 8. Lower and latch tab on purple cover
(Do not reopen)
If also changing other cartridge, go to step 3
 9. Lower and close Printer cover
 10. Press Load/Eject button; Printer will perform a cleaning that will last approx 3 min
 11. Go to COLOR PRINTER WARMUP AND SELF-TEST, SELF-TEST, 12-49, to ensure proper operation

CLEANING PRINTER HEADS (Black and/or Color)

NOTE

Printer must be on, not printing, and appropriate ink cartridge light must not illuminate red

- Printer
1. ✓Printer pwr – on
 2. ✓Ink cartridge lt – OFF
If ink cartridge lt flashing or solid, go to INK CARTRIDGE CHANGEOUT, 12–52

NOTE

Perform following steps from PGSC connected to Printer via parallel cable or networked to Printer

- PGSC
3. Sel ‘Start’ from Windows taskbar
 4. Sel ‘Settings’
 5. Sel ‘Printers’
 6. Right-click appropriate printer icon:
Parallel: Local Color Printer
Network: Network Color Printer
 7. Verify ‘Set as default’ selected (✓)
 8. Sel ‘Properties’
 9. Sel ‘Utility’ tab
 10. Sel ‘Head Cleaning’
Sel ‘Next’
 11. Sel ‘Black’, ‘Color’, or ‘Both’
Sel ‘Next’
 12. When cleaning complete (~5 min), sel ‘Nozzle Check’
If test still missing sections, repeat steps 10 and 11
 13. If nozzle test nominal, click ‘OK’ to exit

PRINTER HEAD ALIGNMENT

NOTE

Printer must be on, not printing, and appropriate ink cartridge light must not illuminate red

- Printer
1. ✓Printer pwr – on
 2. ✓Ink cartridge lt – off
If ink cartridge lt flashing or solid, go to INK CARTRIDGE CHANGEOUT, 12-52
 3. Verify paper Feeder Tray has at least ten sheets of paper

NOTE

Perform following steps from PGSC connected to Printer via parallel cable or networked to Printer

- PGSC
4. Sel ‘Start’ from Windows taskbar
Sel ‘Settings’
Sel ‘Printers’
 5. Right-click appropriate printer icon:
Parallel: Local Color Printer
Network: Network Color Printer
 6. Verify ‘Set as default’ selected (✓)
Sel ‘Properties’
 7. Sel ‘Utility’ tab
Sel ‘Print Head Alignment’ button
At ‘Printer Head Alignment’ dialog box, sel ‘Next’ button
 8. At second ‘Printer Head Alignment’ dialog box, sel ‘Next’ button
 9. Examine printed sheet “A”
If alignment satisfactory, sel ‘Cancel’ twice to exit
If alignment not satisfactory, follow directions on screen
 10. When alignment complete (~5 min), sel ‘OK’ to exit

EXECUTE PACKAGE PRINTING

NOTE

Perform following procedure(s) if instructed by MCC. Perform from PGSC connected to Printer via parallel cable or networked to Printer

DOCUMENTS

PGSC Double-click 'Shuttle Apps'>'Color Printer'>
 'DOCS Printing'

PICTURES

Double-click 'Shuttle Apps'>'Color Printer'>
 'PICS Printing'

PILOT WITH RHC

NOTE

It is assumed PGSC (with STS load)
has been set up without expansion unit

A. EQUIPMENT SETUP

1. Unstow:

PILOT HC
PILOT Y-Cable
Elastic Strap (1)
Tie Wraps (2)

- Towel Rack/
Handhold 2. Secure elastic strap to Towel Rack and
 Window Handhold (right or left, to match
 seat used) with tie wraps

CAUTION

Once secure, pushing buckle will
allow it to release, freeing RHC.
When pushing buckle lever to
release, keep thumb clear from
underneath (pinch hazard)

- PILOT HC 3. Extend (pull) PILOT HC straps and position
 HC on aft portion of orbiter RHC pedestal.
 Secure lower strap over pedestal, pull
 strap taut and pull out firmly on buckle;
 repeat with upper strap

- PGSC 4. Shut down Windows

- PWR SPLY 5. DC PWR SPLY PWR sw1 – off

- F1 6. DC UTIL PWR – OFF (utility outlet for
 PGSC)

- PGSC 7. If present, disconnect any cable from PGSC
 RS-232 port and secure

8. Disconnect DC PWR SPLY cable from
 PGSC pwr port

- PILOT HC 9. PILOT HC pwr – OFF (down posn)

Cont next page

- PILOT Y-Cable
10. Connect PILOT Y-Cable to PGSC RS-232 port
Connect PILOT Y-Cable to PGSC pwr port
PILOT HC
(See PILOT WITH RHC SETUP DIAGRAM,
12-61)
 11. Connect DC PWR SPLY cable to PILOT HC

NOTE

Adjust elastic strap so as not to press screen suspend sw (small vertical button by left hinge) or else screen will blank

- PGSC
12. Position and secure PGSC in front of HUD and behind elastic strap (top of display touching bottom of eyebrow panel). Duct tape can be used as needed to secure PGSC

- F1
13. DC UTIL PWR – ON (utility outlet for PGSC)

- PWR SPLY
14. DC PWR SPLY PWR sw1 – ON

B. PILOT OPERATION WITH RHC

- PGSC
1. PGSC pwr – on
 2. PILOT HC pwr – ON (up position)
 3. Double-click ‘Shuttle Apps’ > ‘PILOT w/RHC’
Agree to quit all Windows Apps
 4. Follow instructions for HC calibration
(after ~30 sec)
 5. Menu Selection Values:
Modify as desired
'Enter' twice to run simulation


Cont next page

6. Simulation Begins (~15 sec)
 - 'z' – toggles between instruments and out-the-window displays
 - [space bar] – HUD declutter or if WOW, drag chute deploy
 - 'a' – switch to auto
 - 'c' – switch to CSS (same as HC breakout)
 - 'p' – pause sim, 'p' again resumes
 7. Post Simulation
 - [space bar] – cycles through data to main menu
 - 'b' – cycles back through post run data
 8. Terminate PILOT
Enter 'q' to quit (returns to Windows)
- PILOT HC 9. PILOT HC pwr – OFF (down posn)
- PILOT HC C. PILOT DISCONNECT and STOWAGE
1. Confirm PILOT HC pwr – OFF (down posn)
 2. Shut down Windows
 3. DC PWR SPLY PWR sw1 – OFF
 4. DC UTIL PWR – OFF (utility outlet for PGSC)
 5. Disconnect cables from PGSC and HC (remove PGSC from behind elastic if necessary)

CAUTION
When pushing buckle lever to release,
keep thumb clear from underneath
(pinch hazard)

Cont next page

- PILOT HC 6. Unsecure HC, press buckle on top strap,
 loosen strap, repeat for bottom strap
7. Stow PILOT HC and Y-Cable in original
 locker
8. Cut loose tie wraps and elastic strap from
 window and secure after final on-orbit
 PILOT session
- PGSC 9. Reconfigure PGSC as desired
- D. **TROUBLESHOOTING**
1. If HC appears to have bias, calibrate HC at
main menu – enter ‘c’, follow onscreen
instructions
 2. If DOS prompt appears (sometimes after
bad sim crash), enter ‘win’ to restart
Windows
 3. If program hangs:
Enter [CTRL]/[C] to get to DOS prompt,
once at prompt, restart Windows
(step 2), restart PILOT normally
If [CTRL]/[C] does not work, force
Windows restart with
[CTRL]/[ALT]/[DELETE] simo



PILOT WITHOUT RHC

NOTE

No PILOT equipment reqd,
only PGSC with STS load

- PGSC A. PILOT OPERATION WITHOUT RHC
1. Double-click 'Shuttle Apps' > 'PILOT w/out RHC'
Agree to quit all Windows Apps
 2. Menu Selection Values:

NOTE
Sim must be in 'auto' to keep from crashing:
Sel 'Auto' at startup (item 7)
Otherwise, modify as desired
'Enter' twice to run simulation
 3. Simulation Begins (~15 sec)
'z' – toggles between instruments and out-the-window displays
[space bar] – HUD declutter or if WOW, drag chute deploy
'p' – pause sim, 'p' again resumes
 4. Post Simulation
[space bar] – cycles thru data to main menu
'b' – cycles back thru post run data
 5. Terminate PILOT
Enter 'q' to quit (returns to Windows)
- B. TROUBLESHOOTING
1. If DOS prompt appears (sometimes after bad sim crash), enter 'win' to restart Windows

Cont next page

2. If program hangs:
Enter [CTRL]/[C] to get to DOS prompt,
once at prompt, restart Windows
(step 1), restart PILOT normally
If [CTRL]/[C] does not work, force
Windows restart with
[CTRL]/[ALT]/[DELETE] simo

UPDATING SpOC APPLICATIONS USING OCA DATA DISKETTE (ODD)

NOTE

Procedure assumes KFX application run from ProShare PGSC during OCA ops.
Crew not reqd to perform following procedure for PGSC(s) networked to OCA Router PGSC during OCA ops.

MCC ground personnel automatically update SpOC applications on PGSC(s) on STS network during OCA ops

- PGSC
1. If OCA Data Diskette (ODD) was not in ProShare PGSC floppy drive during OCA ops:
 Retrieve ODD from FDF
 Insert ODD into ProShare PGSC floppy drive
 Copy all files under C:\OCA-UP\SPOC\UPLINK to A:\UPLINK
 2. Insert ODD into PGSC requiring updates to SpOC applications
 3. Double-click 'Shuttle Apps'>'Floppy Update'
 4. At 'Floppy Update' dialog box, sel 'OK'
 5. At 'Floppy Update Status' dialog box, verify no errors generated
 If errors generated, contact MCC >>
 6. If asked to view complete update status:
 Sel 'Yes' or 'No'
 Go to step 7

 Sel 'OK'
 7. Remove ODD, repeat steps 2 thru 6 for other PGSCs as needed
 8. Reinsert ODD into ProShare PGSC floppy drive

PCANYWHERE ACT/DEACT

NOTE

Procedure assumes both PGSCs
powered and connected via network

- PGSC ON HOST PGSC (PGSC SENDING DISPLAY)
1. Double-click 'Shuttle Apps'>'pcANYWHERE'
 - ✓ 'Be A Host PC' box is selected
 - Double-click 'NETWORK' icon in pcANYWHERE window
 2. Double-click 'Shuttle Apps'>'pcANYWHERE'
 - Sel 'Remote Control' box
 - Double-click 'NETWORK' icon in pcANYWHERE window
 - After 'pcANYWHERE waiting' dialog box appears, double-click host PGSC name to establish connection
 - After approx 10 sec, verify window appears showing image of host PGSC display
 - To maximize to full screen, sel  button on title bar
 - To cancel full screen, press [ALT]/[ENTER]
 - ✓ 'Execute Locally' is selected and sel 'OK'
- EXIT APPLICATION ON HOST PGSC
3. Right-click 'pcANYWHERE' on bottom taskbar
 - Sel 'pcANYWHERE'>'End Session'
 - Right-click 'pcANYWHERE' on bottom task bar
 - Sel 'Close'
 - Sel 'Exit' box in pcANYWHERE window
 4. After exiting application on host PGSC, sel 'Exit' box in pcANYWHERE window

PGSC HARD DISK SWAP

- PGSC
1. If running Windows NT (OCA Router s/w) on OCA Router PGSC:
 Press [CNTL]/[ALT]/[DEL]
 Sel 'Shut Down' at 'Logon Information' dialog box
 Sel 'OK'
 When prompted:
 PGSC pwr – off
 Go to step 3
 2. Shut down Windows
 ✓Automatic power off of PGSC
 3. Open PGSC monitor to 180°
 Slide two side latches back and hold latches in back position
 Open Keyboard
- CAUTION**

Some components under Keyboard contain sharp edges
4. Remove hard disk (right component):
 Pull plastic tape to expose hard disk drive handle
 Slide thumbs under handle
 Lift to remove
 5. Insert new hard disk:
 Press only on shaded area until it snaps into connector
 Push hard disk drive handle under lip
 Stow old hard disk drive in carrying case
 6. Close keyboard
 7. PGSC pwr – on
 8. If PGSC intended for use on STS network,
 go to PGSC NETWORK – D. PGSC Naming,
 12–34

PGSC SWAP ON EXPANSION UNIT

- PGSC1 1. Shut down Windows
✓Automatic pwr off of PGSC
2. Close PGSC monitor
3. Firmly turn security key to 'eject' position until PGSC slides away from Expansion Unit
4. Remove, stow PGSC
- PGSC2 5. ✓Sliding door of PGSC Sys Expansion connector – op
6. Slide PGSC onto Expansion Unit
7. Push PGSC back, connecting PGSC Sys Expansion connector to Expansion Unit connector
8. ✓Connection secure
9. Security key – locked
10. PGSC pwr – on

PGSC DEACT

- PGSC 1. ✓Floppy disk drive – empty
 Stow floppy disk(s) in originating locker
2. If running Windows NT (OCA Router s/w) on
 OCA Router PGSC:
 Press [CNTL]/[ALT]/[DEL]
 Sel 'Shut Down' at 'Logon Information'
 dialog box
 Sel 'OK'
 When prompted:
 PGSC pwr – off
 Go to step 6
3. Close any running applications
 Shut down Windows

 ✓Automatic power off of PGSC
 If no Expansion Unit attached:
PWR SPLY 4. DC PWR SPLY PWR sw1 – OFF
 (It off)
- F1 5. DC UTIL PWR – OFF
(MO13Q,
A11,A15,
MO30F,
O19, L12,
MO52J,
ML85E)
- If Expansion Unit attached:
F1 6. AC UTIL PWR – OFF
(MO13Q,
A15,MO52J,
ML85E)
7. Disconnect cables
8. Stow PGSC assembly, PGSC accessories

WINDOWS KEYBOARD REF

NOTE

Simo key combinations linked by slash marks.
Sequential key combinations linked by commas

WINDOWS DESKTOP

Shut down Windows	[CTRL]/[ESC], [↑], [ENTER]
Sel and open desktop icon	[CTRL]/[ESC], [ESC], [TAB], [TAB], [Arrow keys], [ENTER]
Program item icons contained in folder:	
Sel program item icon	[Arrow keys]
Start program	Sel program item, [ENTER]

WINDOWS EXPLORER

Sel previous/next directory or subcategory	[↑] or [↓]
Page forward/backward	[PG DN] or [PG UP]
Sel root directory	[HOME]
Sel last directory	[END]
Expand current selection (if in left pane and not expanded)	[→]
Collapse current selection (if in left pane and expanded)	[←]
Toggle between panes	[TAB] or [F6]
Refresh screen	[F5]

Cont next page

FILE MANIPULATION IN WINDOWS EXPLORER

Sel adjacent files	[SHIFT]/[Up or down arrow keys]
Sel nonadjacent files	[CTRL]/[Up or down arrow keys to move to desired file], [spacebar], repeat as needed
Sel all items	[CTRL]/[A]
Move sel files or dir	[CTRL]/[X], sel drive/dir to move files/dir to, [CTRL]/[V]
Copy sel files or dir	[CTRL]/[C], sel drive/dir to copy files/dir to, [CTRL]/[V]

OPERATING PROGRAMS IN WINDOWS: STARTING, QUITTING, AND SWITCHING BETWEEN PROGRAMS

Start Windows or DOS program	Sel icon on Windows desktop, [ENTER]
Cycle between open applications	[ALT]/[TAB] or [ALT]/[ESC] (sel applications in forward direction) or [SHIFT]/[ALT]/[ESC] (sel applications in reverse direction)
Display Task List Dialog Box	[CTRL]/[ALT]/[DELETE]
Cycle between selections in Dialog Box	[TAB] (forward dir) or [SHIFT]/[TAB] (reverse dir)
Cancel menu currently displayed	[ESC]
Quit active application	[ALT]/[F4] or [ALT], [spacebar], [C] or [ALT], [F], [X]

Cont next page

SIZING, CLOSING, AND MOVING WINDOWS

NOTE

Maximized window cannot be resized;
use Restore to config window for resizing

Restore window from
maximized configuration [ALT], [spacebar], [R]

Resize active program window [ALT], [spacebar], [S], [press
arrow keys to adjust window
size], [ENTER]

NOTE

Document window is working area window
inside applications main window

Resize document window [ALT], [S], [press arrow keys to
adjust window size], [ENTER]

Close window [ALT], [spacebar], [C]

Close document window [ALT], [C]

Move window [ALT], [spacebar], [M], [use
arrow keys to move window
to desired location],
[ENTER]

Move document window [ALT], [M], [use arrow keys
to move window to desired
location], [ENTER]

Minimize program or document [ALT], [spacebar], [N]
window to icon

Maximize program or document [ALT], [spacebar], [X]
window to full screen

Cont next page

PROGRAM CURRENTLY RUNNING

Sel menu and perform task [ALT], [underlined menu letter],
[underlined task letter]

Move between areas (lists,
buttons, etc) in Dialog Box [TAB] or [SHIFT]/[TAB] or
[ALT]/[underlined letter]

Sel pulldown list within Dialog Box [ALT]/[underlined letter]

Cancel pulldown list [ESC]

Cancel menu sel [ESC]

CLIPBOARD FUNCTIONS

Copy displayed image to
Clipboard [CTRL]/[C]

Cut image to Clipboard [CTRL]/[X]

Paste object from Clipboard to
document, spreadsheet, etc [CTRL]/[V]

GETTING HELP

Get Help [F1] or [ALT], [H]

WORLD MAP KEYBOARD REF

NOTE

Simo key combinations linked by slash marks.
Sequential key combinations linked by commas

Help Index	[F1]
Zoom in	[CTRL]/[I], [+] or [PG UP]
Zoom out	[CTRL]/[O], [-] or [PG DN]
Toggle click and drag zoom on/off	[CTRL]/[F12]
Zoom on point clicked	Right click, sel zoom option
Toggle night colors on/off	[CTRL]/[N]
Restore nadir zoom from point zoom	[ESC]
Identify point on map	Left double-click
Toggle previous/next longitude of ascending node (LAN)	[CTRL]/[L]
Exit application	[ALT]/[F4]

GRAFTRAK KEYBOARD REF

NOTE

Simo key combinations linked by slash marks

Toggle zoom and auto zoom	[CTRL]/[Z]
Exit other modes and return to track mode	[T]
Cycle thru three available zoom factors	[Z]
Observer selection menu	[O]
Enter epoch mode to set display to any past or future time	[E]
Return display to current date and time	[ESC]
Quit (exit program)	[Q]
Display help screens (full command list)	[H]
Display 3-D perspective view of Earth as seen from shuttle	[3]
Next observer	[ALT]/[N]
Previous observer	[ALT]/[P]
Change screen colors	[C]
Start/stop clock (freeze/unfreeze display)	[G]
Move time cursor one digit left	[←]
Move time cursor one digit right	[→]
Step date/time cursor digit up by one	[+]
Step date/time cursor digit down by one	[−]
Step time forward one orbit	[PG UP]
Step time backward one orbit	[PG DN]
Search forward to next zero elevation	[↑]
Search backward to last zero elevation	[↓]
Step forward to next TCA	[HOME]
Step backward to previous TCA	[END]
Enter fixed map mode. (Map remains centered on input longitude)	[L]
Alternate satellite selection (shows Mir range circle)	[ALT]/[S]
Enter auto switchover observer mode	[F1]
Calculate next AOS time for all observers in data file	[F2]
Find next AOS for selected observer	[/]
Change default shutter speed and ASA	[ALT]/[C]
Input launch date and time for MET display	[ALT]/[M]

STARS KEYBOARD REF

NOTE

Simo key combinations linked by slash marks

	<u>Run-time Keys</u>
Mnvr at discrete step size or continuous rate	[Arrow keys]
In combination with above to move at greater rate	[SHIFT] or [CTRL]
Terminate continuous mnvr; or, if in cursor mode, recenter cursor. If on menu page, sends user to view selected	[ESC]
Zoom in by 10% (smaller FOV)	[+] or [=]
Zoom out by 10% (larger FOV)	[-] or [-]
Sel star from star table for mnvr. Set inertial hold	[F1]
Sel a specific RA, DEC, and roll. Set inertial hold	[SHIFT]/[F1]
Sel UNIV PTG display	[F2]
Toggle between 'Cursor Mode' and 'Maneuver Mode'. In 'Cursor Mode' arrow keys move cursor/LOS. In 'Maneuver Mode' whole FOV moves	[F3]
Decr discrete step size, for cursor/LOS movement, to a min of 0.1 deg/sec	[SHIFT]/[F3]
Incr discrete step size, for cursor/LOS movement, to max of 100 deg	[CTRL]/[F3]
Decr mnvr rate, to min of 0.1 deg/sec	[SHIFT]/[F4]
Incr mnvr rate, to max of 8 deg/sec	[CTRL]/[F4]
Sel VIEW/FOV display	[F5]
Sel sequentially available vehicle modes: +X COAS, -Z COAS/STRK, W1/-Y STRK, CAMR D, Hercules, and User Select	[SHIFT]/[F5]

Cont next page

NOTE

If CAMR D sel, using [F1] or [SHIFT]/[F1] while LVLH hold sel will cause camera angles to change to track object while orbiter maintains LVLH hold

Sel VIEW/FOV page	[F6]
Sel sequentially available FOVs:	[SHIFT]/[F6]
30 x 23	
40 x 30	
50 x 38	
64 x 48	
80 x 60	
175 x 131	
Cycle backward through available FOVs, see above	[CTRL]/[F6]
Sel TIME/SV page	[F8]
Step GMT forward 5 min/step	[SHIFT]/[F8]
Return to current GMT from previous offset	[CTRL]/[F8]
“ETC....” menu page. Includes:	[F9]
a. Map detail control	
b. Star magnitude control	
c. Star size control	
d. Display screen aspect ratio	
Allow resizing displayed image to account for monitor variations	[SHIFT]/[F9]
Exit program	[SHIFT]/[F10]
If printer enabled, print hard copy ‘P’ enables printer for hard copies	[CTRL]/[F1]

POC STATE VECTOR PADS

L/O ____ — ____ — ____ — ____ — ____ — ____ — ____ —
 YEAR DAY HOUR MIN SEC

SET STATE VECTOR

OPS 2: OPS 3:
 SPEC 34 GNC 0 GPC MEMORY
 ITEM 26 +210 EXEC

X	BE40	VX	BE4C
Y	BE44	VY	BE50
Z	BE48	VZ	BE54

S/V ____ — ____ / ____ : ____ : ____
 DAY HR MIN SEC

X()____ — ____ — ____ . ____ — ____
 Y()____ — ____ — ____ . ____ — ____
 Z()____ — ____ — ____ . ____ — ____
 VX()____ . ____ — ____ — ____ — ____
 VY()____ . ____ — ____ — ____ — ____
 VZ()____ . ____ — ____ — ____ — ____

S/V ____ — ____ / ____ : ____ : ____
 DAY HR MIN SEC

S/V ____ — ____ / ____ : ____ : ____
 DAY HR MIN SEC

X()____ — ____ — ____ . ____ — ____
 Y()____ — ____ — ____ . ____ — ____
 Z()____ — ____ — ____ . ____ — ____
 VX()____ . ____ — ____ — ____ — ____
 VY()____ . ____ — ____ — ____ — ____
 VZ()____ . ____ — ____ — ____ — ____

X()____ — ____ — ____ . ____ — ____
 Y()____ — ____ — ____ . ____ — ____
 Z()____ — ____ — ____ . ____ — ____
 VX()____ . ____ — ____ — ____ — ____
 VY()____ . ____ — ____ — ____ — ____
 VZ()____ . ____ — ____ — ____ — ____

S/V ____ — ____ / ____ : ____ : ____
 DAY HR MIN SEC

S/V ____ — ____ / ____ : ____ : ____
 DAY HR MIN SEC

X()____ — ____ — ____ . ____ — ____
 Y()____ — ____ — ____ . ____ — ____
 Z()____ — ____ — ____ . ____ — ____
 VX()____ . ____ — ____ — ____ — ____
 VY()____ . ____ — ____ — ____ — ____
 VZ()____ . ____ — ____ — ____ — ____

X()____ — ____ — ____ . ____ — ____
 Y()____ — ____ — ____ . ____ — ____
 Z()____ — ____ — ____ . ____ — ____
 VX()____ . ____ — ____ — ____ — ____
 VY()____ . ____ — ____ — ____ — ____
 VZ()____ . ____ — ____ — ____ — ____

RELOAD STS PGSC

- PGSC
1. PGSC pwr – on (while holding [F1] key down)
 2. Sel ‘Config’ at Easy–setup main menu
 3. Sel ‘Initialize’
 4. Sel ‘OK’ to initialize system settings
 5. Sel ‘Exit’
 6. Insert ‘AutoXD Configurator’ disk in floppy drive
 7. Click ‘Restart’ on easy setup window
 8. Sel ‘OK’
 9. Allow timeout prompts to proceed with defaults
 10. Verify that AutoXD reported no errors during config process (config completed successfully)
 11. After config process complete, remove disk from floppy drive
 12. PGSC pwr – off
 13. Insert bootable PGSC Software Reload Diskette into floppy drive
 14. PGSC pwr – on
 15. When prompted, sel ‘Y’ to overwrite hard drive
 16. Insert CD when prompted
 17. When light stops blinking, press any key to continue (software recovery program now loading)
 18. After hard drive updated, remove PGSC Software Reload Diskette and remove CD
 19. Press ‘Ctrl–Alt–Del’ to reboot PGSC

COMPOUND SPECIFIC ANALYZER – COMBUSTION
PRODUCTS (CSA-CP)

COMPOUND SPECIFIC ANALYZER – COMBUSTION PRODUCTS CHECKOUT	
AND ZERO CALIBRATION OPS	13-2
PASSIVE SAMPLING WITH DATA LOGGING	13-5
ACTIVE SAMPLING WITH PUMP AND DATA LOGGING	13-7
CSA-CP BATTERY CHANGEOUT	13-9
SAMPLING PUMP BATTERY CHANGEOUT	13-11
ZERO CALIBRATION	13-12
DATA LOGGER ACTIVATION/DEACTIVATION ...	13-15
ALARM DISABLE/ENABLE	13-16
DATA RECORDING TABLE	13-17

CSA-CP

COMPOUND SPECIFIC ANALYZER – COMBUSTION PRODUCTS CHECKOUT AND ZERO CALIBRATION OPS

NOTE

Function of Zero calibration filter is to remove all target gases (if present) in air stream so that sensors can be rezeroed. Capacity to remove target gases is severely reduced if tethered filter caps are not immediately replaced and tightened after use

- _____ 1. Unstow:
CSA-CP Kit
 - CSA-CP 2. Unstow:
Kit CSA-CP/Sampling Pump
Zero Filter
 3. Sampling Pump sw – ON
- NOTE**
MODE pb (black) located between two red alarm lights.
- Audible beeps occur when MODE pb depressed during unit activation
4. Activate CSA-CP
Press, hold MODE pb until 'RELEASE' displayed

NOTE

Wait approx 1 min while unit runs self–check routine. A single beep occurs when self–check routine complete

5. ✓Display indicates readings for O₂, HCN, HCl, CO and record values in Data Recording Table, 13–15

CSA-CP

Cont next page

6. Sampling Pump sw OFF
7. If any reading higher than listed values below, proceed to step 8 for sensor rezeroing
 - CO ≤ 4 ppm
 - HCL ≤ 0.4 ppm
 - HCN ≤ 0.4 ppmIf readings less than or equal to listed values, go to step 22
8. Unscrew, remove Sampling Pump Inlet (blue) Filter; temp stow
9. Unscrew tethered end caps on Zero Filter

NOTE

Pump inlet fitting has outside
and inside threads

10. Screw end of Zero Filter cw into Sampling Pump inlet fitting until snug
 - Arrow on Zero Filter should point toward Sampling Pump
11. Sampling Pump sw – ON
12. After 2 min, press MODE pb (11 times) until ‘GO CAL’ displayed at top
13. Press “E” button,
 - ✓‘SET SPAN’ displayed at top
14. Press “+” button,
 - ✓‘ZERO’ displayed at top
15. Press “E” button, verify ‘ZEROING’ displayed, wait 15 sec
 - ✓‘ZERO’ displayed at top

Cont next page

16. Press MODE pb once
After 15 sec, verify nominal display
(gas concentrations)
17. ✓Display readings for CO, HCN, HCL less than
or equal to values below
If readings higher than values below, notify MCC
CO ≤ 4 ppm
HCL ≤ 0.4 ppm
HCN ≤ 0.4 ppm
18. Sampling Pump sw – OFF
19. Remove Zero Filter from Sampling Pump inlet.
Replace tethered endcaps and tighten
finger tight

CSA-CP 20. Stow Zero Filter
Kit

NOTE

Damage to O-ring can occur if overtightened

21. Replace Sampling Pump Inlet Filter and tighten
until snug

NOTE

CSA-CP can be used in active sampling
mode using pump or in passive mode
without pump. Use of pump provides faster
response times for some contaminants.

Audible beeps occur when MODE pb
depressed during unit activation

22. Deactivate CSA-CP
Press, hold 'MODE' pb until 'RELEASE'
displayed

23. Temp stow:
CSA-CP/Sampling Pump at crew discretion
location. Call MCC with location

24. Stow CSA-CP Kit

PASSIVE SAMPLING WITH DATA LOGGING

1. Unstow:
CSA-CP Kit
 - CSA-CP 2. Unstow:
Kit CSA-CP/Sampling Pump
 3. Demate CSA-CP ← | → Sampling Pump
 - CSA-CP 4. Stow:
Kit Sampling Pump
- NOTE
Audible beeps occur when MODE pb depressed during unit activation
5. Press, hold MODE pb until 'RELEASE' displayed
- NOTE
Wait ~1 min while unit runs self-check routine. A single beep occurs when self-check routine complete
6. ✓Display indicates readings for O₂, CO, HCN, HCL
- NOTE
When activated, there is an audible beep, fault LED illuminates momentarily, and power LED stays illuminated
7. Transfer CSA-CP to desired location

NOTE
After activating/deactivating logger, nominal display (gas concentrations) returns in ~10 sec

Cont next page

8. Press MODE pb (9 times) until 'LOG OFF' or
'LOG ON' displayed
If reqd, press "+" button to reset data logger to
'LOG ON' displayed
✓'LOG ON' displayed
Notify MCC to discuss sampling plan
9. Conduct sampling session
10. Record value
Notify MCC of results
11. Press, hold MODE pb until 'RELEASE' displayed
✓Unit off

CSA-CP12. Unstow:
Kit Sampling Pump

NOTE

CSA-CP should be oriented with display
visible when facing front panel of
sampling pump

13. CSA-CP ← | → Sampling Pump. Slide CSA-CP
into sampling pump bracket as far forward
(toward inlet) as possible. Tighten Velcro straps

CSA-CP14. Stow:
Kit CSA-CP/Sampling Pump

15. Stow:
CSA-CP Kit

ACTIVE SAMPLING WITH PUMP AND DATA LOGGING

- _____ 1. Unstow:
CSA-CP Kit

- CSA-CP 2. Unstow:
Kit CSA-CP/Sampling Pump

NOTE

Audible beeps occur when MODE pb
depressed during unit activation

3. Press, hold MODE pb until 'RELEASE' displayed

NOTE

Wait approx 1 min while unit runs self-check
routine. A single beep occurs when
self-check routine complete

4. ✓Display indicates readings for O₂, CO, HCN,
HCL

NOTE

When activated, there is an audible beep, fault
LED illuminates momentarily, and power LED
stays illuminated

5. Sampling Pump switch ON

6. Transfer active sampling assembly to desired
location

NOTE

After activating/deactivating logger,
nominal display (gas concentrations)
returns in approx 10 sec

Cont next page

7. Press MODE pb (9 times) until 'Log OFF' or 'LOG ON' displayed
If reqd, press "+" button to reset data logger to 'LOG ON'
✓'LOG ON' displayed
Notify MCC to discuss sampling plan
8. Conduct active sampling session
Record values
Notify MCC of results
9. At end of active sampling, press, hold MODE pb until 'RELEASE' displayed
✓Unit off
10. Sampling Pump switch off

CSA-CP11. Stow:
Kit CSA-CP/Sampling Pump

_____ 12. Stow:
CSA-CP Kit |

CSA-CP BATTERY CHANGEOUT

1. If CSA-CP/Sampling Pump active:
Sampling Pump switch OFF
Press, hold MODE pb until 'RELEASE'
displayed
✓CSA-CP off
If not active, go to step 3
2. CSA-CP ← | → Sampling Pump
- CSA-CP 3. Unstow:
Kit Batt Pack, marker
4. Replace battery, turn fasteners (two) on back panel 1/4 turn ccw; temp stow panel

NOTE

Stored data maintained for a maximum of 30 min without battery installed. All data lost if battery installation delayed more than 30 min

5. Grasp Batt Pack pull tab, remove pack
6. Mark Batt Pack "DISCHARGED" with marker
- CSA-CP 7. Stow:
Kit Used Batt Pack
8. Install replacement Batt pack, press firmly to seat electrodes
9. Replace Panel, press firmly, turn fasteners (two) 1/4 turn cw to lock

NOTE

CSA-CP should be oriented with display visible when facing front panel of sampling pump

10. CSA-CP → | ← Sampling Pump. Slide CSA-CP into sampling pump bracket as far forward (toward inlet) as possible. Tighten Velcro straps

Cont next page

11. If contingency, activate CSA-CP/Sampling Pump:

Press, hold MODE pb until 'RELEASE' displayed

✓CSA-CP on
Sampling Pump sw ON

CSA-CP
Kit

If not contingency, stow CSA-CP/Sampling Pump

12. Stow:
CSA-CP Kit

SAMPLING PUMP BATTERY CHANGEOUT

- IFM Kit 1. Unstow:
Small Flathead Screwdriver
Marker
- CSA-CP 2. Unstow:
Kit Spare Batt Pack
3. Turn screw on back panel ccw 3 to 4 turns
 4. Remove panel
Temp stow
 5. Grasp Batt Pack pull tab, remove Batt Pack
 6. Mark Batt Pack "DISCHARGED" with marker
 7. Install replacement Batt Pack, press firmly to seat electrodes
 8. Replace cover plate, turn screw cw until tight
- IFM Kit 9. Stow:
Screwdriver
- CSA-CP 10. Stow:
Kit Used Batt Pack

ZERO CALIBRATION

NOTE

Function of zero calibration filter is to remove all target gases (if present) in the air stream so that sensors can be rezeroed. Capacity to remove target gases is severely reduced if tethered filter caps are not immediately replaced and tightened after use

- _____ 1. Unstow:
CSA-CP Kit

- CSA-CP 2. Unstow:
Kit CSA-CP/Sampling Pump
Zero Filter

NOTE
Audible beeps occur when MODE pb depressed during unit activation

3. Press, hold MODE pb until 'RELEASE' displayed

NOTE

Wait approx 1 min while unit runs self-check routine. A single beep occurs when self-check routine complete

4. ✓Display indicates readings for O₂, HCN, HCL, CO

5. Unscrew, remove Sampling Pump Inlet (blue)
Filter
Temp stow

6. Unscrew tethered end caps on Zero Filter

NOTE

Pump inlet fitting has outside and inside threads

Cont next page

7. Screw end of Zero Filter cw into Sampling Pump inlet fitting until snug
Arrow on Zero Filter should point toward Sampling Pump
8. Sampling Pump sw ON
9. After 2 min, press MODE pb (11 times) until 'GO CAL' is displayed at top
10. Press "E" button
✓'SET SPAN' displayed at top
11. Press "+" button,
✓'ZERO' displayed at top
12. Press "E" button, verify 'ZEROING displayed,
wait 15 sec
✓'ZERO' displayed at top
13. Press MODE pb once
After 15 sec, verify nominal display (gas concentrations)
14. Sampling Pump sw OFF
15. Remove Zero Filter from Sampling Pump inlet.
Replace tethered endcaps and tighten finger tight

NOTE
Damage to O-ring can occur if overtightened

16. Replace Sampling Pump Inlet Filter and tighten until snug

NOTE
CSA-CP can be used in active sampling mode using pump or in passive mode without pump. Use of pump provides faster response times for some contaminants

Cont next page

13-13 ORB OPS/ALL/GEN H

- | | | |
17. If passive operation of the CSA-CP is desired, then:
| CSA-CP ← | → Sampling Pump
If active sampling desired, use as configured

CSA-CP18. Stow:
Kit Zero Filter
 Sampling Pump (for passive operation)
Notify MCC

19. Transfer CSA-CP to desired location for sampling session

DATA LOGGER ACTIVATION/DEACTIVATION

NOTE

After activating/deactivating Data Logger,
nominal display (gas concentrations)
returns in approx 10 sec

- CSA-CP 1. Press MODE pb (9 times) until 'LOG OFF'
(for activation) or 'LOG ON' (for deactivation)
displayed
2. Press "+" button to activate or deactivate Data
Logger
✓'LOG ON' or 'LOG OFF' displayed, as desired

ALARM DISABLE/ENABLE

NOTE

Disabling CSA-CP alarm function removes audio and visual annunciation (flashing red lights) if target gas thresholds are exceeded. However, any target gas concentration(s) above preset threshold(s) continue to be indicated by blinking display

1. Notify MCC prior to disabling alarm function

NOTE

Audible beeps occur when MODE pb depressed during unit activation

2. Press, hold MODE pb until 'RELEASE' displayed

NOTE

Wait ~1 min while unit runs self-check routine. A single beep occurs when self-check routine complete

3. ✓Display indicates readings for OXYGEN, HCN, HCL, CO

NOTE

Operating mode reverts to nominal display after 10 sec

4. Press MODE pb (10 times) until 'MUTE' or 'UNMUTE' is displayed
5. Press "+" button to disable/enable alarms, as desired

✓Display indicates alarm enabled/disabled

DATA RECORDING TABLE

MET	LOCATION	DATA READINGS	REMARKS
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	
___/___:___		1. O2 _____ 2. CO _____ 3. HCN _____ 4. HCL _____	

This Page Intentionally Blank

13-18

ORB OPS/ALL/GEN H

SHUTTLE AUDIO DOSIMETER

ACTIVATION	14-2
SOUND LEVEL METER (SLM) MODE	14-2
Lavg/Leq MODE	14-3
DEACTIVATION	14-4

SHUTTLE
AUD DOS

14-1 ORB OPS/ALL/GEN H

ACTIVATION

VOL 3B 1. Unstow:

Audio Dosimeter

2. Slide front panel up ~1 inch on audio dosimeter
3. O/I sw → I (on)

NOTE

Front panel LED will light for ~10 sec while circuits test battery, then flash at intervals of ~2 sec to show circuits functioning

4. ✓‘BATT OK’ appears in top left of display and does not blink after ~10 sec
- ✓‘0:00 time’ appears on display

SOUND LEVEL METER (SLM) MODE

1. Depress and release front black pb until ‘SLM dB’ appears on display

NOTE

Do not read SLM dB data when talking. This may interfere with real-time decibel measurement.

An ‘OFL’ (memory overflow) msg may appear momentarily on display if dosimeter measures sound \geq 99 dB. Ignore msg and continue measurements

2. Hold mic in front of desired location for ~10 sec to take measurement
3. Record:
SLM dB _____ dB
Location _____
MET Time _____ / _____ : _____ : _____
4. Call down recorded data to MCC

Lavg/Leq MODE

1. Depress and release front black pb until
'Lavg/Leq' appears on display
2.

For Crew Worn: Attach dosimeter to belt Run mic underneath shirt Attach mic to collar as close to ear as possible	For Static Deployment: Place dosimeter in specified location Slide front panel down to cover display Attach mic ~60 cm (2 ft) away from dosimeter
--	--
3. Record:
Deployed Location: _____
MET Start Time _____ / _____ : _____ : _____
4. Retrieve dosimeter from location or crewmember after specified time (~24 hr) of deployment expired
5. Record:
MET Stop Time _____ / _____ : _____ : _____
Lavg/Leq _____ dBA
6. Call down recorded location, MET Start and Stop Time, and Lavg/Leq dBA to MCC

NOTE

An 'OFL' (memory overflow) msg may appear momentarily on display if dosimeter measures sound \geq 99 dB or if dosimeter has been on \geq 20 hr. Ignore msg and continue measurements

DEACTIVATION

1. Slide front panel up, if not already up
 2. O/I sw → O (off)
 3. Slide front panel down
- VOL 3B 4. Stow dosimeter

CUE CARD
CONFIG

CUE CARD CONFIGURATION

FAB USE ONLY

15-1

ORB OPS/ALL/GEN H

CUE CARD
CONFIG

TOP

WCCS COMM PLAN

CREW/CHNL	WALL UNIT	A/G1	A/G2	A/A	ICOM A	ICOM B
_____ /A1	A	_____	_____	_____	_____	_____
_____ /A2		_____	_____	_____	_____	_____
_____ /B1	B	_____	_____	_____	_____	_____
_____ /B2		_____	_____	_____	_____	_____
_____ /C1	C	_____	_____	_____	_____	_____
_____ /C2		_____	_____	_____	_____	_____
_____ /D1	D	_____	_____	_____	_____	_____
_____ /D2		_____	_____	_____	_____	_____
_____ /E1	E	_____	_____	_____	_____	_____
_____ /E2		_____	_____	_____	_____	_____

ORB OPS-1a/O/A

FAB USE ONLY

(reduced copy)

CC 15-2

ORB OPS/ALL/GEN H

TOP
BACK OF 'WCCS COMM PLAN'

HOOK
VELCRO

ORB OPS-1b/O/A

FAB USE ONLY

(reduced copy)
CC A15-3

MEDS
ORB OPS/ALL/GEN H


MEDS

(reduced copy)

CC A15-4

ORB OPS/MEDS/GENH

FAB USE ONLY



NO	GNC SPEC	OPS		NO	SM OPS 2		
		2	8		SPEC	NO	SPEC
43	CONTROLLERS		X	88	APU/ENVIRON THERM	97	PL RETENTION
20	DAP CONFIG	X		86	APU/HYD	89	PRPLT THERMAL
1	DPS UTILITY	X	X	76	COMMUNICATIONS	60	SM TABLE MAINT
6	GPC/BUS STATUS	X	X	68	CRYO SYSTEM	2	TIME
0	GPC MEMORY	X	X	8	CRYO PALLET		
21	IMU ALIGN	X		1	DPS UTILITY		
45	NWS		X	67	ELECTRIC		
34	ORBIT TGT	X		66	ENVIRONMENT		
23	RCS	X	X	77	EVA - MMU/FSS		
33	REL NAV	X		69	FUEL CELLS		
41	RGA/ADTA/RCS		X	6	GPC/BUS STATUS		
25	RM ORBIT	X		0	GPC MEMORY		
40	SENSOR TEST		X	87	HYD THERMAL		
22	S TRK/COAS CNTL	X		85	MASS MEMORY R/W		
44	SWITCHES		X	62	PCMMU/PL COMM		
42	SWITCH/SURF		X	94	PDRS CONTROL		
2	TIME	X	X	95	PDRS OVERRIDE		
55	GPS STATUS	X	X	96	PDRS STATUS		
ORBIT SPEC (R11)		900-902		TEXT SPEC INDEX			MEDS

ORB OPS-2a/MEDS/O/F

TOP
BACK OF 'WCCS COMM PLAN'

HOOK
VELCRO

ORB OPS-1b/O/A

FAB USE ONLY

(reduced copy)
CC B15-3

NOM
ORB OPS/ALL/GEN H

NOM

(reduced copy)


CC B15-4

ORB OPS/NOM/GENH

FAB USE ONLY

NO	GNC SPEC	OPS		NO	SM OPS 2		
		2	8		SPEC	NO	SPEC
43	CONTROLLERS		X	88	APU/ENVIRON THERM	97	PL RETENTION
20	DAP CONFIG	X		86	APU/HYD	89	PRPLT THERMAL
1	DPS UTILITY	X	X	76	COMMUNICATIONS	60	SM TABLE MAINT
6	GPC/BUS STATUS	X	X	68	CRYO SYSTEM	2	TIME
0	GPC MEMORY	X	X	8	CRYO PALLET		
21	IMU ALIGN	X		1	DPS UTILITY		
45	NWS		X	67	ELECTRIC		
34	ORBIT TGT	X		66	ENVIRONMENT		
23	RCS	X	X	77	EVA - MMU/FSS		
33	REL NAV	X		69	FUEL CELLS		
41	RGA/ADTA/RCS		X	6	GPC/BUS STATUS		
25	RM ORBIT	X		0	GPC MEMORY		
40	SENSOR TEST		X	87	HYD THERMAL		
22	S TRK/COAS CNTL	X		85	MASS MEMORY R/W		
44	SWITCHES		X	62	PCMMU/PL COMM		
42	SWITCH/SURF		X	94	PDRS CONTROL		
2	TIME	X	X	95	PDRS OVERRIDE		
				96	PDRS STATUS		
ORBIT SPEC (R11)		900-902		TEXT SPEC INDEX			NOM

ORB OPS-35a/NOM/O/A



TOP

FAB USE ONLY
 (reduced copy)
 CC 15-5 ORB OPS/ALL/GEN H

TOP
BACK OF 'ORBIT SPEC (R11)'

PRIMARY C/W PARAMETER MATRIX

ORB OPS-2b/O/B

	0	1	2	3	4	5	6	7	8	9
00	TK1	TK1 HTR 1	FC1 O2	MNA	CABIN P	OX TK P	OX TK P	1 EGT	C He TK P	
01	TK2	TK1 HTR 2	FC1 H2	MNB	O2 SYS 1 FLOW	FU TK P	FU TK P	2 EGT	L He TK P	
02	TK3	TK2 HTR 1	FC2 O2	MNC	O2 SYS 2 FLOW	LEAK/TK P	LEAK/TK P	3 EGT	R He TK P	
03	TK4	TK2 HTR 2	FC2 H2	AC1	CABIN PPO2 A	OX TK P	OX TK P	1 OIL INT	C He REG P.	
04	PLBK	HEATER THERM	FC3 O2	AC2	CABIN PPO2 B	FU TK P	FU TK P	2 OIL INT	L He REG P.	
05	TK1	TK3 HTR 1	FC3 H2	AC3	N2 SYS 1 FLOW	LEAK/TK P	LEAK/TK P	3 OIL INT	R He REG P.	
06	TK2	TK4 HTR 1	FC1	AC1	N2 SYS 2 FLOW	OMS TVC	APU 1	APU 1	L02 MANF P	
07	TK3	TK4 HTR 2	FC2	AC2	CABIN FAN	FU TK P	OX TK P	APU 2	LH2 MANF P	
08	TK4	PLBK TK HTR	FC3	AC3	PAYOUT MAN AIR	LEAK/TK P	LEAK/TK P	APU 3	H2 PRESS	
09	PLBK	ADTA	FUEL CELL PUMP	RGA/AA	AV BAY/CABIN AIR	RCS JET	PAYOUT CAUTION	APU 1	SYS 1	
10	L RHC	FCS SAT	FC1	IMU	AV BAY 2 T	1 OUT	1 FLOW	APU 2	SYS 2	
11	R/AFT RHC	FCS CH BYPASS	FC2		AV BAY 3 T	1 OUT	1 FLOW	APU 3	H2 PRESS	SYS 3
			FC3		CAB HX OUT	2 OUT	2 FLOW			


ZIPTONED PARAM USED WHEN PL/KIT INSTALLED  PARAM INH IF KIT NOT INSTALLED  PARAM INH ON-ORBIT

1359, ART 5
04/27/92

FAB USE ONLY
(reduced copy)
CC 15-6 ORB OPS/ALL/GEN H

Fabricate as a Transparency


CAM C
ZOOM-IN FULL
MONITOR SCAN – UNDER
MOUNT OVERLAY: ALIGN CROSS HAIR
PAN/TILT TO ALIGN BULKHEAD ROLLERS



KU ANTENNA OVERLAY
(B&W MONITOR)

ORB OPS-3a/O/B

FAB USE ONLY
(reduced copy)
CC 15-7 ORB OPS/ALL/GEN H



ORB OPS/ALL/GEN H

(reduced copy)
CC 15-8

FAB USE ONLY

URINE COLLECTION (w/o UMS)

- ✓ FAN SEP same as HOSE BLOCK
- ✓ MODE – AUTO
- ✓ CRADLE – AUTO
 - Unstow hose and install urinal funnel
 - ✓ Airflow
 - ✓ WCS ON It – on
 - Urinate
 - Remove, clean, stow urinal funnel

NOTE

FAN SEP will run for ~30 sec after hose stowage

- Stow hose in cradle
- ✓ WCS ON It – off

URINE/FECES COLLECTION

- ✓ FAN SEP same as HOSE BLOCK
- ✓ New bag in WCS Coffee Can
- MODE – COMMODE/MANUAL/EMU

NOTE

CRADLE sw disabled when MODE sw in COMMODE/MANUAL/EMU position

- Unstow hose and install urinal funnel
- ✓ Airflow
- ✓ WCS ON It – on
- COMMODE CNTL – UP (wait 15 sec)
- FWD

- Ensure proper seal, restrain body
- Urinate/defecate

- ✓ Transport tube – clean if reqd

NOTE

No WCS Coffee Can airflow until slide vlv cl

- COMMODE CNTL – OFF (BACK/DN)
- Remove, clean, stow urinal funnel
- Clean seat as reqd
- Close WCS trash bag, place in WCS trash module
- Place new bag in WCS Coffee Can

NOTE

FAN SEP will run for ~30 sec after MODE – AUTO

- Stow hose in cradle
- MODE – AUTO
- ✓ WCS ON It – off

NOTE

This Cue Card to fly for missions manifesting WCS w/o UMS

TOP

HOOK
VELCRO

WCS COMPACTOR OPS (DUAL-VANE)

Tools reqd: 1/4-in Torque Wrench
6-in Extension
1/4-in to 3/8-in Adapter

Set Torque Wrench to 50 in-lb (first or second compaction)

- ✓ MODE – AUTO

FIRST COMPACTION

Rotate Compactor crank – cw. Stop when torque limit obtained
At completion of compaction, ✓ net clear of transport tube. If torque limit reached while gauge in yellow region, ✓ MCC before proceeding to CONTINGENCY OPS

SECOND COMPACTION

Rotate Compactor crank – ccw. Stop when torque limit obtained
At completion of compaction, ✓ net clear of transport tube. If torque limit reached while gauge in yellow region, ✓ MCC before proceeding to CONTINGENCY OPS

- * CONTINGENCY OPS (Vanes will not rotate or *
* jammed vane) *
- * MODE – COMMODE/MANUAL/EMU (✓ airflow) *
- * COMMODE CNTL – UP (wait 20 sec) *
- * – FWD *
- * ✓ WCS ON It – on *
- * Allow 5 min for commode contents to soften, then *
* reattempt compaction. If no joy, attempt compaction *
- * once more after 5 min. If still no joy, inspect vanes for *
- * attached debris. If debris present, remove/ *
- * redistribute using scraper tool (wear gloves). *
- * Re-attempt compaction. If still no joy, ✓ MCC *
- * If compactor net blocking transport tube, use scissors to *
- * cut elastic net to clear tube *
- * When complete:
* COMMODE CNTL – OFF (BACK/DN) *
- * MODE – AUTO *
- * ✓ WCS ON It – off *

Stow tools

ORB OPS-5a/O/G

FAB USE ONLY

(reduced copy)
CC 15-9

ORB OPS/ALL/GEN H

CONT WASTE COLLECTION – UCD/APOLLO BAG

NOTE

WCS Compactor Ops must be performed before stowing Apollo Bags in commode

Unstow Bags
Complete urination in UCD
Remove Apollo Bag Seal Cover
Seal to buttocks and defecate
Force gas out and seal
Stow Apollo Bag in commode or wet trash
Stow UCD in wet trash

FAN SEP SWITCHING

- ✓ MODE – AUTO
- ✓ CRADLE – AUTO
- ✓ Hose stowed in cradle
- ✓ WCS ON lt – off
- FAN SEP SEL sw – OFF
- HOSE BLOCK – SEP 2(1)

NOTE

In next step, alternate fan sep will turn on for 30 sec. Normal ops may proceed after 30-sec run complete

FAN SEP SEL sw – 2(1)

If airflow still low or if no airflow, ✓MCC

TOP
BACK OF 'URINE COLLECTION (w/o UMS)'

**HOOK
VELCRO**

WCS CLEANING

Urinal:

NOTE

Hose must be stowed in cradle to take switch to AUTO INHIBIT

CRADLE – AUTO INHIBIT
Inspect/replace prefilter (once/day or as reqd)
Discard old prefilter in WCS dry trash
Inspect/clean urinal Hose Screen (disconnect Hose from Hose Block)
CRADLE – AUTO

Commode:

Use Sanitation Agent/Dry Wipes to clean seat and transport tube above gate vlv
Discard in WCS trash module

**HOOK
VELCRO**

ORB OPS-5b/O/F

ORB OPS/ALL/GEN H

(reduced copy)
CC 15-10

FAB USE ONLY

URINE COLLECTION (w/UMS)

Y-Vlv – WCS
WCS/UMS sw – WCS
Install urinal funnel
✓ FAN SEP same as HOSE BLOCK
✓ MODE – WCS/EMU (✓ airflow)
Urinate
Remove, clean, stow urinal funnel

CAUTION
Allow FAN SEP to run for
30 sec before proceeding

WCS/UMS sw – UMS
Y-Vlv – UMS

URINE/FECES COLLECTION

Y-Vlv – WCS
WCS/UMS sw – WCS
Install urinal funnel
✓ New bag in WCS trash can
✓ FAN SEP same as HOSE BLOCK
✓ MODE – WCS/EMU (✓ airflow)
COMMODE CNTL – UP (wait 15 sec)
– FWD
Ensure proper seal, restrain body
Urinate/defecate
✓ Transport tube

NOTE
No WCS Trash Can airflow until slide vlv cl
COMMODE CNTL – OFF (BACK/DN)
Remove, clean, stow urinal funnel
Clean seal as reqd
Seal WCS trash bag, place in WCS trash module
Place new bag in WCS trash can

CAUTION
Allow FAN SEP to run for
30 sec before proceeding

WCS/UMS sw – UMS
Y-Vlv – UMS

NOTE
This Cue Card to fly for missions manifesting WCS, UMS

TOP

HOOK
VELCRO

WCS COMPACTOR OPS (DUAL-VANE)

Tools reqd: 1/4-in Torque Wrench
4-in Extension
1/4-in to 3/8-in Adapter
Set Torque Wrench to 50 in-lb (first or second compaction)

MODE – OFF

FIRST COMPACTION

Rotate Compactor crank – cw. Stop when torque limit obtained. At completion of compaction, ✓ net clear of transport tube. If torque limit reached while gauge in yellow region, go to CONTINGENCY OPS

SECOND COMPACTION

Rotate Compactor crank – ccw. Stop when torque limit obtained. At completion of compaction, ✓ net clear of transport tube. If torque limit reached while gauge in yellow region, go to CONTINGENCY OPS

- * CONTINGENCY OPS (Van es won't rotate or *)
- * jammed vane): *
- * MODE – WCS/EMU (✓ airflow) *
- * COMMODE CNTL – UP (wait 20 sec) *
- * – FWD *
- * Allow 5 min for commode contents to *
- * soften, then reattempt compaction. If no joy, *
- * attempt compaction every 5 min. If still no *
- * joy, inspect vanes for attached debris. If *
- * debris present, remove/redistribute using *
- * scraper tool (wear gloves). Re-attempt *
- * compaction. If still no joy, ✓MCC *
- *
- * If compactor net blocking transport tube, use *
- * scissors to cut elastic net to clear tube *
- *
- * When complete:
- * COMMODE CNTL – DN *
- * MODE – OFF *

Stow tools

ORB OPS-6a/O/H

ORB OPS/ALL/GEN H

(reduced copy)
CC 15-11

FAB USE ONLY

TOP
BACK OF 'URINE COLLECTION (w/UMS)'

+ -

HOOK VELCRO

UMS CONT WASTE COLLECTION – UCD/APOLLO BAG

NOTE
WCS Compactor Ops must be performed before stowing Apollo Bags in commode

Unstow Bags
Complete urination in UCD
Remove Apollo Bag Seal Cover
Seal to buttocks and defecate
Force gas out and seal
Place Apollo Bag in Outer Bag
Remove Outer Bag Internal Seal Cover
Force gas out and seal
Stow Apollo Bag in commode or wet trash
Stow UCD in wet trash

FAN SEP FAILURE

CAUTION
Do not run both FAN SEPARATORS at same time

If low or no airflow in WCS:
MODE – OFF
HOSE BLOCK – SEP 2(1)

NOTE
In next step, alternate fan sep will turn on for 30 sec. Normal ops may proceed after 30-sec run complete

FAN SEP SEL sw – 2(1)
MODE – WCS/EMU (√airflow)

If airflow still low or if no airflow, √MCC

WCS CLEANING

Urinal:
Inspect/replace prefilter (once/day or as reqd)
Discard old prefilter in WCS dry trash
Disconn Y-Vlv w/bracket and stem hose
Inspect/replace urinal Hose Screen
Reconn Y-Vlv w/bracket and stem hose to WCS

Commode:
Use Sanitation Agent/Dry Wipes to clean seat and transport tube above gate vlv
Discard in WCS trash module

HOOK VELCRO

ORB OPS-6b/O/G

ORB OPS/ALL/GEN H

(reduced copy)
CC 15-12

FAB USE ONLY

EDO WCS URINE COLLECTION

- Unstow urinal hose
- ✓ Airflow
- ✓ URINAL READY It – on (5–15 sec)
- Install urinal funnel
- Urinate
- Remove, clean, and stow urinal funnel
- Stow urinal hose

EDO WCS URINE/FECES COLLECTION

- Unstow urinal hose
- ✓ Airflow
- ✓ URINAL READY It – on (5–15 sec)
- Install urinal funnel
- Open commode lid
 - ✓ Fecal bag installed (gold dot UP)
 - ✓ COMMODE FAN – ON (audible 1–15 sec)
 - ✓ All Its – off (except URINAL READY It)
 - * If COMMODE FAULT It – on:
 - * Verify airflow (commode Fan 1 fault
 - * Controller has started Fan 2)
 - * Continue w/commode use
 - * If COMMODE FAULT It – blinking:
 - * ✓MCC
 - * If SERVICE CANISTER It – on:
 - * Fecal Canister will need servicing soon
 - * Continue w/commode use
 - * If SERVICE CANISTER It – blinking:
 - * Go to EDO WCS FECAL CANISTER
 - * CHANGEOUT (Cue Card)

- Restrain body
- Urinate/defecate
- Remove, clean, and stow urinal funnel
- Stow urinal hose
- Clean seat as reqd
- Raise seat
- Insert fecal bag lid (tab up), ✓Lid seated

(Cont Next Column)

NOTE

This Cue Card to fly in place of current urine collection
Cue Card for missions manifesting EDO WCS

TOP

HOOK
VELCRO

EDO WCS URINE/FECES COLLECTION (Cont)

- Unlatch compactor and rotate to compact position,
- ✓ Engaged in 3 slide brackets
- Latch compactor in place

- * If compactor rotation impeded:
 - * ✓COMPACTOR ARM LOCK PIN – raised *
 - * ✓COMPACTOR CLEANING LATCH *
 - * PIN – engaged *

- ✓ READY TO COMPACT It – on
- COMPACT pb – push
- ✓ READY TO COMPACT It – off (as compacting begins)
- on (as compacting ends)

- * If Commode FAULT It – on: *
- * ✓MCC

- Unlatch compactor and rotate to stowed position
- Latch compactor in place
- ✓ All Its – off
- Install new fecal bag (gold dot UP)
- Lower seat
- Close commode lid, ✓Seat lid latch – latched

EDO WCS CLEANING

Urinal:
Inspect/replace urine screen (once/day or as reqd)
Discard old prefilter in AUX WET TRASH


Commode:
Use Sanitation Agent/Dry Wipes to clean seat
Discard in AUX WET TRASH

ORB OPS-7a/O/C

FAB USE ONLY

(reduced copy)
CC 15-13

ORB OPS/ALL/GEN H



ORB OPS-7b/O/C

TOP

EDO WCS MANUAL COMPACTION

WITH TOOLS

OBJECTIVE: Extend/retract Compactor Piston w/battery-powered Screwdriver or Robbin's Wrench in event of compactor failure

TOOLS REQD: 1/4-in to 3/8-in Adapter
Battery-powered Screwdriver or Robbin's Wrench

1. Raise seat
2. Install Fecal Bag lid
3. Unlatch Compactor, rotate to compact position, latch in place
 - * If Compactor rotation impeded:
 - * ✓COMPACTOR ARM LOCK PIN – raised
 - * ✓COMPACTOR CLEANING LATCH PIN – engaged
4. Rotate Manual Drive cw to extend Compactor Piston
5. Rotate Manual Drive ccw to retract Compactor Piston
6. Unlatch Compactor, rotate to stowed position, latch in place
7. Install new Fecal Bag
8. Lower seat
9. Close commode lid

BY HAND (No more than three times consecutively)

OBJECTIVE: Manually compact Fecal Bag in event of Compactor failure

TOOLS REQD: None

1. Raise seat
2. Install Fecal Bag lid
3. Push Fecal Bag and lid to bottom of Transport Tube
4. Install new Fecal Bag
5. Lower seat
6. Close commode lid

ORB OPS-8a/O/A

NOTE: This Cue Card to fly for missions
manifesting EDO WCS

(reduced copy)

FAB USE ONLY

CC 15-14

ORB OPS/ALL/GEN H

TOP
BACK OF 'EDO WCS MANUAL COMPACTION'

HOOK
VELCRO

ORB OPS-8b/O/A

FAB USE ONLY


(reduced copy)

CC 15-15

ORB OPS/ALL/GEN H

Fabricate as a Transparency

PHOTO GRID OVERLAY



ORB OPS-9a/O/A

(reduced copy)

FAB USE ONLY

CC 15-16

ORB OPS/ALL/GEN H

TOP



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(5 Crewmembers/RED sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1	2	
POST BLUE FD2	3	"	
PRE BLUE FD2	"	4	
POST BLUE FD3	5*	6	
PRE BLUE FD3	7	"	
POST BLUE FD4	"	8	
PRE BLUE FD4	9	"	
POST BLUE FD5	"	10	
PRE BLUE FD5	11	"	
POST BLUE FD6	12*	13	
PRE BLUE FD6	14	"	
POST BLUE FD7	"	15	
PRE BLUE FD7	16	"	
POST BLUE FD8	"	17	
PRE BLUE FD8	18	"	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-11a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-17

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(5 Crewmembers/RED sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST BLUE FD9	19*	20	
PRE BLUE FD9	21	"	
POST BLUE FD10	"	22	
PRE BLUE FD10	23	"	
POST BLUE FD11	"	24	
PRE BLUE FD11	25	"	
POST BLUE FD12	26*	27	
PRE BLUE FD12	28	"	
POST BLUE FD13	"	29	
PRE BLUE FD13	30	"	
POST BLUE FD14	"	31	
PRE BLUE FD14	32	"	
POST BLUE FD15	33*	34	
PRE BLUE FD15	35	"	
POST BLUE FD16	"	36	
PRE BLUE FD16	37	"	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-11b/NON-RCRS/A

(reduced copy)

FAB USE ONLY

CC 15-18

ORB OPS/ALL/GEN H

TOP

HOOK
VELCRO

**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(5 Crewmembers/BLUE sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1	2	
POST RED FD2	3	"	
PRE RED FD2	"	4	
POST RED FD3	5*	6	
PRE RED FD3	7	"	
POST RED FD4	"	8	
PRE RED FD4	9	"	
POST RED FD5	"	10	
PRE RED FD5	11	"	
POST RED FD6	12*	13	
PRE RED FD6	14	"	
POST RED FD7	"	15	
PRE RED FD7	16	"	
POST RED FD8	"	17	
PRE RED FD8	18	"	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-12a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-19

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(5 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST RED FD9	19*	20	
PRE RED FD9	21	"	
POST RED FD10	"	22	
PRE RED FD10	23	"	
POST RED FD11	"	24	
PRE RED FD11	25	"	
POST RED FD12	26*	27	
PRE RED FD12	28	"	
POST RED FD13	"	29	
PRE RED FD13	30	"	
POST RED FD14	"	31	
PRE RED FD14	32	"	
POST RED FD15	33*	34	
PRE RED FD15	35	"	
POST RED FD16	"	36	
PRE RED FD16	37	"	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-12b/NON-RCRS/A

(reduced copy)

FAB USE ONLY

CC 15-20

ORB OPS/ALL/GEN H

TOP



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(6 Crewmembers/RED sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1	2	
POST BLUE FD2	3	4	
POST RED FD3	5	"	
POST BLUE FD3	6	7*	
POST RED FD4	"	8	
POST BLUE FD4	9*	10	
POST RED FD5	11	"	
POST BLUE FD5	"	12	
POST RED FD6	13	14	
POST BLUE FD6	"	15	
POST RED FD7	16	"	
POST BLUE FD7	17	18	
POST RED FD8	"	19*	
POST BLUE FD8	20	21	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-13a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-21

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(6 Crewmembers/RED sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST RED FD9	22*	"	
POST BLUE FD9	23	24*	
POST RED FD10	"	25*	
POST BLUE FD10	26	27	
POST RED FD11	28	"	
POST BLUE FD11	"	29	
POST RED FD12	30	"	
POST BLUE FD12	31	32	
POST RED FD13	33	"	
POST BLUE FD13	34	35	
POST RED FD14	"	36	
POST BLUE FD14	37*	38	
POST RED FD15	39*	"	
POST BLUE FD15	40	41*	
POST RED FD16	"	42*	
POST BLUE FD16	43	44	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-13b/NON-RCRS/A


(reduced copy)

FAB USE ONLY

CC 15-22

ORB OPS/ALL/GEN H

TOP



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(6 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1	2	
POST RED FD2	3	4	
POST BLUE FD3	5	"	
POST RED FD3	6	7*	
POST BLUE FD4	"	8	
POST RED FD4	9*	10	
POST BLUE FD5	11	"	
POST RED FD5	"	12	
POST BLUE FD6	13	14	
POST RED FD6	"	15	
POST BLUE FD7	16	"	
POST RED FD7	17	18	
POST BLUE FD8	"	19*	
POST RED FD8	20	21	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-14a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-23

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(6 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST BLUE FD9	22*	"	
POST RED FD9	23	24*	
POST BLUE FD10	"	25*	
POST RED FD10	26	27	
POST BLUE FD11	28	"	
POST RED FD11	"	29	
POST BLUE FD12	30	"	
POST RED FD12	31	32	
POST BLUE FD13	33	"	
POST RED FD13	34	35	
POST BLUE FD14	"	36	
POST RED FD14	37*	38	
POST BLUE FD15	39*	"	
POST RED FD15	40	41*	
POST BLUE FD16	"	42*	
POST RED FD16	43	44	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-14b/NON-RCRS/A

(reduced copy)

FAB USE ONLY

CC 15-24

ORB OPS/ALL/GEN H

TOP



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(7 Crewmembers/RED sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1*	2	
PRE BLUE FD1	3*	"	
POST BLUE FD2	4	5	
PRE BLUE FD2	6	"	
POST BLUE FD3	7	8	
PRE BLUE FD3	9	"	
POST BLUE FD4	10	11	
PRE BLUE FD4	12*	13*	
POST BLUE FD5	14	15	
PRE BLUE FD5	16	"	
POST BLUE FD6	17	18	
PRE BLUE FD6	19	"	
POST BLUE FD7	20	21	
PRE BLUE FD7	22*	23*	
POST BLUE FD8	24	25	
PRE BLUE FD8	26	"	

*Reseal LiOH cans w/Gray Tape and stow
ORB OPS-15a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-25

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(7 Crewmembers/RED sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST BLUE FD9	27	28	
PRE BLUE FD9	29*	30*	
POST BLUE FD10	31	32	
PRE BLUE FD10	33	"	
POST BLUE FD11	34	35	
PRE BLUE FD11	36*	37*	
POST BLUE FD12	38	39	
PRE BLUE FD12	40	"	
POST BLUE FD13	41	42	
PRE BLUE FD13	43	"	
POST BLUE FD14	44	45	
PRE BLUE FD14	46*	47*	
POST BLUE FD15	48	49	
PRE BLUE FD15	50	"	
POST BLUE FD16	51	52	
PRE BLUE FD16	53*	54*	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-15b/NON-RCRS/A

(reduced copy)

FAB USE ONLY

CC 15-26

ORB OPS/ALL/GEN H

TOP

HOOK
VELCRO

**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(7 Crewmembers/BLUE sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1*	2	
PRE RED FD1	3*	"	
POST RED FD2	4	5	
PRE RED FD2	6	"	
POST RED FD3	7	8	
PRE RED FD3	9	"	
POST RED FD4	10	11	
PRE RED FD4	12*	13*	
POST RED FD5	14	15	
PRE RED FD5	16	"	
POST RED FD6	17	18	
PRE RED FD6	19	"	
POST RED FD7	20	21	
PRE RED FD7	22*	23*	
POST RED FD8	24	25	
PRE RED FD8	26	"	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-16a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-27

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(7 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST RED FD9	27	28	
PRE RED FD9	29*	30*	
POST RED FD10	31	32	
PRE RED FD10	33	"	
POST RED FD11	34	35	
PRE RED FD11	36*	37*	
POST RED FD12	38	39	
PRE RED FD12	40	"	
POST RED FD13	41	42	
PRE RED FD13	43	"	
POST RED FD14	44	45	
PRE RED FD14	46*	47*	
POST RED FD15	48	49	
PRE RED FD15	50	"	
POST RED FD16	51	52	
PRE RED FD16	53*	54*	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-16b/NON-RCRS/A

(reduced copy)

FAB USE ONLY

CC 15-28

ORB OPS/ALL/GEN H

TOP

HOOK
VELCRO

**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(8 Crewmembers/RED sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1*	2	
POST RED FD2	3	"	
POST BLUE FD2	4	5	
POST RED FD3	6*	7*	
POST BLUE FD3	8	9	
POST RED FD4	10*	11*	
POST BLUE FD4	12	13	
POST RED FD5	14	15	
POST BLUE FD5	16	17	
POST RED FD6	18*	19*	
POST BLUE FD6	20	21	
POST RED FD7	22*	23*	
POST BLUE FD7	24	25	
POST RED FD8	26*	27*	
POST BLUE FD8	28	29	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-17a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS


(reduced copy)

FAB USE ONLY

CC 15-29

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(8 Crewmembers/RED sleeps 1st/FD 1-16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST RED FD9	30*	31*	
POST BLUE FD9	32	33	
POST RED FD10	34*	35*	
POST BLUE FD10	36	37	
POST RED FD11	38*	39*	
POST BLUE FD11	40	41	
POST RED FD12	42	"	
POST BLUE FD12	43	44	
POST RED FD13	45*	46*	
POST BLUE FD13	47	48	
POST RED FD14	49*	50*	
POST BLUE FD14	51	52	
POST RED FD15	53	54	
POST BLUE FD15	55*	56*	
POST RED FD16	57	58	
POST BLUE FD16	59*	60*	

*Reseal LiOH cans w/Gray Tape and stow
ORB OPS-17b/NON-RCRS/A


(reduced copy)

FAB USE ONLY

CC 15-30

ORB OPS/ALL/GEN H

TOP



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(8 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1*	2	
POST BLUE FD2	3	"	
POST RED FD2	4	5	
POST BLUE FD3	6*	7*	
POST RED FD3	8	9	
POST BLUE FD4	10*	11*	
POST RED FD4	12	13	
POST BLUE FD5	14	15	
POST RED FD5	16	17	
POST BLUE FD6	18*	19*	
POST RED FD6	20	21	
POST BLUE FD7	22*	23*	
POST RED FD7	24	25	
POST BLUE FD8	26*	27*	
POST RED FD8	28	29	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-18a/NON-RCRS/A

NOTE

Cue Card not flown for missions manifesting RCRS

(reduced copy)

FAB USE ONLY

CC 15-31

ORB OPS/ALL/GEN H

TOP
BACK OF 'DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT'



**DUAL SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**

(8 Crewmembers/BLUE sleeps 1st/FD 1–16)

FLIGHT DAY	POS A	POS B	CK CMPLT
POST BLUE FD9	30*	31*	
POST RED FD9	32	33	
POST BLUE FD10	34*	35*	
POST RED FD10	36	37	
POST BLUE FD11	38*	39*	
POST RED FD11	40	41	
POST BLUE FD12	42	"	
POST RED FD12	43	44	
POST BLUE FD13	45*	46*	
POST RED FD13	47	48	
POST BLUE FD14	49*	50*	
POST RED FD14	51	52	
POST BLUE FD15	53	54	
POST RED FD15	55*	56*	
POST BLUE FD16	57	58	
POST RED FD16	59*	60*	

*Reseal LiOH cans w/Gray Tape and stow

ORB OPS-18b/NON-RCRS/A


(reduced copy)

FAB USE ONLY

CC 15-32

ORB OPS/ALL/GEN H

TOP



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(5 Crewmembers/1 Shift/FD 1–6)

FLIGHT DAY	POS A	POS B	CK CMPLT
FD1 LAUNCH	1*	2	
FD1 PRE SLEEP	3	"	
FD2 POST SLEEP	"	4	
FD2 PRE SLEEP	5	"	
FD3 POST SLEEP	"	6	
FD3 PRE SLEEP	7	"	
FD4 POST SLEEP	"	8	
FD4 PRE SLEEP	9	"	
FD5 POST SLEEP	"	10	
FD5 PRE SLEEP	11*	12	
FD6 POST SLEEP	13	"	
FD6 PRE SLEEP	"	14	

(FLIGHT DAYS 7–12 ON BACK)

*Reseal LiOH cans #1/11/18/19/27
with Gray Tape and stow

ORB OPS-19a/NON-RCRS/A

NOTE: Cue card not flown for missions manifesting RCRS

(reduced copy)

FAB USE ONLY

CC 15-33

ORB OPS/ALL/GEN H

TOP
BACK OF 'SINGLE SHIFT ORBITER CO2 ABSORBER REPLACEMENT'



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(5 Crewmembers/1 Shift/FD 7-12)

FLIGHT DAY	POS A	POS B	CK CMPLT
FD7 POST SLEEP	15	"	
FD7 PRE SLEEP	"	16	
FD8 POST SLEEP	17	"	
FD8 PRE SLEEP	"	18*	
FD9 POST SLEEP	19*	20	
FD9 PRE SLEEP	21	"	
FD10 POST SLEEP	"	22	
FD10 PRE SLEEP	23	"	
FD11 POST SLEEP	"	24	
FD11 PRE SLEEP	25	"	
FD12 POST SLEEP	"	26	
FD12 PRE SLEEP	27*	28	
FD13 POST SLEEP	29	"	

ORB OPS-19b/NON-RCRS/A

FAB USE ONLY

(reduced copy)

CC 15-34

ORB OPS/ALL/GEN H

TOP



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(6 Crewmembers/1 Shift/FD 1–6)

FLIGHT DAY	POS A	POS B	CK CMPLT
1 LAUNCH	1*	2	
1 PRE SLEEP	3	"	
2 POST SLEEP	"	4	
2 PRE SLEEP	5*	6	
3 POST SLEEP	7	"	
3 PRE SLEEP	"	8	
4 POST SLEEP	9	10	
4 PRE SLEEP	11	"	
5 POST SLEEP	"	12	
5 PRE SLEEP	13*	14	
6 POST SLEEP	15	"	
6 PRE SLEEP	"	16	

(FLIGHT DAYS 7–12 ON BACK)

*Reseal LiOH cans #1/5/13/21/29
with Gray Tape and stow

ORB OPS-20a/NON-RCRS/A

NOTE: Cue card not flown for missions manifesting RCRS

(reduced copy)

FAB USE ONLY

CC 15–35

ORB OPS/ALL/GEN H

TOP
BACK OF 'SINGLE SHIFT ORBITER CO2 ABSORBER REPLACEMENT'



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(6 Crewmembers/1 Shift/FD 7-12)

FLIGHT DAY	POS A	POS B	CK CMPLT
7 POST SLEEP	17	18	
7 PRE SLEEP	19	"	
8 POST SLEEP	"	20	
8 PRE SLEEP	21*	22	
9 POST SLEEP	23	"	
9 PRE SLEEP	"	24	
10 POST SLEEP	25	26	
10 PRE SLEEP	27	"	
11 POST SLEEP	"	28	
11 PRE SLEEP	29*	30	
12 POST SLEEP	31	"	
12 PRE SLEEP	"	32	
13 POST SLEEP	33	34	
13 PRE SLEEP	35	"	
14 POST SLEEP	"	36	

ORB OPS-20b/NON-RCRS/A

FAB USE ONLY

(reduced copy)

CC 15-36

ORB OPS/ALL/GEN H

TOP



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(7 Crewmembers/1 Shift/FD 1-6)

FLIGHT DAY	POS A	POS B	CK CMPLT
1 LAUNCH	1*	2	
1 PRE SLEEP	3	"	
2 POST SLEEP	5	4*	
2 PRE SLEEP	"	6	
3 POST SLEEP	7	8	
3 PRE SLEEP	9	"	
4 POST SLEEP	11	10	
4 PRE SLEEP	"	12	
5 POST SLEEP	13	14	
5 PRE SLEEP	15	"	
6 POST SLEEP	17	16	
6 PRE SLEEP	"	18	

(FLIGHT DAYS 7-12 ON BACK)

*Reseal LiOH cans #1/4/21/22
with Gray Tape and stow

ORB OPS-21a/NON-RCRS/A

NOTE: Cue card not flown for missions manifesting RCRS

(reduced copy)

FAB USE ONLY

CC 15-37

ORB OPS/ALL/GEN H

TOP
BACK OF 'SINGLE SHIFT ORBITER CO₂ ABSORBER REPLACEMENT'



**SINGLE SHIFT ORBITER
CO₂ ABSORBER REPLACEMENT**
(7 Crewmembers/1 Shift/FD 7-12)

FLIGHT DAY	POS A	POS B	CK CMPLT
7 POST SLEEP	19	20	
7 PRE SLEEP	21*	22*	
8 POST SLEEP	23	24	
8 PRE SLEEP	"	25	
9 POST SLEEP	26	27	
9 PRE SLEEP	28	"	
10 POST SLEEP	30	29	
10 PRE SLEEP	"	31	
11 POST SLEEP	32	33	
11 PRE SLEEP	34	"	
12 POST SLEEP	36	35	
12 PRE SLEEP	"	37	
13 POST SLEEP	38	39	

ORB OPS-21b/NON-RCRS/A

FAB USE ONLY

(reduced copy)

CC 15-38

ORB OPS/ALL/GEN H

TOP



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(8 Crewmembers/1 Shift/FD 1-8)

FLIGHT DAY	POS A	POS B	CK CMPLT
1 LAUNCH	1	2	
1 PRE SLEEP	3	"	
2 POST SLEEP	4	5	
2 PRE SLEEP	6	7	
3 POST SLEEP	8	9	
3 PRE SLEEP	10	11	
4 POST SLEEP	12	13	
4 PRE SLEEP	14	15	
5 POST SLEEP	16	17	
5 PRE SLEEP	18	19	
6 POST SLEEP	20	21	
6 PRE SLEEP	22	23	
7 POST SLEEP	24	25	
7 PRE SLEEP	26	27	
8 POST SLEEP	28	29	
8 PRE SLEEP	30	31	

ORB OPS-22a/NON-RCRS/A

NOTE: Cue card not flown for missions manifesting RCRS

(reduced copy)

FAB USE ONLY

CC 15-39

ORB OPS/ALL/GEN H

TOP
BACK OF 'SINGLE SHIFT ORBITER CO2 ABSORBER REPLACEMENT'



**SINGLE SHIFT ORBITER
CO2 ABSORBER REPLACEMENT**
(8 Crewmembers/1 Shift/FD 9-14)

FLIGHT DAY	POS A	POS B	CK CMPLT
9 POST SLEEP	32	33	
9 PRE SLEEP	34	35	
10 POST SLEEP	36	37	
10 PRE SLEEP	38	39	
11 POST SLEEP	40	41	
11 PRE SLEEP	42	"	
12 POST SLEEP	43	44	
12 PRE SLEEP	45	46	
13 POST SLEEP	47	48	
13 PRE SLEEP	49	50	
14 POST SLEEP	51	52	

ORB OPS-22b/NON-RCRS/A

FAB USE ONLY

(reduced copy)

CC 15-40

ORB OPS/ALL/GEN H

TOP

HOOK
VELCRO

URINE PRETREAT CHANGEOUT

NOTE

Caps will be transferred to used Oxone Hose Section (OHS). OHS is capped in 1 atm environment. Removal of caps during installation could be propulsive if cabin pressure < 14.7 psia

Retrieve new OHS from large Ziploc Bag
Remove Combitherm Bag from OHS
Record H/N from OHS label and 'installed' MET on Cue Card for new OHS
Remove caps from new OHS; temp stow
Detach used OHS from prefilter housing and hose block extension
Place caps on used OHS
Place used OHS in Ziploc Bag labeled 'Trash'; stow in large Ziploc Bag
Attach new OHS to prefilter housing and hose block extension

FD	OHS H/N	MET INSTALLED
1	N/A	N/A
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		

ORB OPS-23a/O/C

(reduced copy)

FAB USE ONLY

CC 15-41

ORB OPS/ALL/GEN H

TOP
BACK OF "URINE PRETREAT CHANGEOUT"

HOOK
VELCRO

URINE PRETREAT SETUP

NOTE

Caps will be transferred to used Oxone Hose Section (OHS). OHS is capped in 1 atm environment. Removal of caps during installation could be propulsive if cabin pressure < 14.7 psia

- Retrieve OHS kit, temp stow large Ziploc Bag
- Retrieve new OHS from large Ziploc Bag
- Remove Combitherm Bag from OHS
- Record H/N from OHS label and 'installed' MET on Cue Card for new OHS
- Remove caps from new OHS; temp stow
- Detach empty urinal hose section from prefilter housing and hose block extension
- Place caps on empty hose section
- Fasten empty hose section to WCS via Velcro strap
- Attach new OHS to prefilter housing and hose block extension

URINE PRETREAT ENTRY PREP

NOTE

Caps will be transferred to used Oxone Hose Section (OHS). OHS is capped in 1 atm environment. Removal of caps during installation could be propulsive if cabin pressure < 14.7 psia

- Unfasten empty hose section from WCS
- Remove caps from empty hose section; temp stow
- Detach used OHS from prefilter housing and hose block extension
- Place caps on used OHS
- Place used OHS in Ziploc Bag labeled 'Trash'; stow in large Ziploc Bag
- Attach empty hose section to prefilter housing and hose block extension
- Record H/N from OHS label and 'installed' MET on Cue Card for empty hose section
- Stow OHS kit for Entry

ORB OPS-23b/O/C

(reduced copy)


FAB USE ONLY

CC 15-42

ORB OPS/ALL/GEN H

Space Shuttle Program
FLIGHT DATA FILE

JSC-48035
GENERIC, REV H



ORBIT OPS CHECKLIST

STS
ALL

Flight Cover (trim bottom to expose tabs)