

# **CM SOFTWARE**

**COLOSSUS 3  
(ARTEMIS REV 72)  
CM DSKY**

**COMPUTER PROGRAMS  
COMPUTER ROUTINES**

**VERB CODES  
NOUN CODES  
ALARM CODES  
OPTION CODES**

**CHECKLIST CODES**

**FLAGWORD BIT ASSIGNMENTS  
IMODES30 AND IMODES33**

**OPTMODES**

**RCSFLAGS**

**DAPDATR1 AND DAPDATR2  
CHANNEL BIT ASSIGNMENTS  
COMPUTER PROGRAM DESCRIPTION**

## CM DSKY

## UPLINK ACTY Light

1. Is energized by the first character of a digital UPLINK message received by the AGC.
2. Is energized during the Rendezvous Navigation program (P20) when the Tracking Attitude routine (R61) detects that gimbal angle or pointing angle change of greater than 10 degrees is required to align the CSM to the desired attitude and that the V50 N18 flag is not set.
3. Is energized in the TLI INITIATE/CUTOFF program (P15) during the 10-second interval when the S-IVB Injection Sequence Start bit (Channel 12, bit 13) is set. It is deenergized at the end of the 10-second interval.

NO ATT Light — is energized when the AGC is in the Operate mode and there is no inertial reference; that is, the ISS is off, caged, or in the Coarse Align mode.

STBY Light — is energized when the AGC is in the Standby mode and deenergized when the AGC is in the Operate mode.

## KEY REL Light

1. Energized when:
  - a. An internal display comes up while astronaut has the DSKY.
  - b. An astronaut keystroke is made when an internal flashing display is currently on the DSKY.
  - c. The astronaut makes a keystroke on top of (his own) Monitor Verb Display.
2. Deenergized when:
  - a. Astronaut relinquishes DSKY by hitting KEY REL button.
  - b. Astronaut terminates his current sequence normally, for example,
    - (1) With final ENTR of a load sequence.
    - (2) The ENTR of a response to a flashing display.
    - (3) The ENTR of an extended verb request.

OPR ERR Light — is energized when the DSKY operator performs an improper sequence of key depressions. The light is deenergized by pressing the RSET button.

TEMP Light — The AGC receives a signal from the IMU when the stable member temperature is in the range 126.3° F to 134.3° F. In the absence of this signal, the TEMP light on the DSKY is actuated.

GIMBAL LOCK Light — is energized when the middle gimbal angle exceeds ±70 degrees from its zero position. When the middle gimbal angle exceeds ±85 degrees from its zero position, the AGC automatically commands the Coarse Align mode in the ISS to prevent gimbal oscillation (except when the S-IVB is attached). The NO ATT light will then be energized.

PROG Light — The program alarm actuates the PROG light on the DSKY. A program alarm is generated under a variety of situations.

RESTART Light — In the event of a RESTART during operation of a program, a latch is set in the AGC which maintains the RESTART light on the DSKY until the latch is manually reset by pressing RSET.

## TRACKER Light

1. The presence of an Optics CDU Fail signal will cause the TRACKER light to be energized.
2. In addition, the TRACKER light is energized during the Rendezvous Navigation program (P20) when the Rendezvous Data Processing routine (R22) reads VHF range data via the VHF DATA link but the DATA GOOD discrete is missing.
3. It is deenergized if the DATA GOOD discrete is present after reading VHF range data and by keying in V88E (shuts off the VHF range data processing section of R22).
4. It is deenergized when the conditions of 1 above no longer exist.


## CM DSKY (CONTINUED)

COMP ACTY Light — is energized when the AGC is occupied with an internal sequence.

Display Panel — consists of 24 electroluminescent sections. Each section is capable of displaying any decimal character or remaining blank, except the three sign sections. These display a plus sign, a minus sign, or a blank. The numerical sections are grouped to form three data display registers, each of five numerical characters; and three control display registers, each of two numerical characters. The data display registers are referred to as R1, R2, R3. The control display registers are known as VERB, NOUN, and PROGRAM.

Keyboard — contains the following buttons:

1. VERB — pushing this button indicates that the next two numerical characters keyed in are to be interpreted as the Verb Code.
2. NOUN — pushing this button indicates that the next two numerical characters keyed in are to be interpreted as the Noun Code.
3. + and -- are sign keys used for sign convention and to identify decimal data.
4. 0-9 — are numerical keys.
5. CLR — Used during a data loading sequence to clear or blank the data display register (R1, R2, R3) being used. It allows the operator to reload the data word.
6. PRO — This pushbutton performs two functions:
  - a. When the AGC is in a Standby mode, pressing this button will put the AGC in the Operate mode, turn off the STBY light, and automatically select Routine 00 in the AGC.
  - b1. When the AGC is in the Operate mode but Program 06 is not selected, pressing the button will provide the "Proceed" function. If the proceed button is pressed when VERB lights contain 21, 22, or 23, the action is rejected and the OPR ERR light is energized.
  - b2. When the AGC is in the Operate mode and Program 06 is selected, pressing the button will put the AGC in the Standby mode and turn on the STBY light.
7. ENTR — is used in three ways:
  - a. To direct the AGC to execute the Verb/Noun code now appearing on the Verb/Noun lights.
  - b. To direct the AGC to accept a data word just loaded.
  - c. In response to a "please perform" request.
8. RSET — turns off alarm conditions on the DSKY providing the alarm condition has been corrected.



## LIST OF PROGRAMS FOR PROGRAM COLOSSUS

PHASE	PROGRAM	PROGRAM TITLE
Pre-launch and Service	00	AGC Idling
	01	Prelaunch or Service-Initialization
	02	Prelaunch or Service-Gyrocompassing
	03	Prelaunch or Service-Optical Verification of Gyrocompassing
	06	AGC Power Down
	07	System Test
	11	Earth Orbit Insertion Monitor
Boost	15	TLI Initiate/Cutoff
Coast	20	Universal Tracking
	21	Ground Track Determination
	22	Orbital Navigation
	23	Cislunar Midcourse Navigation
	24	Rate Aided Optics Tracking
	27	AGC Update
	29	Time-of-Latitude
Pre-thrusting	30	External Delta V
	31	CSM Height Adjustment Maneuver (HAM)
	32	CSM Coelliptic Sequence Initiation (CSI)
	33	CSM Constant Delta Altitude (CDH)
	34	CSM Transfer Phase Initiation (TPI) Targeting
	35	CSM Transfer Phase Midcourse (TPM) Targeting
	36	CSM Plane Change (PC) Targeting
Thrusting	37	Return to Earth
	40	SPS
	41	RCS
Alignment	47	Thrust Monitor
	51	IMU Orientation Determination
	52	IMU Realign
Entry	53	Backup IMU Orientation Determination
	54	Backup IMU Realign
Pre-thrusting Other Vehicle	61	Entry-Preparation
	62	Entry-CM/SM Separation and Preentry Maneuver
	63	Entry-Initialization
	64	Entry-Post 0.05G
	65	Entry-Upcontrol
	66	Entry-Ballistic
	67	Entry-Final Phase
Pre-thrusting Other Vehicle	72	LM Coelliptic Sequence Initiation (CSI)
	73	LM Constant Delta Altitude (CDH)
	74	LM Transfer Phase Initiation (TPI) Targeting
	75	LM Transfer Phase (Midcourse) Targeting
	76	LM Target Delta V
	77	CSM Target Delta V
	79	Rendezvous Final Phase

## LIST OF ROUTINES FOR PROGRAM COLOSSUS

ROUTINE	ROUTINE TITLE
00	Final Automatic Request Terminate
01	Erasable and Channel Modification Routine
02	IMU Status Check
03	Digital Autopilot Data Load
05	S-Band Antenna
07	MINKEY Controller
21	Rendezvous Tracking Sighting Mark
22	Rendezvous Tracking Data Processing
23	Backup Rendezvous Tracking Sighting Mark
30	Orbit Parameter Display
31	Rendezvous Parameter Display Routine No. 1
33	AGC/LGC Clock Synchronization
34	Rendezvous Parameter Display Routine No. 2
36	Rendezvous Out-of-Plane Display Routine
40	SPS Thrust Fail
41	State Vector Integration (MID to AVE)
50	Coarse Align
52	Automatic Optics Positioning
53	Sighting Mark
54	Sighting Mark Display
55	Gyro Torquing
56	Alternate LOS Sighting Mark
57	Optics Calibration
60	Attitude Maneuver
61	Tracking Attitude
62	Crew-Defined Maneuver
63	Rendezvous Final Attitude
67	Universal Tracking Rotation

## LIST OF VERBS USED IN PROGRAM COLOSSUS

## REGULAR VERBS

00	Not in use
01	Display Octal Component 1 in R1
02	Display Octal Component 2 in R1
03	Display Octal Component 3 in R1
04	Display Octal Components 1, 2 in R1, R2
05	Display Octal Components 1, 2, 3 in R1, R2, R3
06	Display decimal in R1 or R1, R2 or R1, R2, R3
07	Display DP decimal in R1, R2 (test only)
08	Spare
09	Spare
10	Spare
11	Monitor Octal Component 1 in R1
12	Monitor Octal Component 2 in R1
13	Monitor Octal Component 3 in R1
14	Monitor Octal Components 1, 2 in R1, R2
15	Monitor Octal Components 1, 2, 3 in R1, R2, R3
16	Monitor decimal in R1 or R1, R2 or R1, R2, R3
17	Monitor DP decimal in R1, R2 (test only)
18	Spare
19	Spare
20	Spare
21	Load Component 1 into R1
22	Load Component 2 into R2
23	Load Component 3 into R3
24	Load Components 1, 2 into R1, R2
25	Load Components 1, 2, 3 into R1, R2, R3
26	Spare
27	Display Fixed Memory
28	Spare
29	Spare
30	Request EXECUTIVE
31	Request WAITLIST
32	Recycle program
33	Proceed without DSKY inputs
34	Terminate function
35	Test lights
36	Request FRESH START
37	Change program (major mode)
38	Spare
39	Spare
EXTENDED VERBS	
40	Zero ICDU
41	Coarse align CDU's (specify N20 or N91)
42	Pulse torque gyros
43	Load IMU attitude error needles (test only)
44	Set Surface flag
45	Reset Surface flag
46	Establish G & N autopilot control
47	Move LM state vector into CM state vector
48	Request DAP Data Load routine (R03)
49	Start automatic attitude maneuver

## LIST OF VERBS USED IN PROGRAM COLOSSUS

50	Please perform
51	Please mark
52	Mark on offset landing site
53	Please perform CCAS mark
54	Request Rendezvous Backup Sighting Mark routine (R23)
55	Increment AGC time (decimal)
56	Terminate tracking (P20)
57	Request display of full track flag (FULTKFLG)
58	Reset Stick flag and set V50 N18 flag
59	Please calibrate
60	Set astronaut total attitude (N17) to present attitude
61	Display DAP following attitude errors (Mode 1)
62	Display total attitude errors with respect to Noun 22 (Mode 2)
63	Display total astronaut attitude error with respect to Noun 17 (Mode 3)
64	Request S-Band Antenna routine (R05)
65	Optical verification of prelaunch alignment
66	Vehicles are attached. Move this vehicle state vector to other vehicle.
67	Start W-matrix RSS error display
68	Spare
69	Cause RESTART
70	Update liftoff time (P27)
71	Start AGC update; block address (P27)
72	Start AGC update; single address (P27)
73	Start AGC update; AGC time (P27)
74	Initialize erasable dump via DOWNLINK
75	Backup liftoff
76	Spare
77	Spare
78	Update prelaunch azimuth
79	Spare
80	Enable LM state vector update
81	Enable CSM state vector update
82	Request Orbit Parameter display (R30)
83	Request Rendezvous Parameter display No. 1 (R31)
84	Spare
85	Request Rendezvous Parameter display No. 2 (R34)
86	Reject Rendezvous Backup Sighting Mark
87	Set VHF Range flag
88	Reset VHF Range flag
89	Request Rendezvous Final Attitude maneuver (R63)
90	Request Out of Plane Rendezvous display (R36)
91	Display BANKSUM
92	Spare
93	Enable W matrix initialization
94	Perform Cislunar Attitude maneuver
95	Spare
96	Terminate integration and go to P00
97	Please perform engine-fail (R40)
98	Spare
99	Please Enable Engine Ignition

## LIST OF NOUNS USED IN PROGRAM COLOSSUS

00	Not in use	
01	Specify address (fractional)	.XXXXXX fractional .XXXXXX fractional .XXXXXX fractional
02	Specify address (whole)	XXXXXX. integer XXXXXX. integer XXXXXX. integer
03	Specify address (degree)	XXX.XX deg XXX.XX deg XXX.XX deg
04	Spare	
05	Angular error/difference	XXX.XX deg
06	Option code ID Option code	Octal Octal
07	CHANNEL/FLAGWORD/ERASABLE OPERATOR	
	ECADR	Octal
	BIT ID	Octal
	Action	Octal
08	Alarm data	
	ADRES	Octal
	BBANK	Octal
	ERCOUNT	Octal
09	Alarm codes	
	First	Octal
	Second	Octal
	Last	Octal
10	Channel to be specified	Octal
11	TIG of CSI	00XXX. h 000XX. min 0XX.XX s
12	Option code (extended verbs only)	Octal Octal
13	TIG of CDH	00XXX. h 000XX. min 0XX.XX s
14	Specified inertial velocity at TLI cutoff (VI C/O)	XXXXXX,ft/s
15	Increment address	Octal
16	Time of event (used by extended verbs only)	00XXX. h 000XX. min 0XX.XX s
17	Astronaut total attitude	R XXX.XX deg P XXX.XX deg Y XXX.XX deg

## LIST OF NOUNS USED IN PROGRAM COLOSSUS

18	Desired automaneuver FDAO ball angles	R XXX.XX deg P XXX.XX deg Y XXX.XX deg
19	Spare	
20	Present ICDDU angles	R (OG) XXX.XX deg P (IG) XXX.XX deg Y (MG) XXX.XX deg
21	PIPA's	X XXXXXX. pulses Y XXXXXX. pulses Z XXXXXX. pulses
22	Desired ICDDU angles	R (OG) XXX.XX deg P (IG) XXX.XX deg Y (MG) XXX.XX deg
23	Spare	
24	Delta time for AGC clock	00XXX. h 000XX. min 0XX.XX s
25	CHECKLIST (used with V50)	XXXXXX.
26	PRIOR/DELAY, ADRES, BBCON	Octal Octal Octal
27	Self-test on/off switch	XXXXXX.
28	Spare	
29	XSM launch azimuth	XXX.XX deg
30	Target codes	XXXXXX. XXXXXX. XXXXXX.
31	Time of rendezvous W matrix initialization	00XXX. h 000XX. min 0XX.XX s
32	Time from perigee	00XXX. h 000XX. min 0XX.XX s
33	Time of ignition (GETI)	00XXX. h 000XX. min 0XX.XX s
34	Time of event	00XXX. h 000XX. min 0XX.XX s
35	Time from event	00XXX. h 000XX. min 0XX.XX s
36	Time of AGC clock	00XXX. h 000XX. min 0XX.XX s

## LIST OF NOUNS USED IN PROGRAM COLOSSUS

37	Time of ignition {TPI}	00XXXX. h 00XXX. min 0XX.XX s	54	Range Range rate Theta	XXXX.XX nmi XXXX.X ft/s XXXX.XX deg
38	Time of state being integrated	00XXXX. h 00XXX. min 0XX.XX s	55	Perigee code Elevation angle Central angle of passive vehicle	00000X. XXXX.XX deg XXXX.XX deg
39	Delta time for transfer	00XXXX. h 00XX.X min 0XX.XX s	56	Rentry angle Delta V	XXXX.XX deg XXXXXX. ft/s
40 *	Time from ignition/cutoff (TFI/TFC) VG	XXX b XXX min/s XXX.XX. ft/s XXX.XX. ft/s	57	Spare	XXXXXX.X nmi XXXX.X ft/s XXXX.X ft/s
41	Target		58	Pericenter altitude (post TPI) Delta V (TP1) Delta V (TPF)	XXXXXX.X ft/s XXXXXX.X ft/s XXXXXX.X ft/s
42	Apocenter altitude Pericenter altitude Delta V (required)	XXXX.XX deg XX.XXXX deg XXXX.XX nmi XXXX.XX nmi XXXX.XX ft/s	59	Delta V LOS 1 Delta V LOS 2 Delta V LOS 3	XXXXXX.X ft/s XXXXXX.X ft/s XXXXXX.X ft/s
43	Latitude Longitude Altitude	XXXX.XX deg (+ north) XXXX.XX deg (+ east) XXXX.XX nmi	60	GMAX VRFED GAMMA EI	XXXXXX.g XXXXXX ft/s XXXX.XX deg (+ above)
44 *	Apocenter altitude Pericenter altitude TFF	XXXX.XX nmi XXXXXX.X nmi XXX b XXX min/s	61	Impact Latitude Longitude	XXXXXX deg (+ north) XXXXXX deg (+ east)
45 *	Marks (VHF/optics) Time from ignition of next burn Middle gimbal angle	XXX b XX marks XXX b XX min/s XXX.XX deg	62	Inertial velocity magnitude Altitude rate Altitude above pad radius	XXXXXX ft/s XXXXXX ft/s XXXXXX.X nmi
46	DAP configuration	Octal	63 *	Range from E1 altitude to splash Predicted inertial velocity Time from E1 altitude	XXXXXX.X nmi XXXXXX ft/s XXX b XX min/s
47	CSM weight LM weight	XXXXXX. lbs XXXXXX. lbs	64	Drag acceleration Inertial velocity Range to splash	XXXXXX.g XXXXXX ft/s XXXXXX.X nmi (+ is overshoot)
48	Gimbal pitch trim Gimbal yaw trim	XXX.XX deg XXX.XX deg	65	Sampled AGC time (fetched in interrupt)	00XXXX. h 000XXX.min 0XX.XX s
49	Delta R Delta V VHF or optics code	XXXX.XX nmi XXXX.XX ft/s 00000X.	66	Commanded bank angle Crossrange error Downrange error	XXXXXX deg XXXXXX.X nmi (+ south) XXXXXX.X nmi (+ overshoot)
50 *	Splash error Perigee TFF	XXXX.XX nmi XXXXXX.X nmi XXX b XX min/s	67	Range to target Present latitude Present longitude	XXXXXX.X nmi (+ overshoot) XXXXXX deg (+ north) XXXXXX deg (+ east)
51	S-band antenna angles (RHO) (GAMMA)	XXXX.XX deg XXXXXX deg	68	Commanded bank angle Inertial velocity Altitude rate	XXXXXX deg XXXXXX ft/s XXXXXX ft/s
52	Central angle of active vehicle	XXXX.XX deg	69	Commanded bank angle Drag level Exit velocity	XXXXXX deg XXXXXX g XXXXXX ft/s
53	Range Range rate Phi	XXXX.XX nmi XXXXXX.X ft/s XXXX.XX deg			

\*Display cannot be changed via data load (that is, V25NXXE, and so forth)

\*Display cannot be changed via data load (that is, V25NXXE, and so forth)







**FLAGWORD BIT ASSIGNMENTS (ALPHABETICAL)  
FOR COLOSSUS**

STRUULLSW	FW6	B13	VERIFLAG	FW7	B3
SURFFLAG	FW8	B8	VFLAG	FW3	B10
SWTOVER	FW9	B15	VHFRFLAG	FW9	B9
S32.1F1	FW11	B15	VINTFLAG	FW3	B3
S32.1F2	FW11	B14	VNFLAG	FW4	B2
S32.1F3A	FW11	B13	V37FLAG	FW7	B6
S32.1F3B	FW11	B12	V50N18FL	FW3	B15
TARG1FLG	FW1	B10	V59FLAG	FW5	B12
TARG2FLG	FW1	B9	V82EMFLG	FW9	B13
TERMIFLG	FW7	B15	V94FLAG	FW9	B11
TFFSW	FW7	B1	V96ONFLG	FW8	B3
TIMRFLAG	FW7	B11	XDELVFLG	FW2	B8
TPIMNFLG	FW10	B3	XDSPFLAG	FW4	B1
TRACKFLG	FW1	B5	ZMEASURE	FW0	B10
UPDATFLG	FW1	B7	.05GSW	FW6	B3
UPLOCKFL	FW7	B4	22DSPFLG	FW2	B13
UTFLAG	FW8	B9	360SW	FW8	B1
VEHUPFLG	FW1	B8	3AXISFLG	FW5	B6

**FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS**

**(FLAGWORD 0) E Address 74**

Bit	Name	1	0
1	P29FLAG	First pass through P29.	Subsequent pass through P29.
2	AMOONFLG	State vector in lunar sphere at MIDTOAVE.	State vector in earth sphere at MIDTOAVE.
3	FREEFLAG	(Temporary flag used in many routines.)	
4	CYC61FLG	KALCMANU computes maneuver time.	KALCMANU executes maneuver.
5	F2RTE	In time critical mode.	Not in time critical mode.
6	R53FLAG	V51 initiated.	V51 not initiated.
7	RNDVZFLG	P20 rendezvous option running.	P20 rendezvous option not running.
8	IMUSE	IMU in use.	IMU not in use.
9	NEEDLFLG	Total attitude error displayed.	A/P following error displayed.
10	ZMEASURE	Measurement planet and primary planet different.	Measurement planet and primary planet same.
11	NORFHOR	Far horizon.	Near horizon.
12	MOONFLAG	Moon is sphere of influence.	Earth is sphere of influence.
13	MIDFLAG	Integration with solar perturbations.	Integration without solar perturbations.
14	JSWITCH	Integration of W matrix.	Integration of state vector.
15	Not Used		

**(FLAGWORD 1) E Address 75**

Bit	Name	1	0
1	AVEGFLAG	AVERAGEG (SERVICER) to continue.	AVERAGEG (SERVICER) to cease.
2	GUESSW	No starting value for iteration exists.	Starting value for iteration exists.
3	SLOPESW	Iterate with bias method in iterator.	Iterate with Regula Falsi method in iterator.
4	MARKFLG	Mark accepted. Mark reject is ok.	No mark accepted.
5	TRACKFLG	Tracking allowed.	Tracking not allowed.
6	IDLEFAIL	Inhibit R40.	Enable R40 (engine fail).
7	UPDATFLG	Updating by marks allowed.	Updating by marks not allowed.
8	VEHUPFLG	CSM state vector being updated.	LM state vector being updated.
9	TARG2FLG	Sighting landmark.	Sighting star.
10	TARG1FLG	Sighting LM.	Not sighting LM.
11	ENG2FLAG	RCS burn.	SPS burn.
12	NODOP01	P01 not allowed.	P01 allowed.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

(FLAGWORD 1) (Continued)

Bit	Name	1	0
13	ERADFLAG	EARTH—compute Fischer ellipsoid radius. MOON—use mean Lunar radius.	EARTH—use Launch site radius. MOON—use RLS for lunar radius.
14	STIKFLAG	RHC control or MGA $> 75^\circ$ and P20 track inhibited.	AGC control and MGA $< 75^\circ$
15	NJETSFLG	Two-jet RCS burn.	Four-jet RCS burn.

(FLAGWORD 2) E Address 76

Bit	Name	1	0
1	NODOFLAG	V37 not permitted.	V37 permitted.
2	CALCMAN2	Perform maneuver starting procedure.	Bypass starting procedure.
3	P24MKFLG	New mark from SXT mark.	No marking done.
4	PFRATFLG	Preferred attitude computed.	Preferred attitude not computed.
5	AVFLAG	LM is active vehicle.	CSM is active vehicle.
6	FINALFLG	Last pass through rendezvous program computations.	Interim pass through rendezvous program computations.
7	FIRSTFLG	First pass through S40.9.	Succeeding pass through S40.9.
	ETPIFLAG	Elevation angle supplied for P34/74.	TPI time supplied for P34/P74.
8	XDELVFLG	External Delta V VG computation.	Lambert (AIMPOINT) VG computation.
9	IMPULSW	Minimum impulse burn (cutoff time specified).	Steering burn (no cutoff time yet available).
10	SKIPVHF	Disregard radar read because of software or hardware RESTART.	Radar read to proceed normally.
11	STEERSW	Steering to be done (P40). Calculate time to SIVB cutoff (P15).	Steering omitted (P40). Calculate time to SIVB ignition (P15).
12	P21FLAG	Succeeding pass through P21, use base vector for calculation.	First pass through P21, calculate base vector.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

(FLAGWORD 2) (continued)

Bit	Name	1	0
13	22DPSFLG	Display DR, DV.	Do not display DR, DV.
14	R21MARK	Rendezvous optics marking active.	Rendezvous optics marking not active.
15	DRIFTFLG	T3RUPT calls gyro compensation.	T3RUPT does no gyro compensation.

(FLAGWORD 3) E Address 77

Bit	Name	1	0
1	DIM0FLAG	W matrix is to be used.	W matrix is not to be used.
2	D60R9FLG	Dimension of W is 9 for integration.	Dimension of W is 6 for integration.
3	VINTFLAG	CSM state vector being integrated.	LM state vector being integrated.
4	INTYPFLG	Conic integration.	Encke integration.
5	STATEFLG	Permanent state vector being updated.	Permanent state vector not being updated.
6	ORBWFLAG	W matrix valid for orbital navigation.	W matrix invalid for orbital integration.
7	CULTFLAG	Star occulted.	Star not occulted.
8	PRECIFLG	CSMPREC, LEMPREC, or INTEGRVS called.	INTEGRV called.
9	POOFLAG	Inhibit backwards integration.	Allow backwards integration.
10	VFLAG	Less than two stars in the field of view.	Two stars in the field of view.
11	P22MKFLG	P22/P24 downlinked mark data was just taken.	P22/P24 downlinked mark data not just taken.
12	LUNAFLAG	Lunar latitude-longitude.	Earth latitude-longitude.
13	REFSMFLG	REFSMMAT good.	REFSMMAT no good.
14	GLOKFAIL	Desired middle gimbal angle exceeds $60^\circ$ .	Desired middle gimbal angle is less than $60^\circ$ .
15	V50N18FL	Inhibit R60 attitude maneuver.	Enable R60 attitude maneuver.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

## (FLAGWORD 4) E Address 100

Bit	Name	Value	Description	Bit	Name	Value	Description
1	XDSPFLG	1	Mark display not to be interrupted.	0		0	Maneuver specified by one axis.
2	VNFLAG		GOFLASH display	6	3AXISFLG	1	Maneuver specified by three axes.
3	MKOVFLAG		Mark display over normal display.	7	ENGONFLG		Engine turned on.
4	NRUPTFLG		Normal display interrupted by priority or mark display.	8	COMPUTER		Not used in program.
5	MRUPTFLG		Mark display interrupted by priority display.	9	DMENFLG		Dimension of W is 6 for incorporation.
6	PINBRFLG		Astronaut has interfered with existing display.	10	NEWTFLAG		Display normal.
7	PRONYFLG		Astronaut using keyboard when priority display initiated.	11	INCORFLG		Second incorporation.
8	NRMNVFLG		Astronaut using keyboard when normal display initiated.	12	V59FLAG		First incorporation.
9	MRKNVFLG		Astronaut using keyboard when mark display initiated.	13	SLOWFLG		Calibrating for P23.
10	NWAITFLG	1	Astronaut not using keyboard when mark display initiated.	14	RETROFLG		P37 transearth coast slowdown is desired.
11	MWAITFLG		No higher priority display operating when normal display initiated.	15	DSKYFLAG		Orbit is not retrograde.
12	PDSPFLAG		No higher priority display operating when mark display initiated.				Displays sent to DSKY.
13	NRMIDFLG		Higher priority display operating when mark display initiated.				No displays to DSKY.
14	PRIODFLG		Cannot interrupt priority display.				(FLAGWORD 6) E Address 102
15	MRKIDFLG		No normal display in ENDIDLE.	Bit	Name	Value	
			No priority display in ENDIDLE.	1	GYMDIFSW	0	CDU differences and body rates computed.
			No mark display in ENDIDLE.	2	CMDSTBY	1	ENTRY DAP activated.
				3	.05GSW		Drag over 0.005 g.
				4	LATSW		Downlift not inhibited.
				5	INRLSW		Initial roll V(LV) attitude not held.
				6	HIND		Iterating of HUNTEST calculations to be done after range prediction.
				7	NOSWITCH	0	Lateral roll maneuver inhibited in ENTRY.
				8	KNOWNFLG		Landmark known.
				9	LEVELSW		In final entry phase.
							Targeting uses earth-relative velocity.
							(FLAGWORD 5) E Address 101
1	RENDWFLG	1	W matrix invalid for rendezvous navigation.	Bit	Name	Value	
2	Not Assigned			1	W matrix valid for rendezvous navigation.	0	
3	SOLNSW		Lambert converges or time-radius noncircular.	2			
4	Not Assigned			3			
5	GRRBKFLG		Backup liftoff received.	4			
				5			

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

## (FLAGWORD 5) (continued)

FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS  
(FLAGWORD 6) (continued)

Bit	Name	1	0
10	GONEPAST	Lateral control calculations to be omitted.	Lateral control calculations to be done.
11	GAMDIFSW	Calculate GAMDOT.	GAMDOT not to be calculated.
12	CMDAPARM	Allow ENTRY firings and calculations.	Inhibit ENTRY firings and control functions.
13	ENTRYDSP	Do ENTRY display via ENTRYVN.	Omit ENTRY display.
	STRUULLSW	Do STEERULL.	Do ULAGEOFF only.
14	DAPBIT2	B14 0   1   0   1	
15	DAPBIT1	B15 0   0   1   1	DAP selection indicator.
	A/P	None RCS TVC Saturn	

## (FLAGWORD 7) E Address 103

Bit	Name	1	0
1	TFFSW	Calculate TPERIGEE.	Calculate TFF.
2	ATTCHFLG	LM, CM attached.	LM, CM not attached.
3	VERIFLAG	Changed when V33E occurs at end of P27.	
4	UPLOCKFL	K-K-K fail.	No K-K-K fail.
5	Not Assigned		
6	V37FLAG	AVERAGEG (SERVICER) running.	AVERAGEG (SERVICER) off.
7	Not Assigned		
8	GONEBY	Passed target.	Approaching target.
9	RVSW	Do not compute final state vector in time-theta.	Compute final state vector in time-theta.
10	NORMSW	Unit normal input to Lambert.	Lambert computes its own unit normal.
11	TIMRFLAG	CLOKTASK operating.	CLOKTASK inoperative.
12	ASTNFLAG	Astronaut has OKed ignition.	Astronaut has not OKed ignition.
13	IGNFLAG	TIG has arrived.	TIG has not arrived.
14	ITSWICH	Accept next Lambert TPI search solution.	Test Lambert answer against limits.
15	TERMFILG	Terminate R52.	Do not terminate R52.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

(FLAGWORD 8) E Address 104			
Bit	Name	1	0
1	360SW	Transfer angle near 360 degrees.	Transfer angle not near 360 degrees.
2	R67FLAG	R67 rotation active.	R67 rotation inactive.
3	V96ONFLG	P00 integration has been inhibited by V96	P00 integration is proceeding regularly.
4	COGAFLAG	No conic solution, too close to rectilinear (COGA overflows).	Conic solution exists, (COGA does not overflow.)
5	APSESW	RDESIRED outside of PERICENTER-APOCENTER range in time-radius.	RDESIRED inside of PERICENTER-APOCENTER range in time-radius.
6	ORDERSW	Iterator uses second order minimum mode.	Iterator uses first order standard mode.
7	INFINFLG	No conic solution (closure through infinity required).	Conic solution exists.
8	SURFFLAG	LM on lunar surface.	LM not on lunar surface.
9	UTFLAG	P20 option 1,2, or 5 selected.	P20 option 0 or 4 selected.
10	ADVTRK	Advance ground track sighting wanted.	No advanced ground track.
11	LMOONFLG	Permanent LM state vector in lunar sphere.	Permanent LM state vector in earth sphere.
12	CMOONFLG	Permanent CSM state vector in lunar sphere.	Permanent CSM state vector in earth sphere.
13	NEWIFLG	First pass through integration.	Succeeding iteration of integration.
14	NEWLMFLG	Delay rate computation after new landmark update.	Delay completed.
15	RPQFLAG	RPQ not computed. (RPQ = vector between secondary body and primary body.)	RPQ computed.
(FLAGWORD 9) E Address 105			
Bit	Name	1	0
1	AVEMIDSW	AVETOMID calling for W matrix integration. Do not overwrite RN, VN, PIPTIME.	No AVETOMID W matrix integration. Allow setup of RN, VN, PIPTIME.
2	MIDAVFLG	Integration entered from one of MIDTOAV portals.	Integration was not entered via MIDTOAV.
3	MID1FLAG	Integrate to TDEC.	Integrate to the then-present time.
4	R31FLAG	R31 selected (V83).	R34 selected (V85).
5	QUITFLAG	Terminate and exit from integration.	Continue integration.
6	N22ORN17	Compute total attitude errors with respect to N22 (V62).	Compute total attitude errors with respect to N17 (V63).

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

## (FLAGWORD 9) (continued)

Bit	Name	1	0
7	R22CAFGLG	R22 is processing an optics mark.	R22 is not processing an optics mark.
8	SOURCFLG	Source of input data is from VHF radar.	Source of input data is from optics mark.
9	VHFRFLAG	Allow R22 to accept range data.	Stop acceptance of range data.
10	SAVECFLG	P23 display and data storage after mark is done.	P23 display and data storage before mark is done.
11	V94FLAG	V94 allowed during P23.	V94 not allowed.
12	MAXDBFLG	Maximum A/P deadband selected.	Minimum A/P deadband selected.
13	V82EMFLG	Moon vicinity.	Earth vicinity.
14	P24FLAG	P24 operating.	P24 not operating.
15	SWTOVER	Switchover has occurred.	No switchover yet

## (FLAGWORD 10) E Address 106

Bit	Name	1	0
1	PCFLAG	Plane change maneuver being targeted.	Not plane change targeting.
2	FULTKFLG	Optics or VHF marks being taken.	Optics and VHF marks being taken.
3	TPIMNFLG	TPI targeting complete.	TPI targeting not complete.
4	PTV93FLG	W matrix to be initialized after maneuver.	W matrix initialized
5	MANEUFLG	No mark incorporation since targeting completed.	Mark incorporated.
6	Not Assigned		
7	AUTOSEQ	MINKEY auto-rendezvous.	Manual rendezvous.
8	P35FLAG	MCC targeting completed.	MCC targeting not completed.
9	RANGFLAG	Range < 327.67 nmi.	Range > 327.67 nmi.
10	BURNFLAG	CSM performed burn.	LM performed burn.
11	HDSUPFLG	Heads-up tracking attitude.	Heads-down tracking attitude.
12	REJCTFLG	Reject mark data being processed by R22.	No mark rejected.
13	REINTFLG	Restartable integration in process.	No restartable integration in process.
14	INTFLAG	Integration in process.	Integration not in process.
15	PCMANFLG	Maneuver is post plane change or P79.	Not post plane change or P79 maneuver.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

## (FLAGWORD 11) E Address 107

Bit	Name	1	0
1-5	Not Assigned		
6	CSISFLAG	Multiple CSI targeting.	Not multiple CSI.
7	HAFLAG	Height adjustment targeting.	Not height adjustment maneuver.
8	AZIMFLAG	Three-axis tracking maneuver.	Vecpoint tracking maneuver.
9-11	Not Assigned		
12	S32.1F3B	(Bits 12 and 13 function as an ordered pair (13, 12) indicating the possible occurrence of two Newton iterations for S32.1:	
13	S32.1F3A		
14	S32.1F2	First pass of Newton iteration.	Reiteration of Newton.
15	S32.1F1	Delta V at CSI Time 1 exceeds maximum.	Delta V at CSI Time 1 less than maximum.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

IMODES30, a flag whose individual bits are used to control the monitoring of IMU functions associated with Channel 30 (and in a few cases Channel 33).

Bit	Meaning
15	Last sampled value of Channel 30, Bit 15 (0 if IMU temperature within limits).
14	Last sampled value of Channel 30, Bit 14 (0 if ISS has been turned on or commanded to be turned on).
13	Last sampled value of Channel 30, Bit 13 (0 if an IMU fail indication has been produced).
12	Last sampled value of Channel 30, Bit 12 (0 if an IMU CDU fail indication has been produced).
11	Last sampled value of Channel 30, Bit 11 (0 if an IMU cage command has been produced by crew).
10	Last sampled value of Channel 33, Bit 13 (0 if a PIPA fail indication has been produced), having the same value as Bit 13 of IMODES33.
9	Last sampled value of Channel 30, Bit 9 (0 if IMU has been turned on and operating with no malfunctions).
8	Bit used to control the IMU turn-on sequencing.
7	Bit used to control the IMU turn-on sequencing.
6	Bit is set to 1 to indicate that IMU initialization is being carried out. No Verb 37 inputs will be processed while bit is equal to 1 and alarm 01520 <sub>8</sub> is generated.
5	Bit is set to 1 to inhibit the generation of program alarm 0212 <sub>8</sub> if a PIPA fail signal (Bit 13 of Channel 33) is produced.
4	Bit is set to 1 to inhibit generation of an ISS warning based on receipt of an IMU fail signal.
3	Bit is set to 1 to inhibit generation of an ISS warning based on receipt of an IMU CDU fail signal.
2	Bit is set to 1 to indicate failure of the turn-on delay sequence for IMU turn-on (alarm 0207 <sub>8</sub> is also generated).
1	Bit is set to 1 to inhibit generation of an ISS warning based on receipt of a PIPA fail signal (Bit 13 of Channel 33).

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

IMODES33, a flag whose individual bits are used to control the monitoring of functions associated with Channel 33 (and other items).

Bit	Meaning
15	Not assigned.
14	Last sampled value of Channel 32, Bit 14 (0 if a Proceed command is given using the PRO button).
13	Last sampled value of Channel 33, Bit 13 (0 if a PIPA fail has been produced).
12	Last sampled value of Channel 33, Bit 12 (0 if a telemetry end pulse has been rejected because the downlink rate is too fast).
11	Last sampled value of Channel 33, Bit 11 (0 if an uplink bit has been rejected because the uplink rate is too fast).
10-7	Not assigned.
6	Bit is set to 1 to indicate that IMU use for vehicle attitude information should not be attempted.
5	Bit is set to 1 in IMU Zeroing routine external to T4RUPT while zeroing is taking place (for an interval of about 8.22 seconds).
4-2	Not assigned.
1	Bit is set to 1 when a Verb 35 ("lamp test") is received, and reset to 0 about 5 seconds later.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

OPTIMODES, a flag whose individual bits are used to control the performance of optics functions within the T4RUPT package.

Bit	Meaning
15-11	Not Assigned
10	Bit is set to 1 to indicate that zeroing of optics has been completed since the last FRESH START or RESTART (both of which set the bit to 0). If an attempt is made to drive the optics and this bit is found to be zero, alarm 01208 is generated (but computation proceeds).
9	Not assigned.
8	Not assigned.
7	Last sampled value of Channel 30, Bit 7 (0 if an optics CDU fail indication has been generated by the optics CDU hardware). If Bit 2 of this word is 0, a Tracker alarm (Bit 8 of DSPTAB + 11) is generated if this bit has a 1 to 0 transition. Bit is set to 1 by a FRESH START or RESTART.
6	Not assigned.
5	Last sampled value of Channel 33, Bit 5 (0 if Optics Mode switch is set to CMC). Also may be value of C31FLWRD, Bit 5 if backup indicator is used.
4	Last sampled value of Channel 33, Bit 4 (0 if Optics Zero switch set to Zero). If Bits 5-4 = 112, the Optics Mode switch has been set to Manual. Also may be value of C31FLWRD, Bit 4 if backup indicator is used.
3	Bit is set to 1 when the Optics Zero switch is changed to Zero to indicate that zeroing of the optics is in progress.
2	If bit is 1, then a switch out of Zero Optics mode will cause alarm 01168 to be generated (if switched to Manual a "grace period" of about 5.3 seconds is provided before the optics-zeroing time counter is reset, during which time a switchback to optics zeroing can be made). Bit remains 1 for about 16.2 seconds, and is then reset to 0 (at the same time that Bit 10 of this word is set to 1, and Bit 2 of this word is set to 0).
1	Not assigned.

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

RCSFLAGS, a flag whose individual bits are used in monitoring the RCS DAP.

Bit	Meaning
15	Bit is set to 1 to indicate that a high rate (2 deg/s) automaneuver is in progress. Bit is reset to 0 to indicate that a high rate automaneuver is not in progress.
14	Bit is set to 1 if rate estimates are not good and a repeat of the rate filter initialization is required. Bit is reset to 0 if the G & N is in control and the IMU data is usable. Approximately 1 second after the bit is reset to 0 the rate filter initialization is complete.
13	Bit is set to 1 if the rate damping has not been completed on the roll axis. Bit is reset to 0 if the rate damping on the roll axis has been completed.
12	Bit is set to 1 if the rate damping has not been completed on the pitch axis. Bit is reset to 0 if the rate damping has been completed on the pitch axis.
11	Bit is set to 1 if the rate damping has not been completed on the yaw axis. Bit is reset to 0 if the rate damping has been completed on the yaw axis.
10,9	If either or both bits have been set to 1, there has been a change in the RHC roll command since the last DAP cycle. If both bits are reset to 0, it implies that no change in the RHC roll command has occurred since the last DAP cycle.
8,7	If either or both bits have been set to 1, there has been a change in RHC yaw command since the last DAP cycle. If both bits are reset to 0, it implies that no change in the RHC yaw command has occurred since the last DAP cycle.
6,5	If either or both bits have been set to 1, there has been a change in the RHC pitch command since the last DAP cycle. If both bits are reset to 0, it implies that no change in the RHC pitch command has occurred since the last DAP cycle.
4	Bit is set to 1 to indicate that the AK values should be updated. Bit is reset to 0 to indicate that the Needle Drive routine should be processed with the AK values which have been previously acquired.
3,2	If (Bit 3, Bit 2) = (1,1) or (1,0), it is necessary to follow the initialization path of the Needle Drive routine.
	If (Bit 3, Bit 2) = (0, 1), it is necessary to follow Pass 2 of the Needle Drive routine.
	If (Bit 3, Bit 2) = (0, 0), it is necessary to follow Pass 3 and greater paths of the Needle Drive routine.
1	Bit is set to 1 to indicate that the initial pass path in the T6 program should not be followed. Bit is reset to 0 if the T6 program should be initialized.

C31FLWRD, a flag used to determine if the channel representations of the CMC Mode switch, SC CONTROL switch and OPTICS ZERO switch are to be used or if backup indicators are to be used. Octal representation is AXXDX where:

## A VALUE

0 or 4	Bits 13, 14, 15 of Channel 31 are valid
1	CMC Control FREE
2	CMC Control HOLD
3	CMC Control AUTO
5	SCS Control FREE
6	SCS Control HOLD
7	SCS Control AUTO

## D VALUE

0 or 4	Bits 4, 5 of Channel 33 are valid
1 or 5	Optics Mode CMC
2 or 6	Optics Mode ZERO
3 or 7	Optics Mode Manual

C31FLWRD Switch override can be activated by:

V21N01E  
374E  
AXXDXE

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

## FLAGWORD BIT ASSIGNMENTS FOR COLOSSUS

DAPDATR1, a flagword for RCS-CSM DAP interface.

Bits	15-13	12-10	9-7	6-4	3-1
	CONFIG	XTAC	XTBD	DB	RATE
15-13	CONFIG:	Configuration			
			0	No DAP or ENTRY DAP	
			1	CSM	
			2	CSM/LM	
			3	CSM/SIVB	
			6	CSM/LM Ascent Stage Only	
12-10	XTAC:	X-translation using Quads AC			
			0	No AC	
			1	Use AC	
9-7	XTBD:	X-translation using Quads BD			
			0	No BD	
			1	Use BD	
6-4	DB:	Deadband			
			0	± 0.5 degree	
			1	± 5.0 degrees	
3-1	RATE:	Response to RHC, automatic maneuvers			
			0	0.05 degree/second	
			1	0.2 degree/second	
			2	0.5 degree/second	
			3	2.0 degrees/second	

DAPDATR2, a flagword for RCS-CSM DAP interface.

Bits	15-13	12-10	9-7	6-4	3-1
	AC-Roll	Quad A	Quad B	Quad C	Quad D
15-13	AC-Roll:	Roll jet selection			
			0	Use BD Roll	
			1	Use AC Roll	
12-10, 9-7, 6-4, 3-1	A, B, C, D Quad fails				
			0	Quad Failed	
			1	Quad OK	





## CHANNEL BIT ASSIGNMENTS (CM)

## INPUT CHANNEL 33

## BIT

1	Spare
2	Range Unit Data Good
3	Spare
4	Zero Optics
5	CMC Control
6	Not Used
7	Not Used
8	Spare
9	Spare
10	Block Uplink Input*
11	Uplink Too Fast
12	Downlink Too Fast
13	PIPA Fail
14	AGC Warning
15	AGC Oscillator Alarm

\*This bit reads ONE when accept uplink signal is present at interface.

## NOTE:

All of the input signals in Channel 33 are inverted; that is, a ZERO bit indicates that the discrete is ON.

## INPUT CHANNEL 77 – (RESTART MONITOR)

## BIT

1	Parity Fail (E or F)
2	Parity Fail (E memory)
3	TC Trap
4	RUPT Lock
5	Nightwatchman
6	Voltage Fail
7	Counter Fail
8	Scalar Fail
9	Scalar Double Frequency Alarm