




(these wires run to 120 VAC "station power" terminals at bottom of generator rack)




Automation Direct "trip" relay coil



Automation Direct "close" relay coil



Fuji contactor auxiliary contacts



(these two-conductor cables run to terminal blocks at bottom of generator rack)