

# **SEL-551 Relay**

## **Overcurrent Relay**

## **Reclosing Relay**

### **Instruction Manual**

20110408



**SCHWEITZER ENGINEERING LABORATORIES, INC.**



---

**⚠CAUTION**

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

---

**⚠CAUTION**

This procedure requires that you handle components sensitive to Electrostatic Discharge (ESD). If your facility is not equipped to work with these components, we recommend that you return the relay to SEL for firmware installation.

---

**⚠CAUTION**

There is danger of explosion if the battery is incorrectly replaced. Replace only with Ray-O-Vac® no. BR2335 or equivalent recommended by manufacturer. Dispose of used batteries according to the manufacturer's instructions.

---

**⚠CAUTION**

Verify proper orientation of the new EPROM in the socket before applying pressure to engage it. Note the orientation indication provided by the notched inside socket corner and the notched corner.

---

**⚠CAUTION**

Do not connect external voltages to the relay contact inputs. Because the contact inputs are internally wetted, permanent damage to the relay or external equipment may result from connecting external voltage to a relay contact input.

---

**⚠WARNING**

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

---

**⚠WARNING**

Operator safety may be impaired if the device is used in a manner not specified by SEL.

---

**⚠DANGER**

Contact with instrument terminals can cause electrical shock that can result in injury or death.

---

**⚠DANGER**

Contact with this circuitry may cause electrical shock that can result in injury or death. Removal of enclosure panels exposes circuitry which may cause electrical shock which can result in injury or death.

---

**⚠ATTENTION**

Le relais contient des pièces sensibles aux décharges électrostatiques. Quand on travaille sur le relais avec les panneaux avant ou du dessus enlevés, toutes les surfaces et le personnel doivent être mis à la terre convenablement pour éviter les dommages à l'équipement.

---

**⚠ATTENTION**

Cette procédure requiert que vous manipulez des composants sensibles aux décharges électrostatiques (DES). Si vous n'êtes pas équipés pour travailler avec ce type de composants, nous vous recommandons de les retourner à SEL pour leur installation.

---

**⚠ATTENTION**

Il y a un danger d'explosion si la pile électrique n'est pas correctement remplacée. Utiliser exclusivement Ray-O-Vac® No. BR2335 ou un équivalent recommandé par le fabricant. Se débarrasser des piles usagées suivant les instructions du fabricant.

---

**⚠ATTENTION**

Vérifier l'orientation du nouvel EPROM avant d'appliquer la pression pour l'insérer dans sa base. Noter l'orientation indiquée par le coin marqué à l'intérieur de la base et le coin marqué du composant.

---

**⚠ATTENTION**

Ne pas raccorder de tensions externes sur les bornes des entrées de contact. Parce que les contacts sont trempés au mercure, des dommages permanents peuvent résulter pour le relais ou l'équipement externe à la suite du raccordement d'une tension externe à une entrée de contact du relais.

---

**⚠AVERTISSEMENT**

Cet appareil est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accès non-autorisé à l'équipement peut être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accès non-autorisé.

---

**⚠AVERTISSEMENT**

La sécurité de l'opérateur peut être compromise si l'appareil est utilisé d'une façon non indiquée par SEL.

---

**⚠DANGER**

Tout contact avec les bornes de l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.

---

**⚠DANGER**

Tout contact avec ce circuit peut être la cause d'un choc électrique pouvant entraîner des blessures ou la mort. Le retrait des panneaux du boîtier expose le circuit qui peut causer des chocs électriques pouvant entraîner des blessures ou la mort.

© 1998–2011 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by US and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this manual is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language manual.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit [www.selinc.com](http://www.selinc.com) or contact your customer service representative. PM551-01

# Table of Contents

---

List of Tables .....	v
List of Figures .....	vii
Preface .....	ix
Manual Overview .....	ix
Conventions .....	x
<b>Section 1: Introduction and Specifications</b>	
Overview .....	1.1
SEL-551 Model Changes .....	1.2
SEL-551 Applications .....	1.2
Hardware Overview .....	1.3
Specifications .....	1.4
Overcurrent Elements .....	1.6
CT Saturation Protection .....	1.7
Timer Specifications .....	1.8
<b>Section 2: Installation</b>	
Overview .....	2.1
Relay Mounting .....	2.1
Rear-Panel Connections .....	2.5
SEL-551 AC/DC Connection Diagrams for Example Applications .....	2.9
EIA-485 Rear-Panel Adapter .....	2.14
Circuit Board Jumpers and Battery .....	2.15
<b>Section 3: Relay Elements and Logic</b>	
Relay Word Bits and SELOGIC Control Equations .....	3.1
Optoisolated Inputs .....	3.3
Local Control Switches .....	3.5
Remote Control Switches .....	3.7
Instantaneous Overcurrent Elements .....	3.8
Time-Overcurrent Elements .....	3.12
Trip Logic .....	3.17
Close Logic .....	3.20
Reclosing Relay .....	3.22
SELOGIC Control Equation Variables/Timers .....	3.38
Output Contacts .....	3.39
Demand Ammetering .....	3.41
Front-Panel Target LEDs .....	3.47
<b>Section 4: Setting the Relay</b>	
Overview .....	4.1
Settings Changes Via the Front Panel .....	4.1
Settings Changes Via the Serial Port .....	4.1
Time-Overcurrent Element Setting Reference Information .....	4.2
Relay Word Bit Setting Reference Information .....	4.14
Settings Explanations .....	4.18
Settings Sheets .....	4.20
<b>Settings Sheets for the SEL-551 Relay</b>	

## Section 5: Serial Port Communications and Commands

Overview .....	5.1
Port Connector and Communications Cables .....	5.1
Communications Protocol.....	5.4
Serial Port Automatic Messages .....	5.7
Serial Port Access Levels.....	5.8
Command Summary .....	5.9
Command Explanations .....	5.11

## SEL-551 Command Summary

## Section 6: Front-Panel Interface

Overview .....	6.1
Front-Panel Pushbutton Operation.....	6.1
Functions Unique to the Front-Panel Interface .....	6.4
Rotating Default Display .....	6.11

## Section 7: Standard Event Reports and SER

Overview .....	7.1
Standard 15-Cycle Event Reports .....	7.1
Sequential Events Recorder (SER) Event Report.....	7.8
Example Standard 15-Cycle Event Report .....	7.11
Example Sequential Events Recorder (SER) Event Report.....	7.17

## Section 8: Testing and Troubleshooting

Overview .....	8.1
Testing Methods and Tools .....	8.1
Acceptance Testing .....	8.4
Commissioning Testing .....	8.14
Maintenance Testing .....	8.15
Relay Self-Tests .....	8.16
Relay Troubleshooting.....	8.17
Relay Calibration .....	8.18
Factory Assistance .....	8.18

## Appendix A: Firmware and Manual Versions

Firmware .....	A.1
Instruction Manual .....	A.3

## Appendix B: Firmware Upgrade Instructions

EPROM Firmware Upgrades .....	B.1
Flash Firmware Upgrades .....	B.5

## Appendix C: SEL Distributed Port Switch Protocol

Overview .....	C.1
Settings.....	C.1
Operation .....	C.1

## Appendix D: Configuration, Fast Meter, and Fast Operate Commands

Overview .....	D.1
Message Lists.....	D.1
Message Definitions.....	D.2

## Appendix E: Compressed ASCII Commands

Overview .....	E.1
CASCI Command—General Format .....	E.1
CASCI Command—SEL-551 .....	E.3
CSTATUS Command—SEL-551 .....	E.3
CHISTORY Command—SEL-551 .....	E.4
CEVENT Command—SEL-551 .....	E.4

## Appendix F: Setting Negative-Sequence Overcurrent Elements

Setting Negative-Sequence Definite-Time Overcurrent Elements .....	F.1
Setting Negative-Sequence Time-Overcurrent Elements .....	F.1
Coordinating Negative-Sequence Overcurrent Elements .....	F.2
Other Negative-Sequence Overcurrent Element References .....	F.7

## Appendix G: Modbus RTU Communications Protocol

Overview .....	G.1
Modbus RTU Communications Protocol .....	G.1

**This page intentionally left blank**

# List of Tables

Table 1.1	Overcurrent Elements.....	1.6
Table 2.1	Required Control Voltage Jumper Positions for Applied Nominal Control Voltage (SEL-551 With the Conventional Terminal Blocks Option) .....	2.15
Table 2.2	Required Position of Jumper JMP13 for Desired Output Contact OUT4 Operation.....	2.17
Table 3.1	Processing Order of SELOGIC Control Equation Operators.....	3.1
Table 3.2	Processing Order of Relay Elements and Logic (Top to Bottom).....	3.3
Table 3.3	Correspondence Between Local Control Switch Positions and Label Settings.....	3.5
Table 3.4	Correspondence Between Local Control Switch Types and Required Label Settings.....	3.6
Table 3.5	Relay Word Bit and Front-Panel Correspondence to Reclosing Relay States .....	3.23
Table 3.6	Shot Counter Correspondence to Relay Word Bits and Open Interval Times .....	3.27
Table 3.7	Demand Ammeter Settings and Settings Range .....	3.43
Table 3.8	SEL-551 Front-Panel Target LED Definitions.....	3.47
Table 4.1	Serial Port SET Commands.....	4.1
Table 4.2	SET Command Editing Keystrokes.....	4.2
Table 4.3	Equations Associated With U.S. Curves .....	4.3
Table 4.4	Equations Associated With IEC Curves .....	4.3
Table 4.5	SEL-551 Relay Word Bits .....	4.14
Table 4.6	Relay Word Bit Definitions.....	4.14
Table 5.1	Serial Communications Port Pin Function Definitions .....	5.4
Table 5.2	Communications Settings.....	5.6
Table 5.3	Serial Port Automatic Messages .....	5.7
Table 5.4	Serial Port Command Summary.....	5.10
Table 5.5	ACC and 2AC Commands .....	5.11
Table 5.6	SEL-551 Relay Word and Its Correspondence to TAR Command and Front-Panel LEDs .....	5.21
Table 5.7	SEL-551 Control Subcommands.....	5.23
Table 5.8	Valid Password Characters .....	5.24
Table 7.1	Event Types .....	7.4
Table 7.2	Standard Event Report Current Columns .....	7.5
Table 7.3	Other Standard Event Report Columns .....	7.6
Table 7.4	SEL-551 Input/Output Event Report Columns .....	7.8
Table 7.5	SER Report Row Commands and Format.....	7.9
Table 8.1	Instantaneous Overcurrent Elements and Corresponding Settings/Relay Word Bits/TAR Commands .....	8.10
Table 8.2	Inverse-Time Overcurrent Elements and Corresponding Settings/Relay Word Bits/TAR Commands .....	8.12
Table 8.3	Relay Self Tests.....	8.16
Table 8.4	Troubleshooting Procedures.....	8.17
Table A.1	Firmware Revision History .....	A.1
Table A.2	Instruction Manual Revision History .....	A.3
Table D.1	Binary Message List.....	D.1
Table D.2	ASCII Configuration Message List.....	D.2
Table D.3	A5C0 Relay Definition Block.....	D.2
Table D.4	A5C1 Fast Meter Configuration Block .....	D.2
Table D.5	A5D1 Fast Meter Data Block.....	D.4
Table D.6	A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages.....	D.4
Table D.7	A5D2/A5D3 Demand/Peak Demand Fast Meter Message .....	D.5
Table D.8	A5CE Fast Operate Configuration Block.....	D.6
Table D.9	A5E0 Fast Operate Remote Bit Control.....	D.7
Table D.10	A5E3 Fast Operate Breaker Control .....	D.7
Table G.1	Modbus Query Fields .....	G.1
Table G.2	SEL-551 Modbus Function Codes .....	G.2
Table G.3	SEL-551 Modbus Exception Codes .....	G.2
Table G.4	01h Read Coil Status Commands.....	G.3

Table G.5	02h Read Input Status Command .....	G.4
Table G.6	03h Read Holding Register Command .....	G.5
Table G.7	04h Read Holding Register Command .....	G.5
Table G.8	05h Force Single Coil Command .....	G.6
Table G.9	SEL-551 Command Coils .....	G.6
Table G.10	06h Preset Single Register Command .....	G.7
Table G.11	07h Read Exception Status Command .....	G.7
Table G.12	08h Loopback Diagnostic Command .....	G.8
Table G.13	10h Preset Multiple Registers Command .....	G.9
Table G.14	64h Scattered Register Read Command .....	G.10
Table G.15	SEL-551 Modbus Command Region .....	G.11
Table G.16	Modbus Command Codes .....	G.11
Table G.17	Assign Event Report Channel Using Address 00B2 .....	G.13
Table G.18	Modbus Map .....	G.13

# List of Figures

Figure 1.1	SEL-551 Relays Applied Throughout the Power System.....	1.2
Figure 1.2	SEL-551 Inputs, Outputs, and Communications Port.....	1.3
Figure 1.4	SEL-551 Instantaneous Overcurrent Element Pickup Time Curve.....	1.7
Figure 1.5	SEL-551 Relay Instantaneous Overcurrent Element Reset Time Curve.....	1.7
Figure 2.1	SEL-551 Dimensions, Panel Cutout, and Drill Plan .....	2.2
Figure 2.2	Relay Dimensions and Drill Plan for Mounting Two SEL-500 Series Relays Together Using Mounting Block (SEL P/N 9101) .....	2.3
Figure 2.3	Relay Dimensions and Drill Plan for Mounting an SEL-551 With Rack Mount Bracket 9100 (Bracket on Right Side in Front View).....	2.4
Figure 2.4	SEL-551 Fitted with Mounting Bracket (SEL P/N 9100) for Mounting in 19-Inch Rack .....	2.4
Figure 2.5	SEL-551 Front Panel, Rack-Mount Version (Half-Rack Width).....	2.5
Figure 2.6	SEL-551 Front Panel, Panel-Mount Version .....	2.5
Figure 2.7	SEL-551 Rear Panel (Conventional Terminal Blocks Option) .....	2.6
Figure 2.8	SEL-551 Rear Panel (Plug-In Connectors Option).....	2.7
Figure 2.9	SEL-551 Provides Overcurrent Protection and Reclosing for a Utility Distribution Feeder (Includes Fast Bus Trip Scheme).....	2.9
Figure 2.10	SEL-551 Provides Overcurrent Protection for an Industrial Distribution Feeder (Core-Balance Current Transformer Connected to Current Input Channel IN).....	2.10
Figure 2.11	SEL-551 Provides Overcurrent Protection for a Delta-Wye Transformer Bank .....	2.11
Figure 2.12	SEL-551 Provides Overcurrent Protection for a Transformer Bank with a Tertiary Winding .....	2.12
Figure 2.13	SEL-551 Provides Overcurrent Protection for a Distribution Bus (Includes Fast Bus Trip Scheme) .....	2.13
Figure 2.14	SEL-551 Provides Dedicated Breaker Failure Protection.....	2.14
Figure 2.15	Input and Output Jumper Locations (SEL-551 Relay With the Conventional Terminal Blocks With Jumper-Selectable Control Input Voltage Option).....	2.16
Figure 2.16	Output Contact OUT4 Control Jumper Location.....	2.17
Figure 3.1	Example Operation of SEL-551 Optoisolated Inputs .....	3.3
Figure 3.2	Local Control Switches Drive Local Bits LB1–LB8 .....	3.5
Figure 3.3	Remote Control Switches Drive Remote Bits RB1–RB8 .....	3.8
Figure 3.4	Phase Instantaneous Overcurrent Elements 50P1–50P6.....	3.9
Figure 3.5	Single-Phase Instantaneous Overcurrent Elements 50A, 50B, and 50C.....	3.10
Figure 3.6	Neutral Ground Instantaneous Overcurrent Elements 50N1 and 50N2.....	3.10
Figure 3.7	Residual Ground Instantaneous Overcurrent Elements 50G1 and 50G2 .....	3.11
Figure 3.8	Negative-Sequence Instantaneous Overcurrent Elements 50Q1 and 50Q2 .....	3.11
Figure 3.9	Phase Time-Overcurrent Elements 51P1T and 51P2T.....	3.12
Figure 3.10	Neutral Ground Time-Overcurrent Element 51N1T .....	3.15
Figure 3.11	Residual Ground Time-Overcurrent Element 51G1T .....	3.15
Figure 3.12	Negative-Sequence Time-Overcurrent Elements 51Q1T and 51Q2T.....	3.16
Figure 3.13	Trip Logic.....	3.17
Figure 3.14	Close Logic .....	3.20
Figure 3.15	Reclosing Relay States and General Operation.....	3.22
Figure 3.16	Reclosing Sequence From Reset to Lockout With Factory Settings .....	3.25
Figure 3.17	Voltage Relay (27/59) Provides Reclose Block Signal to SEL-551 .....	3.32
Figure 3.18	Sequence Coordination Between the SEL-551 and a Line Recloser .....	3.35
Figure 3.19	Operation of SEL-551 Shot Counter for Sequence Coordination With Line Recloser (Additional Settings Example 1) .....	3.35
Figure 3.20	Operation of SEL-351 Relay Shot Counter for Sequence Coordination With Line Recloser (Additional Setting Example 2).....	3.37
Figure 3.21	SELOGIC Control Equation Variables/Timers .....	3.38
Figure 3.22	Dedicated Breaker Failure Scheme Created With SELOGIC Variables/Timers.....	3.39
Figure 3.23	Logic Flow for Example SEL-551 Output Contact Operation.....	3.40
Figure 3.24	Response of Thermal Demand Ammeter to a Step Input (Setting DMTC = 15 minutes).....	3.42
Figure 3.25	Voltage $V_S$ Applied to Series RC Circuit.....	3.43
Figure 3.26	Demand Current Logic Outputs .....	3.44
Figure 3.27	Raise Pickup of Residual Ground Time-Overcurrent Element for Unbalance Current .....	3.45

Figure 4.1	U.S. Moderately Inverse Curve: U1 .....	4.4
Figure 4.2	U.S. Inverse Curve: U2.....	4.5
Figure 4.3	U.S. Very Inverse Curve: U3.....	4.6
Figure 4.4	U.S. Extremely Inverse Curve: U4.....	4.7
Figure 4.5	U.S. Short-Time Inverse Curve: U5 .....	4.8
Figure 4.6	IEC Class A Curve (Standard Inverse): C1 .....	4.9
Figure 4.7	IEC Class B Curve (Very Inverse): C2 .....	4.10
Figure 4.8	IEC Class C Curve (Extremely Inverse): C3.....	4.11
Figure 4.9	IEC Long-Time Inverse Curve: C4 .....	4.12
Figure 4.10	IEC Short-Time Inverse Curve: C5 .....	4.13
Figure 5.1	Nine-Pin Serial Communications Port Connector.....	5.1
Figure 6.1	SEL-551 Front-Panel Pushbuttons—Overview .....	6.1
Figure 6.2	SEL-551 Front-Panel Pushbuttons—Primary Functions.....	6.2
Figure 6.3	SEL-551 Front-Panel Pushbuttons-Primary Functions (continued).....	6.3
Figure 6.4	SEL-551 Front-Panel Pushbuttons-Secondary Functions.....	6.4
Figure 6.5	Local Control Switch Configured as an ON/OFF Switch .....	6.7
Figure 6.6	Local Control Switch Configured as an OFF/MOMENTARY Switch .....	6.7
Figure 6.7	Local Control Switch Configured as an ON/OFF/MOMENTARY Switch.....	6.7
Figure 7.1	Example Event Summary .....	7.3
Figure 7.2	Example SEL-551 Standard 15-Cycle Event Report (1/8-Cycle Resolution).....	7.14
Figure 7.3	Derivation of Event Report Current Values and RMS Current Values From Sampled Current Waveform .....	7.15
Figure 7.4	Derivation of Phasor RMS Current Values From Event Report Current Values .....	7.16
Figure 7.5	Example Sequential Events Recorder (SER) Event Report .....	7.17
Figure 8.1	Low-Level Test Interface.....	8.2
Figure 8.2	Relay Part Number and Hardware Identification Sticker .....	8.5
Figure 8.3	Test Connections for Balanced Load With Three-Phase Current Sources .....	8.9
Figure 8.4	Test Connections for Balanced Load With Two-Phase Current Sources.....	8.9
Figure B.1	EPROM Socket.....	B.2
Figure B.2	Insertion of the Extraction Tool in the EPROM Socket .....	B.3
Figure B.3	Proper Orientation of the EPROM and EPROM Socket .....	B.3
Figure F.1	Minimum Response Time Added to a Negative-Sequence Time-Overcurrent Element .....	F.2
Figure F.2	Distribution Feeder Protective Devices .....	F.3
Figure F.3	Traditional Phase Coordination .....	F.4
Figure F.4	Phase-to-Phase Fault Coordination.....	F.5
Figure F.5	Negative-Sequence Overcurrent Element Derived From “Equivalent” Phase Overcurrent Element, 51EP .....	F.6

# Preface

---

## Manual Overview

---

The SEL-551 Relay Instruction Manual describes common aspects of relay application and use. It includes the necessary information to install, set, test, and operate the relay and more detailed information about settings and commands.

An overview of each manual section and topics follows:

**Preface.** Describes the manual organization and conventions used to present information.

**Section 1: Introduction and Specifications.** Describes the basic features and functions of the SEL-551; lists the relay specifications.

**Section 2: Installation.** Describes how to mount and wire the SEL-551; illustrates wiring connections for various applications.

**Section 3: Relay Elements and Logic.** Describes operating characteristics of elements through the use of logic diagrams and text and explains how to calculate their settings; describes contact output logic.

**Section 4: Setting the Relay.** Describes how to enter and record settings.

**Section 5: Serial Port Communications and Commands.** Describes how to connect the SEL-551 to a PC for communication; shows serial port pinouts; lists and defines serial port commands.

**Section 6: Front-Panel Interface.** Explains the features and use of the front panel, including front-panel command menu, default displays, and automatic messages.

**Section 7: Standard Event Reports and SER.** Describes event summary data, standard event reports, and Sequential Events Recorder (SER) report.

**Section 8: Testing and Troubleshooting.** Describes protection element test procedures, relay self-test, and relay troubleshooting.

**Section 9: Appendices.** Contains the following appendices:

*Appendix A: Firmware and Manual Versions*

*Appendix B: Firmware Upgrade Instructions*

*Appendix C: SEL Distributed Port Switch Protocol*

*Appendix D: Configuration, Fast Meter, and Fast Operate Commands*

*Appendix E: Compressed ASCII Commands*

*Appendix F: Setting Negative-Sequence Overcurrent Elements*

*Appendix G: Modbus RTU Communications Protocol*

**SEL-551 Command Summary.** Briefly describes the serial port commands that are fully described in *Section 5: Serial Port Communications and Commands*.

# Conventions

## Typographic Conventions

There are three ways to communicate with the SEL-551:

- Using a command line interface on a PC terminal emulation window.
- Using the front-panel menus and pushbuttons.
- Using ACSELERATOR QuickSet® SEL-5030 Software

The instructions in this manual indicate these options with specific font and formatting attributes. The following table lists these conventions:

### Typographic Conventions

Example	Description
<b>STATUS</b>	Commands typed at a command line interface on a PC.
<b>&lt;Enter&gt;</b>	Single keystroke on a PC keyboard.
<b>&lt;Ctrl+D&gt;</b>	Multiple/comboination keystroke on a PC keyboard.
<b>Start &gt; Settings</b>	PC software dialog boxes and menu selections. The > character indicates submenus.
<b>{CLOSE}</b>	Relay front-panel pushbuttons.
<b>ENABLE</b>	Relay front- or rear-panel labels.
<b>MAIN &gt; METER</b>	Relay front-panel LCD menus and relay responses visible on the PC screen. The > character indicates submenus.

## Examples

This instruction manual uses several example illustrations and instructions to explain how to effectively operate the SEL-551. These examples are for demonstration purposes only; the firmware identification information or settings values included in these examples may not necessarily match those in the current version of your SEL-551.

## Safety Information

This manual uses three kinds of hazard statements, formatted as follows:

### **⚠ CAUTION**

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury or equipment damage.

### **⚠ WARNING**

Indicates a potentially hazardous situation that, if not avoided, **could** result in death or serious injury.

### **⚠ DANGER**

Indicates an imminently hazardous situation that, if not avoided, **will** result in death or serious injury.

# Section 1

## Introduction and Specifications

---

### Overview

---

The SEL-551 Overcurrent Relay and Reclosing Relay provides overcurrent protection and up to four shots of reclosing in one compact package. The relay measures phase and neutral currents—no voltages.

#### SEL-551 Feature Highlights

- Numerous Phase, Ground, and Negative-Sequence Overcurrent Elements
- Multiple-Shot Reclosing Relay with Sequence Coordination
- Enhanced SELOGIC® Control Equations to Create Traditional or Advanced Schemes
- Local/Remote Control Logic to Enable/Disable Schemes, Operate Circuit Breakers, etc.
- Sequential Events Recorder (SER) Report and Event Reports Stored in Nonvolatile Memory
- Hardware Options for Rear-Panel Terminals, Output Contacts, and Serial Communications Port
- Demand Ammetering

#### Use the SEL-551 for Overcurrent Protection in New Installations and Retrofits

- Utility Distribution Feeders—includes reclosing
- Industrial Distribution Feeders—includes connections for a core-balance current transformer
- Distribution Buses—includes fast bus trip scheme
- Transformer Banks—includes connections for a separate neutral current transformer
- Other Power System Apparatus—capacitors, reactors, circuit breakers, etc.

#### Differences Between the SEL-551/SEL-551C Relays

The SEL-551C Relay differs from the SEL-551 Relay in the following major areas:

- Different I/O mix.


SEL-551	SEL-551C
5 output contacts (OUT1–OUT4, ALARM)	3 output contacts (OUT1–OUT3)
2 input contacts (IN1, IN2)	6 input contacts (IN1–IN6)

- Relay Word bit differences because of I/O mix and addition of programmable alarm conditions SALARM and HALARM.
- Latch Control Switches to Replace Traditional Latching Relays.
- Optional front-panel EIA-232 serial communications port.
- Available with conventional terminal blocks and level-sensitive optoisolated inputs (see *Specifications, General on page 1.4* for optoisolated inputs ratings).

## SEL-551 Model Changes

Old model 05510J has been superseded by model 05510W. This is because of improvements in the Connectorized® SEL-551 Relay (plug-in connectors)—see *Section 2: Installation* for more details (following *Figure 2.8*). Unless otherwise noted, references to model 05510W also apply to old model 05510J.

## SEL-551 Applications




① See *Figure 2.14*; ② see *Figure 2.11*; ③ see *Figure 2.13*; ④ see *Figure 2.9*; ⑤ see *Figure 2.10*.

**Figure 1.1 SEL-551 Relays Applied Throughout the Power System**

# Hardware Overview

- Rear-panel: conventional terminal blocks or plug-in connectors (see [Figure 2.7](#) and [Figure 2.8](#))
- High-current interrupting output contacts: 10 A for L/R = 40 ms at 125 Vdc (included in the rear-panel plug-in connectors option only—see [Figure 2.8](#))
- Rear-panel serial communications port: EIA-232 or EIA-485 (4-wire)-either option includes a demodulated IRIG-B time-code input (see [Figure 2.7](#) and [Figure 2.8](#))



① See [Figure 2.8](#); ② see [Figure 2.10](#); ③ see [Figure 2.11](#); ④ see [Figure 2.12](#); ⑤ see [Figure 2.9](#), [Figure 2.13](#), and [Figure 2.14](#).

**Figure 1.2 SEL-551 Inputs, Outputs, and Communications Port**

# Specifications

## General

### AC Input Currents

5 A nominal:	15 A continuous, 500 A for 1 s, linear to 100 A symmetrical.
Limiting Dynamic Value:	1250 A for 1 cycle (sinusoidal waveform)
Burden:	0.16 VA at 5 A 1.15 VA at 15 A
1 A nominal:	3 A continuous, 100 A for 1 s, linear to 20 A symmetrical.
Limiting Dynamic Value:	250 A for 1 cycle (sinusoidal waveform)
Burden:	0.06 VA at 1 A 0.18 VA at 3 A

### Power Supply

125/250 Vdc or Vac	
Range:	85–350 Vdc or 85–264 Vac
Burden:	<6.2 W
Interruption:	100 ms at 250 Vdc
Ripple:	100%
48/125 Vdc or 125 Vac	
Range:	36–200 Vdc or 85–140 Vac
Burden:	<5.5 W
Interruption:	100 ms at 125 Vdc
Ripple:	5%
24 Vdc	
Range:	16–36 Vdc polarity dependent
Burden:	<6.2 W
Interruption:	25 ms at 36 Vdc
Ripple:	5%

Note: Interruption and Ripple per IEC 60255-11:1979.

### Output Contacts

#### Conventional Terminal Blocks Option:

Per IEC 255-0-20:1974, using the simplified method of assessment

Make:	30 A
Carry:	6 A continuous carry
1 s Rating:	100 A
MOV Protection:	270 Vac/360 Vdc
Pickup Time:	<5 ms
Dropout Time:	<5 ms

#### Breaking Capacity (10000 operations):

24 V	0.75 A	L/R = 40 ms
48 V	0.50 A	L/R = 40 ms
125 V	0.30 A	L/R = 40 ms
250 V	0.20 A	L/R = 40 ms

#### Cyclic Capacity (2.5 cycle/second):

24 V	0.75 A	L/R = 40 ms
48 V	0.50 A	L/R = 40 ms
125 V	0.30 A	L/R = 40 ms
250 V	0.20 A	L/R = 40 ms

#### Plug-In Connectors Option on SEL-551 (High Current Interrupting):

Make:	30 A
Carry:	6 A continuous carry
MOV Protection:	330 Vdc
Pickup Time:	<5 ms

Dropout Time: <8 ms, typical

#### Breaking Capacity (10000 operations):

24 V	10.0 A	L/R = 40 ms
48 V	10.0 A	L/R = 40 ms
125 V	10.0 A	L/R = 40 ms
250 V	10.0 A	L/R = 20 ms

#### Cyclic Capacity (4 cycles in 1 second followed by 2 minutes idle for thermal dissipation):

24 V	10.0 A	L/R = 40 ms
48 V	10.0 A	L/R = 40 ms
125 V	10.0 A	L/R = 40 ms
250 V	10.0 A	L/R = 20 ms

Note: Do not use high current interrupting output contacts to switch ac control signals. These outputs are polarity dependent.

Note: Make per IEEE C37.90:1989; Breaking and Cyclic Capacity per IEC 60255-23 [IEC 255-23]:1994.

### Optoisolated Inputs

Note: The input type is dependent on the relay ordering options. Level-sensitive inputs differ from jumper-selectable inputs in that they are guaranteed to deassert below a certain voltage level and they are not user-settable. The inputs are not polarity dependent. With nominal control voltage applied, each input draws approximately 4 mA of current.

#### Conventional Terminal Blocks Option

Note: The conventional terminal blocks model of the SEL-551 can be ordered with either jumper-selectable voltage optoisolated inputs or level-sensitive optoisolated inputs.

#### Jumper Selectable Control Voltage:

Both inputs may be individually user-configured to operate on any of the following nominal voltages:

24 Vdc:	on for 15–30 Vdc (also available on the SEL-551C, but not jumper selectable)
48 Vdc:	on for 30–60 Vdc
125 Vdc:	on for 80–150 Vdc
250 Vdc:	on for 150–300 Vdc

#### Level-Sensitive:

Both inputs are factory configured for a fixed voltage level that cannot be changed:

48 Vdc:	on for 38.4–60 Vdc; off below 28.8 Vdc
110 Vdc:	on for 88–132 Vdc; off below 66 Vdc
125 Vdc:	on for 105–150 Vdc; off below 75 Vdc
220 Vdc:	on for 176–264 Vdc; off below 132 Vdc
250 Vdc:	on for 200–300 Vdc; off below 150 Vdc

#### Plug-In Connectors Option

##### Standard (Non-Level Sensitive):

24 Vdc:	on for 15–30 Vdc
---------	------------------

##### Level-Sensitive:

The plug-in connectors model is equipped with fixed “level-sensitive” inputs. Both inputs are factory-configured to the control voltage specified at the time of ordering:

48 Vdc:	on for 38.4–60 Vdc; off below 28.8 Vdc
110 Vdc:	on for 88–132 Vdc; off below 66 Vdc
125 Vdc:	on for 105–150 Vdc; off below 75 Vdc

250 Vdc: on for 200–300 Vdc;  
off below 150 Vdc

### Frequency and Rotation

System Frequency: 50 or 60 Hz  
Phase Rotation: ABC or ACB

### Serial Communications

9-pin sub-D connector  
Baud Rate: 300, 1200, 2400, 4800, 9600, 19200,  
38400; settable baud rate and  
protocol

### Protocols

ASCII  
Distributed Port Switch Protocol (LMD)  
Modbus® RTU (rear port only; baud rate limited to 19200)

### Operating Temperature

IEC Performance Rating:  $-40^{\circ}$  to  $+85^{\circ}$  C ( $-40^{\circ}$  to  $+185^{\circ}$  F)

### Humidity

0% to 95% without condensation

### Altitude

2000 m maximum

### Operating Environment

Pollution Degree: 2  
Overvoltage Category: II  
Indoor Use

### Tightening Torque

Terminal Block:  
Minimum: 0.9 N-m (8-inch-pounds)  
Maximum: 1.4 N-m (12-inch-pounds)  
Connectorized®  
Minimum: 0.5 N-m (4.4-inch-pounds)  
Maximum: 1.0 N-m (8.8-inch-pounds)

### Terminal Connections

Terminals or stranded copper wire. Ring terminals are recommended. Minimum temperature rating of  $105^{\circ}$ C.

### Routine Dielectric Strength

AC current inputs: 2500 Vac for 10 s  
Power supply,  
optoisolated inputs,  
and output contacts: 3000 Vdc for 10 s

The following IEC 60255-5 Dielectric Tests:1977 are performed on all units with the CE mark:

2500 VAC for 10 s on analog inputs.  
3100 Vdc for 10 s on power supply, optoisolated inputs, and output contacts.

### Weight

2.5 kg (5 lbs, 8 oz.)

## Type Tests

### Environmental Tests

Cold: IEC 60068-2-1:1990 +A1:1993  
+A2:1994 [BS EN 60068-2-1:1993  
+REAF:2005]  
Test Ad; 16 hr at  $-40^{\circ}$  C  
Damp Heat Cyclic: IEC 60068-2-30:1980  
Test Db;  $25^{\circ}$  to  $55^{\circ}$  C,  
6 cycles, 95% humidity  
Damp Heat Steady State IEC 60068-2-3:1969  
Test Ca;  $40^{\circ}$ C  $\pm 2^{\circ}$ C,  
93% humidity  $+2\%$ ,  $-3\%$   
4 days, Energized > 1 day

Dry Heat: IEC 60068-2-2:1974 +A1:1993  
+A2:1994 [BS EN 60068-2-2:1993  
+REAF:2005]  
Test Bd; 16 hr at  $+85^{\circ}$  C

### Dielectric Strength and Impulse Tests

Dielectric: IEC 60255-5:1977  
IEEE C37.90-1989  
2500 Vac on analog inputs;  
3100 Vdc (3000 Vdc for  
Plug-in Connectors option)  
on power supply, contact inputs,  
and contact outputs

Impulse: IEC 60255-5:1977 0.5 J, 5000 V

### Electrostatic Discharge Test

ESD: IEC 60255-22-2:1996  
[BS EN 60255-22-2:1997]  
IEC 801-2:1991 Level 4

### RFI and Interference Tests

Fast Transient  
Disturbance: IEC 60255-22-4:1992  
IEC 801-4:1988 Level 4  
Radiated EMI: IEC 60255-22-3:1989  
IEC 801-3:1984  
IEEE C37.90.2-1987  
Surge Withstand: IEC 60255-22-1:1988  
2.5 kV peak common mode,  
1.0 kV peak differential mode  
IEEE C37.90.1-1989  
3.0 kV oscillatory; 5.0 kV fast  
transient

### Vibration and Shock Tests

Shock and Bump: IEC 60255-21-2:1988  
[BS EN 60255-21-2:1996  
+A1:1996] Class 2  
IEC 60255-21-3:1993  
[BS EN 60255-21-3:1995  
+A1:1996] Class 2  
Sinusoidal Vibration: IEC 60255-21-1:1988  
[BS EN 60255-21-1:1996  
+A1:1996]  
Class 1 Endurance,  
Class 2 Response

### Object Penetration

Object Penetration: IEC 60529:1989 IP 30, IP 54 from the  
front panel using the SEL-9103  
front- cover dust and splash  
protection

### Product Safety

C22.2 No. 14-95  
UL 508

## Certifications

ISO: Relay designed and manufactured using ISO 9001 certified  
quality program.

## Processing Specifications

8 times per power system cycle

## Metering Accuracy

Instantaneous and Demand Ammetering Functions.

Currents  $I_A$ ,  $I_B$ ,  $I_C$

5 A Nominal:  $\pm 2\%$  (0.5–80.0 A)

1 A Nominal:  $\pm 2\%$  (0.1–16.0 A)

Currents  $I_N$

5 A Nominal:  $\pm 5\%$  (0.5–80.0 A)

1 A Nominal:  $\pm 5\%$  (0.1–16.0 A)

# Overcurrent Elements

**Table 1.1 Overcurrent Elements**

	Instantaneous	Time-Overcurrent
Phase	50P1–50P6	51P1T, 51P2T
Single-Phase	50A, 50B, 50C	
Neutral Ground <sup>a</sup>	50N1, 50N2	51N1T
Residual Ground	50G1, 50G2	51G1T
Negative-Sequence (3I2) <sup>b</sup>	50Q1, 50Q2	51Q1T, 51Q2T
Setting Range, 5 A nominal <sup>c</sup>	OFF, 0.5–80.0A	OFF, 0.5–16.0A
Setting Range, 1 A nominal <sup>c</sup>	OFF, 0.1–16.0A	OFF, 0.1–3.2A

<sup>a</sup> The neutral ground overcurrent elements (50N1, 50N2, and 51N1T) operate from the separate neutral current input channel IN. All other overcurrent elements (including the residual ground overcurrent elements) operate from the phase current input channels IA, IB, and IC.

<sup>b</sup> **IMPORTANT:** See [Appendix F: Setting Negative-Sequence Overcurrent Elements](#) for information on setting negative-sequence overcurrent elements

<sup>c</sup> The available current channel ratings (5 A or 1 A) for phase (IA, IB, and IC) and neutral (IN) are specified separately—refer to the ordering information sheets for the SEL-551.

The OFF setting disables the overcurrent element.

## Time-Overcurrent Element Specifications

Pickup Accuracy:	±0.10 A secondary and ±5% of setting (5 A nominal channel) ±0.02 A secondary and ±5% of setting (1 A nominal channel)
Curve Timing Accuracy:	±1.5 cycles, and ±2% ( $I_{nom}/I_{sec}$ ), and ±4% of curve time for currents between (and including) 2 and 30 multiples of pickup  Curves operate on definite-time for currents above 30 multiples of pickup or 16 times nominal current.
Transient overreach:	<5% of pickup

See [Section 4: Setting the Relay](#) for complete setting range information.


## Instantaneous Overcurrent Element Specifications

Pickup Accuracy:	±0.10 A secondary and ±5% of setting (5 A nominal channel) ±0.02 A secondary and ±5% of setting (1 A nominal channel)
Transient overreach:	<5% of pickup


See [Section 4: Setting the Relay](#) for complete setting range information.

## Instantaneous Overcurrent Element Pickup and Reset Time Curves

[Figure 1.4](#) and [Figure 1.5](#) show pickup and reset time curves applicable to all the instantaneous overcurrent elements in the SEL-551 (60 Hz or 50 Hz relays). These times do not include output contact operating time and, thus, are accurate for determining element operating time for use in internal SELOGIC control equations. See [Output Contacts on page 1.4](#) for information on output contact operating times (pickup/dropout time). Output contact operating time has to be added to the pickup time given in [Figure 1.4](#) to calculate the overall instantaneous overcurrent element tripping time.



**Figure 1.4 SEL-551 Instantaneous Overcurrent Element Pickup Time Curve**



**Figure 1.5 SEL-551 Relay Instantaneous Overcurrent Element Reset Time Curve**

## CT Saturation Protection

The SEL-551 phase instantaneous overcurrent elements normally operate using the output of a cosine filter algorithm. During heavy fault currents when the relay detects severe CT saturation, the overcurrent elements can operate on the adaptive current algorithm.

The adaptive current algorithm is only used for phase instantaneous overcurrent elements if and only if the corresponding pickup setting is greater than eight times the nominal phase current. For example, if  $50P1P = 45$  A (in a 5 Amp nominal phase current relay), then the 50P1 element operates on the adaptive current algorithm. However, if  $50P1P = 35$  A, then the 50P1 element operates on the output of a cosine filter algorithm. No other overcurrent elements use the adaptive current algorithm.

Based on the level of a “harmonic distortion index,” the adaptive current is either the output of the cosine filter or the output of the bipolar peak detector. When the harmonic distortion index exceeds the fixed threshold that indicates severe CT saturation, the adaptive current is the output of the bipolar peak detector. When the harmonic distortion index is below the fixed threshold, the adaptive current is the output of the cosine filter.

The cosine filter provides excellent performance in removing dc offset and harmonics. However, the bipolar peak detector has the best performance in situations of severe CT saturation when the cosine filter magnitude estimation

is significantly degraded. Combining the two filters provides an elegant solution for ensuring dependable phase instantaneous overcurrent element operation.

## Timer Specifications

---

The SEL-551 has reclosing relay timers, programmable timers, and other timers (see [Section 4: Setting the Relay](#)). All timers are set in cycles, in 1/8 cycle (0.125 cycle) increments. The relay rounds the entered time setting up or down to the nearest 1/8 cycle. For example:

Enter setting

79011 = **264.685**

and the relay rounds it down to

79011 = **264.625**

Enter setting

SV10PU = **1567.318**

and the relay rounds it up to

SV10PU = **1567.375**

The timing accuracy for these timers is:  $\pm 0.25$  cycles and  $\pm 0.1$  percent of setting.

# Section 2

## Installation

---

### Overview

---

Design your installation using the mounting and connection information in this section. Options include rack or panel mounting and terminal block or plug-in connector (Connectorized<sup>®</sup>) wiring. This section also includes information on configuring the relay for your application.

### Relay Mounting

---

#### Rack Mount

A single SEL-551 Relay is roughly half the size of a standard 19-inch rack (see [Figure 2.1](#) and [Figure 2.5](#)). To mount the relay in a standard 19-inch rack follow these steps:

- Step 1. Use another SEL-500 series relay in a package (P/N 9101) or use the Rack Mount Bracket (P/N 9100). See [Figure 2.2](#), [Figure 2.3](#), and [Figure 2.4](#).
- Step 2. Secure the relays with four rack screws (two on each side) that you insert from the front of the relays through the holes on the relay mounting flanges.
- Step 3. Reverse the relay mounting flanges on the single or package versions to cause the relays to project 2.60 inches (66.1 mm).  
  
This provides additional space at the rear of the relays for applications where the relays might otherwise be too deep to fit.





#### Panel Mount

We also offer the SEL-551 in a panel-mount version for a clean look. Panel-mount relays have sculpted front-panel molding that covers all installation holes. See [Figure 2.1](#) and [Figure 2.6](#). For a panel-mount installation, follow these steps:



- Step 1. Cut your panel and drill mounting holes according to the dimensions in [Figure 2.1](#).
- Step 2. Insert the relay into the cutout, aligning four relay mounting studs on the rear of the relay front panel with the drilled holes in your panel.
- Step 3. Use nuts to secure the relay to your panel.

The projection panel-mount option covers all installation holes and maintains the sculpted look of the panel-mount option; the relay projects 2.60 inches (66.1 mm) from the front of your panel. This ordering option increases space at the rear of the relay for applications where the relay would ordinarily be too deep to fit your cabinet.

## PANEL-MOUNT CHASSIS



## RACK-MOUNT CHASSIS




\* ADD 0.80 (20.3) FOR CONNECTORIZED RELAYS


i9011b

Figure 2.1 SEL-551 Dimensions, Panel Cutout, and Drill Plan

# RACK-MOUNT CHASSIS



### LEGEND




\* ADD 0.80 (20.3) FOR CONNECTORIZED RELAYS


i9024b

Figure 2.2 Relay Dimensions and Drill Plan for Mounting Two SEL-500 Series Relays Together Using Mounting Block (SEL P/N 9101)

# RACK-MOUNT CHASSIS




**LEGEND**



\* ADD 0.80 (20.3) FOR CONNECTORIZED RELAYS


i9028a

**Figure 2.3 Relay Dimensions and Drill Plan for Mounting an SEL-551 With Rack Mount Bracket 9100 (Bracket on Right Side in Front View)**




13040a

**Figure 2.4 SEL-551 Fitted with Mounting Bracket (SEL P/N 9100) for Mounting in 19-Inch Rack**



i3038a

Figure 2.5 SEL-551 Front Panel, Rack-Mount Version (Half-Rack Width)



i3041a

Figure 2.6 SEL-551 Front Panel, Panel-Mount Version

## Rear-Panel Connections

We provide two options for secure connection of wiring to the relay rear panel. One of these is the conventional terminal block, in which you use size #6-32 screws to secure rear-panel wiring. The other option uses plug-in (Connectorized) connections that offer robust connections while minimizing installation and replacement time. These connections are intended for use with copper conductors only.


Connectorized rear-panel connections reduce repair time dramatically in the unlikely event that a relay should fail. These connections greatly simplify routine bench testing; connecting and disconnecting rear-panel wiring takes only a few minutes.

Connectorized relays use a current shorting connector for current inputs, a plug-in terminal block that provides maximum wiring flexibility for inputs and outputs, and a quick disconnect voltage-rated connector for voltage inputs. The manufacturers of these connectors have tested them thoroughly,

and many industry applications have proven the performance of these connectors. In addition, we have tested these connectors thoroughly to ensure that they conform to our standards for protective relay applications.

## Terminal Block

Make terminal block connections with size #6-32 screws using a Phillips® or slotted screwdriver. You may request locking screws from the factory. Refer to *Figure 2.7* to make all terminal block connections.



13039b

**Figure 2.7 SEL-551 Rear Panel (Conventional Terminal Blocks Option)**

The output contacts in *Figure 2.7* (OUT1–OUT4 and ALARM) are not polarity dependent.

The optoisolated inputs in *Figure 2.7* (IN1–IN2) are not polarity dependent.

All screws are size #6-32.

## Screw Terminal Connections

All screw/washer styles on SEL relays are recognized by UL for field wiring using terminals or bare wire. However, as stated below, SEL strongly recommends the use of ring or fork terminals.

Two types of screw terminal are provided on the SEL relays, one with a washer (Phillips screw head - standard) and one without (slotted screw head, optional). SEL recommends using ring or fork terminals with both types of screw terminals fitted to the relays. There are two main reasons for this recommendation;

- Step 1. Stray strands and inconsistent wire stripping may compromise hi-pot clearances and give rise to the potential for shorting the adjacent terminals.
- Step 2. Wire/terminal secureness with ring terminals has been tested at SEL to 20 lb minimum. Bare wire has not been tested at SEL.

Both the terminal block manufacturer and UL requirements have qualified the standard terminal blocks for use with bare stranded wire, however, SEL's qualification requirements are more stringent as required by the utility and industrial applications of protective relays.

The SEL terminal retention and hi-pot test voltage requirements are both twice that required by the UL standard.

All SEL qualification testing of terminal blocks and relays is performed with ring or fork terminals.

**NOTE:** #6 ring and fork terminals will accommodate wire sizes from 22 awg to 10 awg.


There is no limit to the number of terminals that can be clamped under one screw, however there is a maximum total thickness of .120" (3 mm). Ring terminals typically range in thickness .030" to .060".

### **⚠ WARNING**

A too-long screw will damage the inside part of the terminal. This is true for both styles of terminal block, but especially for the I/O connections.

## Connectorized

To use the Connectorized version of the SEL-551, ask your SEL sales or customer service representative for the appropriate Model Option Table and order wiring harness kit WA05510W.xXyA, where *x* designates wire size and *y* designates wire length. You can find the Model Option Table on the SEL website at <http://www.selinc.com>. Refer to *Figure 2.8* to make all Connectorized connections.



13042a

**Figure 2.8 SEL-551 Rear Panel (Plug-In Connectors Option)**

Connector terminals A01–A16 accept wire size AWG 24 to 12 (install wires with a small slotted-tip screwdriver).

Output contacts OUT1–OUT4 and ALARM are polarity dependent (note the “+” above terminals A02, A04, A06, A08, and A10).

As an example, consider the connection of terminals A01 and A02 (output contact OUT1) in a circuit:

Terminal A02 (+) has to be at a higher voltage potential than terminal A01 in the circuit.

With this option, output contacts OUT1–OUT4 and ALARM are also high-current interrupting output contacts:

10 A for L/R = 40 ms at 125 Vdc

10 A for L/R = 20 ms at 250 Vdc

See *High-Current Interrupting Output Contacts* for more information.

Optoisolated inputs IN1 and IN2 are not polarity dependent.

Current input connector (terminals Z01–Z08):

- Contains current transformer shorting mechanisms
- Accepts wire size AWG 16 to 10 (special tool required to attach wire to connector)
- Can be ordered prewired

Ground connection (terminal Z09): tab size 0.250 inch x 0.032 inch, screw size #6-32.

## Plug-In Connector Improvements Result in Part Number Changes

**IMPORTANT:** Improvements in Connectorized (Plug-In Connectors) SEL-551 Relay Result in Part Number Changes

The current transformer shorting connector (for current channel inputs IA, IB, IC, and IN) has been made more robust. This improvement makes the new connector design incompatible with the old design. Thus, presently constructed Connectorized SEL-551 Relays with this improved connector have a new part number (partial part numbers shown):

Old	New
05510J	05510W

The respective wiring harness part numbers for these old and new Connectorized SEL-551 Relays are (partial part numbers shown):

Old	New
W05510J	WA05510W

The other connectors on the Connectorized SEL-551 rear panel (power input, output contacts, etc.) are the same for the old or new model. Only the current transformer shorting connector has changed.

*Figure 2.8* shows the rear panel for new model 05510W. This figure can also be used as a reference for old model 05510J. All terminal labeling/numbering remains the same.


## High-Current Interrupting Output Contacts

Relays with plug-in connectors as shown in *Figure 2.8* contain output contacts capable of interrupting load current up to 10 amps. The output contacts contain internal contact arc suppressors that protect the output contacts from damage due to electrical arcs. Apply these output contacts to very sensitive, high speed loads or to heavy resistive or inductive loads up to their interrupt rating. No special connections are required to use the integral arc suppressors; however, the output contacts are polarity dependent as mentioned previously in this section.


The arc suppressors in the SEL-551 are different from the SEL-9501 Contact Arc Suppressor. The high-current interrupting output contacts in the SEL-551 have the same interrupt rating as the SEL-9501, but typically have less than 1  $\mu\text{A}$  of leakage current, and exhibit virtually none of the let-through exhibited by the SEL-9501. See *SEL Application Guide 97-23, SEL-9501 Contact Arc Suppressor Application Guidelines* for more information regarding the SEL-9501 and the let-through phenomenon. A single SEL-9501 can theoretically be used to protect multiple contacts simultaneously, but the arc suppressors inside the SEL-551 protect only the SEL-551 output contacts.

The high-current interrupting output contacts in the SEL-551 are guaranteed to not turn on or latch up regardless of the rate of rise of voltage across the protected contacts (i.e., these arc suppressors do not exhibit SCR type latch up because they do not use SCRs).

# SEL-551 AC/DC Connection Diagrams for Example Applications




**Figure 2.9 SEL-551 Provides Overcurrent Protection and Reclosing for a Utility Distribution Feeder (Includes Fast Bus Trip Scheme)**




**Figure 2.10 SEL-551 Provides Overcurrent Protection for an Industrial Distribution Feeder (Core-Balance Current Transformer Connected to Current Input Channel IN)**


A core-balance current transformer is often referred to as a zero-sequence, ground fault, or window current transformer.



**Figure 2.11 SEL-551 Provides Overcurrent Protection for a Delta-Wye Transformer Bank**



**Figure 2.12 SEL-551 Provides Overcurrent Protection for a Transformer Bank with a Tertiary Winding**



**Figure 2.13 SEL-551 Provides Overcurrent Protection for a Distribution Bus (Includes Fast Bus Trip Scheme)**

The fast bus trip scheme is often referred to as a reverse interlocking or zone interlocking scheme.




Figure 2.14 SEL-551 Provides Dedicated Breaker Failure Protection

## EIA-485 Rear-Panel Adapter

Cable C675 is used with the EIA-485 rear-panel serial communications port option to bring the pins from the 9-pin serial communications connector (see [Figure 5.1](#)) out to a terminal block for ease of wiring.

# Circuit Board Jumpers and Battery

## Control Voltage Jumpers (SEL-551 With the Conventional Terminal Blocks Option)

### ⚠ CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

SEL-551 relays equipped with Conventional Terminal Blocks may be ordered with either jumper-selectable voltage optoisolated inputs or level-sensitive optoisolated inputs. Level sensitive inputs are not jumper selectable. See *Specifications, General on page 1.4* for ratings.

The jumper-selectable control voltage models are factory-configured to the control voltage specified at time of ordering. The jumpers may be changed as outlined below.

To change the control input voltage range using internal jumpers, take the following steps:

- Step 1. De-energize the relay.
- Step 2. Remove the three front-panel screws and the relay front panel.
- Step 3. Disconnect the analog signal ribbon cable from the underside of the relay main board.
- Step 4. Grasp the black knob on the front of the drawout assembly, and pull the assembly from the relay chassis.
- Step 5. Locate the control voltage jumpers near the rear edge of the relay main board. The jumpers are numbered JMP6 through JMP11. Refer to *Figure 2.15*.
- Step 6. Install or remove jumpers according to *Table 2.1* to select the desired control voltage level.
- Step 7. Slide the drawout assembly into the relay chassis.
- Step 8. Reconnect the analog signal ribbon cable.
- Step 9. Replace the relay front panel.
- Step 10. Reenergize the relay.

**Table 2.1 Required Control Voltage Jumper Positions for Applied Nominal Control Voltage (SEL-551 With the Conventional Terminal Blocks Option)**

For use with relays equipped with the jumper-selectable control input voltage option only. Not supported in the level-sensitive control input option. See product Model Option Table (MOT) for details.


Nominal Control Voltage	Optoisolated Input IN1 Jumpers			Optoisolated Input IN2 Jumpers		
	JMP6	JMP7	JMP8	JMP9	JMP10	JMP11
250 Vdc	• •	• •	• •	• •	• •	• •
125 Vdc	•—•	• •	• •	•—•	• •	• •
48 Vdc	•—•	•—•	• •	•—•	•—•	• •
24 Vdc	•—•	•—•	•—•	•—•	•—•	•—•

## Output Contact Jumpers (SEL-551 With the Conventional Terminal Blocks Option)

Refer to *Figure 2.15*. Jumpers JMP1 through JMP5 select the output contact type for the output contacts. With a jumper in the A position, the corresponding output contact is an a-type output contact. An a-type output contact is open when the output contact coil is de-energized and closed when the output contact coil is energized. With a jumper in the B position, the corresponding output contact is a b-type output contact. A b-type output contact is closed when the output contact coil is de-energized and open when the output contact coil is energized. These jumpers are soldered in place.

**NOTE:** For an SEL-551 relay with the Plug-In Connectors Option, the output contact types are fixed. There are no jumpers available to change the output contact types. Output contacts OUT1-OUT4 are all a-type output contacts. The ALARM output contact is a b-type output contact.

In *Figure 2.15*, note that the ALARM output contact is a b-type output contact and the other output contacts are all a-type output contacts. This is how these jumpers are configured in a standard relay shipment. Refer to *Figure 3.23* for examples of output contact operation for different output contact types.



**Figure 2.15 Input and Output Jumper Locations (SEL-551 Relay With the Conventional Terminal Blocks With Jumper-Selectable Control Input Voltage Option)**

## Password and Breaker Jumpers

Password and Breaker jumpers are on the front edge of the relay main board between the front-panel LEDs and the control pushbuttons. Remove the relay front panel to change them.

Put Password jumper **JMP22** (left-most jumper) in place to disable serial port and front-panel password protection. With the jumper removed, password security is enabled. Set the passwords with the **PASSWORD** command (see *Section 5: Serial Port Communications and Commands*).


Put Breaker jumper **JMP24** (right-most jumper) in place to enable the serial port commands **OPEN**, **CLOSE**, and **PULSE**. These commands are ignored while **JMP24** is removed. These commands are used primarily to assert output contacts for circuit breaker control or testing purposes (see *Section 5: Serial Port Communications and Commands*).

## Rear-Panel EIA-232 Serial Communications Port Voltage Jumper (EIA-232 Option Only)

Jumper **JMP14** in the SEL-551 is toward the rear of the main board, near the rear-panel EIA-232 serial communications port. This jumper connects or disconnects +5 Vdc to pin 1 on the EIA-232 serial communications port. In a standard relay shipment, jumper **JMP14** in the SEL-551 would be removed (out-of-place) so that the +5 Vdc is not connected to pin 1 on the EIA-232 serial communications port. See *Figure 5.1*.

## Output Contact OUT4 Control Jumper

Refer to *Figure 2.16* and *Table 2.2*. Main board jumper JMP13 controls the operation of output contact OUT4. It provides the option of a second alarm output contact by changing the signal that drives output contact OUT4.



**Figure 2.16** Output Contact OUT4 Control Jumper Location

**Table 2.2** Required Position of Jumper JMP13 for Desired Output Contact OUT4 Operation

Position	Output Contact OUT4 Operation
	Regular output contact OUT4 (operated by Relay Word bit OUT4). Jumper JMP13 comes in this position in a standard relay shipment.
	Extra Alarm output contact (operated by alarm logic/circuitry). Relay Word bit OUT4 does not have any effect on output contact OUT4 when jumper JMP13 is in this position.

**NOTE:** Some initial shipments of SEL-551 relays did not have this jumper JMP13 feature.

## Clock Battery

### ⚠ CAUTION

There is danger of explosion if the battery is incorrectly replaced. Replace only with Ray-O-Vac® no. BR2335 or equivalent recommended by manufacturer. Dispose of used batteries according to the manufacturer's instructions.

### ⚠ CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

See *Figure 3.23*. If jumper JMP13 is in position ALARM and both output contacts OUT4 and ALARM are the same output contact type (a or b), they will be in the same state (closed or open). If jumper JMP13 is in position ALARM and output contacts OUT4 and ALARM are different output contact types (one is an a and one is a b), they will be in opposite states (one is closed and one is open).

A lithium battery powers the relay clock (date and time) if the external dc source is lost or removed. The battery is a 3 V lithium coin cell. At room temperature (25°C), the battery will nominally operate for 10 years at rated load.

If the dc source is lost or disconnected, the battery discharges to power the clock. When the relay is powered from an external source, the battery only experiences a low self-discharge rate. Thus, battery life can extend well beyond the nominal 10 years because the battery rarely has to discharge after the relay is installed. The battery cannot be recharged.

If the battery voltage is out-of-tolerance, an automatic status message is sent to the serial port and the front-panel display.

To change the battery, take the following steps:

- Step 1. De-energize the relay.
- Step 2. Remove the three front-panel screws and the relay front panel.
- Step 3. Disconnect the analog signal ribbon cable from the underside of the relay main board.

- Step 4. Grasp the black knob on the front of the drawout assembly, and pull the assembly from the relay chassis.
- Step 5. Locate the battery on the right-hand side of the relay main board.
- Step 6. Remove the battery from beneath the clip, and install a new one.  
The positive side (+) of the battery faces up.
- Step 7. Slide the drawout assembly into the relay chassis.
- Step 8. Reconnect the analog signal ribbon cable.
- Step 9. Replace the relay front panel and reenergize the relay.
- Step 10. Set the relay date and time via serial communications port or front panel (see [Section 5: Serial Port Communications and Commands](#) or [Section 6: Front-Panel Interface](#), respectively).

# Section 3

## Relay Elements and Logic

### Relay Word Bits and SELogic Control Equations

This section describes relay elements and logic with numerous figures and accompanying text. Details on setting ranges are given in the setting sheets in [Section 4: Setting the Relay](#). See the [SHO Command \(Showset\) on page 5.16](#) for a listing of the factory settings shipped with the relay.

#### Relay Word Bits

The outputs of the logic in most of the figures in this section are labeled Relay Word bits. Relay Word bits have label names (e.g., 51P1T, TRIP, CLOSE, etc.). They are logic points that can have a state of:

1 (logical 1) or 0 (logical 0)

depending on the operation of the associated logic. Logical 1 represents an element being picked up, timed out, or otherwise asserted. Logical 0 represents an element being dropped out or otherwise deasserted. All Relay Word bits and their descriptions are shown in [Table 4.5](#) and [Table 4.6](#) and are used in SELOGIC<sup>®</sup> control equations.

#### SELogic Control Equations

SELOGIC control equation settings are the inputs for the logic in many of the figures in this section. See the [SELOGIC Control Equation Settings \(SET L Command\) on page SET.6](#) for a listing and short description of each of the SELOGIC control equation settings. See the [SHO Command \(Showset\)](#) for a listing of the factory SELOGIC control equation settings shipped with the relay. Create traditional or advanced custom schemes with SELOGIC control equations.

SELOGIC control equation settings are written in Boolean algebra logic, combining Relay Word bits together with different operators. Parentheses can also be used in SELOGIC control equation settings. More than one set of parentheses can be used in a given SELOGIC control equations setting, but they cannot be “nested” (parentheses within parentheses). See [Trip Logic on page 3.17](#) and [Reclosing Relay on page 3.22](#) for examples of using parentheses (factory settings for ULTR and 79BRS, respectively). Operators in a SELOGIC control equations setting are processed in the following order:

**Table 3.1 Processing Order of SELogic Control Equation Operators**

Operator	Logic Function
/	rising-edge detect
\	falling-edge detect
()	parentheses
!	NOT
*	AND
+	OR

In addition to Relay Word bits, numerals:

1 (logical 1) or 0 (logical 0)

can be entered in a SELOGIC control equations setting. If a SELOGIC control equation setting is set equal to 1, it is always “asserted/on/enabled.” If a SELOGIC control equation setting is set equal to 0, it is always “deasserted/off/disabled.” Under the *SHO Command (Showset)*, note that a number of the factory SELOGIC control equation settings are set equal to 1 or 0.

## Limitations

Any single SELOGIC control equation setting is limited to nine Relay Word bits that can be combined together with the SELOGIC control equation operators listed in [Table 3.1](#). To get around this limitation, a SELOGIC Variable (SELOGIC control equation settings SV1–SV14) can be used as an intermediate setting step.

For example, presume that the trip equation (SELOGIC control equation setting TR) needs more than nine Relay Word bits in its equation setting. Part of the desired equation is put into the SELOGIC control equation setting SV1. The resultant SELOGIC Variable output (Relay Word bit SV1) is then set in SELOGIC control equation setting TR.

Note in [Table 3.2](#) that the SELOGIC Variables (SELOGIC control equation settings SV1–SV14) are processed after the trip equation (SELOGIC control equations setting TR). Thus, any tripping via Relay Word bit SV1 is delayed one processing interval (1/8-cycle). For most applications, this is probably of no consequence.

For all the SELOGIC control equations settings in total, the SEL-551 relay has limits of 235 Relay Word bits that can be combined together with the SELOGIC control equation operators listed in [Table 3.1](#).

Up to 16 total rising-edge and falling-edge detects can be used in SELOGIC control equations settings for the SEL-551 relay.

## Processing Order and Processing Interval


The relay elements and logic (and corresponding SELOGIC control equation settings and resultant Relay Word bits) are processed in the order shown in [Table 3.2](#) (top to bottom). They are processed every eighth-cycle (1/8-cycle), and the Relay Word bit states (logical 1 or logical 0) are updated with each eighth cycle pass. Thus, the relay processing interval is 1/8-cycle. Once a Relay Word bit is updated during an eighth-cycle pass, it retains the state (logical 1 or logical 0) until it is updated again on the next eighth-cycle pass.

The Display Points (DP1–DP8) are described in [Section 6: Front-Panel Interface](#). The Event Report Triggers (ER1 and ER2) are described in [Section 7: Standard Event Reports and SER](#). The other items in [Table 3.2](#) are described in the rest of this section, in the order given in [Table 3.2](#). The exception to this order is [Demand Ammetering on page 3.41](#).

**Table 3.2 Processing Order of Relay Elements and Logic (Top to Bottom)**

Relay Elements and Logic (corresponding SELogic Control Equations listed in parentheses)	Resultant Relay Word Bits
Optoisolated Inputs	IN1, IN2
Local Control Switches	LB1–LB8
Remote Control Switches	RB1–RB8
Demand Ammetering	PDEM, NDEM, GDEM, QDEM
Instantaneous Overcurrent Elements	50P1–50P6, 50A, 50B, 50C, 50N1, 50N2, 50G1, 50G2, 50Q1, 50Q2
Time-Overcurrent Elements (51P1TC, 51P2TC, 51N1TC, 51G1TC, 51Q1TC, 51Q2TC)	51P1, 51P2, 51N1, 51G1, 51Q1, 51Q2, 51P1T, 51P2T, 51N1T, 51G1T, 51Q1T, 51Q2T, 51P1R, 51P2R, 51N1R, 51G1R, 51Q1R, 51Q2R
Trip Logic (TR, ULTR)	TRIP
Close Logic (52A, CL, ULCL) Reclosing Relay (79RI, 79RIS, 79DTL, 79DLS, 79SKP, 79STL, 79BRS, 79SEQ)	CLOSE, CF, 79RS, 79CY, 79LO, SH0, SH1, SH2, SH3, SH4
SELOGIC Variables/Timers (SV1–SV14)	SV1–SV14, SV5T–SV14T
Output Contacts (OUT1–OUT4)	OUT1–OUT4
Display Points (DP1–DP8)	
Event Report Triggers (ER1, ER2)	

## Optoisolated Inputs


**Figure 3.1 Example Operation of SEL-551 Optoisolated Inputs**

Relay Word bits IN1 and IN2 follow optoisolated inputs IN1 and IN2, respectively. See [Figure 3.1](#) for the optoisolated inputs available with the SEL-551 relay. This figure gives an example of an energized and de-energized optoisolated input and corresponding Relay Word bit states. Note the built-in pickup and dropout times of 0.25 cycles for energization or de-energization debounce.

There are no optoisolated input settings such as:

IN1 =

IN2 =

Optoisolated inputs **IN1–IN2** receive their function by how their corresponding Relay Word bits IN1–IN2 are used in SELOGIC control equations.

## Factory Settings Example

Relay Word bit IN1 is used in the factory settings for the SELOGIC control equations circuit breaker status setting:

52A = **IN1**

Connect input **IN1** to a 52a circuit breaker auxiliary contact. See [Close Logic on page 3.20](#) and [Reclosing Relay on page 3.22](#) for more information on SELOGIC control equations setting 52A.

Input **IN1** is also used in other factory settings discussed later in this section (i.e., SELOGIC control equation settings 79RIS and DP2). Just because Relay Word bit IN1 is assigned to the circuit breaker status setting 52A, it does not mean that Relay Word bit IN1 cannot be used in other SELOGIC control equation settings.

In the factory settings, Relay Word bit IN2 is not used.

## Additional Settings Examples

### 52b Circuit Breaker Auxiliary Contact

If a 52b circuit breaker auxiliary contact is connected to input **IN1**, the setting is changed to:

52A = **!IN1** [!IN1 = NOT(IN1)]

### Time-Qualify Optoisolated Inputs

If an input needs to be debounced or time-qualified more than the built-in 0.25 cycles, assign the input to a SELOGIC Variables timer (see [Figure 3.21](#)):

SV6 = **IN1**

The output of the timer (Relay Word bit SV6T) can then be used in place of Relay Word bit IN1. For example, the timer output can be assigned to the SELOGIC control equations circuit breaker status setting:


52A = **SV6T**

### Other Examples

Other example SELOGIC control equation settings in this section use the optoisolated inputs **IN1–IN2** for such applications as breaker failure initiation, time-overcurrent element torque control, reclose initiation, and reclose timing stall condition.

# Local Control Switches

Local control switches emulate traditional panel switches and are operated via the front-panel keyboard/display only (see [Section 6: Front-Panel Interface](#); {CNTRL} pushbutton).



The switch representation in this figure is derived from the standard:

Graphics Symbols for Electrical and Electronics Diagrams IEEE Std 315-1975, CSA Z99-1975, ANSI Y32.2-1975, 4.11 Combination Locking and Nonlocking Switch, Item 4.11.1

**Figure 3.2 Local Control Switches Drive Local Bits LB1-LB8**

The output of the local control switch in [Figure 3.2](#) is a Relay Word bit (local bit  $LB_n$ ,  $n = 1-8$ ). These local bits are used in SELOGIC control equations. For a given local control switch, the local control switch positions are enabled by making corresponding label settings.

**Table 3.3 Correspondence Between Local Control Switch Positions and Label Settings**

Switch Position	Label Setting	Setting Definition	Logic State
ON	SLB $n$	“Set” Local bit LB $n$	logical 1
OFF	CLB $n$	“Clear” Local bit LB $n$	logical 0
MOMENTARY	PLB $n$	“Pulse” Local bit LB $n$	logical 1 for one processing interval

Each local control switch also has a corresponding “name” label setting NLB $n$ . Label settings are made with serial port command **SET T** and viewed with serial port command **SHO T** (see [Section 4: Setting the Relay](#) and [Section 5: Serial Port Communications and Commands](#)).

Any given local control switch can be configured to be one of the following three switch types:

- ON/OFF
- OFF/MOMENTARY
- ON/OFF/MOMENTARY

**Table 3.4 Correspondence Between Local Control Switch Types and Required Label Settings**

Local Switch Type	Label NLBn	Label CLBn	Label SLBn	Label PLBn
ON/OFF	X	X	X	
OFF/MOMENTARY	X	X		X
ON/OFF/MOMENTARY	X	X	X	X

If a local control switch is not being used, “null out” all its corresponding label settings to make it inoperable (see [Section 4: Setting the Relay](#)). The local bit that is “driven” by this inoperable local control switch is fixed at logical 0.

## Factory Settings Example

Local bits LB1, LB3, and LB4 are used in a number of the factory settings in this section. The factory settings examples control reclose enable/disable, manual tripping, and manual closing. Their corresponding local control switch position label settings are:

Local Bit	Label Settings	Function
LB1	NLB1 = RECLOSER	enables/disables reclosing relay; see <a href="#">Reclosing Relay on page 3.22</a> (setting 79DTL)
	CLB1 = DISABLE	OFF position
	SLB1 = ENABLE	ON position
	PLB1 =	MOMENTARY position—not used
LB3	NLB3 = MANUAL TRIP	trips breaker and drive reclosing relay to lockout; see <a href="#">Trip Logic on page 3.17</a> and <a href="#">Reclosing Relay</a> (setting 79DTL)
	CLB3 = RETURN	OFF position (“return from MOMENTARY” position)
	SLB3 =	ON position—not used
	PLB3 = TRIP	MOMENTARY position
LB4	NLB4 = MANUAL CLOSE	closes breaker, separate from reclosing relay algorithm; see <a href="#">Close Logic on page 3.20</a>
	CLB4 = RETURN	OFF position (“return from MOMENTARY” position)
	SLB4 =	ON position—not used
	PLB4 = CLOSE	MOMENTARY position

The operation of these local control switches through the front panel is demonstrated in [Section 6: Front-Panel Interface](#).

## Additional Settings Examples

Other application ideas for local bits are:

- ground relay enable/disable
- remote control supervision
- sequence coordination enable/disable

Local bits can be applied to almost any control scheme.

## Local Bit States Retained When Power Is Lost or Settings Changed

### Power Loss

The states of the local bits (Relay Word bits LB1–LB8) are retained if power is lost to the relay and then it is restored. If a local control switch is in the **ON** position (corresponding local bit is asserted to logical 1) when power is lost, it will come back in the **ON** position (corresponding local bit is still asserted to logical 1) when power is restored. If a local control switch is in the **OFF** position (corresponding local bit is deasserted to logical 0) when power is lost, it will come back in the **OFF** position (corresponding local bit is still deasserted to logical 0) when power is restored. This is akin to a traditional installation with front-panel control switches. If power is lost to the panel, the front-panel control switches remain in position.

### Settings Change

If relay settings are changed, the states of the local bits (Relay Word bits LB1–LB8) are retained, much like in the *Power Loss* explanation. The exception is if a new local control switch is configured as an OFF/MOMENTARY switch. Then, the corresponding local bit is forced to start at logical 0 after the settings change, regardless of the local bit state before the settings change.

If the local control switch is made inoperable because of a settings change, the corresponding local bit is fixed at logical 0, regardless of the local bit state before the settings change.

## Remote Control Switches

---


Remote control switches are operated via the serial communications port only (see *CON Command (Control) on page 5.22*).

The output of the remote control switch in *Figure 3.3* is a Relay Word bit (remote bit  $RB_n$ ,  $n = 1-8$ ). These remote bits are used in SELOGIC control equations.

Any given remote control switch can be put in one of the following three positions:

- ON (logical 1)
- OFF (logical 0)
- MOMENTARY (logical 1 for one processing interval)

With SELOGIC control equations, the remote bits can be used in applications similar to those that local bits are used in (see *Local Control Switches on page 3.5*).



The switch representation in this figure is derived from the standard: Graphics Symbols for Electrical and Electronics Diagrams IEEE Std 315-1975, CSA Z99-1975, ANSI Y32.2-1975, 4.11 Combination Locking and Nonlocking Switch, Item 4.11.1

**Figure 3.3 Remote Control Switches Drive Remote Bits RB1–RB8**

### Remote Bit States Not Retained When Power Is Lost

The states of the remote bits (Relay Word bits RB1–RB8) are not retained if power is lost to the relay and then it is restored. The remote control switches come back in the OFF position (corresponding remote bit is deasserted to logical 0) when power is restored to the relay.

### Remote Bit States Retained When Settings Changed

If relay settings are changed, the states of the remote bits (Relay Word bits RB1–RB8) are retained. If a remote control switch is in the ON position (corresponding remote bit is asserted to logical 1) before a settings change, it will come back in the ON position (corresponding remote bit is still asserted to logical 1) after the settings change. If a remote control switch is in the OFF position (corresponding remote bit is deasserted to logical 0) before a settings change, it will come back in the OFF position (corresponding remote bit is still deasserted to logical 0) after the settings change.

## Instantaneous Overcurrent Elements

See the setting sheets in [Section 4: Setting the Relay](#) for instantaneous overcurrent element setting range information.

See [Trip Logic on page 3.17](#) for an example of tripping with a phase instantaneous overcurrent element (setting TR).


See [Reclosing Relay on page 3.22](#) for an example of using a phase instantaneous overcurrent element to skip a reclosing shot (setting 79SKP).

See [SELOGIC Control Equation Variables/Timers on page 3.38](#) to create definite-time overcurrent elements with SELOGIC control equations (combining instantaneous overcurrent elements with timers.)

### Phase Instantaneous Overcurrent Elements

Six phase instantaneous overcurrent elements (50P1–50P6) are available (see [Figure 3.4](#)). Their pickup settings (50P1P–50P6P, respectively) are compared to the magnitude of the maximum phase current ( $I_P = \text{maximum of } I_A, I_B, \text{ or } I_C$ ). The phase current is normally the output of the cosine filter algorithm, but during CT saturation the phase current can be the output of the adaptive current algorithm if the pickup setting is greater than eight times nominal phase current.

For example, if  $50P1P = 45$  A (in a 5 A nominal phase current relay), the  $I_P$  input into the 50P1 logic is the maximum phase current output of the adaptive current algorithm. If  $50P1P = 35$  A, then the  $I_P$  input into the 50P1 logic is the maximum phase current output of a cosine filter algorithm.



**Figure 3.4 Phase Instantaneous Overcurrent Elements 50P1-50P6**

Example 50P1 element operation:

$I_P > \text{pickup setting } 50P1P$ , then Relay Word bit 50P1 = logical 1

$I_P \leq \text{pickup setting } 50P1P$ , then Relay Word bit 50P1 = logical 0

If pickup setting 50P1P is set to  $50P1P = \text{OFF}$ , then element 50P1 is disabled. Relay Word bit 50P1 equals logical 0 at all times.


The other five phase instantaneous overcurrent elements (50P2–50P6) operate similarly.

## Single-Phase Instantaneous Overcurrent Elements

Single-phase instantaneous overcurrent elements (50A, 50B, and 50C) are available (see [Figure 3.5](#)). The pickup setting (50ABCP, used for all three single-phase elements) is compared to the magnitude of the single-phase current ( $I_A$ ,  $I_B$ , and  $I_C$ ). The phase current is normally the output of the cosine filter algorithm, but during CT saturation the phase current can be the output of the adaptive current algorithm if the pickup setting is greater than eight times nominal phase current.

For example, if  $50ABCP = 45$  A (in a 5 A nominal phase current relay), the  $I_A$  input into the 50A logic is the maximum phase A adaptive current algorithm, the  $I_B$  input into the 50B logic is the maximum phase B adaptive current algorithm, and the  $I_C$  input into the 50C logic is the maximum phase C adaptive current algorithm. If  $50ABCP = 35$  A, the  $I_A$  input into 50A logic is the maximum phase A current output of cosine filter algorithm, the  $I_B$  input

into 50B logic is the maximum phase B current output of cosine filter algorithm, and the  $I_C$  input into 50C logic is the maximum phase C current output of cosine filter algorithm.



**Figure 3.5 Single-Phase Instantaneous Overcurrent Elements 50A, 50B, and 50C**

Example 50A element operation:

$I_A >$  pickup setting 50ABCP, then Relay Word bit 50A = logical 1


$I_A \leq$  pickup setting 50ABCP, then Relay Word bit 50A = logical 0

If pickup setting 50ABCP is set to 50ABCP = OFF, then element 50A is disabled. Relay Word bit 50A equals logical 0 at all times.

The other two phase instantaneous overcurrent elements (50B and 50C) operate similarly.

### Neutral Ground Instantaneous Overcurrent Elements

Two neutral ground instantaneous overcurrent elements (50N1 and 50N2) are available (see [Figure 3.6](#)). Their pickup settings (50N1P and 50N2P, respectively) are compared to the magnitude of the neutral ground current ( $I_N$ ). This current is from separate neutral current input channel  $I_N$  (see [Figure 1.2](#)).



**Figure 3.6 Neutral Ground Instantaneous Overcurrent Elements 50N1 and 50N2**

Example 50N1 element operation:

$I_N >$  pickup setting 50N1P, then Relay Word bit 50N1 = logical 1


$I_N \leq$  pickup setting 50N1P, then Relay Word bit 50N1 = logical 0

If pickup setting 50N1P is set to 50N1P = OFF, then element 50N1 is disabled. Relay Word bit 50N1 equals logical 0 at all times.

The second neutral ground instantaneous overcurrent element (50N2) operates similarly.

## Residual Ground Instantaneous Overcurrent Elements

Two residual ground instantaneous overcurrent elements (50G1 and 50G2) are available (see *Figure 3.7*). Their pickup settings (50G1P and 50G2P, respectively) are compared to the magnitude of the residual ground current ( $I_G = 3I_0$ , derived from  $I_A$ ,  $I_B$ , and  $I_C$ ).



**Figure 3.7 Residual Ground Instantaneous Overcurrent Elements 50G1 and 50G2**

Example 50G1 element operation:

$I_G >$  pickup setting 50G1P, then Relay Word bit 50G1 = logical 1

$I_G \leq$  pickup setting 50G1P, then Relay Word bit 50G1 = logical 0


If pickup setting 50G1P is set to 50G1P = OFF, then element 50G1 is disabled. Relay Word bit 50G1 equals logical 0 at all times.

The second residual ground instantaneous overcurrent element (50G2) operates similarly.

## Negative-Sequence Instantaneous Overcurrent Elements

**IMPORTANT:** See Appendix F for information on setting negative-sequence overcurrent elements.

Two negative-sequence instantaneous overcurrent elements (50Q1 and 50Q2) are available (see *Figure 3.8*). Their pickup settings (50Q1P and 50Q2P, respectively) are compared to the magnitude of the negative-sequence current ( $3I_2$ , derived from  $I_A$ ,  $I_B$ , and  $I_C$ ).



**Figure 3.8 Negative-Sequence Instantaneous Overcurrent Elements 50Q1 and 50Q2**

Example 50Q1 element operation:

$3I_2 >$  pickup setting 50Q1P, then Relay Word bit 50Q1 = logical 1

$3I_2 \leq$  pickup setting 50Q1P, then Relay Word bit 50Q1 = logical 0

If pickup setting 50Q1P is set to 50Q1P = OFF, then element 50Q1 is disabled. Relay Word bit 50Q1 equals logical 0 at all times.

The second negative-sequence instantaneous overcurrent element (50Q2) operates similarly.

# Time-Overcurrent Elements


See the setting sheets in *Section 4: Setting the Relay* for time-overcurrent element setting range information.

See *Trip Logic on page 3.17* for examples of tripping with time-overcurrent elements (setting TR) and unlatching tripping with time-overcurrent element pickups (setting ULTR).

See *Reclosing Relay on page 3.22* for an example of using time-overcurrent element pickups to block reset timing (setting 79BRS).


## Phase Time-Overcurrent Elements

Two phase time-overcurrent elements (51P1T and 51P2T) are available (see *Figure 3.9*). Their pickup settings (51P1P and 51P2P, respectively) are compared to the magnitude of the maximum phase current ( $I_P = \text{maximum of } I_A, I_B, \text{ or } I_C$ ).



SELogic Setting 51P1TC Controls the Torque Control Switch

51P1TC State	Torque Control Switch Position	Setting 51P1RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle



SELogic Setting 51P2TC Controls the Torque Control Switch

51P2TC State	Torque Control Switch Position	Setting 51P2RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle

**Figure 3.9 Phase Time-Overcurrent Elements 51P1T and 51P2T**

The following is an example of 51P1T element operation; the other time-overcurrent elements operate similarly:

## Torque Control Setting

SELOGIC control equations setting 51P1TC (torque control for phase time-overcurrent element 51P1T) controls the input of current  $I_p$  into the pickup comparator and the curve timing/reset timing function.

If 51P1TC = logical 1 and  $I_p >$  pickup setting 51P1P, then:

Relay Word bit 51P1 (pickup indication) = logical 1

and

curve timing takes place if element 51P1T is not already timed-out.

If 51P1TC = logical 1 and  $I_p \leq$  pickup setting 51P1P, then:

Relay Word bit 51P1 (pickup indication) = logical 0

and

reset timing takes place if element 51P1T is not already reset.

If 51P1TC = logical 0, then:

Relay Word bit 51P1 (pickup indication) = logical 0 at all times.

Also, no current  $I_p$  goes into the curve timing/reset timing function—no curve timing takes place [effectively, the magnitude of  $I_p$  as seen by the curve timing/reset timing function is zero (0), and reset timing takes place if the element is not already reset].

## Example Torque Control Settings

**NOTE:** Torque control equation settings cannot be set directly to logical 0.

Note in *SHO Command (Showset) on page 5.16* that the factory settings for 51P1TC and the other time-overcurrent element torque control settings are set equal to 1:

51P1TC = 1

Thus, the time-overcurrent elements are enabled all the time, and they behave as detailed previously for 51P1TC = logical 1.

## Other Torque Control Setting Ideas

51P1TC = **IN1** apply nominal control voltage to optoisolated input **IN1**, resulting in 51P1TC = logical 1; remove nominal control voltage to optoisolated input **IN1**, resulting in 51P1TC = logical 0

51P1TC = **LB2** assert local bit **LB2** via the front-panel pushbuttons/display, resulting in 51P1TC = logical 1; deassert local bit **LB2** via the front-panel pushbuttons/display, resulting in 51P1TC = logical 0

Many other torque control setting ideas are available with the flexibility of SELOGIC control equations.

## Curve Timing/Reset Timing

In addition to SELOGIC control equations setting 51P1TC, phase time-overcurrent element 51P1T curve timing/reset timing are subject to settings:

- 51PIP . pickup
- 51PIC . curve type
- 51P1TD . time dial
- 51PIRS electromechanical reset timing? (Y/N); see [Time-Overcurrent Element Setting Reference Information on page 4.2](#).

If reset timing setting 51PIRS = Y, element 51P1T reset timing emulates electromechanical reset timing. If current  $I_P$  goes above pickup setting 51PIP (element 51P1T is timing or already timed out) and then current  $I_P$  goes below pickup setting 51PIP, element 51P1T starts to time to reset, emulating electromechanical reset timing. Relay Word bit 51P1R (reset indication) = logical 1 when element 51P1T is fully reset.

If reset timing setting 51PIRS = N, element 51P1T reset timing is a one-cycle dropout. If current  $I_P$  goes above pickup setting 51PIP (element 51P1T is timing or already timed out) and then current  $I_P$  goes below pickup setting 51PIP, there is a one-cycle delay before element 51P1T fully resets. Relay Word bit 51P1R (reset indication) = logical 1 when element 51P1T is fully reset.

Any time current  $I_P$  goes above pickup setting 51PIP and element 51P1T starts timing, Relay Word bit 51P1R (reset indication) = logical 0. If the curve times out, Relay Word bit 51P1T (curve timeout indication) = logical 1.

## Disable Time-Overcurrent Element With Pickup Setting

If pickup setting 51PIP is set 51PIP = OFF, phase time-overcurrent element 51P1T is disabled all the time. Relay Word bits 51P1, 51P1T, and 51P1R all equal logical 0 at all times.


## Applications for Time-Overcurrent Element Relay Word Bits

Relay Word Bit	Relay Word Bit Definition	Application
51P1	pickup indication	Primarily for testing or other SELOGIC control equation applications. See <a href="#">Trip Logic on page 3.17</a> (setting ULTR). See <a href="#">Reclosing Relay on page 3.22</a> (setting 79BRS).
51P1T	curve timeout indication	Primarily for tripping or other SELOGIC control equation applications. See <a href="#">Trip Logic</a> (setting TR).
51P1R	reset indication	Primarily for testing.

The second phase time-overcurrent element in [Figure 3.9](#) (51P2T) and the other time-overcurrent elements operate similarly.

## Neutral Ground Time-Overcurrent Element

One neutral ground time-overcurrent element (51N1T) is available (see [Figure 3.10](#)). Its pickup setting (51N1P) is compared to the magnitude of the neutral ground current ( $I_N$ ). This current is from separate neutral current input channel IN (see [Figure 1.2](#)).



SELogic Setting 51N1TC Controls the Torque Control Switch


51N1TC State	Torque Control Switch Position	Setting 51N1RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle

**Figure 3.10 Neutral Ground Time-Overcurrent Element 51N1T**

To understand the operation of [Figure 3.10](#) for the neutral ground time-overcurrent element (51N1T), follow the explanation given for [Figure 3.9](#) for the first phase time-overcurrent element (51P1T), substituting  $I_N$  for  $I_P$  and like settings and Relay Word bits.

## Residual Ground Time-Overcurrent Element

One residual ground time-overcurrent element (51G1T) is available (see [Figure 3.11](#)). Its pickup setting (51G1P) is compared to the magnitude of the residual ground current ( $I_G = 3I_0$ , derived from  $I_A$ ,  $I_B$ , and  $I_C$ ).



SELogic Setting 51G1TC Controls the Torque Control Switch

51G1TC State	Torque Control Switch Position	Setting 51G1RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle


**Figure 3.11 Residual Ground Time-Overcurrent Element 51G1T**

To understand the operation of [Figure 3.11](#) for the residual ground time-overcurrent element (51G1T), follow the explanation given for [Figure 3.9](#) for the first phase time-overcurrent element (51P1T), substituting  $I_G$  for  $I_P$  and like settings and Relay Word bits.

## Negative-Sequence Time-Overcurrent Elements


**IMPORTANT:** See Appendix F for information on setting negative-sequence overcurrent elements.

Two negative-sequence time-overcurrent elements (51Q1T and 51Q2T) are available (see [Figure 3.12](#)). Their pickup settings (51Q1P and 51Q2P) are compared to the magnitude of the negative-sequence current ( $3I_2$ , derived from  $I_A$ ,  $I_B$ , and  $I_C$ ).



SELogic Setting 51Q1TC Controls the Torque Control Switch

51Q1TC State	Torque Control Switch Position	Setting 51Q1RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle



SELogic Setting 51Q2TC Controls the Torque Control Switch

51Q2TC State	Torque Control Switch Position	Setting 51Q2RS =	Reset Timing
Logical 1	Closed	Y	Electromechanical
Logical 0	Open	N	1 Cycle

**Figure 3.12 Negative-Sequence Time-Overcurrent Elements 51Q1T and 51Q2T**

To understand the operation of [Figure 3.12](#) for the negative-sequence time-overcurrent elements (51Q1T and 51Q2T), follow the explanation given for [Figure 3.9](#) for the first phase time-overcurrent element (51P1T), substituting  $3I_2$  for  $I_p$  and like settings and Relay Word bits.

# Trip Logic


The trip logic in [Figure 3.13](#) provides flexible tripping with SELOGIC control equation settings:

TR . Trip Conditions

ULTR . Unlatch Trip Conditions

and setting:

TDURD Minimum Trip Duration Time



**Figure 3.13** Trip Logic

## Set Trip

Any time setting TR = logical 1, Relay Word bit TRIP asserts to logical 1, regardless of other trip logic conditions.

As shown in the time line example in [Figure 3.13](#), the Minimum Trip Duration Timer (setting TDURD) outputs a logical 1 for a time duration of “TDURD” cycles any time it sees a rising edge on its input (logical 0 to logical 1 transition), if it is not already timing. The TDURD timer assures that the TRIP Relay Word bit remains asserted at logical 1 for a minimum of “TDURD” cycles. If SELOGIC control equation setting TR = logical 1 beyond the TDURD time, Relay Word bit TRIP remains asserted at logical 1 for as long as TR = logical 1.

Execution of the serial communications port **OPEN** command causes the TRIP Relay Word bit to assert to logical 1 if the TDURD timer is set greater than zero (0) cycles.

## Unlatch Trip

Once Relay Word bit TRIP is asserted to logical 1, it remains asserted at logical 1 until all the following conditions come true:

- ▶ Trip Duration Timer stops timing (output of the TDURD timer goes to logical 0),
- ▶ SELOGIC control equation setting TR deasserts to logical 0,

and one of the following occurs:

- ▶ SELOGIC control equation setting ULTR asserts to logical 1,
- ▶ The front-panel {TARGET RESET} pushbutton is pressed,
- ▶ Or the **TAR R** (Target Reset) command is executed via the serial port.

The front-panel {TARGET RESET} pushbutton or **TAR R** (Target Reset) serial port command is primarily used during testing only (the **TAR R** serial port command can also be effectively operated via Modbus<sup>®</sup> protocol—see [Appendix G: Modbus RTU Communications Protocol](#)). They are used to deassert the TRIP Relay Word bit to logical 0 if test conditions are such that setting ULTR does not assert to logical 1 to automatically deassert the TRIP Relay Word bit instead.

## Other Applications for the Target Reset Function

Refer to the bottom of [Figure 3.13](#). Note that the combination of the {TARGET RESET} pushbutton and the **TAR R** (Target Reset) serial port command is also available as Relay Word bit TRGTR.

## Factory Settings Example

The factory settings for the trip logic SELOGIC control equation settings are:

TR = **51P1T + 51G1T + 50P1\*SH0 + LB3** (trip conditions)

ULTR = **!(51P1 + 51G1)** (unlatch trip conditions)

The factory setting for the Minimum Trip Duration Timer setting is:

TDURD = **9.000 cycles**

See the setting sheets in [Section 4: Setting the Relay](#) for setting ranges.

## Set Trip

In SELOGIC control equation setting TR = 51P1T + 51G1T + 50P1\*SH0 + LB3:

- ▶ Time-overcurrent elements 51P1T and 51G1T trip directly.
- ▶ Phase instantaneous overcurrent element 50P1 is supervised by Relay Word bit SH0 in an ANDed condition (50P1\*SH0). Element 50P1 can only get through to trip when SH0 = logical 1 (reclosing relay is at shot = 0). After the first trip in a reclose cycle, the shot increments from 0 to 1, SH0 = logical 0, and element 50P1 can then not get through to trip. See [Reclosing Relay on page 3.22](#) for more information on reclosing relay operation.
- ▶ Local bit LB3 trips directly (operates as a manual trip switch via the front-panel). See [Local Control Switches on page 3.5](#) and [Section 6: Front-Panel Interface](#) for more information on local control.

With setting TDURD = 9.000 cycles, once the TRIP Relay Word bit is asserted via the **OPEN** command or setting TR, it remains asserted at logical 1 for a minimum of nine cycles.

## Unlatch Trip

In SELOGIC control equation setting  $ULTR = !(51P1 + 51G1)$ :

- Both time-overcurrent element pickups 51P1P and 51G1P must be deasserted before the trip logic unlatches and the TRIP Relay Word bit deasserts to logical 0.

$$ULTR = !(51P1 + 51G1) = NOT(51P1 + 51G1) = NOT(51P1) * NOT(51G1)$$

## Additional Settings Examples

The factory setting for SELOGIC control equation setting ULTR is a current-based trip unlatch condition. A circuit breaker status unlatch trip condition can be programmed as shown in the following examples.

### Unlatch Trip With 52a Circuit Breaker Auxiliary Contact

A 52a circuit breaker auxiliary contact is wired to optoisolated input **IN1**.

52A = **IN1** (SELOGIC Control Equation Breaker Status Setting—see [Close Logic on page 3.20](#))

$$ULTR = !IN1$$

Input **IN1** has to be de-energized (52a circuit breaker auxiliary contact has to be open) before the trip logic unlatches and the TRIP Relay Word bit deasserts to logical 0.

$$ULTR = !IN1 = NOT(IN1)$$

### Unlatch Trip With 52b Circuit Breaker Auxiliary Contact

A 52b circuit breaker auxiliary contact is wired to optoisolated input **IN1**.

52A = **!IN1** (SELOGIC Control Equation Breaker Status setting—see [Close Logic](#))

$$ULTR = IN1$$

Input **IN1** must be energized (52b circuit breaker auxiliary contact has to be closed) before the trip logic unlatches and the TRIP Relay Word bit deasserts to logical 0.

## Program an Output Contact for Tripping

In the factory settings, the resultant of the trip logic in [Figure 3.13](#) is routed to output contact **OUT1** with the following SELOGIC control equation:

$$OUT1 = TRIP$$

See [Output Contacts on page 3.39](#) for more information on programming output contacts.

# Close Logic

The close logic in *Figure 3.14* provides flexible circuit breaker closing/auto reclosing with SELOGIC control equation settings:


CL (close conditions, other than automatic reclosing or **CLOSE** command)

ULCL (unlatch close conditions, other than breaker status, close failure, or reclose initiation)

52A (breaker status)

and setting:

CFD (Close Failure Time)



**Figure 3.14 Close Logic**

## Set Close

If *all* the following are true:

- The unlatch close condition is not asserted (ULCL = logical 0),
- The circuit breaker is open (52A = logical 0),
- The reclose initiation condition (79RI) is not making a rising edge (logical 0 to logical 1) transition,
- And a close failure condition does not exist (Relay Word bit CF = 0),

then the CLOSURE Relay Word bit can be asserted to logical 1 if any *one* of the following occurs:

- The serial communications port **CLOSE** command is executed,
- A reclosing relay open interval times out,
- Or SELOGIC control equation setting CL goes from logical 0 to logical 1 (rising edge transition).

## Unlatch Close

If the CLOSE Relay Word bit is asserted at logical 1, it stays asserted at logical 1 until one of the following occurs:

- The unlatch close condition asserts (ULCL = logical 1),
- The circuit breaker closes (52A = logical 1),
- The reclose initiation condition (79RI) makes a rising edge (logical 0 to logical 1) transition,
- Or the Close Failure Timer times out (Relay Word bit CF = 1).

The Close Failure Timer is inoperative if setting  $CFD = 0$ . Then, the CLOSE Relay Word bit can be deasserted to logical 0 only if one of the following occurs:

- The unlatch close condition asserts (ULCL = logical 1),
- The circuit breaker closes (52A = logical 1),
- Or the reclose initiation condition (79RI) makes a rising edge (logical 0 to logical 1) transition.

## Factory Settings Example

The factory settings for the close/reclose logic SELOGIC control equation settings are:

CL = **LB4**  
ULCL = **TRIP**  
52A = **IN1**

The factory setting for the Close Failure Timer setting is:

CFD = **60.000 cycles**

See the setting sheets in [Section 4: Setting the Relay](#) for setting ranges.

## Set Close

SELOGIC control equation setting CL is set with local bit LB4. Local bit LB4 closes directly (operates as a manual close switch via the front panel). See [Local Control Switches on page 3.5](#) and [Section 6: Front-Panel Interface](#) for more information on local control.

## Unlatch Close

SELOGIC control equation setting ULCL is set with the TRIP Relay Word bit. This prevents the CLOSE Relay Word bit from being asserted any time the TRIP Relay Word bit is asserted (TRIP takes priority). See [Trip Logic on page 3.17](#).

SELOGIC control equation setting 52A is set with optoisolated input IN1. Input IN1 is connected to a 52a circuit breaker auxiliary contact. Setting 52A operates on 52a circuit breaker auxiliary contact logic. When a closed circuit breaker condition is detected, the CLOSE Relay Word bit is deasserted to logical 0. Setting 52A can handle a 52a or 52b circuit breaker auxiliary contact connected to an optoisolated input (see [Optoisolated Inputs on page 3.3](#) for more 52A setting examples).

With setting  $CFD = 60.000$  cycles, once the CLOSE Relay Word bit is asserted, it can remain asserted at logical 1 for no longer than a *maximum* of 60 cycles.

## Defeat the Close Logic

If SELOGIC control equation setting 52A is set with numeral 0 (52A = 0), then the close logic is inoperable. Also, the reclosing relay is rendered nonexistent (see [Reclosing Relay on page 3.22](#)).

## Program an Output Contact for Closing

In the factory settings, the resultant of the close logic in [Figure 3.14](#) is routed to output contact **OUT2** with the following SELOGIC control equation:

OUT2 = **CLOSE**

See [Output Contacts on page 3.39](#) for more information on programming output contacts.

# Reclosing Relay

Note that the output of the reclosing relay logic (Reclosing Relay Open Interval Time-Out) is an input into the close logic in [Figure 3.14](#). The CLOSE Relay Word bit can be assigned to an output contact and provide automatic reclosing, in addition to closing via the **CLOSE** command or the SELOGIC control equation setting CL. Up to four (4) automatic reclose attempts (shots) can be made.

## Reclosing Relay States and General Operation

[Figure 3.15](#) explains in general the different states of the reclosing relay and its operation.




Figure 3.15 Reclosing Relay States and General Operation

**Table 3.5 Relay Word Bit and Front-Panel Correspondence to Reclosing Relay States**

Reclosing Relay State	Corresponding Relay Word Bit	Corresponding Front-Panel LED
Reset	79RS	RS
Reclose Cycle	79CY	None
Lockout	79LO	L0

The reclosing relay is in one and only one of these states (listed in [Table 3.5](#)) at any time. When in a given state, the corresponding Relay Word bit asserts to logical 1, and the LED illuminates. Automatic reclosing only takes place when the relay is in the Reclose Cycle State.

## Lockout State

The reclosing relay goes to the Lockout State if any *one* of the following occurs:

- The shot counter is equal to or greater than last shot at time of reclose initiation (e.g., all automatic reclosing attempts are unsuccessful—see [Figure 3.16](#)).
- Reclose initiation is unsuccessful because of SELOGIC control equation setting 79RIS [see [Reclose Initiate and Reclose Initiate Supervision Settings \(79RI and 79RIS, Respectively\) on page 3.27](#)].
- The circuit breaker opens without reclose initiation (e.g., an external trip).
- The shot counter is equal to or greater than last shot, and the circuit breaker is open [e.g., the shot counter is driven to last shot with SELOGIC control equation setting 79DLS while open interval timing is in progress. See [Drive-to-Lockout and Drive-to-Last Shot Settings \(79DTL and 79DLS, Respectively\) on page 3.29](#)].
- The close failure timer (setting CFD) times out (see [Figure 3.14](#)).
- SELOGIC control equation setting 79DTL = logical 1 [see [Drive-to-Lockout and Drive-to-Last Shot Settings \(79DTL and 79DLS, Respectively\)](#)].
- Open Command (**OPE**) is executed and SELOGIC control equation setting 79RI = TRIP + ...). [Early SEL-551 firmware versions do not have this feature (see [Appendix A: Firmware and Manual Versions](#)). To effectively incorporate this feature into these firmware versions, set SELOGIC control equation setting 79DTL = OC + ... (and 79RI = TRIP + ...). Relay Word bit OC asserts to logical 1 for 1/8 cycle when the Open Command is executed (see [Table 4.3](#) and [Table 4.4](#)). See [OPE Command \(Open\) on page 5.23](#).]
- A new reclose initiation occurs while the reclosing relay is timing on an open interval (e.g., flashover in the tank while breaker is open).

## Reclosing Relay States and Settings Changes

If a settings change is made, *all* of the following occur:

- The reclosing relay remains in the state it was in before the settings change,
- The shot counter is driven to last shot (last shot corresponding to the new settings; see discussion on last shot that follows),
- And the reset timer is loaded with reset time setting 79RSLD (see discussion on reset timing that follows).

If the relay happened to be in the Reclose Cycle State and was timing on an open interval before the settings change, the relay would be in the Reclose Cycle State after the settings change, but the relay would immediately go to the Lockout State. This is because the breaker is open, and the relay is at last shot after the settings change, and thus no more automatic reclosures are available.

If the breaker remains closed through the settings change, the reset timer times out on reset time setting 79RSLD after the settings change and goes to the Reset State (if it is not already in the Reset State), and the shot counter returns to shot = 0. If the relay happens to trip during this reset timing, the relay will immediately go to the Lockout State, because shot = last shot.

## Existence or Nonexistence of the Reclosing Relay

If any one of the following reclosing relay settings are made:

- Open interval time setting 79OI1 = 0.000
- SELOGIC control equation setting 79RI = 0
- SELOGIC control equation setting 79RIS = 0

then the reclosing relay does not exist, and no automatic reclosing takes place. These settings are explained later in this section. See also the setting sheets in [Section 4: Setting the Relay](#).

If the *reclosing relay does not exist*, the following also occur:

- All three reclosing relay state Relay Word bits (79RS, 79CY, and 79LO) are deasserted to logical 0 (see [Table 3.5](#)).
- All shot counter Relay Word bits (SH0, SH1, SH2, SH3, and SH4) are deasserted to logical 0 (the shot counter is explained later in this section).
- The front-panel LEDs **RS** and **LO** are extinguished.

---

**NOTE:** if the reclosing relay exists, but happens to be in the reclose cycle state, both the RS and LO LEDs are also extinguished.

## Close Logic Can Still Operate When Reclosing Relay Is Nonexistent

If the reclosing relay is nonexistent, the close logic (see [Figure 3.14](#)) can still operate if SELOGIC control equation setting 52A (circuit breaker status) is set to something other than numeral 0. Making the setting 52A = 0 defeats the close logic *and* also renders the reclosing relay nonexistent.

For example, if 52A = IN1, a 52a circuit breaker auxiliary contact is connected to input IN1. If the reclosing relay does not exist, the close logic still operates, allowing closing to take place via the **CLOSE** command or SELOGIC control equation setting CL (close conditions, other than auto reclosing or **CLOSE** command). See [Close Logic on page 3.20](#) for more discussion on SELOGIC control equation settings 52A and CL. Also see [Optoisolated Inputs on page 3.3](#) for more discussion on SELOGIC control equation setting 52A.

## Reclosing Relay Timer Settings

The open interval and reset timer factory settings are:

Timer Setting	Factory Setting (in cycles)	Definition
79OI1	30.000	open interval 1 time
79OI2	600.000	open interval 2 time
79OI3	0.000	open interval 3 time
79OI4	0.000	open interval 4 time
79RSD	1800.000	reset time from reclose cycle state
79RSLD	300.000	reset time from lockout state

The operation of these timers is affected by SELOGIC control equation settings discussed later in this section. Also see the setting sheets in [Section 4: Setting the Relay](#).

### Open Interval Timers

If an open interval time is set to zero, then that open interval time is not operable, *and* neither are the open intervals times that follow it.

In the above factory settings, the open interval time setting 79OI3 is the first open interval time setting set equal to zero:

$$79OI3 = 0.000 \text{ cycles}$$

Thus, open interval times 79OI3 and 79OI4 are not operable. In the factory settings, both open interval times 79OI3 and 79OI4 are set to zero. But if the settings were:


$$79OI3 = 0.000 \text{ cycles}$$

$$79OI4 = 900.000 \text{ cycles (set to some value other than zero)}$$

open interval time 79OI4 would still be inoperative, because a preceding open interval time is set to zero (i.e., 79OI3 = 0.000).

If open interval time setting 79OI1 is set to zero (79OI1 = 0.000 cycles), no open interval timing takes place, and the reclosing relay is rendered nonexistent.

The open interval timers time consecutively; they do not have the same beginning time reference point. In the above factory settings, the open interval time setting 79OI1 times first. If the subsequent first reclosure is not successful, then open interval time setting 79OI2 times. If the subsequent second reclosure is not successful, the relay goes to the Lockout State. See the example time-line [Figure 3.16](#).



**Figure 3.16 Reclosing Sequence From Reset to Lockout With Factory Settings**

## Determination of Number of Reclosures (Last Shot)

The number of reclosures (last shot) is equal to the number of open interval time settings that precede the first open interval time setting set equal to zero.

In the above factory settings, two set open interval times precede the third open interval time, which is set to zero (79OI3 = 0.000):

79OI1 = **30.000**

79OI2 = **600.000**

79OI3 = **0.000**

For this example:

Number of reclosures (last shot) = 2 = the number of set open interval times that precede the first open interval set to zero.

## Reset Timer

The reset timer qualifies breaker closure before taking the relay to the reset state from the reclose cycle state or the lockout state. Breaker status is determined by the SELOGIC control equation setting 52A (see preceding [Close Logic on page 3.20](#) and [Optoisolated Inputs on page 3.3](#) for more discussion on SELOGIC control equation setting 52A).

### Setting 79RSD

Qualifies closures in the Reclose Cycle State. These closures would usually be automatic reclosures resulting from open interval time-out.

It is also the reset time used in sequence coordination schemes [see [Sequence Coordination \(79SEQ\) on page 3.34](#)].

### Setting 79RSLD

Qualifies closures in the Lockout State. These closures would usually be manual closures, external to the relay, via the **CLOSE** command or the SELOGIC control equation setting CL (see [Figure 3.14](#)).

Setting 79RSLD is also the reset timer used when the relay powers up or has its settings changed (see [Reclosing Relay States and General Operation on page 3.22](#)).

Typically, setting 79RSLD is set less than setting 79RSD. Setting 79RSLD emulates reclosing relays with motor-driven timers that have a relatively short reset time from the lockout position to the reset position.

The setting of 79RSD and 79RSLD is independent (setting 79RSLD can even be set greater than setting 79RSD, if desired). SELOGIC control equation setting 79BRS (block reset timing) can be set to control reset timing [see [Block Reset Timing \(79BRS\) on page 3.32](#)].

## Reclosing Relay Shot Counter

Refer to [Figure 3.16](#).

The shot counter increments for each reclose operation. For example, when the relay is timing on the first open interval, 79OI1, it is at shot = 0. When the open interval times out, the shot counter increments to shot = 1 and so forth for the set open intervals that follow. The shot counter cannot increment beyond the last shot for automatic reclosing (see preceding discussion on last shot). The shot counter resets back to shot = 0 when the reclosing relay returns to the Reset State.

**Table 3.6 Shot Counter Correspondence to Relay Word Bits and Open Interval Times**

Shot	Corresponding Relay Word Bit	Corresponding Open Interval
0	SH0	79OI1
1	SH1	79OI2
2	SH2	79OI3
3	SH3	79OI4
4	SH4	

When the shot counter is at a particular shot value (e.g., shot = 2), the corresponding Relay Word bit asserts to logical 1 (e.g., SH2 = logical 1).

The shot counter also increments for sequence coordination operation. The shot counter can increment beyond the last shot for sequence coordination [see [Sequence Coordination \(79SEQ\)](#)].

## Reclosing Relay SELogic Control Equation Settings Overview

SELogic Control Equation Setting	Factory Setting	Definition
79RI	TRIP	reclose initiate
79RIS	IN1	reclose initiate supervision
79DTL	!LB1+LB3	drive-to-lockout
79DLS	79LO	drive-to-last shot
79SKP	50P2*SH0	skip shot
79STL	TRIP	stall open interval timing
79BRS	$(51P1+51G1)*(79RS+79CY)$	block reset timing
79SEQ	0	sequence coordination

These settings are discussed in detail in the following text.

## Reclose Initiate and Reclose Initiate Supervision Settings (79RI and 79RIS, Respectively)

The reclose initiate setting 79RI is a rising-edge detect setting. The reclose initiate supervision setting 79RIS supervises setting 79RI. When setting 79RI senses a rising edge (logical 0 to logical 1 transition), setting 79RIS has to be at logical 1 (79RIS = logical 1) in order for open interval timing to be initiated.

If 79RIS = logical 0 when setting 79RI senses a rising edge (logical 0 to logical 1 transition), the relay goes to the Lockout State.

### Factory Settings Example

With factory settings:

79RI = **TRIP**

79RIS = **IN1**

the transition of the TRIP Relay Word bit from logical 0 to logical 1 initiates open interval timing only if the IN1 Relay Word bit is at logical 1 (IN1 = logical 1). Input IN1 is connected to a 52a breaker auxiliary contact and, thus, the circuit breaker has to be closed when the TRIP Relay Word bit asserts in order to initiate open interval timing.

If the circuit breaker is open (IN1 = logical 0) when the TRIP Relay Word bit asserts (logical 0 to logical 1 transition), the relay goes to the Lockout State. This helps prevent reclose initiation for such conditions as a flashover in the tank of an open circuit breaker.

### Additional Settings Example 1

The preceding settings example initiates open interval timing on rising-edge of the TRIP Relay Word bit. The following is an example of reclose initiation on the opening of the circuit breaker.

Input IN1 is connected to a 52a circuit breaker auxiliary contact.

With setting:

79RI = **!IN1**

the transition of the IN1 Relay Word bit from logical 1 to logical 0 (breaker opening) initiates open interval timing. Setting 79RI looks for a logical 0 to logical 1 transition, thus Relay Word bit IN1 is inverted in the 79RI setting [**!IN1** = NOT(IN1)].

The reclose initiate supervision setting 79RIS supervises setting 79RI. With settings:

79RI = **!IN1**

79RIS = **TRIP**

the transition of the IN1 Relay Word bit from logical 1 to logical 0 initiates open interval timing only if the TRIP Relay Word bit is at logical 1 (TRIP = logical 1). Thus, the TRIP Relay Word bit has to be asserted when the circuit breaker opens in order to initiate open interval timing. With a long enough setting of the Minimum Trip Duration Timer (TDURD), the TRIP Relay Word bit will still be asserted to logical 1 when the circuit breaker opens (see [Figure 3.13](#)).

If the TRIP Relay Word bit is at logical 0 (TRIP = logical 0) when the circuit breaker opens (logical 1 to logical 0 transition), the relay goes to the Lockout State. This helps prevent reclose initiation for circuit breaker openings caused by trips external to the relay.

### Other Settings Considerations

In the preceding factory setting example, the reclose initiate supervision setting (79RIS) includes input IN1, that is connected to a 52a breaker auxiliary contact.

79RIS = **IN1**

If a 52b breaker auxiliary contact is connected to input IN1, the reclose initiate supervision setting (79RIS) would be set as follows:

79RIS = **!IN1**

In the preceding additional setting example 1, the reclose initiate setting (79RI) includes input IN1, that is connected to a 52a breaker auxiliary contact.

79RI = **!IN1**

If a 52b breaker auxiliary contact is connected to input IN1, the reclose initiate setting (79RI) would be set as follows:

79RI = **IN1**

If no reclose initiate supervision is desired, make the following setting:

$$79RIS = 1 \text{ (numeral 1)}$$

Setting 79RIS = logical 1 at all times. Any time a logical 0 to logical 1 transition is detected by setting 79RI, open interval timing will be initiated (unless prevented by some other means).

As discussed previously, if *any one* of the following settings are made:

$$79RI = 0 \text{ (numeral 0)}$$

$$79RIS = 0 \text{ (numeral 0)}$$

the reclosing relay does not exist.

## Drive-to-Lockout and Drive-to-Last Shot Settings (79DTL and 79DLS, Respectively)

**NOTE:** See **OPE** Command (Open) for a possible 79DTL setting for SEL-551 relays with early firmware versions.

When 79DTL = logical 1, the reclosing relay goes to the Lockout State (Relay Word bit 79LO = logical 1) and the front-panel L0 (Lockout) LED illuminates.

When 79DLS = logical 1, the reclosing relay goes to the last shot, if the shot counter is not at a shot value greater than or equal to the calculated last shot (see preceding discussions on last shot determination and the shot counter).

### Factory Settings Example

The drive-to-lockout factory setting is:

$$79DTL = \text{!LB1} + \text{LB3}$$

Local bit LB1 is set to operate as a reclose enable switch (see [Local Control Switches on page 3.5](#)). When Relay Word bit LB1 = logical 1 (reclosing enabled), the relay is not driven to the Lockout State (assuming local bit LB3 = logical 0, too):

$$\text{!LB1} = \text{!(logical 1)} = \text{NOT(logical 1)} = \text{logical 0}$$

$$79DTL = \text{!LB1} + \text{LB3} = (\text{logical 0}) + \text{LB3} = \text{LB3}$$

When Relay Word bit LB1 = logical 0 (reclosing disabled), the relay is driven to the Lockout State:

$$\text{!LB1} = \text{!(logical 0)} = \text{NOT(logical 0)} = \text{logical 1}$$

$$79DTL = \text{!LB1} + \text{LB3} = (\text{logical 1}) + \text{LB3} = \text{logical 1}$$

Local bit LB3 is set to operate as a manual trip switch (see [Local Control Switches](#) and [Trip Logic on page 3.17](#)). When Relay Word bit LB3 = logical 0 (no manual trip), the relay is not driven to the Lockout State (assuming local bit LB1 = logical 1, too):

$$79DTL = \text{!LB1} + \text{LB3} = \text{NOT(LB1)} + (\text{logical 0}) = \text{NOT(LB1)}$$

When Relay Word bit LB3 = logical 1 (manual trip), the relay is driven to the Lockout State:

$$79DTL = \text{!LB1} + \text{LB3} = \text{NOT(LB1)} + (\text{logical 1}) = \text{logical 1}$$

The drive-to-last shot factory setting is:

$$79DLS = 79LO$$

Two open intervals are also set in the factory settings, resulting in last shot = 2. Anytime the relay is in the lockout state (Relay Word bit 79LO = logical 1), the relay is driven to last shot (if the shot counter is not already at a shot value greater than or equal to shot = 2):

$$79DLS = \mathbf{79LO} = \text{logical 1}$$

Thus, if local bit LB1 (reclose enable switch) is in the “disable reclosing” position (LB1 = logical 0) or local bit LB3 (manual trip switch) is operated, then the relay is driven to the Lockout State (by setting 79DTL) and subsequently last shot (by setting 79DLS).

### Additional Settings Example 1

The preceding drive-to-lockout factory settings example drives the relay to the Lockout State immediately when the reclose enable switch (local bit LB1) is put in the “reclosing disabled” position (Relay Word bit LB1 = logical 0):

$$79DTL = \mathbf{!LB1} + \dots = \text{NOT}(LB1) + \dots = \text{NOT}(\text{logical 0}) + \dots = \text{logical 1}$$

To disable reclosing, but not drive the relay to the Lockout State until the relay trips, make settings similar to the following:

$$79DTL = \mathbf{!LB1 * TRIP} + \dots$$

### Additional Settings Example 2

To drive the relay to the Lockout State for fault current above a certain level when tripping (e.g., level of phase instantaneous overcurrent element 50P3), make settings similar to the following:

$$79DTL = \mathbf{TRIP * 50P3} + \dots$$

### Other Settings Considerations

If no special drive-to-lockout or drive-to-last shot conditions are desired, make the following settings:

$$79DTL = \mathbf{0} \text{ (numeral 0)}$$

$$79DLS = \mathbf{0} \text{ (numeral 0)}$$

With settings 79DTL and 79DLS inoperative, the SEL-551 will still end up in the Lockout State (and at last shot) if an entire automatic reclose sequence is unsuccessful.

Overall, settings 79DTL or 79DLS are needed to take the SEL-551 to the Lockout State (or to last shot) for immediate circumstances.

## Skip Shot and Stall Open Interval Timing Settings (79SKP and 79STL, Respectively)

The skip shot setting 79SKP causes a reclose shot to be skipped. Thus, an open interval time is skipped, and the next open interval time is used instead.

If 79SKP = logical 1 at the instant of successful reclose initiation (see preceding discussion on settings 79RI and 79RIS), the relay increments the shot counter to the next shot and then loads the open interval time corresponding to the new shot (see [Table 3.6](#)). If the new shot turns out to be the “last shot,” no open interval timing takes place, and the relay goes to the Lockout State if the circuit breaker is open (see preceding discussion on last shot and shot counter).

After successful reclose initiation, open interval timing does not start until allowed by the stall open interval timing setting 79STL. If 79STL = logical 1, open interval timing is stalled. If 79STL = logical 0, open interval timing can proceed.

If an open interval time has not yet started timing (79STL = logical 1 still), the 79SKP setting is still processed. In such conditions (open interval timing has not yet started timing), if 79SKP = logical 1, the relay increments the shot counter to the next shot and then loads the open interval time corresponding to the new shot (see [Table 3.6](#)). If the new shot turns out to be the “last shot,” no open interval timing takes place, and the relay goes to the Lockout State if the circuit breaker is open (see preceding discussion on last shot and shot counter).

If the relay is in the middle of timing on an open interval and 79STL changes state to 79STL = logical 1, open interval timing stops where it is. If 79STL changes state back to 79STL = logical 0, open interval timing resumes where it left off.

## Factory Settings Example

The skip shot factory setting is:

$$79SKP = 50P2 * SH0$$

If shot = 0 (Relay Word bit SH0 = logical 1) and phase current is above the phase instantaneous overcurrent element 50P2 threshold (Relay Word bit 50P2 = logical 1), at the instant of successful reclose initiation, the shot counter is incremented from shot = 0 to shot = 1. Then, the first open interval time (setting 79OI1) is skipped, and the relay times on the second open interval time (setting 79OI2) instead.

Shot	Corresponding Relay Word Bit	Corresponding Open Interval	Open Interval Factory Setting
0	SH0	79OI1	30 cycles
1	SH1	79OI2	600 cycles

Note that the first open interval time (setting 79OI1) is a short time, while the following second open interval time (setting 79OI2) is significantly longer. For a high magnitude fault (greater than the phase instantaneous overcurrent element 50P2 threshold), the first open interval time is skipped, and open interval timing proceeds on the following second open interval time.

Once the shot is incremented to shot = 1, Relay Word bit SH0 = logical 0 and then setting 79SKP = logical 0, regardless of Relay Word bit 50P2.


The stall open interval timing factory setting is:

$$79STL = TRIP$$

After successful reclose initiation, open interval timing does not start as long as the trip condition is present (Relay Word bit TRIP = logical 1). As discussed previously, if an open interval time has not yet started timing (79STL = logical 1 still), the 79SKP setting is still processed. Once the trip condition goes away (Relay Word bit TRIP = logical 0), open interval timing can proceed.

## Additional Settings Example

If the relay is used on a feeder with a cogenerator, it is desirable that the reclosing does not take place into a line energized by an islanded generator. A potential transformer and voltage relay are installed on the line side of the circuit breaker, and a contact from the undervoltage relay is connected to input IN2 of the SEL-551.



**Figure 3.17 Voltage Relay (27/59) Provides Reclose Block Signal to SEL-551**

The contact from the voltage relay indicates the presence or absence of voltage. If line voltage is present, open interval timing is stalled. If line voltage is not present, open interval timing proceeds. This is realized with the following setting:

79STL = **IN2**

or

79STL = **!IN2**

depending on the nature of the contact from the voltage relay.

## Other Settings Considerations

If no special skip shot or stall open interval timing conditions are desired, make the following settings:

79SKP = **0** (numeral 0)

79STL = **0** (numeral 0)

## Block Reset Timing (79BRS)

The block reset timing setting 79BRS keeps the reset timer from timing. Depending on the reclosing relay state, the reset timer can be loaded with either reset time:

79RSD (Reset Time from Reclose Cycle)

or

79RSLD (Reset Time from Lockout)

Depending on how setting 79BRS is set, none, one, or both of these reset times can be controlled. If the reset timer is timing and then 79BRS asserts to:

79BRS = **logical 1**

reset timing is stopped and will not start timing again until 79BRS deasserts to:

79BRS = **logical 0**

When reset timing starts again, it will be with a fully-loaded reset time. Thus, successful reset timing has to be continuous.

## Factory Settings Example

The block reset timing setting is:

$$79BRS = (51P1 + 51G1) * (79RS + 79CY)$$

Relay Word bits 79RS and 79CY correspond to the Reset State and the Reclose Cycle State, respectively. The reclosing relay is in one and only one of the three reclosing relay states at any one time (see [Figure 3.15](#) and [Table 3.5](#)).

When the relay is in the Lockout State, Relay Word bits 79RS and 79CY are deasserted to logical 0. Thus, the factory 79BRS setting has no effect when the relay is in the Lockout State. When a circuit breaker is closed from lockout, there is usually cold load inrush that would momentarily pick up a time-overcurrent element [e.g., phase time-overcurrent element 51P1T pickup (51P1) asserts momentarily]. But, this assertion of pickup 51P1 has no effect on reset timing because the relay is in the Lockout State (79RS = logical 0, 79CY = logical 0). The relay will time immediately on reset time 79RSLD and take the relay from the Lockout State to the Reset State with no additional delay because 79BRS is deasserted to logical 0.

When the relay is not in the Lockout State, either Relay Word bit 79RS or 79CY is asserted to logical 1. Thus, the factory 79BRS setting can function to block reset timing if time-overcurrent pickup 51P1 or 51G1 is picked up. This helps prevent repetitive “trip-reclose” cycling.

## Additional Settings Example 1

The block reset timing setting can be set as:

$$79BRS = (51P1 + 51G1) * 79CY$$

Relay Word bit 79CY corresponds to the Reclose Cycle State. The reclosing relay is in one of the three reclosing relay states at any one time (see [Figure 3.15](#) and [Table 3.5](#)).

When the relay is in the Reset or Lockout States, Relay Word bit 79CY is deasserted to logical 0. Thus, the 79BRS setting has no effect when the relay is in the Reset or Lockout States. When a circuit breaker is closed from lockout, there could be cold load inrush current that momentarily picks up a time-overcurrent element [e.g., phase time-overcurrent element 51P1T pickup (51P1) asserts momentarily]. But, this assertion of pickup 51P1 has no effect on reset timing because the relay is in the Lockout State (79CY = logical 0). The relay will time immediately on reset time 79RSLD and take the relay from the Lockout State to the Reset State with no additional delay because 79BRS is deasserted to logical 0.

When the relay is in the Reclose Cycle State, Relay Word bit 79CY is asserted to logical 1. Thus, the factory 79BRS setting can function to block reset timing if time-overcurrent pickup 51P1 or 51G1 is picked up while the relay is in the Reclose Cycle State. This helps prevent repetitive “trip-reclose” cycling.

## Additional Settings Example 2

If the block reset timing setting is:

$$79BRS = 51P1 + 51G1$$

then reset timing is blocked if time-overcurrent pickup 51P1 or 51G1 is picked up, regardless of the reclosing relay state.

### Sequence Coordination (79SEQ)

The sequence coordination setting 79SEQ keeps the SEL-551 in step with a downstream line recloser in a sequence coordination scheme, which prevents overreaching SEL-551 overcurrent elements from tripping for faults beyond the line recloser. This is accomplished by incrementing the shot counter and supervising overcurrent elements with resultant shot counter elements.

In order for the sequence coordination setting 79SEQ to increment the shot counter, both the following conditions must be true:

- No trip present (Relay Word bit TRIP = logical 0)
- Circuit breaker closed (SELOGIC control equation setting 52A = logical 1, effectively)

The sequence coordination setting 79SEQ is usually set with some overcurrent element pickups. If the above two conditions are both true and a set overcurrent element pickup asserts for at least 1.25 cycles and then deasserts, the shot counter increments by one count. This assertion/ deassertion indicates that a downstream device (e.g., line recloser—see [Figure 3.18](#)) has operated to clear a fault. Incrementing the shot counter keeps the SEL-551 “in step” with the downstream device, as is shown in the following [Additional Settings Example 1](#) and [Additional Settings Example 2 on page 3.36](#).

Every time a sequence coordination operation occurs, the shot counter is incremented, and the reset timer is loaded up with reset time 79RSD. Sequence coordination can increment the shot counter beyond last shot, but no further than shot = 4. The shot counter returns to shot = 0 after the reset timer times out. Reset timing is subject to the previously discussed SELOGIC control equation setting 79BRS.

Sequence coordination operation does not change the reclosing relay state. For example, if the relay is in the Reset State and there is a sequence coordination operation, it remains in the Reset State.

## Factory Settings Example

Sequence coordination is not enabled in the factory settings:

$$79SEQ = 0$$


## Additional Settings Example 1

With sequence coordination setting:

$$79SEQ = 79RS * 51P1$$


sequence coordination is operable only when the relay is in the Reset State (79RS = logical 1).

Refer to [Figure 3.18](#).



**Figure 3.18 Sequence Coordination Between the SEL-551 and a Line Recloser**

Presume that the line recloser is set to operate twice on the fast curve and then twice on the slow curve. The slow curve is allowed to operate after two fast curve operations because the fast curves are then inoperative for tripping. The SEL-551 phase time-overcurrent element 51P1T is coordinated with the line recloser fast curve. The SEL-551 phase time-overcurrent element 51P2T is coordinated with the line recloser slow curve.



① Fault occurs beyond line recloser; ② fault cleared by line recloser fast curve; ③ line recloser recloses into fault; ④ fault cleared by line recloser slow curve.

**Figure 3.19 Operation of SEL-551 Shot Counter for Sequence Coordination With Line Recloser (Additional Settings Example 1)**

If the SEL-551 is in the Reset State (79RS = logical 1) and then a permanent fault beyond the line recloser occurs (fault current  $I_F$  in *Figure 3.18*), the line recloser fast curve operates to clear the fault. The SEL-551 also sees the fault. The phase time-overcurrent pickup 51P1 asserts and then deasserts without tripping, incrementing the SEL-551 shot counter from:

$$\text{shot} = 0 \text{ to shot} = 1$$

When the line recloser recloses its circuit breaker, the line recloser fast curve operates again to clear the fault. The SEL-551 also sees the fault again. The phase time-overcurrent pickup 51P1 asserts and then deasserts without tripping, incrementing the SEL-551 shot counter from:

$$\text{shot} = 1 \text{ to shot} = 2$$

The line recloser fast curve is now disabled after operating twice. When the line recloser recloses its circuit breaker, the line recloser slow curve operates to clear the fault. The SEL-551 does not operate on its faster-set phase time-overcurrent element 51P1T (51P1T is “below” the line recloser slow curve) because the shot counter is now at shot = 2. For this sequence coordination scheme, the SEL-551 SELOGIC control equation trip equation is:

$$\text{TR} = \mathbf{51P1T * (SH0 + SH1) + 51P2T}$$

With the shot counter at shot = 2, Relay Word bits SH0 (shot = 0) and SH1 (shot = 1) are both deasserted to logical 0. This keeps the 51P1T phase time-overcurrent element from tripping. The 51P1T phase time-overcurrent element is still operative and its pickup (51P1) can still assert and then deassert, thus continuing the sequencing of the shot counter to shot = 3, etc. The 51P1T phase time-overcurrent element cannot cause a trip because shot  $\geq$  2 and SH0 and SH1 both are deasserted to logical 0.

The shot counter returns to shot = 0 after the reset timer (loaded with reset time 79RSD) times out.

**NOTE:** Sequence coordination can increment the shot counter beyond last shot (last shot = 2 in this factory setting example), but no further than shot = 4.

The following Example 2 limits sequence coordination shot counter incrementing.

## Additional Settings Example 2

Review preceding *Additional Settings Example 1 on page 3.34*.

Assume that the line recloser in *Figure 3.18* is set to operate twice on the fast curve and then twice on the slow curve for faults beyond the line recloser.

Assume that the SEL-551 is set to operate once on 51P1T and then twice on 51P2T for faults between the SEL-551 and the line recloser. This results in the following trip setting:

$$\text{TR} = \mathbf{51P1T * (SH0) + 51P2T}$$

This requires that two open interval settings be made (see *Figure 3.16*). This corresponds to the last shot being:

$$\text{last shot} = 2$$

If the sequence coordination setting is:

$$79SEQ = \mathbf{79RS * 51P1}$$

and there is a permanent fault beyond the line recloser, the shot counter of the SEL-551 will increment all the way to shot = 4 (see *Figure 3.19*). If there is a coincident fault between the SEL-551 and line recloser, the SEL-551 will trip and go to the Lockout State. Any time the shot counter is at a value equal to or greater than last shot and the relay trips, it goes to the Lockout State.

To avoid this problem make the following sequence coordination setting:

$$79SEQ = 79RS * 51P1 * SH0$$


Refer to [Figure 3.20](#).

If the SEL-551 is in the Reset State ( $79RS = \text{logical } 0$ ) with the shot counter reset ( $\text{shot} = 0$ ;  $SH0 = \text{logical } 1$ ) and then a permanent fault beyond the line recloser occurs (fault current  $I_F$  in [Figure 3.18](#)), the line recloser fast curve operates to clear the fault. The SEL-551 also sees the fault. The phase time-overcurrent pickup  $51P1$  asserts and then deasserts without tripping, incrementing the relay shot counter from:

$$\text{shot} = 0 \text{ to } \text{shot} = 1$$

Now the SEL-551 cannot operate on its faster-set phase time-overcurrent element  $51P1T$  because the shot counter is at  $\text{shot} = 1$  ( $SH0 = \text{logical } 0$ ):

$$TR = 51P1T * (SH0) + 51P2T = 51P1T * (\text{logical } 0) + 51P2T = 51P2T$$



① Fault occurs beyond line recloser; ② fault cleared by line recloser fast curve; ③ line recloser recloses into fault; ④ fault cleared by line recloser slow curve.

**Figure 3.20 Operation of SEL-351 Relay Shot Counter for Sequence Coordination With Line Recloser (Additional Setting Example 2)**

The line recloser continues to operate for the permanent fault beyond it, but the SEL-551 shot counter does not continue to increment. Sequence coordination setting  $79SEQ$  is effectively disabled by the shot counter incrementing from  $\text{shot} = 0$  to  $\text{shot} = 1$ .

$$79SEQ = 79RS * 51P1 * SH0 = 79RS * 51P1 * (\text{logical } 0) = \text{logical } 0$$


The shot counter stays at  $\text{shot} = 1$ .

Thus, if there is a coincident fault between the SEL-551 and the line recloser, the SEL-551 will operate on  $51P2T$  and then reclose once, instead of going straight to the Lockout State ( $\text{shot} = 1 < \text{last shot} = 2$ ).

As stated earlier, the reset time setting  $79RSD$  takes the shot counter back to  $\text{shot} = 0$  after a sequence coordination operation increments the shot counter. Make sure that reset time setting  $79RSD$  is set long enough to maintain the shot counter at  $\text{shot} = 1$  as shown in [Figure 3.20](#).

# SELogic Control Equation Variables/Timers

Fourteen SELOGIC Variables (SV1–SV14) are available. Ten of these SELOGIC Variables have timer outputs, (SV5T–SV14T) (see [Figure 3.21](#)).



**Figure 3.21 SELogic Control Equation Variables/Timers**

## Factory Settings Example

**NOTE:** The following SELogic Variable Timer examples make use of output contacts. [Output Contacts on page 3.39](#) shows what output contacts are available in the SEL-551 relay.

In the factory SELOGIC control equation settings, a SELOGIC Variable Timer is used for a simple breaker failure scheme:

$$SV5 = \text{TRIP}$$

The TRIP Relay Word bit is run through a timer for breaker failure timing. Timer pickup setting SV5PU is set to the breaker failure time (SV5PU = 12 cycles). Timer dropout setting SV5DO is set for a two cycle dropout (SV5DO = 2 cycles). The output of the timer (Relay Word bit SV5T) operates output contact **OUT3** (SEL-551 factory setting only).

$$\text{OUT3} = \text{SV5T}$$

## Additional Settings Example


Another application idea is dedicated breaker failure protection (see [Figure 3.22](#)):

$$SV6 = \text{IN1 (breaker failure initiate)}$$

$$SV7 = (\text{SV7} + \text{IN1}) * (\text{50P1} + \text{50N1})$$

$$\text{OUT1} = \text{SV6T (retrip)}$$

$$\text{OUT2} = \text{SV7T (breaker failure trip)}$$



**Figure 3.22 Dedicated Breaker Failure Scheme Created With SELogic Variables/Timers**

Note that the above SELOGIC control equation setting SV7 creates a seal-in logic circuit (as shown in [Figure 3.22](#)) by virtue of SELOGIC control equation setting SV7 being set equal to Relay Word bit SV7:

$$SV7 = \underbrace{(SV7 + IN1)} * (50P1 + 50N1)$$

Optoisolated input **IN1** functions as a breaker failure initiate input. Phase instantaneous overcurrent element **50P1** and neutral ground instantaneous overcurrent element **50N1** function as fault detectors.

Timer pickup setting **SV6PU** provides retrip delay, if desired (can be set to zero). Timer dropout setting **SV6DO** holds the retrip output (output contact **OUT1**) closed for extra time if needed after the breaker failure initiate signal (**IN1**) goes away.

Timer pickup setting **SV7PU** provides breaker failure timing. Timer dropout setting **SV7DO** holds the breaker failure trip output (output contact **OUT2**) closed for extra time if needed after the breaker failure logic unlatches (fault detectors **50P1** and **50N1** drop out).

Note that [Figure 3.22](#) suggests the option of having output contacts **OUT3** and **OUT4** operate as additional breaker failure trip outputs. This is done by making the following SELOGIC control equation settings:

$$OUT3 = SV7T \text{ (breaker failure trip)}$$

$$OUT4 = SV7T \text{ (breaker failure trip)}$$

## Output Contacts

SELOGIC control equation settings **OUT1**–**OUT4** control Relay Word bits **OUT1**–**OUT4**, respectively. Relay Word bits **OUT1**–**OUT4** in turn control output contacts **OUT1** through **OUT4**, respectively. Dedicated alarm logic/circuitry controls the **ALARM** output contact. See [Figure 3.23](#) for the output contacts available with the SEL-551 relay.

### Factory Settings Example

In the factory SELOGIC control equation settings, three output contacts are used:

$$OUT1 = \mathbf{TRIP} \text{ (overcurrent tripping/manual tripping; see } \textit{Trip Logic on page 3.17})$$


$$OUT2 = \mathbf{CLOSE} \text{ (automatic reclosing/manual closing; see } \textit{Close Logic on page 3.20})$$

OUT3 = **SV5T** (breaker failure trip; see *SELOGIC Control Equation Variables/Timers* on page 3.38)

OUT4 = **0** (output contact **OUT4** not used-set to logical 0)

Figure 1.2 shows the factory configuration of the output contacts for the SEL-551 relay.

## Operation of Output Contacts for Different Output Contact Types



① **PULSE** command is also available via the front panel (**{CTRL}** pushbutton, output contact testing option). Execution of the **PULSE** command results in a logical 1 input into the above logic.

② Main board jumper **JMP13** allows output contact **OUT4** to operate as: regular output contact **OUT4** (**JMP13** in position **YOUT2**), an extra Alarm output contact (**JMP13** in position **ALARM**). See Figure 2.16 and Table 2.2 for more information.

Figure 3.23 Logic Flow for Example SEL-551 Output Contact Operation

## Output Contacts OUT1 Through OUT4

Refer to [Figure 3.23](#).

The execution of the serial port command **PULSE  $n$**  ( $n = \text{OUT1–OUT4}$ ) asserts the corresponding Relay Word bit (OUT1–OUT4) to logical 1. The assertion of SELOGIC control equation setting  $\text{OUT}_m$  ( $m = 1–4$ ) to logical 1 also asserts the corresponding Relay Word bit  $\text{OUT}_m$  ( $m = 1–4$ ) to logical 1.

The assertion of Relay Word bit  $\text{OUT}_m$  ( $m = 1–4$ ) to logical 1 causes the energization of the corresponding output contact  $\text{OUT}_m$  coil. Depending on the output contact type (a or b), the output contact closes or opens as demonstrated in [Figure 3.23](#). An a-type output contact is open when the output contact coil is de-energized and closed when the output contact coil is energized. A b-type output contact is closed when the output contact coil is de-energized and open when the output contact coil is energized.

Notice in [Figure 3.23](#) that all four possible combinations of output contact coil states (energized or de-energized) and output contact types (a or b) are demonstrated. See [Output Contact Jumpers \(SEL-551 With the Conventional Terminal Blocks Option\) on page 2.15](#) for output contact type options.

## ALARM Output Contact (SEL-551 Relay)

Refer to [Figure 3.23](#) and [Relay Self-Tests on page 8.16](#).

When the relay is OK, the **ALARM** output contact coil is energized. The alarm logic/circuitry keeps the **ALARM** output contact coil energized. Depending on the **ALARM** output contact type (a or b), the **ALARM** output contact closes or opens as demonstrated in [Figure 3.23](#). An a-type output contact is open when the output contact coil is de-energized and closed when the output contact coil is energized. A b-type output contact is closed when the output contact coil is de-energized and open when the output contact coil is energized.

To verify **ALARM** output contact mechanical integrity, execute the serial port command **PULSE ALARM**. Execution of this command momentarily de-energizes the **ALARM** output contact coil.

The Relay Word bit **ALARM** is deasserted to logical 0 when the relay is OK. When the serial port command **PULSE ALARM** is executed, the **ALARM** Relay Word bit momentarily asserts to logical 1. Also, when the relay enters Access Level 2, the **ALARM** Relay Word bit momentarily asserts to logical 1 (and the **ALARM** output contact coil is de-energized momentarily).

Notice in [Figure 3.23](#) that all possible combinations of **ALARM** output contact coil states (energized or de-energized) and output contact types (a or b) are demonstrated. See [Output Contact Jumpers \(SEL-551 With the Conventional Terminal Blocks Option\) on page 2.15](#) for output contact type options.

# Demand Ammetering

---

The demand ammetering settings (in [Table 3.7](#)) are available via the **SET** command (see [Table 4.1](#) and also [Demand Ammetering Settings \(see Figure 3.24 and Figure 3.26\) on page SET.5](#)). Also refer to [MET D Command \(Demand Ammeter\) on page 5.15](#).


The SEL-551 provides demand and peak demand ammetering for the following values:

Currents	
$I_{A,B,C,N}$	Input currents (A primary)
$I_G$	Residual ground current (A primary; $I_G = 3I_0 = I_A + I_B + I_C$ )
$3I_2$	Negative-sequence current (A primary)

These demand and peak demand values are thermal demand values. Thermal demand ammetering is explained in the following discussion.

## Thermal Demand Ammeter Operation


The example in [Figure 3.24](#) shows the response of a thermal demand ammeter to a step current input. The current input is at a magnitude of zero and then suddenly goes to an instantaneous level of 1.0 per unit (a “step”).



**Figure 3.24** Response of Thermal Demand Ammeter to a Step Input (Setting DMTC = 15 minutes)

## Thermal Demand Ammeter Response

The response of the thermal demand ammeter in [Figure 3.24](#) (bottom) to the step current input (top) is analogous to the series RC circuit in [Figure 3.25](#).



**Figure 3.25 Voltage  $V_S$  Applied to Series RC Circuit**

In the analogy:

Voltage  $V_S$  in *Figure 3.25* corresponds to the step current input *Figure 3.24* (top).

Voltage  $V_C$  across the capacitor in *Figure 3.25* corresponds to the response of the thermal demand ammeter in *Figure 3.24* (bottom).

If voltage  $V_S$  in *Figure 3.25* has been at zero ( $V_S = 0.0$  per unit) for some time, voltage  $V_C$  across the capacitor in *Figure 3.25* is also at zero ( $V_C = 0.0$  per unit). If voltage  $V_S$  is suddenly stepped up to some constant value ( $V_S = 1.0$  per unit), voltage  $V_C$  across the capacitor starts to rise toward the 1.0 per unit value. This voltage rise across the capacitor is analogous to the response of the thermal demand ammeter in *Figure 3.24* (bottom) to the step current input (top).

In general, as voltage  $V_C$  across the capacitor in *Figure 3.25* cannot change instantaneously, the thermal demand ammeter response is not immediate either for the increasing or decreasing applied instantaneous current. The thermal demand ammeter response time is based on the demand ammeter time constant setting DMTC (see *Table 3.7*). Note in *Figure 3.24* the thermal demand ammeter response (bottom) is at 90 percent (0.9 per unit) of full applied value (1.0 per unit) after a time period equal to setting DMTC = 15 minutes, referenced to when the step current input is first applied.

The SEL-551 updates thermal demand values approximately every two seconds.


## Demand Ammeter Settings

**NOTE:** Changing setting DMTC resets the demand ammeter values to zero. Demand current pickup settings PDEMP, NDAMP, GDAMP, and QDAMP can be changed without affecting the demand ammeters.

**Table 3.7 Demand Ammeter Settings and Settings Range**

Setting	Definition	Range
DMTC	Demand meter time constant	5, 10, 15, 30, or 60 minutes
PDEMP	Phase demand current pickup	OFF, 0.50–16.00 A {5 A nominal}, 0.10–3.20 A {1 A nominal}, in 0.01 A steps
NDAMP	Neutral ground demand current pickup	
GDAMP	Residual ground demand current pickup	
QDAMP	Negative-sequence demand current pickup	

The demand current pickup settings in *Table 3.7* are applied to demand current meter outputs as shown in *Figure 3.26*. For example, when residual ground demand current  $I_{G(DEM)}$  goes above corresponding demand pickup GDAMP, Relay Word bit GDEM asserts to logical 1. Use these demand current logic outputs (PDEM, NDEM, GDEM, and QDEM) to alarm for high loading or unbalance conditions. Use in other schemes such as the following example.




**Figure 3.26 Demand Current Logic Outputs**

### Demand Current Logic Output Application—Raise Pickup for Unbalance Current

During times of high loading, the residual ground overcurrent elements can see relatively high unbalance current  $I_G$  ( $I_G = 3I_0$ ). To avoid tripping on unbalance current  $I_G$ , use Relay Word bit GDEM to detect the residual ground (unbalance) demand current  $I_{G(DEM)}$  and effectively raise the pickup of the residual ground time-overcurrent element 51G1T. This is accomplished with the following settings from [Table 3.7](#), pertinent residual ground overcurrent element settings, and SELLOGIC control equation torque control setting 51G1TC (see [Figure 3.27](#)).

- DMTC = 5
- GDEMP = 1.0
- 51G1P = 1.50
- 50G1P = 2.30
- 51G1TC = !GDEM + GDEM \* 50G1

Refer to [Figure 3.26](#), [Figure 3.27](#), and [Figure 3.11](#).



**Figure 3.27 Raise Pickup of Residual Ground Time-Overcurrent Element for Unbalance Current**

### Residual Ground Demand Current Below Pickup GDEMP

When unbalance current  $I_G$  is low, unbalance demand current  $I_{G(DEM)}$  is below corresponding demand pickup  $GDEMP = 1.00$  A secondary, and Relay Word bit  $GDEM$  is deasserted to logical 0. This results in SELOGIC control equation torque control setting  $51G1TC$  being in the state:

$$\begin{aligned} 51G1TC &= \text{!}GDEM + GDEM * 50G1 = \text{NOT}(GDEM) + GDEM * 50G1 \\ &= \text{NOT}(\text{logical } 0) + (\text{logical } 0) * 50G1 = \text{logical } 1 \end{aligned}$$

Thus, the residual ground time-overcurrent element  $51G1T$  operates on its standard pickup:

$$51G1P = \mathbf{1.50 \text{ A secondary}}$$

If a ground fault occurs, the residual ground time-overcurrent element  $51G1T$  operates with the sensitivity provided by pickup  $51G1P = 1.50$  A secondary. The thermal demand ammeter, even with setting  $DMTC = 5$  minutes, does not respond fast enough to the ground fault to make a change to the effective residual ground time-overcurrent element pickup—it remains at 1.50 A secondary. Demand meters respond to more “slow moving” general trends.

### Residual Ground Demand Current Goes Above Pickup GDEMP

When unbalance current  $I_G$  increases, unbalance demand current  $I_{G(DEM)}$  follows, going above corresponding demand pickup  $GDEMP = 1.00$  A secondary, and Relay Word bit  $GDEM$  asserts to logical 1. This results in SELOGIC control equation torque control setting  $51G1TC$  being in the state:

$$\begin{aligned} 51G1TC &= \text{!}GDEM + GDEM * 50G1 = \text{NOT}(GDEM) + GDEM * 50G1 = \\ &= \text{NOT}(\text{logical } 1) + (\text{logical } 1) * 50G1 = \text{logical } 0 + 50G1 = 50G1 \end{aligned}$$

Thus, the residual ground time-overcurrent element 51G1T operates with an effective, less-sensitive pickup:

$$50G1P = 2.30 \text{ A secondary}$$

The reduced sensitivity keeps the residual ground time-overcurrent element 51G1T from tripping on higher unbalance current  $I_G$ .

### Residual Ground Demand Current Goes Below Pickup GDEMP Again

When unbalance current  $I_G$  decreases again, unbalance demand current  $I_{G(DEM)}$  follows, going below corresponding demand pickup  $GDEMP = 1.00 \text{ A secondary}$ , and Relay Word bit GDEM deasserts to logical 0. This results in SELLOGIC control equation torque control setting 51G1TC being in the state:

$$51G1TC = !GDEM + GDEM * 50G1 = NOT(GDEM) + GDEM * 50G1 = NOT(logical 0) + (logical 0) * 50G1 = logical 1$$

Thus, the residual ground time-overcurrent element 51G1T operates on its standard pickup again:

$$51G1P = 1.50 \text{ A secondary}$$

## View or Reset Demand Ammetering Information

### Via Serial Port

See *MET D Command (Demand Ammeter)* on page 5.15. The **MET D** command displays demand and peak demand ammetering for the following values:

Currents	
$I_{A,B,C,N}$	Input currents (A primary)
$I_G$	Residual ground current (A primary; $I_G = 3I_0 = I_A + I_B + I_C$ )
$3I_2$	Negative-sequence current (A primary)

The **MET RD** command resets the demand ammetering values. The **MET RP** command resets the peak demand ammetering values.

### Via Front Panel

The information and reset functions available via the previously discussed serial port commands **MET D**, **MET RD**, and **MET RP** are also available via the front-panel {METER} pushbutton. See *Figure 6.2*.

## Demand Ammetering Updating and Storage

The SEL-551 updates demand values approximately every two seconds.

The relay stores peak demand values to nonvolatile storage once per day (it overwrites the previous stored value if it is exceeded). Should the relay lose control power, it will restore the peak demand values saved by the relay at 23:50 hours on the previous day.

# Front-Panel Target LEDs

Refer to [Figure 2.5](#) for the arrangement of the target LEDs on the front panel of the SEL-551 relay.

**Table 3.8 SEL-551 Front-Panel Target LED Definitions**

LED	Definition
EN	Relay Enabled—see subsection <a href="#">Relay Self-Tests on page 8.16</a>
INST	Instantaneous trip—see further details following
A	Phase A involved in the fault—see further details following
B	Phase B involved in the fault—see further details following
C	Phase C involved in the fault—see further details following
N	Ground involved in the fault—see further details following
RS	Reclosing relay in the Reset State (follows Relay Word bit 79RS)
LO	Reclosing relay in the Lockout State (follows Relay Word bit 79LO)

## Further Target LED Details

### A, B, and C Target LEDs

The following overcurrent elements are used for phase targeting: 51P1, 51P1T, 51P2, 51P2T, 51Q1, 51Q1T, 51Q2, 51Q2T, 50P1, 50P2, 50P3, 50P4, 50P5, 50P6, 50Q1, 50Q2, 50A, 50B, 50C.

**NOTE:** Using elements that are not targeting elements (SV5T-SV14T, for example) in the TR equation may produce unexpected results.

The **A** target LED illuminates if any phase targeting element is asserted after the rising edge of TRIP, the asserted element is in the TR equation, and the phase A current (current input IA) is above the overcurrent element pickup. The **A** target LED also illuminates if a negative-sequence overcurrent element is asserted, the asserted element is in the TR equation, and phase A is involved in the fault.

The fault must be present for at least 1.5 cycles after the relay trips for reliable targeting.

The logic for the **B** target LED and **C** target LED is similar.

### N Target LED

The following overcurrent elements are used for ground targeting: 51N1, 51N1T, 51G1, 51G1T, 50N1, 50N2, 50G1, 50G2.

The **N** target LED illuminates if any ground targeting element is asserted after the rising edge of TRIP and the asserted element is in the TR equation.

The fault must be present for at least 1.5 cycles after the relay trips for reliable targeting.

### INST Target LED

The **INST** target LED illuminates if Relay Word bit TRIP asserts less than three cycles after a phase or ground targeting element asserts. Only the targeting elements included in the TR equation are considered.

## Target Reset/Lamp Test Front-Panel Pushbutton

When the Target Reset/Lamp Test front-panel pushbutton is pressed:

- ▶ all front-panel LEDs are illuminated for one (1) second
- ▶ and then the Fault Type target LEDs (INST, A, B, C, and N) are extinguished

### Other Applications for the Target Reset Function

Refer to the bottom of [Figure 3.13](#). The combination of the {TARGET RESET} pushbutton and the **TAR R** (Target Reset) serial port command is available as Relay Word bit TRGTR. Relay Word bit TRGTR pulses to logical 1 for one processing interval when the **TAR R** (Target Reset) serial port command is executed (the **TAR R** serial port command can also be effectively operated via Modbus protocol, too—see [Appendix G: Modbus RTU Communications Protocol](#)). Relay Word bit TRGTR asserts to logical 1 for as long as the {TARGET RESET} pushbutton is pressed.

# Section 4

## Setting the Relay

---

### Overview

---

Change or view settings with the **SET** and **SHOWSET** serial port commands and the front-panel {SET} pushbutton. [Table 4.1](#) lists the serial port **SET** commands.

**Table 4.1 Serial Port SET Commands**

Command	Settings Type	Description	Settings Sheets <sup>a</sup>
<b>SET</b>	Relay	Overcurrent elements, reclosing relay, timers, etc.	1–6
<b>SET L</b>	Logic	SELOGIC® Control Equations	7–9
<b>SET R</b>	SER	Sequential Events Recorder trigger conditions	14
<b>SET T</b>	Text	Front-panel default display text; local control text	12–13
<b>SET P</b>	Port	Rear serial port protocol settings	10
<b>SET P F</b>	Port	Front serial port protocol settings	10–11

<sup>a</sup> Located at end of this section.

View settings with the respective serial port **SHOWSET** commands (**SHO**, **SHO L**, **SHO R**, **SHO T**, **SHO P**). See [SHO Command \(Showset\)](#) on [page 5.16](#).

### Settings Changes Via the Front Panel

---

The relay front-panel {SET} pushbutton provides access to the Relay and Port settings only. Thus, the corresponding Relay and Port settings sheets that follow in this section can also be used when making these settings via the front panel. Refer to [Figure 6.3](#) for information on front-panel communications.

### Settings Changes Via the Serial Port

---

See [Section 5: Serial Port Communications and Commands](#) for information on serial port communications and relay access levels. To change a specific setting, enter the command:

**SET n s**

where:

- $n$  = L, R, T, P, P 1, P F, or P 2 (parameter  $n$  is not entered for the Relay settings)
- $s$  = the name of the specific setting you wish to jump to and begin setting. If  $s$  is not entered, the relay starts at the first setting.

When you execute the **SET** command, the relay presents a list of settings, one at a time. Enter a new setting, or press **<Enter>** to accept the existing setting. Editing keystrokes are shown in [Table 4.2](#).

**Table 4.2 SET Command Editing Keystrokes**

Press Key(s)	Results
<b>&lt;Enter&gt;</b>	Retains setting and moves to the next.
<b>^ &lt;Enter&gt;</b>	Returns to previous setting.
<b>&lt; &lt;Enter&gt;</b>	Returns to previous setting.
<b>&gt; &lt;Enter&gt;</b>	Moves to next setting.
<b>END &lt;Enter&gt;</b>	Exits editing session, then prompts you to save the settings.
<b>&lt;Ctrl+X&gt;</b>	Aborts editing session without saving changes.

The relay checks each entry to ensure that it is within the setting range. If it is not, an *Out of Range* message is generated, and the relay prompts for the setting again.

When settings are complete, the relay displays the new settings and prompts for approval to enable them. Answer **Y <Enter>** to enable the new settings. For about one second, while the active settings are updated, the relay is disabled and the **ALARM** output contact closes for the SEL-551 (assuming b-type output contact; see [Figure 3.23](#)).

## Time-Overcurrent Element Setting Reference Information

---

The following information describes the curve timing for the curve and time dial settings made for the time-overcurrent elements (see [Figure 3.9–Figure 3.12](#)). The time-overcurrent relay curves in [Figure 4.1–Figure 4.3](#) conform to IEEE C37.112-1996 IEEE Standard Inverse Time Characteristic Equations for Overcurrent Relays.

- $t_p$  = operating time in seconds
- $t_r$  = electromechanical induction-disk emulation reset time in seconds (if electromechanical reset setting is made)
- TD = time dial setting
- M = applied multiples of pickup current [for operating time ( $t_p$ ),  $M > 1$ ; for reset time ( $t_r$ ),  $M \leq 1$ ]


**Table 4.3 Equations Associated With U.S. Curves**

Curve Type	Operating Time	Reset Time	Figure
U1 (Moderately Inverse)	$t_p = TD \cdot \left( 0.0226 + \frac{0.0104}{M^{0.02} - 1} \right)$	$t_r = TD \cdot \left( \frac{1.08}{1 - M^2} \right)$	<i>Figure 4.1</i>
U2 (Inverse)	$t_p = TD \cdot \left( 0.180 + \frac{5.95}{M^2 - 1} \right)$	$t_r = TD \cdot \left( \frac{5.95}{1 - M^2} \right)$	<i>Figure 4.2</i>
U3 (Very Inverse)	$t_p = TD \cdot \left( 0.0963 + \frac{3.88}{M^2 - 1} \right)$	$t_r = TD \cdot \left( \frac{3.88}{1 - M^2} \right)$	<i>Figure 4.3</i>
U4 (Extremely Inverse)	$t_p = TD \cdot \left( 0.0352 + \frac{5.67}{M^2 - 1} \right)$	$t_r = TD \cdot \left( \frac{5.67}{1 - M^2} \right)$	<i>Figure 4.4</i>
U5 (Short-Time Inverse)	$t_p = TD \cdot \left( 0.00262 + \frac{0.00342}{M^{0.02} - 1} \right)$	$t_r = TD \cdot \left( \frac{0.323}{1 - M^2} \right)$	<i>Figure 4.5</i>


**Table 4.4 Equations Associated With IEC Curves**

Curve Type	Operating Time	Reset Time	Figure
C1 (Standard Inverse)	$t_p = TD \cdot \left( \frac{0.14}{M^{0.02} - 1} \right)$	$t_r = TD \cdot \left( \frac{13.5}{1 - M^2} \right)$	<i>Figure 4.6</i>
C2 (Very Inverse)	$t_p = TD \cdot \left( \frac{13.5}{M - 1} \right)$	$t_r = TD \cdot \left( \frac{47.3}{1 - M^2} \right)$	<i>Figure 4.7</i>
C3 (Extremely Inverse)	$t_p = TD \cdot \left( \frac{80}{M^2 - 1} \right)$	$t_r = TD \cdot \left( \frac{80}{1 - M^2} \right)$	<i>Figure 4.8</i>
C4 (Long-Time Inverse)	$t_p = TD \cdot \left( \frac{120}{M - 1} \right)$	$t_r = TD \cdot \left( \frac{120}{1 - M} \right)$	<i>Figure 4.9</i>
C5 (Short-Time Inverse)	$t_p = TD \cdot \left( \frac{0.05}{M^{0.04} - 1} \right)$	$t_r = TD \cdot \left( \frac{4.85}{1 - M^2} \right)$	<i>Figure 4.10</i>

4.4 | Setting the Relay  
**Time-Overcurrent Element Setting Reference Information**




**Figure 4.1 U.S. Moderately Inverse Curve: U1**




**Figure 4.2 U.S. Inverse Curve: U2**

4.6 | Setting the Relay  
**Time-Overcurrent Element Setting Reference Information**




**Figure 4.3 U.S. Very Inverse Curve: U3**




**Figure 4.4 U.S. Extremely Inverse Curve: U4**

4.8 | Setting the Relay  
**Time-Overcurrent Element Setting Reference Information**




**Figure 4.5 U.S. Short-Time Inverse Curve: U5**




**Figure 4.6 IEC Class A Curve (Standard Inverse): C1**

**4.10** | Setting the Relay  
**Time-Overcurrent Element Setting Reference Information**




**Figure 4.7 IEC Class B Curve (Very Inverse): C2**




**Figure 4.8 IEC Class C Curve (Extremely Inverse): C3**

4.12 | Setting the Relay  
**Time-Overcurrent Element Setting Reference Information**



**Figure 4.9 IEC Long-Time Inverse Curve: C4**



**Figure 4.10 IEC Short-Time Inverse Curve: C5**

# Relay Word Bit Setting Reference Information

Relay Word bits are used in SELOGIC control equation settings. See [Section 3: Relay Elements and Logic](#) for SELOGIC control equations details and examples. SELOGIC control equation settings can also be set directly to 1 (logical 1) or 0 (logical 0).

The Relay Word bit row numbers correspond to the row numbers used in the **TAR** command (see [TAR Command \(Target\)](#) on page 5.20).

**Table 4.5 SEL-551 Relay Word Bits**

Row <sup>a</sup>	SEL-551 Relay Word Bits							
1	51P1	51P2	51N1	51G1	51P1T	51P2T	51N1T	51G1T
2	51Q1	51Q2	51Q1T	51Q2T	50P1	50P2	50P3	50P4
3	50P5	50P6	50N1	50N2	50G1	50G2	50Q1	50Q2
4	50A	50B	50C	IN1	IN2	OC	CC	CF
5	LB1	LB2	LB3	LB4	LB5	LB6	LB7	LB8
6	RB1	RB2	RB3	RB4	RB5	RB6	RB7	RB8
7	SV1	SV2	SV3	SV4	SV5	SV6	SV7	SV8
8	SV9	SV10	SV11	SV12	SV13	SV14	*b	*b
9	79RS	79CY	79LO	SH0	SH1	SH2	SH3	SH4
10	TRIP	CLOSE	51PIR	51P2R	51N1R	51G1R	51Q1R	51Q2R
11	SV5T	SV6T	SV7T	SV8T	SV9T	SV10T	SV11T	SV12T
12	SV13T	SV14T	*b	ALARM	OUT1	OUT2	OUT3	OUT4
13	PDEM	NDEM	GDEM	QDEM	TRGTR	*b	*b	*b
TAR 14	*b	*b	*b	*b	*b	*b	*b	*b

<sup>a</sup> Row 0 used for front-panel LEDs and TAR command as shown in [Table 5.6](#). Row 0 targets are not available for SELOGIC control equations.  
<sup>b</sup> Reserved for future use.

**Table 4.6 Relay Word Bit Definitions (Sheet 1 of 4)**

Row	Bit	Definition	Primary Application
1	51P1	Maximum phase current above pickup setting 51P1P for phase time-overcurrent element 51P1T (see <a href="#">Figure 3.9</a> )	Event report triggering, Testing
	51P2	Maximum phase current above pickup setting 51P2P for phase time-overcurrent element 51P2T (see <a href="#">Figure 3.9</a> )	
	51N1	Neutral ground current (channel IN) above pickup setting 51N1P for neutral ground time-overcurrent element 51N1T (see <a href="#">Figure 3.10</a> )	
	51G1	Residual ground current above pickup setting 51G1P for residual ground time-overcurrent element 51G1T (see <a href="#">Figure 3.11</a> )	
	51P1T	1st phase time-overcurrent element timed out (see <a href="#">Figure 3.9</a> )	Tripping
	51P2T	2nd phase time-overcurrent element timed out (see <a href="#">Figure 3.9</a> )	
	51N1T	Neutral ground time-overcurrent element timed out (see <a href="#">Figure 3.10</a> )	
	51G1T	Residual ground time-overcurrent element timed out (see <a href="#">Figure 3.11</a> )	

**Table 4.6 Relay Word Bit Definitions (Sheet 2 of 4)**

Row	Bit	Definition	Primary Application
2	51Q1 <sup>a</sup>	Negative-sequence current above pickup setting 51Q1P for negative-sequence time-overcurrent element 51Q1T (see <a href="#">Figure 3.12</a> )	Event report triggering, Testing
	51Q2 <sup>a</sup>	Negative-sequence current above pickup setting 51Q2P for negative-sequence time-overcurrent element 51Q2T (see <a href="#">Figure 3.12</a> )	
	51Q1T <sup>a</sup>	First negative-sequence time-overcurrent element timed out (see <a href="#">Figure 3.12</a> )	Tripping
	51Q2T <sup>a</sup>	Second negative-sequence time-overcurrent element timed out (see <a href="#">Figure 3.12</a> )	
	50P1	First phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
	50P2	Second phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
	50P3	Third phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
	50P4	Fourth phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
3	50P5	Fifth phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
	50P6	Sixth phase instantaneous overcurrent element picked up (see <a href="#">Figure 3.4</a> )	
	50N1	First neutral ground instantaneous overcurrent element picked up (see <a href="#">Figure 3.6</a> )	
	50N2	Second neutral ground instantaneous overcurrent element picked up (see <a href="#">Figure 3.6</a> )	
	50G1	First residual ground instantaneous overcurrent element picked up (see <a href="#">Figure 3.7</a> )	
	50G2	Second residual ground instantaneous overcurrent element picked up (see <a href="#">Figure 3.7</a> )	
	50Q1 <sup>a</sup>	First negative-sequence instantaneous overcurrent element picked up (see <a href="#">Figure 3.8</a> )	
	50Q2 <sup>a</sup>	Second negative-sequence instantaneous overcurrent element picked up (see <a href="#">Figure 3.8</a> )	
4	50A	Single-phase instantaneous overcurrent element picked up (channel IA; see <a href="#">Figure 3.5</a> )	
	50B	Single-phase instantaneous overcurrent element picked up (channel IB; see <a href="#">Figure 3.5</a> )	
	50C	Single-phase instantaneous overcurrent element picked up (channel IC; see <a href="#">Figure 3.5</a> )	
	IN1	Optoisolated input IN1 asserted (see <a href="#">Figure 3.1</a> )	
	IN2	Optoisolated input IN2 asserted (see <a href="#">Figure 3.1</a> )	Circuit breaker status, etc.
	OC <sup>b</sup>	Asserts 1/8 cycle for Open Command execution (see <a href="#">Figure 3.13</a> )	
	CC <sup>b</sup>	Asserts 1/8 cycle for Close Command execution (see <a href="#">Figure 3.14</a> )	
	CF	Close Failure logic output asserted (see <a href="#">Figure 3.14</a> )	
			Indication

**Table 4.6 Relay Word Bit Definitions (Sheet 3 of 4)**

Row	Bit	Definition	Primary Application
5	LB1	Local Bit 1 asserted (see <a href="#">Figure 3.2</a> )	Enable/disable schemes, etc., from the front panel
	LB2	Local Bit 2 asserted (see <a href="#">Figure 3.2</a> )	
	LB3	Local Bit 3 asserted (see <a href="#">Figure 3.2</a> )	
	LB4	Local Bit 4 asserted (see <a href="#">Figure 3.2</a> )	
	LB5	Local Bit 5 asserted (see <a href="#">Figure 3.2</a> )	
	LB6	Local Bit 6 asserted (see <a href="#">Figure 3.2</a> )	
	LB7	Local Bit 7 asserted (see <a href="#">Figure 3.2</a> )	
	LB8	Local Bit 8 asserted (see <a href="#">Figure 3.2</a> )	
6	RB1	Remote Bit 1 asserted (see <a href="#">Figure 3.3</a> )	Enable/disable schemes, etc., from the serial port
	RB2	Remote Bit 2 asserted (see <a href="#">Figure 3.3</a> )	
	RB3	Remote Bit 3 asserted (see <a href="#">Figure 3.3</a> )	
	RB4	Remote Bit 4 asserted (see <a href="#">Figure 3.3</a> )	
	RB5	Remote Bit 5 asserted (see <a href="#">Figure 3.3</a> )	
	RB6	Remote Bit 6 asserted (see <a href="#">Figure 3.3</a> )	
	RB7	Remote Bit 7 asserted (see <a href="#">Figure 3.3</a> )	
	RB8	Remote Bit 8 asserted (see <a href="#">Figure 3.3</a> )	
7	SV1	SELOGIC Variable SV1 asserted (see <a href="#">Figure 3.21</a> )	Seal-in functions, etc.
	SV2	SELOGIC Variable SV2 asserted (see <a href="#">Figure 3.21</a> )	
	SV3	SELOGIC Variable SV3 asserted (see <a href="#">Figure 3.21</a> )	
	SV4	SELOGIC Variable SV4 asserted (see <a href="#">Figure 3.21</a> )	
	SV5	SELOGIC Variable SV5 timer input asserted (see <a href="#">Figure 3.21</a> )	Seal-in functions, Timing, etc.
	SV6	SELOGIC Variable SV6 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV7	SELOGIC Variable SV7 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV8	SELOGIC Variable SV8 timer input asserted (see <a href="#">Figure 3.21</a> )	
8	SV9	SELOGIC Variable SV9 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV10	SELOGIC Variable SV10 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV11	SELOGIC Variable SV11 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV12	SELOGIC Variable SV12 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV13	SELOGIC Variable SV13 timer input asserted (see <a href="#">Figure 3.21</a> )	
	SV14	SELOGIC Variable SV14 timer input asserted (see <a href="#">Figure 3.21</a> )	
9	79RS	Reclosing relay in the Reset State (see <a href="#">Figure 3.15</a> and <a href="#">Table 3.5</a> )	Tripping scheme supervision, Indication
	79CY	Reclosing relay in the Reclose Cycle State (see <a href="#">Figure 3.15</a> and <a href="#">Table 3.5</a> )	
	79LO	Reclosing relay in the Lockout State (see <a href="#">Figure 3.15</a> and <a href="#">Table 3.5</a> )	
	SH0	Reclosing relay shot counter = 0 (see <a href="#">Table 3.6</a> )	
	SH1	Reclosing relay shot counter = 1 (see <a href="#">Table 3.6</a> )	
	SH2	Reclosing relay shot counter = 2 (see <a href="#">Table 3.6</a> )	
	SH3	Reclosing relay shot counter = 3 (see <a href="#">Table 3.6</a> )	
	SH4	Reclosing relay shot counter = 4 (see <a href="#">Table 3.6</a> )	

**Table 4.6 Relay Word Bit Definitions (Sheet 4 of 4)**

Row	Bit	Definition	Primary Application
10	TRIP	Trip logic output asserted (see <a href="#">Figure 3.13</a> )	Output contact assignment
	CLOSE	Close logic output asserted (see <a href="#">Figure 3.14</a> )	
	51P1R	First phase time-overcurrent element reset (see <a href="#">Figure 3.9</a> )	Testing
	51P2R	Second phase time-overcurrent element reset (see <a href="#">Figure 3.9</a> )	
	51N1R	Neutral ground time-overcurrent element reset (see <a href="#">Figure 3.10</a> )	
	51G1R	Residual ground time-overcurrent element reset (see <a href="#">Figure 3.11</a> )	
	51Q1R	First negative-sequence time-overcurrent element reset (see <a href="#">Figure 3.12</a> )	
	51Q2R	Second negative-sequence time-overcurrent element reset (see <a href="#">Figure 3.12</a> )	
11	SV5T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	Timing
	SV6T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV7T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV8T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV9T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV10T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV11T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	SV12T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
12	SV13T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	Indication
	SV14T	SELOGIC Variable timer output asserted (see <a href="#">Figure 3.21</a> )	
	ALARM <sup>c</sup>	<b>ALARM</b> output contact indicating that relay failed or <b>PULSE ALARM</b> executed (see <a href="#">Figure 3.23</a> )	
	OUT1 <sup>c</sup>	Output contact <b>OUT1</b> asserted (see <a href="#">Figure 3.23</a> )	
	OUT2 <sup>c</sup>	Output contact <b>OUT2</b> asserted (see <a href="#">Figure 3.23</a> )	
	OUT3 <sup>c</sup>	Output contact <b>OUT3</b> asserted (see <a href="#">Figure 3.23</a> )	
	OUT4 <sup>c</sup>	Output contact <b>OUT4</b> asserted (see <a href="#">Figure 3.23</a> )	
13	PDEM	Phase demand current above pickup setting PDEMP (see <a href="#">Figure 3.26</a> )	Control
	NDEM	Neutral ground demand current above pickup setting NDEMP (see <a href="#">Figure 3.26</a> )	
	GDEM	Residual ground demand current above pickup setting GDEMP (see <a href="#">Figure 3.26</a> )	
	QDEM	Negative-sequence demand current above pickup setting QDEMP (see <a href="#">Figure 3.26</a> )	
	TRGTR	Target Rest. TRGTR pulses to logical 1 for one processing interval when the <b>TAR R</b> (Target Reset) serial port command is executed. TRGTR asserts to logical 1 for as long as the { <b>TARGET RESET</b> } pushbutton is pressed (see <a href="#">Figure 3.13</a> ).	

<sup>a</sup> **IMPORTANT:** See [Appendix F: Setting Negative-Sequence Overcurrent Elements](#) for special instructions on setting negative-sequence overcurrent elements.

<sup>b</sup> The Open Command (Relay Word Bit OC) and Close Command (Relay Word Bit CC) are already embedded in the Trip Logic (see [Figure 3.13](#)) and Close Logic (see [Figure 3.14](#)), respectively. Thus, they are likely not used in SELogic control equations. They are in the Relay Word for embedded event report information functions (see [Table 7.3](#)).

<sup>c</sup> Output contacts can be a or b type output contacts (see [Figure 2.15](#) and [Figure 3.23](#)).

# Settings Explanations

---

Note that most of the settings in the settings sheets that follow include references for additional information. The following explanations are for relay settings (accessed under the **SET** command) that do not have reference information anywhere else in the instruction manual.

## Identifier Labels

The SEL-551 has two identifier labels:

- the Relay Identifier (RID)
- the Terminal Identifier (TID)

The Relay Identifier is typically used to identify the relay or the type of protection scheme. Typical Terminal Identifiers include an abbreviation of the substation name and line terminal.

The relay tags each report (event report, meter report, etc.) with the Relay Identifier and Terminal Identifier. This allows you to distinguish the report as one generated for a specific breaker and substation.

RID and TID settings may include the following characters:

- 0–9
- A–Z,
- -, /, ., space

## Current Transformer Ratios

Phase and neutral current transformer ratios are set independently. If **IN** is connected residually with **IA**, **IB**, and **IC**, then set **CTR** and **CTRN** the same. For example, for a CT ratio of 600/5, set **CTR** = 120.

## CT Sizing

Sizing a CT to avoid saturation for the maximum asymmetrical fault is ideal, but not always possible. This requires a CT ANSI voltage classification greater than  $(1 + X/R)$  times the burden voltage for the maximum symmetrical fault current, where  $X/R$  is the reactance-to-resistance ratio of the primary system.

Use caution when selecting CTs for saturation conditions in the SEL-551 firmware revisions prior to SEL-551-R507-Vf Z001001-D20020828 and SEL-551-R108-Vr Z001001 D20020828 (see [Appendix A: Firmware and Manual Versions](#)). If you apply the SEL-551 in high-fault current situations, such as in power plant auxiliary buses with as much as 40000 A of line-to-line fault current, current transformers used with the SEL-551 should meet the following criterion:

$$262.5 \geq \left( \frac{X}{R} + 1 \right) \cdot I_f \cdot Z_b$$

**Equation 4.1**

where:

- $I_f$  = the maximum fault current in per unit of CT rating
- $Z_b$  = the CT burden in per unit of standard burden
- $X/R$  = the  $X/R$  ratio of the primary fault current

This ensures a two-cycle trip of an instantaneous element set at 80 A. The following examples show how the criterion is used.

## Example 1: Maximum Fault Current With an 80 A Instantaneous Setting

Maximum fault current in terms of primary CT and ANSI voltage rating, burden in ohms, and X/R ratio is:

$$I_{MAX} = \frac{262.5}{\left(1 + \frac{X}{R}\right)} \cdot \frac{ANSI}{100 \cdot Z_B} \cdot CT_{RATING}$$

**Equation 4.2**

*Equation 4.2* is an actual-value equation derived from Equation 1 above,

where:

$I_{MAX}$  = the maximum primary fault current for line-to-line fault

$CT_{RATING}$  = the CT primary rating in amperes

$Z_B$  = the total CT secondary burden in ohms

ANSI = the ANSI voltage classification of CTs

An SEL-551 phase instantaneous overcurrent element is to be set at 80 amps. The relay will be used with a C400, 400:5 current transformer with a 0.50 W ohm total burden. The X/R ratio is 20. Determine the maximum fault current for dependable operation.

The burden is primarily from the CT windings and external leads to the SEL-551 (the SEL-551 has a negligible burden):

Description	Quantity
300 feet full-circuit run of #10 AWG (1.0 Ω/1000-ft)	0.30
CT winding of 80 turns at 0.0025 Ω/turn	+ 0.20
Total burden	0.50 Ω

$$\begin{aligned} I_{MAX} &= \frac{262.5}{\left(1 + \frac{X}{R}\right)} \cdot \frac{ANSI}{100 \cdot Z_B} \cdot CT_{RATING} \\ &= \frac{262.5}{(1 + 20)} \cdot \frac{400}{100 \cdot 0.50\Omega} \cdot 400 \\ &= 40000 \text{ A} \end{aligned}$$

**Equation 4.3**

## Example 2: Minimum CT Rating With an 80 A Instantaneous Setting

CT rating in terms of maximum fault current, X/R ratio, ANSI rating, and burden is:

$$CT_{RATING} = \frac{\left(1 + \frac{X}{R}\right)}{262.5} \cdot \frac{100}{ANSI} \cdot I_{MAX} \cdot Z_B$$

**Equation 4.4**

With an 80 amp instantaneous setting, what is the minimum CT rating that can be used when the maximum fault current is 40000 amps, X/R = 20, and the burden is 0.50 Ω ohms?

$$\begin{aligned}
 CT_{RATING} &= \frac{\left(1 + \frac{X}{R}\right)}{262.5} \cdot \frac{100}{ANSI} \cdot I_{MAX} \cdot Z_B \\
 &= \frac{(1 + 20)}{262.5} \cdot \frac{100}{400} \cdot 40000 \cdot 0.50 \\
 &= 400 \text{ A}
 \end{aligned}$$

Equation 4.5

### Example 3: Determine Whether the Following Application Meets the Above Criteria

Description	Value
CTs used	400:5 A, class C400
Instantaneous element pickup setting	80 A secondary
Maximum current for a line-to-line fault	40000 A primary
X/R ratio	20
Total CT secondary burden	0.50 ohm

Apply [Equation 4.1](#) to verify if the CTs meet the required criteria.

$$\begin{aligned}
 \left(\frac{X}{R} + 1\right) \cdot I_f \cdot Z_b &= (20 + 1) \cdot \frac{40000}{400} \cdot \frac{0.50\Omega}{4} \\
 &= 262.5
 \end{aligned}$$

Equation 4.6

The calculation shows that the 400:5 (class C400) CT meets the criteria in [Equation 4.1](#).

## Other System Parameters

The relay settings NFREQ and PHROT allow you to configure the SEL-551 to your specific system.

- Set NFREQ equal to your nominal power system frequency, either 50 Hz or 60 Hz.
- Set PHROT equal to your power system phase rotation, either ABC or ACB.

Set DATE\_F to format the date displayed in relay reports and the front-panel display.

- Set DATE\_F to MDY to display dates in Month/Day/Year format.
- Set DATE\_F to YMD to display dates in Year/Month/Day format.

# Settings Sheets

The settings sheets that follow include the definition and input range for each setting in the relay. Refer to [Overcurrent Elements on page 1.6](#) for information on 5 A nominal and 1 A nominal ordering options and how they influence overcurrent element setting ranges.

# Settings Sheets for the SEL-551 Relay

## Relay Settings (SET Command)

### Identifier Labels (see [Settings Explanations on page 4.18](#))

Relay Identifier (12 characters)

**RID** = \_\_\_\_\_

Terminal Identifier (12 characters)

**TID** = \_\_\_\_\_

### Current Transformer Ratios (see [Settings Explanations on page 4.18](#))

Phase (IA, IB, IC) Current Transformer Ratio (1–6000) **CTR** = \_\_\_\_\_

Neutral (IN) Current Transformer Ratio (1–6000) **CTRN** = \_\_\_\_\_

### Minimum Trip Duration Timer (see [Figure 3.13](#))

Min. Trip Duration Time **TDURD** = \_\_\_\_\_  
(0–8000 cycles in 0.125-cycle increments)

### Phase Instantaneous Overcurrent Elements 50P1–50P6 (see [Figure 3.4](#))

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P1P** = \_\_\_\_\_

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P2P** = \_\_\_\_\_

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P3P** = \_\_\_\_\_

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P4P** = \_\_\_\_\_

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P5P** = \_\_\_\_\_

Pickup  
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50P6P** = \_\_\_\_\_

### Single-Phase Instantaneous Overcurrent Elements 50A, 50B, 50C (see [Figure 3.5](#))

Pickup  
 (OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)  
 (OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal) **50ABCP** = \_\_\_\_\_

### Phase Time-Overcurrent Element 51P1T (see [Figure 3.9](#))

Pickup  
 (OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal) **51P1P** = \_\_\_\_\_  
 (OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)  
 Curve (U1–U5, C1–C5; see [Figure 4.1–Figure 4.10](#)) **51P1C** = \_\_\_\_\_  
 Time Dial  
 0.50–15.00 for curves U1–U5 **51P1TD** = \_\_\_\_\_  
 0.05–1.00 for curves C1–C5  
 Electromechanical Reset (Y, N) **51P1RS** = \_\_\_\_\_

### Phase Time-Overcurrent Element 51P2T (see [Figure 3.9](#))

Pickup  
 (OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal) **51P2P** = \_\_\_\_\_  
 (OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)  
 Curve (U1–U5, C1–C5; see [Figure 4.1–Figure 4.10](#)) **51P2C** = \_\_\_\_\_  
 Time Dial  
 0.50–15.00 for curves U1–U5 **51P2TD** = \_\_\_\_\_  
 0.05–1.00 for curves C1–C5  
 Electromechanical Reset (Y, N) **51P2RS** = \_\_\_\_\_

### Neutral Ground Instantaneous Overcurrent Elements 50N1, 50N2 (see [Figure 3.6](#))

Pickup  
 (OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal) **50N1P** = \_\_\_\_\_  
 (OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)  
 Pickup  
 (OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal) **50N2P** = \_\_\_\_\_  
 (OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)

### Neutral Ground Time-Overcurrent Elements 51N1T (see [Figure 3.10](#))

Pickup  
 (OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal) **51N1P** = \_\_\_\_\_  
 (OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)

Curve (U1–U5, C1–C5; see <a href="#">Figure 4.1–Figure 4.10</a> )	51N1C	= _____
Time Dial		
0.50–15.00 for curves U1–U5		
0.05–1.00 for curves C1–C5	51N1TD	= _____
Electromechanical Reset (Y, N)	51N1RS	= _____

## Residual Ground Instantaneous Overcurrent Elements 50G1, 50G2 (see [Figure 3.7](#))

Pickup		
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)	50G1P	= _____
Pickup		
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)	50G2P	= _____

## Residual Ground Time-Overcurrent Elements 51G1T (see [Figure 3.11](#))

Pickup		
(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)	51G1P	= _____
Curve (U1–U5, C1–C5; see <a href="#">Figure 4.1–Figure 4.10</a> )	51G1C	= _____
Time Dial		
0.50–15.00 for curves U1–U5		
0.05–1.00 for curves C1–C5	51G1TD	= _____
Electromechanical Reset (Y, N)	51G1RS	= _____

## Negative-Sequence Instantaneous Overcurrent Elements 50Q1, 50Q2 (see [Figure 3.8](#))

**IMPORTANT:** See [Appendix F: Setting Negative-Sequence Overcurrent Elements](#) for information on setting negative-sequence overcurrent elements.

Pickup		
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)	50Q1P	= _____
Pickup		
(OFF, 0.5–80.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–16.0 A in 0.1 A increments) (1 A nominal)	50Q2P	= _____

## Negative-Sequence Time Overcurrent Element 51Q1T (see [Figure 3.12](#))

**IMPORTANT:** See [Appendix F: Setting Negative-Sequence Overcurrent Elements](#) for information on setting negative-sequence overcurrent elements.

Pickup		
(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)	<b>51Q1P</b>	= _____
Curve (U1–U5, C1–C5; see <a href="#">Figure 4.1–Figure 4.10</a> )	<b>51Q1C</b>	= _____
Time Dial		
0.50–15.00 for curves U1–U5		
0.05–1.00 for curves C1–C5	<b>51Q1TD</b>	= _____
Electromechanical Reset (Y, N)	<b>51Q1RS</b>	= _____

## Negative-Sequence Time Overcurrent Element 51Q2T (see [Figure 3.12](#))

**IMPORTANT:** See [Appendix F: Setting Negative-Sequence Overcurrent Elements](#) for information on setting negative-sequence overcurrent elements.

Pickup		
(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)		
(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)	<b>51Q2P</b>	= _____
Curve (U1–U5, C1–C5; see <a href="#">Figure 4.1–Figure 4.10</a> )	<b>51Q2C</b>	= _____
Time Dial		
0.50–15.00 for curves U1–U5		
0.05–1.00 for curves C1–C5	<b>51Q2TD</b>	= _____
Electromechanical Reset (Y, N)	<b>51Q2RS</b>	= _____

## Reclosing Relay Open Interval Timer (see [Reclosing Relay on page 3.22](#))

Open Interval 1 Time	<b>79OI1</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		
Open Interval 2 Time	<b>79OI2</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		
Open Interval 3 Time	<b>79OI3</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		
Open Interval 4 Time	<b>79OI4</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		

## Reclosing Relay Reset Timer (see [Reclosing Relay on page 3.22](#))

Reset Time from Reclose Cycle	<b>79RSD</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		
Reset Time from Lockout	<b>79RSLD</b>	= _____
(0–54000 cycles in 0.125 cycle increments)		

**Close Failure Timer (see Figure 3.14)**Close Failure Time (0–54000 cycles in 0.125 cycle increments) **CFD** = \_\_\_\_\_**Demand Ammetering Settings (see Figure 3.24 and Figure 3.26)**Time Constant (5, 10, 15, 30, 60 minutes) **DMTC** = \_\_\_\_\_

## Pickup Range

## Phase Pickup

(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)

(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)

**PDEMP** = \_\_\_\_\_

## Neutral Ground Pickup—channel IN

(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)

(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)

**NDEMP** = \_\_\_\_\_

## Residual Ground Pickup

(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)

(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)

**GDEMP** = \_\_\_\_\_

## Negative-Sequence Pickup

(OFF, 0.5–16.0 A in 0.1 A increments) (5 A nominal)

(OFF, 0.1–3.2 A in 0.1 A increments) (1 A nominal)

**QDEMP** = \_\_\_\_\_**SELogic® Variable Timers (see Figure 3.21)**SV5 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV5PU** = \_\_\_\_\_SV5 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV5DO** = \_\_\_\_\_SV6 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV6PU** = \_\_\_\_\_SV6 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV6DO** = \_\_\_\_\_SV7 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV7PU** = \_\_\_\_\_SV7 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV7DO** = \_\_\_\_\_SV8 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV8PU** = \_\_\_\_\_SV8 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV8DO** = \_\_\_\_\_SV9 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV9PU** = \_\_\_\_\_SV9 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV9DO** = \_\_\_\_\_SV10 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV10PU** = \_\_\_\_\_SV10 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV10DO** = \_\_\_\_\_SV11 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV11PU** = \_\_\_\_\_SV11 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV11DO** = \_\_\_\_\_SV12 Pickup Time (0–54000.000 cycles in 0.125-cycle steps) **SV12PU** = \_\_\_\_\_SV12 Dropout Time (0–54000.000 cycles in 0.125-cycle steps) **SV12DO** = \_\_\_\_\_

SV13 Pickup Time (0–54000.000 cycles in 0.125-cycle steps)	<b>SV13PU</b>	= _____
SV13 Dropout Time (0–54000.000 cycles in 0.125-cycle steps)	<b>SV13DO</b>	= _____
SV14 Pickup Time (0–54000.000 cycles in 0.125-cycle steps)	<b>SV14PU</b>	= _____
SV14 Dropout Time (0–54000.000 cycles in 0.125-cycle steps)	<b>SV14DO</b>	= _____

### Other System Parameters (see [Settings Explanations on page 4.18](#))

Nominal Frequency (50, 60 Hz)	<b>NFREQ</b>	= _____
Phase Rotation (ABC, ACB)	<b>PHROT</b>	= _____
Date Format (MDY, YMD)	<b>DATE_F</b>	= _____

## SELogic Control Equation Settings (SET L Command)

SELOGIC® control equations consist of Relay Word Bits (see [Table 4.5](#) and [Table 4.6](#)) and SELOGIC operators \* (AND), + (OR), ! (NOT), and ( ) (parentheses). See [Section 3: Relay Elements and Logic](#) for SELOGIC control equations details and examples. SELOGIC control equation settings can also be set directly to 1 (logical 1) or 0 (logical 0).

### Trip Logic (see [Figure 3.13](#))

Trip Conditions	<b>TR</b>	= _____
Unlatch Trip Conditions	<b>ULTR</b>	= _____

### Torque Control for Time-Overcurrent Elements (see [Figure 3.9–Figure 3.12](#))

NOTE: Torque control equation settings cannot be set directly to logical 0.

Phase Element 51P1T	<b>51P1TC</b>	= _____
Phase Element 51P2T	<b>51P2TC</b>	= _____
Neutral Ground Element 51N1T	<b>51N1TC</b>	= _____
Residual Ground Element 51G1T	<b>51G1TC</b>	= _____
Negative-Sequence Element 51Q1T	<b>51Q1TC</b>	= _____
Negative-Sequence Element 51Q2T	<b>51Q2TC</b>	= _____

### Close Logic (see [Figure 3.14](#))

Circuit Breaker Status	<b>52A</b>	= _____
Close Conditions (other than automatic reclosing or <b>CLOSE</b> command)	<b>CL</b>	= _____
ULCL Unlatch Close Conditions	<b>ULCL</b>	= _____

**Reclosing Relay (see [Reclosing Relay on page 3.22](#))**

Reclose Initiate	<b>79RI</b>	= _____
Reclose Initiate Supervision	<b>79RIS</b>	= _____
Drive to Lockout	<b>79DTL</b>	= _____
Drive to Last Shot	<b>79DLS</b>	= _____
Skip Shot	<b>79SKP</b>	= _____
Stall Open Interval Timing	<b>79STL</b>	= _____
Block Reset Timing	<b>79BRS</b>	= _____
Sequence Coordination	<b>79SEQ</b>	= _____

**Event Report Trigger Conditions (see [Standard 15-Cycle Event Reports on page 7.1](#))**

Event Report Trigger Condition 1	<b>ER1</b>	= _____
Event Report Trigger Condition 2	<b>ER2</b>	= _____

**SELOGIC Variables (see [Figure 3.21](#))**

SELOGIC Variable SV1	<b>SV1</b>	= _____
SELOGIC Variable SV2	<b>SV2</b>	= _____
SELOGIC Variable SV3	<b>SV3</b>	= _____
SELOGIC Variable SV4	<b>SV4</b>	= _____

**SELOGIC Variable Timer Inputs (see [Figure 3.21](#))**

SELOGIC Variable SV5	<b>SV5</b>	= _____
SELOGIC Variable SV6	<b>SV6</b>	= _____
SELOGIC Variable SV7	<b>SV7</b>	= _____
SELOGIC Variable SV8	<b>SV8</b>	= _____
SELOGIC Variable SV9	<b>SV9</b>	= _____
SELOGIC Variable SV10	<b>SV10</b>	= _____
SELOGIC Variable SV11	<b>SV11</b>	= _____
SELOGIC Variable SV12	<b>SV12</b>	= _____
SELOGIC Variable SV13	<b>SV13</b>	= _____
SELOGIC Variable SV14	<b>SV14</b>	= _____

## Output Contacts (see [Figure 3.23](#))

Output Contact OUT1	<b>OUT1</b>	= _____
Output Contact OUT2	<b>OUT2</b>	= _____
Output Contact OUT3	<b>OUT3</b>	= _____
Output Contact OUT4	<b>OUT4</b>	= _____

## Display Points (see [Rotating Default Display on page 6.11](#))

Display Point DP1	<b>DP1</b>	= _____
Display Point DP2	<b>DP2</b>	= _____
Display Point DP3	<b>DP3</b>	= _____
Display Point DP4	<b>DP4</b>	= _____
Display Point DP5	<b>DP5</b>	= _____
Display Point DP6	<b>DP6</b>	= _____
Display Point DP7	<b>DP7</b>	= _____
Display Point DP8	<b>DP8</b>	= _____

## Text Settings (SET T Command)

---

**NOTE:** Enter the following characters: 0-9, A-Z, -, /, ., space for each text label setting, subject to the specified character limit. Enter NA to null a label.

### Local Bit Labels (see [Table 3.3](#) and [Table 3.4](#))

Local Bit LB1 Name (14 characters)	<b>NLB1</b>	= _____
Clear Local Bit LB1 Label (7 characters)	<b>CLB1</b>	= _____
Set Local Bit LB1 Label (7 characters)	<b>SLB1</b>	= _____
Pulse Local Bit LB1 Label (7 characters)	<b>PLB1</b>	= _____
Local Bit LB2 Name (14 characters)	<b>NLB2</b>	= _____
Clear Local Bit LB2 Label (7 characters)	<b>CLB2</b>	= _____
Set Local Bit LB2 Label (7 characters)	<b>SLB2</b>	= _____
Pulse Local Bit LB2 Label (7 characters)	<b>PLB2</b>	= _____
Local Bit LB3 Name (14 characters)	<b>NLB3</b>	= _____
Clear Local Bit LB3 Label (7 characters)	<b>CLB3</b>	= _____
Set Local Bit LB3 Label (7 characters)	<b>SLB3</b>	= _____
Pulse Local Bit LB3 Label (7 characters)	<b>PLB3</b>	= _____

Local Bit LB4 Name (14 characters)	<b>NLB4</b>	= _____
Clear Local Bit LB4 Label (7 characters)	<b>CLB4</b>	= _____
Set Local Bit LB4 Label (7 characters)	<b>SLB4</b>	= _____
Pulse Local Bit LB4 Label (7 characters)	<b>PLB4</b>	= _____
Local Bit LB5 Name (14 characters)	<b>NLB5</b>	= _____
Clear Local Bit LB5 Label (7 characters)	<b>CLB5</b>	= _____
Set Local Bit LB5 Label (7 characters)	<b>SLB5</b>	= _____
Pulse Local Bit LB5 Label (7 characters)	<b>PLB5</b>	= _____
Local Bit LB6 Name (14 characters)	<b>NLB6</b>	= _____
Clear Local Bit LB6 Label (7 characters)	<b>CLB6</b>	= _____
Set Local Bit LB6 Label (7 characters)	<b>SLB6</b>	= _____
Pulse Local Bit LB6 Label (7 characters)	<b>PLB6</b>	= _____
Local Bit LB7 Name (14 characters)	<b>NLB7</b>	= _____
Clear Local Bit LB7 Label (7 characters)	<b>CLB7</b>	= _____
Set Local Bit LB7 Label (7 characters)	<b>SLB7</b>	= _____
Pulse Local Bit LB7 Label (7 characters)	<b>PLB7</b>	= _____
Local Bit LB8 Name (14 characters)	<b>NLB8</b>	= _____
Clear Local Bit LB8 Label (7 characters)	<b>CLB8</b>	= _____
Set Local Bit LB8 Label (7 characters)	<b>SLB8</b>	= _____
Pulse Local Bit LB8 Label (7 characters)	<b>PLB8</b>	= _____

## Display Point Labels

Display if DP1 = logical 1 (16 characters)	<b>DP1_1</b>	= _____
Display if DP1 = logical 0 (16 characters)	<b>DP1_0</b>	= _____
Display if DP2 = logical 1 (16 characters)	<b>DP2_1</b>	= _____
Display if DP2 = logical 0 (16 characters)	<b>DP2_0</b>	= _____
Display if DP3 = logical 1 (16 characters)	<b>DP3_1</b>	= _____
Display if DP3 = logical 0 (16 characters)	<b>DP3_0</b>	= _____
Display if DP4 = logical 1 (16 characters)	<b>DP4_1</b>	= _____
Display if DP4 = logical 0 (16 characters)	<b>DP4_0</b>	= _____
Display if DP5 = logical 1 (16 characters)	<b>DP5_1</b>	= _____
Display if DP5 = logical 0 (16 characters)	<b>DP5_0</b>	= _____

Display if DP6 = logical 1 (16 characters)	<b>DP6_1</b>	= _____
Display if DP6 = logical 0 (16 characters)	<b>DP6_0</b>	= _____
Display if DP7 = logical 1 (16 characters)	<b>DP7_1</b>	= _____
Display if DP7 = logical 0 (16 characters)	<b>DP7_0</b>	= _____
Display if DP8 = logical 1 (16 characters)	<b>DP8_1</b>	= _____
Display if DP8 = logical 0 (16 characters)	<b>DP8_0</b>	= _____

### Reclosing Relay Labels (see [Functions Unique to the Front-Panel Interface on page 6.4](#))

Reclosing Relay Last Shot Label (14 char.)	<b>79LL</b>	= _____
Reclosing Relay Shot Counter Label (14 char.)	<b>79SL</b>	= _____

## Port Settings (SET P Command and Front Panel)

### Rear Port (SET P) Rear Panel

Port Protocol (SEL, LMD, MOD)	<b>PROTOCOL</b>	= _____
-------------------------------	-----------------	---------

#### Communications Settings

LMD Prefix (@, #, \$, %, &) [PROTOCOL = LMD only]	<b>PREFIX</b>	= _____
LMD Address (1-99) [PROTOCOL = LMD only]	<b>ADDRESS</b>	= _____
LMD Settling Time (0-30 seconds) [PROTOCOL = LMD only]	<b>SETTLE_TIME</b>	= _____
Baud Rate (300, 1200, 2400, 4800, 9600, 19200, 38400) (38400 not available when PROTOCOL = MOD)	<b>SPEED</b>	= _____
Number Data Bits (7, 8) [PROTOCOL = SEL or LMD only]	<b>DATA_BITS</b>	= _____
Parity (Odd [O], Even [E], or None [N])	<b>PARITY</b>	= _____
Stop Bits (1, 2)	<b>STOP</b>	= _____
Modbus Slave ID (1-247) [PROTOCOL = MOD only]	<b>SLAVE</b>	= _____

## Other Rear Port Settings

Timeout (0–30 minutes) [PROTOCOL = SEL or LMD only]	<b>TIMEOUT</b> = _____
Send Auto Messages to Port (Y, N) [PROTOCOL = SEL or LMD only]	<b>AUTO</b> = _____
Enable Hardware Handshaking (Y, N) [PROTOCOL = SEL only]	<b>RTS_CTS</b> = _____
Fast Operate Enable (Y, N) [PROTOCOL = SEL or LMD only]	<b>FAST_OP</b> = _____

## Protocol Settings

Set PROTOCOL = SEL for standard SEL ASCII protocol.

Set PROTOCOL = LMD for SEL Distributed Port Switch protocol.

Set PROTOCOL = MOD for Modbus® RTU protocol.

Refer to [Appendix C: SEL Distributed Port Switch Protocol](#) for details on the LMD protocol.

Refer to [Appendix G: Modbus RTU Communications Protocol](#) for details on Modbus.

## Other Port Settings

Set TIMEOUT to the number of seconds of serial port inactivity for an automatic log out. Set TIMEOUT = 0 for no port time-out.

Set AUTO = Y to allow automatic messages at the serial port.

Set RTS\_CTS = Y to enable hardware handshaking. With RTS\_CTS = Y, the relay will not send characters until the CTS input is asserted. Also, if the relay is unable to receive characters, it deasserts the RTS line. Setting RTS\_CTS is not applicable for EIA-485 serial port option.

Set FAST\_OP = Y to enable binary Fast Operate messages at the serial port. Set FAST\_OP = N to block binary Fast Operate messages. Refer to [Appendix D: Configuration, Fast Meter, and Fast Operate Commands](#) for the description of the SEL-551 Fast Operate commands.

# Sequential Events Recorder Settings (SET R Command)

NOTE: Sequential Events Recorder settings consist of three trigger lists. Each trigger list can include up to 24 Relay Word bits delimited by spaces or commas. See [Sequential Events Recorder \(SER\) Event Report on page 7.8](#).

NOTE: Relay Word bits for the SEL-551 in Row 13 of [Table 4.5](#) cannot be used in the following SER settings.

SER Trigger List 1	<b>SER1</b> = _____
SER Trigger List 2	<b>SER2</b> = _____
SER Trigger List 3	<b>SER3</b> = _____

**This page intentionally left blank**

# Section 5

## Serial Port Communications and Commands

---

### Overview

---

The SEL-551 Relay is equipped with a serial communications port on the rear panel of the relay. Connect the serial port to a computer serial port for local communications or to a modem for remote communications. Other devices useful for communications include the SEL-2032, the SEL-2030, or the SEL-2020 Communications Processor.

You can use a variety of terminal emulation programs on your personal computer to communicate with the relay.

The SEL-551 can be ordered with either an EIA-232 or EIA-485 (4-wire) rear-panel serial port. The default settings for the serial port are:

- ▶ Baud Rate = 2400
- ▶ Data Bits = 8
- ▶ Parity = N
- ▶ Stop Bits = 1

To change the port settings, use the serial port **SET P** command (see [Section 4: Setting the Relay](#)) or the front-panel {SET} pushbutton.

### Port Connector and Communications Cables

---



**Figure 5.1** Nine-Pin Serial Communications Port Connector

Pinouts for EIA-232 and EIA-485 rear-panel serial communications port options are as follows:


Pin	EIA-232 Option	EIA-485 (4-wire) Option
1	N/C or +5 Vdc <sup>a</sup>	+TX
2	RXD	-TX
3	TXD	N/C
4	+IRIG-B	+IRIG-B
5	GND	SHIELD
6	-IRIG-B	-IRIG-B
7	RTS	+RX
8	CTS	-RX
9	GND	SHIELD

<sup>a</sup> Main board jumper JMP14 in the SEL-551 relay (see [Section 2: Installation](#)).


The following cable diagrams show several types of EIA-232 serial communications cables. These and other cables are available from SEL. Contact the factory for more information.

## SEL-551 to Computer

Cable SEL-C234A



Cable SEL-C227A



\*DTE = Data Terminal Equipment (Computer, Terminal, etc.)

## SEL-551 to Modem

Cable SEL-C222

<u>SEL-551 Relay</u>			<u>**DCE Device</u>	
9-Pin Male			25-Pin Female	
"D" Subconnector			"D" Subconnector	
Pin				Pin
<u>Func.</u>	<u>Pin #</u>		<u>Pin #</u>	<u>Func.</u>
GND	5	=====	7	GND
TXD	3	=====	2	TXD (IN)
RTS	7	=====	20	DTR (IN)
RXD	2	=====	3	RXD (OUT)
CTS	8	=====	8	CD (OUT)
GND	9	=====	1	GND

\*\*DCE = Data Communications Equipment (Modem, etc.)

## SEL-551 to SEL PRTU

Cable SEL-C231

<u>SEL-PRTU</u>			<u>SEL-551 Relay</u>	
9-Pin Male			9-Pin Male	
Round Conxall			"D" Subconnector	
Pin				Pin
<u>Func.</u>	<u>Pin #</u>		<u>Pin #</u>	<u>Func.</u>
GND	1	=====	5	GND
TXD	2	=====	2	RXD
RXD	4	=====	3	TXD
CTS	5	=====	7	RTS
+12	7	=====	8	CTS
GND	9	=====	9	GND

## SEL-551 to SEL-2032/ SEL-2030/SEL-2020

Cable SEL-C273A

<u>SEL Communications Processors</u>			<u>SEL-551 Relay</u>	
9-Pin Male			9-Pin Male	
"D" Subconnector			"D" Subconnector	
Pin				Pin
<u>Func.</u>	<u>Pin #</u>		<u>Pin #</u>	<u>Func.</u>
RXD	2	=====	3	TXD
TXD	3	=====	2	RXD
IRIG+	4	=====	4	IRIG+
GND	5	=====	5	GND
IRIG-	6	=====	6	IRIG-
RTS	7	=====	8	CTS
CTS	8	=====	7	RTS

**Table 5.1 Serial Communications Port Pin Function Definitions**

Pin Function	Definition
N/C	No Connection
+5 V dc	5 Volt DC Power Connection
RXD, RX	Receive Data
TXD, TX	Transmit Data
IRIG-B	IRIG-B Time-Code Input
GND	Ground
SHIELD	Shielded Ground
RTS	Request To Send
CTS	Clear To Send
DCD	Data Carrier Detect
DTR	Data Terminal Ready
DSR	Data Set Ready

For long-distance communications up to 500 meters and for electrical isolation of communications ports, use the SEL-2800 or SEL-2810 Fiber-Optic Transceivers. Contact SEL for more details on these devices.

## Communications Protocol

Serial communications with the relay includes hardware and software protocols.

### Hardware Protocol

SEL-551 relays equipped with an EIA-232 port support RTS/CTS hardware handshaking. RTS/CTS handshaking is not supported on relays equipped with just the EIA-485 port.

To enable hardware handshaking, use the **SET P** command (or front-panel {SET} pushbutton) to set `RTS_CTS = Y`. Disable hardware handshaking by setting `RTS_CTS = N`.

- If `RTS_CTS = N`, the relay permanently asserts the RTS line.
- If `RTS_CTS = Y`, the relay deasserts RTS when it is unable to receive characters.
- If `RTS_CTS = Y`, the relay does not send characters until the CTS input is asserted.

### Software Protocols

Software protocols consist of:

- Standard SEL ASCII
- SEL Distributed Port Switch Protocol (LMD)
- SEL Fast Meter
- SEL Compressed ASCII
- Modbus® RTU

Based upon the port PROTOCOL setting, the relay activates either SEL ASCII, SEL LMD, or Modbus RTU protocol for the given port. SEL Fast Meter and SEL Compressed ASCII commands are always active for the given port if the corresponding protocol is SEL ASCII or LMD. SEL Fast Meter and SEL Compressed ASCII are not available on the port if the protocol is Modbus RTU.

## SEL ASCII Protocol

**NOTE:** The **<Enter>** key on most keyboards is configured to send the ASCII character 13 (^M) for a carriage return. This manual instructs you to press the **Enter** key after commands, which should send the proper ASCII code to the relay.

SEL ASCII protocol is designed for manual and automatic communications.

1. All commands received by the relay must be of the form:

`<command><CR>` or `<command><CRLF>`

A command transmitted to the relay should consist of the command followed by either a CR (carriage return) or a CRLF (carriage return and line feed). You may truncate commands to the first three characters. For example, **EVENT 1 <Enter>** would become **EVE 1 <Enter>**. Upper- and lower-case characters may be used without distinction, except in passwords.

2. The relay transmits all messages in the following format:

`<STX><MESSAGE LINE 1><CRLF>`

`<MESSAGE LINE 2><CRLF>`

- 
- 
- 

`<LAST MESSAGE LINE><CRLF>< ETX>`

Each message begins with the start-of-transmission character (ASCII 02) and ends with the end-of-transmission character (ASCII 03). Each line of the message ends with a carriage return and line feed.

3. The relay implements XON/XOFF flow control.

The relay transmits XON (ASCII hex 11) and asserts the RTS output (if hardware handshaking is enabled) when the relay input buffer drops below 25 percent full.

The relay transmits XOFF (ASCII hex 13) when the buffer is over 75 percent full. If hardware handshaking is enabled, the relay deasserts the RTS output when the buffer is approximately 95 percent full. Automatic transmission sources should monitor for the XOFF character so they do not overwrite the buffer. Transmission should terminate at the end of the message in progress when XOFF is received and may resume when the relay sends XON.

4. You can use the XON/XOFF protocol to control the relay during data transmission. When the relay receives XOFF during transmission, it pauses until it receives an XON character. If there is no message in progress when the relay receives XOFF, it blocks transmission of any message presented to its buffer. Messages will be accepted after the relay receives XON.

The CAN character (ASCII hex 18) aborts a pending transmission. This is useful in terminating an unwanted transmission.

Control characters can be sent from most keyboards with the following keystrokes:

XON: <Ctrl+Q> (hold down the Control key and press Q)

XOFF: <Ctrl+S> (hold down the Control key and press S)

CAN: <Ctrl+X> (hold down the Control key and press X)

## SEL Distributed Port Switch Protocol (LMD)

The SEL LMD Protocol permits multiple SEL relays to share a common communications channel. The protocol is selected by setting the port setting **PROTOCOL = LMD**. See [Appendix C: SEL Distributed Port Switch Protocol](#) for more information on SEL LMD protocol.

## SEL Fast Meter Protocol

SEL Fast Meter protocol supports binary messages to transfer metering and control messages. The protocol is described in [Appendix D: Configuration, Fast Meter, and Fast Operate Commands](#).

## SEL Compressed ASCII Protocol

SEL Compressed ASCII protocol provides compressed versions of some of the relay ASCII commands. The protocol is described in [Appendix E: Compressed ASCII Commands](#).

## Modbus RTU Protocol

Modbus RTU protocol provides binary multidrop communication with the SEL-551. The protocol is described in [Appendix G: Modbus RTU Communications Protocol](#).

## Serial Port Settings

Serial port settings for each protocol are listed in [Table 5.2](#).

**Table 5.2 Communications Settings (Sheet 1 of 2)**

Field Description	Screen Name	Range	Default
<b>PROTOCOL = SEL</b>			
Port Protocol	PROTOCOL	SEL, LMD, MOD	SEL
Baud Rate	SPEED	300, 1200, 2400, 4800, 9600, 19200, 38400	2400
Number Data Bits	DATA_BITS	7, 8	8
Parity	PARITY	O, E, N (O = Odd, E = Even, N = None)	N
Stop Bits	STOP	1, 2	1
Timeout	TIMEOUT	0–30 minutes	15
Automatic Message Output	AUTO	Y or N	N
Enable Hardware Handshaking	RTS/CTS	Y or N	N
Fast Operate Enable	FAST_OP	Y or N	N

**Table 5.2 Communications Settings (Sheet 2 of 2)**

Field Description	Screen Name	Range	Default
<b>PROTOCOL = LMD</b>			
Port Protocol	PROTOCOL	SEL, LMD, MOD	LMD
LMD Prefix	PREFIX	@, #, \$, %, &	@
LMD Address	ADDRESS	1–99	1
LMD Settling Time	SETTLE_TIME	0–30 seconds	0
Baud Rate	SPEED	300, 1200, 2400, 4800, 9600, 19200, 38400	2400
Number Data Bits	DATA_BITS	7, 8	8
Parity	PARITY	O, E, N (O = Odd, E = Even, N = None)	N
Stop Bits	STOP	1, 2	1
Timeout	TIMEOUT	0–30 minutes	15
Automatic Message Output	AUTO	Y or N	N
Fast Operate Enable	FAST_OP	Y or N	N
<b>PROTOCOL = MOD</b>			
Port Protocol	PROTOCOL	SEL, LMD, MOD	MOD
Baud Rate	SPEED	300, 1200, 2400, 4800, 9600, 19200	2400
Parity	PARITY	O, E, N (O = Odd, E = Even, N = None)	N
Stop Bits	STOP	1, 2	1
Modbus Slave ID	SLAVEID	1–247	1

## Serial Port Automatic Messages

When the serial port AUTO setting is Y, the relay sends automatic messages to indicate specific conditions. The automatic messages are described in [Table 5.3](#).

**Table 5.3 Serial Port Automatic Messages**

Condition	Description
Power-Up	The relay sends a message containing the present date and time, Relay and Terminal Identifiers, and the Access Level 0 prompt when the relay is turned on.
Event Trigger	The relay sends an event summary each time an event report is triggered. See <a href="#">Section 7: Standard Event Reports and SER</a> .
Self-Test Warning or Failure	The relay sends a status report each time a self-test warning or failure condition is detected. See <a href="#">STA Command (Status) on page 5.18</a> .

# Serial Port Access Levels

---

Commands can be issued to the relay via the serial port to view metering values, change relay settings, etc. The available serial port commands are listed in [Table 5.4](#). The commands can be accessed only from the corresponding access level as shown in [Table 5.4](#). The access levels are:

- ▶ Access Level 0 (the lowest access level)
- ▶ Access Level 1
- ▶ Access Level 2 (the highest access level)
- ▶ Access Level C (restricted access level, should be used under direction of SEL only)

## Access Level 0

Once serial port communications are established with the relay, the following prompt appears:

---

-

---

This is referred to as Access Level 0. The only commands that can be executed at Access Level 0 are the **ACC** and **QUI** commands (see [Table 5.4](#)). Enter the **ACC** command at the access level prompt:

---

-ACC <Enter>

---

The **ACC** command allows the relay to go to Access Level 1 [see [ACC](#), [2AC](#), and [CAL Commands \(Access\)](#) on page 5.11 for more detail].

## Access Level 1

When the relay is in Access Level 1, the following prompt appears:

---

=>

---

Commands **2AC** through **TRI** in [Table 5.4](#) can be executed from Access Level 1. For example, enter the **MET** command at the Access Level 1 computer screen prompt to view metering data:

---

=>MET <Enter>

---

The **2AC** command allows the relay to go to Access Level 2 [see [ACC](#), [2AC](#), and [CAL Commands \(Access\)](#) for more detail]. Enter the **2AC** command at the Access Level 1 prompt:

---

=>2AC <Enter>

---

## Access Level 2

When the relay is in Access Level 2, the following prompt appears:

---

=>>

---

Commands **CLO** through **SET** in [Table 5.4](#) can be executed from Access Level 2. For example, enter the **SET** command at the Access Level 2 prompt to make relay settings:

---

```
=>>SET <Enter>
```

---

While in Access Level 2, any of the commands available in the lower access level can also be executed (commands **ACC–TRI** in [Table 5.4](#)).

## Access Level C

The CAL access level is intended for use by the SEL factory, and for use by SEL field service personnel to help diagnose troublesome installations. A list of commands available at the CAL level is available from SEL upon request. Do not enter the CAL access level except as directed by SEL.

The **CAL** command allows the relay to go to Access Level C (see [ACC](#), [2AC](#), and [CAL Commands \(Access\)](#) on page 5.11 for more detail). Enter the **CAL** command at the Access Level 2 prompt:

---

```
=>>CAL <Enter>
```

---

## Command Summary

---

[Table 5.4](#) alphabetically lists the serial port commands within a given access level. The SEL-551 Relay Command Summary at the end of this section (and at the end of this manual) has similar information, expanded in detail. Much of the information available from the serial port commands is also available via the front-panel pushbuttons. The correspondence between the serial port commands and the front-panel pushbuttons is also given in [Table 5.4](#). See [Section 6: Front-Panel Interface](#) for more information on the front-panel pushbuttons.

The primary differences between the serial port commands available at Access Level 1 and those available at Access Level 2 are:

- The Access Level 1 commands primarily allow the user to look at information only (e.g., settings, metering, etc.), not change it.
- The Access Level 2 commands primarily allow the user to change settings or operate relay parameters and output contacts.

The commands are shown in upper-case letters, but can also be entered with lower-case letters.

**Table 5.4 Serial Port Command Summary**

Access Level	Prompt	Serial Port Command	Command Description	Corresponding Front-Panel Pushbutton
0	=	<b>ACC</b>	Go to Access Level 1	
1	=>	<b>2AC</b>	Go to Access Level 2	
1	=>	<b>DAT</b>	View/change date	{OTHER}
1	=>	<b>EVE</b>	15-cycle event report	
1	=>	<b>HIS</b>	Event summaries	{EVENTS}
1	=>	<b>IRI</b>	Synchronize to IRIG-B	
1	=>	<b>MET</b>	Metering	{METER}
1	=>	<b>QUI</b>	Quit access level	
1	=>	<b>SER</b>	Sequential Events Recorder	
1	=>	<b>SHO</b>	View settings	{SET}
1	=>	<b>STA</b>	Relay self-test status	{STATUS}
1	=>	<b>TAR</b>	Relay element status	{OTHER}
1	=>	<b>TIM</b>	View/change time	{OTHER}
1	=>	<b>TRI</b>	Trigger an event report	
2	=>>	<b>CAL</b>	Go to Access Level C	
2	=>>	<b>CLO</b>	Close breaker	
2	=>>	<b>CON</b>	Control remote bits	
2	=>>	<b>OPE</b>	Open breaker	
2	=>>	<b>PAS</b>	Set passwords	{SET}
2	=>>	<b>PUL</b>	Pulse output contacts	{CNTRL}
2	=>>	<b>SET</b>	Change relay settings	{SET}
2	=>>	<b>VER</b>	Show relay configuration and firmware version	

The relay responds with `Invalid Access Level` if a command is entered from an access level lower than the specified access level for the command. The relay responds:

```
Invalid Command
```

to commands not listed above or entered incorrectly.

The following line of information is listed at the start of the relay response to many of the commands:

```
FEEDER 1                               Date: 03/05/96   Time: 17:03:26.484
STATION A
```

Relay Response	Definition
FEEDER 1:	This is the RID setting (the relay is shipped with the default setting RID = FEEDER 1; see <i>Identifier Labels on page 4.18</i> ).
STATION A:	This is the TID setting (the relay is shipped with the default setting TID = STATION A; see <i>Identifier Labels</i> ).

Relay Response	Definition
Date:	This is the date the command response was given [except for relay response to the <b>EVE</b> command (Event), where it is the date the event occurred]. You can modify the date display format (Month/Day/Year or Year/Month/Day) by changing the DATE_F relay setting.
Time:	This is the time the command response was given (except for relay response to the <b>EVE</b> command, where it is the time the event occurred).

The serial port command explanations that follow in *Command Explanations on page 5.11* are in the same order as the commands listed in *Table 5.4*.

## Command Explanations

### Access Level 0 Commands

#### ACC, 2AC, and CAL Commands (Access)

The access commands allow entry to the next higher access levels. Different commands are available at the different access levels (see *Table 5.4*).

**Table 5.5 ACC and 2AC Commands**

Access Level	Prompt	Corresponding Serial Port Command	Password Level <sup>a</sup>	Brief Command Description
0	=	ACC	1	Access—allows entry to Access Level 1
1	=>	2AC	2	2Access—allows entry to Access Level 2
2	=>>	CAL	C	CAccess—allows entry to Access Level C

<sup>a</sup> If the main board password jumper JMP22 is not in place (JMP22 = OFF), then passwords have to be entered when access level attempts are made.

If the main board password jumper is in place (JMP22 = ON), then passwords do not have to be entered when access level attempts are made. See *PAS Command (Password)* on page 5.23 for more information.

### Password Requirements

Passwords are required if the main board password jumper **JMP22** is not in place (JMP22 = OFF). Passwords are not required if the main board password jumper **JMP22** is in place (JMP22 = ON). See *Password and Breaker Jumpers on page 2.16*. See *PAS Command (Password)* for more information on passwords.

**Access Level Attempt (Password Required).** Assume the following conditions exist:

- main board password
- jumper JMP22 = off (passwords required to enter higher access levels)
- Access level = 0 (prompt =)

At the prompt, enter the **ACC** command:

---

```
-ACC <Enter>
```

---

Because the main board jumper is not in place, the relay asks for the Access Level 1 password to be entered:

---

```
Password: ? @@@@@@
```

---

The relay is shipped with the default Access Level 1 password shown in the table under the *PAS Command (Password)*. At the prompt above, enter the default password and press the **<Enter>** key.

The relay replies:

---

```
FEEDER 1                               Date: 03/05/96   Time: 08:31:10.361
STATION A

Level 1
=>
```

---

The => prompt indicates that the relay is now in Access Level 1.

If the entered password is incorrect, the relay asks for the password again (Password: ?). The relay will ask up to three times. If the requested password is incorrectly entered three times, the relay closes the **ALARM** contact for one second and displays the following message:

---

```
Invalid Password
Access Denied
WARNING: ACCESS BY UNAUTHORIZED PERSONS STRICTLY PROHIBITED
```

---

**Access Level Attempt (Password Not Required).** Assume the following conditions exist:

- main board password
- jumper JMP22 = on (passwords not required to enter higher access levels)
- Access level = 0 (prompt =)

At the computer screen prompt, enter the **ACC** command:

---

```
-ACC <Enter>
```

---

Because the main board jumper is in place, the relay does not ask for a password; it goes directly to Access Level 1. The relay responds:

---

```
FEEDER 1                               Date: 03/05/96   Time: 08:31:10.361
STATION A

Level 1
=>
```

---

The => prompt indicates that the relay is now in Access Level 1.

The above two examples demonstrate how to go from Access Level 0 to Access Level 1. The procedure to go from Access Level 1 to Access Level 2 is much the same, with command 2AC entered at computer screen prompt =>. The relay closes the **ALARM** contact for one second after a successful Level 2 or Level C access. If access is denied, the **ALARM** contact also pulses.

Depending on the status of the main board password jumper, an Access Level 2 password may have to be entered, too (Password: ?). The relay is shipped with the default Access Level 2 password shown in the table under the [PAS Command \(Password\) on page 5.23](#). Computer screen prompt =>> indicates that the relay has gained Access Level 2.

## Access Level 1 Commands

### DAT Command (Date)

**DAT** displays the date stored by the internal calendar/clock. If the date format setting DATE\_F is set to MDY, the date is displayed as month/day/year. If the date format setting DATE\_F is set to YMD, the date is displayed as year/month/day.

To set the date, type **DATE mm/dd/yy <Enter>** if the DATE\_F setting is MDY. If the DATE\_F is set to YMD, enter **DATE yy/mm/dd <Enter>**. To set the date to June 1, 1996, enter:

---

```
=>DATE 6/1/96 <Enter>
6/1/96
=>
```

---

You can separate the month, day, and year parameters with spaces, commas, slashes, colons, and semicolons.

### EVE Command (Event)

Use the **EVE** command to view 15-cycle event reports. See [Section 7: Standard Event Reports and SER](#) for further details on retrieving event reports.

### HIS Command (History)

**HIS [X]** displays the summary of the latest 20 events or allows you to clear the history buffer, which contains the latest 20 events in nonvolatile memory.

If no parameters are specified in the **HIS** command, the relay displays the 20 most recent events in reverse chronological order.

If X is a number (1–20), the relay displays the X most recent events.

If X is C or c, the relay clears the history buffer and all corresponding event reports in nonvolatile memory.

The history report includes: the date and time the event was triggered, the type of event, the recloser shot counter, the maximum phase current in the event, and the front-panel fault type targets if the event was a TRIP type of event. For more information on events and event reports, see [Section 7: Standard Event Reports and SER](#).

To display the relay event history, enter the following command:

```

->HIS <Enter>

```

---

The relay responds with the event history:

```

FEEDER 1                               Date: 03/05/96   Time: 10:04:27.151
STATION A

#    DATE        TIME          EVENT  SHOT    CURR    TARGETS
1    03/05/96    10:03:49.109 TRIG   2        6
2    02/29/96    16:42:50.746 ER1    2       2487
3    02/29/96    16:16:08.837 ER2    1         5
4    02/29/96    16:16:07.174 TRIP   0       2279  INST A N

->

```

### IRI Command (IRIG)

**IRI** directs the relay to read the demodulated IRIG-B time code at the serial port input.

To force the relay to synchronize to IRIG-B, enter the following command:

```

=>IRI <Enter>

```

If the relay successfully synchronizes to IRIG, it sends the following header:

```

FEEDER 1                               Date: 03/05/96   Time: 10:15:09.609
STATION A

->

```

If no IRIG-B code is present at the serial port input or if the code cannot be read successfully, the relay responds:

```

IRIG-B DATA ERROR

->

```

If an IRIG-B signal is present, the relay continuously synchronizes its internal clock with IRIG-B. It is not necessary to issue the **IRI** command to synchronize the relay clock with IRIG-B. Use the **IRI** command to determine if the relay is properly reading the IRIG-B signal.

### MET Command (Meter)

**MET** displays instantaneous magnitudes and phase angles of the following:

IA:	A-phase current in primary amps
IB:	B-phase current in primary amps
IC:	C-phase current in primary amps
IN:	Measured neutral ground current in primary amps
IG:	Calculated residual current in primary amps
3I2:	Calculated negative-sequence current in primary amps

The SEL-551 reports the phase angles referenced to IA (IA phase angle = 0, positive phase angles leading).

To view instantaneous metering values, enter the command:

```
=>MET n <Enter>
```

where *n* is an optional parameter to specify the number of times to repeat the meter display. The value for *n* may range from 1 to 32767. If *n* is not specified, the relay displays the meter report once:

```
FEEDER 1                               Date: 03/05/96   Time: 10:29:42.609
STATION A
A, pri      IA      IB      IC      IN      IG      3I2
Degrees     477     455     492     0       31     35
            0.00    239.95  120.28  110.18  88.24  275.83
=>
```

### MET D Command (Demand Ammeter)

The **MET D** command displays the demand and peak demand values of the following quantities:

Currents	$I_{A,B,C,N}$	Input currents (A primary)
	$I_G$	Residual ground current (A primary; IG = 3I0 = IA + IB + IC)
	$3I_2$	Negative-sequence current (A primary)
Reset Time	Demand, Peak	Last time the demands and peak demands were reset

To view demand ammetering values, enter the command:

```
=>MET D <Enter>
```

```
=>MET D <Enter>
FEEDER 1                               Date: 02/01/97   Time: 15:08:05.615
STATION A
DEMAND      IA      IB      IC      IN      IG      3I2
PEAK        188.6  186.6  191.8  0.2     4.5     4.7
            188.6  186.6  191.8  0.3     4.5     4.7
LAST DEMAND RESET 01/27/97 15:31:51.238  LAST PEAK RESET 01/27/97 15:31:56.239
=>
```

Reset the accumulated demand values using the **MET RD** command. Reset the peak demand values using the **MET RP** command. For more information on demand ammetering, see [Demand Ammetering on page 3.41](#).

### QUI Command (Quit)

The **QUI** command returns the relay to Access Level 0.

To return to Access Level 0, enter the command:

```
=>QUI <Enter>
```

The relay sets the port access level to 0. The relay displays the following heading prompt:

```

FEEDER 1                               Date: 03/05/96   Time: 08:55:33.986
STATION A
-
    
```

The = prompt indicates the relay is back in Access Level 0.

The **QUI** command remaps the front-panel targets to the Relay Targets (TAR 0) and terminates the SEL LMD connection if it is established (see [Appendix C: SEL Distributed Port Switch Protocol](#)).

### SER Command (Sequential Events Recorder)

Use the **SER** command to view Sequential Events Records. For more information on SER reports, see [Section 7: Standard Event Reports and SER](#).

### SHO Command (Showset)

Use **SHO** to view relay settings.

The **SHO** command format is: **SHO X Y**

where:

X = the settings class to display

Y = the name of the first setting to display

Valid **SHO** commands include:

Command	Settings Class
<b>SHO</b>	Relay Settings
<b>SHO L</b>	SELOGIC® control equation settings
<b>SHO P</b>	Rear Port Settings (SEL-551)
<b>SHO R</b>	Sequential Event Recorder (SER) Settings
<b>SHO T</b>	Text Label Settings

Parameter Y is the name of the first setting to display. If Y is not specified, all settings are shown in the selected settings class.

Below are sample **SHOWSET** commands, showing all the factory settings for the SEL-551.

=>SHO <Enter>

Relay Settings:

```

RID =FEEDER 1      TID =STATION A
CTR  = 120         CTRN = 120      TDURD = 9.000
50P1P = 15.0      50P2P = 20.0      50P3P = OFF      50P4P = OFF
50P5P = OFF       50P6P = OFF       50ABCP= OFF
51P1P = 6.0       51P1C = U3           51P1TD= 3.00     51P1RS= N
51P2P = OFF       51P2C = U3           51P2TD= 15.00    51P2RS= N
50N1P = OFF       50N2P = OFF
51N1P = OFF       51N1C = U3           51N1TD= 15.00    51N1RS= N
50G1P = OFF       50G2P = OFF
51G1P = 1.5       51G1C = U3           51G1TD= 1.50     51G1RS= N
50Q1P = OFF       50Q2P = OFF
51Q1P = OFF       51Q1C = U3           51Q1TD= 15.00    51Q1RS= N
51Q2P = OFF       51Q2C = U3           51Q2TD= 15.00    51Q2RS= N
79O1I = 30.000    79O1I2 = 600.000     79O1I3 = 0.000   79O1I4 = 0.000
79RSD = 1800.000  79RSLD= 300.000     CFD  = 60.000
DMTC  = 5
PDEMP = 5.00      NDEMP = 1.50         GDEMP = 1.50      QDEMP = 1.50
SV5PU = 12.000    SV5DO = 2.000        SV6PU = 0.000     SV6DO = 0.000
SV7PU = 0.000     SV7DO = 0.000        SV8PU = 0.000     SV8DO = 0.000

```

Press RETURN to continue <Enter>

```

SV9PU = 0.000     SV9DO = 0.000        SV10PU= 0.000     SV10DO= 0.000
SV11PU= 0.000    SV11DO= 0.000       SV12PU= 0.000     SV12DO= 0.000
SV13PU= 0.000    SV13DO= 0.000       SV14PU= 0.000     SV14DO= 0.000
NFREQ = 60        PHROT = ABC          DATE_F= MDY

```

=>SHO L <Enter>

SELogic Control Equations:

```

TR    =51P1T + 51G1T + 50P1 * SHO + LB3
ULTR  =(51P1 + 51G1)
51P1TC=1
51P2TC=1
51N1TC=1
51G1TC=1
51Q1TC=1
51Q2TC=1
52A   =IN1
CL    =LB4
ULCL  =TRIP
79RI  =TRIP
79RIS =IN1
79DTL =!LB1 + LB3
79DLS =79L0
79SKP =50P2 * SHO
79STL =TRIP

```

Press RETURN to continue <Enter>

```

79BRS =(51P1 + 51G1) * (79RS + 79CY)
79SEQ =0
ER1   =51P1 + 51G1
ER2   =SV5T + CF
SV1   =0
SV2   =0
SV3   =0
SV4   =0
SV5   =TRIP
SV6   =0
SV7   =0
SV8   =0
SV9   =0
SV10  =0
SV11  =0
SV12  =0
SV13  =0
SV14  =0
OUT1  =TRIP
OUT2  =CLOSE
OUT3  =SV5T
OUT4  =0

```

Press RETURN to continue <Enter>

```

DP1   =0
DP2   =LB1
DP3   =0
DP4   =IN1
DP5   =0
DP6   =0
DP7   =0
DP8   =0

```

```

=>SHO P <Enter>

PROTOCOL= SEL
SPEED = 2400   DATA_BITS= 8   PARITY= N   STOP = 1
TIMEOUT= 15   AUTO = N   RTS_CTS= N   FAST_OP= N

-----

=>SHO R <Enter>

Sequential Events Recorder trigger lists:
SER1 =51P1 51G1 51P1T 51G1T 50P1 50P2
SER2 =IN1 LB1 LB3 LB4 OUT1 OUT2 OUT3
SER3 =CF 79RS 79LO SV5T

-----

=>SHO T <Enter>

Text Labels:
NLB1 =RECLOSER      CLB1 =DISABLE  SLB1 =ENABLE  PLB1 =
NLB2 =              CLB2 =          SLB2 =          PLB2 =
NLB3 =MANUAL TRIP   CLB3 =RETURN   SLB3 =          PLB3 =TRIP
NLB4 =MANUAL CLOSE  CLB4 =RETURN   SLB4 =          PLB4 =CLOSE
NLB5 =              CLB5 =          SLB5 =          PLB5 =
NLB6 =              CLB6 =          SLB6 =          PLB6 =
NLB7 =              CLB7 =          SLB7 =          PLB7 =
NLB8 =              CLB8 =          SLB8 =          PLB8 =
DP1_1 =              DP1_0 =
DP2_1 =79 ENABLED   DP2_0 =79 DISABLED
DP3_1 =              DP3_0 =
DP4_1 =BREAKER CLOSED  DP4_0 =BREAKER OPEN
DP5_1 =              DP5_0 =
DP6_1 =              DP6_0 =
DP7_1 =              DP7_0 =
DP8_1 =              DP8_0 =
79LL =SET RECLOSURES 79SL =RECLOSE COUNT

```

## STA Command (Status)

The **STA** command displays the status report, showing the relay self-test information.

To view a status report, enter the command:

```

=>STA N <Enter>

```

where:

*N* = a number (*N* = 1, 2, 3, ...) that specifies the number of times to repetitively display the status report. If no number is entered after the **STA** command, the relay displays the status report only once.

After the **STA** command is entered, the relay replies with the following status report:

```

FEEDER 1                               Date: 03/05/96   Time: 14:17:01.359
STATION A

FID=SEL-551-R100-Vr-D960226           CID=00FF

SELF TESTS

W=Warn   F=Fail

OS      IA      IB      IC      IN      MOF
        3       5       3       3       0

PS      +5V_PS  +5V_REG -5V_REG +10V_PS -10V_PS VBAT
        5.03   5.03   -5.03  10.35  -10.20  2.82

        TEMP   RAM     ROM     CR_RAM  EEPROM
        27.6   OK     OK     OK     OK

Relay Enabled

=>

```

### STA Command Row and Column Definitions

Relay Response	Definition
FID	FID is the firmware identifier string. It identifies the firmware revision.
CID	CID is the firmware checksum identifier.
OS	OS = Offset; displays measured dc offset voltages in millivolts for the current channels. The MOF (master) status is the dc offset in the A/D circuit when a grounded input is selected.
PS	PS = Power Supply; displays power supply voltages in Vdc for the power supply outputs. The +5V_REG and -5V_REG are regulated voltages for the A/D circuit. VBAT displays the Real Time Clock battery voltage.
TEMP	Displays the temperature in degrees Celsius. The temperature sensor is an output of the voltage reference in the A/D circuitry.
RAM, ROM, CR_RAM (critical RAM), and EEPROM	These tests verify the relay memory components. The columns display OK if memory is functioning properly; the columns display FAIL if the memory area has failed.  W (Warning) or F (Failure) is appended to the displayed value to indicate an out-of-tolerance condition.

The relay latches all self-test warnings and failures in order to capture transient out-of-tolerance conditions. To reset the self-test statuses, use the **STA C** command from Access Level 2:

```

=>>STA C <Enter>

```

The relay responds:

```

Reboot the relay and clear status
Are you sure (Y/N) ?

```

If you select N or n, the relay displays:

---

Canceled

---

and aborts the command.

If you select Y, the relay displays:

---

Rebooting the relay

---

The relay then restarts (just like powering down, then powering up relay), and all diagnostics are re-run before the relay is enabled.

Refer to [Section 8: Testing and Troubleshooting](#) for self-test thresholds and corrective actions.

## TAR Command (Target)

The **TAR** command remaps the front-panel targets to display Relay Word bit information. It also sends this same information to the serial port. Refer to [Table 5.6](#) (note the correspondence with [Table 4.5](#)).

The **TAR** command format is: **TAR M N**

where:

- M* = the Relay Word row (1–15) to be displayed, or 0 (zero) to take the targets back to their normal front-panel target operation, or R to take the targets back to their normal front-panel target operation (like **TAR 0**), reset the FAULT TYPE targets (**INST**, **A**, **B**, **C**, and **N**), and unlatch the trip logic for testing purposes (see [Figure 3.13](#))
- N* = the number of times to repeat the displaying of the selected Relay Word row on the computer screen connected to the serial port. If parameter *N* is not entered, the information displays once on the screen

Parameter *N* does not affect the remapping of the front-panel targets. They are remapped according to parameter *M* and will stay in that new state until a new **TAR** command is executed or the port times out due to port inactivity (see serial port setting TIMEOUT). Port timeout takes the targets back to their normal front-panel target operation (like **TAR 0**).

To prevent the front-panel targets from being remapped by the execution of the **TAR** command, add an X after the Relay Word row parameter. For example, command **TAR 2 X** causes Relay Word row 2 to be sent to the serial port/computer screen, but the front-panel targets remain unchanged—they continue in their normal front-panel target operation mode (like **TAR 0**).

If the **TAR** command is executed from the front panel (see [Figure 6.3](#)), front-panel timeout is 15 minutes of front-panel keyboard inactivity. Front-panel timeout takes the targets back to their normal front-panel target operation, also (like **TAR 0**).

**Table 5.6 SEL-551 Relay Word and Its Correspondence to TAR Command and Front-Panel LEDs**

TAR 0 (Front-Panel LEDs)	EN	INST	A	B	C	N	RS	LO
TAR 1	51P1	51P2	51N1	51G1	51P1T	51P2T	51N1T	51G1T
TAR 2	51Q1	51Q2	51Q1T	51Q2T	50P1	50P2	50P3	50P4
TAR 3	50P5	50P6	50N1	50N2	50G1	50G2	50Q1	50Q2
TAR 4	50A	50B	50C	IN1	IN2	OC	CC	CF
TAR 5	LB1	LB2	LB3	LB4	LB5	LB6	LB7	LB8
TAR 6	RB1	RB2	RB3	RB4	RB5	RB6	RB7	RB8
TAR 7	SV1	SV2	SV3	SV4	SV5	SV6	SV7	SV8
TAR 8	SV9	SV10	SV11	SV12	SV13	SV14	*a	*a
TAR 9	79RS	79CY	79LO	SH0	SH1	SH2	SH3	SH4
TAR 10	TRIP	CLOSE	51P1R	51P2R	51N1R	51G1R	51Q1R	51Q2R
TAR 11	SV5T	SV6T	SV7T	SV8T	SV9T	SV10T	SV11T	SV12T
TAR 12	SV13T	SV14T	*a	ALARM	OUT1	OUT2	OUT3	OUT4
TAR 13	PDEM	NDEM	GDEM	QDEM	TRGTR	*a	*a	*a
TAR 14	*a							

<sup>a</sup> Reserved for future use.

Command **TAR 9 10** is executed in the following example:

```

=>TAR 9 10 <Enter>

79RS  79CY  79LO  SH0  SH1  SH2  SH3  SH4
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0

79RS  79CY  79LO  SH0  SH1  SH2  SH3  SH4
0      0      1      0      0      1      0      0
0      0      1      0      0      1      0      0

```

Note that Relay Word bits row 9 is repeated 10 times on the computer display. In this example, the reclosing relay is in the Lockout State (79LO = logical 1), and the shot is at shot = 2 (SH2 = logical 1). Correspondingly, the remapped front-panel targets have the A LED illuminated (corresponding to Relay Word Bit 79LO in row 9) and the N LED illuminated (corresponding to Relay Word Bit SH2 in row 9).

### TIM Command (Time)

**TIM** displays the relay clock. To set the clock, type **TIM** and the desired setting, then press **<Enter>**. Separate the hours, minutes, and seconds with colons, semicolons, spaces, commas, or slashes. To set the clock to 23:30:00, enter:

```

=>TIM 23:30:00 <Enter>
23:30:00
=>

```

## TRI Command (Trigger)

Issue the **TRI** command to generate an event report:

---

```
=>TRI <Enter>
Triggered

=>
```

---

See [Section 7: Standard Event Reports and SER](#) for more information on event reports.

## Access Level 2 Commands

### CLO Command (Close)

The **CLO** (Close) command asserts the CLOSE Relay Word bit, which can be programmed to an output contact to close circuit breakers. See [Figure 3.14](#).

To issue the **CLO** command, enter the following:

---

```
=>>CLO <Enter>
Close Breaker (Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
=>>
```

---

Typing **N** <Enter> after either of the above prompts will abort the command.

The **CLO** command is supervised by main board jumper **JMP24**. If the jumper is not in place (jumper **JMP24** = off), the relay does not execute the **CLO** command and responds:

---

```
Aborted: No Breaker Jumper
```

---

### CON Command (Control)

The **CON** command is a two-step command that allows you to control Relay Word bits **RB1–RB8** (see [Figure 3.3](#)). At the Access Level 2 prompt, type **CON**, a space, and the number of the bit you wish to control (1–8). The relay responds by repeating your command followed by a colon. At the colon, type the Control subcommand you wish to perform (see [Table 5.7](#)).

The following example shows the steps necessary to pulse Remote Bit 5 (**RB5**):

---

```
=>>CON 5 <Enter>
CONTROL RB5: PRB 5 <Enter>
=>>
```

---

You must enter the same remote bit number in both steps in the command. If the bit numbers do not match, the relay responds:

---

```
Invalid Command
```

---

**Table 5.7 SEL-551 Control Subcommands**

Subcommand	Description
<b>SRB <i>n</i></b>	Set Remote Bit <i>n</i> (“ON” position)
<b>CRB <i>n</i></b>	Clear Remote Bit <i>n</i> (“OFF” position)
<b>PRB <i>n</i></b>	Pulse Remote Bit <i>n</i> for one processing interval (1/8 cycle; “MOMENTARY” position)

See [Remote Control Switches on page 3.7](#) for more information.

## OPE Command (Open)

**NOTE:** If the **OPE** command is executed (and SELoGic control equation setting 79RI = TRIP + . . .), the relay goes directly to the Lockout State. [Early SEL-551 firmware versions do not have this feature (see [Appendix A: Firmware and Manual Versions](#)). To effectively incorporate this feature into these firmware versions, set SELoGic control equation setting 79DTL = OC + . . . (and 79RI = TRIP + . . .). Relay Word bit OC asserts to logical 1 for 1/8 cycle when the **OPE** command is executed (see [Table 4.5](#) and [Table 4.6](#)). See [Figure 3.15](#) and [Table 3.5](#) and accompanying text in [Section 3: Relay Elements and Logic](#).]

The **OPE** (Open) command asserts the TRIP Relay Word bit, which can be programmed to an output contact to trip circuit breakers. See [Figure 3.13](#).

To issue the **OPE** command, enter the following:

```
=>>OPE <Enter>
Open Breaker (Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
=>>
```

Typing **N** <Enter> after either of the above prompts will abort the command.

The **OPE** command is supervised by main board jumper **JMP24**. If the jumper is not in place (jumper **JMP24** = off), the relay does not execute the **OPE** command and responds:

```
Aborted: No Breaker Jumper
```

## PAS Command (Password)

The factory default passwords for Access Levels 1 and 2 are:

Access Level	Factory Default Password
1	OTTER
2	TAIL
C	CLARKE

The **PAS** (Password) command allows you to change existing Level 1, and 2 passwords at Access Level 2 and allows you to change the Level C password from Level C. To change passwords, enter **PAS *x***, where *x* is the access level of the password being changed. The relay will prompt for the old password, new password, and a confirmation of the new password.

To change the password for Access Level 1, enter the following:

```
=>>PAS 1 <Enter>
Old Password: *****
New Password: *****
Confirm New Password: *****

Password Changed
```

Similarly, **PAS 2** can be used to change the Level 2 password.

### WARNING

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

The new passwords will not echo on the screen, and passwords cannot be viewed from the device. Record the new passwords in a safe place for future reference.

If the passwords are lost or you wish to operate the relay without password protection, install the main board Password jumper (Password jumper = ON). Refer to [Section 2: Installation](#) for Password jumper information. While the password protection is disabled by setting the main board Password jumper in place (Password jumper = ON), lost or forgotten passwords can be replaced by new passwords by using the **PAS x** command at Access Level 2. The relay will prompt for a new password and a confirmation of the new password.

If you wish to disable password protection for a specific access level (even if the Password jumper is not in place [Password jumper = OFF]), simply set the password to DISABLE. For example, **PAS 1 DISABLE** disables password protection for Access Level 1.

Passwords may include up to 12 characters. See [Table 5.8](#) for valid characters. Upper- and lowercase letters are treated as different characters. Strong passwords consist of 12 characters, with at least one special character or digit and mixed case sensitivity, but do not form a name, date, acronym, or word. Passwords formed in this manner are less susceptible to password guessing and automated attacks. Examples of valid, distinct strong passwords include:

- Ot3579A24.68
- Ih2dcs4u-Iwg
- .351s.Nt9g-t

**Table 5.8 Valid Password Characters**

Symbol	Example
Alpha	A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w x y z
Numeric	0 1 2 3 4 5 6 7 8 9
Special	! " # \$ % & ' ( ) * , - . / : ; < = > ? @ [ \ ] ^ _ { ` } ~

The relay will issue a weak password warning if the new password does not include at least one special character, number, lowercase letter, and an uppercase letter.

```

=>>PAS 1 <Enter>
Old Password: *****

New Password: *****
Confirm New Password: *****

Password Changed
=>>
CAUTION: This password can be strengthened. Strong passwords do not include a name,
date, acronym, or word. They consist of the maximum allowable characters, with at
least one special character, number, lower-case letter, and upper-case letter. A
change in password is recommended.
=>>

```

## PUL Command (Pulse)

The **PULSE** command allows you to pulse any of the output contacts for a specified length of time. The command format is:

**PUL X Y**

where:

$X$  = **OUT1, OUT2, OUT3, OUT4**, or **ALARM**

$Y$  = the pulse duration (1–30) in seconds. If  $Y$  is not specified, the pulse duration defaults to one second

To pulse **OUT1** for five seconds:

---

```
=>>PUL OUT1 5 <Enter>
Are you sure (Y/N) ? Y <Enter>
=>>
```

---

If the response to the Are you sure (Y/N) ? prompt is N or n, the command is aborted.

The **PUL** command is supervised by the main board breaker jumper, **JMP24**. If **JMP24** is not in place (jumper **JMP24** = off), the relay does not accept the **PUL** command and responds:

---

```
Aborted: No Breaker Jumper
```

---

The relay generates an event report if the **OUT1, OUT2, OUT3**, or **OUT4** contact is pulsed.

The response of a programmable alarm output contact to a **PULSE** command is discussed in the [Output Contacts on page 3.39](#).

## SET Command

The **SET** command allows the user to view or change the relay settings (see [Table 4.1](#)).

## VER Command (Show Relay Configuration and Firmware Version)

The **VER** command provides relay configuration and information such as nominal current input ratings.

An SEL-551 example printout of the **VER** command follows:

---

```
=>>VER <Enter>
FID=SEL-551-R500-Vf-Z001001-D20050124
CID=D07F
Part Number: 055100BX5X4X
SELboot:
  BFD=SLBT-500-R100-V0-Z001001-D20050124
  Checksum: 3EB5
Mainboard:
  Code FLASH Size: 256 kB
  Data FLASH Size: 128 kB
  RAM Size: 128 kB
  EEPROM Size: 8 kB
Front Panel: Installed
Analog Inputs:
  Currents: 5 Amp Phase
  Currents: 5 Amp Neutral
Interface Boards:
  None
Communications:
  Rear Port: EIA-485
Extended Relay Features:

If above information is unexpected,
contact SEL for assistance
=>>
```

---

**This page intentionally left blank**

# SEL-551 Command Summary

Access Level 0 Command	The only thing that can be done at Access level 0 is to go to Access Level 1. The screen prompt is: =
ACC	Enters Access Level 1. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 1 password in order to enter Access Level 1.
Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
2AC	Enters Access Level 2. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 2 password in order to enter Access Level 2.
DAT	Shows date presently in the relay.
DAT <i>m/d/y</i>	Enters date in this manner if Date Format setting DATE_F = MDY.
DAT <i>y/m/d</i>	Enters date in this manner if Date Format setting DATE_F = YMD.
EVE <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/4 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE C <i>n</i>	Causes the relay to add digital data at the end of the Event <i>n</i> report.
EVE L <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/8 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE L C <i>n</i>	Causes the relay to add digital data at the end of Event L <i>n</i> report.
EVE R <i>n</i>	Causes the relay to display an unfiltered event report with 1/16-cycle resolution.
EVE R C <i>n</i>	Causes the relay to add digital data at the end of the Event R <i>n</i> report.
HIS <i>n</i>	Shows brief summary of the <i>n</i> latest standard 15-cycle event reports.
HIS C	Clears the brief summary and corresponding standard 15-cycle event reports.
IRI	Forces synchronization attempt of internal relay clock to IRIG-B time-code input.
MET <i>k</i>	Displays metering data, both magnitude and phase angle. Phase angles are referenced to phase input IA. Enter number <i>k</i> to scroll metering <i>k</i> times on screen.
MET D	Displays demand and peak demand data. Select <b>MET RD</b> or <b>MET RP</b> to reset.
QUI	Quit. Returns to Access Level 0. Returns front-panel LEDs to the default targets (corresponding to command <b>TAR 0</b> ).
SER <i>n</i>	Show the latest <i>n</i> rows in the Sequential Events Recorder (SER) event report.
SER <i>m n</i>	Show rows <i>m</i> through <i>n</i> in the Sequential Events Recorder (SER) event report.
SER <i>d1</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> .
SER <i>d1 d2</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> to <i>d2</i> . Entry of dates is dependent on the Date Format setting DATE_F (= MDY or YMD).
SER C	Clears the Sequential Events Recorder (SER) event report.
SHO	Show relay settings (overcurrent, reclosing, timers, etc.).
SHO L	Show SELOGIC® control equation settings.
SHO P	Show port settings
SHO R	Show Sequential Events Recorder (SER) settings.
SHO T	Show text label settings.
STA	Show relay self-test status. <b>STA C</b> resets self-test warnings/failures.
TAR R	Return front-panel LED targets to regular operation and reset the <b>FAULT TYPE</b> front-panel targets.
TAR 0 <i>k</i>	Return front-panel LED targets to regular operation. Enter number <i>k</i> to scroll front-panel LED status <i>k</i> times on screen.

Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
<b>TAR <i>n k</i></b>	Display Relay Word row <i>n</i> status ( <i>n</i> = 1–15) on remapped front-panel LED targets. Enter number <i>k</i> to scroll Relay Word row <i>n</i> status <i>k</i> times on screen.
<b>TAR <i>n X</i></b>	Relay Word row <i>n</i> status ( <i>n</i> = 1–15) is sent to the serial port/computer screen, but the front-panel LED targets remain unchanged.
<b>TIM</b>	Show or set time (24-hour time). Show time presently in the relay by entering just <b>TIM</b> . Example time 22:47:36 is entered with command <b>TIM 22:47:36</b> .
<b>TRI</b>	Trigger an event report.

Access Level 2 Commands	The Access Level 2 commands primarily allow the user to change settings or operate relay parameters and output contacts. All Access Level 1 commands can also be executed from Access Level 2. The screen prompt is: =>>
<b>CAL</b>	Enter Access Level C. If the main board Access jumper is not in place, the relay prompts for the entry of the Access Level C password. Access Level C is reserved for SEL use only.
<b>CLO</b>	Assert the CLOSE Relay Word bit. If CLOSE is assigned to an output contact (e.g., OUT2 = CLOSE), then the output contact will assert if command <b>CLO</b> is executed and the circuit breaker is open.
<b>CON <i>n</i></b>	Control Relay Word bit <i>RB<sub>n</sub></i> (Remote Bit <i>n</i> ; <i>n</i> = 1–8). Execute <b>CON <i>n</i></b> and the relay responds: CONTROL <i>RB<sub>n</sub></i> . Then reply with one of the following: <b>SRB <i>n</i></b> set Remote Bit <i>n</i> (assert <i>RB<sub>n</sub></i> ) <b>CRB <i>n</i></b> clear Remote Bit <i>n</i> (deassert <i>RB<sub>n</sub></i> ) <b>PRB <i>n</i></b> pulse Remote Bit <i>n</i> [assert <i>RB<sub>n</sub></i> for one processing interval (1/8 cycle)].
<b>OPE</b>	Assert the TRIP Relay Word bit. If TRIP is assigned to an output contact (e.g., OUT1 = TRIP), then the output contact will assert if command <b>OPE</b> is executed.
<b>PAS 1</b>	Change Access Level 1 password.
<b>PAS 2</b>	Change Access Level 2 password.
<b>PAS C</b>	Change Access Level C password.
<b>PUL <i>n k</i></b>	Pulse output contact <i>n</i> ( <i>n</i> = OUT1, OUT2, OUT3, OUT4, and ALARM). Enter number <i>k</i> to pulse for <i>k</i> seconds [ <i>k</i> = 1 to 30 (seconds)], otherwise pulse time is 1 second.
<b>SET <i>n</i></b>	Change relay settings (overcurrent, reclosing, timers, etc.).
<b>SET L <i>n</i></b>	Change SELOGIC control equations settings.
<b>SET P <i>n</i></b>	Change port settings
<b>SET R <i>n</i></b>	Change Sequential Events Recorder (SER) settings.
<b>SET T <i>n</i></b>	Change text label settings.
<b>VER</b>	For the <b>SET</b> commands, jump to parameter <i>n</i> to begin setting editing. If parameter <i>n</i> is not entered, setting editing starts at the first setting. Show relay configuration and firmware version.

# Section 6

## Front-Panel Interface

### Overview

This section describes how to get information, make settings, and execute control operations from the relay front panel. It also describes the default displays.


### Front-Panel Pushbutton Operation

#### Overview

Note in [Figure 6.1](#) that most of the pushbuttons have dual functions (primary/secondary).

A primary function is selected first (e.g., {METER} pushbutton).

After a primary function is selected, the pushbuttons then revert to operating on their secondary functions ({CANCEL}, {SELECT}, left/right arrows, up/down arrows). For example, after the {METER} pushbutton is pressed, the up/down arrows are used to scroll through the front-panel metering screens. The primary functions are activated again when the present selected function (metering) is exited (press {EXIT} pushbutton) or the display goes back to the default display after 15 minutes of no front-panel activity.



① See [Figure 6.3](#).


**Figure 6.1 SEL-551 Front-Panel Pushbuttons—Overview**

#### Primary Functions

Note in [Figure 6.2](#) and [Figure 6.3](#) that the front-panel pushbutton primary functions have correspondence to serial port commands—both retrieve the same information or perform the same function. To get more detail on the information provided by the front-panel pushbutton primary functions, refer to the corresponding serial port commands in [Section 5: Serial Port Communications and Commands](#). For example, to get more information on

the metering values available via the front-panel {METER} pushbutton, refer to the *MET Command (Meter) on page 5.14* and *MET D Command (Demand Ammeter) on page 5.15*.

A few of the front-panel primary functions do not have serial port command equivalents. These are discussed in the following *Functions Unique to the Front-Panel Interface on page 6.4*.




① Front-panel pushbutton functions that correspond to Access Level 1 serial port commands **do not** require the entry of the Access Level 1 password through the front panel.

**Figure 6.2 SEL-551 Front-Panel Pushbuttons—Primary Functions**

## Front-Panel Password Security

Refer to the comments at the bottom of *Figure 6.3* concerning the Access Level 2 password. See *PAS Command (Password) on page 5.23* for more information on passwords.

To enter the Access Level 2 password from the front panel (if required), use the left-right arrow pushbuttons to underscore a password digit position. Use the up/down arrow pushbuttons to then change the digit. Press the {SELECT} pushbutton once the correct Access Level 2 password is ready to enter. The factory default passwords for Access Levels 1 and 2 are shown in the table in subsection *PAS Command (Password)*.



- ① Front-panel pushbutton functions that correspond to Access Level 1 serial port commands **do not** require the entry of the Access Level 1 password through the front panel.
- ② Front-panel pushbutton functions that correspond to Access Level 2 serial port commands **do** require the entry of the Access Level 2 password through the front panel **if** main board jumper JMP24 is not in place.
- ③ Output contacts are pulsed for only one second from the front panel.
- ④ Local control **is not** available through the serial port and **does not** require the entry of a password.

**Figure 6.3 SEL-551 Front-Panel Pushbuttons-Primary Functions (continued)**

## Secondary Functions


After a primary function is selected (see [Figure 6.2](#) and [Figure 6.3](#)), the pushbuttons then revert to operating on their secondary functions (see [Figure 6.4](#)).

Use the left/right arrows to underscore a desired function. Then press the **{SELECT}** pushbutton to select the function.

Use left/right arrows to underscore a desired setting digit. Then use the up/down arrows to change the digit. After the setting changes are complete, press the **{SELECT}** pushbutton to select/enable the setting.

Press the **{CANCEL}** pushbutton to abort a setting change procedure and return to the previous display.

Press the **{EXIT}** pushbutton to return to the default display and have the primary pushbutton functions activated again (see [Figure 6.2](#) and [Figure 6.3](#)).



**Figure 6.4 SEL-551 Front-Panel Pushbuttons-Secondary Functions**

## Functions Unique to the Front-Panel Interface

Two front-panel primary functions do not have serial port command equivalents. These are:

- Reclosing relay shot counter screen (accessed via the {OTHER} pushbutton)
- Local control (accessed via the {CNTRL} pushbutton)


## Reclosing Relay Shot Counter Screen

Use this screen to see the progression of the shot counter during reclosing relay testing.


Access the reclosing relay shot counter screen via the {OTHER} pushbutton. The following screen appears:



Scroll right with the right arrow button and select function 79. Upon selecting function 79, the following screen appears (shown here with factory default settings):



or



If the reclosing relay does not exist (see [Reclosing Relay on page 3.22](#)), the following screen appears:



The corresponding text label settings (shown with factory default settings) are:

79LL = SET RECLOSURES (Last Shot Label-limited to 14 characters)

79SL = RECLOSE COUNT (Shot Counter Label-limited to 14 characters)

These text label settings are set with the **SET T** command or viewed with the **SHOWSET T** command via the serial port [see [Section 4: Setting the Relay](#) and [SHO Command \(Showset\) on page 5.16](#)].

The top numeral in the above example screen (SET RECLOSURES = 2) corresponds to the last shot value, which is a function of the number of set open intervals. There are two set open intervals in the factory default settings, thus two reclosures (shots) are possible in a reclose sequence.

The bottom numeral in the above example screen [RECLOSE COUNT = 0 (or = 2)] corresponds to the present shot value. If the breaker is closed and the reclosing relay is reset (RS LED on front panel is illuminated), RECLOSE COUNT = 0. If the breaker is open and the reclosing relay is locked out after a reclose sequence (LO LED on front panel is illuminated), RECLOSE COUNT = 2.

## Reclosing Relay Shot Counter Screen Operation (With Factory Settings)

With the breaker closed and the reclosing relay in the reset state (front-panel RS LED illuminated), the reclosing relay shot counter screen appears as:

```
SET RECLOSURES=2  
RECLOSE COUNT =0
```

The relay trips the breaker open, and the reclosing relay goes to the reclose cycle state (front-panel RS LED extinguishes). The reclosing relay shot counter screen still appears as:

```
SET RECLOSURES=2  
RECLOSE COUNT =0
```

The first open interval (79OI1 = 30) times out, the shot counter increments from 0 to 1, and the relay recloses the breaker. The reclosing relay shot counter screen shows the incremented shot counter:

```
SET RECLOSURES=2  
RECLOSE COUNT =1
```

The relay trips the breaker open again. The reclosing relay shot counter screen still appears as:

```
SET RECLOSURES=2  
RECLOSE COUNT =1
```

The second open interval (79OI2 = 600) times out, the shot counter increments from 1 to 2, and the relay recloses the breaker. The reclosing relay shot counter screen shows the incremented shot counter:

```
SET RECLOSURES=2  
RECLOSE COUNT =2
```

If the relay trips the breaker open again, the reclosing relay goes to the lockout state (front-panel L0 LED illuminates). The reclosing relay shot counter screen still appears as:

```
SET RECLOSURES=2  
RECLOSE COUNT =2
```

If the breaker is closed, the reclosing relay reset timer times out (79RSLD = 300), the relay goes to the reset state (front-panel **L0** LED extinguishes and **RS** LED illuminates), and the shot counter returns to 0. The reclosing relay shot counter screen appears as:




## Local Control


Use local control to enable/disable schemes, trip/close breakers, etc. via the front panel.

In more specific terms, local control asserts (sets to logical 1) or deasserts (sets to logical 0) what are called local bits **LB1–LB8**. These local bits are available as Relay Word bits and are used in **SELOGIC®** control equations (see [Table 4.5](#) and [Table 4.6](#)).


Local control can emulate the following switch types in [Figure 6.5](#) through [Figure 6.7](#).



**Figure 6.5 Local Control Switch Configured as an ON/OFF Switch**



**Figure 6.6 Local Control Switch Configured as an OFF/MOMENTARY Switch**



**Figure 6.7 Local Control Switch Configured as an ON/OFF/MOMENTARY Switch**


Local control switches are created by making corresponding switch position label settings. These text label settings are set with the **SET T** command or viewed with the **SHOWSET T** command via the serial port [see [Section 4: Setting the Relay](#) and [SHO Command \(Showset\) on page 5.16](#)]. See [Local Control Switches on page 3.5](#) for more information on local control.

## View Local Control

Access local control via the **{CNTRL}** pushbutton. If local control switches exist (i.e., corresponding switch position label settings were made), the following message displays with the rotating default display messages.




Press the **{CNTRL}** pushbutton, and the first set local control switch displays (shown here with factory default settings):




The RECLOSER: ENABLE/DISABLE switch is an ON/OFF switch.

Press the right arrow pushbutton, and scroll to the next set local control switch:




and to the next local control switch:



The MANUAL TRIP: RETURN/TRIP and MANUAL CLOSE: RETURN/CLOSE switches are both OFF/MOMENTARY switches.


There are no more local control switches in the factory default settings. Press the right arrow pushbutton, and scroll to the Output Contact Testing function:




This front-panel function provides the same function as the serial port **PULSE** command (see [Figure 6.3](#)).

## Operate Local Control (With Factory Settings)

Press the right arrow pushbutton, and scroll back to the first set local control switch in the factory default settings:




Press the **{SELECT}** pushbutton, and the operate option for the displayed local control switch displays:




With this first local control switch (RECLOSER ENABLE/DISABLE) in the DISABLE position, the ENABLE position is the only operate option.


Scroll left with the left arrow button and then select Yes. The display then shows the new local control switch position:




Use the right arrow pushbutton, and scroll to the next set local control switch:



Press the **{SELECT}** pushbutton, and the operate option for the displayed local control switch displays:



Scroll left with the left arrow button and then select Yes. The display then shows the new local control switch position:




Because this is an OFF/MOMENTARY type switch, the MANUAL TRIP switch returns to the RETURN position after momentarily being in the TRIP position. Technically, the MANUAL TRIP switch (being an OFF/MOMENTARY type switch) is in the:

TRIP position for one processing interval (1/8 cycle; long enough to assert the corresponding local bit LB3 to logical 1).

and then returns to the:

RETURN position (local bit LB3 deasserts to logical 0 again).

On the display, the MANUAL TRIP switch is shown to be in the TRIP position for two seconds (long enough to be seen by human eyes), and then it returns to the RETURN position:




The MANUAL CLOSE switch is an OFF/MOMENTARY type switch, like the MANUAL TRIP switch, and operates similarly.

### Local Control State Retained When Relay De-energized

Local bit states are stored in nonvolatile memory, so when power to the relay is turned off, the local bit states are retained.


For example, with the factory default settings, local bit LB1 controls the enabling/disabling of reclosing. If local bit LB1 is at logical 1, reclosing is enabled:




If power to the relay is turned off and then turned on again, local bit LB1 remains at logical 1, and reclosing is still enabled. This is similar to a traditional panel, where enabling/disabling of reclosing and other functions is accomplished by panel-mounted switches. If dc control voltage to the panel is lost and then restored again, the switch positions are still in place. If the reclosing switch is in the enable position (switch closed) before the power outage, it will be in the same position after the outage when power is restored.

# Rotating Default Display


The relay name, SEL-551, displays if no local control is operational (i.e., no corresponding switch position label settings were made) and no display point labels are enabled for display.



The Press CNTRL for Local Control message displays if at least one local control switch is operational. It is a reminder of how to access the local control function. See the preceding discussion in this section and [Local Control Switches on page 3.5](#) for more information on local control.



If display point labels are also enabled for display, the Press CNTRL for Local Control displays for two seconds and then is followed by enabled display point labels in subsequent two-second rotations.



The following table and figures demonstrate the correspondence between changing display point states (e.g., DP2 and DP4) and enabled display point labels (DP2\_1/DP2\_0 and DP4\_1/DP4\_0, respectively). The display is on a two-second rotation for each screen.


The display point factory settings are:

DP2 = **LB1** (local bit LB1)

DP4 = **IN1** (optoisolated input IN1)

Local bit LB1 is used as a recloser enable/disable local control switch (see [Local Control Switches on page 3.5](#)).

Optoisolated input IN1 is used as a circuit breaker status input (a 52a circuit breaker auxiliary contact is connected to input IN1; see [Optoisolated Inputs on page 3.3](#)).



In the preceding example, only two display points (DP2 and DP4) and their corresponding display point labels are set. If additional display points and corresponding display point labels are set, the additional enabled display point labels join the two seconds per screen rotation on the front-panel display.

Display point label settings are set with the **SET T** command or viewed with the **SHOWSET T** command via the serial port [see [Section 4: Setting the Relay](#) and [SHO Command \(Showset\) on page 5.16](#)].

# Section 7

## Standard Event Reports and SER

---

### Overview

---

The SEL-551 Relay has two styles of event reports:

- Standard 15-cycle event reports
- Sequential events recorder (SER) event report

These event reports contain date, time, current, relay element, optoisolated input, and output contact information.

Standard 15-cycle event reports are generated (triggered) by fixed and programmable conditions. These reports show information for 15 continuous cycles. The latest 20 standard 15-cycle event reports are stored in nonvolatile memory. If more than 20 events are triggered, the latest event report will overwrite the oldest event report, and the oldest event report will be lost. See [Figure 7.2](#) for an example standard 15-cycle event report.

Lines in the sequential events recorder (SER) event report are generated (triggered) by programmable conditions only. This report lists date and time-stamped lines of information each time a programmed condition changes state. The latest 512 lines of the SER event report are stored in nonvolatile memory. If the report fills up, newer rows will overwrite the oldest rows in the report. See [Figure 7.5](#) for an example SER event report.

### Standard 15-Cycle Event Reports

---

See [Figure 7.2](#) for an example standard 15-cycle event report.

#### Standard Event Report Triggering

The relay triggers (generates) a standard 15-cycle event report when any of the following occur:

- Relay Word bit TRIP asserts
- Programmable SELOGIC® control equations setting ER1 asserts to logical 1
- Programmable SELOGIC control equations setting ER2 asserts to logical 1
- **TRIGGER** serial port command executed
- **PULSE** serial port command for output contact **OUT1**, **OUT2**, **OUT3**, or **OUT4** executed

## Relay Word Bit TRIP

Relay Word bit TRIP would usually be assigned to an output contact for tripping a circuit breaker (e.g., SELOGIC control equations setting  $OUT1 = TRIP$ ). SELOGIC Control Equations setting TR controls the assertion of Relay Word bit TRIP (see [Figure 3.13](#)). Any condition that is set to trip in setting TR (e.g.,  $TR = 51P1T + 51G1T + 50P1*SH0 + LB3$ ) does *not* have to be entered in SELOGIC control equation settings ER1 or ER2. The assertion of Relay Word bit TRIP automatically triggers a standard 15-cycle event report.

## Programmable SELOGIC Control Equation Settings ER1 and ER2

The programmable SELOGIC control equation settings ER1 and ER2 are set to trigger standard 15-cycle event reports for conditions other than tripping conditions already listed in SELOGIC control equations setting TR. The factory settings are:

$$ER1 = 51P1 + 51G1$$

$$ER2 = SV5T + CF$$

ER1 is factory-set with time-overcurrent element pickups 51P1 and 51G1. Thus, at the inception of a fault, whichever pickup asserts first will trigger a standard 15-cycle event report.

ER2 is factory-set with a breaker failure condition (SV5T) and close failure condition (CF). It is not likely that these two conditions would assert at the same time. When a breaker failure or close failure condition occurs, a standard 15-cycle event report is triggered.

ER1 and ER2 trigger event reports independently and are rising-edge sensitive (logical 0 to logical 1 transition). For example, if a line-to-ground fault occurs and 51G1 asserts first in setting ER1 (logical 0 to logical 1 transition), it will trigger an event report. If 51G1 remains asserted and then a short time later 51P1 asserts, a second report will not be generated for the assertion of 51P1. ER1 is already at logical 1 because of the initial assertion of 51G1.

Rising-edge or falling-edge detects can be used in making SELOGIC settings. This is particularly useful in these event report trigger settings ER1 and ER2. For example, if setting  $ER1 = /IN2 + \dots$ , then every time input IN2 asserts (logical 0 to logical 1 transition), setting ER1 is effectively pulsed for one-processing interval. Thus, if input IN2 continues to be asserted (maintained at logical 1), it has no further effect on setting ER1 and any other Relay Word bit in setting ER1 is effectively free to operate and be detected by setting ER1. Most likely, each ORed Relay Word bit in setting ER1 or ER2 would have a rising-edge or falling-edge detect in front of it.

See [Section 3: Relay Elements and Logic](#) for more information on SELOGIC control equations.

## TRIGGER and PULSE Serial Port Commands

The sole function of the **TRIGGER** serial port command is to generate standard 15-cycle event reports, primarily for testing purposes.

The **PULSE** serial port command is used to assert the output contacts for testing purposes or for remote control. If output contact **OUT1**, **OUT2**, **OUT3**, or **OUT4** is asserted with the **PULSE** command, a standard 15-cycle event report is also generated.

## Standard Event Report Summary

See [Section 5: Serial Port Communications and Commands](#) for more information on serial port commands.

Each time the relay generates a standard 15-cycle event report, it also generates a corresponding event summary (see [Figure 7.1](#)). Event summaries contain the following information:

- Relay and terminal identifiers (settings RID and TID)
- Date and time when the event was triggered
- Event type
- Recloser shot count at time of trip
- Front-panel fault type targets at the time of trip
- Phase (IA, IB, IC), neutral (IN), calculated residual (3I0), and negative-sequence (3I2) current magnitudes in amps primary measured at the largest phase current magnitude in the triggered event report.

The Event Report Summary shows the magnitude of the maximum phase current calculated by the cosine filter or bipolar peak detector. When the relay uses the bipolar peak detector value (when a phase instantaneous pickup setting is greater than eight times nominal phase current, and the harmonic distortion index is greater than a fixed threshold), the relay displays  $p_k$  as shown in the Event Summary portion of the Example Standard 15-Cycle Event Report near the end of this section (for more information on the cosine filter and bipolar peak detector, see subsection [CT Saturation Protection on page 1.7](#)).

This event summary information is also contained in the corresponding standard 15-cycle event report. The identifiers, date, and time information is at the top of the standard 15-cycle event report, and the other information follows at the end. See [Figure 7.2](#).

---

FEEDER 1	Date: 08/07/02	Time: 15:33:09.498
STATION A		
Event: ER2 Shot: 2 Targets: INST A N		
Currents (A Pri), ABCNGQ:	19896 pk	13088 13108 1 1154 714

---

**Figure 7.1 Example Event Summary**

If serial port setting AUTO = Y, the event summary is sent from the serial port a few seconds after the event.

The latest 20 event summaries are stored in nonvolatile memory and are accessed by the **HISTORY** command. These event summaries correspond to the latest 20 standard 15-cycle event reports also stored in nonvolatile memory.

## Event Type

The `Event:` field shows the event type. The possible event types and their descriptions are shown in the table below. Note the correspondence to the preceding event report triggering conditions (see [Standard Event Report Triggering on page 7.1](#)).

**Table 7.1 Event Types**

Event	Event Triggered by:
TRIP	Assertion of Relay Word bit TRIP
ER1	SELOGIC control equations setting ER1
ER2	SELOGIC control equations setting ER2
TRIG	Execution of <b>TRIGGER</b> serial port command
PULSE	Execution of <b>PULSE</b> serial port command

## Currents

The Currents (A pri), ABCNGQ: field shows the currents present in the event report row containing the maximum phase current. The listed currents are:

- Phase (A = channel IA, B = channel IB, C = channel IC)
- Neutral (N = channel IN)
- Calculated residual (G =  $3I_0$ ; calculated from channels IA, IB, and IC)
- Negative-sequence (Q =  $3I_2$ ; calculated from channels IA, IB, and IC)

## Retrieving Full-Length Standard Event Reports

The latest 20 standard 15-cycle (full-length) event reports are stored in nonvolatile memory. Any given event report has four different ways it can be displayed, depending on the particular serial port command issued to the relay. The command choices are shown below. The *n* parameter refers to the event report number (*n* = 1–20), with *n* = 1 being the most recent event report and *n* = 20 being the oldest event report.

Serial Port Command	Format
EVENT <i>n</i>	Event report <i>n</i> displayed with rows of information each quarter (1/4) cycle.
EVENT C <i>n</i>	Digital data are added at the end of the quarter (1/4) cycle resolution event report <i>n</i> .
EVENT L <i>n</i>	Event report <i>n</i> displayed with rows of information each 1/8 cycle. See <a href="#">Figure 7.2</a> for an example of an 1/8-cycle resolution event report.
EVENT L C <i>n</i>	Digital data are added at the end of the 1/8-cycle resolution event report <i>n</i> .
EVENT R <i>n</i>	Event report <i>n</i> displayed with 16 cycles of raw (unfiltered) analog information in 1/16-cycle resolution.
EVENT R C <i>n</i>	Digital Data are added at the end of the 1/16-cycle resolution raw event report <i>n</i> with 1/8-cycle resolution.

If no numeric *n* parameter is entered with the serial port command, the most recent event report (*n* = 1) is displayed.

If an event report is requested which does not exist, the relay responds:

Invalid Event
---------------

The **EVENT** serial port commands can be entered with only the first three letters of the word **EVENT**. For example, the second most recent 1/8-cycle resolution event report can be retrieved by entering command:

---

```
=>EVE L 2 <Enter>
```

---

## Clearing Standard Event Report Buffer

The **HIS C** command clears the event summaries and corresponding full-length standard event reports from nonvolatile memory. See the [HIS Command \(History\) on page 5.13](#) for more information.

## Standard Event Report Column Definitions

Refer to the example event report in [Figure 7.2](#) to view event report columns. This example event report displays rows of information each 1/8 cycle and was retrieved with the **EVENT L n** command.

The columns contain current, element, input, and output information. The current columns show currents in primary amperes. The other columns show a number, letter, or symbol to indicate the condition of the elements, inputs, and outputs.

### Current Columns

The current columns show sampled current (after filtering) in primary amperes. The columns are shown in [Table 7.2](#).

**Table 7.2 Standard Event Report Current Columns**

Column Heading	Definition
IA	Current measured by channel IA
IB	Current measured by channel IB
IC	Current measured by channel IC
IN	Current measured by channel IN
IG	Calculated residual current (calculated from channels IA, IB, and IC; $IG = IA + IB + IC$ , vectorially added together)

Note that the current values change from plus to minus (–) values in [Figure 7.2](#), indicating the sinusoidal nature of the waveforms.

Other figures help in understanding the information available in the event report current columns:

[Figure 7.3](#) shows how event report current column data relate to the actual sampled current waveform and rms current values.

[Figure 7.4](#) shows how event report current column data can be converted to phasor rms current values.

**Table 7.3 Other Standard Event Report Columns (Sheet 1 of 3)**

Column Heading	Corresponding Elements (Relay Word Bits)	Symbol	Definition
All columns		.	Element/input/output not picked up or not asserted, unless otherwise stated.
51 P1	51P1, 51P1T, 51P1R	.	Time-overcurrent element reset (51_1R, 51_2R).
51 P2	51P2, 51P2T, 51P2R		
51 N1	51N1, 51N1T, 51N1R	p	Time-overcurrent element picked up and timing (51_1, 51_2).
51 G1	51G1, 51G1T, 51G1R		
51 Q2	51Q1, 51Q1T, 51Q1R	T	Time-overcurrent element timed out (51_1T, 51_2T).
51 Q2	51Q2, 51Q2T, 51Q2R	r	Time-overcurrent element timing to reset.
		1	Time-overcurrent element timing to reset after having timed out (when element reset is set for 1 cycle, not electromechanical reset).
50 P12	50P1, 50P2	1	Phase instantaneous overcurrent element 50P1 picked up.
		2	Phase instantaneous overcurrent element 50P2 picked up.
		b	Both 50P1 and 50P2 picked up.
50 P34	50P3, 50P4	3	Phase instantaneous overcurrent element 50P3 picked up.
		4	Phase instantaneous overcurrent element 50P4 picked up.
		b	Both 50P3 and 50P4 picked up.
50 P56	50P5, 50P6	5	Phase instantaneous overcurrent element 50P5 picked up.
		6	Phase instantaneous overcurrent element 50P6 picked up.
		b	Both 50P5 and 50P6 picked up.
50 ABC	50A, 50B, 50C	3	Single-phase instantaneous overcurrent elements 50A, 50B, and 50C picked up.
		a	Only 50A and 50B picked up.
		b	Only 50B and 50C picked up.
		c	Only 50C and 50A picked up.
		A	Only 50A picked up.
		B	Only 50B picked up.
		C	Only 50C picked up.
50 N12	50N1, 50N2	1	Neutral ground instantaneous overcurrent element 50N1 picked up.
		2	Neutral ground instantaneous overcurrent element 50N2 picked up.
		b	Both 50N1 and 50N2 picked up.
50 G12	50G1, 50G2	1	Residual ground instantaneous overcurrent element 50G1 picked up.
		2	Residual ground instantaneous overcurrent element 50G2 picked up.
		b	Both 50G1 and 50G2 picked up.
50 Q12	50Q1, 50Q2	1	Negative-sequence instantaneous overcurrent element 50Q1 picked up.
		2	Negative-sequence instantaneous overcurrent element 50Q2 picked up.
		b	Both 50Q1 and picked up.

**Table 7.3 Other Standard Event Report Columns (Sheet 2 of 3)**

Column Heading	Corresponding Elements (Relay Word Bits)	Symbol	Definition
79	CF, 79RS, 79CY, 79LO	. F R C L	Reclosing relay nonexistent Close failure condition CF asserts for only 1/8 cycle Reclosing relay in Reset State (79RS) Reclosing relay in Reclose Cycle State (79CY) Reclosing relay in Lockout State (79LO)
Shot	SH0, SH1, SH2 SH3, SH4	. 0 1 2 3 4	Reclosing relay nonexistent shot = 0 (SH0) shot = 1 (SH1) shot = 2 (SH2) shot = 3 (SH3) shot = 4 (SH4)
Lc1 12	LB1, LB2	1 2 b	Local bit LB1 asserted Local bit LB2 asserted Both LB1 and LB2 asserted
Lc1 34	LB3, LB4	3 4 b	Local bit LB3 asserted Local bit LB4 asserted Both LB3 and LB4 asserted
Lc1 56	LB5, LB6	5 6 b	Local bit LB5 asserted Local bit LB6 asserted Both LB5 and LB6 asserted
Lc1 78	LB7, LB8	7 8 b	Local bit LB7 asserted Local bit LB8 asserted Both LB7 and LB8 asserted
Rem 12	RB1, RB2	1 2 b	Remote bit RB1 asserted Remote bit RB2 asserted Both RB1 and RB2 asserted
Rem 34	RB3, RB4	3 4 b	Remote bit RB3 asserted Remote bit RB4 asserted Both RB3 and RB4 asserted
Rem 56	RB5, RB6	5 6 b	Remote bit RB5 asserted Remote bit RB6 asserted Both RB5 and RB6 asserted
Rem 78	RB7, RB8	7 8 b	Remote bit RB7 asserted Remote bit RB8 asserted Both RB7 and RB8 asserted
Rem 0C	OC, CC	o c	<b>OPEN</b> command executed <b>CLOSE</b> command executed
SELogic Var 12	SV1, SV2	1 2 b	SELOGIC Variable SV1 asserted SELOGIC Variable SV2 asserted Both SV1 and SV2 asserted

**Table 7.3 Other Standard Event Report Columns (Sheet 3 of 3)**

Column Heading	Corresponding Elements (Relay Word Bits)	Symbol	Definition
SELogic Var 34	SV3, SV4	3	SELOGIC Variable SV3 asserted
		4	SELOGIC Variable SV4 asserted
		b	Both SV3 and SV4 asserted
SELogic Var 5T	SV5, SV5T	p	SELOGIC Variable Timer input SV_ asserted; timer timing on pickup time; timer output SV_T not asserted.
SELogic Var 6T	SV6, SV6T		
SELogic Var 7T	SV7, SV7T	T	SELOGIC Variable Timer input SV_ asserted; timer timed out on pickup time; timer output SV_T asserted.
SELogic Var 8T	SV8, SV8T		
SELogic Var 9T	SV9, SV9T		
SELogic Var 10T	SV10, SV10T	d	SELOGIC Variable Timer input SV_ not asserted; timer previously timed out on pickup time; timer output SV_T remains asserted while timer timing on dropout time.
SELogic Var 11T	SV11, SV11T		
SELogic Var 12T	SV12, SV12T		
SELogic Var 13T	SV13, SV13T		
SELogic Var 14T	SV14, SV14T		

**Table 7.4 SEL-551 Input/Output Event Report Columns**

Column Heading	Corresponding Elements (Relay Word Bits)	Symbol	Definition
Out 12 <sup>a</sup>	OUT1, OUT2	1	Output contact OUT1 asserted
		2	Output contact OUT2 asserted
		b	Both OUT1 and OUT2 asserted
Out 34 <sup>a</sup>	OUT3, OUT4	3	Output contact OUT3 asserted
		4	Output contact OUT4 asserted
		b	Both OUT3 and OUT4 asserted
Out AL <sup>a</sup>	ALARM	A	Relay failed or PULSE A command executed
In12	IN1, IN2	1	Optoisolated input IN1 asserted
		2	Optoisolated input IN2 asserted
		b	Both IN1 and IN2 asserted

<sup>a</sup> Output contacts can be a or b type output contacts (see [Figure 2.15](#) and [Figure 3.23](#)).

## Sequential Events Recorder (SER) Event Report

See [Figure 7.5](#) for an example SER event report.

### SER Event Report Row Triggering

The relay triggers (generates) a row in the SER event report for any change of state in any one of the elements listed in the SER1, SER2, and SER3 trigger settings. The factory default settings are:

SER1 = **51P1 51G1 51P1T 51G1T 50P1 50P2**

SER2 = **IN1 LB1 LB3 LB4 OUT1 OUT2 OUT3**

SER3 = **CF 79RS 79LO SV5T**

The elements are Relay Word bits from [Table 4.5](#). Each element is looked at individually to see if it asserts or deasserts. Any assertion or deassertion of a listed element triggers a row in the SER event report. For example, setting SER1 contains:

- time-overcurrent element pickups (51P1 and 51G1)
- time-overcurrent element (timed out; 51P1T and 51G1T)
- instantaneous overcurrent elements (50P1 and 50P2)

Thus, any time one of these overcurrent elements picks up, times out, or drops out, a row is triggered in the SER event report.

The other two SER factory settings (SER2 and SER3) trigger rows in the SER event report for such things as optoisolated input (IN1), output contact (OUT1, OUT2, or OUT3), lockout state (79L0), and breaker failure (SV5T) operation, among other things.

Also, if the relay is newly powered up or a settings change is made, a row is triggered in the SER event report with the message:

```
Relay newly powered up or settings changed
```

Each row in the SER event report contains date, time, current, relay element, optoisolated input, and output contact information.

## Making SER Event Report Trigger Settings

Each SER trigger setting (SER1, SER2, or SER3) can be set with up to 24 elements (Relay Word bits from [Table 4.5](#) or [Table 4.6](#)). Thus, up to 72 elements can be monitored altogether for SER event report row triggering.

The SER settings can be made using spaces or commas as delimiters between elements. For example, if setting SER1 is made as follows:

SER1 = **51P1,51G1 51P1T,,51G1T , 50P1, , 50P2**

The setting displays as:

```
SER1 = 51P1 51G1 51P1T 51G1T 50P1 50P2
```

## Retrieving SER Event Report Rows

The latest 512 rows of the SER event report are stored in nonvolatile memory. Row 1 is the most recently triggered row, and row 512 is the oldest. These lines are accessed with the **SER** command in the different ways described in [Table 7.5](#).

**Table 7.5 SER Report Row Commands and Format (Sheet 1 of 2)**

Example SER Serial Port Commands	Format
<b>SER</b>	If <b>SER</b> is entered with no numbers following it, all available rows are displayed (up to row number 256). They display with the oldest row at the beginning (top) of the report and the latest row (row 1) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
<b>SER 17</b>	If <b>SER</b> is entered with a single number following it (17 in this example), the first 17 rows are displayed, if they exist. They display with the oldest row (row 17) at the beginning (top) of the report and the latest row (row 1) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.

**Table 7.5 SER Report Row Commands and Format (Sheet 2 of 2)**

Example SER Serial Port Commands	Format
<b>SER 10 33</b>	If <b>SER</b> is entered with two numbers following it (10 and 33 in this example; 10 < 33), all the rows between (and including) rows 10 and 33 are displayed, if they exist. They display with the oldest row (row 33) at the beginning (top) of the report and the latest row (row 10) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
<b>SER 47 22</b>	If <b>SER</b> is entered with two numbers following it (47 and 22 in this example; 47 > 22), all the rows between (and including) rows 47 and 22 are displayed, if they exist. They display with the newest row (row 22) at the beginning (top) of the report and the oldest row (row 47) at the end (bottom) of the report. <i>Reverse</i> chronological progression through the report is down the page and in ascending row number.
<b>SER 512 257</b>	Use this format to view any SER row between Row 512 and Row 257 (if these exist). The rows display with the newest row (Row 257) at the beginning (top) of the report and the oldest row (Row 512) at the end (bottom) of the report. Reverse chronological progression through the report is down the page in ascending row number.
<b>SER 3/30/96</b>	If <b>SER</b> is entered with one date following it (date 3/30/96 in this example), all the rows on that date are displayed, if they exist. They display with the oldest row at the beginning (top) of the report and the latest row at the end (bottom) of the report, for the given date. Chronological progression through the report is down the page and in descending row number.
<b>SER 2/17/96 3/23/96</b>	If <b>SER</b> is entered with two dates following it (date 2/17/96 chronologically <i>precedes</i> date 3/23/96 in this example), all the rows between (and including) dates 2/17/96 and 3/23/96 are displayed, if they exist. They display with the oldest row (date 2/17/96) at the beginning (top) of the report and the latest row (date 3/23/96) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
<b>SER 3/16/96 1/5/96</b>	If <b>SER</b> is entered with two dates following it (date 3/16/96 chronologically <i>follows</i> date 1/5/96 in this example), all the rows between (and including) dates 1/5/96 and 3/16/96 are displayed, if they exist. They display with the latest row (date 3/16/96) at the beginning (top) of the report and the oldest row (date 1/5/96) at the end (bottom) of the report. <i>Reverse</i> chronological progression through the report is down the page and in ascending row number.

The date entries in the above example **SER** commands are dependent on the Date Format setting DATE\_F. If setting DATE\_F = MDY, then the dates are entered as in the above examples (Month/Day/Year). If setting DATE\_F = YMD, then the dates are entered Year/Month/Day.

For any SER event report request, no more than 256 rows can be displayed at a time.

If the requested SER event report rows do not exist, the relay responds:

```
Invalid Record
```

If there are no rows in the SER event report buffer, the relay responds:

```
No SER data
```

## Clearing SER Event Report Buffer

If the **SER C** command is entered, the relay prompts the operator for confirmation:

```
Clear SER Buffer
Are you sure (Y/N)?
```

If Y is entered, the relay clears the SER event reports from nonvolatile memory. If N is entered, no reports are cleared, and the relay responds:

---

Canceled

---

## SER Event Report Column Definitions

Refer to the example SER event report in [Figure 7.5](#) to view SER event report columns. Note in [Figure 7.5](#) that a row in the SER event report is actually two lines long; the first line contains row, date, time, and any written message, and the second line contains the current and the other relay information.

The column definitions in [Table 7.2](#) and [Table 7.3](#) also apply to the columns of the SER Event Report. The SER Event Report has a few additional columns:

Column Heading	Definition
Row	SER event report row number (1–512)
Date	Date that the SER event report row was triggered
Time	Time (24-hour time) that the SER event report row was triggered

The SER event report current columns (IA, IB, IC, IN, and IG) display rms primary current magnitude values, rather than sampled current values, as the standard event report current columns do.

## Example Standard 15-Cycle Event Report

---

The following example SEL-551 standard 15-cycle event report in [Figure 7.2](#) also corresponds to the example sequential events recorder (SER) event report in [Figure 7.5](#). The circled, numbered comments in both these figures are explained in the text following [Figure 7.5](#).

In [Figure 7.2](#), the arrow (>) in the column following the IG current column identifies the “trigger” row. This is the row that corresponds to the Date and Time values at the top of the event report.

The asterisk (\*) in the column following the IG current column identifies the row with the maximum phase current. The maximum phase current is calculated from the row identified with the asterisk and the row one quarter-cycle previous (see [Figure 7.3](#)). These currents are listed at the end of the example event report. If the trigger row (>) and the maximum phase current row (\*) are the same row, the \* symbol takes precedence and is displayed.

7.12 Standard Event Reports and SER  
**Example Standard 15-Cycle Event Report**

FEEDER 1		Date: 02/29/96		Time: 13:45:44.924				firmware identifier		
STATION A								firmware checksum		
FID=SEL-551-R101-Vr-D960321		CID=00FF						firmware identifier		
IA	IB	Amps	Pri	IN	IG	51	50	S Lcl Rem	SELogic Var	OutI
IC	IN	IG	IG	IG	IG	IG	IG	IG	IG	IG
						51	50	S Lcl Rem	SELogic Var	OutI
						PPANGQ	h		11111	n
						PPNGQ0135B111	7o	135713570	135678901234	13A1
						121112246C222	9t	24682468C	24TTTTTTTTTT	24L2
137	-440	339	0	35	.....	RO	1	.....	.....	1
420	-386	-13	0	21	.....	RO	1	.....	.....	1
457	-106	-361	-0	-10	.....	RO	1	.....	.....	1
225	236	-494	-1	-34	.....	RO	1	.....	.....	1
-138	440	-339	-0	-37	.....	RO	1	.....	.....	1
-420	385	12	0	-23	.....	RO	1	.....	.....	1
-457	106	360	1	8	.....	RO	1	.....	.....	1
-224	-236	493	0	33	.....	RO	1	.....	.....	1
[Two cycles of data not shown in this example]										
137	-439	339	0	36	.....	RO	1	.....	.....	1
420	-385	-13	-0	22	.....	RO	1	.....	.....	1
456	-106	-361	-0	-11	.....	RO	1	.....	.....	1
225	236	-494	-0	-34	.....	RO	1	.....	.....	1
-138	439	-339	0	-38	.....	RO	1	.....	.....	1
-419	385	12	0	-22	.....	RO	1	.....	.....	1
-551	106	360	0	-86	.....	RO	1	.....	.....	1
-675	-236	491	0	-420	p.p.....	RO	1	.....	.....	1
-459	-437	336	0	-560	p.p.....	RO	1	.....	.....	1
320	-382	-14	-0	-76	p.p.....	RO	1	.....	.....	1
1150	-104	-356	-0	690	p.p.....	RO	1	.....	.....	1
1698	232	-485	-1	1445	p.p.....	RO	1	.....	.....	1
1308	432	-331	-0	1409	p.p.....	RO	1	.....	.....	1
-58	377	16	0	335	p.p.....	RO	1	.....	.....	1
-1654	101	353	0	-1201	p.p..1.....	CO	1	.....	..p.....	1.1
-2273	-231	483	1	-2022	p.p..1.....	CO	1	.....	..p.....	1.1
-1560	-430	330	0	-1661	p.p..1.....	CO	1	.....	..p.....	1.1
68	-376	-16	-0	-325	p.p..1.....	CO	1	.....	..p.....	1.1
1655	-101	-353	-1	1201	p.p..1.....	CO	1	.....	..p.....	1.1
2272	231	-482	-1	2020	p.p..1.....	CO	1	.....	..p.....	1.1
1559	429	-330	-0	1658	p.p..1.....	CO	1	.....	..p.....	1.1
-67	376	16	0	325	p.p..1.....	CO	1	.....	..p.....	1.1
-1654	102	352	1	-1201	p.p..1.....	CO	1	.....	..p.....	1.1
-2272	-230	482	1	-2020	p.p..1.....	CO	1	.....	..p.....	1.1
-1560	-429	330	0	-1660	p.p..1.....	CO	1	.....	..p.....	1.1
66	-376	-16	-0	-326	p.p..1.....	CO	1	.....	..p.....	1.1
1654	-102	-352	-0	1200	p.p..1.....	CO	1	.....	..p.....	1.1
2274	230	-482	-0	2022	p.p..1.....	CO	1	.....	..p.....	1.1
1559	430	-330	0	1658	p.p..1.....	CO	1	.....	..p.....	1.1
-69	376	16	0	322	p.p..1.....	CO	1	.....	..p.....	1.1
-1656	100	352	0	-1204	p.p..1.....	CO	1	.....	..p.....	1.1
-2274	-232	482	0	-2025	p.p..1.....	CO	1	.....	..p.....	1.1
-1558	-430	330	0	-1658	p.p..1.....	CO	1	.....	..p.....	1.1
70	-375	-16	-0	-321	*p.p..1.....	CO	1	.....	..p.....	1.1
1656	-100	-352	-0	1204	p.p..1.....	CO	1	.....	..p.....	1.1
2273	232	-483	-1	2022	p.p..1.....	CO	1	.....	..p.....	1.1
1555	430	-329	-0	1656	p.p..1.....	CO	1	.....	..p.....	1.1
-70	374	17	0	321	p.p..1.....	CO	1	.....	..p.....	1.1
-1538	88	330	1	-1120	p.p..1.....	CO	1	.....	..p.....	1.1
-1725	-222	366	1	-1580	p.p.....	CO	1	.....	.....	1.1
-922	-337	193	0	-1067	p.p.....	CO	1	.....	.....	1.1
128	-236	-32	-1	-140	p.p.....	CO	1	.....	.....	1.1
708	-38	-156	-1	514	p.p.....	CO	1	.....	.....	1.1
587	107	-127	-1	567	r.p.....	CO	1	.....	.....	1.1
146	122	-30	-0	238	r.p.....	CO	1	.....	.....	1.1
-94	47	25	1	-22	r.p.....	CO	1	.....	.....	1.1
1	0	2	0	3	r.p.....	CO	1	.....	.....	1.1
1	0	2	0	3	r.p.....	CO	1	.....	.....	1.1
0	0	0	0	0	r.p.....	CO	1	.....	.....	1.1
0	0	-4	-0	-4	r.p.....	CO	1	.....	.....	1.1
0	0	-1	0	-1	r.p.....	CO	1	.....	.....	1.1
0	0	-2	-0	-2	r.p.....	CO	1	.....	.....	1.1
0	0	-1	-0	-1	r.p.....	CO	1	.....	.....	1.1
0	0	1	0	1	r.p.....	CO	1	.....	.....	1.1
0	0	1	0	1	r.p.....	CO	1	.....	.....	1.1
0	0	3	1	3	.....	CO	1	.....	.....	1.1

firmware identifier  
firmware checksum  
firmware identifier

one cycle of data

⑥

⑦

⑧

See Figure 7.3 and Figure 7.4 for details on this example one cycle of phase A (channel IA) current.

(Continued on next page)

(Continued from previous page)

[Three cycles of data not shown in this example]

```

1      0      1      0      2 ..... CO 1..... .p..... 1...
0      0      -2     -0     -2 ..... CO 1..... .p..... 1...
0      0      -1     -0     -1 ..... CO 1..... .p..... 1...
-1     0      -4     -0     -5 ..... CO 1..... .p..... 1...
-1     0      -1     -0     -2 ..... CO 1..... .p..... 1...
0      0      2      0      2 ..... CO 1..... .p..... 1...
0      0      2      0      2 ..... CO 1..... .p..... 1...
1      0      3      0      4 ..... CO 1..... .p..... 1...

```

9

[One cycle of data not shown in this example]

Event: TRIP Shot: 0 Targets: INST A N  
 Currents (A Pri), ABCNGQ: 2275 441 482 1 2050 2119

Relay Settings:

```

RID =FEEDER 1 TID =STATION A
CTR = 120 CTRN = 120 TDURD = 9.000
50P1P = 15.0 50P2P = 20.0 50P3P = OFF 50P4P = OFF
50P5P = OFF 50P6P = OFF 50ABCP= OFF
51P1P = 6.0 51P1C = U3 51P1TD= 3.00 51P1RS= N
51P2P = OFF 51P2C = U3 51P2TD= 15.00 51P2RS= N
50N1P = OFF 50N2P = OFF
51N1P = OFF 51N1C = U3 51N1TD= 15.00 51N1RS= N
50G1P = OFF 50G2P = OFF
51G1P = 1.5 51G1C = U3 51G1TD= 1.50 51G1RS= N
50Q1P = OFF 50Q2P = OFF
51Q1P = OFF 51Q1C = U3 51Q1TD= 15.00 51Q1RS= N
51Q2P = OFF 51Q2C = U3 51Q2TD= 15.00 51Q2RS= N
79O1I = 30.000 79O12 = 600.000 79O13 = 0.000 79O14 = 0.000
79RSD = 1800.000 79RSLD= 300.000 CFD = 60.000
SV5PU = 12.000 SV5D0 = 2.000 SV6PU = 0.000 SV6D0 = 0.000
SV7PU = 0.000 SV7D0 = 0.000 SV8PU = 0.000 SV8D0 = 0.000
SV9PU = 0.000 SV9D0 = 0.000 SV10PU= 0.000 SV10D0= 0.000
SV11PU= 0.000 SV11D0= 0.000 SV12PU= 0.000 SV12D0= 0.000
SV13PU= 0.000 SV13D0= 0.000 SV14PU= 0.000 SV14D0= 0.000
NFREQ = 60 PHROT = ABC DATE_F= MDY

```

Relay and SELogic Control  
 Equations follow the standard  
 15-cycle event report.

SELogic Control Equations:

```

TR =51P1T + 51G1T + 50P1 * SH0 + LB3
ULTR =!(51P1 + 51G1)
51P1TC=1
51P2TC=1
51N1TC=1
51G1TC=1
51Q1TC=1
51Q2TC=1
52A =IN1
CL =LB4
ULCL =TRIP
79RI =TRIP
79RIS =IN1
79DTL =!LB1 + LB3
79DLS =79L0
79SKP =50P2 * SH0
79STL =TRIP
79BRS =(51P1 + 51G1) * (79RS + 79CY)
79SEQ =0
ER1 =51P1 + 51G1
ER2 =SV5T + CF
SV1 =0
SV2 =0
SV3 =0
SV4 =0
SV5 =TRIP
SV6 =0
SV7 =0
SV8 =0
SV9 =0
SV10 =0
SV11 =0
SV12 =0
SV13 =0
SV14 =0
OUT1 =TRIP
OUT2 =CLOSE
OUT3 =SV5T
OUT4 =0

```

(Continued on next page)

---

(Continued from previous page)


```
DP1  =0  
DP2  =LB1  
DP3  =0  
DP4  =IN1  
DP5  =0  
DP6  =0  
DP7  =0  
DP8  =0
```

```
=>>
```

---


**Figure 7.2 Example SEL-551 Standard 15-Cycle Event Report (1/8-Cycle Resolution)**

*Figure 7.3* and *Figure 7.4* look in detail at 1 cycle of phase A (channel IA) current identified in *Figure 7.2*. *Figure 7.3* shows how the event report current column data relate to the actual sampled current waveform and rms current values. *Figure 7.4* shows how the event report current column data can be converted to phasor rms current values.



**Figure 7.3 Derivation of Event Report Current Values and RMS Current Values From Sampled Current Waveform**

In [Figure 7.3](#), note that any two rows of current data from the event report in [Figure 7.2](#), one quarter (1/4) cycle apart, can be used to calculate rms current values.



**Figure 7.4 Derivation of Phasor RMS Current Values From Event Report Current Values**

In *Figure 7.4*, note that two rows of current data from the event report in *Figure 7.2*, one quarter (1/4) cycle apart, can be used to calculate phasor rms current values. In *Figure 7.4*, at the present sample, the phasor rms current value is:

$$IA = 2275 \text{ A } \angle -88.24^\circ$$

The present sample (IA = 70 A) is a real rms current value that relates to the phasor rms current value:

$$2275 \text{ A} \cdot \cos(-88.24^\circ) = 70 \text{ A}$$

## Example Sequential Events Recorder (SER) Event Report

The following example SEL-551 sequential events recorder (SER) event report in *Figure 7.5* also corresponds to the example standard 15-cycle event report in *Figure 7.2*.

Row	Date	Time	Amps	Pri	IN	OutI	n			
FEEDER 1		Date: 02/29/96	Time: 13:46:26.988							
STATION A										
FID=SEL-551-R101-Vr-D960321		CID=00FF		See explanation in <a href="#">Figure 7.2</a> .						
			51	50	S	Lc1	Rem	SELogic	Var	OutI
			PPANGQ	h				11111		n
			PPNGQ0135B111	7o	135713570	135678901234	13A1			
			IG 121112246C222	9t	24682468C	24TTTTTTTTTT	24L2			
13	02/29/96	13:44:30.146								
2	0	2	1							
12	02/29/96	13:45:02.487								
0	0	2	1							
11	02/29/96	13:45:18.239								
1	0	1	0							
10	02/29/96	13:45:18.241								
0	0	2	1							
9	02/29/96	13:45:18.256								
236	274	137	0							
8	02/29/96	13:45:23.258								
475	454	494	1							
7	02/29/96	13:45:44.924								
794	451	491	1							
6	02/29/96	13:45:44.939								
2109	443	484	0							
5	02/29/96	13:45:44.991								
1726	435	367	1							
4	02/29/96	13:45:44.999								
601	259	131	1							
3	02/29/96	13:45:45.001								
723	127	158	1							
2	02/29/96	13:45:45.008								
94	47	25	1							
1	02/29/96	13:45:45.089								
1	0	2	0							

**Figure 7.5 Example Sequential Events Recorder (SER) Event Report**

The circled, numbered comments in both *Figure 7.2* and *Figure 7.5* are explained in the following text.

**NOTE:** Two set open intervals (790I1, 790I2) precede the first open interval set to zero (790I3 = 0.000). Thus, last shot = 2.

- ① Relay powers up in the Lockout State (L) and at last shot (= 2).

Related setting:

790I1 = . **30.000**

790I2 = . **600.000**

790I3 = **0.000**

- ② Front-panel operation of Local bit LB1(1) enables reclosing.

Related setting:

79DTL = **!LB1 +**

- ③ Front-panel operation of Local bit LB4 (4) closes the circuit breaker via output contact **OUT2** (2).

Related settings:

CL = **LB4**

OUT2 = **CLOSE**

- ④ Input **IN1**(1) indicates the circuit breaker closed.

Related setting:

52A = **IN1**

- ⑤ Relay goes to the Reset State (R), 300 cycles after the circuit breaker closes.

Related setting:

79RSLD = **300.000 cycles**

Time difference: 13:45:23.258 – 13:45:18.256 = 5.002 seconds  
(= 300 cycles)

- ⑥ Fault starts and time-overcurrent elements 51P1T and 51G1T pick up and start timing (p).

- ⑦ Relay trips on element 50P1(1). Relay goes to the Reclose Cycle State (C). Element 50P1 can trip because the shot = 0 (0). Output contact **OUT1** (1) trips the circuit breaker.

Related settings:

TR = **... + 50P1 \* SHO +**

OUT1 = **TRIP**

- ⑧ The circuit breaker opens (.).

- ⑨ Output contact **OUT1** deasserts (.) after being asserted a minimum of 9 cycles.

Related settings:

TDURD = **9.000 cycles**

OUT1 = **TRIP**

Time difference: 13:45:45.089 – 13:45:44.939 = 0.150 seconds  
(= 9 cycles)

# Section 8

## Testing and Troubleshooting

---

### Overview

---

The *Acceptance Testing on page 8.4*, *Commissioning Testing on page 8.14*, and *Maintenance Testing on page 8.15* should be used for determining and establishing test routines for the SEL-551 Relay. Included are discussions on testing philosophies, methods, and tools. Example test procedures are shown for the overcurrent elements, differential elements, and metering. Relay troubleshooting procedures are shown at the end of the section.

Protective relay testing can be divided into three categories:

- acceptance
- commissioning
- maintenance

The categories are differentiated by when they take place in the life cycle of the relay, as well as in the test complexity.

The paragraphs below describe when each type of test is performed, the goals of testing at that time, and the relay functions that you need to test at each point. This information is intended as a guideline for testing SEL relays.

### Testing Methods and Tools

---

#### Test Features Provided by the Relay

The following features assist you during relay testing:

Feature	Description
<b>METER</b> Command	The <b>METER</b> command shows the currents presented to the relay in primary values. Compare these quantities against other devices of known accuracy.
<b>EVENT</b> Command	The relay generates an event report in response to faults or disturbances. Each report contains current information, relay element states, and input/output contact information. If you question the relay response or your test method, use the <b>EVENT</b> command to display detailed information.
<b>TARGET</b> Command	Use the <b>TARGET n</b> command to view the state of relay control inputs, relay outputs, and relay elements individually during a test.
<b>SER</b> Command	Use the Sequential Event Recorder for timing tests by setting the SER trigger settings (SER1, SER2, or SER3) to trigger for specific elements asserting or deasserting. View the SER with the <b>SER</b> command.
Programmable Outputs	Programmable outputs allow you to isolate individual relay elements. Refer to the <b>SET</b> command.

## Low-Level Test Interface

### CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

For more information on these features and commands, see [Section 5: Serial Port Communications and Commands](#).

The SEL-551 has a low-level test interface between the calibrated input module and the separately-calibrated processing module. You can test the relay in either of two ways:

- conventionally, by applying ac current signals to the relay inputs
- by applying low magnitude ac voltage signals to the low-level test interface


Access the test interface by removing the relay front panel.

[Figure 8.1](#) shows the low-level interface connections. Remove the ribbon cable between the two modules to access the outputs of the input module and the inputs to the processing module (relay main board).

You can test the relay processing module, using signals from the SEL RTS Low-Level Relay Test System. Never apply voltage signals greater than 9 V peak-to-peak to the low-level test interface. [Figure 8.1](#) shows the signal scaling factors.

You can test the input module two different ways:

1. Measure the outputs from the input module with an accurate voltmeter, and compare the readings to accurate instruments in the relay input circuits, or
2. Replace the ribbon cable, press the front-panel {METER} button, and compare the relay readings to other accurate instruments in the relay input circuits.



**Figure 8.1 Low-Level Test Interface**

## Test Methods

Test the pickup and dropout of relay elements, using one of three methods:

- front-panel target LCD/LED indication
- output contact operation
- the Sequential Event Recorder (SER)

### Target LED Illumination

- Step 1. During testing, use target LED illumination to determine relay element status.
- Step 2. Using the **TAR** command, set the front-panel targets to display the element under test.

- Step 3. Monitor element pickup and dropout by observing the target LEDs.

For example, the level 1 phase instantaneous overcurrent element 50P1 appears in Relay Word Row 2. When you type the command **TAR 2 <Enter>**, the terminal displays the labels and status for each bit in the Relay Word Row (2) and the LEDs display their status. Thus, with these new targets displayed, if the level 1 phase instantaneous overcurrent element (50P1) asserts, the fifth from the left LED illuminates. See [Section 4: Setting the Relay](#) for a list of all Relay Word elements.

- Step 4. Be sure to reset the front-panel targets to the default targets after testing before returning the relay to service.

This can be done by pressing the front-panel {TARGET RESET} pushbutton, or by issuing the **TAR R** command from the serial port.

## Output Contact Operation

- Step 1. To test using this method, set one programmable output contact to assert when the element under test picks up.
- Step 2. With the **SET L n** command, enter the Relay Word bit name of the element under test.
- Step 3. For an a-type output contact, when the condition asserts, the output contact closes. When the condition deasserts, the output contact opens.
- Step 4. For a b-type output contact, when the condition asserts, the output contact opens. When the condition deasserts, the output contact closes.

Programmable contacts can be changed to a- or b-type output contacts with a solder jumper.

- Step 1. Refer to [Section 2: Installation](#) for jumper locations.
- Step 2. Using output contact operation as an indicator, you can measure element operating characteristics, stop timers, etc.

Tests in this section assume an a-type output contact.

## Sequential Event Recorder (SER)

- Step 1. To test using this method, set the SER to trigger for the element under test.
- Step 2. With the **SET R** command, put the element name in the SER1, SER2, or SER3 setting.
- Whenever an element asserts or deasserts, a time stamp is recorded.
- Step 3. View the SER report with the **SER** command.
- Step 4. Clear the SER report with the **SER C** command.

# Acceptance Testing

---

When: Qualifying a relay model to be used on the utility system.

Goal:

- Ensure relay meets published critical performance specifications such as operating speed and element accuracy.
- Ensure that the relay meets the requirements of the intended application.
- Gain familiarity with relay settings and capabilities.

What to test: All protection elements and logic functions critical to the intended application.

SEL performs detailed acceptance testing on all new relay models and versions. We are certain the relays we ship meet their published specifications. It is important for you to perform acceptance testing on a relay if you are unfamiliar with its operating theory, protection scheme logic, or settings. This helps ensure the accuracy and correctness of the relay settings when you issue them.

## Equipment Required

The following equipment is necessary to perform all of the acceptance tests:

1. A terminal or computer with terminal emulation with EIA-232 serial interface
2. Interconnecting data cable between terminal and relay
3. Source of relay control power
4. Source of one current at nominal frequency
5. Ohmmeter or contact opening/closing sensing device

## Initial Checkout

Step 1. Purpose:

Be sure you received the relay in satisfactory condition.

Method:


Inspect the instrument for physical damage such as dents or rattles.

Step 2. Purpose:

Verify requirements for relay logic inputs, control power voltage level, and voltage and current inputs.

Method:

- a. Refer to the information sticker on the rear panel of the relay. Actual information stickers vary, but [Figure 8.2](#) provides an example.
- b. Check the information on this sticker before applying power to the relay or starting tests.
- c. Be sure your dc supply is correctly adjusted for the control and logic input requirements. The logic input voltage rating is jumper selectable. The sticker gives the factory default voltage rating.



**Figure 8.2 Relay Part Number and Hardware Identification Sticker**

## Power Supply

### Step 1. Purpose:

Establish control power connections.

### Method:

Connect a frame ground to terminal marked **GND** on the rear panel and connect rated control power to terminals marked **+** and **-**. Relays supplied with 125 or 250 V power supplies can be powered from a 115 Vac wall receptacle for testing. Other power supplies require dc voltage and are polarity sensitive.

## Serial Communication

### Step 1. Purpose:

Verify the communications interface setup.

### Method:

Connect a computer terminal to the serial port of the relay.

Communication Parameters: 2400 Baud, 8 Data Bits, 1 Stop Bit, N Parity

Cables: SEL C234A for 9-pin male computer connections, SEL C227A for 25-pin male computer connections

### Step 2. Purpose:

Apply control voltage to the relay, and start Access Level 0 communications.

### Method:

- Apply control voltage to the relay. The enable target (**EN**) LED should illuminate. If not, be sure that power is present.
- Press the **<Enter>** key from your terminal to get the Access Level 0 response from the relay.

The = prompt should appear, indicating that you have established communications at Access Level 0 (presuming correct terminal configuration).

The **ALARM** relay should hold its b-type output contact open.

If these do not occur, refer to [Relay Troubleshooting on page 8.17](#).

**NOTE:** If you are using a battery simulator, be sure the simulator voltage level is stabilized before turning the relay on.

Step 3. Purpose:

Establish Access Level 1 communications.

Method:

- a. Type **ACC** <Enter>.
- b. At the prompt, enter the Access Level 1 password and press <Enter>. The => prompt should appear, indicating that you have established communications at Access Level 1.

Step 4. Purpose:

Verify relay self-test status.

Method:

- a. Type **STA** <Enter>. The following display should appear on the terminal:

```
=>>STA <Enter>

FEEDER 1                               Date: 02/07/00   Time: 23:25:34.869
STATION A

FID=SEL-551-R504-Vf-D970616           CID=D7F0

SELF TESTS

W=Warn   F=Fail

OS      IA      IB      IC      IN      MOF
        3       3       3       3       0

PS      +5V_PS  +5V_REG  -5V_REG  +10V_PS  -10V_PS  VBAT
        4.99   4.99    -5.06    10.17   -10.33   2.92

        TEMP    RAM     ROM     CR_RAM  EEPROM
        28.6   OK     OK     OK     OK     OK

Relay Enabled

=>
```

The **STA** Command (Status) subsection in [Section 5: Serial Port Communications and Commands](#) explains the values listed in the above status printout.

Step 5. Purpose:

View factory settings entered before shipment.

Method:

- a. The relay is shipped with factory settings; type **SHO** <Enter> to view the settings. [Section 4: Setting the Relay](#) includes a complete description of the settings. The terminal display should look similar to the following:

```

=>>SHO <Enter>

Relay Settings:
RID =FEEDER 1      TID =STATION A
CTR = 120          CTRN = 120      TDURD = 9.000
50P1P = 15.0      50P2P = 20.0      50P3P = OFF      50P4P = OFF
50P5P = OFF       50P6P = OFF       50ABCP= OFF
51P1P = 6.0       51P1C = U3        51P1TD= 3.00     51P1RS= N
51P2P = OFF       51P2C = U3        51P2TD= 15.00    51P2RS= N
50N1P = OFF       50N2P = OFF
51N1P = OFF       51N1C = U3        51N1TD= 15.00    51N1RS= N
50G1P = OFF       50G2P = OFF
51G1P = 1.5       51G1C = U3        51G1TD= 1.50     51G1RS= N
50Q1P = OFF       50Q2P = OFF
51Q1P = OFF       51Q1C = U3        51Q1TD= 15.00    51Q1RS= N
51Q2P = OFF       51Q2C = U3        51Q2TD= 15.00    51Q2RS= N
79O1I = 30.000    79O1I2 = 600.000  79O1I3 = 0.000   79O1I4 = 0.000
79RSD = 1800.000  79RSLD= 300.000  CFD = 60.000
DMTC = 5
PDEMP = 5.00      NDEMP = 1.50      GDEMP = 1.50      QDEMP = 1.50

Press RETURN to continue
SV5PU = 12.000    SV500 = 2.000     SV6PU = 0.000     SV600 = 0.000
SV7PU = 0.000    SV700 = 0.000     SV8PU = 0.000     SV800 = 0.000
SV9PU = 0.000    SV900 = 0.000     SV10PU= 0.000     SV1000= 0.000
SV11PU= 0.000    SV1100= 0.000     SV12PU= 0.000     SV1200= 0.000
SV13PU= 0.000    SV1300= 0.000     SV14PU= 0.000     SV1400= 0.000
NFREQ = 60        PHROT = ABC        DATE_F= MDY
=>>

```

The *SHO Command (Showset)* on page 5.16 explains the other settings available with variations of the **SHO** command.

## Outputs

Step 1. Purpose:

Verify that contact outputs operate when you execute the **PULSE** command.

Method:

- Isolate all circuitry connected to the output contacts.
- Set the target LEDs to display the contact outputs by typing **TAR 12 <Enter>**. The front-panel LEDs should now follow Row 12 of the Relay Word where the outputs are listed.
- Execute the **PULSE *n*** command for each output contact.
- Verify that the corresponding target LED illuminates and that the output contact closes for approximately one second. For example, type **PUL OUT1 <Enter>** to test output contact OUT1.

The response of a programmable alarm output contact to a **PULSE** command is discussed in the *Output Contacts* on page 3.39.

## Inputs

Step 1. Purpose:

Verify that logic inputs assert when control voltage is applied across the respective terminal pair.

Method:

- Set the target LEDs to display the contact inputs by typing **TAR 4 <Enter>**. The fourth and fifth front-panel LED should now follow logic inputs IN1 and IN2, which are in Relay Word Row 4.2.

- b. Apply the appropriate control voltage to each input and make sure the corresponding target LED turns on.

Note that the control voltage required to assert an input is jumper selectable.

If you suspect the jumpers to be different from the factory default, refer to [Section 2: Installation](#) for the jumper locations.

## Metering

### Step 1. Purpose:

Connect simulated power system secondary current sources to the relay.

#### Method:

- a. Turn power off to the relay and connect current sources. If three current sources are available, connect them to the relay as shown in [Figure 8.3](#). If only two current sources are available, connect the sources as shown in [Figure 8.4](#) to generate balanced positive-sequence currents.
- b. Set the current sources to deliver 1 A secondary.
- c. Set the current angles (e.g., B-phase lags A-phase by 120°) according to the phase rotation setting PHROT (i.e., PHROT = ABC or ACB).

### Step 2. Purpose:

Verify correct current levels.

#### Method:


- a. Turn relay power on, and use the **METER** command to display the currents applied in [Step 1](#).  
With applied currents of 1 A secondary per phase and a current transformer ratio of 120:1 (assuming setting CTR = 120), the displayed line currents should be close to 120 amperes primary.

### Step 3. Purpose:


Verify phase rotation.

#### Method:

- a. Verify that residual (IG) and negative-sequence (3I2) quantities are approximately zero (or much less than the approximately 120 A primary displayed for the phases).  
If IG equals approximately 3 times the applied current, then all three phases have the same angle. If 3I2 equals approximately 3 times the applied current, then the phase rotation is reversed.
- b. Turn the current sources off.



**Figure 8.3** Test Connections for Balanced Load With Three-Phase Current Sources



**Figure 8.4** Test Connections for Balanced Load With Two-Phase Current Sources

## Instantaneous Overcurrent Elements

**NOTE:** This example tests the 50P1 phase overcurrent element. Use the same procedure to test all instantaneous overcurrent elements for each phase.

Step 1. Purpose:

Determine the expected instantaneous overcurrent element pickup value.

Method:

- a. Execute the **SHO** command via the relay front panel or serial port and verify the setting (i.e., **SHO 50P1 <Enter>**).

Step 2. Purpose:

Display the appropriate Relay Word bit on the front-panel LEDs.

Method:

- a. Execute the **TARGET** command (i.e., **TAR 2 <Enter>**).

The SEL-551 now displays the state of several overcurrent elements on the front-panel LED and LCD display.

Step 3. Purpose:

Connect and apply a single current test source until the appropriate LED illuminates.

Method:

- a. Connect a single current test source (i.e., source 1 to current input **IA**) as shown in [Figure 8.3](#).
- b. Turn on the current test source for the phase under test, and slowly increase the magnitude of current applied until the appropriate element asserts (i.e., 50P1), causing the LED to illuminate (i.e., fifth from the left; see [Table 5.5](#)).
- c. Note the magnitude of the current applied. It should equal the 50P1P setting  $\pm 5$  percent of the setting and  $\pm 0.1$  A secondary.

Step 4. Purpose:

Repeat test for each instantaneous overcurrent element.

Method:

- a. Repeat [Step 1–Step 3](#) for each instantaneous overcurrent element listed in [Table 8.1](#).
- b. Remember to view the element with the **TAR** command (see [Table 5.6](#)). The computer terminal will display the LED labels from left to right when the **TAR** command is issued.

**Table 8.1 Instantaneous Overcurrent Elements and Corresponding Settings/Relay Word Bits/TAR Commands**

Element	Pickup Setting	Relay Word Bit	TAR
Phase Level 1	50P1P	50P1	2
Phase Level 2	50P2P	50P2	2
Phase Level 3	50P3P	50P3	2
Phase Level 4	50P4P	50P4	2
Phase Level 5	50P5P	50P5	3
Phase Level 6	50P6P	50P6	3
Independent A-Phase	50ABCP	50A	4
Independent B-Phase		50B	
Independent C-Phase		50C	
Neutral Ground Level 1	50N1P	50N1	3
Neutral Ground Level 2	50N2P	50N2	3
Residual Ground Level 1	50G1P	50G1	3
Residual Ground Level 2	50G2P	50G2	3
Negative-Sequence Level 1	50Q1P	50Q1	3
Negative-Sequence Level 2	50Q2P	50Q2	3

## Inverse-Time Overcurrent Elements

**NOTE:** This example tests the 51P1T phase inverse-time overcurrent element. Use the same procedure to test all inverse-time overcurrent elements for each phase.

### Step 1. Purpose:

Determine the expected time delay for the overcurrent element.

#### Method:

- Execute the **SHO** command via the relay front panel or serial port and verify the time delay settings (i.e., **SHO 51P1P <Enter>**).

The delay settings will follow the pickup settings when they are displayed.

- Calculate the time delay to pickup (tp).

Inverse-time elements are calculated using three element settings and the operating time equations shown in [Section 4: Setting the Relay](#). TD is the time-dial setting (i.e., 51P1TD), and M is the applied multiple of pickup current.

For example, if 51P1P = 2.2 A, 51P1C = U3, and 51P1TD = 4.0, we can use the equation below to calculate the expected operating time for M = 3 (applied current equals M • 51P1P = 6.6 A):

$$tp = TD \cdot \left( 0.0963 + \frac{3.88}{M^2 - 1} \right)$$

$$tp = 2.33 \text{ seconds}$$

**Equation 8.1**

### Step 2. Purpose:

Set the Sequential Event Recorder to record the element timing.

#### Method:

- Use **SET R SER1 <Enter>** to set SER1 equal to the element pickup and time-out Relay Word bits (i.e., 51P1, 51P1T).
- When prompted, set SER2 and SER3 to NA.
- Save settings.

### Step 3. Purpose:

Connect and apply a single current test source at a level that is M times greater than the pickup (i.e., 2.2 • M = 6.6 A; M = 3 for this example).

#### Method:

- Connect a single current test source (i.e., source 1 to current input **IA**) as shown in [Figure 8.3](#).
- Turn on the single current test source for the phase under test at the desired level.

### Step 4. Purpose:

Verify the operation times.

#### Method:

- Type **SER <Enter>** to view the sequential event records.

The assertion and deassertion of each element listed in the SER 1, 2, and 3 settings is recorded.

- b. Subtract the time from the assertion of the pickup (i.e., 51P1) to the assertion of the time-delayed element (i.e., 51P1T).

**SER C** clears the Sequential Event Records.

**Step 5. Purpose:**

Repeat the test for each inverse-time overcurrent element.

**Method:**

- a. Repeat *Step 1–Step 4* for each time element listed in *Table 8.2* for each phase.
- b. Remember to set the SER for the appropriate elements and apply current to the appropriate phase.

The neutral ground overcurrent elements operate based on current applied to the separate **IN** input.

**NOTE:** If the electromechanical induction-disk reset emulation is enabled (i.e., 51PIRS = Y), the element under test may take some time to reset fully. If the element is not fully reset when you run a second test, the time to trip will be lower than expected. Usually this setting is set 51PIRS = N.

**Table 8.2 Inverse-Time Overcurrent Elements and Corresponding Settings/ Relay Word Bits/TAR Commands (Sheet 1 of 2)**

Element/Settings	Setting Names	Relay Word Bits	TAR
Phase Level 1		51P1	1
Pickup	51PIP	(picked up)	
Curve	51PIC		
Time-Dial	51P1TD	51P1T	1
Electromechanical Reset	51PIRS	(timed out)	
Phase Level 2		51P2	1
Pickup	51P2P		
Curve	51P2C		
Time-Dial	51P2TD	51P2T	1
Electromechanical Reset	51P2RS	(timed out)	
Neutral Ground		51N1	1
Pickup	51N1P	(picked up)	
Curve	51N1C		
Time-Dial	51N1TD	51N1T	1
Electromechanical Reset	51N1RS	(timed out)	
Residual Ground		51G1	1
Pickup	51G1P	(picked up)	
Curve	51G1C		
Time-Dial	51G1TD	51G1T	1
Electromechanical Reset	51G1RS	(timed out)	
Negative-Sequence Level 1		51Q1	2
Pickup	51Q1P	(picked up)	
Curve	51Q1C		
Time-Dial	51Q1TD	51Q1T	2
Electromechanical Reset	51Q1RS	(timed out)	

**Table 8.2 Inverse-Time Overcurrent Elements and Corresponding Settings/  
Relay Word Bits/TAR Commands (Sheet 2 of 2)**

Element/Settings	Setting Names	Relay Word Bits	TAR
Negative-Sequence Level 2		51Q2	2
Pickup	51Q2P	(picked up)	
Curve	51Q2C		
Time-Dial	51Q2TD	51Q2T	2
Electromechanical Reset	51Q2RS	(timed out)	

## Phase Overcurrent Elements

The SEL-551 has many phase overcurrent elements as shown in [Table 8.1](#) and [Table 8.2](#). Except for elements 50A, 50B, and 50C, they operate based on a comparison between the maximum phase current directly applied to the phase inputs and the phase overcurrent setting.

Test the instantaneous and inverse-time phase overcurrent elements by applying current to the inputs and comparing relay operation to the phase overcurrent settings. These tests were previously outlined in this section.

## Negative-Sequence Overcurrent Elements

The SEL-551 has four negative-sequence overcurrent elements as shown in [Table 8.1](#) and [Table 8.2](#). They all operate based on a comparison between a negative-sequence calculation of the three-phase inputs and the negative-sequence overcurrent setting. The negative-sequence calculation that is performed on the three-phase inputs is as follows (assuming ABC rotation):

$$3I_2 = A\text{-phase} + B\text{-phase (shifted by } -120^\circ) \\ + C\text{-phase (shifted by } 120^\circ) \quad \text{Equation 8.2}$$

This means that if balanced positive-sequence currents are applied to the relay, the relay reads  $3I_2 = 0$  (load conditions).

For testing purposes, apply a single-phase current to the relay and the negative-sequence overcurrent elements will operate. For example, assume one ampere on A-phase and zero on B- and C-phases:

$$3I_2 = 1 + 0 \text{ (shifted by } -120^\circ) \\ + 0 \text{ (shifted by } 120^\circ) \\ = 1 \text{ (simulated ground fault condition)} \quad \text{Equation 8.3}$$

Test the instantaneous and inverse-time negative-sequence overcurrent elements by applying current to the inputs and comparing relay operation to the negative-sequence overcurrent settings. These tests were previously outlined in this section.

## Neutral Ground Overcurrent Elements

The SEL-551 has four neutral ground overcurrent elements. They all operate based on a comparison between the separate neutral current input (IN) and the neutral ground overcurrent setting.

For testing purposes, apply a single-phase current to the separate neutral input and the neutral ground overcurrent elements will operate at the setting threshold.

Test the instantaneous and time-delayed neutral ground overcurrent elements by applying current to the inputs and comparing relay operation to the neutral ground overcurrent settings. These tests were previously outlined in this section.

## Residual Ground Overcurrent Elements

The SEL-551 has four residual ground overcurrent elements. They all operate based on a comparison between a residual calculation of the three-phase inputs and the residual ground overcurrent setting. The residual calculation that is performed on the three-phase inputs is as follows:

$$IG = A\text{-phase} + B\text{-phase} + C\text{-phase} \quad \text{Equation 8.4}$$

This means that if balanced positive-sequence currents are applied to the relay, the relay reads  $IG = 0$  (load conditions) because the currents cancel one another.

For testing purposes, apply a single-phase current to the relay and the residual overcurrent elements will operate. For example, assume one ampere on A-phase and zero on B- and C-phases:

$$\begin{aligned} IG &= 1 + 0 + 0 \\ &= 1 \text{ (simulated ground fault condition)} \end{aligned} \quad \text{Equation 8.5}$$

Test the instantaneous and time-delayed residual overcurrent elements by applying current to the inputs and comparing relay operation to the residual overcurrent settings. These tests were previously outlined in this section.

## Commissioning Testing

---

When: When installing a new protection system.

Goals:

- Ensure that all system ac and dc connections are correct.
- Ensure that the relay functions as intended using your settings.
- Ensure that all auxiliary equipment operates as intended.

What to test:

- all connected or monitored inputs and outputs
- polarity and phase rotation of ac current connections
- simple check of protection elements

SEL performs a complete functional check and calibration of each relay before it is shipped. This helps ensure that you receive a relay that operates correctly and accurately. Commissioning tests should:

1. Verify that the relay is properly connected to the power system and all auxiliary equipment.
2. Verify control signal inputs and outputs.
3. Check breaker auxiliary inputs, SCADA control inputs, and monitoring outputs.
4. Use an ac connection check to verify that the relay current inputs are of the proper magnitude and phase rotation.

Brief fault tests ensure that the relay settings are correct. It is not necessary to test every relay element, timer, and function in these tests.

At commissioning time, use the relay **METER** command to record load currents.

# Maintenance Testing

---

When: At regularly scheduled intervals, or when there is an indication of a problem with the relay or system.

Goals:

- Ensure that the relay is measuring ac quantities accurately.
- Ensure that scheme logic and protection elements are functioning correctly.
- Ensure that auxiliary equipment is functioning correctly.

What to test: Anything not shown to have operated during an actual fault within the past maintenance interval.

SEL relays use extensive self-testing capabilities and feature detailed metering and event reporting functions that lower the utility dependence on routine maintenance testing.

Use the SEL relay reporting functions as maintenance tools.

1. Periodically verify that the relay is making correct and accurate current measurements by comparing the relay METER output to other meter readings on that line.
2. Review relay event reports in detail after each fault.
  - a. Using the event report current and relay element data, you can determine that the relay protection elements are operating properly.
  - b. Using the event report input and output data, you can determine that the relay is asserting outputs at the correct instants and that auxiliary equipment is operating properly.

At the end of your maintenance interval, the only items that need testing are those that have not operated during the maintenance interval.

The basis of this testing philosophy is simple: If the relay is correctly set and connected, is measuring properly, and no self-test has failed, there is no reason to test it further.

Each time a fault occurs, the protection system is tested. Use event report data to determine areas requiring attention. Slow breaker auxiliary contact operations and increasing or varying breaker operating time can be detected through detailed analysis of relay event reports.

Because SEL relays are microprocessor-based, their operating characteristics do not change over time. Time-overcurrent element operating times are affected only by the relay settings and applied signals. It is not necessary to verify operating characteristics as part of maintenance checks.

At SEL, we recommend that maintenance tests on SEL relays be limited under the guidelines provided above. The time saved may be spent analyzing event data and thoroughly testing those systems that require more attention.

# Relay Self-Tests

The relay runs a variety of self-tests. The relay takes the following corrective actions for out-of-tolerance conditions (see [Table 8.3](#)):

- Protection Disabled: The relay disables overcurrent elements and trip/close logic. All output contacts are de-energized. The EN front-panel LED is extinguished.
- ALARM Output: The ALARM output contact signals an alarm condition by going to its de-energized state. If the ALARM output contact is a b-type output contact (normally closed), it closes for an alarm condition or if the relay is de-energized. If the ALARM output contact is an a-type output contact (normally open), it opens for an alarm condition or if the relay is de-energized. Alarm condition signaling can be five-second pulses (Pulsed) or permanent (Latched).
- The relay generates automatic STATUS reports at the serial port for warnings and failures.
- The relay displays failure messages on the relay LCD display for failures.

Use the serial port **STATUS** command or front-panel {STATUS} pushbutton to view relay self-test status.

**Table 8.3 Relay Self Tests (Sheet 1 of 2)**

Self-Test	Condition	Limits	Protection Disabled	ALARM	Description
IA,IB,IC,IN Offset	Warning	30 mV	No	Pulsed	Measures the dc offset at each of the current input channels every 0.2 seconds.
Master Offset	Warning	20 mV	No	Pulsed	Measures the dc offset at the A/D every 0.2 seconds.
	Failure	30 mV	Yes	Latched	
+5V PS	Warning	+4.75 V +5.25 V	No	Pulsed	Measures the +5 volt power supply every 0.2 seconds.
	Failure	+4.70 V +5.50 V	Yes	Latched	
±5V REG	Warning	±4.65 V ±5.35 V	No	Pulsed	Measures the regulated 5 volt power supply every 0.2 seconds.
	Failure	±4.50 V ±5.50 V	Yes	Latched	
±10V PS	Warning	±9.00 V ±11.00 V	No	Pulsed	Measures the 10 volt power supply every 0.2 seconds.
	Failure	±8.00 V ±12.00 V	Yes	Latched	
VBAT	Warning	+2.25 V +5.00 V	No	Pulsed	Measures the Real Time clock battery every 0.2 seconds.
	Failure	+2.10 V +6.00 V	No	Pulsed	
TEMP	Warning	-40° C +85° C	No		Measures the temperature at the A/D voltage reference every 0.2 seconds.
	Failure	-50° C +100° C	Yes	Latched	

**Table 8.3 Relay Self Tests (Sheet 2 of 2)**

Self-Test	Condition	Limits	Protection Disabled	ALARM	Description
RAM	Failure		Yes	Latched	Performs a read/write test on system RAM every 60 seconds.
ROM	Failure	checksum	Yes	Latched	Performs a checksum test on the relay program memory every 0.2 seconds.
CR_RAM	Failure	checksum	Yes	Latched	Performs a checksum test on the active copy of the relay settings every 0.2 seconds.
EEPROM	Failure	checksum	Yes	Latched	Performs a checksum test on the nonvolatile copy of the relay settings every 0.2 seconds.
<b>The following self-tests are performed by dedicated circuitry in the microprocessor and the SEL-551 main board. Failures in these tests shut down the microprocessor and are not shown in the STATUS report.</b>					
Microprocessor Crystal	Failure		Yes	Latched	The relay monitors the microprocessor crystal. If the crystal fails, the relay displays <b>CLOCK STOPPED</b> on the LCD display. The test runs continuously.
Microprocessor	Failure		Yes	Latched	The microprocessor examines each program instruction, memory access, and interrupt. The relay displays <b>VECTOR nn</b> on the LCD upon detection of an invalid instruction, memory access, or spurious interrupt. The test runs continuously.
+5V PS Under/Over Voltage	Failure	+4.65 V +5.95 V	Yes	Latched	A circuit on the SEL-551 main board monitors the +5 V power supply. Upon detection of a failure, the circuit forces the microprocessor to reset.

## Relay Troubleshooting

### Inspection Procedure

Complete the following procedure before disturbing the relay. After you finish the inspection, proceed to the [Troubleshooting Procedure](#).

- Step 1. Measure and record the power supply voltage at the power input terminals.
- Step 2. Check to see that the power is on. Do not turn the relay off.
- Step 3. Measure and record the voltage at all control inputs.
- Step 4. Measure and record the state of all output relays.

### Troubleshooting Procedure

**Table 8.4 Troubleshooting Procedures (Sheet 1 of 2)**

Symptom/Possible Cause	Diagnosis/Solution
All Front-Panel LEDs Dark	Input power not present or fuse is blown. Self-test failure.
Cannot See Characters on Relay LCD Screen	
Relay is de-energized.	Check to see if the <b>ALARM</b> output contact is closed.

**Table 8.4 Troubleshooting Procedures (Sheet 2 of 2)**

Symptom/Possible Cause	Diagnosis/Solution
LCD contrast is out of adjustment.	Use the steps below to adjust the contrast. <ol style="list-style-type: none"> <li>1. Remove the relay front panel by removing the three front-panel screws.</li> <li>2. Press any front-panel button. The relay should turn on the LCD back lighting.</li> <li>3. Locate the contrast adjust potentiometer directly adjacent to the EN LED.</li> <li>4. Use a small screwdriver to adjust the potentiometer.</li> <li>5. Replace the relay front panel.</li> </ol>
<b>Relay Does Not Respond to Commands From Device Connected to Serial Port</b>	
Communications device is not connected to the relay.	Connect a communications device.  Relay or communications device at incorrect baud rate or other communication parameter incompatibility, including cabling error.
Relay serial port has received an XOFF, halting communications.	Type <Ctrl+Q> to send relay an XON and restart communications.
<b>Relay Does Not Respond to Faults</b>	
Relay is set improperly.	Review the relay settings. See <a href="#">Section 4: Setting the Relay</a> .
Improper test settings.	Restore operating settings.
CT connection wiring error.	Confirm CT wiring.
The analog input cable between the transformer secondary and the main board is loose or defective.	Reseat both ends of the analog input cable, observing proper ESD precautions.
Failed relay self-test.	

## Relay Calibration

---

The SEL-551 is factory-calibrated. If you suspect that the relay is out of calibration, please contact the factory.

## Factory Assistance

---

We appreciate your interest in SEL products and services. If you have any questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.  
 2350 NE Hopkins Court  
 Pullman, WA 99163-5603 USA  
 Phone: +1.509.332.1890  
 Fax: +1.509.332.7990  
 Internet: [www.selinc.com](http://www.selinc.com)  
 E-mail: [info@selinc.com](mailto:info@selinc.com)

# Appendix A

## Firmware and Manual Versions

### Firmware

#### Determining the Firmware Version in Your Relay

To find the firmware revision number in your relay, view the status report using the serial port **STATUS** command or the front-panel {**STATUS**} pushbutton. For firmware versions prior to February 11, 2000, the status report displays the Firmware Identification (FID) label:

FID=SEL-551-Rxxx-Vx-Dxxxxxx

For firmware versions with the date code of February 11, 2000, or later, the FID label will appear as follows with the Part/Revision number in bold:

FID=SEL **551-Rxxx-Vx-Z001001-Dxxxxxxx**

The firmware revision number is after the “R” and the release date is after the “D.” The single “x” after the “V” will be an “r” if the firmware is stored in EPROM, and it will be an “f” if the firmware is stored in FLASH.

For example:

FID=SEL-551-**R506-Vf-Z001001-D20000211**

is firmware revision number 506, stored in FLASH, release date February 11, 2000.

[Table A.1](#) lists the firmware versions, a description of modifications, and the instruction manual date code that corresponds to firmware versions. The most recent firmware version is listed first.

**Table A.1 Firmware Revision History (Sheet 1 of 3)**

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-551-R514-Vf-Z002002-D20110408	➤ Modified front-panel targeting logic to improve operation for evolving faults, allow overcurrent elements to generate targets only when in the TR equation, and add 50Q1 and 50Q2 to the list of elements that initiate targeting.	20110408
SEL-551-R513-Vf-Z002002-D20080104	➤ Manual update only (see <a href="#">Table A.2</a> ).	20100630
SEL-551-R513-Vf-Z002002-D20080104	➤ Reduced Modbus exception code 6 responses.	20080104
SEL-551-R512-Vf-Z002002-D20070301	➤ Manual update only (see <a href="#">Table A.2</a> ).	20071025
SEL-551-R512-Vf-Z002002-D20070301	➤ Manual update only (see <a href="#">Table A.2</a> ).	20070709
SEL-551-R512-Vf-Z002002-D20070301	<ul style="list-style-type: none"> <li>➤ Fixed potential conflict between simultaneous Fast Operate requests through Port 1 and the front panel.</li> <li>➤ Repaired Compressed Event report format to restore SEL-5601 compatibility.</li> </ul>	20070301

**Table A.1 Firmware Revision History (Sheet 2 of 3)**

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-551-R111-Vr-Z001001-D20061005 SEL-551-R511-Vf-Z002002-D20061005	<ul style="list-style-type: none"> <li>➤ Modified front-panel phase targeting to target on other 50/51 fault elements.</li> <li>➤ Fixed the demand ammeter calculation during the transition of daylight savings when connected to a timesource.</li> <li>➤ Added relay settings to the end of the compressed event reports.</li> </ul>	20061005
SEL-551-R110-Vr-Z001001-D20050523 SEL-551-R510-Vf-Z002002-D20050523	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	20050725
SEL-551-R110-Vr-Z001001-D20050523 SEL-551-R510-Vf-Z002002-D20050523	<ul style="list-style-type: none"> <li>➤ Fixed Modbus® communications issue when polled by certain Modbus master devices.</li> </ul>	20050523
SEL-551-R509-Vf-Z002002-D20050124	<ul style="list-style-type: none"> <li>➤ Password security enhancement.</li> <li>➤ Rising-edge and falling-edge detect operators in SELOGIC® control equations.</li> <li>➤ Torque control setting equations for overcurrent elements can no longer be set directly to logical 0.</li> <li>➤ Relay Word bit TRGTR (Target Reset output).</li> <li>➤ <b>VER</b> serial port command.</li> </ul>	20050124
SEL-551-R109-Vr-Z001001-D20030905 SEL-551-R508-Vf-Z001001-D20030905	<ul style="list-style-type: none"> <li>➤ CT Saturation Protection was enhanced to improve security with low-set instantaneous values.</li> </ul>	20030905
SEL-551-R108-Vr-Z001001-D20020828 SEL-551-R507-Vf-Z001001-D20020828	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	20021025
SEL-551-R108-Vr-Z001001-D20020828 SEL-551-R507-Vf-Z001001-D20020828	<ul style="list-style-type: none"> <li>➤ Added CT Saturation Protection</li> <li>➤ Added Raw Event Report</li> <li>➤ Made internal changes to support battery-backed clock hardware change.</li> </ul>	20020828
SEL-551-R107-Vr-Z001001-D20000211 SEL-551-R506-Vf-Z001001-D20000211	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	20010518
SEL-551-R107-Vr-Z001001-D20000211 SEL-551-R506-Vf-Z001001-D20000211	<ul style="list-style-type: none"> <li>➤ Added Modbus® RTU protocol.</li> <li>➤ Added instantaneous element front-panel targeting of <b>INST</b>, <b>A</b>, <b>B</b>, <b>C</b>, and <b>N</b> LEDs.</li> <li>➤ Changed FID format.</li> </ul>	20000211
SEL-551-R106-Vr-D991116 SEL-551-R505-Vf-D991112	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	991117
SEL-551-R106-Vr-D991116 SEL-551-R505-Vf-D991112	<ul style="list-style-type: none"> <li>➤ Improved Fast Operate compatibility.</li> </ul>	991112
SEL-551-R105-Vr-D970616 SEL-551-R504-Vf-D970616	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	981201
SEL-551-R105-Vr-D970616 SEL-551-R504-Vf-D970616	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	981027
SEL-551-R105-Vr-D970616 SEL-551-R504-Vf-D970616	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	980831
SEL-551-R105-Vr-D970616 SEL-551-R504-Vf-D970616	<ul style="list-style-type: none"> <li>➤ Manual update only (see <a href="#">Table A.2</a>).</li> </ul>	970717
SEL-551-R105-Vr-D970616 SEL-551-R504-Vf-D970616	<p><b>Added Demand Ammetering:</b> See <i>Demand Ammetering</i> toward end of <i>Section 3: Relay Elements and Logic</i>.</p> <ul style="list-style-type: none"> <li>➤ Added settings DMTC, PDEMP, NDEMP, GDEMP, QDEMP (see <i>Settings Sheet</i> page 3, <i>Section 4: Setting the Relay</i>).</li> <li>➤ Added Relay Word bits PDEM, NDEM, GDEM, QDEM (see <i>Table 4.3</i> and <i>Table 5.5</i>).</li> </ul>	970616

**Table A.1 Firmware Revision History (Sheet 3 of 3)**

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	<ul style="list-style-type: none"> <li>➤ Added serial port and front-panel commands to access demand ammeter data [see <i>MET D Command (Demand Ammeter)</i> in <i>Section 5: Serial Port Communications and Commands</i>].</li> <li>➤ Added Fast Meter messages A5C2, A5D2, A5C3, A5D3 for demand ammeter data.</li> <li>➤ Increased the number of digital banks in the A5C1 message. Added demand ammeter Relay Word bits to the Compressed ASCII DNA command (see <i>Appendix C: Configuration, Fast Meter, and Fast Operate Commands</i>).</li> </ul> <p><b>Modified Recloser Logic:</b> Relay goes to the Lockout State for Open Command execution [see <i>OPE Command (Open)</i> in <i>Section 5: Serial Port Communications and Commands</i>].</p>	
SEL-551-R503-Vf-D961211	➤ Decreased power-up initialization time.	a
SEL-551-R502-Vf-D961012	➤ Removed quotation marks from ID message Modbus ID field (see <i>Appendix C</i> ).	a
SEL-551-R104-Vr-D960528 SEL-551-R501-Vf-D960528	<ul style="list-style-type: none"> <li>➤ Simplified operation of front panel functions under the {CNTRL} pushbutton.</li> <li>➤ Removed password requirement for local control switches.</li> </ul>	a
SEL-551-R103-Vr-D960322	Corrected use of the “^” character in the SET command.	a
SEL-551-R101-Vr-D960322	Initial version.	a

<sup>a</sup> Information about changes to earlier versions of the SEL-551 Instruction Manual is not available.

# Instruction Manual

The date code at the bottom of each page of this manual reflects the creation or revision date.

[Table A.2](#) lists the instruction manual release dates and a description of modifications. The most recent instruction manual revisions are listed at the top.

**Table A.2 Instruction Manual Revision History (Sheet 1 of 8)**

Revision Date	Summary of Revisions
20110408	<p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Corrected <i>Figure 3.14: Close Logic</i>.</li> <li>➤ Added additional requirements to logic used to illuminate A, B, C, and N target LEDs in <i>Front-Panel Target LEDs</i>.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R514.</li> </ul>
20100630	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Updated timing accuracy information in <i>Overcurrent Elements</i>.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 2 of 8)**

Revision Date	Summary of Revisions
20080104	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Removed <i>Figure 1.1: SEL-551 Front Panel</i>.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>▶ Corrected JMP12 to be JMP14.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>▶ Corrected table number references for Relay Word bits and their descriptions to <i>Table 4.5: SEL-551 Relay Word Bits</i> and <i>Table 4.6: Relay Word Bit Definitions</i>.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>▶ Corrected table number references for Relay Word bits and their descriptions to <i>Table 4.5: SEL-551 Relay Word Bits</i> and <i>Table 4.6: Relay Word Bit Definitions</i>.</li> <li>▶ Added Row 0 note for <i>Table 4.5: SEL-551 Relay Word Bits</i>.</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>▶ Corrected table number references for Relay Word bits and their descriptions to <i>Table 4.5: SEL-551 Relay Word Bits</i> and <i>Table 4.6: Relay Word Bit Definitions</i>.</li> </ul> <p><b>Section 6</b></p> <ul style="list-style-type: none"> <li>▶ Corrected table number references for Relay Word bits and their descriptions to <i>Table 4.5: SEL-551 Relay Word Bits</i> and <i>Table 4.6: Relay Word Bit Definitions</i>.</li> </ul> <p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>▶ Corrected table number references for Relay Word bits and their descriptions to <i>Table 4.5: SEL-551 Relay Word Bits</i> and <i>Table 4.6: Relay Word Bit Definitions</i>.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>▶ Updated for firmware version R513.</li> </ul>
20071025	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Added the 110 Vdc option to Optoisolated Inputs information in <i>Specifications</i>.</li> </ul>
20070709	<p>Overall, manual updated for splitting the SEL-551 manual from the SEL-551C manual. This manual now is for the SEL-551. A separate manual has been created for the SEL-551C relays.</p> <p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Listed major differences for the SEL-551C, compared to the SEL-551 updated.</li> <li>▶ Removed SEL-551C front-panel drawing and hardware overview.</li> <li>▶ Removed certain specifications in General Specifications noted for the SEL-551C.</li> <li>▶ Updated 5 A nominal current input specification to include accuracy range.</li> <li>▶ Removed UL/CSA temperature rating (SEL-551C only).</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>▶ Removed SEL-551C rear-panel drawing and detailed hardware differences such as the SEL-551C having only conventional terminal blocks.</li> <li>▶ Removed EN-61010-1 and the <i>SEL-551C</i> subsection concerning SEL-551C compliance with EN (European Norm) 61010-1 requirements.</li> <li>▶ Added information noting that level sensitive inputs are not jumper selectable.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>▶ Removed SEL-551C relay digital I/O information to the <i>Optoisolated Inputs and Output Contacts</i> subsection.</li> <li>▶ Remove the explanation on the programmable alarm output contact feature in the SEL-551C.</li> <li>▶ Removed the <i>Latch Control Switch</i> subsection for latch bits LT1–LT8 (SEL-551C only).</li> <li>▶ Added information to Lockout State 'A new reclose initiation occurs while the reclosing relay is timing on an open interval'.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 3 of 8)**

Revision Date	Summary of Revisions
	<p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>➤ Removed the separate Relay Word bit table for the SEL-551C, showing Relay Word bits IN1–IN6 and OUT1–OUT3 for the new digital I/O mix and latch bit outputs LT1–LT8.</li> <li>➤ Removed programmable software and hardware alarm Relay Word bits SALARM and HALARM, respectively, for the SEL-551C.</li> <li>➤ Removed additional set and reset SELOGIC settings to the Setting Sheets for latch bits LT1–LT8 (SEL-551C only).</li> <li>➤ Removed additional settings to the Setting Sheets for the optional front-panel EIA-232 serial communications port for the SEL-551C.</li> <li>➤ Added example for a CT ration of 600/5, set CTR = 120.</li> <li>➤ Added 0.1 increment information to <i>Overcurrent Elements</i>.</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>➤ Removed details concerning the optional front-panel EIA-232 serial communications port for the SEL-551C.</li> <li>➤ Removed explanation on the factory settings listed in <b>SHO</b> Command (Showset) that differ for the new SEL-551C, compared to the SEL-551.</li> <li>➤ Under <b>TAR</b> Command (Target), removed separate Relay Word bit table for the SEL-551C, showing Relay Word bits IN1–IN6 and OUT1–OUT3 for the new digital I/O mix and latch bit outputs LT1–LT8.</li> <li>➤ Removed programmable software and hardware alarm Relay Word bits SALARM and HALARM, respectively, for the SEL-551C.</li> <li>➤ Added TAR14 row to Table 5.6.</li> </ul> <p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>➤ Removed the rearrangement of digital I/O columns in the event report for the new SEL-551C.</li> <li>➤ Removed the number of rows available in the SER for the SEL-551C relay.</li> </ul> <p><b>Section 8</b></p> <ul style="list-style-type: none"> <li>➤ In <i>Relay Self-Tests</i>, removed the programmable alarm output contact feature in the SEL-551C.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated <i>Instruction Manual Revision History</i> to note the splitting of the SEL-551 and the SEL-551C instruction manual.</li> </ul> <p><b>Appendix B</b></p> <ul style="list-style-type: none"> <li>➤ Added Firmware upgrade information to SEL-551R108/ SEL-551-R507 to include note 'Made internal changes to support battery-backed clock hardware change'.</li> </ul> <p><b>Appendix D</b></p> <ul style="list-style-type: none"> <li>➤ Removed DNA message for the SEL-551C.</li> </ul>
20070301	<p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R512 for the SEL-551.</li> <li>➤ Updated for firmware version R503 for the SEL-551C.</li> </ul>
20061005	<p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Added additional phase pickup settings to the lists of phase pickup settings which cause the A, B, and C target LEDs to illuminate in the <i>Front-Panel Target LEDs</i> subsection.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R111 and R511 for the SEL-551.</li> <li>➤ Updated for firmware version R502 for the SEL-551C.</li> </ul>
20050725	<p><b>Entire Manual</b></p> <ul style="list-style-type: none"> <li>➤ Updated format of instruction manual.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Updated rear-panel drawing (<i>Figure 2.8</i>).</li> <li>➤ Updated Output Contact OUT4 Control Jumper Location drawing (<i>Figure 2.12</i>).</li> <li>➤ Updated <i>Table 2.2: Required Position of Jumper JMP13 for Desired Output Contact OUT4 Operation</i>.</li> </ul> <p><b>Section 8</b></p> <ul style="list-style-type: none"> <li>➤ Updated <i>Figure 8.2: Relay Part Number and Hardware Identification Sticker</i>.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 4 of 8)**

Revision Date	Summary of Revisions
	<p><b>Appendix B</b></p> <ul style="list-style-type: none"> <li>➤ Added a step about disconnecting the rear serial port connection to the <i>Firmware Upgrade Instructions</i>.</li> </ul>
20050608	<p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R501.</li> </ul>
20050523	<p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R110/R510.</li> </ul>
20050120	<p>Overall, manual updated for new relay model SEL-551C. The manual now is a combined, dual manual for both the SEL-551 and the SEL-551C relays.</p> <p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Listed major differences for the new SEL-551C, compared to the SEL-551.</li> <li>➤ Inserted SEL-551C front-panel drawing and hardware overview.</li> <li>➤ Certain specifications in General Specifications updated and noted for the new SEL-551C.</li> <li>➤ Updated 5 A nominal current input specification.</li> <li>➤ Changed power supply (125/250 Vdc or Vac) burden value to &lt;6.2 W.</li> <li>➤ Added UL/CSA temperature rating (SEL-551C only).</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Inserted SEL-551C rear-panel drawing and detailed hardware differences such as the SEL-551C having only conventional terminal blocks.</li> <li>➤ Reference made to Cable C675, an adapter that brings out EIA-485 pins to a terminal block.</li> <li>➤ Added EN-61010-1 and the SEL-551C subsection concerning SEL-551C compliance with EN (European Norm) 61010-1 requirements.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Added rising-edge and falling-edge detects as SELOGIC operators.</li> <li>➤ Clarified the respective limits of Relay Word bits that can be used in the SELOGIC settings of each relay.</li> <li>➤ Added SEL-551C relay digital I/O information to the <i>Optoisolated Inputs and Output Contacts</i> subsection.</li> <li>➤ Explained the programmable alarm output contact feature in the SEL-551C.</li> <li>➤ Torque control setting equations for overcurrent elements can no longer be set directly to logical 0.</li> <li>➤ Added Relay Word bit TRGTR (Target Reset output) application example to the <i>Front-Panel Target LEDs</i> subsection.</li> <li>➤ Added the <i>Latch Control Switch</i> subsection for latch bits LT1–LT8 (SEL-551C only).</li> <li>➤ Added a Relay Word bit TRGTR (Target Reset output) application example to the <i>Front-Panel Target LEDs</i> subsection.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>➤ Created separate Relay Word bit table for the SEL-551C, showing Relay Word bits IN1–IN6 and OUT1–OUT3 for the new digital I/O mix and latch bit outputs LT1–LT8.</li> <li>➤ Added programmable software and hardware alarm Relay Word bits SALARM and HALARM, respectively, for the SEL-551C.</li> <li>➤ Added Relay Word bit TRGTR (Target Reset output).</li> <li>➤ In <i>Setting Sheets</i>, torque control settings equation for overcurrent elements can no longer be set directly to logical 0.</li> <li>➤ Added additional set and rest SELOGIC settings to the Setting Sheets for latch bits LT1–LT8 (SEL-551C only).</li> <li>➤ Added note in the Setting Sheets clarifying SER setting range for the SEL-551.</li> <li>➤ Added additional settings to the Setting Sheets for the optional front-panel EIA-232 serial communications port for the SEL-551C.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 5 of 8)**

Revision Date	Summary of Revisions
	<p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>➤ Added details concerning the optional front-panel EIA-232 serial communications port for the SEL-551C.</li> <li>➤ Added explanation on the factory settings listed in SHO Command (Showset) that differ for the new SEL-551C, compared to the SEL-551.</li> <li>➤ Under TAR Command (Target), created separate Relay Word bit table for the SEL-551C, showing Relay Word bits IN1–IN6 and OUT1–OUT3 for the new digital I/O mix and latch bit outputs LT1–LT8.</li> <li>➤ Added programmable software and hardware alarm Relay Word bits SALARM and HALARM, respectively, for the SEL-551C.</li> <li>➤ Added Relay Word bit TRGTR (Target Reset output).</li> <li>➤ Under PAS Command (Password), added password security enhancement explanation.</li> <li>➤ Added VER Command.</li> </ul> <p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>➤ Explained the rearrangement of digital I/O columns in the event report for the new SEL-551C.</li> <li>➤ Clarified the number of rows available in the SER for each relay.</li> </ul> <p><b>Section 8</b></p> <ul style="list-style-type: none"> <li>➤ In <i>Relay Self-Tests</i>, explained the programmable alarm output contact feature in the SEL-551C.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R509 for the SEL-551 and firmware version R500 for the new SEL-551C.</li> </ul> <p><b>Appendix D</b></p> <ul style="list-style-type: none"> <li>➤ Added new DNA message for the new SEL-551C. Changed DNA message for SEL-551.</li> <li>➤ Expanded ID message explanation.</li> </ul> <p><b>Appendix E</b></p> <ul style="list-style-type: none"> <li>➤ Added Compressed ASCII command responses for the SEL-551C.</li> </ul> <p><b>Appendix G</b></p> <ul style="list-style-type: none"> <li>➤ Added new Modbus updates for the new SEL-551C, primarily because of the new digital I/O mix and target LED rearrangement.</li> </ul>
20030905	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Modified text in <i>CT Saturation Protection</i>.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Modified text in <i>Phase Instantaneous Overcurrent Elements</i>.</li> </ul> <p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>➤ Modified text in <i>Standard Event Report Summary</i>.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R109 and R508.</li> </ul>
20021025	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Modified <i>Optoisolated Input Ratings</i> information in <i>General Specifications</i>.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Modified text in <i>Control Voltage Jumpers (Conventional Terminal Blocks Option Only)</i>.</li> </ul>
20020828	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Updated the <i>Tightening Torque</i> information.</li> <li>➤ Added information on <i>CT Saturation Protection</i>.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Updated the relay figures.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>➤ Added CT sizing information.</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>➤ Updated the <i>Command Summary</i>.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 6 of 8)**

Revision Date	Summary of Revisions
	<p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>➤ Updated <i>Standard Event Report Summary</i> to include CT Saturation Protection information.</li> <li>➤ Updated the example on the Event Summary Report.</li> <li>➤ Added Raw Event Report Commands.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R108 and R507.</li> </ul>
20010518	<p><b>Title Page</b></p> <ul style="list-style-type: none"> <li>➤ Added Caution, Danger, and Warning information to the back of the cover page of the Manual.</li> <li>➤ Replaced Standard Product Warranty page with warranty statement on cover page.</li> <li>➤ updated password information.</li> </ul> <p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Added <i>Tightening Torque</i> information to <i>General Specifications</i>.</li> <li>➤ Updated Power Supply specification.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Updated <i>Figure 2.7: SEL-551 Relay Rear Panel (Plug-In Connectors Option)</i>.</li> <li>➤ Added caution note to the <i>Clock Battery</i> subsection.</li> </ul> <p><b>Appendix G</b></p> <ul style="list-style-type: none"> <li>➤ Added clarification to Command Code 10 in <i>Table G.16: Modbus Command Codes</i>.</li> </ul>
20000211	<p>Reissued all pages with new date code with four-digit year (e.g., 20000211).</p> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Added <i>High-Current Interrupting Output Contacts</i> discussion.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Updated target logic operation.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>➤ Updated serial port <i>Setting Sheets</i>.</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>➤ Added <i>Table 5.2: Serial Port Protocols</i>. Incremented all subsequent table numbers and cross references.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R506 and R107.</li> </ul> <p><b>Appendix G</b></p> <ul style="list-style-type: none"> <li>➤ Added: <i>Appendix G: Modbus® RTU Communications Protocol</i>.</li> </ul>
991117	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>➤ Made minor corrections to <i>General Specifications</i>.</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>➤ Added <i>Figure 2.3</i>.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>➤ Reissued due to cross-reference changes.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>➤ Reissued due to cross-reference changes.</li> </ul> <p><b>Section 7</b></p> <ul style="list-style-type: none"> <li>➤ Reissued due to cross-reference changes.</li> </ul> <p><b>Appendix B</b></p> <ul style="list-style-type: none"> <li>➤ Added new <i>Appendix B: Firmware Upgrade Instructions</i> and relettered appendices following Appendix B.</li> </ul>
991112	<p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>➤ Updated for firmware version R505 and R106.</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 7 of 8)**

Revision Date	Summary of Revisions
981201	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Corrected typographical error on page 1–5 in (no date code change).</li> </ul> <p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>▶ Updated Figure 2.6.</li> <li>▶ Replaced missing <i>Figure 2.8</i> on page 2-7.</li> </ul> <p><b>Section 4</b></p> <ul style="list-style-type: none"> <li>▶ Corrected headings on <i>Settings Sheets</i>.</li> </ul> <p><b>Section 8</b></p> <ul style="list-style-type: none"> <li>▶ Due to printer error, the <i>Relay Self-Tests</i> subsection was reinserted.</li> <li>▶ Updated <i>Figure 8.3</i> and <i>Figure 8.4</i>.</li> <li>▶ Deleted <i>Figure 8.5</i>.</li> </ul>
981027	<p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>▶ Added new Connectorized model 05510W (plug-in connectors) explanation (following <i>Figure 2.6</i>).</li> </ul> <p><b>Section 8</b></p> <ul style="list-style-type: none"> <li>▶ Updated <i>Figure 8.1</i> and <i>Figure 8.2</i>.</li> </ul>
980831	<p><b>Section 2</b></p> <ul style="list-style-type: none"> <li>▶ Replaced <i>Figure 2.1</i> and <i>Figure 2.2</i> on pages 2-1 and 2-2 with updated drawings to provide more accurate dimensions and changed figure captions.</li> <li>▶ Clarified figure caption and replaced <i>Figure 2.4</i> on page 2-3 with updated drawing.</li> </ul>
970717	<p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Added 24 V breaking capacity and cyclic capacity specifications to <i>Output Contacts</i> (page 1-5).</li> <li>▶ Added a note to Level Sensitive input ratings and added 24 V power supply specifications to <i>Power Supply Ratings</i> (page 1–6).</li> <li>▶ Added power supply voltage input polarity sensitive warning to <i>Power Supply Ratings</i> (page 1–6).</li> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul> <p><b>Section 4, Settings Sheets</b></p> <ul style="list-style-type: none"> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul> <p><b>Section 6</b></p> <ul style="list-style-type: none"> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul> <p><b>Appendix A</b></p> <ul style="list-style-type: none"> <li>▶ Changed all Demand Meter references to Demand Ammeter.</li> </ul>
970616	<p>Reissued entire manual. Significant changes are listed below.</p> <p><b>Section 1</b></p> <ul style="list-style-type: none"> <li>▶ Removed subsection <i>Output Contact Operating Times</i> (output contact pickup/dropout information found in <i>General Specifications</i> in the same section).</li> <li>▶ Updated specifications in <i>AC Input Currents</i>, <i>Output Contacts</i>, <i>Optoisolated Input Ratings</i>, and <i>Routine Dielectric Test</i>.</li> <li>▶ Added IEC 255-21-2, IEC 255-22-2, IEC 255-22-3, IEC 255-22-4, and IEC 255-11.</li> <li>▶ Added document dates to type tests and standards.</li> </ul> <p><b>Section 3</b></p> <ul style="list-style-type: none"> <li>▶ Added <i>Demand Ammetering</i>.</li> <li>▶ Removed first settings example for settings 79RI and 79RIS [see <i>Reclose Initiate and Reclose Initiate Supervision Settings (79RI and 79RIS, Respectively)</i>].</li> <li>▶ Replaced second settings example for setting 79SEQ [see <i>Sequence Coordination (79SEQ)</i>].</li> </ul>

**Table A.2 Instruction Manual Revision History (Sheet 8 of 8)**

Revision Date	Summary of Revisions
	<p><b>Section 4, Settings Sheets</b></p> <ul style="list-style-type: none"> <li>➤ Added settings DMTC, PDEMP, NDEMP, GDEMP, QDEMP to Sheet 3 of 9.</li> <li>➤ Added Relay Word bits PDEM, NDEM, GDEM, QDEM (see Table 4.3 and Table 5.5).</li> </ul> <p><b>Section 5</b></p> <ul style="list-style-type: none"> <li>➤ Added serial port and front-panel commands to access demand meter data [see <i>MET D Command (Demand Meter)</i>].</li> <li>➤ Modified Recloser Logic. Relay goes to the Lockout State for Open Command execution [see <i>OPE Command (Open)</i>].</li> </ul> <p><b>Appendix C</b></p> <ul style="list-style-type: none"> <li>➤ Added fast meter messages A5C2, A5D2, A5C3, A5D3 for demand meter data.</li> <li>➤ Increased the number of digital banks in the A5C1 message.</li> <li>➤ Added demand meter Relay Word bits to the Compressed ASCII <b>DNA</b> command.</li> </ul>

Information about changes to earlier versions of the SEL-551 Instruction Manual is not available.

# Appendix B

## Firmware Upgrade Instructions

---

The SEL-551 Relay includes two firmware configurations:

- EPROM
- Flash

---

### IMPORTANT NOTE

**REGARDING SETTINGS:** The firmware Upgrade Procedure may result in lost relay settings due to the addition of new features and changes in the way memory is used. It is imperative to have a copy of the original relay settings available in case they need to be re-entered. Carefully following these upgrade instructions will minimize the chance of inadvertently losing relay settings.

Upgrade EPROM firmware by replacing an integrated circuit (IC) component on the SEL-551 main board. Upgrade Flash firmware by downloading the firmware from a personal computer to the relay serial port. SEL ships EPROM firmware upgrades in an IC and Flash upgrades on a diskette.

EPROM and Flash firmware may not be interchanged on a relay. To determine the type of firmware in your relay, display the firmware version by pressing the relay front-panel {STATUS} pushbutton. The relay displays the FID firmware version string.

SEL-551 R100-series firmware versions are EPROM versions:

FID=SEL-551-R1xx-Vr-Dxxxxxx (for date codes prior to February 11, 2000)

or

FID=SEL-551-R1xx-Vr-Z001001 Dxxxxxxx (for date codes February 11, 2000 or later)

SEL-551 R500-series firmware versions are Flash versions:

FID=SEL-551-R5xx-Vf-Dxxxxxx (for date codes prior to February 11, 2000)

or

FID=SEL-551-R5xx-Vf-Z001001 Dxxxxxxx (for date codes February 11, 2000 or later)

EPROM firmware upgrade instructions are shown below. Flash firmware upgrade instructions follow after.

## EPROM Firmware Upgrades

---

Installing new EPROM firmware requires that you power down the relay, remove the front panel, pull out the main circuit board, exchange an integrated circuit (IC) component, and reassemble the relay. If you do not wish to perform the installation yourself, SEL can assist you. Simply return the relay and IC to SEL. We will install the new IC and return the unit to you within a few days.

## Required Equipment

- ▶ Phillips® screwdriver
- ▶ Personal computer
- ▶ Terminal emulation software
- ▶ Serial communications cable (SEL-234A or equivalent)
- ▶ ESD workstation (grounding pad and wrist strap)
- ▶ AMP Extraction Tool 822154-1

## Upgrade Instructions

### ⚠CAUTION

This procedure requires that you handle components sensitive to Electrostatic Discharge (ESD). If your facility is not equipped to work with these components, we recommend that you return the relay to SEL for firmware installation.

### ⚠CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.


- Step 1. Connect a computer to the relay serial communications port, and enter Access Level 1.
- Step 2. Execute the **SHO C** command, and record all displayed data for possible reentry after the EPROM upgrade.
- Step 3. If you do not already have copies of the Relay, Logic, Port, SER, and Text label settings, issue the following commands to retrieve the settings: **SHO**, **SHO L**, **SHO P**, **SHO R**, and **SHO T**.

Normally, the relay will preserve the settings during the firmware upgrade. However, if the new firmware version includes more settings than the old version, you will have to reenter your old settings.

- Step 4. If the relay is in service, disable its breaker control functions.
- Step 5. Turn off control power to the relay.
- Step 6. Disconnect the rear serial port connection, if used, before removing the main board.
- Step 7. Remove the three front-panel screws with the Phillips screwdriver, and remove the relay front panel.
- Step 8. Disconnect the analog signal ribbon cable from the underside of the relay main board and from the input module.
- Step 9. Grasp the black knob on the front of the drawout assembly, and remove the assembly from the relay chassis.

Because [Step 11](#) through [Step 14](#) involve handling devices and assemblies sensitive to ESD, perform these steps at an ESD-safe workstation. This will help prevent possible damage by ESD.

- Step 10. Locate the EPROM socket (reference designator U8) on the SEL-551 main board.




**Figure B.1 EPROM Socket**

- Step 11. Insert AMP Extraction Tool 822154-1 into one of the extraction slots on the EPROM socket.

Step 12. With a slight downward pressure, rotate the extraction tool away from the EPROM socket until the EPROM starts to lift away from the socket.

Step 13. Do not lift the EPROM all the way out on the first attempt.



**Figure B.2 Insertion of the Extraction Tool in the EPROM Socket**

Reference: AMP Instruction Sheet 408-9695 (dated May 18, 1994, Rev. B).

Step 14. Remove the extraction tool from the slot, and insert it into the opposite extraction slot.


Step 15. With a slight downward pressure, rotate the extraction tool away from the EPROM socket until the other side of the EPROM starts to lift away from the EPROM socket.

Step 16. Alternate between the two extraction slots, and gently lift the EPROM from the socket.

Step 17. Carefully place the new EPROM in the socket, and apply even, firm pressure to fully engage it in the socket.

**CAUTION**

Verify proper orientation of the new EPROM in the socket before applying pressure to engage it. Note the orientation indication provided by the notched inside socket corner and the notched corner.



**Figure B.3 Proper Orientation of the EPROM and EPROM Socket**

Step 18. Slide the drawout assembly into the relay chassis.

Step 19. Reconnect the analog signal ribbon cable.

Step 20. Replace the relay front panel.

Step 21. Replace the rear-panel communications cable.

Step 22. With breaker control disabled, turn relay power on.

Step 23. If the **EN** LED is illuminated, proceed to [Step 10](#) below.

If the relay front-panel display is blank, the EPROM may not be seated properly.

- Step 1. Turn relay power off.
- Step 2. Disassemble the relay (following [Step 7](#) through [Step 9 on page B.2](#)) and verify the EPROM is seated into its socket.
- Step 3. Verify proper orientation.
- Step 4. If the EPROM is seated properly and the relay will not power up, remove the EPROM and inspect it for bent pins.
- Step 5. If EPROM pins are bent, contact the SEL factory for a replacement.

If the relay front panel displays a `CR RAM` or `EEPROM FAILURE` message, reload the relay settings with the procedure below.

- Step 1. Set your communications software settings to 2400 baud, 8 data bits, 1 stop bit.
- Step 2. Enter Access Level 2 by issuing the **ACC** and **2AC** commands.
- Step 3. If the relay prompts for passwords, enter your Level 1 and Level 2 passwords.
- Step 4. Issue the **R\_S** command to restore the factory default settings in the relay. The relay will reboot with the factory default settings.
- Step 5. Enter Access Level 2.
- Step 6. Verify the calibration settings by issuing the **SHO C** command.
- Step 7. If the settings do not match the settings recorded in [Step 2 on page B.2](#), reissue the settings with the **SET C** command.
- Step 8. Set the Relay, Logic, SER, and Text settings with each of the following commands: **SET**, **SET L**, **SET P**, **SET R**, **SET T**.
- Step 9. Set the relay passwords via the **PAS** command.
- Step 10. Execute the **STATUS** command to verify all relay self-test parameters are within tolerance.
- Step 11. Apply current signals to the relay.
- Step 12. Issue the **METER** command.
- Step 13. Verify the current signals are correct.
- Step 14. Issue the **TRIGGER** and **EVENT** commands.
- Step 15. Verify the current signals are correct in the EVENT report.  
The relay is now ready for your commissioning procedure.
- Step 16. With relay communications still established at Access Level 2, execute the **SHO C** command and review displayed data.
- Step 17. If data are identical to previously recorded data of [Step 2 on page B.2](#), you can execute the **QUIT** command. The relay is ready for your commissioning procedure.
- Step 18. If, however, any channel gains are different, you must reenter the previously recorded values by executing the **SET C** command (similar to relay settings procedure).

Step 19. After this procedure is completed and changes have been saved, execute the **QUIT** command.

The relay is now ready for your commissioning procedure.

## Flash Firmware Upgrades

---

### Required Equipment

- Personal computer.
- Terminal emulation software that supports XMODEM/CRC protocol.
- Serial communications cable (SEL 234A or equivalent).
- Disk containing firmware upgrade file.

### Upgrade Procedure

**NOTE:** If the SEL-551 contains History (HIS) data, Event (EVE) data, Metering (MET) data, or Sequential Events Recorder (SER) data that you want to retain, these must be retrieved prior to performing the firmware upgrade, because all of these data sets may be erased in the upgrade procedure.

The instructions below assume you have a working knowledge of your personal computer terminal emulation software. In particular, you must be able to modify your serial communications parameters (baud rate, data bits, parity, etc.), disable any hardware or software flow control in your computer terminal emulation software, select transfer protocol (i.e., XMODEM/CRC), and transfer files (e.g., send and receive binary files).

- Step 1. If the relay is in service, disable its control functions.
- Step 2. Connect the personal computer to the relay serial port and enter Access Level 2 by issuing the **ACC** and **2AC** commands.
- Step 3. Execute the Show Calibration (**SHO C**) command to retrieve the relay calibration settings.
- Step 4. Record the displayed settings (or save them to a computer file) for possible reentry after the firmware upgrade.
- Step 5. If you do not already have copies of the Global, Group, Logic, Port, SER, and Text label settings, use the following Show commands to retrieve the necessary settings: **SHO**, **SHO L**, **SHO P**, **SHO R**, and **SHO T**.

Normally, the relay will preserve the settings during the firmware upgrade. However, depending on the firmware version that was previously installed and the use of relay memory, this cannot be ensured. Saving settings is always recommended.

- Step 6. Set up your communication connection to the highest possible baud rate. The relay will support speeds up to 38,400 baud.
- Step 7. Use the **SET P** command to change the SPEED setting to the desired baud rate.
- Step 8. From Access Level 2, issue the **L\_D <Enter>** command to the relay (L underscore D <Enter>) to start the SELBOOT program.
- Step 9. Type **Y <Enter>** at the `Disable relay to send or receive firmware (Y/N)?` prompt and **Y <Enter>** to the `Are you sure (Y/N)?` prompt. The relay will send the SELBOOT prompt `!>`.
- Step 10. Make a copy of the firmware currently in the relay. This is recommended in case the new firmware download is unsuccessful. To make a backup of the firmware, you will need approximately 500 KB of free disk space. The procedure takes approximately three minutes at 38,400 baud.

**NOTE:** SELBOOT does not echo nonalphanumeric characters as the first character of a line. This may make it appear that the relay is not functioning properly when just the **<Enter>** key is pressed on the connected PC, even though everything is OK.

Step 11. Issue the Send (**SEN <Enter>**) command to the relay to initiate the firmware transfer from the relay to your computer. No activity will be seen on the PC screen, because the relay is waiting for the PC to request the first XMODEM data packet.

Step 12. Select the “Receive File” function with the XMODEM protocol in your terminal emulation software.

Step 13. Give the file a unique name to clearly identify the firmware version (e.g., 551\_R500.S19). After the transfer, the relay will respond:

---

**NOTE:** If the relay power fails during a firmware receive after the old firmware is erased, the relay will restart in SELBOOT, but the baud rate will default to 2400 baud. (If this happens, connect to the relay at 2400 baud and type BAUD 38400 at the SELBOOT prompt. The firmware receive can be started again at [Step 14.](#))

---

**NOTE:** The relay will display one or more “C” characters as it waits for your PC Terminal Emulation program to send the new firmware. If you do not start the transfer quickly enough (within about 18 seconds), it may time out and respond “Remote system is not responding.” If this happens, begin again in [Step 14](#), above.

---

**NOTE:** The file transfer takes approximately three minutes at 38,400 baud, using the 1k-XMODEM protocol.

---

```
Download completed successfully!
```

---

Step 14. Begin the transfer of the new firmware to the relay by issuing the Receive (**REC <Enter>**) command to instruct the relay to receive new firmware.

Step 15. The relay will ask if you are sure you want to erase the existing firmware.

Step 16. Type **Y** to erase the existing firmware and load new firmware, or just **<Enter>** to abort.

Step 17. The relay then prompts you to press a key and begin the transfer.

Step 18. Press a key (e.g., **<Enter>**).

Step 19. Start the file transfer by selecting the “Send File” function in your terminal emulation software. Use the XMODEM or 1k-XMODEM (fastest) protocol and send the file that contains the new firmware (e.g., Relay.S19).

After the transfer completes, the relay will reboot and return to Access Level 0. The following screen capture shows the entire process.

---

```
=>>L_D <Enter>
Disable relay to send or receive firmware(Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
Relay Disabled
!>SEN <Enter>
Download completed successfully!

!>REC <Enter>
Caution! - This command erases the relay's firmware.
If you erase the firmware, new firmware must be loaded into the relay
before it can be put back into service.

Are you sure you wish to erase the existing firmware? (Y/N)Y <Enter>
Erasing
Erase successful
Press any key to begin transfer, then start transfer at the PC <Enter>

Upload completed successfully. Attempting a restart
```

---

Step 20. The relay illuminates the **EN** front-panel LED if the original relay settings were retained through the download.

Step 21. If the **EN** LED is illuminated, proceed to [Step 23](#); otherwise, the relay may display various self-test failures because of changes in the way memory is used.

Step 22. If the **EN LED** is extinguished, the relay baud rate has changed back to the factory default of 2400 baud; go to self-test failure: **CR\_RAM** and **EEPROM**, [Step 22 Step a.](#)

Self-test failure: **CR\_RAM** and **EEPROM**

- a. Set your communications software settings to 2400 baud, 8 data bits, 1 stop bit.
- b. Now enter Access Level 2 by issuing the **ACC** and **2AC** commands, (the factory default passwords will be in effect).
- c. Issue the Restore Settings (**R\_S**) command to restore the factory default settings in the relay. This takes about two minutes, then the **EN LED** will illuminate.
- d. Enter Access Level 2 by issuing the **ACC** and **2AC** commands, (the factory default passwords will be in effect).
- e. Restore the original settings as necessary with each of the following commands: **SET**, **SET L**, **SET P**, **SET R**, and **SET T**.
- f. Set the relay passwords via the **PAS** command. Passwords are case-sensitive, so the lower- and uppercase letters are treated differently.
- g. If there are still any **FAIL** codes on the Relay LCD, see [Section 8: Testing and Troubleshooting.](#)

Step 23. Verify the calibration settings by issuing the **SHO C** command.

Step 24. If the settings do not match the settings recorded in [Step 2 on page B.2.](#), reissue the settings with the **SET C** command.

Step 25. Execute the Status (**STA**) command to verify that all relay self-test parameters are within tolerance, and that the relay is enabled.

Step 26. Apply current signals to the relay.

Step 27. Issue the **MET** command.

Step 28. Verify that the current and voltage signals are correct.

Step 29. Issue the Trigger (**TRI**) and Event (**EVE**) commands.

Step 30. Verify that the current and voltage signals are correct in the event report.

The relay is now ready for your commissioning procedure.

**This page intentionally left blank**

# Appendix C

## SEL Distributed Port Switch Protocol

---

### Overview

---

SEL Distributed Port Switch Protocol (LMD) permits multiple SEL relays to share a common communications channel. It is appropriate for low-cost, low-speed port switching applications where updating a real-time database is not a requirement.

### Settings

---

Use the front-panel {SET} pushbutton or the serial port **SET P** command to activate the LMD protocol. Change the port PROTOCOL setting from the default SEL to LMD to reveal the following settings:

Setting	Description
PREFIX:	One character to precede the address. This should be a character that does not occur in the course of other communications with the relay. Valid choices are one of the following: "@" "#" "\$" "%" "&." The default is "@".
ADDRESS:	Two character ASCII address. The range is "01" to "99." The default is "01."
SETTLE TIME:	Time in seconds that transmission is delayed after the request to send (RTS line) asserts. This delay accommodates transmitters with a slow rise time.

### Operation

---

**NOTE:** You can use the front-panel {SET} pushbutton to change the port settings to return to SEL protocol.

1. The relay ignores all input from this port until it detects the prefix character and the two-byte address.
2. Upon receipt of the prefix and address, the relay enables echo and message transmission.
3. Wait until you receive a prompt before entering commands to avoid losing echoed characters while the external transmitter is warming up.
4. Until the relay connection terminates, you can use the standard commands that are available when PROTOCOL is set to SEL.

5. The **QUIT** command terminates the connection. If no data are sent to the relay before the port time-out period, it automatically terminates the connection.
6. Enter the sequence **<Ctrl+X> QUIT <CR>** before entering the prefix character, if all relays in the multidrop network do not have the same prefix setting.

# Appendix D

## Configuration, Fast Meter, and Fast Operate Commands

---

### Overview

---

SEL relays have two separate data streams that share the same serial port. The human data communications with the relay consist of ASCII character commands and reports that are intelligible to humans using a terminal or terminal emulation package. The binary data streams can interrupt the ASCII data stream to obtain information and then allow the ASCII data stream to continue. This mechanism allows a single communications channel to be used for ASCII communications (e.g., transmission of a long event report) interleaved with short bursts of binary data to support fast acquisition of metering data. The device connected to the other end of the link requires software that uses the separate data streams to exploit this feature. The binary commands and ASCII commands can also be accessed by a device that does not interleave the data streams.

*SEL Application Guide AG95-10, Configuration and Fast Meter Messages*, is a comprehensive description of the SEL binary messages. Below is a description of the messages provided in the SEL-551.

### Message Lists

---

**Table D.1 Binary Message List**

Request to Relay (hex)	Response From Relay
A5C0	Relay Definition Block
A5C1	Fast Meter Configuration Block
A5D1	Fast Meter Data Block
A5C2	Demand Fast Meter Configuration Block
A5D2	Demand Fast Meter Data Message
A5C3	Peak Demand Fast Meter Configuration Block
A5D3	Peak Demand Fast Meter Data Message
A5B9	Fast Meter Status Acknowledge
A5CE	Fast Operate Configuration Block
A5E0	Fast Operate Remote Bit Control
A5E3	Fast Operate Breaker Control

**Table D.2 ASCII Configuration Message List**

Request to Relay (ASCII)	Response From Relay
ID	ASCII Firmware ID String and Terminal ID Setting (TID)
DNA	ASCII Names of Relay Word bits
BNA	ASCII Names of bits in the A5B9 Status Byte

## Message Definitions

### A5C0 Relay Definition Block

In response to the A5C0 request, the relay sends the following block:

**Table D.3 A5C0 Relay Definition Block**

Data	Description
A5C0	Command
30	Length
02	Support two protocols, SEL and LMD
03	Support three Fast Meter messages
03	Three status flag commands
A5C1	Fast Meter configuration command
A5D1	Fast Meter command
A5C2	Demand Fast Meter configuration command
A5D2	Demand Fast Meter command
A5C3	Peak Demand Fast Meter configuration command
A5D3	Peak Demand Fast Meter command
0004	Settings change bit
A5C100000000	Fast Meter configuration message
0004	Settings change bit
A5C200000000	Demand Fast Meter configuration message
0004	Settings change bit
A5C300000000	Peak Demand Fast Meter configuration message
0100	SEL protocol, Fast Operate
0101	LMD protocol, Fast Operate
00	Reserved
checksum	1-byte checksum of preceding bytes

### A5C1 Fast Meter Configuration Block

In response to the A5C1 request, the relay sends the following block:

**Table D.4 A5C1 Fast Meter Configuration Block (Sheet 1 of 2)**

Data	Description
A5C1	Fast Meter command
48	Length
01	One status flag byte
00	Scale factors in Fast Meter message
02	Two scale factors

**Table D.4 A5C1 Fast Meter Configuration Block (Sheet 2 of 2)**

Data	Description
04	Four analog input channels
04	Four samples per channel
0F	Fifteen digital banks (SEL-551)
01	One calculation block
000C	Analog channel offset
002C	Time stamp offset
0034	Digital offset
494100000000	Analog channel name (IA)
00	Analog channel type (integer)
01	Scale factor type (float)
0004	Scale factor offset in A5D1 message
494200000000	Analog channel name (IB)
00	Analog channel type (integer)
01	Scale factor type (float)
0004	Scale factor offset in A5D1 message
494300000000	Analog channel name (IC)
00	Analog channel type (integer)
01	Scale factor type (float)
0004	Scale factor offset in A5D1 message
494E00000000	Analog channel name (IN)
00	Analog channel type (integer)
01	Scale factor type (float)
0008	Scale factor offset in A5D1 message
1-byte	Line configuration: 00 - ABC, 01 - ACB; based on PHROT relay setting
03	Calculation type (currents only)
FFFF	Skew correction offset (none)
FFFF	Rs scale factor offset (none)
FFFF	Xs scale factor offset (none)
00	IA channel index
01	IB channel index
02	IC channel index
FF	VA channel index (none)
FF	VB channel index (none)
FF	VC channel index (none)
00	Reserved
checksum	1-byte checksum of all preceding bytes

## A5D1 Fast Meter Data Block

In response to the A5D1 request, the relay sends the following block:

**Table D.5 A5D1 Fast Meter Data Block**

Data	Description
A5D1	Command
44	Message length
1-byte	Status Byte
4-bytes	Phase current scale factor (4-byte IEEE FPS)
4-bytes	Neutral current scale factor (4-byte IEEE FPS)
32 bytes	The first and third half-cycles of two cycles of data saved by the relay. The data are presented in quarter-cycle sets of integer data in the following order: IA, IB, IC, IN
8-bytes	Time stamp
15-bytes	SEL-551 Relay Word bits (see DNA message for bit map)
checksum	1-byte checksum of all preceding bytes

## A5C2/A5C3 Demand/ Peak Demand Fast Meter Configuration Messages

In response to the A5C2 or A5C3 request, the relay sends the following fast meter configuration block:

**Table D.6 A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages (Sheet 1 of 2)**

Data	Description
A5C2 or A5C3	Demand (A5C2) or Peak Demand (A5C3) command
4E	Length
01	# of status flag bytes
00	Scale factors in meter message
00	# of scale factors
06	# of analog input channels
01	# of samples per channel
00	# of digital banks
00	# of calculation blocks
0004	Analog channel offset
0034	Time stamp offset
FFFF	Digital offset
494100000000	Analog channel name (IA)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494200000000	Analog channel name (IB)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494300000000	Analog channel name (IC)
02	Analog channel type
FF	Scale factor type

**Table D.6 A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages (Sheet 2 of 2)**

Data	Description
0000	Scale factor offset in Fast Meter message
494E00000000	Analog channel name (IN)
02	Analog channel type
FF	Scale factor type
0000	Second scale factor offset in Fast Meter message
494700000000	Analog channel name (IG)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
334932000000	Analog channel name (3I2)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
00	Reserved
checksum	

### A5D2/A5D3 Demand/ Peak Demand Fast Meter Message

In response to the A5D2 or A5D3 request, the relay sends the following block:

**Table D.7 A5D2/A5D3 Demand/Peak Demand Fast Meter Message**

Data	Description
A5D2 or A5D3	Command
3E	Length
1-byte	1 Status Byte
48-bytes	Demand IA, IB, IC, IN, IG, 3I2 in 8-byte IEEE FPS
8-bytes	Time stamp
1-byte	reserved
1-byte	1-byte checksum of all preceding

### A5B9 Fast Meter Status Acknowledge Message

In response to the A5B9 request, the relay clears the Fast Meter (message A5D1) Status Byte. The SEL-551 Status Byte contains one active bit, STSET (bit 4). The bit is set on power up and on settings changes. If the STSET bit is set, the external device should request the A5C1, A5C2, and A5C3 messages. The external device can then determine if the scale factors or line configuration parameters have been modified.

## A5CE Fast Operate Configuration Block

In response to the A5CE request, the relay sends the following block:

**Table D.8 A5CE Fast Operate Configuration Block**

Data	Description
A5CE	Command
24	Message length
01	Support one circuit breaker
0008	Support 8 remote bit set/clear commands
01	Allow remote bit pulse commands
00	Reserved
31	Operate code, open breaker 1
11	Operate code, close breaker 1
00	Operate code, clear remote bit RB1
20	Operate code, set remote bit RB1
40	Operate code, pulse remote bit RB1
01	Operate code, clear remote bit RB2
21	Operate code, set remote bit RB2
41	Operate code, pulse remote bit RB2
02	Operate code, clear remote bit RB3
22	Operate code, set remote bit RB3
42	Operate code, pulse remote bit RB3
03	Operate code, clear remote bit RB4
23	Operate code, set remote bit RB4
43	Operate code, pulse remote bit RB4
04	Operate code, clear remote bit RB5
24	Operate code, set remote bit RB5
44	Operate code, pulse remote bit RB5
05	Operate code, clear remote bit RB6
25	Operate code, set remote bit RB6
45	Operate code, pulse remote bit RB6
06	Operate code, clear remote bit RB7
26	Operate code, set remote bit RB7
46	Operate code, pulse remote bit RB7
07	Operate code, clear remote bit RB8
27	Operate code, set remote bit RB8
47	Operate code, pulse remote bit RB8
00	Reserved
checksum	1-byte checksum of all preceding bytes

## A5E0 Fast Operate Remote Bit Control

The external device sends the following message to perform a remote bit operation:

**Table D.9 A5E0 Fast Operate Remote Bit Control**

Data	Description
A5E0	Command
06	Message length
1-byte	Operate code: 00-07 clear remote bit RB1–RB8 20-27 set remote bit RB1–RB8 40-47 pulse remote bit for RB1–RB8
1-byte	Operate validation: 4 • Operate code + 1
checksum	1-byte checksum of preceding bytes

The relay performs the specified remote bit operation if the following conditions are true:

- The Operate code is valid.
- The Operate validation = 4 • Operate code + 1.
- The message checksum is valid.
- The FAST\_OP port setting is set to Y.
- The relay is enabled.

Remote bit set and clear operations are latched by the relay. Remote bit pulse operations assert the remote bit for one processing interval (1/8 cycle).

## A5E3 Fast Operate Breaker Control

The external device sends the following message to perform a fast breaker open/close:

**Table D.10 A5E3 Fast Operate Breaker Control**

Data	Description
A5E3	Command
06	Message length
1-byte	Operate code: 31-OPEN breaker 11-CLOSE breaker
1-byte	Operate Validation: 4 • Operate code + 1
checksum	1-byte checksum of preceding bytes

The relay performs the specified breaker operation if the following conditions are true:

- Conditions 1–5 defined in the A5E0 message are true.
- The **BREAKER** jumper is in place on the SEL-551 main board.
- The TDURD setting is non-zero.

## ID Message

In response to the **ID** command, the relay sends the following:

---

```
<STX>"FID STRING ENCLOSED IN QUOTES","yyyy" <CR>
"BFID STRING ENCLOSED IN QUOTES","yyyy" <CR>
"CID STRING ENCLOSED IN QUOTES","yyyy" <CR>
"DEVID STRING ENCLOSED IN QUOTES","yyyy" <CR>
"DEVCODE STRING ENCLOSED IN QUOTES","yyyy" <CR>
"PARTNO STRING ENCLOSED IN QUOTES","yyyy" <CR>
"CONFIG STRING ENCLOSED IN QUOTES","yyyy" <CR>
"SPECIAL STRING ENCLOSED IN QUOTES","yyyy" <CR>
<ETX>
```

---

where:

<STX> = the STX character (02)

<CR> = the carriage return character (13)

<ETX> = the ETX character (03)

DEVCODE = the string containing the Modbus® device code (29 for SEL-551)

yyyy = the 4-byte ASCII hex representation of the checksum for each line

The ID message is available from Access Level 1 and higher.

## DNA Message

In response to the **DNA** command, the relay sends names of the Relay Word bits transmitted in the A5D1 message. The first name is associated with the MSB, the last name with the LSB. The DNA message for the SEL-551 is:

---

```
<STX>"EN","INST","A","B","C","N","RS","L0","07A5"
"51P1","51P2","51N1","51G1","51P1T","51P2T","51N1T","51G1T","0BF4"
"51Q1","51Q2","51Q1T","51Q2T","50P1","50P2","50P3","50P4","0B68"
"50P5","50P6","50N1","50N2","50G1","50G2","50Q1","50Q2","0AA8"
"50A","50B","50C","IN1","IN2","OC","CC","CF","08A7"
"LB1","LB2","LB3","LB4","LB5","LB6","LB7","LB8","0994"
"RB1","RB2","RB3","RB4","RB5","RB6","RB7","RB8","09C4"
"SV1","SV2","SV3","SV4","SV5","SV6","SV7","SV8","0A6C"
"SV9","SV10","SV11","SV12","SV13","SV14","*","*","09F2"
"79RS","79CY","79LO","SH0","SH1","SH2","SH3","SH4","0AAD"
"TRIP","CLOSE","51P1R","51P2R","51N1R","51G1R","51Q1R","51Q2R","0D84"
"SV5T","SV6T","SV7T","SV8T","SV9T","SV10T","SV11T","SV12T","0DA1"
"SV13T","SV14T","*","ALARM","OUT1","OUT2","OUT3","OUT4","0C84"
"PDEM","NDEM","GDEM","QDEM","TRGTR","*","*","*","*","0A1F"
"*","*","*","*","*","*","*","*","04D0"<ETX>
```

---

where:

<STX> = the STX character (02)

<ETX> = the ETX character (03)

the last field in each line = the 4-byte ASCII hex representation of the checksum for the line

\* = an unused bit location

The DNA command is available from Access Level 1 and higher.

## BNA Message

In response to the **BNA** command, the relay sends names of the bits transmitted in the Status Byte in the A5D1 message. The first name is the MSB, the last name is the LSB. The BNA message is:

---

```
<STX>"*","*","*","STSET","*","*","*","*","0639"<ETX>
```

---

where:

0639 = the 4-byte ASCII representation of the checksum

\* = an unused bit location

The BNA command is available from Access Level 1 and higher.

# Appendix E

## Compressed ASCII Commands

---

### Overview

---

The SEL-551 Relay provides Compressed ASCII versions of some relay ASCII commands. The Compressed ASCII commands allow an external device to obtain data from the relay, in a format which directly imports into spreadsheet or database programs, and which can be validated with a checksum.

The SEL-551 provides the following Compressed ASCII commands:

Command	Description
CASCI	Configuration message
CSTATUS	Status message
CHISTORY	History message
CEVENT	Event message

### CASCI Command—General Format

---

The Compressed ASCII configuration message provides data for an external computer to extract data from other Compressed ASCII commands. To obtain the configuration message for the Compressed ASCII commands available in an SEL relay, type:

**CAS <CR>**

The relay sends:

---

```
<STX> "CAS",n,"yyyy" <CR>
"COMMAND 1",l1,"yyyy" <CR>
"#H","xxxxx","xxxxx",.....,"xxxxx","yyyy" <CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyyy" <CR>
"COMMAND 2",l1,"yyyy" <CR>
"#h","ddd","ddd",.....,"ddd","yyyy" <CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyyy" <CR>
.
.
.
"COMMAND n",l1,"yyyy" <CR>
"#H","xxxxx","xxxxx",.....,"xxxxx","yyyy" <CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyyy" <CR><ETX>
```

---

where:

$n$  = the number of Compressed ASCII command descriptions to follow.

COMMAND = the ASCII name for the Compressed ASCII command as sent by the requesting device. The naming convention for the compressed ASCII commands is a C preceding the typical command. For example, **CSTATUS** (abbreviated to **CST**) is the Compressed **STATUS** command.

l1 = the minimum access level at which the command is available.

#H identifies a header line to precede one or more data lines; # is the number of subsequent ASCII names. For example, 21H identifies a header line with 21 ASCII labels.

#h identifies a header line to precede one or more data lines; # is the number of subsequent format fields. For example, 8h identifies a header line with 8 format fields.

xxxx = an ASCII name for corresponding data on following data lines. Maximum ASCII name width is 10 characters.

#D identifies a data format line; # is the maximum number of subsequent data lines.

ddd identifies a format field containing one of the following type designators:

I = Integer data

F = Floating point data

mS = String of maximum m characters  
(e.g., 10S for a 10-character string)

yyyy = the 4-byte hex ASCII representation of the checksum.

A Compressed ASCII command may require multiple header and data configuration lines.

If a Compressed ASCII request is made for data that are not available, (e.g. the history buffer is empty or invalid event request), the relay responds with the following message:

---

```
<STX>"No Data Available", "0668"<CR><ETX>
```

---

## CASCII Command–SEL-551

---

Display the SEL-551 Compressed ASCII configuration message by sending:

**CAS <CR>**

The SEL-551 sends:

---

```

<STX>
"CAS",5,"01A8"<CR>
"CST",1,"01B7"<CR>
"23H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","IA","IB","IC",
"IN","MOF","+5V_PS","+5V_REG","-5V_REG","+10V_PS","-10V_PS","VBAT",
"TEMP","RAM","ROM","CR_RAM","EEPROM","2738"<CR>
"1D","I","I","I","I","I","I","I","9S","9S","9S","9S","9S","9S","9S",
"9S","9S","9S","9S","9S","9S","15B4"<CR>
"CHI",1,"01A1"<CR>
"12H","REC_NUM","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC",
"EVENT","SHOT","CURR","TARGETS","1654"<CR>
"20D","I","I","I","I","I","I","I","6S","I","I","22S","0A70"<CR>
"CEV",1,"01AB"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","0BB9"<CR>
"1D","I","I","I","I","I","I","I","05F4"<CR>
"7H","IA","IB","IC","IN","IG","TRIG","RLY_BITS","0A85"<CR>
"60D","F","F","F","F","F","1S","45S","06C8"<CR>
"CEV L",1,"0217"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","0BB9"<CR>
"1D","I","I","I","I","I","I","I","05F4"<CR>
"7H","IA","IB","IC","IN","IG","TRIG","RLY_BITS","0A85"<CR>
"120D","F","F","F","F","F","1S","45S","06F5"<CR>
"CEV R",1,"021D"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","0BB9"<CR>
"1D","I","I","I","I","I","I","I","05F4"<CR>
"7H","IA","IB","IC","IN","IG","TRIG","RLY_BITS","0A85"<CR>
"256D","F","F","F","F","F","1S","45S","06FF"<CR>
<ETX>

```

---

## CSTATUS Command–SEL-551

---

Display status data in Compressed ASCII format by sending:

**CST <CR>**

The SEL-551 sends:

---

```

<STX>"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","IA","IB","IC",
"IN","MOF","+5V_PS","+5V_REG","-5V_REG","+10V_PS","-10V_PS",
"VBAT","TEMP","RAM","ROM","CR_RAM","EEPROM","261B" <CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,"xxxx","xxxx","xxxx","xxxx",
"xxxx","xxxx","xxxx","xxxx","xxxx","xxxx","xxxx","xxxx","xxxx",
"yyyy"
<CR><ETX>

```

---

where:

xxxx = the data values corresponding to the first line labels

yyyy = the 4-byte hex ASCII representation of the checksum

## CHISTORY Command–SEL-551

---

Display history data in Compressed ASCII format by sending:

**CHI <CR>**

The SEL-551 sends:

---

```
<STX>"REC_NUM","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC",  
"EVENT","SHOT","CURR","TARGETS","1539"<CR>  
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,"xxxx",xxxx,xxxx,"yyyy"<CR>  
<ETX>
```

---

(the last line is then repeated for each record)

where:

xxxx = the data values corresponding to the first line labels

yyyy = the 4-byte hex ASCII representation of the checksum

## CEVENT Command–SEL-551

---

Display event report in Compressed ASCII format by sending:

**CEV [n x] <CR>**

The parameters in brackets, [ ], are optional.

- n* = the number of the event report, as used in the **EVE** command
- x* = L specifies long event report, as used in the **EVE** command
- x* = R specifies raw (unfiltered) analog data, as used in the **EVE** command

The SEL-551 responds to the **CEV** command with the *n*th event report as shown below:

---

```
<STX>"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","OACA"<CR>  
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,"yyyy" <CR>  
"IA","IB","IC","IN","IG","TRIG","RLY_BITS","0996"<CR>  
xxxx,xxxx,xxxx,xxxx,xxxx,"z","xxxx","yyyy" <CR>  
<ETX>
```

---

(the fourth line is then repeated for each data line in record one)

where:

xxxx = the data values corresponding to the first and third line labels

yyyy = the 4 byte hex ASCII representation of the checksum

z = > for the trigger record and empty for all others

TRIG refers to the event trigger record indication

RLY\_BITS refers to the Relay Word bits

# Appendix F

## Setting Negative-Sequence Overcurrent Elements

---

### Setting Negative-Sequence Definite-Time Overcurrent Elements

---

*Negative-sequence instantaneous overcurrent elements 50Q1 and 50Q2 should not be set to trip directly.* This is because negative-sequence current can transiently appear when a circuit breaker is closed and balanced load current suddenly appears.

To avoid having negative-sequence instantaneous overcurrent elements trip for this transient condition, delay negative-sequence instantaneous overcurrent elements by at least 1.5 cycles (transient condition lasts less than 1.5 cycles). Use the SELLOGIC® Variable timers described in [SELOGIC Control Equation Variables/Timers on page 3.38](#).

Effectively, negative-sequence instantaneous overcurrent elements 50Q1 and 50Q2 are turned into negative-sequence definite-time overcurrent elements by running them through timers. Use the timer output for tripping.

Continue reading in [Coordinating Negative-Sequence Overcurrent Elements on page F.2](#) for guidelines on coordinating negative-sequence definite-time overcurrent elements and a following coordination example. The coordination example uses time-overcurrent elements, but the same principles can be applied to definite-time overcurrent elements.

### Setting Negative-Sequence Time-Overcurrent Elements

---


Negative-sequence time-overcurrent elements 51Q1T and 51Q2T should not be set to trip directly when they are set with low time-dial settings 51Q1TD and 51Q2TD, respectively, that result in curve times below 3 cycles (see curves in [Figure 4.1–Figure 4.10](#)). This is because negative-sequence current can transiently appear when a circuit breaker is closed and balanced load current suddenly appears.

To avoid having negative-sequence time-overcurrent elements with such low time-dial settings trip for this transient negative-sequence current condition, make settings similar to the following:

SV6PU = **1.500 cycles** (minimum response time; transient condition lasts less than 1.5 cycles)

SV6 = **51Q1** (run pickup of negative-sequence time-overcurrent element 51Q1T through SELOGIC Variable timer SV6)

TR = **..+51Q1T\*SV6T+..** (trip conditions; SV6T is the output of the SELOGIC Variable timer SV6)



**Figure F.1 Minimum Response Time Added to a Negative-Sequence Time-Overcurrent Element**

Continue reading in *Coordinating Negative-Sequence Overcurrent Elements on page F.2* for guidelines on coordinating negative-sequence time-overcurrent elements and a following coordination example.

## Coordinating Negative-Sequence Overcurrent Elements

The following coordination guidelines and example assume that the negative-sequence overcurrent elements operate on  $3I_2$  magnitude negative-sequence current and that the power system is radial. The negative-sequence overcurrent elements in the SEL-551 Relay operate on  $3I_2$  magnitude negative-sequence current.

The coordination example is a generic example that can be used with any relay containing negative-sequence overcurrent elements that operate on  $3I_2$  magnitude negative-sequence current. The SEL-551 can be inserted as the

feeder relay in this example. Note that the overcurrent element labels in the example are not the same as the labels of the corresponding SEL-551 overcurrent elements.

## Coordination Guidelines

1. Start with the furthest downstream negative-sequence overcurrent element (e.g., distribution feeder relay in a substation).
2. Identify the phase overcurrent device (e.g., line recloser, fuse) downstream from the negative-sequence overcurrent element that is of greatest concern for coordination.

This is usually the phase overcurrent device with the longest clearing time.

3. Consider the negative-sequence overcurrent element as an “equivalent” phase overcurrent element.

Derive pickup, time dial (lever), curve type, or time-delay settings for this “equivalent” element to coordinate with the downstream phase overcurrent device, as any phase coordination would be performed.

Load considerations can be disregarded when deriving the “equivalent” phase overcurrent element settings.

4. Multiply the “equivalent” phase overcurrent element pickup setting by  $\sqrt{3}$  to convert it to the negative-sequence overcurrent element pickup setting in terms of  $3I_2$  current.

$$\left. \begin{array}{l} \text{Negative-} \\ \text{sequence} \\ \text{overcurrent} \\ \text{element} \\ \text{pickup} \end{array} \right\} = \sqrt{3} \cdot (\text{"equivalent" phase overcurrent element pickup})$$


Any time dial (lever), curve type, or time delay calculated for the “equivalent” phase overcurrent element is also used for the negative-sequence overcurrent element with no conversion factor applied.

5. Set the next upstream negative-sequence overcurrent element to coordinate with the first downstream negative-sequence overcurrent element and so on.

Again, coordination is not influenced by load considerations.

## Coordination Example


In *Figure F.2* the phase and negative-sequence overcurrent elements of the feeder relay (51F and 51QF, respectively) must coordinate with the phase overcurrent element of the line recloser (51R).



**Figure F.2 Distribution Feeder Protective Devices**

- $I_F$  = Maximum load current through feeder relay = 450 A
- $I_R$  = Maximum load current through line recloser = 150 A
- 51F = Feeder relay phase time-overcurrent element
- 51QF = Feeder relay negative-sequence time-overcurrent element
- 51R = Line recloser phase time-overcurrent element (phase “slow curve”)

### Traditional Phase Coordination



**Figure F.3 Traditional Phase Coordination**


51F: pickup = 600 A (above max. feeder load,  $I_F$ )

51R: pickup = 200 A (above max. line recloser load,  $I_R$ )

*Figure F.3* shows traditional phase overcurrent element coordination between the feeder relay and line recloser phase overcurrent elements. Phase overcurrent elements must accommodate load and cold load pickup current. The 450 A maximum feeder load current limits the sensitivity of the feeder phase overcurrent element, 51F, to a pickup of 600 A. The feeder relay cannot back up the line recloser for phase faults below 600 A.

### Apply the Feeder Relay Negative-Sequence Overcurrent Element (Guidelines 1 to 3)

Applying negative-sequence overcurrent element coordination *Guideline 1* to *Guideline 3* results in the feeder relay “equivalent” phase overcurrent element (51EP) in *Figure F.4*. Curve for 51F is shown for comparison only.




**Figure F.4 Phase-to-Phase Fault Coordination**

51EP: pickup = 300 A (below max. feeder load,  $I_F$ )

Considerable improvement in sensitivity and speed of operation for phase-to-phase faults is achieved with the 51EP element. The 51EP element pickup of 300 A has twice the sensitivity of the 51F element pickup of 600 A. The 51EP element speed of operation for phase-to-phase faults below about 2000 A is faster than that for the 51F element.

### Convert “Equivalent” Phase Overcurrent Element Settings to Negative-Sequence Overcurrent Element Settings (Guideline 4)

The “equivalent” phase overcurrent element (51EP element in [Figure F.4](#)) converts to true negative-sequence overcurrent element settings (51QF in [Figure F.5](#)) by applying the equation given in guideline 4. The time dial (lever) and curve type of the element remain the same (if the element is a definite-time element, the time delay remains the same).



**Figure F.5 Negative-Sequence Overcurrent Element Derived From "Equivalent" Phase Overcurrent Element, 51EP**

$$51QF: \text{pickup} = \sqrt{3} \cdot (300 \text{ A}) = 520 \text{ A}$$

Having achieved coordination between the feeder relay negative-sequence overcurrent element (51QF) and the downstream line recloser phase overcurrent element (51R) for phase-to-phase faults, coordination between the two devices for other fault types is also achieved.

### Negative-Sequence Overcurrent Element Applied at a Distribution Bus (Guideline 5)

The preceding example was for a distribution feeder. A negative-sequence overcurrent element protecting a distribution bus provides an even more dramatic improvement in phase-to-phase fault sensitivity.

The distribution bus phase overcurrent element pickup must be set above the combined load of all the feeders on the bus, plus any emergency load conditions. The bus phase overcurrent element pickup is often set at least four times greater than the pickup of the feeder phase overcurrent element it backs up. Thus, sensitivity to both bus and feeder phase faults is greatly reduced. Feeder relay backup by the bus relay is limited.

Negative-sequence overcurrent elements at the distribution bus can be set significantly below distribution bus load levels and provide dramatically increased sensitivity to phase-to-phase faults. It is coordinated with the distribution feeder phase or negative-sequence overcurrent elements and provides more sensitive and faster phase-to-phase fault backup.

## Ground Coordination Concerns

If the downstream protective device includes ground overcurrent elements, in addition to phase overcurrent elements, there should be no need to check the coordination between the ground overcurrent elements and the upstream negative-sequence overcurrent elements. The downstream phase overcurrent element, whether it operates faster or slower than its complementary ground overcurrent element, will operate faster than the upstream negative-sequence overcurrent element for all faults, including those that involve ground.

## Other Negative-Sequence Overcurrent Element References

---

A. F. Elneweihi, E. O. Schweitzer, M. W. Feltis, “Negative-Sequence Overcurrent Element Application and Coordination in Distribution Protection,” IEEE Transactions on Power Delivery, Volume 8, Number 3, July 1993, pp. 915–924.

This IEEE paper is the source of the coordination guidelines and example given in this appendix. The paper also contains analyses of system unbalances and faults and the negative-sequence current generated by such conditions.

A. F. Elneweihi, “Useful Applications for Negative-Sequence Overcurrent Relaying,” 22nd Annual Western Protective Relay Conference, Spokane, Washington, October 24–26, 1995.

This conference paper gives many good application examples for negative-sequence overcurrent elements. The focus is on the transmission system, where negative-sequence overcurrent elements provide better sensitivity than zero-sequence overcurrent elements in detecting some single-line-to-ground faults.

**This page intentionally left blank**

# Appendix G

## Modbus RTU Communications Protocol

---

### Overview

---

This appendix describes Modbus® RTU communications features supported by the SEL-551 Relay. Complete specifications for the Modbus protocol are available from the Modicon website at [www.modicon.com](http://www.modicon.com).

Enable Modbus protocol using the serial port settings. When Modbus protocol is enabled, the relay switches the port to Modbus protocol and deactivates the ASCII protocol.

Modbus RTU is a binary protocol that permits communication between a single master device and multiple slave devices. The communication is half duplex; only one device transmits at a time. The master transmits a binary command that includes the address of the desired slave device. All of the slave devices receive the message, but only the slave device with the matching address responds.

The SEL-551 Modbus communication allows a Modbus master device to:

- Acquire metering, monitoring, and event data from the relay.
- Control SEL-551 output contacts.
- Read the SEL-551 self-test status and learn the present condition of all relay protection elements.

## Modbus RTU Communications Protocol

---

### Modbus Queries

Modbus RTU master devices initiate all exchanges by sending a query. The query consists of the fields shown in [Table G.1](#).

**Table G.1 Modbus Query Fields**

Field	Number of Bytes
Slave Device Address	1 byte
Function Code	1 byte
Data Region	0–251 bytes
Cyclical Redundancy Check (CRC)	2 bytes

The SEL-551 SLAVEID setting defines the device address. Set this value to a unique number for each device on the Modbus network. For Modbus communication to operate properly, no two slave devices may have the same address.

Function codes supported by the SEL-551 are described in [Table G.2](#).

The cyclical redundancy check detects errors in the received data. If an error is detected, the relay discards the packet.

## Modbus Responses

The slave device sends a response message after it performs the action requested in the query. If the slave cannot execute the command for any reason, it sends an error response. Otherwise, the slave device response is formatted similarly to the query including the slave address, function code, data (if applicable), and a cyclical redundancy check value.

## Supported Modbus Function Codes

The SEL-551 supports the Modbus function codes shown in [Table G.2](#).

**Table G.2 SEL-551 Modbus Function Codes**

Codes	Description
01h	Read Coil Status
02h	Read Input Status
03h	Read Holding Registers
04h	Read Input Registers
05h	Force Single Coil
06h	Preset Single Register
07h	Read Exception Status
08h	Loopback Diagnostic Command
10h	Preset Multiple Registers
64h	Scattered Register Read

## Modbus Exception Responses

The SEL-551 sends an exception code under the conditions described in [Table G.3](#).

**Table G.3 SEL-551 Modbus Exception Codes**

Exception Code	Error Type	Description
01	Illegal Function Code	The received function code is either undefined or unsupported.
02	Illegal Data Address	The received command contains an unsupported address in the data field.
03	Illegal Data Value	The received command contains a value that is out of range.
04	Device Error	The SEL-551 is in the wrong state for the requested function.
06	Busy	The SEL-551 is unable to process the command at this time due to a busy resource.

In the event that any of the errors listed in [Table G.3](#) occur, the relay assembles a response message that includes the exception code in the data field. The relay sets the most significant bit in the function code field to indicate to the master that the data field contains an error code, instead of the requested data.

## Cyclical Redundancy Check

The SEL-551 calculates a 2-byte CRC value using the device address, function code, and data fields. It appends this value to the end of every Modbus response. When the master device receives the response, it recalculates the CRC. If the calculated CRC matches the CRC sent by the

SEL-551, the master device uses the data received. If there is not a match, the check fails and the message is ignored. The devices use a similar process when the master sends queries.

## 01h Read Coil Status Command

Use function code 01h to read the On/Off status of the selected bits (coils). You may read the status of up to 2000 bits per query. Note that the relay coil addresses start at 0 (e.g., Coil 1 is located at address zero). The relay returns 8 bits per byte, most significant bit first, with zeroes padded into incomplete bytes.

**Table G.4 01h Read Coil Status Commands**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (01h)
2 bytes	Address of the First Bit
2 bytes	Number of Bits to Read
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (01h)
1 byte	Number Bytes of Data ( <i>n</i> )
<i>n</i> bytes	Data
2 bytes	CRC-16

To build the response, the relay calculates the number of bytes required to contain the number of bits requested. If the number of bits requested is not evenly divisible by 8, the relay adds one more byte to maintain the balance of bits, padded by zeroes to make an even byte.

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Invalid bit to read	Illegal Data Address (02h)	Invalid Address
Invalid number of bits to read	Illegal Data Value (03h)	Illegal Register
Format error	Illegal Data Value (03h)	Bad Packet Format

Please refer to [Table G.9](#) for coil number assignments.

## 02h Read Input Status Command

Use function code 02h to read the On/Off status of the selected bits (coils). You may read the status of up to 2000 bits per query. Note that the relay coil addresses start at 0 (e.g., Coil 1 is located at address zero). The relay returns 8 bits per byte, most significant bit first, with zeroes padded into incomplete bytes.

**Table G.5 02h Read Input Status Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (02h)
2 bytes	Address of the First Bit
2 bytes	Number of Bits to Read
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (02h)
1 byte	Number of Bytes of Data ( <i>n</i> )
<i>n</i> bytes	Data
2 bytes	CRC-16

To build the response, the relay calculates the number of bytes required to contain the number of bits requested. If the number of bits requested is not evenly divisible by 8, the relay adds one more byte to maintain the balance of bits, padded by zeroes to make an even byte.

Input numbers are defined below:

Input Numbers	Description
1	Input 1
2	Input 2

Input addresses start at 0000 (i.e., input 1 is located at Input Address 0000).

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Invalid bit to read	Illegal Data Address (02h)	Invalid Address
Invalid number of bits to read	Illegal Data Value (03h)	Illegal Register
Format error	Illegal Data Value (03h)	Bad Packet Format

## 03h Read Holding Register Command

Use function code 03h to read directly from the Modbus Register map shown in [Table G.18](#). You may read a maximum of 125 registers at once with this function code. Most masters use 4X references with this function code. If you are accustomed to 4X references with this function code, for 5 digit addressing, add 40001 to the standard database address.

**Table G.6 03h Read Holding Register Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (03h)
2 bytes	Starting Register Address
2 bytes	Number of Registers to Read
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (03h)
1 byte	Number of Bytes of Data ( <i>n</i> )
<i>n</i> bytes	Data
2 bytes	CRC-16

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Illegal register to read	Illegal Data Address (02h)	Invalid Address
Illegal number of registers to read	Illegal Data Value (03h)	Illegal Register
Format error	Illegal Data Value (03h)	Bad Packet Format

## 04h Read Input Registers Command

Use function code 04h to read from the Modbus Register map shown in [Table G.18](#). You may read a maximum of 125 registers at once with this function code.

**Table G.7 04h Read Holding Register Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (04h)
2 bytes	Starting Register Address
2 bytes	Number of Registers to Read
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (04h)
1 byte	Number of Bytes of Data ( <i>n</i> )
<i>n</i> bytes	Data
2 bytes	CRC-16

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Illegal register to read	Illegal Data Address (02h)	Invalid Address
Illegal number of registers to read	Illegal Data Value (03h)	Illegal Register
Format error	Illegal Data Value (03h)	Bad Packet Format

## 05h Force Single Coil Command

Use function code 05h to set or clear a coil.

**Table G.8 05h Force Single Coil Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (05h)
2 bytes	Coil Reference
1 byte	Operation Code (FF for bit set, 00 for bit clear)
1 byte	Placeholder (00)
2 bytes	CRC-16

The command response is identical to the command request.

The coil numbers supported by the SEL-551 are listed in [Table G.9](#). The physical coils (coils 1–5) are self resetting. Pulsing a set remote bit clears the remote bit.

**Table G.9 SEL-551 Command Coils (Sheet 1 of 2)**

Coil	Field
1	OUT1
2	OUT2
3	OUT3
4	OUT4
5	ALARM
6	RB1
7	RB2
8	RB3
9	RB4
10	RB5
11	RB6
12	RB7
13	RB8
14	Pulse RB1
15	Pulse RB2
16	Pulse RB3
17	Pulse RB4
18	Pulse RB5

**Table G.9 SEL-551 Command Coils (Sheet 2 of 2)**

Coil	Field
19	Pulse RB6
20	Pulse RB7
21	Pulse RB8

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Invalid bit (coil) number	Illegal Data Address (02h)	Invalid Address
Illegal bit state requested	Illegal Data Value (03h)	Illegal Function Code/Op Code
Format error	Illegal Data Value (03h)	Bad Packet Format

## 06h Preset Single Register Command

The SEL-551 uses this function to allow a Modbus master to write directly to a database register. If you are accustomed to 4X references with this function code, for 6-digit addressing, add 400001 to the standard database addresses.

**Table G.10 06h Preset Single Register Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (06h)
2 bytes	Register Address
2 bytes	Data
2 bytes	CRC-16

The command response is identical to the command request.

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Illegal register address	Illegal Data Address (02h)	Invalid Address Illegal Write
Illegal register value	Illegal Data Value (03h)	Illegal Write
Format error	Illegal Data Value (03h)	Bad Packet Format

## 07h Read Exception Status Command

The SEL-551 uses this function to allow a Modbus master to read the present status of the relay and protected circuit.

**Table G.11 07h Read Exception Status Command (Sheet 1 of 2)**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (07h)
0 bytes	No Data Fields Are Sent
2 bytes	CRC-16

**Table G.11 07h Read Exception Status Command (Sheet 2 of 2)**

Bytes	Field
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (07h)
1 byte	Status Byte
2 bytes	CRC-16
<b>The status byte is sent most significant bit first, and consists of the following bits:</b>	
Bit 0	OUT4 Status
Bit 1	OUT3 Status
Bit 2	OUT2 Status
Bit 3	OUT1 Status
Bit 4	Alarm Output status
Bit 5	Input 2 Status
Bit 6	Input 1 Status
Bit 7	Relay Status

If the bit is set to 1, the following are true:

- Output and Alarm contacts are asserted.
- Relay inputs are asserted.
- Relay is disabled.

If the bit is set to 0, the following are true:

- Output and Alarm contacts are deasserted.
- Relay inputs are deasserted.
- Relay is enabled.

The relay response to errors in the query is shown below:

Error	Error Code Returned	Communication Counter Increments
Format error	Illegal Data Value (03h)	Bad Packet Format

## 08h Loopback Diagnostic Command

The SEL-551 uses this function to allow a Modbus master to perform a diagnostic test on the Modbus communications channel and relay. When the subfunction field is 0000h, the relay returns a replica of the received message.

**Table G.12 08h Loopback Diagnostic Command (Sheet 1 of 2)**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (08h)
2 bytes	Subfunction (0000h)

**Table G.12 08h Loopback Diagnostic Command (Sheet 2 of 2)**

Bytes	Field
2 bytes	Data Field
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (08h)
2 bytes	Subfunction (0000h)
2 bytes	Data Field (identical to data in Master request)
2 bytes	CRC-16

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Illegal subfunction code	Illegal Data Value (03h)	Illegal Function Code/Op Code
Format error	Illegal Data Value (03h)	Bad Packet Format

## 10h Preset Multiple Registers Command

This function code works much like code 06h, except that it allows you to write multiple registers at once, up to 100 per operation. If you are accustomed to 4X references with the function code, for 6-digit addressing, simply add 400001 to the standard database addresses.

**Table G.13 10h Preset Multiple Registers Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (10h)
2 bytes	Starting Address
2 bytes	Number of Registers to Write
1 byte	Number of Bytes of Data ( <i>n</i> )
<i>n</i> bytes	Data
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (10h)
2 bytes	Starting Address
2 bytes	Number of Registers
2 bytes	CRC-16

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Illegal register to set	Illegal Data Address (02h)	Invalid Address Illegal Write
Illegal number of registers to set	Illegal Data Value (03h)	Illegal Register Illegal Write
Incorrect number of bytes in query data region	Illegal Data Value (03h)	Bad Packet Format Illegal Write
Invalid register data value	Illegal Data Value (03h)	Illegal Write

## 64h Scattered Register Read

The SEL-551 uses this function to allow a Modbus master to read noncontiguous registers in a single request. A maximum of 100 registers can be read in a single query.

**Table G.14 64h Scattered Register Read Command**

Bytes	Field
<b>Requests from the master must have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (64h)
1 byte	Query Data Length
1 byte	Subfunction Code (04h) <sup>a</sup>
1 byte	Transmission Number
2 bytes	Address of First Register
2 bytes	Address of Second Register
•	•
•	•
•	•
2 bytes	Address of <i>n</i> th Register
2 bytes	CRC-16
<b>A successful response from the slave will have the following format:</b>	
1 byte	Slave Address
1 byte	Function Code (64h)
1 byte	Response Data Length
1 byte	Subfunction Code (04h) <sup>a</sup>
1 byte	Transmission Number
2 bytes	Data from First Register
2 bytes	Data from Second Register
•	•
•	•
•	•
2 bytes	Data from <i>n</i> th Register
2 bytes	CRC-16

<sup>a</sup> Only subfunction 04h is supported.

The relay responses to errors in the query are shown below:

Error	Error Code Returned	Communication Counter Increments
Incorrect/Illegal query data length	Illegal Data Value (03h)	Bad Packet Format
Invalid subfunction code	Illegal Data Value (03h)	Illegal Function Code/Op Code
Illegal register address	Illegal Data Address (02h)	Invalid Address

## Controlling Output Contacts

The SEL-551 Modbus Register Map ([Table G.18](#)) includes three fields that allow a Modbus master to force the relay to perform a variety of operations. Use Modbus function codes 06h or 10h to write the appropriate command codes and parameters into the registers shown in [Table G.15](#). If function code 06h is used to write to a command code that has parameters, the parameters must be written before the command code.

**Table G.15 SEL-551 Modbus Command Region**

Address	Field
0090h	Command Code
0091h	Parameter 1
0092h	Parameter 2

[Table G.16](#) defines the command codes, their function and associated parameters, and the Modbus function code used to initiate the related command code.

**Table G.16 Modbus Command Codes**

Command Code	Function	Parameter Definition	Modbus Function Code
01	Open	No Parameter	06h, 10h
02	Close	No Parameter	06h, 10h
03	Reset Targets	No Parameter	06h, 10h
04	Trigger	No Parameter	06h, 10h
05	Pulse OUT1	1–30 seconds duration (defaults to 1 second)	06h, 10h
06	Pulse OUT2	1–30 seconds duration (defaults to 1 second)	06h, 10h
07	Pulse OUT3	1–30 seconds duration (defaults to 1 second)	06h, 10h
08 <sup>a</sup>	Pulse OUT4	1–30 seconds duration (defaults to 1 second)	06h, 10h
09 <sup>a</sup>	Pulse Alarm	1–30 seconds duration (defaults to 1 second)	06h, 10h
10	Switch Protocol <sup>b</sup>	0080h	06h, 10h
11 <sup>c</sup>	Reset Data Regions	0000 0000 0000 0001 Demand Metering 0000 0000 0000 0010 Peak Metering 0000 0000 0000 0100 History Buffer 0000 0000 0000 1000 Communication Counters	06h, 10h

<sup>a</sup> SEL-551 only.

<sup>b</sup> Switches the serial port protocol to SEL ASCII, the baud rate, parity, stop bits, and flow control remain the same.

<sup>c</sup> Parameter of Command code 11 is bit masked to allow you to manipulate several data regions simultaneously.

## Remote Bits

Command Code 0Ch-Control Remote Bits:

This code controls the remote bits. This command code has two parameters.

Parameter 1 determines the bit operation.

Value	Operation
1	Set
2	Clear
3	Pulse (1/8 cycle)

Parameter 2 determines which bit to control. It is bitmasked for future expansion, but only one bit can be controlled at a time. The highest numbered bit will be controlled if more than one bit occurs in the parameter.

Bit Pattern	Remote Bit
0000 0000 0000 0001	RB1
0000 0000 0000 0010	RB2
0000 0000 0000 0100	RB3
0000 0000 0000 1000	RB4
0000 0000 0001 0000	RB5
0000 0000 0010 0010	RB6
0000 0000 0100 0000	RB7
0000 0000 1000 0000	RB8

Error Codes:

- If the relay is disabled while the commands are issued, the relay will return error code 04 (device error).
- If the **TRIGGER** command cannot be executed due to multiple events in progress, the relay will return error code 06h (device busy).
- If the breaker jumper is not installed when a pulse output command is issued, the relay will return error code 04h (device error).

## Reading Event Data Using Modbus

The Modbus Register Map ([Table G.18](#)) provides a feature that allows you to download complete event data via Modbus. The SEL-551 stores the 20 latest 15-cycle, full-length event reports. Please refer to [Section 7: Standard Event Reports and SER](#) for more detailed description.

The event report will contain both analog and digital data. To download the event data using Modbus, proceed as follows:

- Step 1. Write the event number you wish to download at address 00B1h.
- Step 2. Write the channel number you wish to download at address 00B2h.
- Step 3. Read the four-sample per cycle event data from the Modbus Map.

**Table G.17 Assign Event Report Channel Using Address OOB2**

Set OOB2	To Read Data From Channel
1	IA
2	IB
3	IC
4	IN
5	IG
6	Relay Element Status Row 1 <sup>a</sup>
7	Relay Element Status Row 2 <sup>a</sup>
8	Relay Element Status Row 3 <sup>a</sup>
9	Relay Element Status Row 4 <sup>a</sup>
10	Relay Element Status Row 5 <sup>a</sup>
11	Relay Element Status Row 6 <sup>a</sup>
12	Relay Element Status Row 7 <sup>a</sup>
13	Relay Element Status Row 8 <sup>a</sup>
14	Relay Element Status Row 9 <sup>a</sup>
15	Relay Element Status Row 10 <sup>a</sup>
16	Relay Element Status Row 11 <sup>a</sup>
17	Relay Element Status Row 12 <sup>a</sup>
18	Relay Element Status Row 13 <sup>a</sup>

<sup>a</sup> Please refer to [Table 5.6](#) to obtain the contents of each relay element status row. Relay Element Status Row 0, which represents targets, is displayed at OOFB in the Modbus Map.

If the user selects an event number for which there are no data available, 8000h will be returned.

## Reading History Data Using Modbus

The Modbus Register Map ([Table G.18](#)) provides a feature that allows you to download complete history of the last 20 events via Modbus. The history contains the date and time stamp, type of event that triggered the report, and the targets. Please refer to Note 3 of the Modbus Map for a list of event types.

To download the history data using Modbus, write the event number (1–20) to address 00A1h. Then read the history of the specific event number you requested from the Modbus Map ([Table G.18](#)).

If the user selects a history number for which there are no data available, 8000h will be returned.

**Table G.18 Modbus Map (Sheet 1 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
<b>Relay ID</b>						
0000–0016	FID <sup>a</sup>	ASCII String	–	–	–	–
0017–0019	Revision <sup>a</sup>	ASCII String	–	–	–	–
001A–0022	Relay ID <sup>a</sup>	ASCII String	–	–	–	–
0023–002B	Terminal ID <sup>a</sup>	ASCII String	–	–	–	–

**Table G.18 Modbus Map (Sheet 2 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
002C	Reserved (see Note 1)					
002D	Device Tag # <sup>b</sup>	15043	–	–	–	–
002E	Feature Set ID <sup>b</sup>	0	–	–	–	–
002F	Reserved					
<b>Relay Status</b>						
0030	Channel IA offset value <sup>c</sup>	mV	–5000	5000	1	1
0031	Channel IA status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0032	Channel IB offset value <sup>c</sup>	mV	–5000	5000	1	1
0033	Channel IB status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0034	Channel IC offset value <sup>c</sup>	mV	–5000	–5000	1	1
0035	Channel IC status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0036	Channel IN offset value <sup>c</sup>	mV	–5000	5000	1	1
0037	Channel IN status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0038	(MOF) DC offset in A/D circuit when a grounded input is selected <sup>c</sup>	mV	–5000	5000	1	1
0039	MOF status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
003A	+5 V power supply voltage value <sup>b</sup>	V	0	600	1	0.01
003B	+5 V power <sup>b</sup> supply status message 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
003C	+5_REG power <sup>b</sup> supply value	V	0	600	1	0.01

**Table G.18 Modbus Map (Sheet 3 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
003D	+5_REG power supply status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
003E	–5_REG power supply value <sup>c</sup>	V	–600	0	1	0.01
003F	–5_REG power supply status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0040	+10_ps power supply value <sup>b</sup>	V	0	1500	1	0.01
0041	+10_ps power supply status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0042	–10_ps power supply value <sup>c</sup>	V	–1500	0	1	0.01
0043	–10_ps power supply status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0044	VBAT power supply value <sup>b</sup>	V	0	500	1	0.01
0045	VBAT power supply status message <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0046	TEMP in degrees Celsius <sup>c</sup>	°C	–100	100	1	1
0047	Temperature status <sup>b</sup> 0 = OK, 1 = Warn, 2 = Fail	–	–	–	–	–
0048	RAM status <sup>b</sup> 0 = OK, 2 = Fail	–	–	–	–	–
0049	ROM status <sup>b</sup> 0 = OK, 2 = Fail	–	–	–	–	–
004A	CR_RAM status <sup>b</sup> 0 = OK, 2 = Fail	–	–	–	–	–
004B	EEPROM status <sup>b</sup> 0 = OK, 2 = Fail	–	–	–	–	–

**Table G.18 Modbus Map (Sheet 4 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor	
			Low	High	Step		
004C	Enable status <sup>b</sup> 0 = relay enabled, 2 = relay disabled	–	–	–	–	–	
004D–004F	Reserved						
<b>Demand Meter</b>							
0050	Demand current phase A <sup>b</sup>	Amps	0	65535	1	1	
0051	Demand current phase B <sup>b</sup>	Amps	0	65535	1	1	
0052	Demand current phase C <sup>b</sup>	Amps	0	65535	1	1	
0053	Demand current I <sub>N</sub> <sup>b</sup>	Amps	0	65535	1	1	
0054	Demand residual current I <sub>G</sub> <sup>b</sup>	Amps	0	65535	1	1	
0055	Demand negative-sequence current 3I <sub>2</sub> <sup>b</sup>	Amps	0	65535	1	1	
<b>Last Reset Time and Date–Demand Metering</b>							
0056	Time	ss	0	59	1	1	
0057		mm	0	59	1	1	
0058		hh	0	23	1	1	
0059		Date	dd	1	31	1	1
005A			mm	1	12	1	1
005B			yyyy	1992	2999	1	1
<b>Peak Demand Meter</b>							
005C	Peak demand current phase A <sup>b</sup>	Amps	0	65535	1	1	
005D	Peak demand current phase B <sup>b</sup>	Amps	0	65535	1	1	
005E	Peak demand current phase C <sup>b</sup>	Amps	0	65535	1	1	
005F	Peak demand neutral current I <sub>N</sub> <sup>b</sup>	Amps	0	65535	1	1	
0060	Peak demand residual current I <sub>G</sub> <sup>b</sup>	Amps	0	65535	1	1	
0061	Peak demand negative-sequence current 3I <sub>2</sub> <sup>b</sup>	Amps	0	65535	1	1	
<b>Last Reset Time and Date–Peak Demand Metering</b>							
0062	Time	ss	0	59	1	1	
0063		mm	0	59	1	1	
0064		hh	0	23	1	1	
0065		Date	dd	1	31	1	1
0066			mm	1	12	1	1
0067			yyyy	1992	2999	1	1

**Table G.18 Modbus Map (Sheet 5 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
<b>Instantaneous Metering</b>						
0068	Inst. current phase A <sup>b</sup>	Amps	0	65535	1	1
0069	Inst. current phase A angle <sup>b</sup>	Degrees	0	36000	1	0.01
006A	Inst. current phase B <sup>b</sup>	Amps	0	65535	1	1
006B	Inst. current phase B angle <sup>b</sup>	Degrees	0	36000	1	0.01
006C	Inst. current phase C <sup>b</sup>	Amps	0	65535	1	1
006D	Inst. current phase C angle <sup>b</sup>	Degrees	0	36000	1	0.01
006E	Inst. neutral current <sup>b</sup>	Amps	0	65535	1	1
006F	Inst. neutral current angle <sup>b</sup>	Degrees	0	36000	1	0.01
0070	Inst. residual current <sup>b</sup>	Amps	0	65535	1	1
0071	Inst. residual current angle <sup>b</sup>	Degrees	0	36000	1	0.01
0072	Inst. negative-sequence current <sup>b</sup>	Amps	0	65535	1	1
0073	Inst. neg.-seq. current angle <sup>b</sup>	Degrees	0	36000	1	0.01
0074	Reserved					
0075	Reserved					
<b>Relay Time and Date</b>						
0076 (RW) (see Note 2)	Time <sup>b</sup>	ss	0	59	1	1
0077 (RW)	b	mm	0	59	1	1
0078 (RW)	b	hh	0	23	1	1
0079 (RW)	Date <sup>b</sup>	dd	1	31	1	1
007A (RW)	b	mm	1	12	1	1
007B (RW)	b	yyyy	1992	2999	1	1
007C–007F	Reserved					
<b>Relay Word</b>						
0080	Targets  Bit 0 = 1 if any of bits 8–15 are set to 1  Bit 0 = 0 if any of bits 8–15 are set to 0  Bits 1–7 = 0  Bit 8 = LO  Bit 9 = RS  Bit 10 = Phase N 51/50					

**Table G.18 Modbus Map (Sheet 6 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor	
			Low	High	Step		
0081	Bit 11 = Phase C 51/50						
	Bit 12 = Phase B 51/50						
	Bit 13 = Phase A 51/50						
	Bit 14 = Inst.						
	Bit 15 = Enable						
	Contact Status						
	Bit 0 = 1 if any of bits 1–15 are set to 1						
	Bit 0 = 0 if all of bits 1–15 are set to 0						
	Bits 1–7 = 0						
	Bit 8 = OUT4						
	Bit 9 = OUT3						
	Bit 10 = OUT2						
	Bit 11 = OUT1						
	Bit 12 = Alarm						
	Bit 13 = IN2						
Bit 14 = IN1							
Bit 15 = 0							
0082	Row 1						
	Bit 0 = 1 if any of bits 8–15 are set to 1						
	Bit 0 = 0 if all of bits 8–15 are set to 0						
	Bits 1–7 = 0						
	Bit 8 = 51G1T						
	Bit 9 = 51N1T						
	Bit 10 = 51P2T						
	Bit 11 = 51P1T						
	Bit 12 = 51G1						
	Bit 13 = 51N1						
	Bit 14 = 51P2						
	Bit 15 = 51P1						
	0083	Row 2					
		Bit 0 = 1 if any of bits 8–15 are set to 1					

**Table G.18 Modbus Map (Sheet 7 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
0084	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = 50P4					
	Bit 9 = 50P3					
	Bit 10 = 50P2					
	Bit 11 = 50P1					
	Bit 12 = 51Q2T					
	Bit 13 = 51Q1T					
	Bit 14 = 51Q2					
	Bit 15 = 51Q1					
	Row 3					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = 50Q2					
Bit 9 = 50Q1						
Bit 10 = 50G2						
Bit 11 = 50G1						
Bit 12 = 50N2						
Bit 13 = 50N1						
Bit 14 = 50P6						
Bit 15 = 50P5						
0085	Row 4					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = CF					
	Bit 9 = CC					
	Bit 10 = OC					
	Bit 11 = IN2					
	Bit 12 = IN1					
	Bit 13 = 50C					
	Bit 14 = 50B					

**Table G.18 Modbus Map (Sheet 8 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
0086	Bit 15 = 50A					
	Row 5					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = LB8					
	Bit 9 = LB7					
	Bit 10 = LB6					
	Bit 11 = LB5					
	Bit 12 = LB4					
	Bit 13 = LB3					
	Bit 14 = LB2					
	Bit 15 = LB1					
0087	Row 6					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = RB8					
	Bit 9 = RB7					
	Bit 10 = RB6					
	Bit 11 = RB5					
	Bit 12 = RB4					
	Bit 13 = RB3					
	Bit 14 = RB2					
	Bit 15 = RB1					
	0088	Row 7				
Bit 0 = 1 if any of bits 8–15 are set to 1						
Bit 0 = 0 if all of bits 8–15 are set to 0						
Bits 1–7 = 0						
Bit 8 = SV8						
Bit 9 = SV7						
Bit 10 = SV6						

**Table G.18 Modbus Map (Sheet 9 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor	
			Low	High	Step		
0089	Bit 11 = SV5						
	Bit 12 = SV4						
	Bit 13 = SV3						
	Bit 14 = SV2						
	Bit 15 = SV1						
	Row 8						
	Bit 0 = 1 if any of bits 8–15 are set to 1						
	Bit 0 = 0 if all of bits 8–15 are set to 0						
	Bits 1–7 = 0						
	Bit 8 = 0						
	Bit 9 = 0						
	Bit 10 = SV14						
	Bit 11 = SV13						
	Bit 12 = SV12						
	Bit 13 = SV11						
Bit 14 = SV10							
Bit 15 = SV9							
008A	Row 9						
	Bit 0 = 1 if any of bits 8–15 are set to 1						
	Bit 0 = 0 if all of bits 8–15 are set to 0						
	Bits 1–7 = 0						
	Bit 8 = SH4						
	Bit 9 = SH3						
	Bit 10 = SH2						
	Bit 11 = SH1						
	Bit 12 = SH0						
	Bit 13 = 79LO						
	Bit 14 = 79CY						
	Bit 15 = 79RS						
	008B	Row 10					
		Bit 0 = 1 if any of bits 8–15 are set to 1					
		Bit 0 = 0 if all of bits 8–15 are set to 0					

**Table G.18 Modbus Map (Sheet 10 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
008C	Bits 1–7 = 0					
	Bit 8 = 51Q2R					
	Bit 9 = 51Q1R					
	Bit 10 = 51G1R					
	Bit 11 = 51N1R					
	Bit 12 = 51P2R					
	Bit 13 = 51P1R					
	Bit 14 = CLOSE					
	Bit 15 = TRIP					
	Row 11					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
Bit 0 = 0 if all of bits 8–15 are set to 0						
Bits 1–7 = 0						
Bit 8 = SV12T						
Bit 9 = SV11T						
Bit 10 = SV10T						
Bit 11 = SV9T						
Bit 12 = SV8T						
Bit 13 = SV7T						
Bit 14 = SV6T						
Bit 15 = SV5T						
008D	Row 12					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bits 1–7 = 0					
	Bit 8 = OUT4					
	Bit 9 = OUT3					
	Bit 10 = OUT2					
	Bit 11 = OUT1					
	Bit 12 = Alarm					
	Bit 13 = 0					
	Bit 14 = SV14T					
Bit 15 = SV13T						

**Table G.18 Modbus Map** (Sheet 11 of 15)

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
008E	Row 13  Bit 0 = 1 if any of bits 8–15 are set to 1  Bit 0 = 0 if all of bits 8–15 are set to 0  Bits 1–7 = 0  Bit 8 = 0  Bit 9 = 0  Bit 10 = 0  Bit 11 = TRGTR  Bit 12 = QDEM  Bit 13 = GDEM  Bit 14 = NDEM  Bit 15 = PDEM					
<b>Commands (see Note 5)</b>						
0090 (W)	Command Code		1	12		
0091 (W)	Parameter 1					
0092 (W)	Parameter 2					
0093–009F	Reserved					
<b>History Records</b>						
00A0	Number of History Records <sup>b</sup>		1	20	1	1
00A1 (RW)	History Selection <sup>b</sup>		1	20	1	1
00A2	Event Time <sup>b</sup>	millisec	0	999	1	1
00A3	b	ss	0	59	1	1
00A4	b	mm	0	59	1	1
00A5	b	hh	0	23	1	1
00A6	Event Date <sup>b</sup>	dd	1	31	1	1
00A7	b	mm	1	12	1	1
00A8	b	yyyy	1992	2999	1	1
00A9	Event Type <sup>a</sup>	ASCII string				
00AA		see Note 3				
00AB						
00AC						
00AD	Shot		0	4	1	1
00AE	Maximum phase current		0	65535	1	1
00AF	Targets					

**Table G.18 Modbus Map (Sheet 12 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
	Bit 0 = 1 if any of bits 8–15 are set to 1 Bit 0 = 0 if all of bits 8–15 are set to 0 Bit 1–7 = 0 Bit 8 = LO Bit 9 = RS Bit 10 = Phase N 51/50 Bit 11 = Phase C 51/50 Bit 12 = Phase B 51/50 Bit 13 = Phase A 51/50 Bit 14 = Inst. Bit 15 = 0					
<b>Event Reporting (see Note 4)</b>						
00B0	Number event records <sup>b</sup>	–	1	20	1	1
00B1	Event selection <sup>b</sup>	–	1	20	1	1
00B2	Channel selection <sup>b</sup>	–	1	18	1	1
00B3	1/4 cycle <sup>c</sup>		–32767	32767	1	1
00B4	1/2 cycle <sup>c</sup>		–32767	32767	1	1
00B5	3/4 cycle <sup>c</sup>		–32767	32767	1	1
00B6	1 cycle <sup>c</sup>		–32767	32767	1	1
00B7	1 1/4 cycle <sup>c</sup>		–32767	32767	1	1
00B8	1 1/2 cycle <sup>c</sup>		–32767	32767	1	1
00B9	1 3/4 cycle <sup>c</sup>		–32767	32767	1	1
00BA	2 cycle <sup>c</sup>		–32767	32767	1	1
00BB	2 1/4 cycle <sup>c</sup>		–32767	32767	1	1
00BC	2 1/2 cycle <sup>c</sup>		–32767	32767	1	1
00BD	2 3/4 cycle <sup>c</sup>		–32767	32767	1	1
00BE	3 cycle <sup>c</sup>		–32767	32767	1	1
00BF	3 1/4 cycle <sup>c</sup>		–32767	32767	1	1
00C0	3 1/2 cycle <sup>c</sup>		–32767	32767	1	1
00C1	3 3/4 cycle <sup>c</sup>		–32767	32767	1	1
00C2	4 cycle <sup>c</sup>		–32767	32767	1	1
00C3	4 1/4 cycle <sup>c</sup>		–32767	32767	1	1
00C4	4 1/2 cycle <sup>c</sup>		–32767	32767	1	1
00C5	4 3/4 cycle <sup>c</sup>		–32767	32767	1	1

**Table G.18 Modbus Map (Sheet 13 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
00C6	5 cycle <sup>c</sup>		-32767	32767	1	1
00C7	5 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00C8	5 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00C9	5 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00CA	6 cycle <sup>c</sup>		-32767	32767	1	1
00CB	6 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00CC	6 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00CD	6 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00CE	7 cycle <sup>c</sup>		-32767	32767	1	1
00CF	7 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00D0	7 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00D1	7 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00D2	8 cycle <sup>c</sup>		-32767	32767	1	1
00D3	8 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00D4	8 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00D5	8 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00D6	9 cycle <sup>c</sup>		-32767	32767	1	1
00D7	9 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00D8	9 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00D9	9 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00DA	10 cycle <sup>c</sup>		-32767	32767	1	1
00DB	10 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00DC	10 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00DD	10 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00DE	11 cycle <sup>c</sup>		-32767	32767	1	1
00DF	11 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00E0	11 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00E1	11 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00E2	12 cycle <sup>c</sup>		-32767	32767	1	1
00E3	12 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00E4	12 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00E5	12 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00E6	13 cycle <sup>c</sup>		-32767	32767	1	1
00E7	13 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00E8	13 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00E9	13 3/4 cycle <sup>c</sup>		-32767	32767	1	1
00EA	14 cycle <sup>c</sup>		-32767	32767	1	1
00EB	14 1/4 cycle <sup>c</sup>		-32767	32767	1	1
00EC	14 1/2 cycle <sup>c</sup>		-32767	32767	1	1
00ED	14 3/4 cycle <sup>c</sup>		-32767	32767	1	1

**Table G.18 Modbus Map (Sheet 14 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
00EE	15 cycle <sup>c</sup>		-32767	32767	1	1
<b>Event Summary Data</b>						
00EF	Event type <sup>a</sup>	ASCII string				
00F0		see Note 5				
00F1						
00F1						
<b>Date and Time</b>						
00F3	Event time <sup>b</sup>	millisec	0	999	1	1
00F4	b	ss	0	59	1	1
00F5	b	mm	0	59	1	1
00F6	b	hh	0	23	1	1
00F7	Event date <sup>b</sup>	dd	1	31	1	1
00F8	b	mm	1	12	1	1
00F9	b	yyyy	1992	2999	1	1
00FA	Shots		0	4		
00FB	Targets					
	Bit 0 = 1 if any of bits 8–15 are set to 1					
	Bit 0 = 0 if all of bits 8–15 are set to 0					
	Bit 1–7 = 0					
	Bit 8 = LO					
	Bit 9 = RS					
	Bit 10 = Phase N 51/50					
	Bit 11 = Phase C 51/50					
	Bit 12 = Phase B 51/50					
	Bit 13 = Phase A 51/50					
	Bit 14 = Inst.					
	Bit 15 = 0					
00FC	Event current phase A	Amps	0	65535	1	
00FD	Event current phase B	Amps	0	65535	1	
00FE	Event current phase C	Amps	0	65535	1	
00FF	Event neutral current IN	Amps	0	65535	1	
0100	Event residual current IG	Amps	0	65535	1	

**Table G.18 Modbus Map (Sheet 15 of 15)**

Address (Hex)	Field	Units	Range			Scale Factor
			Low	High	Step	
0101	Event neg.-seq. current IQ	Amps	0	65535	1	
0102–010F	Reserved					
<b>Maximum Current Limit</b>						
0110	Phase current <sup>d</sup>	Amps	–32767	32767	1	1
0111	Phase current <sup>e</sup>	Exponent	–4	4	1	1
0112	Neutral current <sup>d</sup>	Amps	–32767	32767	1	1
0113	Neutral current <sup>e</sup>	Exponent	–4	4	1	1
0114–011F	Reserved					
<b>Communication Counter</b>						
0120	Number of messages received <sup>b</sup>	–	0	65535	1	1
0121	Number of messages sent to other devices <sup>b</sup>	–	0	65535	1	1
0122	Invalid address <sup>b</sup>	–	0	65535	1	1
0123	Bad CRC <sup>b</sup>	–	0	65535	1	1
0124	UART error <sup>b</sup>	–	0	65535	1	1
0125	Illegal function code/Op code <sup>b</sup>	–	0	65535	1	1
0126	Illegal register <sup>b</sup>	–	0	65535	1	1
0127	Illegal write <sup>b</sup>	–	0	65535	1	1
0128	Bad packet format <sup>b</sup>	–	0	65535	1	1
0129	Bad packet length <sup>b</sup>	–	0	65535	1	1
012A	Reserved					
	Reserved					
	Reserved					
1FFB	Device tag # <sup>b</sup>	15043	–	–	–	–
1FFC	Feature set ID <sup>b</sup>	0				
1FFD	Reserved					
	Reserved					
FFFF	Reserved					

<sup>a</sup> Two 8-bit ASCII characters per register.

<sup>b</sup> 16-bit unsigned value.

<sup>c</sup> 16-bit signed value.

<sup>d</sup> Two 16-bit registers needed to accomplish the Signed Integer Dynamic Fixed Point data format. Final value read = (R1 • 10<sup>R2</sup>).

<sup>e</sup> R1 is the content of register 0110h (0112h). R2, which is stored in 0111h (0113h), determines the decimal point position for the final value.

**NOTE 1:** Reserved addresses return 8000h.

**NOTE 2:** Registers (RW) are read-write registers. Registers (W) are write-only registers. All other registers are read-only.

**NOTE 3:** Event Types

TRIG	ER2
TRIP	PULSE
ERI	

**NOTE 4:** The Modbus map ([Table G.18](#)) provides a feature that allows you to download complete event data via Modbus. See [Table G.17](#) for data descriptions.

**NOTE 5:** Please refer to [Table G.16](#) for a list of Command Codes.

## General Comments

All registers are 16 bits with bit locations ranging from 0 to 15.

Relay words and targets are mapped in bit positions 8–15 in the register. Contact status is mapped in bit positions 7–15 in the register. The 0 bit position of this register is set equal to 1 if any of the 1–15 positions are set to 1.

# SEL-551 Command Summary

Access Level 0 Command	The only thing that can be done at Access level 0 is to go to Access Level 1. The screen prompt is: =
ACC	Enters Access Level 1. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 1 password in order to enter Access Level 1.
Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
2AC	Enters Access Level 2. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 2 password in order to enter Access Level 2.
DAT	Shows date presently in the relay.
DAT <i>m/d/y</i>	Enters date in this manner if Date Format setting DATE_F = MDY.
DAT <i>y/m/d</i>	Enters date in this manner if Date Format setting DATE_F = YMD.
EVE <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/4 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE C <i>n</i>	Causes the relay to add digital data at the end of the Event <i>n</i> report.
EVE L <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/8 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE L C <i>n</i>	Causes the relay to add digital data at the end of Event L <i>n</i> report.
EVE R <i>n</i>	Causes the relay to display an unfiltered event report with 1/16-cycle resolution.
EVE R C <i>n</i>	Causes the relay to add digital data at the end of the Event R <i>n</i> report.
HIS <i>n</i>	Shows brief summary of the <i>n</i> latest standard 15-cycle event reports.
HIS C	Clears the brief summary and corresponding standard 15-cycle event reports.
IRI	Forces synchronization attempt of internal relay clock to IRIG-B time-code input.
MET <i>k</i>	Displays metering data, both magnitude and phase angle. Phase angles are referenced to phase input IA. Enter number <i>k</i> to scroll metering <i>k</i> times on screen.
MET D	Displays demand and peak demand data. Select <b>MET RD</b> or <b>MET RP</b> to reset.
QUI	Quit. Returns to Access Level 0. Returns front-panel LEDs to the default targets (corresponding to command <b>TAR 0</b> ).
SER <i>n</i>	Show the latest <i>n</i> rows in the Sequential Events Recorder (SER) event report.
SER <i>m n</i>	Show rows <i>m</i> through <i>n</i> in the Sequential Events Recorder (SER) event report.
SER <i>d1</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> .
SER <i>d1 d2</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> to <i>d2</i> . Entry of dates is dependent on the Date Format setting DATE_F (= MDY or YMD).
SER C	Clears the Sequential Events Recorder (SER) event report.
SHO	Show relay settings (overcurrent, reclosing, timers, etc.).
SHO L	Show SELOGIC® control equation settings.
SHO P	Show port settings
SHO R	Show Sequential Events Recorder (SER) settings.
SHO T	Show text label settings.
STA	Show relay self-test status. <b>STA C</b> resets self-test warnings/failures.
TAR R	Return front-panel LED targets to regular operation and reset the <b>FAULT TYPE</b> front-panel targets.
TAR 0 <i>k</i>	Return front-panel LED targets to regular operation. Enter number <i>k</i> to scroll front-panel LED status <i>k</i> times on screen.

Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
<b>TAR <i>n k</i></b>	Display Relay Word row <i>n</i> status ( <i>n</i> = 1–15) on remapped front-panel LED targets. Enter number <i>k</i> to scroll Relay Word row <i>n</i> status <i>k</i> times on screen.
<b>TAR <i>n X</i></b>	Relay Word row <i>n</i> status ( <i>n</i> = 1–15) is sent to the serial port/computer screen, but the front-panel LED targets remain unchanged.
<b>TIM</b>	Show or set time (24-hour time). Show time presently in the relay by entering just <b>TIM</b> . Example time 22:47:36 is entered with command <b>TIM 22:47:36</b> .
<b>TRI</b>	Trigger an event report.

Access Level 2 Commands	The Access Level 2 commands primarily allow the user to change settings or operate relay parameters and output contacts. All Access Level 1 commands can also be executed from Access Level 2. The screen prompt is: =>>
<b>CAL</b>	Enter Access Level C. If the main board Access jumper is not in place, the relay prompts for the entry of the Access Level C password. Access Level C is reserved for SEL use only.
<b>CLO</b>	Assert the CLOSE Relay Word bit. If CLOSE is assigned to an output contact (e.g., OUT2 = CLOSE), then the output contact will assert if command <b>CLO</b> is executed and the circuit breaker is open.
<b>CON <i>n</i></b>	Control Relay Word bit <i>RB<sub>n</sub></i> (Remote Bit <i>n</i> ; <i>n</i> = 1–8). Execute <b>CON <i>n</i></b> and the relay responds: CONTROL <i>RB<sub>n</sub></i> . Then reply with one of the following: <b>SRB <i>n</i></b> set Remote Bit <i>n</i> (assert <i>RB<sub>n</sub></i> ) <b>CRB <i>n</i></b> clear Remote Bit <i>n</i> (deassert <i>RB<sub>n</sub></i> ) <b>PRB <i>n</i></b> pulse Remote Bit <i>n</i> [assert <i>RB<sub>n</sub></i> for one processing interval (1/8 cycle)].
<b>OPE</b>	Assert the TRIP Relay Word bit. If TRIP is assigned to an output contact (e.g., OUT1 = TRIP), then the output contact will assert if command <b>OPE</b> is executed.
<b>PAS 1</b>	Change Access Level 1 password.
<b>PAS 2</b>	Change Access Level 2 password.
<b>PAS C</b>	Change Access Level C password.
<b>PUL <i>n k</i></b>	Pulse output contact <i>n</i> ( <i>n</i> = OUT1, OUT2, OUT3, OUT4, and ALARM). Enter number <i>k</i> to pulse for <i>k</i> seconds [ <i>k</i> = 1 to 30 (seconds)], otherwise pulse time is 1 second.
<b>SET <i>n</i></b>	Change relay settings (overcurrent, reclosing, timers, etc.).
<b>SET L <i>n</i></b>	Change SELOGIC control equations settings.
<b>SET P <i>n</i></b>	Change port settings
<b>SET R <i>n</i></b>	Change Sequential Events Recorder (SER) settings.
<b>SET T <i>n</i></b>	Change text label settings.
<b>VER</b>	For the <b>SET</b> commands, jump to parameter <i>n</i> to begin setting editing. If parameter <i>n</i> is not entered, setting editing starts at the first setting. Show relay configuration and firmware version.

# SEL-551 Command Summary

Access Level 0 Command	The only thing that can be done at Access level 0 is to go to Access Level 1. The screen prompt is: =
ACC	Enters Access Level 1. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 1 password in order to enter Access Level 1.
Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
2AC	Enters Access Level 2. If the main board password jumper is not in place, the relay prompts for the entry of the Access Level 2 password in order to enter Access Level 2.
DAT	Shows date presently in the relay.
DAT <i>m/d/y</i>	Enters date in this manner if Date Format setting DATE_F = MDY.
DAT <i>y/m/d</i>	Enters date in this manner if Date Format setting DATE_F = YMD.
EVE <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/4 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE C <i>n</i>	Causes the relay to add digital data at the end of the Event <i>n</i> report.
EVE L <i>n</i>	Shows standard 15-cycle event report number <i>n</i> , with 1/8 cycle resolution ( <i>n</i> = 1–20, with <i>n</i> = 1 most recent).
EVE L C <i>n</i>	Causes the relay to add digital data at the end of Event L <i>n</i> report.
EVE R <i>n</i>	Causes the relay to display an unfiltered event report with 1/16-cycle resolution.
EVE R C <i>n</i>	Causes the relay to add digital data at the end of the Event R <i>n</i> report.
HIS <i>n</i>	Shows brief summary of the <i>n</i> latest standard 15-cycle event reports.
HIS C	Clears the brief summary and corresponding standard 15-cycle event reports.
IRI	Forces synchronization attempt of internal relay clock to IRIG-B time-code input.
MET <i>k</i>	Displays metering data, both magnitude and phase angle. Phase angles are referenced to phase input IA. Enter number <i>k</i> to scroll metering <i>k</i> times on screen.
MET D	Displays demand and peak demand data. Select <b>MET RD</b> or <b>MET RP</b> to reset.
QUI	Quit. Returns to Access Level 0. Returns front-panel LEDs to the default targets (corresponding to command <b>TAR 0</b> ).
SER <i>n</i>	Show the latest <i>n</i> rows in the Sequential Events Recorder (SER) event report.
SER <i>m n</i>	Show rows <i>m</i> through <i>n</i> in the Sequential Events Recorder (SER) event report.
SER <i>d1</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> .
SER <i>d1 d2</i>	Show rows in the Sequential Events Recorder (SER) event report from date <i>d1</i> to <i>d2</i> . Entry of dates is dependent on the Date Format setting DATE_F (= MDY or YMD).
SER C	Clears the Sequential Events Recorder (SER) event report.
SHO	Show relay settings (overcurrent, reclosing, timers, etc.).
SHO L	Show SELOGIC® control equation settings.
SHO P	Show port settings
SHO R	Show Sequential Events Recorder (SER) settings.
SHO T	Show text label settings.
STA	Show relay self-test status. <b>STA C</b> resets self-test warnings/failures.
TAR R	Return front-panel LED targets to regular operation and reset the <b>FAULT TYPE</b> front-panel targets.
TAR 0 <i>k</i>	Return front-panel LED targets to regular operation. Enter number <i>k</i> to scroll front-panel LED status <i>k</i> times on screen.

Access Level 1 Command	The Access Level 1 commands primarily allow the user to look at information (e.g., settings, metering, etc.), not change it. The screen prompt is: =>
<b>TAR <i>n k</i></b>	Display Relay Word row <i>n</i> status ( <i>n</i> = 1–15) on remapped front-panel LED targets. Enter number <i>k</i> to scroll Relay Word row <i>n</i> status <i>k</i> times on screen.
<b>TAR <i>n X</i></b>	Relay Word row <i>n</i> status ( <i>n</i> = 1–15) is sent to the serial port/computer screen, but the front-panel LED targets remain unchanged.
<b>TIM</b>	Show or set time (24-hour time). Show time presently in the relay by entering just <b>TIM</b> . Example time 22:47:36 is entered with command <b>TIM 22:47:36</b> .
<b>TRI</b>	Trigger an event report.

Access Level 2 Commands	The Access Level 2 commands primarily allow the user to change settings or operate relay parameters and output contacts. All Access Level 1 commands can also be executed from Access Level 2. The screen prompt is: =>>
<b>CAL</b>	Enter Access Level C. If the main board Access jumper is not in place, the relay prompts for the entry of the Access Level C password. Access Level C is reserved for SEL use only.
<b>CLO</b>	Assert the CLOSE Relay Word bit. If CLOSE is assigned to an output contact (e.g., OUT2 = CLOSE), then the output contact will assert if command <b>CLO</b> is executed and the circuit breaker is open.
<b>CON <i>n</i></b>	Control Relay Word bit <i>RB<sub>n</sub></i> (Remote Bit <i>n</i> ; <i>n</i> = 1–8). Execute <b>CON <i>n</i></b> and the relay responds: CONTROL <i>RB<sub>n</sub></i> . Then reply with one of the following: <b>SRB <i>n</i></b> set Remote Bit <i>n</i> (assert <i>RB<sub>n</sub></i> ) <b>CRB <i>n</i></b> clear Remote Bit <i>n</i> (deassert <i>RB<sub>n</sub></i> ) <b>PRB <i>n</i></b> pulse Remote Bit <i>n</i> [assert <i>RB<sub>n</sub></i> for one processing interval (1/8 cycle)].
<b>OPE</b>	Assert the TRIP Relay Word bit. If TRIP is assigned to an output contact (e.g., OUT1 = TRIP), then the output contact will assert if command <b>OPE</b> is executed.
<b>PAS 1</b>	Change Access Level 1 password.
<b>PAS 2</b>	Change Access Level 2 password.
<b>PAS C</b>	Change Access Level C password.
<b>PUL <i>n k</i></b>	Pulse output contact <i>n</i> ( <i>n</i> = OUT1, OUT2, OUT3, OUT4, and ALARM). Enter number <i>k</i> to pulse for <i>k</i> seconds [ <i>k</i> = 1 to 30 (seconds)], otherwise pulse time is 1 second.
<b>SET <i>n</i></b>	Change relay settings (overcurrent, reclosing, timers, etc.).
<b>SET L <i>n</i></b>	Change SELOGIC control equations settings.
<b>SET P <i>n</i></b>	Change port settings
<b>SET R <i>n</i></b>	Change Sequential Events Recorder (SER) settings.
<b>SET T <i>n</i></b>	Change text label settings.
<b>VER</b>	For the <b>SET</b> commands, jump to parameter <i>n</i> to begin setting editing. If parameter <i>n</i> is not entered, setting editing starts at the first setting. Show relay configuration and firmware version.