

Orbit Operations Checklist

STS-124 Flight Supplement

**Mission Operations Directorate
Operations Division**

**Final
April 30, 2008**

National Aeronautics and
Space Administration

Lyndon B. Johnson Space Center
Houston, Texas




MISSION OPERATIONS DIRECTORATE

**ORBIT OPERATIONS CHECKLIST
STS-124 FLIGHT SUPPLEMENT**

FINAL
April 30, 2008


PREPARED BY:




Thomas R. Zulauf
Publication Manager

APPROVED BY:

ACCEPTED BY:



Kimberly A. Johnson
Manager, Shuttle
Procedures Management



Michael T. Hurt
FDF Manager

This document is under the configuration control of the Crew Procedures Control Board (CPCB). All proposed changes must be submitted via FDF Workflow Crew Procedure Change Request (CR) to DO3/FDF Manager.

Additional distribution of this book, for official use only, may be requested in writing to DO3/PMO Administrator. The request must include justification and requester's name, organization, position, and phone number. Contractor requests are made through the NASA or DOD organization supported. Deletions, reduction in quantity, or change of address may be submitted to DO3/FDF Management Office, 281-244-1184.

Incorporates the following:			
482#:	ORB OPS_FS-0059	ORB OPS_FS-0075	ORB OPS_FS-0080
	ORB OPS_FS-0072	ORB OPS_FS-0076	ORB OPS_FS-0081
	ORB OPS_FS-0073	ORB OPS_FS-0078	
	ORB OPS_FS-0074	ORB OPS_FS-0079	

AREAS OF TECHNICAL RESPONSIBILITY

Publication Manager	DO3/T. Zulauf	281-244-0922
Alternate Publication Manager	DO3/L. Giles	281-244-9068
COMM/INST	DS2/J. King	281-483-0776
PTG	DO4/S. Patano	281-244-1137
DAP TABLES	DS6/M. Hamilton	281-483-0944
REBOOST/DAP	DS6/M. Hamilton	281-483-0944
OIU	DS2/J. King	281-483-0776
PRLA	DS4/E. Eskola	281-483-4067
SDBI	SK/K. Ofori	281-244-0929
WLES	DO5/R. Carroll	281-244-0914
MAUI	DS6/M. Hamilton	281-483-0944

CUE CARDS:

LIOH CHANGEOUT	DS4/K. Rogers	281-483-1395
ORBIT BURN MONITOR	DS6/D. Lenort	281-483-2644
DAP TABLES	DS6/M. Hamilton	281-483-0944
MAUI – RCS FIRING SEQUENCE	DS6/M. Hamilton	281-483-0944
MIDODRINE PILL INGESTION	Lockheed Martin/P. Watters	281-218-3331

ORBIT OPERATIONS CHECKLIST
STS-124 FLIGHT SUPPLEMENT

LIST OF EFFECTIVE PAGES

FINAL 04/30/08

Sign Off	*	124/FIN	FS 4-3.....	124/FIN
FS ii	*	124/FIN	FS 4-4.....	124/FIN
FS iii	*	124/FIN	FS 4-5.....	124/FIN
FS iv	*	124/FIN	FS 4-6.....	124/FIN
FS v	*	124/FIN	FS 5-1.....	124/FIN
FS vi	*	124/FIN	FS 5-2.....	124/FIN
FS vii		124/FIN	FS 6-1.....	124/FIN
FS viii		124/FIN	FS 6-2.....	124/FIN
FS 1-1		124/FIN	FS 7-1.....	124/FIN
FS 1-2		124/FIN	FS 7-2.....	124/FIN
FS 1-3		124/FIN	FS 7-3.....	124/FIN
FS 1-4		124/FIN	FS 7-4.....	124/FIN
FS 1-5		124/FIN	FS 7-5.....	124/FIN
FS 1-6		124/FIN	FS 7-6.....	124/FIN
FS 1-7		124/FIN	FS 7-7.....	124/FIN
FS 1-8		124/FIN	FS 7-8.....	124/FIN
FS 2-1		124/FIN	FS 7-9.....	124/FIN
FS 2-2		124/FIN	FS 7-10.....	124/FIN
FS 2-3		124/FIN	FS 7-11.....	124/FIN
FS 2-4		124/FIN	FS 7-12.....	124/FIN
FS 3-1		124/FIN	FS 8-1.....	124/FIN
FS 3-2		124/FIN	FS 8-2.....	124/FIN
FS 3-3		124/FIN	FS 8-3.....	124/FIN
FS 3-4		124/FIN	FS 8-4.....	124/FIN
FS 3-5		124/FIN	FS 8-5.....	124/FIN
FS 3-6		124/FIN	FS 8-6.....	124/FIN
FS 3-7		124/FIN	FS 8-7.....	124/FIN
FS 3-8		124/FIN	FS 8-8.....	124/FIN
FS 4-1		124/FIN	FS 8-9.....	124/FIN
FS 4-2		124/FIN	FS 8-10.....	124/FIN

* – Omit from flight book

FS 8-11	124/FIN
FS 8-12	124/FIN
FS 8-13	124/FIN
FS 8-14	124/FIN
FS 8-15	124/FIN
FS 8-16	124/FIN
FS 8-17	124/FIN
FS 8-18	124/FIN
FS 9-1	124/FIN
FS 9-2	124/FIN
FS 9-3	124/FIN
FS 9-4	124/FIN
FS 9-5	124/FIN
FS 9-6	124/FIN
FS 10-1	124/FIN *
FS 10-2	124/FIN *
FS CC 10-3	124/FIN *
FS CC 10-4	124/FIN *
FS CC 10-5	124/FIN *
FS CC 10-6	124/FIN *
FS CC 10-7	124/FIN *
FS CC 10-8	124/FIN *
FS CC 10-9	124/FIN *
FS CC 10-10	124/FIN *
FS CC 10-11	124/FIN *
FS CC 10-12	124/FIN *
FS CC 10-13	124/FIN *
FS 10-14	124/FIN *


* – Omit from flight book

ORBIT OPS CUE CARDS

<u>Title</u>	<u>Ref. Page</u>	<u>Card No.</u>
LIOH CHANGEOUT FLIGHT DAY 3 DOCKING ORBITER WITH ISS (Front).....	FS CC 10-3	ORB OPS-29a/ nonRCRS/124/O/A
LIOH CANISTER STOWAGE LOCATIONS (Back)	FS CC 10-4	ORB OPS-29b/ nonRCRS/124/O/A
ORBIT BURN MONITOR (Front).....	FS CC 10-5	ORB OPS-31a/124/O/A
OMS FAILURES (Back).....	FS CC 10-6	ORB OPS-31b/124/O/A
STS-124 DAP CONFIGURATIONS (Front/Top).....	FS CC 10-7	ORB OPS-41a/124/O/A
(Front/Bottom)	FS CC 10-8	ORB OPS-41aa/124/O/A
(Back/Top)	FS CC 10-9	ORB OPS-41b/124/O/C
(Back/Bottom).....	FS CC 10-10	ORB OPS-41bb/124/O/C
MAUI – RCS FIRING SEQUENCE (Front).....	FS CC 10-11	ORB OPS-42a/124/O/A
(Back).....	FS CC 10-12	ORB OPS-42b/124/O/A
MIDODRINE PILL INGESTION (Front).....	FS CC 10-13	ORB OPS-45a/E/C



This Page Intentionally Blank



<u>CONTENTS</u>	<u>PAGE</u>
<u>COMM/INST</u>	FS 1-1
LOAD PCMMU FORMAT.....	FS 1-2
PDI DECOM FORMAT.....	FS 1-4
OIU FORMAT/CONFIG.....	FS 1-6
<u>PTG</u>	FS 2-1
STAR PAIRS PAD.....	FS 2-2
PAIRS.....	FS 2-3
<u>DAP TABLES</u>	FS 3-1
DAP OVERVIEW.....	FS 3-2
UNIV PTG.....	FS 3-3
STS-124 DAP A CONFIGURATIONS.....	FS 3-4
B CONFIGURATIONS.....	FS 3-6
<u>REBOOST/DAP</u>	FS 4-1
AUTO REBOOST.....	FS 4-2
ATTITUDE REFERENCE.....	FS 4-4
DOCKED DAP REFERENCE.....	FS 4-5
<u>OIU PROCEDURES</u>	FS 5-1
OIU ACTIVATION.....	FS 5-2
DEACTIVATION.....	FS 5-2
<u>PRLA</u>	FS 6-1
PRLA CLOSE.....	FS 6-2
<u>SHORT DURATION BIOASTRONAUTICS</u>	
<u>INVESTIGATION (SDBI)</u>	FS 7-1
SDBI 1634, SLEEP-WAKE ACTIGRAPHY.....	FS 7-2
SDBI 1900, INTEGRATED IMMUNE BLOOD	
COLLECTION.....	FS 7-3
SDBI 1900, SALIVA COLLECTION FOR	
INTEGRATED IMMUNE.....	FS 7-9

Cont next page

<u>WING LEADING EDGE SENSORS (WLES)</u>	
<u>PROCEDURES</u>	FS 8-1
WLES ACTIVATION AND CHECKOUT	FS 8-2
DEACTIVATION AND TEARDOWN	FS 8-10
LAPTOP RECEIVER UNIT (LRU) R&R	FS 8-12
CONFIGURE WLES DATA FILE BACKUP PATH	FS 8-14
PREP WLES LAPTOPS FOR TRANSFER	FS 8-15
WLES RNDZ TOOLS CHECKOUT PREP	FS 8-16
DOCK/UNDOCK RECOVERY	FS 8-16
DISABLE WLES FILE BACKUP	FS 8-17
ENABLE WLES FILE BACKUP	FS 8-17

<u>MAUI ANALYSIS OF UPPER-ATMOSPHERIC</u>	
<u>INJECTIONS (MAUI)</u>	FS 9-1
MAUI PROCEDURE	FS 9-2

<u>CUE CARD CONFIGURATION</u>	FS 10-1
LIOH CHANGEOUT FLIGHT DAY 3 DOCKING	
ORBITER WITH ISS (Front)	FS CC 10-3
LIOH CANISTER STOWAGE LOCATIONS	
(Back)	FS CC 10-4
ORBIT BURN MONITOR (Front)	FS CC 10-5
OMS FAILURES (Back)	FS CC 10-6
STS-124 DAP CONFIGURATIONS	
(Front/Top)	FS CC 10-7
(Front/Bottom)	FS CC 10-8
(Back/Top)	FS CC 10-9
(Back/Bottom)	FS CC 10-10
MAUI – RCS FIRING SEQUENCE (Front)	FS CC 10-11
(Back)	FS CC 10-12
MIDODRINE PILL INGESTION (Front)	FS CC 10-13

COMM/INST

LOAD PCMMU FORMAT.....	FS 1-2
PDI DECOM FORMAT	FS 1-4
OIU FORMAT/CONFIG.....	FS 1-6

**COMM/
INST**

COMM/
INST

LOAD PCMMU FORMAT

- C3 1. √OI PCMMU FORMAT – GPC
SM 62 PCMMU/PL COMM
- CRT 2. FORMAT:
SEL FXD – ITEM 1 EXEC (*)
SEL ID – ITEM 3 +X X X EXEC
3. √SM COMM BUF – RDY
LOAD – ITEM 4 EXEC
√LOAD, ITEM 4 – RUN,CPLT
- If LOAD – CPLT:
Repeat steps 2 and 3 for second ID
- * If LOAD – FAIL and ERR MSG – 'I/O ERR MMU 1(2)': *
 - * Go to 5.2a, 'I/O ERR MMU 1(2)' (MAL, *
DPS) >> *
 - * If LOAD – FAIL and a first load attempt: *
 - * Repeat steps 1 and 2 for failed ID *
 - * If LOAD – FAIL and a subsequent load *
 - * attempt: *
 - * √MCC *
 - * OI PCMMU PWR – 2(1) *
 - * √ERR MSG – 'I/O ERR PCM' *
 - C3 * I/O RESET PCM – ITEM 5 EXEC (*) *
 - CRT * Repeat steps 2 and 3 *
4. When final LOAD – CPLT:
SEL PGM – ITEM 2 EXEC (*)

DNLIST COMPATIBILITY	PHASE	FORMAT ID 64/128	CONFIG NO.
G1,G3,BFS	(ASCENT)	102/FXD	-
G3,BFS	(ENTRY)	102/164	-
G2,G8,S2	ORBIT/ORBIT BURN/FCS C/O	103/161	-
G2,S2,OPS 0	OPS 0	- /163	-
G2,S2,P9	MMU C/O	- /163	-
G9	Prelaunch PL C/O	103/180	758
G2,G8,S2	RNDZ w/UHF FMT CCSU (SSOR/SSV/TCS) (PRIME)	103/192	763
G2,G8,S2	RNDZ w/UHF FMT CCSU (SSOR/SSV/TCS) (B/U)	103/211	770
G2,G8,S2	DOCKED ISS FMT CCSH (OIU/SSV) (PRIME)	103/184	760
G2,G8,S2	DOCKED ISS FMT CCSH (OIU/SSV) (B/U)	103/205	767
G2,G8,S2	OIU C/O AND SSV RATE 4 (PRIME)	103/188	762
G2,G8,S2	OIU C/O AND SSV RATE 5 (B/U)	103/203	765

NOTE

LDR TFL may affect PCMMU BITE. If PCMMU or SM 2 GPC switched since last TFL, ID 64 and 128 will not reflect current state

LOAD PDI DECOM FORMAT

SM 62 PCMMU/PL COMM

1. PDI:

CRT √I/O RESET – ITEM 8 (*)
 SEL DECOM – ITEM 9 +X EXEC
 SEL FMT – ITEM 10 +X X X EXEC
 LOAD – ITEM 11 EXEC

If LOAD – CPLT:
 SEL INPUT – ITEM 12 +X EXEC
 LOAD – ITEM 13 EXEC
 Repeat step 1 for additional DECOMs/FPM

* If LOAD – FAIL and ERR MSG – 'I/O ERR *
* MMU 1(2)': *
* Go to 5.2a, 'I/O ERR MMU 1(2)' (MAL, *
* DPS) >> *
* *
* If LOAD – FAIL and a first load attempt: *
* Repeat step 1 *
* *
* If LOAD – FAIL and a subsequent load *
* attempt: *
* *
* NOTE *
* Power cycling PDI will cause PDI *
* to lose DFLs previously loaded *
* *
* √MCC *
A1L * S-BD PL CNTL – PNL *
* PL DATA INTLVR PWR – OFF,ON *
* √ERR MSG – 'S62 BCE BYP PL' *
* √'S62 BCE BYP PDI' *
* S-BD PL CNTL – CMD *
* *
* PCM: *
CRT * I/O RESET PCM – ITEM 5 EXEC (*) *
* PDI: *
* I/O RESET – ITEM 8 EXEC (*) *
* Repeat step 1 for all of config (XXX) *

CONFIG	DECOM	FMT	INPUT	USE
763 RNDZ w/UHF FMT CCSU (PRIME) TFL 192	1 2 3 4 5-FPM	30 - 9 4 503	1,2 - 5 4	OIU7 (CCSU) ** - TCS SSV (3) *** H-H-H *
770 RNDZ w/UHF FMT CCSU (BACKUP) TFL 211	1 2 3 4 5-FPM	14 31 - 19 502	4 1,2 - 5	SSV (3) *** OIU7 (CCSU) ** - TCS H-H-H *
760 DOCKED FMT CCSH (PRIME) TFL 184	1 2 3 4 5-FPM	7 - - 27 501	1,2 - - 4	OIU9 (CCSH) ** - - SSV (2) *** H-H-H *
767 DOCKED FMT CCSH (BACKUP) TFL 205	1 2 3 4 5-FPM	- 17 29 - 506	- 1,2 4 -	- OIU9 (CCSH) ** SSV (2) *** - H-H-H *
762 SSV RATE 4 (PRIME) TFL 188	1 2 3 4 5-FPM	5 - - 1 505	1,2 - - 4	OIU255 ** - - SSV (4) *** H-H-H *
765 SSV RATE 5 (BACKUP) TFL 203	1 2 3 4 5-FPM	- 15 11 - 507	- 1,2 4 -	- OIU255 ** SSV (5) *** - L-H-H *
758 Pre-Launch PL C/O (PRIME) TFL 180	1 2 3 4 5-FPM	28 15 9 - 504	1,2 1,2 5 -	OIU253 ** OIU255 ** TCS - H-H-H *

* OI-GNC-SM, Orbiter Downlist Data Rates (High or Low)
** # in OIU# represents the OIU format; (XXX) represents data type
*** # in SSV (#) represents the SSV Out Rate sw selection

LOAD OIU FORMAT/CONFIG

Determine which step is needed and complete all actions to obtain desired OIU configuration

NOTE

A corresponding TFL/DFL CONFIG is reqd for MCC to receive telemetry. Reference S62 PCMMU/PL COMM for the last loaded HDR TFL and perform LOAD PCMMU FORMAT/LOAD PDI DECOM FORMAT for the associated CONFIG

S212 OIU

1. GNC-1 PRIMARY ON LB-ORB N2-1 (OIU BUS 3)

LOAD FORMAT	ITEM 1 + <u>9</u> EXEC
GNC TO GNC 1	ITEM 18 + <u>1</u> <u>4</u> EXEC
GNC 1 TO BUS 3	ITEM 18 + <u>1</u> <u>6</u> EXEC
BUS 4 BC	ITEM 15 EXEC (*)
BUS 3 RT	ITEM 10 EXEC (*)
LOAD FORMAT	ITEM 1 + <u>9</u> EXEC >>

2. GNC-1 PRIMARY ON LB-ORB N2-2 (OIU BUS 4)

LOAD FORMAT	ITEM 1 + <u>9</u> EXEC
GNC TO GNC 1	ITEM 18 + <u>1</u> <u>4</u> EXEC
GNC 1 TO BUS 4	ITEM 18 + <u>1</u> <u>5</u> EXEC
BUS 3 BC	ITEM 11 EXEC (*)
BUS 4 RT	ITEM 14 EXEC (*)
LOAD FORMAT	ITEM 1 + <u>9</u> EXEC >>

3. GNC-2 PRIMARY ON LB-ORB N2-1 (OIU BUS 3)

LOAD FORMAT	ITEM 1 + <u>9</u> EXEC
GNC TO GNC 2	ITEM 18 + <u>1</u> <u>3</u> EXEC
GNC 2 TO BUS 3	ITEM 18 + <u>1</u> <u>8</u> EXEC
BUS 4 BC	ITEM 15 EXEC (*)
BUS 3 RT	ITEM 10 EXEC (*)
LOAD FORMAT	ITEM 1 + <u>9</u> EXEC >>

4. GNC-2 PRIMARY ON LB-ORB N2-2 (OIU BUS 4)

LOAD FORMAT	ITEM 1 + <u>9</u> EXEC
GNC TO GNC 2	ITEM 18 + <u>1</u> <u>3</u> EXEC
GNC 2 TO BUS 4	ITEM 18 + <u>1</u> <u>7</u> EXEC
BUS 3 BC	ITEM 11 EXEC (*)
BUS 4 RT	ITEM 14 EXEC (*)
LOAD FORMAT	ITEM 1 + <u>9</u> EXEC >>

Cont next page

5. MPLM (if flown)
LOAD FORMAT ITEM 1 +5 EXEC
BUS 2 BC ITEM 7 EXEC (*)
LOAD FORMAT ITEM 1 +5 EXEC >>
6. SSOR
LOAD FORMAT ITEM 1 +7 EXEC
BUS 1 BC ITEM 3 EXEC (*)
LOAD FORMAT ITEM 1 +7 EXEC >>



This Page Intentionally Blank



PTG

STAR PAIRS PAD FS 2-2
PAIRS..... FS 2-3

PTG

FS 2-1

ORB OPS/124/FIN

PTG

STAR PAIRS PAD										
STAR PAIR	SEP ANGLE	ATTITUDE SET 1					ATTITUDE SET 2			
		DUAL S TRK		SINGLE S TRK			DUAL S TRK		SINGLE S TRK	
				-Z	-Y	-Z			-Y	
A	92.1	-Y:53 R+ 295 -Z:22 P+ 225 Y+ 344	R+ 206 P+ 227 Y+ 359	-Z:53	R+ 28 P+ 241 Y+ 342	-Y:22	R+ 335 P+ 51 Y+ 359	-Z:53	R+ 247 P+ 43 Y+ 12	-Y:53 R+ 64 P+ 64 Y+ 6
B	83.0	-Y:95 R+ 69 -Z:88 P+ 336 Y+ 20	R+ 348 P+ 324 Y+ 11	-Z:95	R+ 157 P+ 327 Y+ 32	-Y:88	R+ 197 P+ 139 Y+ 348	-Z:95	R+ 117 P+ 154 Y+ 344	-Y:95 R+ 280 P+ 134 Y+ 334
C	91.0	-Y:81 R+ 157 -Z:97 P+ 36 Y+ 346	R+ 72 P+ 45 Y+ 334	-Z:81	R+ 241 P+ 22 Y+ 339	-Y:97	R+ 111 P+ 223 Y+ 30	-Z:81	R+ 24 P+ 220 Y+ 16	-Y:81 R+ 209 P+ 206 Y+ 33
D	84.6	-Y:21 R+ 185 -Z:45 P+ 358 Y+ 35	R+ 92 P+ 13 Y+ 27	-Z:21	R+ 274 P+ 350 Y+ 22	-Y:45	R+ 93 P+ 193 Y+ 338	-Z:45	R+ 4 P+ 184 Y+ 325	-Y:21 R+ 175 P+ 180 Y+ 346
E	84.3	-Y:47 R+ 274 -Z:43 P+ 241 Y+ 12	R+ 186 P+ 249 Y+ 24	-Z:47	R+ 357 P+ 253 Y+ 3	-Y:43	R+ 1 P+ 74 Y+ 335	-Z:43	R+ 272 P+ 61 Y+ 343	-Y:47 R+ 89 P+ 83 Y+ 347

STAR PAIRS PAD

FS-2-2

ORB OPS/124/FIN


PAIR		COAS ALIGN ATTITUDE 1	ANG SEP	COAS ALIGN ATTITUDE 2
COAS	+X HUD	R+ 17 P+ 351 Y+ 298	NOSE UP 63.6	R+ 62 P+ 55 Y+ 344
	-Z COAS	R+ 242 P+ 64 Y+ 4		TAIL UP R+ 215 P+ 111 Y+ 55

SINGLE S TRK MIN MNVR OPT
TGT ID = 11-110 NAV STAR #

	-Z S TRK	-Y S TRK
BV	5	4
P	87.7	√ 0
Y	358	√ 280.57

MET Applicable 00/00:00 to 13/00:00
Liftoff Date: 05/31/08
Liftoff GMT: 152/21:01:31.000

STAR PAIRS



MET Applicable: 00/00:00 to 13/00:00
 Liftoff Date: 05/31/08
 Liftoff GMT: 152/21:01:31.000



This Page Intentionally Blank



DAP TABLES

DAP OVERVIEW	FS 3-2
UNIV PTG	FS 3-3
STS-124 DAP A CONFIGURATIONS.....	FS 3-4
B CONFIGURATIONS.....	FS 3-6

**DAP
TABLES**

DAP TABLES

DAP Overview

DAP – Purpose	DAP – Purpose
A1 – Nominal	B1 – OMS & RCS Burns (ORB OPS)
A2 – PTC	B2 – Loss of VERN (Tail Only)
A3 – GG	B3 – Loss of VERN (All)
A4 – Pre/Post Deploy	B4 –
A5 – Loss of VERN (All)	B5 – COAS/HUD CAL
A6 – Loss of VERN (Tail Only)	B6 –
A7 – Rendezvous	B7 – Rendezvous
A8 – Terminal Phase	B8 – Terminal Phase
A9 – PROX OPS/Flyaround	B9 – PROX OPS/Flyaround
A10 – Docking	B10 – Docking
A11 – Auto Reboost	B11 –
A12 – Mated Stack (VRCS all & ALT maneuver)	B12 – Mated Stack (VRCS all & ALT attitude hold)
A13 –	B13 –
A14 – Orbiter alone SRMS/OBSS Ops	B14 –
A15 –	B15 –

- CNTL ACC = 0 Orbiter alone with unloaded RMS
 = 1 Orbiter alone SRMS/OBSS Ops
 = 2 Mated - VRCS and ALT with no vehicle docked to SM aft, Pre JPM Install
 = 3 Mated - VRCS and ALT with no vehicle docked to SM aft, Post JPM Install
 = 4 Mated - VRCS and ALT with Progress/Soyuz docked to SM aft, Pre JPM Install
 = 5 Mated - VRCS and ALT with Progress/Soyuz docked to SM aft, Post JPM Install
 = 6 Mated - VRCS and ALT with ATV docked to SM aft, Pre JPM Install
 = 7 Mated - VRCS and ALT with ATV docked to SM aft, Post JPM Install
 = 8 Not used
 = 9 Not used

DAPs for mated operations are based on analysis from GNC, PDRS, C. S. Draper Labs, and ISS Structures

FS 3-2

ORB OPS/124/FIN

UNIV PTG

TGT ID = 1 Orbiting Vehicle = 2 Earth Center = 3 Earth Target Input LAT (± 90) LON (± 180 , + = East) ALT (-3444.0 to 20000.0 nm) = 4 Sun Center = 5 Celestial Target Input RA (0-359.99) DEC (± 90) = 11-110 Nav Stars
BODY VECTOR = 1 +X* = 2 -X* = 3 -Z* = 4 -Y Star Tracker* = 5 Selectable Input P (0-359.99) Y (270-359.99, 0-90) *Input OM \rightarrow OM (0-359.99)
MON AXIS = 1 +X = 2 -X

STS-124 DAP A1 -- A8 CONFIGURATIONS

	ITEM #	A1	A2	A3	A4	A5	A6	A7	A8
PRI									
ROT RATE	10 (50)	0.2000	0.4000	0.2000	0.5000	0.2000	0.2000	0.2000	0.0500
ATT DB	11 (51)	5.00	1.00	0.30	3.00	5.00	5.00	2.00	2.00
RATE DB	12 (52)	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20
ROT PLS	13 (53)	0.100	0.100	0.100	0.100	0.100	0.100	0.100	0.100
COMP	14 (54)	.000	.000	.000	.000	.000	.000	.000	.000
P OPTION	15 (55)	ALL	ALL	ALL	ALL	ALL	TAIL	ALL	ALL
Y OPTION	16 (56)	ALL	ALL	TAIL	ALL	ALL	TAIL	ALL	ALL
TRAN PLS	17 (57)	0.100	0.100	0.100	0.100	0.100	0.100	0.100	0.100
ALT									
RATE DB	18 (58)	0.200	0.200	0.070	0.200	0.070	0.070	0.100	0.100
JET OPT	19 (59)	ALL	ALL	ALL	ALL	ALL	TAIL	ALL	ALL
# JETS	20 (60)	2	2	1	2	1	1	2	2
ON TIME	21 (61)	0.08	0.08	0.08	0.08	0.08	0.08	0.08	0.08
DELAY	22 (62)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
VERN									
ROT RATE	23 (63)	0.2000	0.4000	0.0080	0.2000	0.0500	0.0500	0.0160	0.0500
ATT DB	24 (64)	1.000	1.000	0.070	1.000	1.000	1.000	1.000	1.000
RATE DB	25 (65)	.020	.020	.010	.020	.020	.020	.020	.020
ROT PLS	26 (66)	0.010	0.010	0.010	0.010	0.010	0.010	0.010	0.050
COMP	27 (67)	.000	.000	.000	.000	.000	.000	.000	.000
CNTL ACC	28 (68)	0	0	0	0	0	0	0	0
PURPOSE		NOMINAL	PTC	GG	PRE/POST DEPLOY	LOSS OF VERN (ALL)	LOSS OF VERN (TAIL ONLY)	RNDZ	TERMINAL PHASE

BOLD/ITALIC indicates change from I-Load.

FS 3-4

ORB OPS/124/FIN

STS-124 DAP A9 -- A14 CONFIGURATIONS

	ITEM #	A9	A10	A11	A12	A14
PRI						
ROT RATE	10 (50)	0.1300	0.0500	0.0500	0.0500	0.2000
ATT DB	11 (51)	2.00	0.60	10.00	5.00	5.00
RATE DB	12 (52)	0.10	0.10	0.20	0.20	0.20
ROT PLS	13 (53)	0.100	0.100	0.100	0.040	0.100
COMP	14 (54)	.000	.000	.000	.000	.000
P OPTION	15 (55)	TAIL	TAIL	TAIL	TAIL	TAIL
Y OPTION	16 (56)	TAIL	TAIL	TAIL	TAIL	TAIL
TRAN PLS	17 (57)	0.050	0.050	0.100	0.010	0.100
ALT						
RATE DB	18 (58)	0.100	0.100	0.035 ¹	0.035 ¹	0.200
JET OPT	19 (59)	TAIL	TAIL	TAIL	TAIL	TAIL
# JETS	20 (60)	2	2	1	1	1
ON TIME	21 (61)	0.08	0.08	0.08	0.08	0.08
DELAY	22 (62)	0.00	0.00	6.00	6.00	6.00
VERN						
ROT RATE	23 (63)	0.1300	0.0500	0.1000	0.1000	0.2000
ATT DB	24 (64)	1.000	0.500	5.000	3.000	3.000
RATE DB	25 (65)	.020	.020	.050	.050	.200
ROT PLS	26 (66)	0.050	0.050	0.010	0.002	0.010
COMP	27 (67)	.000	.000	.000	.000	.000
CNTL ACC	28 (68)	0	0	6 ²	6 ²	1
PURPOSE		PROX/OPS FLYAROUND	DOCKING	AUTO REBOOST	MATED STACK (VRCS & ALT) ³	ORBITER ALONE SRMS/OBSS

BOLD/ITALIC indicates change from I-Load.

¹ I-loaded below keyboard limit; do not change

² Assumes ATV is docked to SM aft position. See DAP Overview for Cntl Acc applicability

³ VRCS for maneuvers and attitude hold. ALT for maneuvers and a maximum 15 min of attitude hold

FS 3-5

ORB OPS/124/FIN

STS-124 DAP B1 -- B8 CONFIGURATIONS

	ITEM #	B1	B2	B3	B4	B5	B6	B7	B8
PRI									
ROT RATE	30 (50)	0.5000	0.2000	0.2000	0.2000	0.2000	0.5000	0.5000	0.0500
ATT DB	31 (51)	3.00	3.00	3.00	0.30	3.00	3.00	2.00	2.00
RATE DB	32 (52)	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20
ROT PLS	33 (53)	0.040	0.040	0.040	0.040	0.040	0.040	0.040	0.040
COMP	34 (54)	.000	.000	.000	.000	.000	.000	.000	.000
P OPTION	35 (55)	ALL	TAIL	ALL	TAIL	TAIL	ALL	ALL	ALL
Y OPTION	36 (56)	ALL	TAIL	ALL	TAIL	TAIL	ALL	ALL	ALL
TRAN PLS	37 (57)	0.100	0.020	0.020	0.020	0.020	0.020	0.050	0.050
ALT									
RATE DB	38 (58)	0.200	0.070	0.070	0.100	0.200	0.200	0.100	0.100
JET OPT	39 (59)	ALL	TAIL	ALL	ALL	ALL	ALL	ALL	ALL
# JETS	40 (60)	2	1	1	2	2	2	2	2
ON TIME	41 (61)	0.08	0.08	0.08	0.08	0.08	0.08	0.08	0.08
DELAY	42 (62)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
VERN									
ROT RATE	43 (63)	0.2000	0.2000	0.2000	0.0080	0.0160	0.2000	0.2000	0.0500
ATT DB	44 (64)	1.000	1.000	1.000	0.100	0.033	1.000	1.000	1.000
RATE DB	45 (65)	.020	.020	.020	.010	.020	.020	.020	.020
ROT PLS	46 (66)	0.002	0.002	0.002	0.002	0.002	0.002	0.002	0.020
COMP	47 (67)	.000	.000	.000	.000	.000	.000	.000	.000
CNTL ACC	48 (68)	0	0	0	0	0	0	0	0
PURPOSE		OMS & RCS Burns (ORB OPS)	Loss of VERN (Tail Only)	Loss of VERN (All)		COAS/HUD CAL		RNDZ	TERMINAL PHASE

BOLD/ITALIC indicates change from I-Load.

FS 3-6

ORB OPS/124/FIN

STS-124 DAP B9 -- B12 CONFIGURATIONS

	ITEM #	B9	B10	B12
PRI				
ROT RATE	30 (50)	0.1300	0.0500	0.0500
ATT DB	31 (51)	2.00	0.60	5.00
RATE DB	32 (52)	0.10	0.10	0.20
ROT PLS	33 (53)	0.040	0.040	0.040
COMP	34 (54)	.000	.000	.000
P OPTION	35 (55)	TAIL	TAIL	TAIL
Y OPTION	36 (56)	TAIL	TAIL	TAIL
TRAN PLS	37 (57)	0.010	0.010	0.010
ALT				
RATE DB	38 (58)	0.100	0.100	0.035 ¹
JET OPT	39 (59)	TAIL	TAIL	TAIL
# JETS	40 (60)	2	2	1
ON TIME	41 (61)	0.08	0.08	0.08
DELAY	42 (62)	10.00	0.00	11.04
VERN				
ROT RATE	43 (63)	0.1300	0.0500	0.1000
ATT DB	44 (64)	1.000	0.500	3.000
RATE DB	45 (65)	.020	.020	.050
ROT PLS	46 (66)	0.020	0.020	0.002
COMP	47 (67)	.000	.000	.000
CNTL ACC	48 (68)	0	0	6 ²
PURPOSE		PROX OPS/ FLYAROUND	DOCKING	MATED STACK (VRCS & ALT) ³

BOLD/ITALIC indicates change from I-Load.

¹ I-loaded below keyboard limit; do not change

² Assumes ATV is docked to SM aft position. See DAP Overview for Cntl Acc applicability

³ VRCS for maneuvers and attitude hold. ALT for attitude hold only

FS 3-7

ORB OPS/124/FIN



This Page Intentionally Blank



REBOOST/DAP

AUTO REBOOST.....	FS 4-2
ATTITUDE REFERENCE.....	FS 4-4
DOCKED DAP REFERENCE	FS 4-5

**REBOOST/
DAP**

AUTO REBOOST

NOTE

Allow 5 min between establishing reboost attitude and reboost start time for DAP accelerations to converge

REBOOST/
DAP

1. If PRCS required:
- | | | |
|--------|--------------------------|-------|
| O14:F, | RJDA 1A L2/R2 DRIVER | - OFF |
| O15:F, | RJD MANF L5/F5/R5 DRIVER | - OFF |
| O16:F | Pri RJD LOGIC (eight) | - ON |

√MCC for GO to power up Pri Drivers
RJD MANF L5/F5/R5 DRIVER - ON
Pri RJD DRIVER (eight) - ON

2. Select Reboost Configuration

GNC 20 DAP CONFIG
REBOOST CFG - ITEM 8 +_ EXEC
INTVL - ITEM 9 +_ EXEC

3. Set up Future Reboost

GNC UNIV PTG
DURATION - ITEM 27 +_ +_ +_ EXEC
START TIME - ITEM 1 +_ . . . +_ . . . +_ EXEC
RBST - ITEM 25 EXEC (FUT-*)

4. Select appropriate Reboost Rotation DAP
When in attitude and prior to START TIME,
C3 DAP: A11/AUTO/VERN(ALT)

If using Config 1(2):

GNC 20 DAP CONFIG
Disable X JETS ROT - ITEM 7 EXEC (no *)

Cont next page

FS 4-2

ORB OPS/124/FIN

NOTE

Reboost can be aborted with an item 26 on UNIV PTG or by selecting FREE on the DAP

5. Post Reboost Configuration

If using Config 1(2):

GNC 20 DAP CONFIG

Enable X JETS ROT – ITEM 7 EXEC (*)

Return to FLIGHT PLAN Attitude


DAP: as reqd

Pri RJD LOGIC,DRIVER (sixteen) – as reqd

C3
O14,
O15,
O16

AUTO REBOOST ATTITUDE REFERENCE

ALT & VRCS ATTITUDE HOLD CONFIGURATIONS:



DOCKED DAP REFERENCE

SHUTTLE AIRLOCK

PRESS(≥ 3.45 psia)			DEPRESS (< 3.45 psia)
VERN	ALT maneuver and attitude hold < 15 min	ALT attitude hold only	VERN or ALT
A12 (or B12)	A12	B12	Not Certified

ALT not certified for loaded RMS operations (JPM and JLP ops)

CNTL ACC configurations for VERN and ALT:

- CNTL ACC 2: No vehicle docked at SM aft, Pre JPM install
- 3: No vehicle docked at SM aft, Post JPM install
- 4: Progress/Soyuz docked at SM aft, Pre JPM install
- 5: Progress/Soyuz docked at SM aft, Post JPM install
- 6: ATV docked at SM aft, Pre JPM install
- 7: ATV docked at SM aft, Post JPM install

RATE DAMPING

RATE DAMPING	LVLH(INRTL), when rates are below rate deadband and jet activity stopped, FREE > 2 sec, AUTO
RATE > 0.20	LVLH(INRTL) 6 min max FREE, LVLH(INRTL)

REBOOST

Configurations 1 & 2 are identical and ALT PRCS only
Configurations 3 & 4 are identical and VRCS only



This Page Intentionally Blank



OIU PROCEDURES

OIU ACTIVATION	FS 5-2
DEACTIVATION	FS 5-2

OIU

OIU ACTIVATION

NOTE

√MCC that steps 1 and 2 may not be reqd

1. Load PCMMU/PDI (config 763) for OIU
2. Power on PSP 1(2)

A1L √S-BD PL CNTL – CMD
 PWR SYS – 1(2)
 √SEL – PSP
 √PSP CMD OUTPUT – PL UMB
 CNTL – PNL,CMD

SM 62 PCMMU/PL COMM

I/O RESET PSP 1(2) – ITEM 6(7) EXEC (*)

3. Power on OIU 1(2)

SSP1 OIU PWR – OIU 1(2) ON
 √tb – UP(DN)

OIU DEACTIVATION

NOTE

√MCC for OIU ops complete

1. Possible 'S62 PDI DECOM FAIL' msg

SSP1 OIU PWR – OFF
 √tb – bp

2. MCC will config PCMMU and PDI as reqd

OIU

PRLA

PRLA CLOSE..... FS 6-2

PRLA

FS 6-1

ORB OPS/124/FIN

SHORT DURATION BIOASTRONAUTICS
INVESTIGATION (SDBI)

SDBI 1634, SLEEP-WAKE ACTIGRAPHY	FS 7-2
DON ACTIWATCH	FS 7-2
DOFF ACTIWATCH	FS 7-2
SDBI 1900, INTEGRATED IMMUNE BLOOD COLLECTION	FS 7-3
SDBI 1900, SALIVA COLLECTION FOR INTEGRATED IMMUNE	FS 7-9

SDBI

SDBI 1634, SLEEP-WAKE ACTIGRAPHY

- MF28K A. DON ACTIWATCH (ASAP after entry into orbit)
1. Unstow: Actiwatch
SLEEP LOGBOOK

NOTE

Actiwatch should be worn on top of non-dominant wrist outside of clothing. Face of Actiwatch should remain uncovered at all times.

If necessary to remove Actiwatch, record doff/don time in SLEEP LOGBOOK

2. Don Actiwatch on non-dominant arm and wear continuously throughout mission
3. Deploy SLEEP LOGBOOK and record required information daily (within 15 min after waking)

B. DOFF ACTIWATCH

NOTE

If mission length extended, continue to wear Actiwatch and complete SLEEP LOGBOOK as timeline permits

- On final day of orbit:
- MF28K 1. Remove Actiwatch, stow in locker
- Clothing Locker 2. Recover SLEEP LOGBOOK, stow in locker

SDBI

SDBI 1900, INTEGRATED IMMUNE BLOOD COLLECTION

OBJECTIVE:

Integrated Immune Assessment (Integrated Immune). The purpose of this procedure is to effectively and safely perform a blood draw, process blood samples, and properly stow them to achieve Integrated Immune Experiment objectives

PARTS:

Integrated Immune Blood Collection Kit:

- Band-Aid
- Fine Point Sharpie
- Gauze
- Tourniquet
- X-Large Gloves
- Butterfly Needle
- Tube Holder
- Blood Sample Sleeve:
 - Blood 8.5ml ACD (yellow top tube)
 - Blood 10ml EDTA (purple top tube)
- Biocide Wipes
- Biohazard Bag
- Surgical Paper Tape, 1-in
- Sharps Container
- Gray Tape

WARNING

All consumable items that come in contact with blood must be discarded in Biohazard Bag (provided in kit)

All sharp items (i.e., needles) must be discarded into Sharps Container

NOTE

Any spilled blood should be cleaned up with Gauze and followed with a Biocide Wipe

Cont next page

FS 7-3

ORB OPS/124/FIN

A. SETUP FOR BLOOD SAMPLE COLLECTION

NOTE

The lid of the Integrated Immune Blood Collection Kit, when opened, can be used as a workstation on which to temporarily store items via Velcro. Gray Tape can also be used

- MF43H
1. If desired for temporary stowage of supplies during blood draw, deploy about 12-inch piece of Gray Tape near location of blood draw
 2. Deploy hardware near area where activity will be performed:
- MA16D/F
- Integrated Immune Blood Collection Kit:
- Band-Aid
 - Fine Point Sharpie
 - Gauze (1 package)
 - Tourniquet
 - Butterfly Needle (1)
 - Tube Holder
 - Blood Sample Sleeve (open sleeve and loosen tubes)
 - Biocide Wipes
 - Surgical Paper Tape, 1-in
 - Sharps Container
 - Biohazard Bag
 - X-Large Gloves
3. Place Biohazard Bag in convenient location for trash disposal

B. PERFORM BLOOD SAMPLE COLLECTION

1. Retrieve Butterfly Needle (1) and remove from package. Place package in the Biohazard Bag and temporarily store

Cont next page

FS 7-4

ORB OPS/124/FIN

2. Retrieve Tube Holder
Screw Tube Holder onto threaded end of
Butterfly Needle
Temp stow Butterfly Needle/Tube Holder
3. Retrieve Gauze, open package but do not
remove Gauze, temp stow Gauze package
4. Retrieve Tourniquet from Integrated Immune
Blood Collection Kit
Apply Tourniquet to subject's arm
Using fingers find vein and select puncture site

<p><u>WARNING</u> Operator must don X-Large Gloves prior to needle insertion and observe Universal Precautions for Handling Biohazardous Materials</p>

5. Retrieve and don X-Large Gloves
Retrieve and open Biocide Wipe, placing empty
package in Biohazard Bag
Cleanse area with Biocide Wipe
Place used Biocide Wipe in Biohazard Bag
6. Retrieve Butterfly Needle/Tube Holder from temp
stow
Remove protective cover from Butterfly
Needle/Tube Holder. Place cover in Biohazard
Bag

<p><u>CAUTION</u> Blood tubes must be inspected for cracks. If cracked, tubes should be discarded in the Biohazard Bag</p>

7. Retrieve:
Blood Sample Sleeve
Surgical Paper Tape, 1-in

Cont next page

WARNING

Insert needle at 30 degree angle to vein to ensure proper blood flow and avoid injury

Avoid shifting needle from side to side after entering vein

NOTE

Taping of central portion of needle tubing to subject's arm is to prevent excessive movement during blood draw. Only tape tubing after needle is properly inserted in vein

8. Insert Butterfly Needle in subject's arm with bevel up. When the needle is properly inserted in the vein a flash of blood will be observed in butterfly tubing

Using strips of 1-in Surgical Paper Tape as necessary, tape central portion of Butterfly Needle tubing to subject's arm

Blood
Sample
Sleeve

9. Retrieve subject's empty Blood 8.5ml ACD (yellow top blood tube)

NOTE

Allow 10 sec to ensure the tube vacuum draws the appropriate volume of blood

10. Verify a flash of blood in butterfly tubing
11. Firmly push the blood tube into Tube Holder to puncture tube cap and initiate blood flow
12. When filled, detach blood tube from Tube Holder
13. Gently agitate tube for blood to mix with reagent for ~5 sec

Cont next page

FS 7-6

ORB OPS/124/FIN

- ┌ | | | ┌
- Blood Sample Sleeve
14. Temp stow filled blood tube in Blood Sample Sleeve
 15. Retrieve Blood 10.5ml EDTA tube (purple top) and repeat steps 11 thru 14 for the second tube
 16. Loosen Tourniquet
 17. Retrieve Gauze from temp stow
 18. Hold Gauze to venipuncture site while simultaneously grasping wings of Butterfly Needle and removing it at same angle of insertion, applying gentle pressure to Gauze
- Have subject hold Gauze on venipuncture site for 2-5 min
- If taped, remove tape from arm and dispose
- Slide safety shield over Butterfly Needle by holding yellow sheath and pulling wings backward
- NOTE
Do not discard tube holder
19. Carefully unscrew Tube Holder from Butterfly Needle; temp stow
 20. Discard used Butterfly Needle (with sharp edges facing down) in Sharps Container
 21. Remove Tourniquet and stow in Integrated Immune Blood Collection Kit

Cont next page

FS 7-7

ORB OPS/124/FIN

└ | | | └

- 22. Keep Gauze on venipuncture site for pressure bandage
Place Band-Aid over folded Gauze
Discard any excess Gauze and Band-Aid wrapper in Biohazard Bag
 - 23. Retrieve filled blood tubes from Blood Sample Sleeve and label both tubes with crewmember name and GMT (e.g., Smith: GMT 168:19:48)
 - 24. Stow blood tubes back in Blood Sample Sleeve and temp stow
 - 25. Discard X-Large Gloves in Biohazard Bag
- Dispose of any remaining Biocide Wipes, Gauze, Gray Tape, or empty packaging used in the activity

C. STOW HARDWARE

- 1. Remove full Biohazard Bag, close with Gray Tape
Discard full Biohazard Bag in appropriate disposal location
- 2. Stow in Integrated Immune Blood Collection Kit:
Blood Sample Sleeve with blood samples
Sharps Container (bottom first into pouch)
Biocide Wipes (if any)
Gauze (if any)
Surgical Paper Tape, 1-in
Fine Point Sharpie
Tube Holder
Remaining Band-Aid packages (if any)
- 3. Stow:
Integrated Immune Blood Collection Kit
Put away Gray Tape per crew preference

MA16D/F

SDBI 1900, SALIVA COLLECTION FOR INTEGRATED IMMUNE

OBJECTIVE:

Integrated Immune Assessment (Integrated Immune). The purpose of this procedure is to effectively perform saliva collection to achieve Integrated Immune Experiment objectives

PARTS:

Integrated Immune Saliva Collection Kit:

Salivette Bag (package with cotton swabs)

Saliva Sample Preservative Bag

Label

Saliva Collection Dry Booklet

Saliva Sample Return Pouch

Fine Point Sharpie

A. SETUP FOR SALIVA SAMPLE COLLECTION

NOTE

Any Saliva Sample Return Pouch (labeled USED and does not have crewmember data filled in) located in the Integrated Immune Saliva Collection Kit will suffice for this step

- MA16D/F
1. Unstow:
Integrated Immune Saliva Collection Kit:
Fine Point Sharpie
Label from plastic window of Saliva Sample Return Pouch
 2. Write crewmember name on label using Fine Point Sharpie
Return label to plastic window it was taken from
Temp stow Fine Point Sharpie

Cont next page

FS 7-9

ORB OPS/124/FIN

B. PERFORM LIQUID SALIVA SAMPLE COLLECTION

NOTE

Liquid saliva should be collected immediately post-sleep (before brushing teeth, before breakfast, and before any liquid intake)

1. Retrieve from Integrated Immune Saliva Collection Kit:
Salivette Bag
Saliva Sample Preservative Bag
2. Temp stow Saliva Sample Preservative Bag

NOTE

Touching the Cotton Swab with fingers at any point of the data collection will contaminate the sample

3. Open Salivette Bag and by kneading and manipulating the outside of package, separate one Cotton Swab from the others and move it towards the opening of the package
4. Place Salivette Bag with Cotton Swab near mouth and then transfer Cotton Swab from package into mouth. Lightly roll Cotton Swab around mouth with tongue until saturated (2 min max). Do not bite down or chew on Cotton Swab
5. Stow Salivette Bag with remaining Cotton Swab in Integrated Immune Saliva Collection Kit
6. Retrieve Saliva Sample Preservative Bag from temp stow
7. Using mouth, place Cotton Swab in Saliva Sample Preservative Bag

Cont next page

8. Close seal on Saliva Sample Preservative Bag

NOTE

Ensure bag is sealed prior
to mixing preservative

9. Remove clamp, mix preservative with Cotton Swab
10. Reclamp across top of Saliva Sample Preservative Bag
11. Using Fine Point Sharpie, write crewmember name and GMT on Saliva Sample Preservative Bag (e.g., Smith: GMT 168:19:48)
12. Stow sample in Saliva Sample Return Pouch (labeled with crewmember name in part A step 2) inside Integrated Immune Saliva Collection Kit

C. PERFORM DRY SALIVA COLLECTION

NOTE

First sample should be taken as
soon after waking as is convenient

1. Retrieve from Integrated Immune Saliva Collection Kit:
Dry Saliva Collection Book
2. Write crewmember name in name section on cover of Dry Saliva Collection Book
3. Open cover
Select (but do not remove from book) the corresponding sheet of filter paper to the time period sample is being taken (WAKE, WAKE + 30 MINUTES, WAKE + SIX HOURS, WAKE + TEN HOURS, RETIRE) as illustrated on the cover

Label GMT on corresponding color and time period on cover

Cont next page

NOTE

Take care not to touch other collection time's filter papers when using Dry Saliva Collection Book

4. Place filter paper in mouth and saturate filter paper with saliva

NOTE

Do not touch saturated part of filter paper while drying. Filter paper does not have to be 100% dry before stowing/temp stowing. Use crew discretion

5. Remove filter paper from mouth. Wipe excess liquid saliva from filter paper with lips
Allow to air dry
6. Temp stow Dry Saliva Collection Book or maintain on person if desired
7. For subsequent collections, retrieve Dry Saliva Collection Book from temp stow and repeat steps 3 thru 6 four times throughout the day that correspond to the remaining four time intervals from wake period
8. After collecting last dry saliva sample, open Saliva Sample Return Pouch (labeled with crew ID) inside Integrated Immune Collection Kit and stow Dry Saliva Collection Book inside Saliva Sample Return Pouch

D. STOW HARDWARE

- MA16D/F 1. Stow: Integrated Immune Saliva Collection Kit |

WING LEADING EDGE SENSORS (WLES) PROCEDURES

WLES ACTIVATION AND CHECKOUT.....	FS 8-2
DEACTIVATION AND TEARDOWN.....	FS 8-10
LAPTOP RECEIVER UNIT (LRU) R&R.....	FS 8-12
CONFIGURE WLES DATA FILE BACKUP PATH.....	FS 8-14
PREP WLES LAPTOPS FOR TRANSFER.....	FS 8-15
WLES RNDZ TOOLS CHECKOUT PREP.....	FS 8-16
DOCK/UNDOCK RECOVERY.....	FS 8-16
DISABLE WLES FILE BACKUP	FS 8-17
ENABLE WLES FILE BACKUP	FS 8-17

**WLE
SENSORS**

WLES ACTIVATION AND CHECKOUT

1. UNSTOW EQUIPMENT

NOTE

A31p laptops may already be unstowed as part of orbiter laptop network setup

LW MAR

Unstow:

Laptop Receiver Units (2)

Cabin Relay Units (2):

CRU A (S/N 1664)

CRU B (S/N 1728)

STS7 A31p laptop (WLES)

STS6 A31p laptop (RPOP2)

2. SETUP WLES RELAY UNITS

CAUTION

Cross-connecting CRU A to MICRO WIS SYSTEM B (and vice versa) will prevent WLES ops, though step 8 would still show good comm

NOTE

Green patch on Cabin Relay Unit is antenna and must face into cabin

- | | |
|--------------|---|
| A6 | Unstow coiled WLE SYSTEM A cable |
| A13 | Connect plug PNL A13 SYSTEM A to jack MICRO WIS SYSTEM A J7 (see fig 8-1) |
| CRU A | Connect plug CABIN RELAY UNIT to J1 on CRU S/N 1664 |
| STBD
OVHD | Secure CRU A to STBD side of aft cabin with Velcro (see fig 8-2) |
| A9 | Unstow coiled WLE SYSTEM B cable |
| A13 | Connect plug PNL A13 SYSTEM B to jack MICRO WIS SYSTEM B J8 (see fig 8-1) |
| CRU B | Connect plug CABIN RELAY UNIT to J1 on CRU S/N 1728 |
| PORT
OVHD | Secure CRU B to PORT side of aft cabin with Velcro (see fig 8-3) |

Cont next page




Figure 8-1.- A13 panel.

Cont next page

FS 8-3

ORB OPS/124/FIN




Figure 8-2.- Aft STBD location.




Figure 8-3.- Aft PORT location.

Cont next page

FS 8-4

ORB OPS/124/FIN

NOTE

Laptops may be powered or unpowered.
Laptops may be connected to network or
standalone

A31p

3. SETUP PRIME WLES LAPTOP

Secure Laptop Receiver Unit to A31p with Velcro
(see fig 8-4)

Connect Laptop Receiver Unit to A31p Serial port
using thumbscrews (see fig 8-5)

Verify line of sight between Laptop Receiver Unit
and both CRUs

Verify 5-in minimum distance between Laptop
Receiver Unit and both CRUs

4. SETUP BACKUP WLES LAPTOP

NOTE

Single laptop ops are preferred over
delays in activation. If problems with
Backup Laptop occur, skip step 4

Secure Laptop Receiver Unit to A31p with Velcro
(see fig 8-4)

Connect Laptop Receiver Unit to A31p Serial port
using thumbscrews (see fig 8-5)

Verify line of sight between Laptop Receiver Unit
and both CRUs

Verify 5-in minimum distance between Laptop
Receiver Unit and both CRUs




Figure 8-4.- Laptop Receiver Unit.

Cont next page

FS 8-5

ORB OPS/124/FIN



Figure 8-5.- A31p ports.

5. LAUNCH WLES SOFTWARE

Perform for both laptops:

If laptops are off, A31p pwr – On

Double click the time in system tray (lower-right corner)

'Date and Time Properties'

'Time Zone'

Time zone – (GMT) Greenwich Mean Time

Click 'OK'

Double click 'Shuttle Apps'>'WLES'>'WLES'

'Backup Mode Selection'

If setting up one A31p, select 'Standard'

|

If setting up two A31p laptops:

For prime laptop, select 'Primary'

For backup laptop, select 'Secondary'

If 'EWBMTAU - WLEFlight' appears with message 'Run the current command:

XXXX_AA_BB_SNYYY.xml?':

Click 'Yes'

NOTE

The secondary laptop lid may be closed at this time, if no longer needed for other applications.

The laptops are configured so that they do not enter 'standby' or 'hibernate' mode when the lids are closed. However, due to cooling concerns, fully closing the lid is not recommended

Cont next page

A31p

6. VERIFY LRU INSTALLATION

Use prime WLES laptop

'Enhanced Wideband MicroTAU – WLEFlight 3.0'

Click 'System Settings' (left side of display)

'Communications Settings'

√RF Receiver Port: 'COM 1'

Click 'Query Receiver'

Verify 'Receiver found on COM1' message appears

7. ENABLE DATA FILE BACKUP

Use prime WLES laptop

Verify 'Backup Directory:' set to

'S:\Program Files\Invocon\EWBMTAU-WLEFlight'

- * If 'Backup Directory' not set as above: *
- * 'System Settings' *
- * 'Directories' *
- * At the line 'Backup Directory:' click *
- * 'Browse...' (right side of display) *
- * *
- * 'Browse for Folder' *
- * Navigate to WLES folder on RPOP2: *
- * 'My Computer'>'C on RPOP2 *
- * (S:)>'Program Files'>'Invocon'> *
- * 'EWBMTAU-WLEFlight' *
- * *
- * Click 'OK' *

Verify 'Backup Interval' set to '30 minutes'

Cont next page

FS 8-7

ORB OPS/124/FIN

8. VERIFY COMM WITH RELAY UNITS

Use prime WLES laptop

'Main'

Click 'Unit List' (left side of display)

NOTE

Each Cabin Relay Unit is identified with a unique serial number; this number appears as 'Unit ID' in the software

√Cabin Relay Units Unit ID 1664 and 1728 (2) present on display in first column; scroll down as necessary

For each Cabin Relay Unit:

√Unit ID present

√Type: 'Relay-GL'

√Last Update: time is updating (every 5 to 15 sec)

* If one CRU time updates:	*
* Continue procedure	*
* Report off-nominal CRU status in step 10	*
*	*
* If neither CRU time updates after 2 min,	*
* contact MCC-H	*

√Via: 'RF'

√Mode: 'Idle'

9. INITIATE COMMANDING

NOTE

The first time a user navigates to 'Program Files' folder, display may show information saying the program files are hidden. To view the contents of the folder, select 'display files' in the left-hand portion of the Windows Explorer window

Double click 'Shuttle Apps'>'WLES'>'WLES Data Folder'

Double click 'Shuttle Apps'>'WLES'>'WLES Cmd Folder'

Cont next page

NOTE

Deleting 'BLOCK.xml' file initiates command execution. Command files disappear from this folder as they are executed.

Files appearing in the 'Data' folder verifies two-way communication with the Sensor Units in the orbiter wing

'Command'

Delete file labeled 'BLOCK.xml'

At prompt "Are you sure you want to send 'Block.xml' to the Recycle Bin?", click 'Yes'

Wait 1 minute

Verify the first data file appears in the 'Data' folder

Close 'Command' and 'Data' folders

10. REPORT WLES STATUS

Notify MCC-H: "WLES setup complete"

If reporting off-nominal CRU status, include:

Unit ID

Type

Last Update (updating or static)

Via

Mode

NOTE

The laptop lid may be closed at this time, if no longer needed for other applications. The laptops are configured so that they do not enter 'standby' or 'hibernate' mode when the lids are closed. However, due to cooling concerns, fully closing the lid is not recommended

WLES DEACTIVATION AND TEARDOWN

1. DEACTIVATE WLES LAPTOP
A31p 'Enhanced Wideband MicroTAU – WLEFlight 3.0'

For each WLES A31p:

Click 'Exit'

At prompt 'Are you sure you want to exit?'

click 'Yes'

Click 'Start' > 'Turn Off Computer...' > 'Turn Off'

Disconnect Laptop Receiver Unit from A31p

Serial port

Remove Laptop Receiver Unit from Velcro on
A31p

2. REMOVE WLES RELAY UNITS

Remove Cabin Relay Units (2) from aft cabin (see
fig 8-6 and fig 8-7)

Disconnect Cabin Relay Units from pre-routed
cables

Disconnect and coil cables, stow in launch location




Figure 8-6.- Aft STBD location.

Cont next page

FS 8-10

ORB OPS/124/FIN




Figure 8-7.- Aft PORT location.

- LW MAR
3. STOW EQUIPMENT
 Stow:
 Laptop Receiver Units (2)
 Cabin Relay Units (2)
 Notify MCC-H: "WLES Teardown Complete"

WLES LAPTOP RECEIVER UNIT (LRU) R&R

- A31p 1. DISCONNECT BACKUP LRU FROM LAPTOP
'Enhanced Wideband MicroTAU – WLEFlight 3.0'

Click 'Exit'
At prompt 'Are you sure you want to exit?'
click 'Yes'

Disconnect Backup LRU from Backup A31p Serial
port (see fig 8-8)
Remove Backup LRU from Velcro on Backup A31p
(see fig 8-9)



Figure 8-8.- A31p ports.




Figure 8-9.- Laptop Receiver Unit.

2. DISCONNECT PRIME LRU FROM LAPTOP
Disconnect Prime LRU from Prime A31p Serial port
(see fig 8-8)
Remove LRU from Velcro on A31p

Cont next page

3. CONNECT BACKUP LRU

Connect Backup LRU to Prime WLES A31p Serial port
Secure LRU to A31p with Velcro

A31p

4. VERIFY LRU INSTALLATION

Use prime WLES laptop

'Enhanced Wideband MicroTAU – WLEFlight 3.0'
Click 'System Settings' (left side of display)

'Communications Settings'
√RF Receiver Port: 'COM 1'

Click 'Query Receiver'
Verify 'Receiver found on COM1' message appears

5. VERIFY COMM WITH RELAY UNITS

Click 'Unit List' (left side of display)

√Cabin Relay Units Unit ID 1664 and 1728 (2) present
on display in first column; scroll down as necessary

For each Cabin Relay Unit:

- √Unit ID present
- √Type: 'Relay-GL'
- √Last Update: time is updating (every 5 to 15 sec)
- √Via: 'RF'
- √Mode: 'Idle'

If no time updates after 2 min, contact MCC-H

Notify MCC-H: "WLES LRU R&R complete", mark
failed LRU as 'failed'

LW MAR

6. STOW EQUIPMENT

Stow:
Prime (failed) LRU

CONFIGURE WLES DATA FILE BACKUP PATH

NOTE

MCC will identify new backup WLES laptop to be used in place of RPOP2 (S:)

A31p

Use prime WLES laptop

'Enhanced Wideband MicroTAU – WLEFlight 3.0'
Click 'System Settings' (left side of display)

'Directories'
At the line 'Backup Directory' click 'Browse...' (right side of display)

'Browse for Folder'
Navigate to WLES folder on RPOP2:
'My Computer'>'C on RPOP2 (S:)'>'Program Files'>'Invocon'>'EWBMTAU-WLEFlight'

Click 'OK'

Verify 'Backup Directory:' set to:
'S:\Program Files\Invocon\EWBMTAU-WLEFlight'

Verify 'Backup Interval' set to '30 minutes'

Click 'Unit List' (left side of display)

PREP WLES LAPTOPS FOR TRANSFER

- A31p 1. DEACTIVATE WLES LAPTOP(S)
'Enhanced Wideband MicroTAU – WLEFlight 3.0'

For each WLES A31p to be transferred:

Click 'Exit'

At prompt 'Are you sure you want to exit?'

click 'Yes'

Click 'Start'>'Turn Off Computer... '>'Turn Off'

Disconnect Laptop Receiver Unit from A31p

Serial port

Remove Laptop Receiver Unit from Velcro on
A31p

2. SET UP NEW WLES LAPTOP

√MCC-H for which laptop to use

If Prime Laptop being transferred:

Perform WLES ACTIVATION AND CHECKOUT,
steps 3 thru 8, then:

If Backup Laptop being transferred:

Perform WLES ACTIVATION AND CHECKOUT,
steps 4 and 5, then:

Notify MCC-H: "PREP WLES LAPTOPS FOR
TRANSFER complete"

WLES RNDZ TOOLS CHECKOUT PREP

- A31p
1. DEACTIVATE BACKUP WLES LAPTOP
On backup WLES laptop:
 'Enhanced Wideband MicroTAU – WLEFlight 3.0'
 Click 'Exit'
 At prompt 'Are you sure you want to exit?'
 click 'Yes'
 Disconnect Laptop Receiver Unit from A31p
 Serial port
 Leave attached to laptop with Velcro on A31p
 2. DEACTIVATE WLES FILE BACKUP
On prime WLES laptop:
 'Enhanced Wideband MicroTAU – WLEFlight 3.0'
 Click 'System Settings' (left side of display)

 'Backup Mode Selection'
 Click 'Standard'
 Click 'Unit List' (left side of display)

WLES DOCK/UNDOCK RECOVERY

- A31p
1. RECOVER BACKUP WLES LAPTOP
On backup WLES laptop:
 Connect Laptop Receiver Unit to A31p Serial port
 If laptop is off:
 A31p pwr – On
 At prompt select option 1 to start WLES
 If laptop is on:
 Double click 'Shuttle Apps'>'WLES'>'WLES'
 'Backup Mode Selection'
 Click 'Secondary'
 2. REACTIVATE WLES FILE BACKUP
On prime WLES laptop:
 'Enhanced Wideband MicroTAU – WLEFlight 3.0'
 Click 'System Settings' (left side of display)

 'Backup Mode Selection'
 Click 'Primary'
 Click 'Unit List' (left side of display)

┌ | | | ┌

DISABLE WLES FILE BACKUP

A31p On prime WLES laptop:
 'Enhanced Wideband MicroTAU – WLEFlight 3.0'
 Click 'System Settings' (left side of display)

 'Backup Mode Selection'
 Click 'Standard'
 Click 'Unit List' (left side of display)

ENABLE WLES FILE BACKUP

A31p On prime WLES laptop:
 'Enhanced Wideband MicroTAU – WLEFlight 3.0'
 Click 'System Settings' (left side of display)

 'Backup Mode Selection'
 Click 'Primary'
 Click 'Unit List' (left side of display)



This Page Intentionally Blank



MAUI ANALYSIS OF UPPER-ATMOSPHERIC
INJECTIONS (MAUI)

MAUI PROCEDURE FS 9-2

MAUI

FS 9-1

ORB OPS/124/FIN

MAUI

MAUI PROCEDURE

- 15:00 or earlier 1. MANEUVER TO START ATTITUDE
(BIASED +ZLV +YVV)

Deploy MAUI – RCS FIRING SEQUENCE
(Cue Card)

GNC 20 DAP CONFIG

√DAP A1, B1 loaded

UNIV PTG

TGT ID – ITEM 8 +2 EXEC
BODY VECT – ITEM 14 +5 EXEC
P – ITEM 15 +2 7 0 EXEC
Y – ITEM 16 +3 5 0 EXEC
OM – ITEM 17 +2 7 0 EXEC

TRK – ITEM 19 EXEC (CUR - *)

2. INITIATE TIMER

√MCC for start time

GNC 2 TIME

Set count down/count up timer per MCC

√MET – ITEM 2 EXEC (*)

CRT TIMER COUNT TO – ITEM 17 + + + EXEC

3. SETUP

O14:E, cb DDU L (two) – cl
O15:E

O14:F, Pri RJD LOGIC, DRIVER (sixteen) – ON
O15:F,
O16:F

GNC 20 DAP CONFIG

DAP A PRI P OPTION – ITEM 15 EXEC (NOSE)

TRAN PLS – ITEM 17 +0.7 3 EXEC

VERN ROT PLS – ITEM 26 +0.1 5 3 EXEC

Cont next page

FS 9-2

ORB OPS/124/FIN

GNC 23 RCS

Deselect Jets:

Forward RCS page – ITEM 1 EXEC

JET DES F1D – ITEM 23 EXEC (*)

F2D – ITEM 27 EXEC (*)

C3 √DAP: A/AUTO/VERN
 √DAP TRANS: PULSE/PULSE/PULSE
 DAP ROT: PULSE/PULSE/PULSE

-05:00 4. VERIFY ATTITUDE
 Verify in attitude

NOTE

For the following RCS firing sequence
(step 5):

- A. Expect total orbiter body rates
(RSS) to exceed 1 deg/sec
- B. Possible loss of comm due to orbiter
body rates and attitude excursions
- C. For any jet fail OFF, continue with
firing sequence
- D. Requirement is for a particular jet
group, not a specific jet
- E. The table in step 5 is also provided
as a cue card

Cont next page

FS 9-3

ORB OPS/124/FIN

5. RCS FIRING SEQUENCE

NOTE

Use the table below or the cue card

MAUI – RCS FIRING SEQUENCE

Timer	Jets Fired	CDR	PLT
-03:00		Body rates: $+0.047 \leq \text{roll} \leq +0.087$ $-0.020 \leq \text{pitch} \leq +0.020$ $-0.020 \leq \text{yaw} \leq +0.020$ DAP: FREE DAP: A/PRI Inform PLT "GO" for jet deselects	Configure initial setup [GNC 23 RCS] Left RCS page – ITEM 2 EXEC On CDR "GO", proceed <u>NOTE</u> Expect DAP RECONF msgs in following actions Deselect jets: JET DES L5L – ITEM 37 EXEC (*) Right RCS page – ITEM 3 EXEC JET DES R5D – ITEM 39 EXEC (*) Forward RCS page – ITEM 1 EXEC JET DES F5L – ITEM 37 EXEC (*) <u>NOTE</u> Queue the following ITEM entry on the scratch pad. Do not perform the EXEC until specified at 35 sec JET DES F3D – ITEM 25
-00:30		FLT CNTRL PWR – ON	
00:00	RXA, LXA	THC +X (in) (3 sec firing)	
00:15	FXL, LXL	THC +Y (right) (3 sec firing)	
00:30	FXR, RXR	THC -Y (left) (3 sec firing)	
00:35			When jets stop firing: [GNC 23 RCS] EXEC [JET DES F3D – ITEM 25 (*)]
00:45	F4D	RHC +pitch (hard stop, hold 3 sec)	
00:48		RHC release	
00:50			DAP: VERN
01:00	R5R	RHC +yaw (10 sec firing)	
01:20	L5D	RHC -pitch (12 sec firing)	
01:40	F5R	RHC +pitch (12 sec firing)	
		FLT CNTRL PWR – OFF	Return to MAUI PROCEDURE, step 6, (ORB OPS FS, <u>MAUI</u>)

Cont next page

FS 9-4

ORB OPS/124/FIN

6. CLEANUP
F6 √FLT CNTRL PWR – OFF

GNC 23 RCS

√Forward RCS page – ITEM 1 EXEC

Reselect Jets:

JET DES F1D – ITEM 23 EXEC (no *)
F3D – ITEM 25 EXEC (no *)
F2D – ITEM 27 EXEC (no *)
F5L – ITEM 37 EXEC (no *)

Left RCS page – ITEM 2 EXEC
JET DES L5L – ITEM 37 EXEC (no *)

Right RCS page – ITEM 3 EXEC
JET DES R5D – ITEM 39 EXEC (no *)

GNC 20 DAP CONFIG

DAP A1 – ITEM 1 +1 EXEC

7. SNAP LVLH ATTITUDE AND NULL RATES

When time \geq +03:30:

DAP: A/PRI
DAP: LVLH

When rates stable:

DAP: VERN


Return to FLT PLN attitude

8. RECONFIGURE TO GROUP B POWERDOWN


√MCC

O14:E, cb DDU L (two) – op
O15:E

O14:F, Pri RJD LOGIC,DRIVER (sixteen) – OFF
O15:F, RJDA 1A L2/R2 MANF DRIVER – ON
O16:F



This Page Intentionally Blank



CUE CARD CONFIGURATION

LIOH CHANGEOUT FLIGHT DAY 3 DOCKING

ORBITER WITH ISS (Front)	FS CC 10-3
LIOH CANISTER STOWAGE LOCATIONS (Back) ...	FS CC 10-4
ORBIT BURN MONITOR (Front)	FS CC 10-5
OMS FAILURES (Back)	FS CC 10-6
STS-124 DAP CONFIGURATIONS	
(Front/Top)	FS CC 10-7
(Front/Bottom)	FS CC 10-8
(Back/Top).....	FS CC 10-9
(Back/Bottom)	FS CC 10-10
MAUI – RCS FIRING SEQUENCE (Front)	FS CC 10-11
(Back).....	FS CC 10-12
MIDODRINE PILL INGESTION (Front).....	FS CC 10-13

CUE
CARDS

NOT FLOWN

FS 10-1

ORB OPS/124/FIN

CUE
CARDS

This Page Intentionally Blank

NOT FLOWN

FS 10-2

ORB OPS/124/FIN

TOP

HOOK
VELCRO

**LiOH CHANGEOUT
FLIGHT DAY 3 DOCKING ORBITER WITH ISS**
(7 Crewmembers/Single Shift/FD 17)

FLIGHT DAY	POS A	POS B	CK CMPLT
LAUNCH	1	2	
PRE FD1	"	"	
POST FD2	3	4	
PRE FD2	5	6 *	
POST FD3	"	7	Docking
PRE FD3	8	"	
POST FD4	"	"	
PRE FD4	"	9	
POST FD5	"	"	
PRE FD5	10	"	
POST FD6	"	"	
PRE FD6	"	11	
POST FD7	"	"	
PRE FD7	12	"	
POST FD8	"	"	
PRE FD8	"	13	
POST FD9	"	"	
PRE FD9	STS-118	"	
POST FD10	"	"	
MID FD10	STS-118 * STS-118 *		Hatch Close
PRE FD10	"	"	
POST FD11	STS-118	STS-118	
PRE FD11	STS-118	"	
POST FD12	STS-118	STS-118	
PRE FD12	STS-118 * STS-118 *		
POST FD13	STS-118	STS-118	
PRE FD13	"	STS-118	
POST FD14	STS-118	14	EOM
PRE FD14	15 *	16 *	
POST FD15	17	18	EOM+1
PRE FD15	19	"	
POST FD16	20	21	EOM+2
PRE FD16	22 *	23 *	
POST FD17	24	25	EOM+3

*Reseal LiOH cans w/Gray Tape and stow
(Locations of canisters on back)

ORB OPS-29a/nonRCRS/124/O/A

NOTE

This card is specifically used for the STS-124 mission with the orbiter conducting single shift operations with a crew size of 7. This changeout scheme reflects FD3 docking with ISS, Vozdukyh, and dual bed CDRA operation


(reduced copy)

NOT FLOWN

FS CC 10-3

ORB OPS/124/FIN

TOP
BACK OF 'LIOH CHANGEOUT
FLIGHT DAY 3 DOCKING ORBITER WITH ISS'



LIOH CANISTER STOWAGE LOCATIONS


Ascent LiOH Locations

Orbiter:

MD52M (LiOH): Cans 1-31

ISS:

STS-118 Cans 47, 49-61



NOT FLOWN

(reduced copy)

FS CC 10-4

ORB OPS/124/FIN

TOP

HOOK
VELCRO

HOOK
VELCRO

ORBIT BURN MONITOR

OMS TEMP*		
FU IN P >	L 225	R 220
≤	205	204
or No FU IN P		
		OMS ENG FAIL
		OMS PRPLT FAIL
OMS PC* & OMS ↓		
ENG VLV 1 or 2 < 70		OMS ENG FAIL
or OX IN P > 227		
OX IN P ≤ 227		OMS PRPLT FAIL
or No OX IN P		
OMS OX/FU TK P (√ENG IN P)		
OX/FU LOW		He PRESS/VAP ISOL (two) – OP
		If aff TK P not incr:
		OMS PRPLT FAIL
OX & FU HIGH		He PRESS/VAP ISOL (two) – CL
		Cycle He A(B) to maintain TK P 234-284
OMS N2 REG P HIGH or LOW		OMS ENG – ARM
OMS N2 TK P LOW (√[OMS/MPS])		At N2 TK P < 470:
		OMS ENG – ARM
OMS GMBL	PRI fail	L(R) OMS GMBL – SEC (twice)
	SEC fail	If high RCS usage: OMS ENG FAIL
GPC	<input type="checkbox"/> (<input type="checkbox"/>) & Burning OMS aff	aff GPC PWR – OFF
		If SEC GMBL avail:
		aff MDM FF 1(4) – OFF, ON
		L(R) OMS GMBL – SEC (twice)
	SEC GMBL lost	If high RCS usage: OMS ENG FAIL
	2 FAs lost	√MAN SHUTDN
I/O ERROR FA	1(4)	L(R) OMS GMBL – SEC
		I/O RESET
		If high RCS usage: OMS ENG FAIL
	2 FAs lost	√MAN SHUTDN
BCE STRG D		I/O RESET (if recov: >>)
	1(4)	If high RCS usage:
		L(R) OMS GMBL – SEC (twice)
GPC SET SPLIT	Non-crit burn	STOP BURN: OMS ENG(s) – OFF
	Crit burn	Go to "GPC" above
I/O ERROR PCM		OI PCMMU PWR – 2(1)
BCE BYP OA		SM I/O RESET

*If XFD, BLDN, or sensor fail, monitor ENG IN P for off-nominal performance

ORB OPS-31a/124/O/A

(reduced copy)

NOT FLOWN


FS CC 10-5

ORB OPS/124/FIN

TOP
BACK OF 'ORBIT BURN MONITOR'




LEFT OMS



- † If CNTL AB1 or AB2 (CA1 or CA2) failed and ign path still exists at OMS fail, assume L(R) OMS ↓ is PRPLT FAIL
- * If L(R) Pc failed high during burn or FA3(4) failed, at L(R) OMS fail, no guidance downmode after L(R) OMS ENG switch OFF (TGO slow, ADI needles in error, 6 ft/s underburn)

RIGHT OMS



If two FA MDMs lost		
MDMs	Preburn: ENG – OFF	During burn: MAN SHUTDN
1,2	LEFT (TVC)	BOTH
1,3	RIGHT (IGN)	LEFT
1,4	LEFT (IGN)	RIGHT
2,3	LEFT (IGN)	RIGHT
2,4	RIGHT (IGN)	LEFT
3,4	RIGHT (TVC)	BOTH

ORB OPS-31b/124/O/A

(reduced copy)

NOT FLOWN

FS CC 10-6

ORB OPS/124/FIN

NOT FLOWN

FS CC 10-7

ORB OPS/124/FIN

(reduced copy)

TOP

PILE
VELCRO

ORB OPS-41a/124/O/A

PILE
VELCRO

STS-124 DAP A1 – DAP A8 CONFIGURATIONS

	ITEM #	A1	A2	A3	A4	A5	A6	A7	A8
PRI									
ROT RATE	10 (50)	0.2000	0.4000	0.2000	0.5000	0.2000	0.2000	0.2000	0.0500
ATT DB	11 (51)	5.00	1.00	0.30	3.00	5.00	5.00	2.00	2.00
RATE DB	12 (52)	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20
ROT PLS	13 (53)	0.100	0.100	0.100	0.100	0.100	0.100	0.100	0.100
COMP	14 (54)	.000	.000	.000	.000	.000	.000	.000	.000
P OPTION	15 (55)	ALL	ALL	ALL	ALL	ALL	TAIL	ALL	ALL
Y OPTION	16 (56)	ALL	ALL	TAIL	ALL	ALL	TAIL	ALL	ALL
TRAN PLS	17 (57)	0.100	0.100	0.100	0.100	0.100	0.100	0.100	0.100
ALT									
RATE DB	18 (58)	0.200	0.200	0.070	0.200	0.070	0.070	0.100	0.100
JET OPT	19 (59)	ALL	ALL	ALL	ALL	ALL	TAIL	ALL	ALL
# JETS	20 (60)	2	2	1	2	1	1	2	2
ON TIME	21 (61)	0.08	0.08	0.08	0.08	0.08	0.08	0.08	0.08
DELAY	22 (62)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
VERN									
ROT RATE	23 (63)	0.2000	0.4000	0.0080	0.2000	0.0500	0.0500	0.0160	0.0500
ATT DB	24 (64)	1.000	1.000	0.070	1.000	1.000	1.000	1.000	1.000
RATE DB	25 (65)	.020	.020	.010	.020	.020	.020	.020	.020
ROT PLS	26 (66)	0.010	0.010	0.010	0.010	0.010	0.010	0.010	0.050
COMP	27 (67)	.000	.000	.000	.000	.000	.000	.000	.000
CNTL ACC	28 (68)	0	0	0	0	0	0	0	0
PURPOSE		NOMINAL	PTC	GG	PREPOST DEPLOY	LOSS OF VERN (ALL)	LOSS OF VERN (TAIL ONLY)	RNDZ	TERMINAL PHASE

BOLD/ITALIC indicates change from I-Load.

HINGE

NOT FLOWN

FS CC 10-8

ORB OPS/124/FIN

(reduced copy)

TOP
HINGED AT BOTTOM OF
'STS-124 DAP A1 – DAP A8 CONFIGURATIONS'
HINGE

STS-124 DAP B1 – DAP B8 CONFIGURATIONS

	ITEM #	B1	B2	B3	B4	B5	B6	B7	B8
PRI									
ROT RATE	30 (50)	0.5000	0.2000	0.2000	0.2000	0.2000	0.5000	0.5000	0.0500
ATT DB	31 (51)	3.00	3.00	3.00	0.30	3.00	3.00	2.00	2.00
RATE DB	32 (52)	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20
ROT PLS	33 (53)	0.040	0.040	0.040	0.040	0.040	0.040	0.040	0.040
COMP	34 (54)	.000	.000	.000	.000	.000	.000	.000	.000
P OPTION	35 (55)	ALL	TAIL	ALL	TAIL	TAIL	ALL	ALL	ALL
Y OPTION	36 (56)	ALL	TAIL	ALL	TAIL	TAIL	ALL	ALL	ALL
TRAN PLS	37 (57)	0.100	0.020	0.020	0.020	0.020	0.020	0.050	0.050
ALT									
RATE DB	38 (58)	0.200	0.070	0.070	0.100	0.200	0.200	0.100	0.100
JET OPT	39 (59)	ALL	TAIL	ALL	ALL	ALL	ALL	ALL	ALL
# JETS	40 (60)	2	1	1	2	2	2	2	2
ON TIME	41 (61)	0.08	0.08	0.08	0.08	0.08	0.08	0.08	0.08
DELAY	42 (62)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
VERN									
ROT RATE	43 (63)	0.2000	0.2000	0.2000	0.0080	0.0160	0.2000	0.2000	0.0500
ATT DB	44 (64)	1.000	1.000	1.000	0.100	0.033	1.000	1.000	1.000
RATE DB	45 (65)	.020	.020	.020	.010	.020	.020	.020	.020
ROT PLS	46 (66)	0.002	0.002	0.002	0.002	0.002	0.002	0.002	0.020
COMP	47 (67)	.000	.000	.000	.000	.000	.000	.000	.000
CNTL ACC	48 (68)	0	0	0	0	0	0	0	0
PURPOSE		OMS & RCS Burns (ORB OPS)	Loss of VERN (Tail Only)	Loss of VERN (All)		COASHUD CAL		RNDZ	TERMINAL PHASE

BOLD/ITALIC indicates change from I-Load.

HOOK
VELCRO

ORB OPS-41aa/124/O/A

HOOK
VELCRO

NOT FLOWN

FS CC 10-9

ORB OPS/124/FIN

(reduced copy)

TOP
BACK OF 'STS-124 DAP A1 – DAP A8 CONFIGURATIONS'

PILE
VELCRO

ORB OPS-41b/124/O/C

PILE
VELCRO

STS-124 DAP A9 – DAP A14 CONFIGURATIONS

	ITEM #	A9	A10	A11	A12	A14
PRI						
ROT RATE	10 (50)	0.1300	0.0500	0.0500	0.0500	0.2000
ATT DB	11 (51)	2.00	0.60	10.00	5.00	5.00
RATE DB	12 (52)	0.10	0.10	0.20	0.20	0.20
ROT PLS	13 (53)	0.100	0.100	0.100	0.040	0.100
COMP	14 (54)	.000	.000	.000	.000	.000
P OPTION	15 (55)	TAIL	TAIL	TAIL	TAIL	TAIL
Y OPTION	16 (56)	TAIL	TAIL	TAIL	TAIL	TAIL
TRAN PLS	17 (57)	0.050	0.050	0.100	0.010	0.100
ALT						
RATE DB	18 (58)	0.100	0.100	0.035 ¹	0.035 ¹	0.200
JET OPT	19 (59)	TAIL	TAIL	TAIL	TAIL	TAIL
# JETS	20 (60)	2	2	1	1	1
ON TIME	21 (61)	0.08	0.08	0.08	0.08	0.08
DELAY	22 (62)	0.00	0.00	6.00	6.00	6.00
VERN						
ROT RATE	23 (63)	0.1300	0.0500	0.1000	0.1000	0.2000
ATT DB	24 (64)	1.000	0.500	5.000	3.000	3.000
RATE DB	25 (65)	.020	.020	.050	.050	.200
ROT PLS	26 (66)	0.050	0.050	0.010	0.002	0.010
COMP	27 (67)	.000	.000	.000	.000	.000
CNTL ACC	28 (68)	0	0	6²	6²	1
PURPOSE		PROX OPS FLYAROUND	DOCKING	AUTO REBOOST	MATED STACK (VRCS & ALT) ³	ORBITER ALONE SRMS/OBSS

BOLD/ITALIC indicates change from I-Load.

¹ I-loaded below keyboard limit; do not change

² Assumes ATV is docked to SM aft position. See DAP Overview for Cntl Acc applicability

³ VRCS for maneuvers and attitude hold. ALT for maneuvers and a maximum 15 min of attitude hold

HINGE

NOT FLOWN

FS CC 10-10

ORB OPS/124/FIN

(reduced copy)

TOP
BACK OF 'STS-124 DAP B1 – DAP B8 CONFIGURATIONS'
HINGED AT BOTTOM OF 'STS-124 DAP A9 – DAP A14 CONFIGURATIONS'
HINGE

STS-124 DAP B9 – DAP B12 CONFIGURATIONS

	ITEM #	B9	B10	B12
PRI				
ROT RATE	30 (50)	0.1300	0.0500	0.0500
ATT DB	31 (51)	2.00	0.60	5.00
RATE DB	32 (52)	0.10	0.10	0.20
ROT PLS	33 (53)	0.040	0.040	0.040
COMP	34 (54)	.000	.000	.000
P OPTION	35 (55)	TAIL	TAIL	TAIL
Y OPTION	36 (56)	TAIL	TAIL	TAIL
TRAN PLS	37 (57)	0.010	0.010	0.010
ALT				
RATE DB	38 (58)	0.100	0.100	0.035 ¹
JET OPT	39 (59)	TAIL	TAIL	TAIL
# JETS	40 (60)	2	2	1
ON TIME	41 (61)	0.08	0.08	0.08
DELAY	42 (62)	10.00	0.00	11.04
VERN				
ROT RATE	43 (63)	0.1300	0.0500	0.1000
ATT DB	44 (64)	1.000	0.500	3.000
RATE DB	45 (65)	.020	.020	.050
ROT PLS	46 (66)	0.020	0.020	0.002
COMP	47 (67)	.000	.000	.000
CNTL ACC	48 (68)	0	0	6 ²
PURPOSE		PROX OPS/ FLYAROUND	DOCKING	MATED STACK (VRCS & ALT) ³

BOLD/ITALIC indicates change from I-Load.

¹ I-loaded below keyboard limit; do not change

² Assumes ATV is docked to SM aft position. See DAP Overview for Cntl Acc applicability

³ VRCS for maneuvers and attitude hold. ALT for attitude hold only

HOOK
VELCRO

ORB OPS-41bb/124/O/C

HOOK
VELCRO

TOP

MAUI – RCS FIRING SEQUENCE

Timer	Jets Fired	CDR	PLT
-03:00		Body rates: $+0.047 \leq \text{roll} \leq +0.087$ $-0.020 \leq \text{pitch} \leq +0.020$ $-0.020 \leq \text{yaw} \leq +0.020$ DAP: FREE DAP: A/PRI Inform PLT "GO" for jet deselections	Configure initial setup [GNC 23 RCS] Left RCS page – ITEM 2 EXEC On CDR "GO", proceed NOTE Expect DAP RECONF msgs in following actions Deselect jets: JET DES L5L – ITEM 37 EXEC (*) Right RCS page – ITEM 3 EXEC JET DES R5D – ITEM 39 EXEC (*) Forward RCS page – ITEM 1 EXEC JET DES F5L – ITEM 37 EXEC (*) NOTE Queue the following ITEM entry on the scratch pad. Do not perform the EXEC until specified at 35 sec JET DES F3D – ITEM 25
-00:30		FLT CNTRL PWR – ON	
00:00	RXA, LXA	THC +X (in) (3 sec firing)	
00:15	FXL, LXL	THC +Y (right) (3 sec firing)	
00:30	FXR, RXR	THC -Y (left) (3 sec firing)	
00:35			When jets stop firing: [GNC 23 RCS] EXEC [JET DES F3D – ITEM 25 (*)]
00:45	F4D	RHC +pitch (hard stop, hold 3 sec)	
00:48		RHC release	
00:50			DAP: VERN
01:00	R5R	RHC +yaw (10 sec firing)	
01:20	L5D	RHC -pitch (12 sec firing)	
01:40	F5R	RHC +pitch (12 sec firing)	
		FLT CNTRL PWR – OFF	Return to MAUI PROCEDURE, step 6, (ORB OPS FS, MAUI)


ORB OPS-42a/124/O/A

(reduced copy)



NOT FLOWN

FS CC 10-11

ORB OPS/124/FIN



TOP
BACK OF 'MAUI - RCS FIRING SEQUENCE'



ORB OPS-42b/124/O/A



NOT FLOWN

(reduced copy)
FS CC 10-12

ORB OPS/124/FIN

TOP

MIDODRINE PILL INGESTION

NO GO

If ANY of the conditions below are true, then you are NO GO for pill ingestion:

1. Midodrine PI/Crew Surgeon has given a "NO GO"
2. Taken promethazine/Phenergan or phenDex in the last 70 hrs.
3. Taken any medication that effects the autonomic nervous system within 24 hrs.
4. Performed maximum exercise in the last 24 hrs.
5. Taken nicotine, caffeine, or alcohol in the last 12 hrs.

GO

LOCATION	STEP
Midodrine Pill Kit	Between TIG and landing, ingest 10 mg dose (1 tablet) of midodrine with liquid NOTE In the event the midodrine pill is lost, a backup dose is located beneath the first pill
	Record time of ingestion: <input type="checkbox"/> GMT <input type="checkbox"/> MET
ACES right leg pocket	Stow kit.

ORB OPS-45a/E/C

FABRICATION NOTES

- 1) Fabricate as a kneeboard card

(reduced copy)

NOT FLOWN

FS CC 10-13

ORB OPS/124/FIN




This Page Intentionally Blank



NOT FLOWN

FS 10-14

ORB OPS/124/FIN



Space Shuttle Program
FLIGHT DATA FILE

JSC-48036-124
FINAL



ORBIT OPS CHECKLIST

STS
124

Flight Cover (trim bottom to expose tabs)